

SECTION

EX

EX

EXHAUST SYSTEM

CONTENTS

PRECAUTION	2	EXHAUST SYSTEM	4
PRECAUTIONS	2	Inspection	4
Removal and Installation	2	REMOVAL AND INSTALLATION	5
PREPARATION	3	EXHAUST SYSTEM	5
PREPARATION	3	Exploded View	5
Commercial Service Tool	3	Removal and Installation	5
PERIODIC MAINTENANCE	4	Inspection	6

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Removal and Installation

INFOID:000000008462089

CAUTION:

- Be sure to use genuine exhaust system parts or equivalents which are specially designed for heat resistance, corrosion resistance, and shape.
- Perform the operation with the exhaust system fully cooled down because the system will be hot just after engine stops.
- Be careful not to cut your hand on the heat insulator edge.

PREPARATION

< PREPARATION >

PREPARATION


PREPARATION

Commercial Service Tool

INFOID:0000000008462090

A

EX

Tool name	Description
Power tool	Loosening nuts and bolts
 PBIC0190E	

C

D

E

F

G

H

I

J

K

L

M

N

O

P

EXHAUST SYSTEM

< PERIODIC MAINTENANCE >

PERIODIC MAINTENANCE


EXHAUST SYSTEM

Inspection

INFOID:000000008462091

Check exhaust pipes, muffler, and mounting for improper attachment, leakage, cracks, damage or deterioration.

- If anything is found, repair or replace damaged parts.



SMA211A

EXHAUST SYSTEM


< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION

EXHAUST SYSTEM

Exploded View

INFOID:000000008462092



- | | | |
|------------------------|--------------------|--------------------|
| 1. Main muffler | 2. Mounting rubber | 3. Gasket |
| 4. Mounting rubber | 5. Center muffler | 6. Dynamic damper |
| 7. Mounting rubber | 8. Gasket | 9. Mounting rubber |
| 10. Exhaust front tube | 11. Gasket | |

: N·m (kg-m, ft-lb)

: Always replace after every disassembly.

Removal and Installation

INFOID:000000008462093

REMOVAL

Disconnect each joint and mounting using power tool.

INSTALLATION

Note the following, and install in the reverse order of removal.

- If exhaust front tube stud bolts were removed, and install them and tighten to the specified torque below.

: **14.7 N·m (1.5 kg-m, 11 ft-lb)**

CAUTION:

- Always replace exhaust tube gaskets with new ones when reassembling.
- If heat insulator is badly deformed, repair or replace it. If deposits such as mud pile up on the heat insulator, remove them.

EXHAUST SYSTEM

< REMOVAL AND INSTALLATION >

- When installing heat insulator avoid large gaps or interference between heat insulator and each exhaust pipe.
- Remove deposits from the sealing surface of each connection. Connect them securely to avoid gases leakage.
- Temporarily tighten mounting nuts and bolts. Check each part for unusual interference, and then tighten them to the specified torque.
- When installing each mounting rubber, avoid twisting or unusual extension in up/down and right/left directions.

Inspection

INFOID:0000000008462094

INSPECTION AFTER INSTALLATION

- Check clearance between tail tube and rear bumper is even.
- With engine running, check exhaust tube joints for gas leakage and unusual noises.
- Check to ensure that mounting brackets and mounting rubbers are installed properly and free from undue stress. Improper installation could result in excessive noise and vibration.