


DAC Indicator Light does not Come ON

WIRING DIAGRAM

See page [BC-271](#).

1 CHECK DAC INDICATOR LIGHT

Skid Control ECU
(harness side connector):



C121700E24

OK

- Disconnect the skid control ECU connector.
- Turn the ignition switch to the ON position.
- Ground terminal HDCW of the skid control ECU.
- Check DAC indicator light.

OK

HDCW - GND Condition	Illumination Condition
Connecting	OFF
Disconnecting	ON


- Turn the ignition switch to OFF.
- Reconnect the skid control ECU connector.

NG

Go to step 3

2 INSPECT DAC SWITCH

DAC Switch:



H

I044044E02

- Remove the DAC switch.
- Disconnect the DAC switch connector.
- Measure the resistance.

Standard

Tester Connection	Switch Condition	Specified Condition
D8-3 - D8-4	Released	10 kΩ or higher
D8-3 - D8-4	Pushed in	Below 1 Ω

- Reconnect the DAC switch connector.
- Reinstall the DAC switch connector.


NG

REPLACE DAC SWITCH

OK

3

CHECK HARNESS AND CONNECTOR (SKID CONTROL ECU - DAC SWITCH)



- (a) Disconnect the skid control ECU connector.
- (b) Disconnect the DAC switch connector.
- (c) Measure the resistance.

Standard

Tester Connection	Specified Condition
S1-44 (HDCS) - D8-3	Below 1 Ω
S1-44 (HDCS) - Body ground	10 kΩ or higher
D8-4 - Body ground	Below 1 Ω

- (d) Reconnect the DAC switch connector.
- (e) Reconnect the skid control ECU connector.

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR


OK

REPLACE MASTER CYLINDER SOLENOID

4

CHECK HARNESS AND CONNECTOR (SKID CONTROL ECU - COMBINATION METER)

BC



- (a) Disconnect the skid control ECU connector.
- (b) Disconnect the combination meter connector.
- (c) Measure the resistance.

Standard

Tester Connection	Specified Condition
S1-33 (HDCW) - C10-13	Below 1 Ω
S1-33 (HDCW) - Body ground	10 kΩ or higher

- (d) Reconnect the combination meter connector.
- (e) Reconnect the skid control ECU connector.

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

5 INSPECT COMBINATION METER ASSEMBLY

(a) Check the combination meter system (See page [ME-8](#)).

OK:

Combination meter is normal.

NG

**REPLACE COMBINATION METER
ASSEMBLY**

OK

CHECK FOR INTERMITTENT PROBLEMS