

FRONT & REAR AXLE

SECTION **AX**


CONTENTS

FRONT AXLE	2	INSPECTION.....	14
Precautions	2	ASSEMBLY	14
PRECAUTIONS	2	Service Data and Specifications (SDS).....	19
Preparation	2	DRIVE SHAFT	19
SPECIAL SERVICE TOOLS	2	DYNAMIC DAMPER (WHERE FITTED)	20
COMMERCIAL SERVICE TOOLS.....	2	WHEEL BEARING (FRONT)	20
Noise, Vibration and Harshness (NVH)		REAR AXLE	21
Troubleshooting	3	Precautions	21
NVH TROUBLESHOOTING CHART	3	PRECAUTIONS	21
On-vehicle Service.....	3	Preparation	21
FRONT AXLE PARTS	3	SPECIAL SERVICE TOOLS	21
FRONT WHEEL BEARING	3	COMMERCIAL SERVICE TOOLS.....	21
DRIVE SHAFT	4	Noise, Vibration and Harshness (NVH)	
Wheel Hub and Knuckle.....	5	Troubleshooting	22
COMPONENTS	5	On-vehicle Service.....	22
REMOVAL.....	5	REAR AXLE PARTS.....	22
INSTALLATION.....	7	REAR WHEEL BEARING	22
DISASSEMBLY.....	7	Wheel Hub	23
INSPECTION.....	8	COMPONENTS	23
ASSEMBLY	8	REMOVAL.....	23
Drive Shaft	10	INSTALLATION.....	24
COMPONENTS	10	Service Data and Specifications (SDS).....	26
REMOVAL.....	11	WHEEL BEARING (REAR)	26
INSTALLATION.....	11		
DISASSEMBLY	12		

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

FRONT AXLE

Precautions



Precautions

PRECAUTIONS

NLAX0001

- When installing rubber parts, final tightening must be carried out under unladen condition* with tires on ground.
- *: Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.
- After installing removed suspension parts, check wheel alignment and adjust if necessary.
- Use flare nut wrench when removing or installing brake tubes.
- Always torque brake lines when installing.

Preparation

SPECIAL SERVICE TOOLS

NLAX0002

Tool number Tool name	Description
HT72520000 Ball joint remover	NT146 Removing tie-rod outer end and lower ball joint
KV38106800 Differential side oil seal protector	NT147 Installing drive shaft
KV40107300 Boot band tool	ZZA1229D Installing boot bands

COMMERCIAL SERVICE TOOLS

NLAX0003

Tool name	Description
1 Flare nut crowfoot 2 Torque wrench	NT360 Removing and installing each brake piping a: 10 mm (0.39 in)

FRONT AXLE

Noise, Vibration and Harshness (NVH) Troubleshooting

Noise, Vibration and Harshness (NVH) Troubleshooting

=NLAX0004


NVH TROUBLESHOOTING CHART

NLAX0004S01

Use the chart below to help you find the cause of the symptom. If necessary, repair or replace these parts.

Reference page			—	AX-14	—	AX-5, 23	—	AX-3, 22	—	—	SU-4	SU-4	SU-4	BR-9	ST-5
Possible cause and SUSPECTED PARTS			Excessive joint angle	Joint sliding resistance	Imbalance	Improper installation, looseness	Parts interference	Wheel bearing damage	DRIVE SHAFT	AXLE	SUSPENSION	TIRES	ROAD WHEEL	BRAKES	STEERING
Symptom	DRIVE SHAFT	Noise, Vibration	×	×						×	×	×	×	×	×
		Shake	×		×					×	×	×	×	×	×
	AXLE	Noise				×	×		×		×	×	×	×	×
		Shake				×	×		×		×	×	×	×	×
		Vibration				×	×		×		×	×			×
		Shimmy				×	×				×	×	×	×	×
		Judder				×					×	×	×	×	×
		Poor quality ride or handling				×	×	×			×	×	×		

×: Applicable



On-vehicle Service

FRONT AXLE PARTS

NLAX0005

Check front axle and front suspension parts for excessive play, cracks, wear or other damage.

- Shake each front wheel to check for excessive play.
- Make sure that cotter pin is inserted.
- Retighten all axle and suspension nuts and bolts to the specified torque.

Tightening torque:

Refer to SU-4, "FRONT SUSPENSION".

FRONT WHEEL BEARING

NLAX0006


- Check that wheel bearings operate smoothly.
- Check axial end play.

Axial end play:

0.05 mm (0.0020 in)


If out of specification or wheel bearing does not turn smoothly, replace wheel bearing assembly.

Refer to "Wheel Hub and Knuckle", "FRONT AXLE", AX-5.



FRONT AXLE

On-vehicle Service (Cont'd)



DRIVE SHAFT


Check for grease leakage or other damage.

NLAX0007

Wheel Hub and Knuckle COMPONENTS

=NLAX0008

SEC. 430




- | | | |
|--------------------------------|---------------------------|---------------------------|
| 1. Drive shaft | 5. Wheel bearing assembly | 9. Wheel bearing lock nut |
| 2. Knuckle | 6. Snap ring | 10. Cotter pin |
| 3. Baffle plate (where fitted) | 7. Hub bolt | 11. Brake disc |
| 4. ABS sensor | 8. Wheel hub | 12. Wheel nut |

REMOVAL

NLAX0009

CAUTION:

Before removing the front axle assembly, disconnect the ABS wheel sensor from the assembly. Then move it away from the front axle assembly area. Failure to do so may result in damage to the sensor wires and the sensor becoming inoperative.




SFA090A

1. Remove wheel bearing lock nut.

FRONT AXLE


Wheel Hub and Knuckle (Cont'd)



2. Remove brake caliper assembly and rotor.


Brake hose need not be disconnected from brake caliper. In this case, suspend caliper assembly with wire so as not to stretch brake hose. Be careful not to depress brake pedal, or piston will pop out.

Make sure brake hose is not twisted.




3. Separate tie-rod from knuckle with Tool.

Install stud nut on stud bolt to prevent damage to stud bolt.




4. Separate drive shaft from knuckle by lightly tapping it. If it is hard to remove, use a puller.

Cover boots with shop towel so as not to damage them when removing drive shaft.



5. Remove strut lower mounting bolts.



6. Loosen lower ball joint tightening nut.


7. Separate knuckle from lower ball joint stud with Tool.

8. Remove knuckle from transverse link.

FRONT AXLE

Wheel Hub and Knuckle (Cont'd)

NLAX0010



SFA114A

INSTALLATION

1. Install knuckle with wheel hub.

When installing knuckle to strut, be sure to hold bolts and tighten nuts.

⚙️ : 140 - 160 N·m (14 - 16 kg-m, 103 - 118 ft-lb)

Before tightening, apply oil to threaded portion of drive shaft.

2. Tighten wheel bearing lock nut.


⚙️ : 255 - 333 N·m (26 - 34 kg-m, 188 - 246 ft-lb)

3. Make sure that wheel bearings operate smoothly.


4. Check wheel bearing axial end play.

Axial end play:

0.05 mm (0.0020 in)



SFA543A



SFA116A

DISASSEMBLY

NLAX0011


CAUTION:

When removing wheel hub or wheel bearing from knuckle, replace wheel bearing assembly (outer race and inner races) with a new one.

Wheel Hub

NLAX0011S01

Drive out hub with inner race (outside) from knuckle with a suitable tool.




SFA654A

Wheel Bearing

NLAX0011S02

When replacing wheel bearing, replace complete wheel bearing assembly (Inner races and outer race).

1. Remove bearing inner race (outside).




SAX008

2. Remove snap rings.

FRONT AXLE

Wheel Hub and Knuckle (Cont'd)



3. Press out bearing outer race.

INSPECTION

Wheel Hub and Knuckle

Check wheel hub and knuckle for cracks by using a magnetic exploration or dyeing test.


Snap Ring

Check snap ring for wear or cracks. Replace if necessary.

NLAX0012

NLAX0012S01


NLAX0012S02



ASSEMBLY

- When removing baffle plate, replace it with a new one.
- When installing the baffle plate, press new plate so that it is in contact with knuckle wall. Refer to figure at left.

NLAX0013



1. Install inner snap ring into groove of knuckle.
2. Press new wheel bearing assembly into knuckle until it contacts steering knuckle.


Maximum load P:

29 kN (3 ton, 3.3 US ton, 3.0 Imp ton)

CAUTION:

- Do not press inner race of wheel bearing assembly.
- Do not apply oil or grease to mating surfaces of wheel bearing outer race and knuckle.

3. Install outer snap ring into groove of knuckle.




4. Press wheel hub into knuckle until it stops when the end of the wheel bearing is hit.

Maximum load P:

29 kN (3 ton, 3.3 US ton, 3.0 Imp ton)

FRONT AXLE

Wheel Hub and Knuckle (Cont'd)



5. Check bearing operation.
 - a. Add load P with press.

Load P:
49.0 kN
(5.0 ton, 5.5 US ton, 4.92 Imp ton)
 - b. Spin knuckle several turns in both directions.
 - c. Make sure that wheel bearings operate smoothly.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

FRONT AXLE

Drive Shaft

Drive Shaft COMPONENTS

=NLAX0016



SEC. 391

Circular clip:

Circular clips should be properly meshed with differential side gear (transaxle side) and with joint assembly (wheel side).
Make sure they will not come out.

Be careful not to damage boots. Use suitable protector or cloth during removal and installation.



TS79C, T79C, GI2300I &
GI3300I



D90
Left drive shaft

Transaxle side

Wheel side ZF90, B90, AC2300I & AC3300I




YD
Right drive shaft

: N•m (kg-m, ft-lb)

YAX010

- | | | |
|---------------------------------------|-------------------------|--|
| 1. Joint assembly | 11. Inner race | 21. Slide joint housing with extension shaft |
| 2. Boot | 12. Cage | 22. Dust shield |
| 3. Boot band | 13. Ball | 23. Snap ring |
| 4. Circular clip | 14. Snap ring | 24. Support bearing |
| 5. Drive shaft | 15. Slide joint housing | 25. Support bearing retainer |
| 6. Dynamic damper band (where fitted) | 16. Circular clip | 26. Bracket |
| 7. Dynamic damper (where fitted) | 17. Spider assembly | 27. Snap ring |
| 8. Boot | 18. Snap ring | 28. Dust shield |
| 9. Boot band | 19. Slide joint housing | |
| 10. Stopper ring | 20. Circular clip | |


NLAX0014




REMOVAL

1. Remove wheel bearing lock nut.


Brake caliper need not be disconnected. Do not twist or stretch brake hose when moving components.




2. Remove strut lower mount bolts.
3. Remove brake hose clip.



4. Separate drive shaft from knuckle by lightly tapping it. If it is hard to remove, use a puller.
Cover boots with shop towel so as not to damage them when removing drive shaft.
Refer to "Wheel Hub and Knuckle", "FRONT AXLE", AX-5.
5. Remove right drive shaft from transaxle.



6. Remove left drive shaft from transaxle.
- Pry off drive shaft from transaxle as shown at left.



INSTALLATION

Transaxle Side

NLAX0015


NLAX0015S01

1. Drive a new oil seal to transaxle. Refer to MT-16 (5MT), MT-11 (6MT) or AT-413.
2. Set Tool along the inner circumference of oil seal.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

FRONT AXLE

Drive Shaft (Cont'd)




3. Insert drive shaft into transaxle. Be sure to properly align the serrations and then withdraw Tool.
4. Push the drive shaft until the circular clip on the drive shaft fits into the circular clip groove of the side gear.
5. After its insertion, try to pull the flange out of the slide joint by hand. If it pulls out, the circular clip is not properly meshed with the side gear.

Wheel Side

NLAX0015S02

- Install drive shaft into knuckle.
- Tighten upper knuckle nut and wheel bearing lock nut. Refer to section Installation in "Wheel Hub and Knuckle", "FRONT AXLE", AX-5.




DISASSEMBLY

NLAX0017

Transaxle Side (D90 — types)


NLAX0017S01

1. Remove boot bands.
2. Put matching marks on slide joint housing and inner race, before separating joint assembly.
3. Remove stopper ring with a screwdriver, and pull out slide joint housing.



4. Put matching marks on inner race and drive shaft.
5. Remove snap ring, then remove ball cage, inner race and balls as a unit.
6. Draw out boot.

Cover drive shaft serrations with tape so as not to damage the boot.




Transaxle Side (TS79C, T79C, GI2300I & GI3300I)

NLAX0017S04

1. Remove boot bands.
2. Put matching marks on slide joint housing and drive shaft before separating joint assembly.
3. Put matching marks on spider assembly and drive shaft.

FRONT AXLE

Drive Shaft (Cont'd)




4. Pry off snap ring, then remove spider assembly.

CAUTION:

Do not disassemble spider assembly.

5. Draw out boot.

Cover drive shaft serration with tape to prevent damage to the boot.



Wheel Side (ZF90, B90, AC2300I & AC3300I)

NLAX0017S02


1. Before separating joint assembly, put matching marks on drive shaft and joint assembly.

2. Separate joint assembly with a suitable tool.

Be careful not to damage threads on drive shaft.

3. Remove boot bands.


4. Draw out boot.




Support Bearing

NLAX0017S03

1. Remove dust shield.



2. Remove snap ring.



3. Press support bearing assembly off of drive shaft.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX

FRONT AXLE

Drive Shaft (Cont'd)



4. Separate support bearing from retainer.

INSPECTION

Thoroughly clean all parts in cleaning solvent, and dry with compressed air. Check parts for evidence of deformation or other damage.

NLAX0018

Drive Shaft

Replace drive shaft if it is twisted or cracked.

NLAX0018S01

Boot

Check boot for fatigue, cracks or wear. Replace boot with new boot bands.

NLAX0018S02

Joint Assembly (Transaxle side)

- Check spider assembly for needle bearing and washer damage. Replace if necessary. (Tripod type)
- Check roller surfaces for scratches, wear or other damage. Replace if necessary. (Tripod type)
- Replace any parts of double offset joint which show signs of scorching, rust, wear or excessive play. (Double offset type)
- Check serration for deformation. Replace if necessary.
- Check slide joint housing for any damage. Replace if necessary.

NLAX0018S03

Joint Assembly (Wheel side)

Replace joint assembly if it is deformed or damaged.

NLAX0018S04

Support Bearing

Make sure wheel bearing rolls freely and is free from noise, cracks, pitting or wear.

NLAX0018S05

Support Bearing Bracket


Check support bearing bracket for cracks with a magnetic exploration or dyeing test.

NLAX0018S06

ASSEMBLY

- After drive shaft has been assembled, ensure that it moves smoothly over its entire range without binding.
- Use grease according to AX-19, SDS.

NLAX0019




Wheel Side (ZF90, B90, AC2300I & AC3300I)


NLAX0019S01

1. Install boot and new small boot band on drive shaft.

Cover drive shaft serration with tape so as not to damage boot during installation.



2. Set joint assembly onto drive shaft by lightly tapping it. Install joint assembly securely, ensuring marks which were made during disassembly are properly aligned.



3. Pack drive shaft with specified amount of grease.


Specified amount of grease:

Refer to AX-19, SDS.

4. Make sure that boot is properly installed on the drive shaft groove. Set boot so that it does not swell and deform when its length is "L₁".

Length "L₁":


Refer to AX-19, SDS.



5. Lock new larger and smaller boot bands.

- Boot bands type A

- a) Lock new larger and smaller boot bands securely with a suitable tool.




- Boot bands type B

- a) As shown in the figure, secure the big and small ends of the boot with new boot bands.

FRONT AXLE

Drive Shaft (Cont'd)




- b) Rotate joint part and confirm that mounting position of boot does not deviate. When it deviates, mount a new boot band again.

CAUTION:

When fixing boot band, fix so that the diameter "M" on the figure becomes as follows.

Diameter "M": 5 mm (0.20 in)




Dynamic Damper (where fitted)

NLAX0019S02

1. Use new damper bands when installing.
2. Install dynamic damper from stationary-joint side while holding it securely.

Length:

Refer to AX-20, SDS.




Transaxle Side (D90)


NLAX0019S03

1. Install boot and new small boot band on drive shaft.

Cover drive shaft serration with tape so as not to damage boot during installation.



2. Install ball cage, inner race and balls or spider assembly as a unit, making sure the marks which were made during disassembly are properly aligned.
3. Install new snap ring.



4. Pack drive shaft with specified amount of grease.


Specified amount of grease:

Refer to AX-19, SDS.


5. Install slide joint housing, then install new snap ring.
6. Make sure that boot is properly installed on the drive shaft groove.
Set boot so that it does not swell and deform when its length is "L₂".

Length "L₂":

Refer to AX-19, SDS.



7. Lock new larger and smaller boot bands securely with a suitable tool.




Transaxle Side (TS79C, T79C, GI2300I & GI3300I)


NLAX0019S05

1. Install boot and new small boot band on drive shaft.

Cover drive shaft serration with tape so as not to damage boot during installation.



2. Install spider assembly securely, making sure the marks which were made during disassembly are properly aligned.
3. Install new snap ring.




4. Pack drive shaft with specified amount of grease.

Specified amount of grease:

Refer to AX-19, SDS.

5. Install slide joint housing.
6. Set boot so that it does not swell and deform when its length is "L₂":

Refer to AX-19, SDS.




Make sure that the boot is properly installed on the drive shaft groove.

7. Lock new larger and smaller boot bands.
 - Boot bands type A
- a) Lock new larger and smaller boot bands securely with a suitable tool.


GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

FRONT AXLE

Drive Shaft (Cont'd)




- Boot bands type B
- a) As shown in the figure, secure the big and small ends of the boot with new boot bands.



- b) Rotate joint part and confirm that mounting position of boot does not deviate. When it deviates, mount a new boot band again.

CAUTION:
When fixing boot band, fix so that the diameter "M" on the figure becomes as follows.


Diameter "M": 5 mm (0.20 in)




Support Bearing

NLAX0019S04

- Press bearing into retainer.



- Press drive shaft into bearing.



- Install snap ring.
- Install new dust shield.

FRONT AXLE

Service Data and Specifications (SDS)


Service Data and Specifications (SDS)

DRIVE SHAFT


=NLAX0020

		QG			YD	
		M/T models	A/T models		5 M/T models	6 M/T models
			LH	RH		
Joint type	Transaxle side	GI2300I	T79C	TS79C	D90	GI3300I
Grease	Quality	39709-BM500	39709-2U600		39709-BM500	*2
Joint type	Wheel side	AC2300I	ZF90		B90	AC3300I
Grease	Quality	Nissan genuine grease or equivalent	39209-2U600		Nissan genuine grease or equivalent	*3
Grease Capacity g (oz)	Transaxle side	125.5 - 135.5 (4.42 - 4.77)	155 - 165 (5.47 - 5.82)		145 - 165 (5.11 - 5.82)	167 - 177 (5.89 - 6.24)
	Wheel side	40 - 50 (1.41 - 1.76)	115 - 125 (4.06 - 4.41)	93 - 103 (3.28 - 3.63)	120 - 140 (4.41 - 4.94)	110 - 130 (3.88 - 4.59)*4
Boot length mm (in)	Transaxle side "L ₂ "	98 - 100 (3.86 - 3.94)*1	101.5 - 103.5 (4.00 - 4.07)*1		98 (3.86)*1	*1
	Wheel side "L ₁ "	94 - 96 (3.70 - 3.78)*1	94.1 - 96.1 (3.705 - 3.783)*1		110 (4.33)	*1

Transaxle side



Wheel side



SFA961AA

SFA962A

*1: Fit boot to boot groove in bar shaft

*2: GKN-ONE LUBER C grease or Nissan genuine grease or equivalent

*3: GKN HTBJ grease or Nissan genuine grease or equivalent

*4: Preload the grease 45 to 55 g (1.59 to 1.94 oz) before assembling boot and shaft. After assembling boot and shaft, inject the grease 65 to 75 g (2.29 to 2.65 oz).


FRONT AXLE

Service Data and Specifications (SDS) (Cont'd)

DYNAMIC DAMPER (WHERE FITTED)

^{=NLAX0033}
Unit: mm (in)

		QG				YD	
		M/T models		A/T models			
		LH	RH	LH	RH	LH	RH
Distance	“A”	178 - 184 (7.01 - 7.24)	375 - 381 (14.76 - 15.00)	—	398 (15.67)	172 - 178 (6.77 - 7.01)	190 -196 (7.48 - 7.72)
	“B”	64 (2.52)		—	70 (2.76)	70 (2.76)	70 (2.76)



SAX015


WHEEL BEARING (FRONT)

NLAX0021

Wheel bearing axial end play limit mm (in)	0.05 (0.0020)
Wheel bearing lock nut tightening torque N·m (kg-m, ft-lb)	255 - 333 (26 - 34, 188 - 245)

REAR AXLE

Precautions



Precautions

PRECAUTIONS

- When installing each rubber part, final tightening must be carried out under unladen condition* with tires on ground. *: Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.
- Use flare nut wrench when removing or installing brake tubes.
- After installing removed suspension parts, check wheel alignment.
- Do not jack up at the trailing arm and lateral link.
- Always torque brake lines when installing.

NLAX0022

GI

MA

EM

LC

EC

FE

CL

MT

Preparation

SPECIAL SERVICE TOOLS

NLAX0032

Tool number Tool name	Description
KV40104710 Drift	Install ABS sensor rotor a: 76.3 mm (3.004 in) dia. b: 67.9 mm (2.673 in) dia. NT474
ST3072000 Drift	Install ABS sensor rotor a: 77 mm (3.03 in) dia. b: 55.5 mm (2.185 in) dia. NT115

AT

AX

SU

BR

ST

RS

COMMERCIAL SERVICE TOOLS

NLAX0024

Tool name	Description
1 Flare nut crowfoot 2 Torque wrench	Removing and installing brake piping a: 10 mm (0.39 in) NT360

BT

HA

SC

EL


IDX

REAR AXLE

Noise, Vibration and Harshness (NVH) Troubleshooting

Refer to "Noise, Vibration and Harshness (NVH) Troubleshooting", "FRONT AXLE", AX-3.

NLAX0025



SMA525A


On-vehicle Service

REAR AXLE PARTS

Check axle and suspension parts for excessive play, wear or damage.

NLAX0026

- Shake each rear wheel to check for excessive play.



SRA690A

REAR WHEEL BEARING


NLAX0027

- Check axial end play.
Axial end play:
0.05 mm (0.0020 in)
- Check that wheel hub bearings operate smoothly.
- Check tightening torque of wheel bearing lock nut.
⚙ : 187 - 254 N·m (19 - 26 kg-m, 138 - 188 ft-lb)
- Replace wheel bearing assembly if there is axial end play or wheel bearing does not turn smoothly. Refer to "Wheel Hub", "REAR AXLE", AX-23.

Wheel Hub COMPONENTS

NLAX0028

SEC. 430



NAX001

- | | | |
|---------------------|---------------------------|---------------|
| 1. Spindle | 4. Wheel hub bearing | 6. Hub cap |
| 2. Baffle plate | 5. Wheel bearing lock nut | 7. ABS sensor |
| 3. ABS sensor rotor | | |


REMOVAL

CAUTION:

- Before removing the rear wheel hub assembly, disconnect the ABS wheel sensor from the assembly. Then move it away from the hub assembly. Failure to do so may result in damage to the sensor wires and the sensor becoming inoperative.
- Wheel hub bearing does not require maintenance. If any of the following symptoms are noted, replace wheel hub bearing assembly.
 - Growling noise is emitted from wheel hub bearing during operation.
 - Wheel hub bearing drags or turns roughly. This occurs when turning hub by hand after bearing lock nut is tightened to specified torque.

REAR AXLE

Wheel Hub (Cont'd)




1. Remove brake caliper assembly.
2. Remove wheel bearing lock nut.
3. Remove brake rotor (models with disk brake) or brake drum (models with drum brakes).
4. Remove wheel hub bearing from spindle.


CAUTION:

Do not disconnect brake hose from caliper.

- Suspend caliper assembly with wire so as not to stretch brake hose.
 - Be careful not to depress brake pedal, or piston will pop out.
- Make sure brake hose is not twisted.




5. Remove the sensor rotor using suitable puller, drift and bearing replacer.



INSTALLATION

- With vehicles equipped with ABS, press-fit ABS sensor rotor into wheel hub bearing using a drift. **Do not reuse ABS sensor rotor. When installing, replace it with a new one.**

NLAX0030




- Press-fit ABS sensor rotor as far as the location shown in figure at left.

Height "h":

12.5 - 13.5 mm (0.492 - 0.531 in)

REAR AXLE


Wheel Hub (Cont'd)



- Install wheel hub bearing.
- Tighten wheel bearing lock nut.
Before tightening, apply oil to threaded portion of rear spindle.
Do not reuse wheel bearing lock nut.


 : 187 - 254 N·m (19 - 26 kg-m, 138 - 188 ft-lb)

- Check that wheel bearings operate smoothly.




- Check wheel hub bearing axial end play.

Axial end play:
0.05 mm (0.0020 in)



- Clinch two places of lock nut.



- Install hub cap using a suitable tool.
Do not reuse hub cap. When installing, replace it with a new one.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

REAR AXLE

Service Data and Specifications (SDS)

Service Data and Specifications (SDS)

WHEEL BEARING (REAR)

=NLAX0031

Wheel bearing axial end play mm (in)	0.05 (0.0020)
Wheel bearing lock nut tightening torque N·m (kg-m, ft-lb)	187 - 254 (19 - 26, 138 - 188)