

tc

2015

QUICK REFERENCE GUIDE

GET INFORMED.
ROLL.



what moves you

2015 Scion tC

This *Quick Reference Guide* is a summary of basic vehicle operations. It contains brief descriptions of fundamental operations so you can locate and use the vehicle's main equipment quickly and easily.

The *Quick Reference Guide* is not intended as a substitute for the *Owner's Manual* located in the vehicle's glove box. We strongly encourage you to review the *Owner's Manual* and supplementary manuals so you will have a better understanding of the vehicle's capabilities and limitations.

Your dealership and the entire staff of Scion, a marque of Toyota Motor Sales, U.S.A., Inc., wish you many years of satisfied driving in your new Scion tC.

A word about safe vehicle operation

This *Quick Reference Guide* is not a full description of Scion tC operations. Every Scion tC owner should review the *Owner's Manual* that accompanies this vehicle.

Pay special attention to the boxed information highlighted in color throughout the *Owner's Manual*. Each box contains safe operating instructions to help you avoid injury or equipment malfunction.

All information in this *Quick Reference Guide* is current at the time of printing. Toyota reserves the right to make changes at any time without notice.

INDEX

OVERVIEW

Auto lock/unlock	7
Engine maintenance	8
Fuel tank door opener and cap	7
Hood release	8
Indicator symbols	4-5
Instrument cluster	4
Instrument panel	2-3
Keyless entry	6

FEATURES/OPERATIONS

Air Conditioning/Heating	14
Automatic Transmission	9
AUX port/USB port	14
Bottle holders	15
Clock	13
Cruise control	11
Cup holders	15
Light control-Instrument panel	13
Lights & turn signals	11
Moonroof	12
Parking brake	9
Power outlet	15
Seat adjustments-Front	10
Seat adjustments-Rear	10
Seats-Head restraints	10
Steering wheel switches	15
Tilt steering wheel	9
Windows	13
Windshield wipers & washers	12

SAFETY AND

EMERGENCY FEATURES

Door locks	16
Floor mat installation	19
Seat belts	16
Spare tire & tools	17
Star Safety System™	18-19
Tire Pressure Monitoring (warning) System	16


OVERVIEW

FEATURES/OPERATIONS


SAFETY AND EMERGENCY FEATURES

OVERVIEW

Instrument panel



- ① Power outside rearview mirror controls
- ② Hood release
- ③ Headlight and turn signal controls
- ④ Paddle shift switches¹
- ⑤ Wiper and washer controls
- ⑥ Cruise control¹
- ⑦ Ignition switch (standard key)
- ⑧ Steering wheel audio controls²
- ⑨ Air Conditioning controls




- ⑩ Rear window defogger switch
- ⑪ Emergency flasher switch
- ⑫ Clock
- ⑬ Clock adjustment buttons
- ⑭ Front passenger occupant classification indicator
- ⑮ Engine immobilizer system indicator¹
- ⑯ Power outlet
- ⑰ Tilt and telescopic steering lock release

¹ If equipped

² For details, refer to the *SCION Audio Manual* or *Scion.com*.

Instrument cluster



- ① Tachometer
- ② Service indicator and reminder
- ③ Fuel gauge
- ④ Automatic Transmission shift position indicator (if equipped)
- ⑤ Speedometer
- ⑥ Odometer/Trip meter display change button
- ⑦ Odometer/Trip meter display
- ⑧ Low fuel level warning
- ⑨ Instrument panel light control knob

Indicator symbols

For details, refer to “Indicators and warning lights,” Section 2-2, 2015 *Owner’s Manual*.

	Brake system warning ¹
	Seat belt reminder (alarm will sound if speed is over 12 mph)
	Charging system warning ¹
	Malfunction/Check Engine indicator ¹
	Low engine oil pressure warning ¹
	Open door warning
	AIR BAG ON and AIR BAG OFF indicator

¹ If indicator does not turn off within a few seconds of starting engine, there may be a malfunction. Have vehicle inspected by your Toyota or Scion dealer.

	Airbag SRS warning ¹
	Low Tire Pressure Warning ¹
	Engine oil replacement reminder ¹
	Turn signal indicators
	Headlight low/high beam indicator
	Cruise control indicator ²
	Cruise control "SET" indicator
	Anti-lock Brake System warning ¹
	High coolant temperature warning ¹
	Electric power steering system warning ¹
	Slip indicator ¹
	Low fuel level warning
	Automatic Transmission fluid temperature warning ¹
	Vehicle Stability Control OFF indicator ¹
	ECO driving indicator ¹
	Engine immobilizer system indicator
	Low engine coolant temperature indicator
	Traction Control OFF indicator ¹

² If this light flashes, refer to "Cruise control" Section 2-4, 2015 Owner's Manual.

Keyless entry

Locking operation



Push 

Unlocking operation



Push ONCE: Driver door
TWICE: All doors 


NOTE: If a door is not opened within 60 seconds of unlocking, all doors will relock for safety.

Panic button



Push and hold 


Fuel tank door opener and cap



NOTE: Tighten cap until one click is heard. If the cap is not tightened enough, Check Engine "CHECK" indicator may illuminate.



Auto lock/unlock

Automatic door locks can be programmed to operate in four different modes, or turned OFF.


- Doors lock when shifting from Park (Automatic Transmission only).
- Doors lock when the vehicle speed goes above approximately 12 mph.
- Doors unlock when shifting into Park (Automatic Transmission only).
- Doors unlock when the ignition switch is set from "ON" to "ACC" or "LOCK" and driver's door is opened.

Refer to the *Owner's Manual* for more details.

Hood release



Engine maintenance




- ❶ Windshield washer fluid tank
- ❷ Engine coolant reservoir
- ❸ Engine oil filler cap
- ❹ Engine oil level dipstick

NOTE: Regularly scheduled maintenance, including oil changes, will help extend the life of your vehicle and maintain performance. Please refer to the "Warranty Maintenance Guide."

FEATURES/OPERATIONS

OVERVIEW

Automatic Transmission (if equipped)




P	Park*
R	Reverse
N	Neutral
D	Drive
S	“S” mode


* The ignition switch must be “ON” and the brake pedal depressed to shift from Park.

Downshifting increases power going uphill, or provides engine braking downhill. For best fuel economy during normal driving conditions, always drive with the shift lever in the “D” position.

FEATURES/OPERATIONS

Tilt steering wheel








Lock release lever

Hold wheel, push lever down, set angle and length, and return lever.

NOTE: Do not attempt to adjust while the vehicle is in motion.

Parking brake




Set	Release
 Pull	 (2) Push (1) Pull slightly (3) Lower

BRAKE


SAFETY AND EMERGENCY FEATURES

Seat adjustments-Front




- 1 Seat position (forward/backward)
- 2 Height crank (driver side only)
- 3 Seatback angle
- 4 Seatback lock release

Seat adjustments-Rear




Seats-Head restraints




Cruise control (if equipped)

Turning system ON/OFF



Functions




¹ The set speed may also be cancelled by depressing the brake pedal.


² The set speed may be resumed once vehicle speed reaches 25 mph.

Lights & turn signals

Headlights




Turn signals




Windshield wipers & washers


Front



Intermittent windshield wiper frequency adjustment




Rear (if equipped)



Moonroof


Opening operation

Push once to tilt up; again to open





Closing operation

Push once to partially close; again to fully close





Windows

Driver door window controls





Window lock switch



Automatic operation (driver's window) Push the switch completely down or pull it completely up and release to fully open or close. To stop the window partway, operate the switch in the opposite direction.


Window lock switch Deactivates all passenger windows. Driver's window remains operable.

Light control-Instrument panel



Brightness control

Clock




H ☐

M ☐


H-Hour set
M-Minute set

Air Conditioning/Heating



- ① Airflow vent
“ ” mode uses fresh air (“ ” indicator OFF) to reduce window fogging.
- ② Fan speed
- ③ Temperature selector
- ④ Air Conditioning ON/OFF
- ⑤ Rear window defogger
- ⑥ Windshield airflow
- ⑦ Recirculate cabin air (fresh air when OFF)

AUX port/USB port



AUX port


By inserting a mini plug (not included) into the AUX port, you can listen to music from a portable audio device through the vehicle's speaker system while in AUX mode.

USB port

By connecting a USB memory or USB-compatible portable audio device to the USB port, you can listen to music from the portable audio device or USB memory through the vehicle's speaker system.

Refer to the *SCION Audio Manual* or *Scion.com* for more details.

Steering wheel switches



1 “MODE”


Push to turn audio ON and select an audio mode. Push and hold to turn audio system OFF.

2 “V A”

Use to search within the selected audio medium (radio, CD, iPod®, etc.).


Refer to the *SCION Audio System Owner's Manual* or the *SCION Navigation System Owner's Manual* for more details.

Power outlet




Designed for car accessories. Ignition switch must be in the “ACC” or “ON” position for use.

Cup holders




Bottle holders

Front




Rear




SAFETY AND EMERGENCY FEATURES

Door locks




Seat belts



If belt is fully extended, then retracted even slightly, it cannot be re-extended beyond that point, unless fully retracted again. This feature is used to help hold child restraint systems securely.

To find more information about seat belts, and how to install a child restraint system, refer to the *Owner's Manual*.

Tire Pressure Monitoring (warning) System




After adjusting tire pressures, or after tires have been rotated or replaced, turn the ignition switch to "ON" and press and hold the "SET" button until indicator blinks three times. Then allow the vehicle to sit for a few minutes to allow initialization to complete.

Refer to the load label on the door jamb or the *Owner's Manual* for tire inflation specifications.


If the tire pressure indicator flashes for more than 60 seconds and then remains on, take the vehicle to your local Toyota or Scion dealer.

Spare tire & tools

Tool location



Removing the spare tire



- (1) Remove the spare tire cover.
- (2) Loosen and remove the bolt.

Refer to the *Owner's Manual* for jack positioning and tire changing procedures.

SAFETY AND EMERGENCY FEATURES

Star Safety System™

All new Toyota vehicles come standard with the Star Safety System™, which combines Vehicle Stability Control (VSC), Traction Control (TRAC), Anti-lock Braking System (ABS), Electronic Brake-force Distribution (EBD), Brake Assist (BA) and Smart Stop Technology (SST).

Vehicle Stability Control (VSC)

VSC helps prevent loss of traction during cornering by reducing engine power and applying brake force to selected wheels.

Toyota's VSC monitors steering angle and the direction your vehicle is traveling. When it senses that the front or rear wheels begin to lose traction, VSC reduces engine power and applies braking to selected wheels. This helps restore traction and vehicle control.

Traction Control (TRAC)

VSC helps prevent loss of traction during cornering by reducing engine power, and Traction Control helps maintain traction on loose gravel and wet, icy, or uneven surfaces by applying brake force to the spinning wheel(s).

Toyota's TRAC sensors are activated when one of the drive wheels starts to slip. TRAC limits engine output and applies the brakes to the spinning wheel. This transfers power to the wheels that still have traction to help keep you on track.

Brake Assist (BA)

Brake Assist is designed to detect sudden or "panic" braking, and then add braking pressure to help decrease the vehicle's stopping distance. When there's only a split second to react, Brake Assist can add additional brake pressure more quickly than just the driver alone can.

Electronic Brake Force Distribution (EBD)

Toyota's ABS technology has Electronic Brake-force Distribution (EBD) to help maintain control and balance when braking. Abrupt stops can cause a vehicle to tilt forward, reducing the braking power of the rear wheels. EBD responds to sudden stops by redistributing brake force to enhance the braking effectiveness of all four wheels.

Anti-Lock Brake System (ABS)

ABS helps prevent brakes from locking up by "pulsing" brake pressure to each wheel. This limits brake lockup and helps provide directional control for the current road conditions.

Toyota's ABS sensors detect which wheels are locking up and limits wheel lockup by "pulsing" each wheel's brakes independently. Pulsing releases brake pressure repeatedly for fractions of a second. This helps the tires attain the traction that current road conditions will allow, helping you to stay in directional control.

Smart Stop Technology (SST)

Smart Stop Technology automatically reduces engine power when the accelerator and brake pedals are pressed simultaneously under certain conditions.

SST engages when the accelerator is depressed first and the brakes are applied firmly for longer than one-half second at speeds greater than five miles per hour.


SST doesn't engage if the brake pedal is depressed before the accelerator pedal, allowing vehicles to start on a steep hill and safely accelerate without rolling backward.

Floor mat installation

There are two types of Toyota floor mats: carpeted and all-weather. Each vehicle has model-specific floor mats. Installation is easy.

To keep your floor mat properly positioned, follow these steps:

- Only use floor mats designed for your specific model.
- Use only one floor mat at a time, using the retaining hooks to keep the mat in place.
- Install floor mats right side up.



EMAIL

www.scion.com

→ Contact

-

CHAT

www.scion.com

→ Have a Question?

→ Contact

-

PHONE

1.866.70.SCION

-

MAIL

SCION

19001 S. Western Ave.

D102, P.O. Box 2742

Torrance, CA 90509-2742

USA

-

WEB

www.scion.com

-

