

PCS

SECTION

POWER CONTROL SYSTEM

CONTENTS

IPDM E/R	DTC/CIRCUIT DIAGNOSIS	26
PRECAUTION	U1000 CAN COMM CIRCUIT	26
PRECAUTIONS	Description	26
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	DTC Logic	26
	Diagnosis Procedure	26
SYSTEM DESCRIPTION	B2098 IGNITION RELAY ON STUCK	27
COMPONENT PARTS	DTC Logic	27
Component Parts Location	Diagnosis Procedure	27
SYSTEM	B2099 IGNITION RELAY OFF STUCK	28
RELAY CONTROL SYSTEM	DTC Logic	28
RELAY CONTROL SYSTEM : System Description	Diagnosis Procedure	28
RELAY CONTROL SYSTEM : Fail-safe	POWER SUPPLY AND GROUND CIRCUIT	29
POWER CONSUMPTION CONTROL SYSTEM	Diagnosis Procedure	29
POWER CONSUMPTION CONTROL SYSTEM : System Description	REMOVAL AND INSTALLATION	30
DIAGNOSIS SYSTEM (IPDM E/R)	IPDM E/R	30
Diagnosis Description	Exploded View	30
CONSULT Function (IPDM E/R)	Removal and Installation	30
ECU DIAGNOSIS INFORMATION	POWER DISTRIBUTION SYSTEM	
IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	PRECAUTION	32
Reference Value	PRECAUTIONS	32
Fail-safe	Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	32
DTC Index	SYSTEM DESCRIPTION	33
WIRING DIAGRAM	COMPONENT PARTS	33
IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	Component Parts Location	33
Wiring Diagram	SYSTEM	34
	POWER DISTRIBUTION SYSTEM	34
	POWER DISTRIBUTION SYSTEM : System Description	34

DIAGNOSIS SYSTEM (BCM)	36	B2616 IGNITION RELAY CIRCUIT	57
COMMON ITEM	36	DTC Logic	57
COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)	36	Diagnosis Procedure	57
INTELLIGENT KEY	36	Component Inspection	58
INTELLIGENT KEY : CONSULT Function (BCM - INTELLIGENT KEY)	37	B2618 BCM	59
ECU DIAGNOSIS INFORMATION	40	DTC Logic	59
BCM	40	Diagnosis Procedure	59
List of ECU Reference	40	B261A PUSH-BUTTON IGNITION SWITCH	61
WIRING DIAGRAM	41	DTC Logic	61
POWER DISTRIBUTION SYSTEM	41	Diagnosis Procedure	61
Wiring Diagram	41	B26F1 IGNITION RELAY	63
BASIC INSPECTION	48	DTC Logic	63
DIAGNOSIS AND REPAIR WORK FLOW	48	Diagnosis Procedure	63
Work Flow	48	B26F2 IGNITION RELAY	65
DTC/CIRCUIT DIAGNOSIS	51	DTC Logic	65
U1000 CAN COMM CIRCUIT	51	Diagnosis Procedure	65
Description	51	B26F6 BCM	67
DTC Logic	51	DTC Logic	67
Diagnosis Procedure	51	Diagnosis Procedure	67
U1010 CONTROL UNIT (CAN)	52	PUSH-BUTTON IGNITION SWITCH	69
DTC Logic	52	Component Function Check	69
Diagnosis Procedure	52	Diagnosis Procedure	69
B2614 ACC RELAY CIRCUIT	53	Component Inspection	70
DTC Logic	53	SYMPTOM DIAGNOSIS	72
Diagnosis Procedure	53	PUSH-BUTTON IGNITION SWITCH DOES NOT OPERATE	72
Component Inspection	54	Description	72
B2615 BLOWER RELAY CIRCUIT	55	Diagnosis Procedure	72
DTC Logic	55	REMOVAL AND INSTALLATION	73
Diagnosis Procedure	55	BCM (BODY CONTROL MODULE)	73
Component Inspection	56	Removal and Installation	73
		PUSH-BUTTON IGNITION SWITCH	74
		Removal and Installation	74

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000009607429

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P


PCS

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:000000009567560



- 1. IPDM E/R
- A. Engine compartment (LH)


SYSTEM

RELAY CONTROL SYSTEM

RELAY CONTROL SYSTEM : System Description

INFOID:000000009567562

SYSTEM DIAGRAM



DESCRIPTION

IPDM E/R activates the internal control circuit to perform the relay ON-OFF control according to the input signals from various sensors and the request signals received from control units via CAN communication.

CAUTION:

IPDM E/R integrated relays cannot be removed.

SYSTEM

< SYSTEM DESCRIPTION >

[IPDM E/R]

Control relay	Input/output	Transmit unit	Control part	Reference page
- Headlamp low relay - Headlamp high relay	- Low beam request signal - High beam request signal	BCM (CAN)	- Headlamp LO - Headlamp HI	EXL-8
Tail lamp relay	Position light request signal	BCM (CAN)	- Parking lamp - License plate lamp - Tail lamp	EXL-10
			Illuminations	INL-8
- Front wiper relay - Front wiper high relay	Front wiper request signal	BCM (CAN)	Front wiper motor	WW-8
	Front wiper stop position signal	Front wiper motor		
Starter control relay	Starter control relay signal	BCM (CAN)	Starter motor	STR-6
	Transmission range switch signal (CVT models)	Transmission range switch		
	Clutch interlock switch signal (M/T models)	Clutch interlock switch		
- Cooling fan low relay - Cooling fan high relay	Cooling fan speed request signal	ECM (CAN)	Cooling fan	EC-35
A/C relay	A/C compressor request signal	ECM (CAN)	A/C compressor (Magnet clutch)	HAC-13
Ignition relay	Ignition switch ON signal	BCM (CAN)	Each control unit, sensor, actuator and relay (Ignition power supply)	EC-32
	Vehicle speed signal (Meter)	Combination meter (CAN)		
	Push-button ignition switch signal	Push-button ignition switch		

RELAY CONTROL SYSTEM : Fail-safe

INFOID:000000009667165

CAN COMMUNICATION CONTROL

When CAN communication with ECM and BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.

If No CAN Communication Is Available With ECM

Control part	Fail-safe operation
Cooling fan	- The cooling fan relay turn ON when the ignition switch is turned ON (Cooling fan HI operation) - The cooling fan relay turn OFF when the ignition switch is turned OFF
A/C compressor	A/C relay OFF

If No CAN Communication Is Available With BCM

Control part	Fail-safe operation
Headlamp	- Turns ON the headlamp low relay when the ignition switch is turned ON - Turns OFF the headlamp low relay when the ignition switch is turned OFF - Headlamp high relay OFF
- Parking lamp - License plate lamp - Illumination - Tail lamp	- Turns ON the tail lamp relay when the ignition switch is turned ON - Turns OFF the tail lamp relay when the ignition switch is turned OFF
Front wiper motor	- The status just before activation of fail-safe control is maintained until the ignition switch is turned OFF while the front wiper is operating at LO or HI speed. - The wiper is operated at LO speed until the ignition switch is turned OFF if the fail-safe control is activated while the front wiper is set in the INT mode and the front wiper motor is operating. - Returns automatically wiper to stop position when ignition switch is turned ON if fail-safe control is activated while front wiper motor is operated and wiper stop in the other position than stop position.
Front fog lamp	Front fog lamp relay OFF

SYSTEM

< SYSTEM DESCRIPTION >

[IPDM E/R]

Control part	Fail-safe operation
Horn	Horn OFF
Ignition relay	The status just before activation of fail-safe is maintained.
Starter motor	Starter control relay OFF

IGNITION RELAY MALFUNCTION DETECTION FUNCTION

- IPDM E/R monitors the voltage at the contact circuit and excitation coil circuit of the ignition relay inside it.
- IPDM E/R judges the ignition relay error if the voltage differs between the contact circuit and the excitation coil circuit.
- If the ignition relay cannot turn OFF due to contact seizure, it activates the tail lamp relay for 10 minutes to alert the user to the ignition relay malfunction when the ignition switch is turned OFF.

DTC	Ignition switch	Ignition relay	Tail lamp relay
—	ON	ON	—
—	OFF	OFF	—
B2098: IGN RELAY ON	OFF	ON	ON (10 minutes)
B2099: IGN RELAY OFF	ON	OFF	—

NOTE:

The tail lamp turns OFF when the ignition switch is turned ON.

FRONT WIPER CONTROL

IPDM E/R detects front wiper stop position by a front wiper auto stop signal.

When a front wiper auto stop signal is in the conditions listed below, IPDM E/R stops power supply to wiper after repeating a front wiper 10 second activation and 20 second stop five times.

Ignition switch	Front wiper switch	Auto stop signal
ON	OFF	Front wiper stop position signal cannot be input 10 seconds.
	ON	The signal does not change for 10 seconds.

NOTE:

This operation status can be confirmed on the IPDM E/R “Data Monitor” that displays “BLOCK” for the item “WIP PROT” while the wiper is stopped.

STARTER MOTOR PROTECTION FUNCTION

IPDM E/R turns OFF the starter control relay to protect the starter motor when the starter control relay remains active for 90 seconds.


POWER CONSUMPTION CONTROL SYSTEM

POWER CONSUMPTION CONTROL SYSTEM : System Description

INFOID:000000009567564

PCS

SYSTEM DIAGRAM



DESCRIPTION

Outline

- IPDM E/R incorporates a power consumption control function that reduces the power consumption according to the vehicle status.
- IPDM E/R changes its status (control mode) with the sleep wake up signal received from BCM via CAN communication.

Normal mode (wake-up)

- CAN communication is normally performed with other control units.
- Individual unit control by IPDM E/R is normally performed.

Low power consumption mode (sleep)

- Low power consumption control is active.
- CAN transmission is stopped.

Sleep Mode Activation

- IPDM E/R judges that the sleep-ready conditions are fulfilled when the ignition switch is OFF and none of the conditions below are present. Then it transmits a sleep-ready signal (ready) to BCM via CAN communication.
- Outputting signals to actuators
- Switches or relays operating
- Output requests are being received from control units via CAN communication.
- IPDM E/R stops CAN communication and enters the low power consumption mode when it receives a sleep wake up signal (sleep) from BCM and the sleep-ready conditions are fulfilled.

Wake-up Operation

- IPDM E/R changes from the low power consumption mode to the normal mode when it receives a sleep wake-up signal (wake up) from BCM or any of the following conditions is fulfilled. In addition, it transmits a sleep-ready signal (not-ready) to BCM via CAN communication to report the CAN communication start.
- Ignition switch ON
- An output request is received from a control unit via CAN communication.

DIAGNOSIS SYSTEM (IPDM E/R)

Diagnosis Description

INFOID:000000009567565

AUTO ACTIVE TEST

Description

In auto active test, the IPDM E/R sends a drive signal to the following systems to check their operation.

- Front wiper (LO, HI)
- Parking lamp
- License plate lamp
- Tail lamp
- Front fog lamp
- Headlamp (LO, HI)
- A/C compressor (magnet clutch)
- Cooling fan

Operation Procedure

NOTE:

Never perform auto active test in the following conditions.

- Passenger door is open
- CONSULT is connected

1. Close the hood and lift the wiper arms from the windshield. (Prevent windshield damage due to wiper operation)

NOTE:

When auto active test is performed with hood opened, sprinkle water on windshield beforehand.

2. Turn the ignition switch OFF.
3. Turn the ignition switch ON, and within 20 seconds, press the driver door switch 10 times. Then turn the ignition switch OFF.
4. Turn the ignition switch ON within 10 seconds. After that the horn sounds once and the auto active test starts.
5. After a series of the following operations is repeated 3 times, auto active test is completed.

NOTE:

- When auto active test has to be cancelled halfway through test, turn the ignition switch OFF.
- When auto active test is not activated, door switch may be the cause. Check door switch. Refer to [DLK-84, "Component Function Check"](#).

Inspection in Auto Active Test

When auto active test is actuated, the following operation sequence is repeated 3 times.


Operation sequence	Inspection location	Operation
1	Front wiper	LO for 5 seconds → HI for 5 seconds
2	• Parking lamp • License plate lamp • Tail lamp • Front fog lamp	10 seconds
3	Headlamp	LO for 10 seconds → HI ON ⇔ OFF 5 times
4	A/C compressor (magnet clutch)	ON ⇔ OFF 5 times
5	Cooling fan	LO for 5 seconds → MID for 3 seconds → HI for 2 seconds

DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

[IPDM E/R]

Concept of Auto Active Test



- IPDM E/R starts the auto active test with the door switch signals transmitted by BCM via CAN communication. Therefore, the CAN communication line between IPDM E/R and BCM is considered normal if the auto active test starts successfully.
- The auto active test facilitates troubleshooting if any systems controlled by IPDM E/R cannot be operated.

Diagnosis Chart in Auto Active Test

Symptom	Inspection contents	Possible cause
Any of the following components do not operate • Parking lamp • License plate lamp • Tail lamp • Front fog lamp • Headlamp (HI, LO) • Front wiper (HI, LO)	Perform auto active test. Does the applicable system operate?	YES BCM signal input circuit
		NO • Lamp or motor • Lamp or motor ground circuit • Harness or connector between IPDM E/R and applicable system • IPDM E/R
A/C compressor does not operate	Perform auto active test. Does the magnet clutch operate?	YES • BCM signal input circuit • CAN communication signal between BCM and ECM • CAN communication signal between ECM and IPDM E/R
		NO • Magnet clutch • Harness or connector between IPDM E/R and magnet clutch • IPDM E/R
Cooling fan does not operate	Perform auto active test. Does the cooling fan operate?	YES • ECM signal input circuit • CAN communication signal between ECM and IPDM E/R
		NO • Cooling fan motor • Harness or connector between IPDM E/R and cooling fan motor • IPDM E/R

CONSULT Function (IPDM E/R)

INFOID:000000009567566

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with IPDM E/R.

Direct Diagnostic Mode	Description
Ecu Identification	The IPDM E/R part number is displayed.
Self Diagnostic Result	The IPDM E/R self diagnostic results are displayed.
Data Monitor	The IPDM E/R input/output data is displayed in real time.

DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

[IPDM E/R]

Direct Diagnostic Mode	Description
Active Test	The IPDM E/R activates outputs to test components.
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

ECU IDENTIFICATION

The IPDM E/R part number is displayed.

SELF DIAGNOSTIC RESULT

Refer to [PCS-20, "DTC Index"](#).

DATA MONITOR

Monitor Item [Unit]	Main Signals	Description
MOTOR FAN REQ [%]	×	Indicates cooling fan speed signal received from ECM on CAN communication line
AC COMP REQ [On/Off]	×	Indicates A/C compressor request signal received from ECM on CAN communication line
TAIL&CLR REQ [On/Off]	×	Indicates position light request signal received from BCM on CAN communication line
HL LO REQ [On/Off]	×	Indicates low beam request signal received from BCM on CAN communication line
HL HI REQ [On/Off]	×	Indicates high beam request signal received from BCM on CAN communication line
FR FOG REQ [On/Off]	×	Indicates front fog light request signal received from BCM on CAN communication line
FR WIP REQ [Stop/1LOW/Low/Hi]	×	Indicates front wiper request signal received from BCM on CAN communication line
WIP AUTO STOP [STOP P/ACT P]	×	Indicates condition of front wiper auto stop signal
WIP PROT [Off/BLOCK]	×	Indicates condition of front wiper fail-safe operation
IGN RLY1 -REQ [On/Off]		Indicates ignition switch ON signal received from BCM on CAN communication line
IGN RLY [On/Off]	×	Indicates condition of ignition relay
PUSH SW [On/Off]		Indicates condition of push-button ignition switch
INTER/NP SW [On/Off]		Indicates condition of CVT shift position
ST RLY CONT [On/Off]		Indicates starter relay status signal received from BCM on CAN communication line
IHBT RLY -REQ [On/Off]		Indicates starter control relay signal received from BCM on CAN communication line
ST/INHI RLY [Off/ ST /INHI]		Indicates condition of starter relay and starter control relay
DETENT SW [On/Off]		Indicates condition of CVT shift selector (park position switch)
DTRL REQ [Off]		Indicates daytime light request signal received from BCM on CAN communication line
HOOD SW [On/Off]		Indicates condition of hood switch
THFT HRN REQ [On/Off]		Indicates theft warning horn request signal received from BCM on CAN communication line
HORN CHIRP [On/Off]		Indicates horn reminder signal received from BCM on CAN communication line

ACTIVE TEST

Test item	Description
HORN	This test is able to check horn operation [On].
FRONT WIPER	This test is able to check wiper motor operation [Hi/Low/Off].

DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

[IPDM E/R]

Test item	Description
MOTOR FAN	This test is able to check cooling fan operation [4/3/2/1].
EXTERNAL LAMPS	This test is able to check external lamp operation [Fog/Hi/Lo/TAIL/Off].

CAN DIAG SUPPORT MNTR

Refer to [LAN-12. "CAN Diagnostic Support Monitor"](#).

ECU DIAGNOSIS INFORMATION

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Reference Value

INFOID:000000009567567

VALUES ON THE DIAGNOSIS TOOL

Monitor Item	Condition		Value/Status
MOTOR FAN REQ	Engine idle speed	Changes depending on engine coolant temperature, air conditioner operation status, vehicle speed, etc.	1/2/3/4
AC COMP REQ	Engine running	A/C switch OFF	Off
		A/C switch ON (Compressor is operating)	On
TAIL&CLR REQ	Lighting switch OFF		Off
	Lighting switch 1ST or 2ND		On
HL LO REQ	Lighting switch OFF		Off
	Lighting switch 2ND		On
HL HI REQ	Lighting switch 2ND	Lighting switch other than HI and PASS	Off
		Lighting switch HI or PASS	On
FR FOG REQ	Lighting switch 2ND	Front fog lamp switch OFF	Off
		Front fog lamp switch ON	On
FR WIP REQ	Ignition switch ON	Front wiper switch OFF	Stop
		Front wiper switch INT	1LOW
		Front wiper switch LO	Low
		Front wiper switch HI	Hi
WIP AUTO STOP	Ignition switch ON	Front wiper stop position	STOP P
		Any position other than front wiper stop position	ACT P
WIP PROT	Ignition switch ON	Front wiper operates normally.	Off
		Front wiper stops at fail-safe operation.	BLOCK
IGN RLY1 -REQ	Ignition switch OFF or ACC		Off
	Ignition switch ON		On
IGN RLY	Ignition switch OFF or ACC		Off
	Ignition switch ON		On
PUSH SW	Release the push-button ignition switch		Off
	Press the push-button ignition switch		On
INTER/NP SW	Ignition switch ON	Selector lever in any position other than P or N (CVT models)	Off
		Release clutch pedal (M/T models)	
		Selector lever in P or N position (CVT models)	On
		Depress clutch pedal (M/T models)	
ST RLY CONT	Ignition switch ON		Off
	At engine cranking		On

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

[IPDM E/R]


Monitor Item	Condition		Value/Status
IHBT RLY -REQ	Ignition switch ON		Off
	At engine cranking		On
ST/INHI RLY	Ignition switch ON		Off
	At engine cranking		INHI ON → ST ON
	The status of starter relay or starter control relay cannot be recognized by the battery voltage malfunction, etc. when the starter relay is ON and the starter control relay is OFF.		UNKWN
DETENT SW	Ignition switch ON	• Press the selector button with selector lever in P position. • Selector lever in any position other than P.	Off
	Release the selector button with selector lever in P position.		On
DTRL REQ	Daytime running lamps OFF		Off
	Daytime running lamps ON		On
HOOD SW	Hood closed		Off
	Hood open		On
THFT HRN REQ	Not operation		Off
	• Panic alarm is activated • Theft warning alarm is activated		On
HORN CHIRP	Not operated		Off
	Door locking with keyfob (horn chirp mode)		On

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

[IPDM E/R]

TERMINAL LAYOUT



PHYSICAL VALUES

Terminal	Wire color	Circuit	Input/Output	Ignition switch	Condition	Value
1	R	Battery power supply	Input	OFF	—	9 – 16 V
2	Y	Battery power supply	Input	OFF	—	9 – 16 V
3	SB	Ignition switch power supply (START)	Input	OFF ACC ON	—	0V
				START	—	9 – 16 V
5	Y	Cooling fan power supply (HIGH)	Output	ON or START	Cooling fan OFF	0V
					Cooling fan LO	4 – 8 V
					Cooling fan MID or HI	9 – 16 V
6	R	Starter motor power supply	Output	OFF ACC ON	—	0V
				START	—	6 – 16 V

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

[IPDM E/R]

Terminal	Wire color	Circuit	Input/ Output	Ignition switch	Condition	Value
7	P	Cooling fan power supply (LOW)	Output	ON or START	Cooling fan OFF	0V
					Cooling fan LO	9 – 16 V
					Cooling fan MID	4 – 8 V
					Cooling fan HI	9 – 16 V
8	G	Battery power supply	Input	OFF	—	9 – 16 V
9	BR	Fuel pump power supply	Output	ON RUN	Approximately 1 second after turning the ignition switch ON	9 – 16 V
				ON	Approximately 1 second after turning the ignition switch ON	0 - 1 V
11	G	ECM relay power supply	Output	OFF	More than a few seconds after turning ignition switch OFF	0 – 1 V
				ON OFF	For a few seconds after turning ignition switch OFF	6 – 16 V
13	R	Clutch interlock switch power supply	Input	ON	Clutch pedal depressed	0 – 1 V
					Clutch pedal released	9 – 16 V
14	L	Headlamp LOW (LH) power supply	Output		Lighting switch OFF	0 – 1 V
					Lighting switch 2ND	9 – 16 V
15	LG	Starter relay coil power supply	Input			0 – 1 V
						9 – 16 V
16	P	Headlamp LOW (RH) power supply	Output		Lighting switch OFF	0 – 1 V
					Lighting switch 2ND	9 – 16 V
17	LG	Front wiper motor LOW power supply	Output	ON	Front wiper switch OFF	0 – 1 V
					Front wiper switch LO	9 – 16 V
18	GR	Front wiper motor HIGH power supply	Output	ON	Front wiper switch OFF	0 – 1 V
					Front wiper switch HI	9 – 16 V
19	B	Ground	—	—	—	—
20	BR	ABS actuator and electric unit (control unit) power supply	Output	OFF	—	0V
				ON or START	—	9 – 16 V
21	R	Transmission range switch power supply	Output	OFF or ACC		0 – 1 V
				ON		9 – 16 V
22	P	Illumination power supply	Output		Lighting switch OFF	0 – 1 V
					Lighting switch 1ST	9 – 16 V
23	R	Combination lamp power supply	Output		Lighting switch OFF	0 – 1 V
					Lighting switch 1ST	9 – 16 V
24	W	Daytime light relay 1 power supply	Output		Lighting switch OFF	0 – 1 V
					Lighting switch 1ST	9 – 16 V
25	G	Headlamp HIGH (LH) power supply	Output		Lighting switch other than HI and PASS	0 – 1 V
					Lighting switch HI Lighting switch PASS	9 – 16 V

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

[IPDM E/R]

Terminal	Wire color	Circuit	Input/ Output	Ignition switch	Condition	Value
27	Y	Headlamp HIGH (RH) power supply	Output		Lighting switch other than HI and PASS	0 – 1 V
					Lighting switch HI Lighting switch PASS	9 – 16 V
28	V	A/C compressor power supply	Output	RUN	A/C switch OFF	0 – 1 V
					A/C switch ON (A/C compressor is operating)	9 – 16 V
29	L/W	Throttle control motor relay power supply	Output	OFF	More than a few seconds after turning ignition switch OFF	0 – 1 V
				ON OFF	For a few seconds after turning ignition switch OFF	9 – 16 V
32	G/W	Throttle control motor relay control	Output	ON → OFF		0 – 1 V ↓ 9 – 16 V ↓ 0 – 1 V
				ON		0 – 1 V
34	Y	Ignition coil power supply	Output	OFF or ACC		0 – 1 V
				ON		9 – 16 V
35	BR	NATS antenna amp power supply	Output	OFF		9 – 16 V
36	SB	Fuel injector power supply	Output	OFF or ACC		0 – 1 V
				ON		9 – 16 V
39	L	Timing control solenoid valve power supply	Output	OFF	More than a few seconds after turning ignition switch OFF	0 – 1 V
				ON OFF	For a few seconds after turning ignition switch OFF	9 – 16 V
40	BR	Transmission range switch power supply	Input	ON	Select lever in any position other than P or N	0 – 1 V
					Select lever P or N	9 – 16 V
43	GR	Fuel pump relay control	Output	ON RUN	Approximately 1 second after turning the ignition switch ON	0 – 1 V
				ON	Approximately 1 second or more after turning the ignition switch	9 – 16 V
47	R/W	ECM power supply	Output	OFF	More than a few seconds after turning ignition switch OFF	0 – 1 V
				ON OFF	For a few seconds after turning ignition switch OFF	9 – 16 V
50	P	ECM relay control	Output	OFF	More than a few seconds after turning ignition switch OFF	0 – 1 V
				ON OFF	For a few seconds after turning ignition switch OFF	9 – 16 V

A

B

C

D

E

F

G

H

I

J

K

L

PCS

N

O

P

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

[IPDM E/R]

Terminal	Wire color	Circuit	Input/Output	Ignition switch	Condition	Value
59	Y	Cooling fan relay control	Output		Cooling fan OFF or LO operated	9 – 16 V
					Cooling fan MID or HI operated	0 – 1 V
60	B	Ground	—	—	—	—
61	P	CAN-L	Input/Output	—	—	—
62	L	CAN-H	Input/Output	—	—	—
64	LG	Hood switch	Input	ON	Hood closed	0 – 1 V
					Hood open	9 – 16 V
65	BR	Cooling fan relay power supply	Output	OFF or ACC		0 – 1 V
				ON		9 – 16 V
69	GR	Daytime light relay 1 control	Output			9 – 16 V
						0 – 1 V
71	W	Front fog lamp relay control	Output		Front fog lamp switch OFF	9 – 16 V
					Front fog lamp switch ON	0 – 1 V
73	SB	Horn relay control	Output		Horn is not activated	9 – 16 V
					Horn is activated	0 – 1 V
74	V	Front wiper motor stop position	Input	ON	Front wiper stop position	0 – 1 V
					Any position other than front wiper stop position	9 – 16 V
80	R	PNP switch	Input	ON	Selector Lever in P	0 – 1 V
					Selector lever in any position other than P	9 – 16 V
81	SB	Push-button ignition switch	Input	ON	Press the push-button ignition switch	0 – 1 V
					Release the push button ignition switch	9 – 16 V
89	B	Ground	—	—	—	—
90	L	Ignition relay power supply	Input	ON	Ignition switch OFF or ACC	0 – 1 V
					Ignition switch ON	9 – 16 V

Fail-safe

INFOID:000000009567568

CAN COMMUNICATION CONTROL

When CAN communication with ECM and BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.

If No CAN Communication Is Available With ECM

Control part	Fail-safe operation
Cooling fan	- The cooling fan relay turn ON when the ignition switch is turned ON (Cooling fan HI operation) - The cooling fan relay turn OFF when the ignition switch is turned OFF
A/C compressor	A/C relay OFF

If No CAN Communication Is Available With BCM

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

[IPDM E/R]

Control part	Fail-safe operation
Headlamp	- Turns ON the headlamp low relay when the ignition switch is turned ON - Turns OFF the headlamp low relay when the ignition switch is turned OFF - Headlamp high relay OFF
- Parking lamp - License plate lamp - Illumination - Tail lamp	- Turns ON the tail lamp relay when the ignition switch is turned ON - Turns OFF the tail lamp relay when the ignition switch is turned OFF
Front wiper motor	- The status just before activation of fail-safe control is maintained until the ignition switch is turned OFF while the front wiper is operating at LO or HI speed. - The wiper is operated at LO speed until the ignition switch is turned OFF if the fail-safe control is activated while the front wiper is set in the INT mode and the front wiper motor is operating. - Returns automatically wiper to stop position when ignition switch is turned ON if fail-safe control is activated while front wiper motor is operated and wiper stop in the other position than stop position.
Front fog lamp	Front fog lamp relay OFF
Horn	Horn OFF
Ignition relay	The status just before activation of fail-safe is maintained.
Starter motor	Starter control relay OFF

IGNITION RELAY MALFUNCTION DETECTION FUNCTION

- IPDM E/R monitors the voltage at the contact circuit and excitation coil circuit of the ignition relay inside it.
- IPDM E/R judges the ignition relay error if the voltage differs between the contact circuit and the excitation coil circuit.
- If the ignition relay cannot turn OFF due to contact seizure, it activates the tail lamp relay for 10 minutes to alert the user to the ignition relay malfunction when the ignition switch is turned OFF.

DTC	Ignition switch	Ignition relay	Tail lamp relay
—	ON	ON	—
—	OFF	OFF	—
B2098: IGN RELAY ON	OFF	ON	ON (10 minutes)
B2099: IGN RELAY OFF	ON	OFF	—

NOTE:

The tail lamp turns OFF when the ignition switch is turned ON.

FRONT WIPER CONTROL

IPDM E/R detects front wiper stop position by a front wiper auto stop signal.

When a front wiper auto stop signal is in the conditions listed below, IPDM E/R stops power supply to wiper after repeating a front wiper 10 second activation and 20 second stop five times.

Ignition switch	Front wiper switch	Auto stop signal
ON	OFF	Front wiper stop position signal cannot be input 10 seconds.
	ON	The signal does not change for 10 seconds.

NOTE:

This operation status can be confirmed on the IPDM E/R “Data Monitor” that displays “BLOCK” for the item “WIP PROT” while the wiper is stopped.

STARTER MOTOR PROTECTION FUNCTION

IPDM E/R turns OFF the starter control relay to protect the starter motor when the starter control relay remains active for 90 seconds.

DTC Index

INFOID:000000009567569

CONSULT display	Fail-safe	TIME ^{NOTE}		Refer to
No DTC is detected. Further testing may be required.	—	—	—	—
U1000: CAN COMM CIRCUIT	×	CRNT	1 – 39	PCS-26
B2098: IGN RELAY ON	×	CRNT	1 – 39	PCS-27
B2099: IGN RELAY OFF	—	CRNT	1 – 39	PCS-28
B210B: PNP RELAY ON stuck failure	—	CRNT	1 – 39	SEC-108
B210C: PNP RELAY OFF stuck failure	—	CRNT	1 – 39	SEC-109
B210D: STARTER relay ON stuck failure	—	CRNT	1 – 39	SEC-111
B210E: STARTER relay OFF stuck failure	—	CRNT	1 – 39	SEC-113
B210F: Interlock/NP switch ON stuck failure	—	CRNT	1 – 39	SEC-115
B2110: Interlock/NP switch OFF stuck failure	—	CRNT	1 – 39	SEC-117

NOTE:

The details of TIME display are as follows.


- CRNT: The malfunctions that are detected now
- 1 - 39: The number is indicated when it is normal at present and a malfunction was detected in the past. It increases like 0 → 1 → 2 ... 38 → 39 after returning to the normal condition whenever IGN OFF → ON. It is fixed to 39 until the self-diagnosis results are erased if it is over 39. It returns to 0 when a malfunction is detected again in the process.

WIRING DIAGRAM

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Wiring Diagram

INFOID:000000009567570




AAMWA0770GB

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)


< WIRING DIAGRAM >

[IPDM E/R]

FJ : WITH PRE-WIRING FOR FRONT FOG LAMP
 FL : WITH FRONT FOG LAMP
 M : WITH M/T
 RL : WITH DAYTIME LIGHT SYSTEM
 VT : WITH CVT



IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) CONNECTORS

E42			E43			E44		
IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)			IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)			IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)		
BLACK			BLACK			BROWN		
 			 			 		
Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
1	R	F/L USM (+B1)	3	SB	F/L IGNSW	9	BR	FUEL PUMP
2	Y	F/L MAIN (+B2)	4	-	-	10	-	-
			5	Y	MOTOR FAN HI	11	G	ECM VB
			6	R	STARTER MOTOR	12	-	-
			7	P	MOTOR FAN LO	13	R	CLUTCH I/L SW
			8	G	F/L MOTOR FAN	14	L	HEADLAMP LO LH
						15	LG	ST RLY COIL
						16	P	HEADLAMP LO RH

AAMIA1680GB

PCS

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< WIRING DIAGRAM >

[IPDM E/R]

Connector No.	E47
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



84	83	82	81	80	79	78	77
92	91	90	89	88	87	86	85

Terminal No.	Color of Wire	Signal Name
77	-	-
78	-	-
79	-	-
80	R	DETENT SW
81	SB	PUSH START SW
82	-	-
83	-	-
84	-	-
85	-	-
86	-	-
87	-	-
88	-	-
89	B	SL CONDITION 2
90	L	IGN SIGNAL
91	-	-
92	-	-

Connector No.	E46
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



64	63	62	61	60	59	58	57	56	55	54	53
76	75	74	73	72	71	70	69	68	67	66	65

Terminal No.	Color of Wire	Signal Name
53	-	-
54	-	-
55	-	-
56	-	-
57	-	-
58	-	-
59	Y	MOTOR FAN RLY GND
60	B	GND (SIGNAL)
61	P	CAN-L
62	L	CAN-H
63	-	-
64	LG	HOOD SW
65	BR	RELAY IG
66	-	-
67	-	-
68	-	-
69	GR	DTRL RLY
70	-	-
71	W	FR FOG RLY
72	-	-
73	SB	HORN RLY
74	V	WIPER AUTOSTOP
75	-	-
76	-	-

Connector No.	E45
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN



21	20	19	18	17		
28	27		26	25	24	23

Terminal No.	Color of Wire	Signal Name
17	LG	FR WIPER LO
18	GR	FR WIPER HI
19	B	GND (POWER)
20	BR	ABS ECU
21	R	AT ECU
22	P	CLEARANCE
23	R	TAIL/ILLUMI
24	W	DTRL
25	G	HEADLAMP HI LH
26	-	-
27	Y	HEADLAMP HI RH
28	V	AC-COMP

AAMIA1681GB

Connector No.	F43
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



46	45	44	43	42	41
52	51	50	49	48	47

Terminal No.	Color of Wire	Signal Name
41	-	-
42	-	-
43	GR	FPR
44	-	-
45	-	-
46	-	-
47	RW	ECM IGNSW
48	-	-
49	-	-
50	P	SSOFF
51	-	-
52	-	-

Connector No.	F42
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



33	32		31	30	29	
40	39	38	37	36	35	34

Terminal No.	Color of Wire	Signal Name
29	LW	ETC
30	-	-
31	-	-
32	G/W	MOTRLY
33	-	-
34	Y	IGN COIL
35	BR	ECM BAT
36	SB	INJECTOR
37	-	-
38	-	-
39	L	ENG SOL
40	BR	NPSW

AAMIA1682GB

PCS

DTC/CIRCUIT DIAGNOSIS

U1000 CAN COMM CIRCUIT

Description

INFOID:000000009567571

Refer to [LAN-6, "CAN COMMUNICATION SYSTEM : System Description"](#).

DTC Logic

INFOID:000000009567572

DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
CAN COMM CIRCUIT [U1000]	When IPDM E/R cannot communicate with CAN communication signal continuously for 2 seconds or more	In CAN communication system, any item (or items) of the following listed below is malfunctioning. • Transmission • Receiving (ECM) • Receiving (BCM) • Receiving (Combination meter)

Diagnosis Procedure

INFOID:000000009567573

1. PERFORM SELF DIAGNOSTIC RESULT

1. Turn ignition switch ON and wait for 2 second or more.
2. Check "SELF-DIAG RESULTS" of IPDM E/R.

Is "CAN COMM CIRCUIT" displayed?

- YES >> Refer to [LAN-15, "Trouble Diagnosis Flow Chart"](#).
- NO >> Refer to [GI-41, "Intermittent Incident"](#).

B2098 IGNITION RELAY ON STUCK

< DTC/CIRCUIT DIAGNOSIS >

[IPDM E/R]

B2098 IGNITION RELAY ON STUCK

DTC Logic

INFOID:000000009567575

DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
IGN RELAY ON [B2098]	The ignition relay ON is detected for 1 second at ignition switch OFF (CPU monitors the status at the contact and excitation coil circuits of the ignition relay inside it)	IPDM E/R

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION

1. Turn ignition switch ON.
2. Turn ignition switch OFF and wait 1 second or more.
3. Turn ignition switch ON.
4. Perform Self Diagnostic Result of IPDM E/R using CONSULT.

Is DTC B2098 displayed?

- YES >> Refer to [PCS-27, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000009567576

1. PERFORM SELF DIAGNOSTIC RESULT

Perform Self Diagnostic Result of IPDM E/R using CONSULT.

Is display history of DTC B2098 CRNT?

- YES >> Replace IPDM E/R. Refer to [PCS-30](#).
NO >> Refer to [GI-41](#).

PCS

B2099 IGNITION RELAY OFF STUCK

< DTC/CIRCUIT DIAGNOSIS >

[IPDM E/R]

B2099 IGNITION RELAY OFF STUCK

DTC Logic

INFOID:000000009567578

DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
IGN RELAY OFF [B2099]	The ignition relay OFF is detected for 1 second at ignition switch ON (CPU monitors the status at the contact and excitation coil circuits of the ignition relay inside it)	IPDM E/R

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION

1. Turn ignition switch ON.
2. Turn ignition switch OFF and wait 1 second or more.
3. Turn ignition switch ON.
4. Perform Self Diagnostic Result of IPDM E/R using CONSULT.

Is DTC B2099 displayed?

- YES >> Refer to [PCS-28, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000009567579

1. PERFORM SELF DIAGNOSTIC RESULT

Perform Self Diagnostic Result of IPDM E/R using CONSULT.

Is display history of DTC B2099 CRNT?

- YES >> Replace IPDM E/R. Refer to [PCS-30](#).
NO >> Refer to [GI-41](#).

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[IPDM E/R]

POWER SUPPLY AND GROUND CIRCUIT

Diagnosis Procedure

INFOID:000000009567580

Regarding Wiring Diagram information, refer to [PCS-21, "Wiring Diagram"](#).

1. CHECK FUSE AND FUSIBLE LINKS

Check that the following IPDM E/R fuse or fusible links are not blown.

Terminal No.	Signal name	Fuse and fusible link Nos.
1	Battery	A (120A), E (80A)
2	Battery	B (60A)

Is the fuse blown?

- YES >> Replace the blown fuse or fusible link after repairing the affected circuit.
NO >> GO TO 2.

2. CHECK BATTERY POWER SUPPLY CIRCUIT

1. Disconnect IPDM E/R connector E42.
2. Check voltage between IPDM E/R connector E42 and ground.

IPDM E/R		Ground	Voltage (Approx.)
Connector	Terminal		
E42	1	—	Battery voltage
	2		

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace harness or connectors.

3. CHECK GROUND CIRCUIT

Check continuity between IPDM E/R connectors and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E45	19	—	Yes
E46	60		
E47	89		

Is the inspection result normal?


- YES >> Inspection End.
NO >> Repair or replace harness or connectors.

REMOVAL AND INSTALLATION

IPDM E/R

Exploded View

INFOID:000000009607430



1. IPDM E/R

↩ Front

Removal and Installation

INFOID:000000009607431


CAUTION:

IPDM E/R integrated relays are not serviceable and must not be removed from unit.

REMOVAL

1. Disconnect the negative battery terminal. Refer to [PG-69. "Removal and Installation \(Battery\)"](#).
2. Release pawls on IPDM E/R cover (1) and remove.

○:Pawl




IPDM E/R

< REMOVAL AND INSTALLATION >

[IPDM E/R]

3. Release pawls, then lift IPDM E/R (1) as shown and position aside.
○:Pawl
4. Disconnect the harness connectors from the IPDM E/R (1) and remove.



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

PCS

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000009607420

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:


- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:0000000009567585



AWMIA1438ZZ

No.	Component	Description
1.	Accessory relay-2	- Accessory relay-2 is controlled by BCM. - Accessory relay-2 supplies accessory power supply or ignition switch ACC signal to each ECU when ignition switch is turned to ACC or ON. - BCM compares status of accessory relay-2 control signal, and ignition switch position judged by BCM.
2.	BCM	- BCM controls power distribution system. - BCM judges ignition switch position by push-button ignition switch (push switch) and vehicle condition. - BCM checks ignition switch position internally.
3.	Push-button ignition switch	Push-button ignition switch (push switch) is pressed, and transmits status signal to BCM and IPDM E/R.
4.	IPDM E/R	- IPDM E/R detects push-button ignition switch (push switch) status, and transmits push-button ignition switch status signal (CAN) to BCM. - IPDM E/R receives ignition relay-1 (IPDM E/R) control signal and ignition switch ON signal (CAN) from BCM, and controls ignition relay-1 (built into IPDM E/R)
5.	Blower relay (in fuse block)	- Blower relay is controlled by BCM. - Blower relay supplies ignition switch ON power supply or ignition switch ON signal to air conditioning system when ignition switch is turned ON. - BCM compares status of blower relay control signal and ignition switch position judged by BCM.
6.	Accessory relay-1 (in fuse block)	- Accessory relay-1 is controlled by BCM. - Accessory relay-1 supplies accessory power supply or ignition switch ACC signal to each ECU when ignition switch is turned ACC or ON. - BCM compares status of accessory relay-1 control signal, and ignition switch position judged by BCM.
7.	Ignition relay-2 (in fuse block)	- Ignition relay-2 is controlled by BCM. - Ignition relay-2 supplies ignition switch ON power supply or ignition switch ON signal to each ECU and system when ignition switch is turned ON. - BCM compares status of ignition relay-2 control signal and ignition switch position judged by BCM. - BCM monitors ignition relay-2 operating status by ignition relay feedback signal.


SYSTEM

POWER DISTRIBUTION SYSTEM

POWER DISTRIBUTION SYSTEM : System Description

INFOID:000000009567588

SYSTEM DIAGRAM



SYSTEM DESCRIPTION

- PDS (POWER DISTRIBUTION SYSTEM) is the system that BCM controls with the operation of the push-button ignition switch and performs the power distribution to each power circuit. This system is used instead of the mechanical power supply changing mechanism with the operation of the conventional key cylinder.
- The push-button ignition switch can be operated when Intelligent Key is in the following condition.
 - Intelligent Key is in the detection area of the inside key antenna.
 - Intelligent Key backside is contacted to push-button ignition switch.
- The push-button ignition switch operation is input to BCM as a signal. BCM changes the power supply position according to the status and operates the following relays to supply power to each power circuit.
 - Ignition relay-1
 - Ignition relay-2
 - Accessory relay-1
 - Accessory relay-2
 - Blower motor relay

NOTE:

- The engine switch operation changes due to the conditions of brake pedal, selector lever and vehicle speed.
- The power supply position can be confirmed with the lighting of the indicators in the push-button ignition switch.

BATTERY SAVER SYSTEM

When all the following conditions are met for 30 minutes, the battery saver system will cut off the power supply to prevent battery discharge.

- The ignition switch is in the ACC or ON position
- All doors are closed
- Selector lever is in the P (park) position

Reset Condition of Battery Saver System

In order to prevent the battery from discharging, the battery saver system will cut off the power supply when all doors are closed, the selector lever is in P (park) position and the ignition switch is left in the ACC or ON position for 30 minutes. If any of the following conditions are met the battery saver system is released and the steering will change automatically to lock position from OFF position.

- Opening any door
- Operating door request switch on door handle
- Operating Intelligent Key

POWER SUPPLY POSITION CHANGE TABLE BY PUSH-BUTTON IGNITION SWITCH OPERA-

SYSTEM

< SYSTEM DESCRIPTION >

[POWER DISTRIBUTION SYSTEM]

TION

The power supply position changing operation can be performed with the following operations.

NOTE:

- When an Intelligent Key is within the detection area of inside key antenna and when Intelligent Key backside is contacted to push-button ignition switch, it is equivalent to the operations below.
- When starting the engine, the BCM monitors under the engine start conditions:
 - Brake pedal operating condition
 - Selector lever position
 - Vehicle speed

Vehicle speed: less than 4 km/h (2.5 MPH)

Power supply position	Engine start/stop condition		Push-button ignition switch operation frequency
	Selector lever position	Brake pedal operation condition	
OFF → ACC	—	Not depressed	1
OFF → ACC → ON	—	Not depressed	2
OFF → ACC → ON → OFF	—	Not depressed	3
OFF → START ACC → START ON → START	P or N position	Depressed	1
Engine is running → OFF	—	—	1

Vehicle speed: 4 km/h (2.5 MPH) or more

Power supply position	Engine start/stop condition		Push-button ignition switch operation frequency
	Selector lever position	Brake pedal operation condition	
Engine is running → ACC	—	—	Emergency stop operation
Engine stall return operation while driving	N position	Not depressed	1

Emergency stop operation

- Press and hold the push-button ignition switch for 2 seconds or more.
- Press the push-button ignition switch 3 times or more within 1.5 seconds.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

PCS

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[POWER DISTRIBUTION SYSTEM]

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000009654077

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Direct Diagnostic Mode	Description
ECU identification	The BCM part number is displayed.
Self Diagnostic Result	The BCM self diagnostic results are displayed.
Data Monitor	The BCM input/output data is displayed in real time.
Active Test	The BCM activates outputs to test components.
Work support	The settings for BCM functions can be changed.
Configuration	- The vehicle specification can be read and saved. - The vehicle specification can be written when replacing BCM.
CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication is displayed.

SYSTEM APPLICATION

BCM can perform the following functions.

System	Sub System	Direct Diagnostic Mode						
		ECU identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration	CAN DIAG SUPPORT MNTR
Door lock	DOOR LOCK		×	×	×	×		
Rear window defogger	REAR DEFOGGER			×	×			
Warning chime	BUZZER			×	×			
Interior room lamp timer	INT LAMP			×	×	×		
Exterior lamp	HEAD LAMP			×	×	×		
Wiper and washer	WIPER			×	×	×		
Turn signal and hazard warning lamps	FLASHER			×	×			
Air conditioner	AIR CONDITIONER			×				
Intelligent Key system	INTELLIGENT KEY		×	×	×	×		
Combination switch	COMB SW			×				
BCM	BCM	×	×			×	×	×
Immobilizer	IMMU		×		×	×		
Interior room lamp battery saver	BATTERY SAVER			×	×	×		
Vehicle security system	THEFT ALM			×	×	×		
RAP system	RETAINED PWR			×		×		
Signal buffer system	SIGNAL BUFFER			×				

INTELLIGENT KEY

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[POWER DISTRIBUTION SYSTEM]

INTELLIGENT KEY : CONSULT Function (BCM - INTELLIGENT KEY)

INFOID:000000009654078

SELF DIAGNOSTIC RESULT

Refer to [BCS-46. "DTC Index"](#).

DATA MONITOR

Monitor Item [Unit]	Main	Description
REQ SW -DR [On/Off]	×	Indicates condition of door request switch LH.
REQ SW -AS [On/Off]	×	Indicates condition of door request switch RH.
REQ SW -BD/TR [On/Off]	×	Indicates condition of back door request switch.
PUSH SW [On/Off]		Indicates condition of push-button ignition switch.
BRAKE SW 1 [On/Off]	×	Indicates condition of brake switch.
CLUTCH SW [On/Off]	×	Indicates condition of clutch interlock switch.
BRAKE SW 2 [On/Off]		Indicates condition of brake switch.
DETE/CANCL SW [On/Off]	×	Indicates condition of P (park) position.
SFT PN/N SW [On/Off]	×	Indicates condition of P (park) or N (neutral) position.
UNLK SEN -DR [On/Off]	×	Indicates condition of door unlock sensor.
PUSH SW -IPDM [On/Off]		Indicates condition of push-button ignition switch received from IPDM E/R on CAN communication line.
IGN RLY1 -F/B [On/Off]		Indicates condition of ignition relay 1 received from IPDM E/R on CAN communication line.
DETE SW -IPDM [On/Off]		Indicates condition of detent switch received from TCM on CAN communication line.
SFT PN -IPDM [On/Off]		Indicates condition of P (park) or N (neutral) position from TCM on CAN communication line.
SFT P -MET [On/Off]		Indicates condition of P (park) position from TCM on CAN communication line.
SFT N -MET [On/Off]		Indicates condition of N (neutral) position from IPDM E/R on CAN communication line.
ENGINE STATE [Stop/Start/Crank/Run]	×	Indicates condition of engine state from ECM on CAN communication line.
VEH SPEED 1 [mph/km/h]	×	Indicates condition of vehicle speed signal received from ABS on CAN communication line.
VEH SPEED 2 [mph/km/h]	×	Indicates condition of vehicle speed signal received from combination meter on CAN communication line.
DOOR STAT -DR [LOCK/READY/UNLK]	×	Indicates condition of driver side door status.
DOOR STAT -AS [LOCK/READY/UNLK]	×	Indicates condition of passenger side door status.
ID OK FLAG [Set/Reset]		Indicates condition of Intelligent Key ID.
PRMT ENG STRT [Set/Reset]		Indicates condition of engine start possibility.
RKE OPE COUN1 [0-19]	×	When remote keyless entry receiver receives the signal transmitted while operating on Intelligent Key, the numerical value start changing.
RKE OPE COUN2 [0-19]	×	When remote keyless entry receiver receives the signal transmitted while operating on Intelligent Key, the numerical value start changing.
RKE-LOCK [On/Off]		Indicates condition of lock signal from Intelligent Key.
RKE-UNLOCK [On/Off]		Indicates condition of unlock signal from Intelligent Key.
RKE-MODE CHG [On/Off]		Indicates condition of mode change signal from Intelligent Key.

ACTIVE TEST

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[POWER DISTRIBUTION SYSTEM]

Test Item	Description
INSIDE BUZZER	This test is able to check combination meter warning chime operation [Take Out/Knob/Key/Off].
LCD	This test is able to check combination meter display information [Off/LK WN/OUTKEY/NO KY/BATT/INSRT/SFT P/ROTAT/ID NG/B&P I/B&P N].
BATTERY SAVER	This test is able to check battery saver operation [On/Off].
ENGINE SW ILLUMI	This test is able to check push-button ignition switch START indicator operation [On/Off].
PUSH SWITCH INDICATOR	This test is able to check back door lock actuator operation [On/Off].
INT LAMP	This test is able to check interior room lamp operation [On/Off].
INDICATOR	This test is able to check combination meter warning lamp operation [KEY ON/KEY IND/Off].
FLASHER	This test is able to check hazard lamp operation [LH/RH/Off].
OUTSIDE BUZZER	This test is able to check Intelligent Key warning buzzer operation [On/Off].
HORN	This test is able to check horn operation [On].
P RANGE	This test is able to check CVT shift selector illumination operation [On/Off].

WORK SUPPORT

Support Item	Setting		Description
LOCK/UNLOCK BY I-KEY	On*		Door lock/unlock function from Intelligent Key ON.
	Off		Door lock/unlock function from Intelligent Key OFF.
ANTI KEY LOCK IN FUNCTI	On*		Anti lock out setting ON.
	Off		Anti lock out setting OFF.
ANS BACK I-KEY UNLOCK	Off		No buzzer reminder when doors are unlocked with request switch.
	On*		Buzzer reminder when doors are unlocked with request switch.
ANS BACK I-KEY LOCK	Horn Chirp		Horn chirp reminder when doors are locked with request switch.
	Buzzer*		Buzzer reminder when doors are locked with request switch.
	Off		No reminder when doors are locked with request switch.
HORN WITH KEYLESS LOCK	Off		Horn chirp reminder when doors are locked with Intelligent Key.
	On*		No horn chirp reminder when doors are locked with Intelligent Key.
HAZARD ANSWER BACK	Lock/Unlock*		Hazard warning lamp activation when doors are locked/unlocked with Intelligent Key or request switch.
	Unlock Only		Hazard warning lamp activation when doors are unlocked with Intelligent Key or request switch.
	Lock Only		Hazard warning lamp activation when doors are locked with Intelligent Key or request switch.
	Off		No hazard warning lamp activation when doors are locked/unlocked with Intelligent Key or request switch.
INSIDE ANT DIAGNOSIS	—		This function allows inside key antenna self-diagnosis.
CONFIRM KEY FOB ID	—		Intelligent Key ID code can be checked.
SHORT CRANKING OUTPUT	Start	70 msec	Starter motor operation duration time setting.
		100 msec	
		200 msec	
	End		—
LO- BATT OF KEY FOB WARN	On*		Intelligent Key low battery warning ON.
	Off		Intelligent Key low battery warning OFF.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[POWER DISTRIBUTION SYSTEM]

Support Item	Setting		Description
AUTO LOCK SET	MODE7	5 min	Auto door lock time setting.
	MODE6	4 min	
	MODE5	3 min	
	MODE4	2 min	
	MODE3*	1 min	
	MODE2	30 sec	
	MODE1	Off	

*: Initial Setting

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

PCS

ECU DIAGNOSIS INFORMATION

BCM

List of ECU Reference

INFOID:000000009567591

ECU	Reference
BCM	BCS-28. "Reference Value"
	BCS-44. "Fail-safe"
	BCS-46. "DTC Inspection Priority Chart"
	BCS-46. "DTC Index"

POWER DISTRIBUTION SYSTEM

< WIRING DIAGRAM >


[POWER DISTRIBUTION SYSTEM]

WIRING DIAGRAM

POWER DISTRIBUTION SYSTEM

Wiring Diagram

INFOID:000000009567592



AAMWA0772GB


A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

PCS

POWER DISTRIBUTION SYSTEM

< WIRING DIAGRAM >

[POWER DISTRIBUTION SYSTEM]



AAMWA0773GB

POWER DISTRIBUTION SYSTEM

< WIRING DIAGRAM >

[POWER DISTRIBUTION SYSTEM]

POWER DISTRIBUTION SYSTEM CONNECTORS

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W	—

Connector No.	M5
Connector Name	JOINT CONNECTOR-M03
Connector Color	BROWN



10	9	8	7	6	5	4	3	2	1
20	19	18	17	16	15	14	13	12	11

Terminal No.	Color of Wire	Signal Name
16	B	—
17	B	—
18	LG	—
20	R	—

Connector No.	M10
Connector Name	JOINT CONNECTOR-M01
Connector Color	BLUE



9	8	7	6	5	4	3	2	1
20	19	18	17	16	15	14	13	12
11	10							

Terminal No.	Color of Wire	Signal Name
7	L	—
8	L	—
16	P	—
17	P	—

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40

Terminal No.	Color of Wire	Signal Name
9	LG	BRAKE SW 1
39	L	CAN-H
40	P	CAN-L

Connector No.	M25
Connector Name	PUSH-BUTTON IGNITION SWITCH
Connector Color	WHITE



4	3
5	6
7	8

Terminal No.	Color of Wire	Signal Name
3	G	—
4	B	—
7	V	—
8	L	—

Connector No.	M39
Connector Name	ACCESSORY RELAY-2
Connector Color	BLUE



3	5
2	1

Terminal No.	Color of Wire	Signal Name
1	SB	—
2	B	—
3	L	—
5	O	—

AAMIA1683GB

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

PCS

POWER DISTRIBUTION SYSTEM

< WIRING DIAGRAM >

[POWER DISTRIBUTION SYSTEM]


Connector No.	M98
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE

71	72	73	74	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90
91	92	93	94	95	96	97	98	99	100	101	102	103	104	105	106	107	108	109	110

Terminal No.	Color of Wire	Signal Name
76	L	ENGINE START SW
91	V	POWER POSITION LED (LOCK POSITION LED)
96	SB	ACC RELAY OUTPUT
98	O	IGN RELAY OUTPUT1 (USM)
99	GR	IGN RELAY OUTPUT2 (ELEC)
105	SB	BRAKE SW2
106	Y	BLOWER FAN MOTOR RELAY OUTPUT

Terminal No.	Color of Wire	Signal Name
20A	P	-
21A	L	-
39A	SB	-
47A	L	-
91A	G	-
92A	R	-
93A	O	-

Connector No.	M69
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M99
Connector Name	BCM (BODY CONTROL MODULE) (WITH INTELLIGENT KEY SYSTEM)
Connector Color	WHITE

56	57	58	59	60	61	62	63	64
65	66	67	68	69	70			



Terminal No.	Color of Wire	Signal Name
57	Y	BATTERY (FUSE)
67	B	GND
70	G	BATTERY (F/L)

AAMIA1684GB

[POWER DISTRIBUTION SYSTEM]

A
B
C
D
E
F
G
H
I
J
K
L
PC
N
O
P

2014 Note

POWER DISTRIBUTION SYSTEM

< WIRING DIAGRAM >

[POWER DISTRIBUTION SYSTEM]

Connector No.	E47
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



84	83	82	81	80	79	78	77
92	91	90	89	88	87	86	85

Terminal No.	Color of Wire	Signal Name
81	SB	PUSH START SW
90	L	IGN SIGNAL

Connector No.	E46
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



64	63	62	61	60	59	58	57	56	55	54	53
76	75	74	73	72	71	70	69	68	67	66	65

Terminal No.	Color of Wire	Signal Name
60	B	GND (SIGNAL)
61	P	CAN-L
62	L	CAN-H


Connector No.	E45
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN




21	20		19	18	17	
28	27	26	25	24	23	22

Terminal No.	Color of Wire	Signal Name
19	B	GND (POWER)
21	R	AT ECU (WITH CVT)

Connector No.	J-2
Connector Name	FUSE BLOCK (J/B) (ACCESSORY RELAY-1)
Connector Color	



Connector No.	J-1
Connector Name	FUSE BLOCK (J/B) (BLOWER RELAY)
Connector Color	-



Connector No.	E57
Connector Name	STOP LAMP SWITCH (WITH M/T)
Connector Color	BLACK



2	1
---	---

Terminal No.	Color of Wire	Signal Name
1	SB	-
2	LG	-


AAMIA1686GB

POWER DISTRIBUTION SYSTEM

< WIRING DIAGRAM >

[POWER DISTRIBUTION SYSTEM]

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P



PCS

AAMIA1687GB

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[POWER DISTRIBUTION SYSTEM]


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:000000009567593

OVERALL SEQUENCE



JMKIA8652GB

DETAILED FLOW

Revision: April 2013

PCS-48

2014 Note

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[POWER DISTRIBUTION SYSTEM]

1.GET INFORMATION FOR SYMPTOM

1. Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurs).
2. Check operation condition of the component or system that is malfunctioning.

>> GO TO 2.

2.CHECK DTC

1. Check DTC.
2. Perform the following procedure if DTC is detected.
 - Record DTC and freeze frame data (Print them out using CONSULT).
 - Erase DTC.
 - Study the relationship between the cause detected by DTC and the symptom described by the customer.
3. Check related service bulletins for information.

Are any symptoms described and any DTC detected?

Symptom is described, DTC is detected>>GO TO 3.

Symptom is described, DTC is not detected>>GO TO 4.

Symptom is not described, DTC is detected>>GO TO 5.

3.CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.

Also study the normal operation and fail-safe related to the symptom.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 5.

4.CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.

Verify relation between the symptom and the condition when the symptom is detected.

NOTE:

Freeze frame data is useful if the DTC is not detected.

>> GO TO 6.

5.PERFORM DTC CONFIRMATION PROCEDURE

Perform DTC CONFIRMATION PROCEDURE for the detected DTC, and then check that DTC is detected again. At this time, always connect CONSULT to the vehicle, and check self diagnostic results in real time.

If two or more DTCs are detected, refer to [BCS-46, "DTC Inspection Priority Chart"](#), and determine trouble diagnosis order.

Is DTC detected?

YES >> GO TO 7.

NO >> Refer to [GI-41, "Intermittent Incident"](#).

6.DETECT MALFUNCTIONING SYSTEM BY SYMPTOM DIAGNOSIS

Detect malfunctioning system according to SYMPTOM DIAGNOSIS based on the confirmed symptom in step 4, and determine the trouble diagnosis order based on possible causes and symptom.

Is the symptom described?

YES >> GO TO 7.

NO >> Monitor input data from related sensors or check voltage of related module terminals using CONSULT.

7.DETECT MALFUNCTIONING PART BY DIAGNOSIS PROCEDURE

Inspect according to Diagnosis Procedure of the system.

Is malfunctioning part detected?

YES >> GO TO 8.

NO >> Refer to [GI-41, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

PCS

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[POWER DISTRIBUTION SYSTEM]

8. REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnosis Procedure again after repair and replacement.
3. Check DTC. If DTC is detected, erase it.

>> GO TO 9.

9. FINAL CHECK

When DTC is detected in step 2, perform DTC CONFIRMATION PROCEDURE again, and then check that the malfunction is repaired securely.

When symptom is described by the customer, refer to confirmed symptom in step 3 or 4, and check that the symptom is not detected.

Is DTC detected and does symptom remain?

YES-1 >> DTC is detected: GO TO 7.

YES-2 >> Symptom remains: GO TO 4.

NO >> Inspection End.

U1000 CAN COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

DTC/CIRCUIT DIAGNOSIS

U1000 CAN COMM CIRCUIT

Description

INFOID:0000000009567594

Refer to [LAN-6, "CAN COMMUNICATION SYSTEM : System Description"](#).

DTC Logic

INFOID:0000000009567595

DTC DETECTION LOGIC

NOTE:

U1000 can be set if a module harness was disconnected and reconnected, perhaps during a repair. Confirm that there are actual CAN diagnostic symptoms and a present DTC by performing the Self Diagnostic Result procedure.

CONSULT Display	DTC Detection Condition	Possible Cause
CAN COMM CIRCUIT [U1000]	When any listed module cannot communicate with CAN communication signal continuously for 2 seconds or more with ignition switch ON	In CAN communication system, any item (or items) of the following listed below is malfunctioning. • Transmission • Receiving (ECM) • Receiving (VDC/TCS/ABS) • Receiving (METER/M&A) • Receiving (TCM) • Receiving (IPDM E/R)

Diagnosis Procedure

INFOID:0000000009567596

1. PERFORM SELF DIAGNOSTIC RESULT

1. Turn ignition switch ON and wait for 2 second or more.
2. Check "SELF- DIAG RESULTS".

Is "CAN COMM CIRCUIT" displayed?

- YES >> Perform CAN Diagnosis as described in DIAGNOSIS section of CONSULT Operation Manual.
NO >> Refer to [GI-41, "Intermittent Incident"](#).

PCS

U1010 CONTROL UNIT (CAN)

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

U1010 CONTROL UNIT (CAN)

DTC Logic

INFOID:0000000009567597

DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
CONTROL UNIT (CAN) [U1010]	BCM detected internal CAN communication circuit malfunction.	BCM

Diagnosis Procedure

INFOID:0000000009567598

1.REPLACE BCM

When DTC "U1010" is detected, replace BCM.

>> Replace BCM. Refer to [BCS-67. "Removal and Installation"](#).

B2614 ACC RELAY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

B2614 ACC RELAY CIRCUIT

DTC Logic

INFOID:000000009567599

DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
ACC RELAY REQ F/B [B2614]	An immediate operation of accessory relay-2 is requested by BCM, but there is no response for more than 1 second.	• Harness or connectors • Accessory relay-2 • BCM

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch to ACC, and wait for 1 second or more.
2. Perform Self-diagnosis result of BCM with CONSULT.

Is DTC B2614 displayed?

- YES >> Go to [PCS-53, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000009567600

Regarding Wiring Diagram information, refer to [PCS-41, "Wiring Diagram"](#).

1.CHECK ACCESSORY RELAY-2 CONTROL SIGNAL

1. Turn ignition switch ON.
2. Check voltage between BCM connector M98 and ground.

BCM		Ground	Voltage (Approx.)
Connector	Terminal		
M98	96	—	Battery voltage

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-67, "Removal and Installation"](#).
NO >> GO TO 2.

2.CHECK ACCESSORY RELAY-2 CONTROL SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector M98 and accessory relay-2 connector.
3. Check continuity between BCM connector M98 and accessory relay-2 connector M39.

BCM		Accessory relay-2		Continuity
Connector	Terminal	Connector	Terminal	
M98	96	M39	1	Yes

4. Check continuity between BCM connector M98 and ground.

BCM		Ground	Continuity
Connector	Terminal		
M98	96		No

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace harness or connectors.

3.CHECK ACCESSORY RELAY-2

A

B

C

D

E

F

G

H

I

J

K

L

PCS

N

O

P

B2614 ACC RELAY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

Refer to [PCS-54, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-67, "Removal and Installation"](#).
NO >> Replace accessory relay-2.

Component Inspection

INFOID:000000009567601


1. CHECK ACCESSORY RELAY-2

1. Turn ignition switch OFF.
2. Disconnect accessory relay-2.
3. Check the continuity between accessory relay-2 terminals.

Terminals	Condition	Continuity
3 and 5	12 V direct current supply between terminals 1 and 2	Yes
	No current supply	No

Is the inspection result normal?

- YES >> Inspection End.
NO >> Replace accessory relay-2.



PBIB0098E

B2615 BLOWER RELAY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

B2615 BLOWER RELAY CIRCUIT

DTC Logic

INFOID:000000009567602

DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
BLOWER RELAY CIRCUIT [B2615]	An immediate operation of front blower motor relay is requested by BCM, but there is no response for more than 1 second.	• Harness or connectors. • Blower relay. • Fuse block J/B. • BCM.

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON, and wait for 1 second or more.
2. Perform Self-diagnosis result with CONSULT.

Is DTC B2615 displayed?

- YES >> Go to [PCS-57, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000009567603

Regarding Wiring Diagram information, refer to [PCS-41, "Wiring Diagram"](#).

1. CHECK BLOWER RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Remove blower relay.
3. Disconnect BCM connector M98.
4. Check continuity between blower relay connector J-1 and BCM connector M98.

Blower relay		BCM		Continuity
Connector	Terminal	Connector	Terminal	
J-1	2	M98	106	Yes

5. Check continuity between Blower relay connector J-1 and ground.

Blower relay		Ground	Continuity
Connector	Terminal		
J-1	2	—	No

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace harness or connectors.

2. CHECK BLOWER RELAY GROUND CIRCUIT

Check continuity between Blower relay connector J-1 terminal 1 and ground.

Blower relay		Ground	Continuity
Connector	Terminal		
J-1	1	—	Yes

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace harness or connectors.

B2615 BLOWER RELAY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

3. CHECK BLOWER RELAY

Perform the relay component inspection. Refer to [PCS-56, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace blower relay.

4. CHECK BLOWER RELAY POWER SUPPLY (BCM)

1. Turn ignition switch ON.
2. Check voltage between BCM connector M98 and ground.

BCM		Ground	Voltage (Approx.)
Connector	Terminal		
M98	106	—	Battery voltage

Is the inspection result normal?

YES >> Refer to [GI-41, "Intermittent Incident"](#).

NO >> Replace BCM. Refer to [BCS-67, "Removal and Installation"](#).

Component Inspection

INFOID:000000009567604

1. CHECK BLOWER RELAY


1. Turn blower switch OFF.
2. Remove blower relay.
3. Check continuity between blower relay terminals.

Terminals	Condition	Continuity
3 and 5	12 V direct current supply between terminals 1 and 2	Yes
	No current supply	No

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace blower relay.



B2616 IGNITION RELAY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

B2616 IGNITION RELAY CIRCUIT

DTC Logic

INFOID:000000009567605

DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
IGN RELAY2 CIRCUIT [B2616]	An immediate operation of ignition relay-2 is requested by BCM, but there is no response for more than 1 second.	• Harness or connectors. • Ignition relay-2. • Fuse block J/B. • BCM.

DTC CONFIRMATION PROCEDURE

1. PERFORM SELF DIAGNOSTIC RESULT

1. Turn ignition switch ON under the following conditions, and wait for at least 1 second.
 - CVT selector lever is in the P (park) or N (neutral) position.
 - Release brake pedal
2. Perform Self Diagnostic Result of BCM with CONSULT.

Is DTC B2616 displayed?

- YES >> Refer to [PCS-57, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000009567606

Regarding Wiring Diagram information, refer to [PCS-41, "Wiring Diagram"](#).

1. CHECK IGNITION RELAY-2 POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Remove ignition relay-2.
3. Disconnect BCM connector M98.
4. Check continuity between ignition relay-2 connector J-3 and BCM connector M98.

Ignition relay-2		BCM		Continuity
Connector	Terminal	Connector	Terminal	
J-3	1	M98	99	Yes

5. Check continuity between ignition relay-2 connector J-3 and ground.

Ignition relay-2		Ground	Continuity
Connector	Terminal		
J-3	1	—	No

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace harness or connectors.

2. CHECK IGNITION RELAY-2 GROUND CIRCUIT

Check continuity between ignition relay-2 connector J-3 and ground.

Ignition relay-2		Ground	Continuity
Connector	Terminal		
J-3	2	—	Yes

Is the inspection result normal?

B2616 IGNITION RELAY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

- YES >> GO TO 3.
NO >> Repair or replace harness or connectors.

3. CHECK IGNITION RELAY-2

Perform the relay component inspection. Refer to [PCS-58, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Replace ignition relay-2.

4. CHECK IGNITION RELAY-2 POWER SUPPLY (BCM)

1. Turn ignition switch ON.
2. Check voltage between BCM connector M98 and ground.

BCM		Ground	Voltage (Approx.)
Connector	Terminal		
M98	99	—	Battery voltage

Is the inspection result normal?

- YES >> Refer to [GI-41, "Intermittent Incident"](#).
NO >> Replace BCM. Refer to [BCS-67, "Removal and Installation"](#).

Component Inspection

INFOID:000000009567607


1. CHECK IGNITION RELAY

1. Turn ignition switch OFF.
2. Remove ignition relay-2.
3. Check the continuity between ignition relay-2 terminals.

Terminals	Condition	Continuity
3 and 5	12 V direct current supply between terminals 1 and 2	Yes
	No current supply	No

Is the inspection result normal?

- YES >> Inspection End.
NO >> Replace ignition relay-2.



B2618 BCM

DTC Logic

INFOID:000000009567608

DTC DETECTION LOGIC

NOTE:

- If DTC B2618 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [PCS-51, "DTC Logic"](#).
- If DTC B2618 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [PCS-52, "DTC Logic"](#).

CONSULT Display	DTC Detection Condition	Possible Cause
BCM [B2618]	An immediate operation of ignition relay-1 is requested by BCM, but there is no response for more than 1 second	• Harness or connectors • BCM • IPDM E/R

DTC CONFIRMATION PROCEDURE

1. PERFORM SELF DIAGNOSTIC RESULT

1. Turn ignition switch ON under the following conditions, and wait for at least 1 second.
 - CVT selector lever is in the P (park) or N (neutral) position.
 - Release brake pedal
2. Perform Self Diagnostic Result of BCM with CONSULT.

Is DTC B2618 displayed?

- YES >> Refer to [PCS-59, "Diagnosis Procedure"](#).
- NO >> Inspection End.

Diagnosis Procedure

INFOID:000000009567609

Regarding Wiring Diagram information, refer to [PCS-41, "Wiring Diagram"](#).

1. CHECK IGNITION RELAY-1 CONTROL SIGNAL

1. Turn ignition switch ON.
2. Check voltage between BCM connector M98 and ground.

BCM		Ground	Voltage (Approx.)
Connector	Terminal		
M98	98	—	Battery voltage

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-67, "Removal and Installation"](#).
- NO >> GO TO 2.

2. CHECK IGNITION RELAY-1 CONTROL SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector M98 and IPDM E/R connector E47.
3. Check continuity between BCM connector M98 and IPDM E/R connector E47.

BCM		IPDM E/R		Continuity
Connector	Terminal	Connector	Terminal	
M98	98	E47	90	Yes

4. Check continuity between BCM connector M98 and ground.

B2618 BCM

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

BCM		Ground	Continuity
Connector	Terminal		
M98	98		No

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connectors.

3. CHECK VOLTAGE OF IGNITION RELAY-1 CONTROL SIGNAL CIRCUIT (IPDM E/R SIDE)

1. Connect IPDM E/R connector E47.
2. Check voltage between IPDM E/R connector E47 and ground.

IPDM E/R		Ground	Voltage (Approx.)
Connector	Terminal		
E47	90		Battery voltage

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-67, "Removal and Installation"](#).

NO >> Replace IPDM E/R. Refer to [PCS-30, "Removal and Installation"](#).

B261A PUSH-BUTTON IGNITION SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

B261A PUSH-BUTTON IGNITION SWITCH

DTC Logic

INFOID:000000009567610

DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
PUSH-BUTTON IGNITION SWITCH [B261A]	BCM detects a difference of signal for 1 second or more between the following information: - Power supply position by push-button ignition switch. - Power supply position from IPDM E/R (CAN).	- Harness or connectors - Push-button ignition switch - BCM

DTC CONFIRMATION PROCEDURE

1. PERFORM SELF DIAGNOSTIC RESULT

- Press the push-button ignition switch under the following conditions, and wait for at least 1 second.
 - CVT selector lever is in the P (park) or N (neutral) position.
 - Release the brake pedal.
- Perform Self Diagnostic Result of BCM with CONSULT.

Is DTC B261A displayed?

- YES >> Refer to [PCS-61, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000009567611

Regarding Wiring Diagram information, refer to [PCS-41, "Wiring Diagram"](#).

1. CHECK PUSH-BUTTON IGNITION SWITCH OUTPUT SIGNAL (PUSH-BUTTON IGNITION SWITCH)

- Disconnect push-button ignition switch connector.
- Check voltage between push-button ignition switch connector M25 and ground.

Push-button ignition switch		Ground	Voltage (Approx.)
Connector	Terminal		
M25	8	—	Battery voltage

Is the inspection result normal?

- YES >> GO TO 2.
NO >> GO TO 4.

2. CHECK IGNITION SWITCH OUTPUT SIGNAL (IPDM E/R)

Check voltage between IPDM E/R connector E47 terminal 81 and ground.

IPDM E/R		Ground	Voltage (Approx.)
Connector	Terminal		
E47	81	—	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Replace IPDM E/R. Refer to [PCS-30, "Removal and Installation"](#).

3. CHECK PUSH-BUTTON IGNITION SWITCH CIRCUIT (IPDM E/R)

- Turn ignition switch OFF.
- Disconnect IPDM E/R connector E47 and BCM connector M98.
- Check continuity between IPDM E/R connector E47 and push-button ignition switch connector M25.

B261A PUSH-BUTTON IGNITION SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

IPDM E/R		Push-button ignition switch		Continuity
Connector	Terminal	Connector	Terminal	
E47	81	M25	8	Yes

4. Check continuity between IPDM E/R connector E47 and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E47	81	—	No

Is the inspection result normal?

YES >> Refer to [GI-41, "Intermittent Incident"](#).

NO >> Repair or replace harness or connectors.

4. CHECK IGNITION SWITCH OUTPUT SIGNAL (BCM)

Check voltage between BCM connector M98 and ground.

BCM		Ground	Voltage (Approx.)
Connector	Terminal		
M98	76	—	Battery voltage

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace BCM. Refer to [BCS-67, "Removal and Installation"](#).

5. CHECK PUSH-BUTTON IGNITION SWITCH CIRCUIT (BCM)

1. Turn ignition switch OFF.
2. Disconnect BCM connector M98 and IPDM E/R connector E47.
3. Check continuity between BCM connector M98 and push-button ignition switch connector M25.

BCM		Push-button ignition switch		Continuity
Connector	Terminal	Connector	Terminal	
M98	76	M25	8	Yes

4. Check continuity between BCM connector M98 and ground.

BCM		Ground	Continuity
Connector	Terminal		
M98	76	—	No

Is the inspection result normal?

YES >> Refer to [GI-41, "Intermittent Incident"](#).

NO >> Repair or replace harness or connectors.

B26F1 IGNITION RELAY

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

B26F1 IGNITION RELAY

DTC Logic

INFOID:000000009567612

DTC DETECTION LOGIC

CONSULT Display	DTC detecting condition	Possible cause
IGN RELAY OFF [B26F1]	BCM transmits the ignition relay-1 control signal, but does not receive ignition switch ON signal (CAN) from IPDM E/R.	• Harness or connectors • BCM • IPDM E/R

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON, and wait for 2 seconds or more.
2. Perform Self-diagnosis result of BCM with CONSULT.

Is DTC B26F1 displayed?

- YES >> Go to [PCS-63, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000009567613

Regarding Wiring Diagram information, refer to [PCS-41, "Wiring Diagram"](#).

1.CHECK IPDM E/R SELF-DIAGNOSTIC RESULT

1. Turn ignition switch ON.
2. Erase the DTC of IPDM E/R.
3. Turn ignition switch OFF.
4. Turn ignition switch ON and check the DTC again.

Is DTC detected?

- YES >> Repair or replace the malfunctioning part. Refer to [PCS-20, "DTC Index"](#).
NO >> GO TO 2.

2.CHECK IGNITION RELAY-1 CONTROL SIGNAL (IPDM E/R)

1. Turn ignition switch ON.
2. Check voltage between BCM connector M98 and ground.

BCM		Ground	Voltage (Approx.)
Connector	Terminal		
M98	98	—	0 V

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Replace BCM. Refer to [BCS-67, "Removal and Installation"](#).

3.CHECK IGNITION RELAY-1 CONTROL SIGNAL CIRCUIT (IPDM E/R)

1. Turn ignition switch OFF.
2. Disconnect BCM connector M98 and IPDM E/R connector E47.
3. Check continuity between BCM connector M98 and IPDM E/R connector E47.

BCM		IPDM E/R		Continuity
Connector	Terminal	Connector	Terminal	
M98	98	E47	90	Yes

Is the inspection result normal?

B26F1 IGNITION RELAY

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

YES >> Replace IPDM E/R. Refer to [PCS-30, "Removal and Installation"](#).
NO >> Repair or replace harness or connectors.

B26F2 IGNITION RELAY

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

B26F2 IGNITION RELAY

DTC Logic

INFOID:000000009567614

DTC DETECTION LOGIC

CONSULT Display	DTC detecting condition	Possible cause
IGN RELAY ON [B26F2]	BCM transmits the ignition relay-1 control signal, but does not receive ignition switch ON signal (CAN) from IPDM E/R.	• Harness or connectors • BCM • IPDM E/R

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON, and wait for 2 seconds or more.
2. Perform Self-diagnosis result of BCM with CONSULT.

Is DTC B26F2 displayed?

- YES >> Go to [PCS-65, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000009567615

Regarding Wiring Diagram information, refer to [PCS-41, "Wiring Diagram"](#).

1.CHECK IPDM E/R SELF-DIAGNOSTIC RESULT

1. Turn ignition switch ON.
2. Erase the DTC of IPDM E/R.
3. Turn ignition switch OFF.
4. Turn ignition switch ON and check the DTC again.

Is DTC detected?

- YES >> Repair or replace the malfunctioning part. Refer to [PCS-20, "DTC Index"](#).
NO >> GO TO 2.

2.CHECK IGNITION RELAY-1 CONTROL SIGNAL (IPDM E/R)

1. Turn ignition switch OFF.
2. Check voltage between IPDM E/R connector E47 and ground.

IPDM E/R		Ground	Voltage (Approx.)
Connector	Terminal		
E47	90	—	Battery voltage

Is the inspection result normal?

- YES >> Replace IPDM E/R. Refer to [PCS-30, "Removal and Installation"](#).
NO >> GO TO 3.

3.CHECK IGNITION RELAY-1 CONTROL SIGNAL CIRCUIT - 1 (IPDM E/R)

1. Turn ignition switch OFF.
2. Disconnect BCM connector M98 and IPDM E/R connector E47.
3. Check continuity between IPDM E/R connector E47 and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E47	90		No

Is the inspection result normal?

B26F2 IGNITION RELAY

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

- YES >> GO TO 4.
NO >> Repair or replace harness or connectors.

4. CHECK IGNITION RELAY-1 CONTROL SIGNAL CIRCUIT - 2 (IPDM E/R)

1. Connect IPDM E/R connector E47.
2. Check voltage between IPDM E/R connector E47 and ground.

IPDM E/R		Ground	Voltage (Approx.)
Connector	Terminal		
E47	90	—	Battery voltage

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-67. "Removal and Installation"](#).
NO >> Replace IPDM E/R. Refer to [PCS-30. "Removal and Installation"](#).

B26F6 BCM

DTC Logic

INFOID:000000009567616

DTC DETECTION LOGIC

NOTE:

- If DTC B26F6 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [PCS-51, "DTC Logic"](#).
- If DTC B26F6 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [PCS-52, "DTC Logic"](#).

CONSULT Display	DTC Detection Condition	Possible Cause
BCM [B26F6]	Ignition relay-1 ON signal is not transmitted from IPDM E/R (CAN) when BCM turns ignition relay ON.	BCM

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON, and wait for 0.5 second or more.
2. Perform Self Diagnostic Result of BCM with CONSULT.

Is DTC B26F6 displayed?

- YES >> Go to [PCS-67, "Diagnosis Procedure"](#).
 NO >> Inspection End.

Diagnosis Procedure

INFOID:000000009567617

Regarding Wiring Diagram information, refer to [PCS-41, "Wiring Diagram"](#).

1. CHECK SELF DIAGNOSTIC RESULT FOR IPDM E/R

Perform Self Diagnostic Result of IPDM E/R with CONSULT.

Are any DTCs detected?

- YES >> Refer to [PCS-20, "DTC Index"](#).
 NO >> GO TO 2

2. CHECK IGNITION RELAY-1 POWER SUPPLY (IPDM E/R)

Check voltage between IPDM E/R connector E47 and ground.

IPDM E/R		Ground	Voltage (Approx.)
Connector	Terminal		
E47	90	—	Battery voltage

Is the inspection result normal?

- YES >> Replace IPDM E/R. Refer to [PCS-30, "Removal and Installation"](#).
 NO >> GO TO 3.

3. CHECK IGNITION RELAY-1 POWER SUPPLY (BCM)

Check voltage between BCM connector M98 and ground.

BCM		Ground	Voltage (Approx.)
Connector	Terminal		
M98	98	—	Battery voltage

Is the inspection result normal?

- YES >> Refer to [GI-41, "Intermittent Incident"](#).

B26F6 BCM

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

NO >> Replace BCM. Refer to [BCS-67, "Removal and Installation"](#).

PUSH-BUTTON IGNITION SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

PUSH-BUTTON IGNITION SWITCH

Component Function Check

INFOID:000000009567618

1. CHECK FUNCTION

1. Select "PUSH SW" in "Data Monitor" of BCM with CONSULT.
2. Check the push-button ignition switch signal under the following conditions.

Test item	Condition	Status
PUSH SW	Push-button ignition switch is pressed	On
	Push-button ignition switch is not pressed	Off

Is the indication normal?

- YES >> Inspection End.
NO >> Go to [PCS-69, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009567619

Regarding Wiring Diagram information, refer to [PCS-41, "Wiring Diagram"](#).

1. CHECK PUSH-BUTTON IGNITION SWITCH OUTPUT SIGNAL (PUSH-BUTTON IGNITION SWITCH)

1. Turn ignition switch OFF.
2. Disconnect push-button ignition switch connector and IPDM E/R connector E47.
3. Check voltage between push-button ignition switch connector M25 terminal 8 and ground.

Push-button ignition switch		Ground	Voltage (Approx.)
Connector	Terminal		
M25	8	—	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2. CHECK PUSH-BUTTON IGNITION SWITCH CIRCUIT (BCM)

1. Disconnect BCM connector M98.
2. Check continuity between BCM connector M98 and push-button ignition switch connector M25.

BCM		Push-button ignition switch		Continuity
Connector	Terminal	Connector	Terminal	
M98	76	M25	8	Yes

3. Check continuity between BCM connector M98 and ground.

BCM		Ground	Continuity
Connector	Terminal		
M98	76	—	No

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-67, "Removal and Installation"](#).
NO >> Repair or replace harness or connectors.

3. CHECK IGNITION SWITCH OUTPUT SIGNAL (IPDM E/R)

Check voltage between IPDM E/R connector E47 and ground.

PUSH-BUTTON IGNITION SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

IPDM E/R		Ground	Voltage (Approx.)
Connector	Terminal		
E47	81	—	Battery voltage

Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 4.

4. CHECK PUSH-BUTTON IGNITION SWITCH CIRCUIT (IPDM E/R)

1. Disconnect BCM connector M98.
2. Check continuity between IPDM E/R connector E47 and push-button ignition switch connector M25.

IPDM E/R		Push-button ignition switch		Continuity
Connector	Terminal	Connector	Terminal	
E47	81	M25	8	Yes

3. Check continuity between IPDM E/R connector E47 and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E47	81	—	No

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-30, "Removal and Installation"](#).

NO >> Repair or replace harness or connectors.

5. CHECK PUSH-BUTTON IGNITION SWITCH GROUND CIRCUIT

Check continuity between push-button ignition switch connector M25 and ground.

Push-button ignition switch		Ground	Continuity
Connector	Terminal		
M25	4	—	Yes

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace harness or connectors.

6. CHECK PUSH-BUTTON IGNITION SWITCH

Refer to [PCS-70, "Component Inspection"](#).

Is the inspection result normal?

YES >> Refer to [GI-41, "Intermittent Incident"](#).

NO >> Replace push-button ignition switch. Refer to [PCS-74, "Removal and Installation"](#).

Component Inspection

INFOID:0000000009567620

1. CHECK PUSH-BUTTON IGNITION SWITCH

1. Turn ignition switch OFF.
2. Disconnect push-button ignition switch connector.
3. Check continuity between push-button ignition switch terminals.

Push-button ignition switch terminals	Condition	Continuity
4 – 8	Pressed	Yes
	Not pressed	No

Is the inspection result normal?

YES >> Inspection End.

PUSH-BUTTON IGNITION SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

NO >> Replace push-button ignition switch. Refer to [PCS-74, "Removal and Installation"](#).

A

B

C

D

E

F

G

H

I

J

K

L

PCS

N

O

P

PUSH-BUTTON IGNITION SWITCH DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

SYMPTOM DIAGNOSIS

PUSH-BUTTON IGNITION SWITCH DOES NOT OPERATE

Description

INFOID:000000009567621

Check that vehicle is under the condition shown in “Conditions of vehicle” before starting diagnosis, and check each symptom.

NOTE:

The engine start function, door lock function, power distribution system, and NATS-IVIS/NVIS in the Intelligent Key system are closely related to each other regarding control. The vehicle security function can operate only when the door lock and power distribution system are operating normally.

Conditions of Vehicle (Operating Conditions)

- “ENGINE START BY I-KEY” in “WORK SUPPORT” is ON when setting on CONSULT.
- One or more of Intelligent Keys with registered Intelligent Key ID is in the vehicle.

Diagnosis Procedure

INFOID:000000009567622

1.PERFORM WORK SUPPORT

Perform INSIDE ANT DIAGNOSIS in Work Support of INTELLIGENT KEY.

Refer to [PCS-37, "INTELLIGENT KEY : CONSULT Function \(BCM - INTELLIGENT KEY\)"](#).

>> GO TO 2.

2.PERFORM SELF-DIAGNOSIS RESULT

Perform Self Diagnostic Result of BCM.

Is any DTCs displayed?

YES >> Refer to [BCS-46, "DTC Index"](#).

NO >> GO TO 3.

3.CHECK PUSH-BUTTON IGNITION SWITCH

Check push-button ignition switch.

Refer to [PCS-69, "Component Function Check"](#).

Is the operation normal?

YES >> GO TO 4.

NO >> Repair or replace malfunctioning parts.

4.CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection normal?

YES >> Refer to [GI-41, "Intermittent Incident"](#).

NO >> GO TO 1.

REMOVAL AND INSTALLATION

BCM (BODY CONTROL MODULE)

Removal and Installation

INFOID:0000000009607422

For removal and installation of the BCM (Body Control Module), refer to [BCS-67. "Removal and Installation"](#).

A

B

C

D

E

F

G

H

I

J

K

L

PCS

N

O

P

PUSH-BUTTON IGNITION SWITCH

< REMOVAL AND INSTALLATION >

[POWER DISTRIBUTION SYSTEM]

PUSH-BUTTON IGNITION SWITCH


Removal and Installation

INFOID:000000009607424

REMOVAL

1. Remove NATS antenna amp. Refer to [SEC-121, "Removal and Installation"](#).
2. Release pawls and remove the push-button ignition switch (1).

(1): Pawl



INSTALLATION

Installation is in the reverse order of removal.