


DTC	C0200/31	RIGHT FRONT SPEED SENSOR CIRCUIT
DTC	C0205/32	LEFT FRONT SPEED SENSOR CIRCUIT
DTC	C1235/35	FOREIGN MATTER IS ATTACHED ON TIP OF RIGHT FRONT SENSOR
DTC	C1236/36	FOREIGN MATTER IS ATTACHED ON TIP OF LEFT FRONT SENSOR

CIRCUIT DESCRIPTION



The speed sensor detects wheel speed and sends the appropriate signals to the ECU. These signals are used for control of the ABS and VSC control systems. Each of the front and rear rotors has 48 serrations.

When the rotors rotate, the magnetic field emitted by the permanent magnet in the speed sensor generates an AC voltage. Since the frequency of this AC voltage changes in direct proportion to the speed of the rotor, the frequency is used by the ECU to detect the speed of each wheel.


DTC No.	DTC Detecting Condition	Trouble Area
C0200/31 C0205/32	Detection of any of conditions 1. through 3.: 1. At vehicle speed of 10 km/h (6 mph) or more, pulses are not input for 15 sec. 2. Momentary interruption of the speed sensor signal occurs at least 7 times in the time between switching the ignition switch ON and switching it OFF. 3. The condition that the speed sensor signal circuit is open continues for 0.5 sec. or more.	• Right front and left front speed sensor • Each speed sensor circuit • Speed sensor rotor
C1235/35 C1236/36	At the vehicle speed of 20 km/h (12 mph) or more, the condition that noise is included in the speed sensor signal continues for 5 sec. or more.	• Right front and left front speed sensor • Speed sensor rotor

HINT:

DTC No. C0200/31 and C1235/35 is the right front speed sensor.

DTC No. C0205/32 and C1236/36 is the left front speed sensor.

WIRING DIAGRAM



INSPECTION PROCEDURE

HINT:

Start the inspection from step 1 in case of using hand-held tester and start from step 2 in case of not using hand-held tester.

1	READ VALUE OF HAND-HELD TESTER(SPEED SENSOR OUTPUT VALUE)
----------	--

- (a) Select the item "WHEEL SPEED FL (FR)" in the DATA LIST and read its value displayed on the hand-held tester.
- (b) Check that there is no difference between the speed value output from the speed sensor displayed on the hand-held tester and the speed value displayed on the speedometer when driving the vehicle.

OK: There is almost no difference from the displayed speed value.

HINT:


There is tolerance of $\pm 10\%$ in the speedometer indication.

OK	CHECK AND REPLACE SKID CONTROL ECU ASSY
-----------	--

NG

2

INSPECT FRONT SPEED SENSOR



- (a) Remove the fender liner.
- (b) Disconnect the speed sensor connector.
- (c) Measure resistance between terminals 1 and 2 of the speed sensor connector.
OK: 1.4 - 1.8 kΩ at 20°C
- (d) Measure resistance between each of terminals 1 and 2 of speed sensor connector and body ground.
OK: 1 MΩ or higher

A	OK
B	NG (Right front speed sensor)
C	NG (Left front speed sensor)

B

REPLACE SPEED SENSOR FRONT RH

C

REPLACE SPEED SENSOR FRONT LH

NOTICE:
Check the speed sensor signal last (See page 05-288).

A

3

CHECK HARNESS AND CONNECTOR(FRONT SPEED SENSOR-SKID CONTROL ECU ASSY)


- (a) Check for open and short circuit in harness and connector between each speed sensor and skid control ECU connector (See page 01-31).

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

4 CHECK SPEED SENSOR AND SENSOR ROTOR SERRATIONS



(REFERENCE) INSPECTION USING OSCILLOSCOPE

- Remove the skid control ECU with connectors still connected.
- Connect the oscilloscope to the terminals FR+ - FR- and FL+ - FL- of the skid control ECU.
- Drive the vehicle at about 30 km/h (19 mph), and check the signal waveform.

HINT:


- As the vehicle speed (wheel revolution speed) increases, a cycle of the waveform becomes shorter and the fluctuation in the output voltage becomes greater.
- When noise is identified in the waveform on the oscilloscope, error signals are generated due to the speed sensor rotor's scratches, looseness or foreign matter deposited on it.

OK

CHECK AND REPLACE SKID CONTROL ECU ASSY

NG

5 CHECK FRONT SPEED SENSOR INSTALLATION



- Check the speed sensor installation.

OK:

The installation bolt is tightened properly and there is no clearance between the sensor and front steering knuckle.

Torque: 8.0 N·m (82 kgf·cm, 71 in·lbf)

A	OK
B	NG (Right front speed sensor)
C	NG (Left front speed sensor)

B

REPLACE SPEED SENSOR FRONT RH

C

REPLACE SPEED SENSOR FRONT LH

NOTICE:

Check the speed sensor signal last (See page 05-288).

A

6**CHECK SPEED SENSOR ROTOR AND SENSOR TIP****NG****CLEAN OR REPLACE SPEED SENSOR AND
SENSOR ROTOR SERRATIONS****NOTICE:**Check the speed sensor signal last (See page [05-288](#)).**OK****CHECK AND REPLACE SKID CONTROL ECU ASSY**