

BRC

SECTION BRAKE CONTROL SYSTEM

CONTENTS

					A
					B
					C
					D
					E
					F
					G
					H
					I
					J
					K
					L
					M
					N
					O
					P
					Q
					R
					S
					T
					U
					V
					W
					X
					Y
					Z
					AA
					AB
					AC
					AD
					AE
					AF
					AG
					AH
					AI
					AJ
					AK
					AL
					AM
					AN
					AO
					AP
					AQ
					AR
					AS
					AT
					AU
					AV
					AW
					AX
					AY
					AZ
					BA
					BB
					BC
					BD
					BE
					BF
					BG
					BH
					BI
					BJ
					BK
					BL
					BM
					BN
					BO
					BP
					BQ
					BR
					BS
					BT
					BU
					BV
					BW
					BX
					BY
					BZ
					CA
					CB
					CC
					CD
					CE
					CF
					CG
					CH
					CI
					CJ
					CK
					CL
					CM
					CN
					CO
					CP
					CQ
					CR
					CS
					CT
					CU
					CV
					CW
					CX
					CY
					CZ
					DA
					DB
					DC
					DD
					DE
					DF
					DG
					DH
					DI
					DJ
					DK
					DL
					DM
					DN
					DO
					DP
					DQ
					DR
					DS
					DT
					DU
					DV
					DW
					DX
					DY
					DZ
					EA
					EB
					EC
					ED
					EE
					EF
					EG
					EH
					EI
					EJ
					EK
					EL
					EM
					EN
					EO
					EP
					EQ
					ER
					ES
					ET
					EU
					EV
					EW
					EX
					EY
					EZ
					FA
					FB
					FC
					FD
					FE
					FF
					FG
					FH
					FI
					FJ
					FK
					FL
					FM
					FN
					FO
					FP
					FQ
					FR
					FS
					FT
					FU
					FV
					FW
					FX
					FY
					FZ
					GA
					GB
					GC
					GD
					GE
					GF
					GG
					GH
					GI
					GJ
					GK
					GL
					GM
					GN
					GO
					GP
					GQ
					GR
					GS
					GT
					GU
					GV
					GW
					GX
					GY
					GZ
					HA
					HB
					HC
					HD
					HE
					HF
					HG
					HH
					HI
					HJ
					HK
					HL
					HM
					HN
					HO
					HP
					HQ
					HR
					HS
					HT
					HU
					HV
					HW
					HX
					HY
					HZ
					IA
					IB
					IC
					ID
					IE
					IF
					IG
					IH
					II
					IJ
					IK
					IL
					IM
					IN
					IO
					IP
					IQ
					IR
					IS
					IT
					IU
					IV
					IW
					IX
					IY
					IZ
					JA
					JB
					JC
					JD
					JE
					JF
					JG
					JH
					JI
					JJ
					JK
					JL
					JM
					JN
					JO
					JP
					JQ
					JR
					JS
					JT
					JU
					JV
					JW
					JX
					JY
					JZ
					KA
					KB
					KC
					KD
					KE
					KF
					KG
					KH
					KI
					KJ
					KK
					KL
					KM
					KN
					KO
					KP
					KQ
					KR
					KS
					KT
					KU
					KV
					KW
					KX
					KY
					KZ
					LA
					LB
					LC
					LD
					LE
					LF
					LG
					LH

CALIBRATION OF DECEL G SENSOR	37	Diagnosis Procedure	66
Description	37		
Work Procedure	37		
DTC/CIRCUIT DIAGNOSIS	39		
C1101, C1102, C1103, C1104 WHEEL SEN- SOR	39	C1143 STEERING ANGLE SENSOR	67
DTC Logic	39	DTC Logic	67
Diagnosis Procedure	39	Diagnosis Procedure	67
C1105, C1106, C1107, C1108 WHEEL SEN- SOR	42	C1144 INCOMPLETE STEERING ANGLE SENSOR ADJUSTMENT	69
DTC Logic	42	DTC Logic	69
Diagnosis Procedure	42	Diagnosis Procedure	69
C1109 POWER AND GROUND SYSTEM	47	C1155 BRAKE FLUID LEVEL SWITCH	70
DTC Logic	47	DTC Logic	70
Diagnosis Procedure	47	Diagnosis Procedure	70
		Component Inspection	72
C1110 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)	49	C1160 INCOMPLETE DECEL G SENSOR CALIBRATION	73
DTC Logic	49	DTC Logic	73
Diagnosis Procedure	49	Diagnosis Procedure	73
C1111 ABS MOTOR, MOTOR RELAY SYS- TEM	50	C1161 INCOMPLETE SIDE G SENSOR CAL- IBRATION	74
DTC Logic	50	DTC Logic	74
Diagnosis Procedure	50	Diagnosis Procedure	74
C1113, C1145, C1146 YAW RATE/SIDE/DE- CEL G SENSOR	51	C1162 INCOMPLETE PRESSURE SENSOR CALIBRATION	75
DTC Logic	51	DTC Logic	75
Diagnosis Procedure	51	Diagnosis Procedure	75
C1115 WHEEL SENSOR	53	C1164, C1165 CV SYSTEM	76
DTC Logic	53	DTC Logic	76
Diagnosis Procedure	53	Diagnosis Procedure	76
C1116 STOP LAMP SWITCH	58	C1166, C1167 SV SYSTEM	77
DTC Logic	58	DTC Logic	77
Diagnosis Procedure	58	Diagnosis Procedure	77
Component Inspection	59	U1000 CAN COMM CIRCUIT	78
C1120, C1122, C1124, C1126 IN ABS SOL	60	Description	78
DTC Logic	60	DTC Logic	78
Diagnosis Procedure	60	Diagnosis Procedure	78
C1121, C1123, C1125, C1127 OUT ABS SOL..	62	U1002 SYSTEM COMM (CAN)	79
DTC Logic	62	Description	79
Diagnosis Procedure	62	DTC Logic	79
C1130 ENGINE SIGNAL	64	Diagnosis Procedure	79
DTC Logic	64	POWER SUPPLY AND GROUND CIRCUIT	81
Diagnosis Procedure	64	Diagnosis Procedure	81
C1140 ACTUATOR RELAY SYSTEM	65	PARKING BRAKE SWITCH	83
DTC Logic	65	Component Function Check	83
Diagnosis Procedure	65	Diagnosis Procedure	83
C1142 PRESS SENSOR	66	Component Inspection	83
DTC Logic	66	VDC OFF SWITCH	85
		Component Function Check	85
		Diagnosis Procedure	85
		Component Inspection	86

ABS WARNING LAMP	87	NORMAL OPERATING CONDITION	97	
Component Function Check	87	Description	97	A
Diagnosis Procedure	87	REMOVAL AND INSTALLATION	98	
BRAKE WARNING LAMP	88	WHEEL SENSOR	98	B
Component Function Check	88	FRONT WHEEL SENSOR	98	
Diagnosis Procedure	88	FRONT WHEEL SENSOR : Exploded View	98	C
VDC OFF INDICATOR LAMP	89	FRONT WHEEL SENSOR : Removal and Instal- lation	98	
Component Function Check	89	REAR WHEEL SENSOR	99	D
Diagnosis Procedure	89	REAR WHEEL SENSOR : Exploded View	99	
SLIP INDICATOR LAMP	90	REAR WHEEL SENSOR : Removal and Installa- tion	99	E
Component Function Check	90	SENSOR ROTOR	100	
Diagnosis Procedure	90	FRONT SENSOR ROTOR	100	BRC
SYMPTOM DIAGNOSIS	91	FRONT SENSOR ROTOR : Exploded View	100	
EXCESSIVE ABS FUNCTION OPERATION		FRONT SENSOR ROTOR : Removal and Instal- lation	100	G
FREQUENCY	91	REAR SENSOR ROTOR	100	
Description	91	REAR SENSOR ROTOR : Exploded View	100	H
Diagnosis Procedure	91	REAR SENSOR ROTOR : Removal and Installa- tion	100	
UNEXPECTED PEDAL REACTION	92	ABS ACTUATOR AND ELECTRIC UNIT		I
Description	92	(CONTROL UNIT)	101	
Diagnosis Procedure	92	Exploded View	101	J
THE BRAKING DISTANCE IS LONG	93	Removal and Installation	101	
Description	93	YAW RATE/SIDE/DECEL G SENSOR	103	K
Diagnosis Procedure	93	Exploded View	103	
ABS FUNCTION DOES NOT OPERATE	94	Removal and Installation	103	L
Description	94	STEERING ANGLE SENSOR	104	
Diagnosis Procedure	94	Exploded View	104	
PEDAL VIBRATION OR ABS OPERATION		Removal and Installation	104	M
SOUND OCCURS	95	VDC OFF SWITCH	105	
Description	95	Removal and Installation	105	N
Diagnosis Procedure	95			O
VEHICLE JERKS DURING VDC/TCS/ABS				P
CONTROL	96			
Description	96			
Diagnosis Procedure	96			

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000007227862

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Service Procedure Precautions for Models with a Pop-up Roll Bar

INFOID:000000007256882

WARNING:

Always observe the following items for preventing accidental activation.

- Risk of passenger injury or death may increase if the pop-up roll bar does not deploy during a roll over collision. In order to reduce the chance of an incident where the pop-up roll bar is inoperative, all maintenance must be performed by a NISSAN or INFINITI dealer.
- Before removing and installing the pop-up roll bar component parts and harness, always turn the ignition switch OFF, disconnect the battery negative terminal, and wait for 3 minutes or more. (The purpose of this operation is to discharge electricity that is accumulated in the auxiliary power supply circuit in the air bag diagnosis sensor unit.)
- When repairing, removing, and installing a pop-up roll bar, always refer to SRS AIR BAG and SRS AIR BAG CONTROL warnings in the Service Manual.

Precaution for Battery Service

INFOID:000000007256883

Before disconnecting the battery, lower both the driver and passenger windows. This will prevent any interference between the window edge and the vehicle when the door is opened/closed. During normal operation, the window slightly raises and lowers automatically to prevent any window to vehicle interference. The automatic window function will not work with the battery disconnected.

PRECAUTIONS


< PRECAUTION >

[WITH VDC]

Precaution for Procedure without Cowl Top Cover

INFOID:000000007227865

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc to prevent damage to windshield.



Precaution for Brake System


INFOID:000000006941650

WARNING:

Since dust covering the front and rear brakes has an affect on human body, the dust must be removed with a dust collector. Never splatter the dust with an air blow gun.

CAUTION:

- Brake fluid use refer to [MA-10, "Fluids and Lubricants"](#).
- Never reuse drained brake fluid.
- Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface.
- Never use mineral oils such as gasoline or light oil to clean. They may damage rubber parts and cause improper operation.
- Always loosen the brake tube flare nut with a flare nut wrench.
- Tighten the brake tube flare nut to the specified torque with crowfoot (A) and torque wrench (B).
- Always confirm the specified tightening torque when installing the brake pipes.
- Turn the ignition switch OFF and disconnect the ABS actuator and electric unit (control unit) connector or the battery negative terminal before performing the work.
- Check that no brake fluid leakage is present after replacing the parts.



Precaution for Brake Control

INFOID:000000006941651

- When starting engine or when starting vehicle just after starting engine, brake pedal may vibrate or motor operating noise may be heard from engine compartment. This is normal condition.
- When an error is indicated by ABS or another warning lamp, collect all necessary information from customer (what symptoms are present under what conditions) and check for estimate causes before starting diagnostic servicing. Besides electrical system inspection, check brake booster operation, brake fluid level, and oil leaks.
- If tire size and type are used in an improper combination, or brake pads are not Genuine NISSAN parts, stopping distance or steering stability may deteriorate.
- ABS might be out of order or malfunctions by putting a radio (wiring inclusive), an antenna and a lead-in wire near the control unit.
- If aftermarket parts (car stereo, CD player, etc.) have been installed, check for incidents such as harness pinches, open circuits, and improper wiring.
- VDC system may not operate normally or a VDC OFF indicator lamp or SLIP indicator lamp may light.
- When replacing the following parts with parts other than genuine parts or making modifications: Suspension-related parts (shock absorber, spring, bushing, etc.), tires, wheels (other than specified sizes), brake-related parts (pad, rotor, caliper, etc.), engine-related parts (muffler, ECM, etc.) and body reinforcement-related parts (roll bar, tower bar, etc.).
- When driving with worn or deteriorated suspension, tires and brake-related parts.

PRECAUTIONS


< PRECAUTION >

[WITH VDC]


Precaution for Harness Repair

INFOID:000000007229484

- Solder the repair part, and wrap it with tape. [Twisted wire fray must be 110 mm (4.33 in) or less.]



- Never bypass the repair point with wire. (If it is bypassed, the turn-out point cannot be separated and the twisted wire characteristics are lost.)



PREPARATION

< PREPARATION >

[WITH VDC]


PREPARATION

PREPARATION

Commercial Service Tool

INFOID:000000007227858

Tool name	Description
Power tool	Loosening bolts and nuts



A

B

C

D

E

BRC

G

H

I

J

K

L

M

N

O


P

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:000000006941490



COMPONENT PARTS

< SYSTEM DESCRIPTION >

[WITH VDC]

- | | | |
|----------------------------------|---------------------------------|--|
| 1. Steering angle sensor | 2. ABS warning lamp | 3. Brake warning lamp |
| 4. VDC OFF indicator lamp | 5. SLIP indicator lamp | 6. ABS actuator and electric unit (control unit) |
| 7. Front wheel sensor | 8. Yaw rate/side/decel G sensor | 9. VDC OFF switch |
| 10. Rear wheel sensor | | |
| A. Back of spiral cable assembly | B. Combination meter | C. Engine room (right side) |
| D. Steering knuckle | E. Under center console | F. Instrument driver lower panel |
| G. Rear axle | | |

Component Description

INFOID:000000006941491

Component parts		Reference
ABS actuator and electric unit (control unit)	Pump	BRC-9, "ABS Actuator and Electric Unit (Control Unit)"
	Motor	
	Actuator relay (Main relay)	
	ABS IN valve	
	ABS OUT valve	
	Pressure sensor	
	Motor relay	
	Cut valve 1, Cut valve2	
	Suction Valve 1, Suction Valve 2	
Wheel sensor		BRC-10, "Wheel Sensor and Sensor Rotor"
Stop lamp switch		BRC-10, "Stop Lamp Switch"
Steering angle sensor		BRC-10, "Steering Angle Sensor"
Yaw rate/side/decel G sensor		BRC-10, "Yaw Rate/Side/Decel G Sensor"
Brake fluid level switch		BRC-10, "Brake Fluid Level Switch"
VDC OFF switch		BRC-10, "VDC OFF Switch"
ABS warning lamp		BRC-11, "System Description"
Brake warning lamp		
VDC OFF indicator lamp		
SLIP indicator lamp		

ABS Actuator and Electric Unit (Control Unit)

INFOID:000000007227881

Electric unit (control unit) is integrated with actuator and comprehensively controls VDC function, TCS function, ABS function and EBD function.

ELECTRIC UNIT (CONTROL UNIT)

- Brake fluid pressure, engine and transaxle are controlled according to signals from each sensor.
- If malfunction is detected, the system enters fail-safe mode.

ACTUATOR

The following components are integrated with ABS actuator.

Pump

The pump returns the brake fluid stored in the reservoir to the master cylinder by reducing the pressure.

Motor

The motor drives the pump according to the signals transmitted by the ABS actuator and electric unit (control unit).

Motor Relay

Activates or deactivates motor according to the signals transmitted by the ABS actuator and electric unit (control unit).

Actuator Relay (Main Relay)

Activates or deactivates each solenoid valve according to the signals transmitted by the ABS actuator and electric unit (control unit).

ABS IN Valve

The solenoid valve increases, holds or decreases the fluid pressure of each brake caliper according to the signals transmitted by the ABS actuator and electric unit (control unit).

ABS OUT Valve

The solenoid valve increases, holds or decreases the fluid pressure of each brake caliper according to the signals transmitted by the ABS actuator and electric unit (control unit).

Cut Valve 1, Cut Valve 2

The cut valve shuts off the normal brake fluid path from the master cylinder, when VDC/TCS is activated.

Suction Valve 1, Suction Valve 2

The suction valve supplies the brake fluid from the master cylinder to the pump, when VDC/TCS is activated.

Pressure Sensor

The pressure sensor converts the brake fluid pressure to an electric signal and transmits it to the ABS actuator and electric unit (control unit). [The pressure sensor is integrated in the ABS actuator and electric unit (control unit).]

Wheel Sensor and Sensor Rotor

INFOID:000000006941505

When the sensor rotor rotates, the magnetic field changes. It converts the magnetic field changes to current signals (rectangular wave) and transmits them to the ABS actuator and electric unit (control unit).

Stop Lamp Switch

INFOID:000000006941539

The stop lamp switch transmits the stop lamp switch signal (ON/OFF) to the ABS actuator and electric unit (control unit).

Steering Angle Sensor

INFOID:000000006941568

The steering angle sensor detects the rotation amount, angular velocity and direction of the steering wheel, and transmits the data to the ABS actuator and electric unit (control unit) via CAN communication.

Yaw Rate/Side/Decel G Sensor

INFOID:000000006941529

Yaw rate/side/decel G sensor detects yaw rate/side/decel G affecting the vehicle, and transmits the data to the ABS actuator and electric unit (control unit) as an analog voltage signal.

Brake Fluid Level Switch

INFOID:000000006941578

The brake fluid level switch converts the brake fluid level to an electric signal and transmits it to the ABS actuator and electric unit (control unit).

VDC OFF Switch

INFOID:000000006941619

VDC OFF switch can deactivate (turn OFF) the VDC/TCS function by pressing the VDC OFF switch.


SYSTEM

System Description

INFOID:000000007227889

- The system switches fluid pressure of each brake caliper to increase, to hold or to decrease according to signals from control unit in ABS actuator and electric unit (control unit). This control system is applied to VDC function, TCS function, ABS function and EBD function.
- Fail-safe function is available for each function and is activated by each function when system malfunction occurs.

SYSTEM DIAGRAM



CONDITION FOR TURN ON THE WARNING LAMP

ABS Warning Lamp

×: ON –: OFF

Condition	ABS warning lamp
Ignition switch OFF	–
For 2 seconds after turning ignition switch ON	×
2 seconds later after turning ignition switch ON	–
ABS function is malfunctioning.	×
EBD function is malfunctioning.	×

Brake Warning Lamp

×: ON –: OFF

Condition	Brake warning lamp (Note 1)
Ignition switch OFF	–
For 2 seconds after turning ignition switch ON	× (Note 2)
2 seconds later after turning ignition switch ON	× (Note 2)
EBD function is malfunctioning.	×

NOTE:

SYSTEM

< SYSTEM DESCRIPTION >

[WITH VDC]

- 1: Brake warning lamp will turn on in case of parking brake operation (when switch is ON) or of brake fluid level switch operation (when brake fluid is insufficient).
- 2: After starting the engine, brake warning lamp is turned off.

CONDITION FOR TURN ON THE INDICATOR LAMP

VDC OFF Indicator Lamp

×: ON –: OFF

Condition	VDC OFF indicator lamp
Ignition switch OFF	–
For 2 seconds after turning ignition switch ON	×
2 seconds later after turning ignition switch ON	–
VDC OFF switch turned ON. (VDC function is OFF.)	×
VDC/TCS function is malfunctioning.	×
ABS function is malfunctioning.	×
EBD function is malfunctioning.	×

SLIP Indicator Lamp

×: ON Δ: Blink –: OFF

Condition	SLIP indicator lamp
Ignition switch OFF	–
For 2 seconds after turning ignition switch ON	×
2 seconds later after turning ignition switch ON	–
VDC/TCS is activated while driving.	Δ
VDC/TCS function is malfunctioning.	×
ABS function is malfunctioning.	×
EBD function is malfunctioning.	×

Fail-Safe

INFOID:000000007227891

ABS, EBD SYSTEM

If ABS malfunction electrically, ABS warning lamp, VDC OFF indicator lamp, SLIP indicator lamp will turn on. If EBD malfunction electrically, brake warning lamp, ABS warning lamp, VDC OFF indicator lamp and SLIP indicator lamp will turn on. Simultaneously, the VDC/TCS/ABS become one of the following conditions of the fail-safe function.

- For malfunction of ABS, only the EBD is activated and the condition of vehicle is the same condition of vehicles without TCS/ABS system.

NOTE:

ABS self-diagnosis sound may be heard. That is a normal condition because a self-diagnosis for "Ignition switch ON" and "The first starting" are being performed.

- For malfunction of EBD, EBD and ABS become inoperative, and the condition of vehicle is the same as the condition of vehicles without TCS/ABS, EBD system.

VDC/TCS

If VDC/TCS/ABS system malfunction electrically, VDC OFF indicator lamp, SLIP indicator lamp are turned on, and the condition of vehicle is the same as the condition of vehicles without VDC/TCS control.

CAUTION:

If the Fail-Safe function is activated, then perform self-diagnosis for "ABS" with CONSULT.

VDC FUNCTION

VDC FUNCTION : System Description

INFOID:000000006941489

- In addition to the TCS/ABS function, the driver steering amount and brake operation amount are detected by the steering angle sensor and pressure sensor, and the vehicle's driving status (amount of under steering/over steering) is determined by the information from the yaw rate/side/decel G sensor, wheel sensor, etc.,

SYSTEM

< SYSTEM DESCRIPTION >

[WITH VDC]

and this information is used to improve vehicle stability by controlling the braking and engine power to all four wheels.

- During VDC operation, it informs driver of system operation by blinking the SLIP indicator lamp.
- Electrical system diagnosis by CONSULT is available.

TCS FUNCTION

TCS FUNCTION : System Description

INFOID:0000000006941493

- The wheel spin of the drive wheels is detected by the ABS actuator and electric unit (control unit) using the wheel speed signals from the four wheels, so if wheel spin occurs, the drive wheel right and left brake fluid pressure control and engine fuel cut are conducted while the throttle valve opening is restricted to reduce the engine torque and decrease the amount of wheel spin. In addition, the throttle opening is controlled to achieve the optimum engine torque.
- During TCS operation, TCS informs driver of system operation by blinking the SLIP indicator lamp.
- Electrical system diagnosis by CONSULT is available.

ABS FUNCTION

ABS FUNCTION : System Description

INFOID:0000000006941497

- The Anti-Lock Braking System detects wheel revolution while braking, and it improves handling stability during sudden braking by electrically preventing 4 wheel lock. Maneuverability is also improved for avoiding obstacles.
- Electrical system diagnosis by CONSULT is available.

EBD FUNCTION

EBD FUNCTION : System Description

INFOID:0000000006941501

- Electronic Brake force Distribution detects subtle slippages between front and rear wheels during braking, and it improves handling stability by electronically controlling brake fluid pressure which results in reduced rear wheel slippage.
- Electrical system diagnosis by CONSULT is available.

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[WITH VDC]

DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

CONSULT Function

INFOID:000000006941504

APPLICATION ITEMS

CONSULT can display each diagnostic item using the diagnostic test modes as following.

Mode	Function
Work support	This mode enables a technician to adjust some devices faster and more accurately by following the indications on CONSULT.
Self diagnostic result	Self-diagnostic results can be read and erased quickly.
Data monitor	Input/Output data in the ABS actuator and electric unit (control unit) can be read.
Active test	CONSULT drives some actuators apart from the ABS actuator and electric unit (control unit) and also shifts some parameters in a specified range.
ECU identification	ABS actuator and electric unit (control unit) part number can be read.

WORK SUPPORT

Item	Description
ST ANGLE SENSOR ADJUSTMENT	Adjusts the neutral position of the steering angle sensor.
DECEL G SEN CALIBRATION	Calibrates decel G sensor.

SELF DIAGNOSTIC RESULT

Operation Procedure

Before performing the self-diagnosis for "ABS" with CONSULT, start the engine and drive the vehicle at 30 km/h (19 MPH) or more for approximately 1 minute.

Display Item List

Refer to [BRC-23, "DTC No. Index"](#).

How to Erase Self-diagnosis Results

After erasing DTC memory for "ABS" with CONSULT, start the engine and drive the vehicle at 30 km/h (19 MPH) or more for approximately 1 minute as the final inspection, and make sure that the ABS warning lamp, VDC OFF indicator lamp, SLIP indicator lamp and brake warning lamp turn OFF.

CAUTION:

If memory cannot be erased, perform applicable diagnosis.

NOTE:

- When the wheel sensor malfunctions, after inspecting the wheel sensor system, the ABS warning lamp, VDC OFF indicator lamp, SLIP indicator lamp and brake warning lamp will not turn OFF even when the system is normal unless the vehicle is driving at approximately 30 km/h (19 MPH) or more for approximately 1 minute.
- Brake warning lamp will turn ON in case of parking brake operation (when switch is ON) or of brake fluid level switch operation (when brake fluid is insufficient).
- VDC OFF switch should not stay "ON" position.

DATA MONITOR

Display Item List

DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[WITH VDC]

×: Applicable ▼: Optional item

Monitor item (Unit)	SELECT MONITOR ITEM		Remarks
	ECU INPUT SIGNALS	MAIN SIGNALS	
FR LH SENSOR [km/h (MPH)]	×	×	Wheel speed
FR RH SENSOR [km/h (MPH)]	×	×	
RR LH SENSOR [km/h (MPH)]	×	×	
RR RH SENSOR [km/h (MPH)]	×	×	
STOP LAMP SW (On/Off)	×	×	Stop lamp switch signal status
BATTERY VOLT (V)	×	×	Battery voltage supplied to the ABS actuator and electric unit (control unit)
GEAR	×	×	Gear position determined by TCM
R POSI SIG (On/Off)	▼	▼	Shift position judged by shift position (R) signal
N POSI SIG (On/Off)	▼	▼	Shift position judged by shift position (N) signal
P POSI SIG (On/Off)	▼	▼	Shift position judged by shift position (P) signal
SLCT LVR POSI	×	×	Shift position judged by shift position signal
OFF SW (On/Off)	×	×	VDC OFF switch
YAW RATE SEN (d/s)	×	×	Yaw rate detected by yaw rate/side/decel G sensor
DECEL G-SEN (G)	×	×	Decel G detected by yaw rate/side/decel G sensor
ACCEL POS SIG (%)	×	▼	Throttle actuator opening/closing is displayed (Linked with accelerator pedal)
SIDE G-SENSOR (m/s ²)	×	▼	Transverse G detected by yaw rate/side/decel G sensor
STR ANGLE SIG (°)	×	▼	Steering angle detected by steering angle sensor
ENGINE RPM [tr/min (rpm)]	×	▼	Engine speed
FLUID LEV SW (On/Off)	×	▼	Brake fluid level switch
PRESS SENSOR (bar)	×	▼	Brake fluid pressure detected by pressure sensor

A

B

C

D

E

BRC

G

H

I

J

K

L

M

N

O

P

DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[WITH VDC]

Monitor item (Unit)	SELECT MONITOR ITEM		Remarks
	ECU INPUT SIGNALS	MAIN SIGNALS	
FR RH IN SOL (On/Off)	▼	×	Operation status of each ABS IN valve or each ABS OUT valve
FR RH OUT SOL (On/Off)	▼	×	
FR LH IN SOL (On/Off)	▼	×	
FR LH OUT SOL (On/Off)	▼	×	
RR RH IN SOL (On/Off)	▼	×	
RR RH OUT SOL (On/Off)	▼	×	
RR LH IN SOL (On/Off)	▼	×	
RR LH OUT SOL (On/Off)	▼	×	
MOTOR RELAY (On/Off)	▼	×	Motor and motor relay operation
ACTUATOR RLY (On/Off)	▼	×	Actuator relay operation
ABS WARN LAMP (On/Off)	▼	×	ABS warning lamp
OFF LAMP (On/Off)	▼	×	VDC OFF indicator lamp
SLIP/VDC LAMP (On/Off)	▼	×	SLIP indicator lamp
CV1 (On/Off)	▼	▼	Cut valve 1 monitor
CV2 (On/Off)	▼	▼	Cut valve 2 monitor
SV1 (On/Off)	▼	▼	Suction valve 1 monitor
SV2 (On/Off)	▼	▼	Suction valve 2 monitor
EBD SIGNAL (On/Off)	▼	▼	EBD operation
ABS SIGNAL (On/Off)	▼	▼	ABS operation
TCS SIGNAL (On/Off)	▼	▼	TCS operation
VDC SIGNAL (On/Off)	▼	▼	VDC operation
EBD FAIL SIG (On/Off)	▼	▼	EBD fail-safe status
ABS FAIL SIG (On/Off)	▼	▼	ABS fail-safe status
TCS FAIL SIG (On/Off)	▼	▼	TCS fail-safe status
VDC FAIL SIG (On/Off)	▼	▼	VDC fail-safe status

DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[WITH VDC]

Monitor item (Unit)	SELECT MONITOR ITEM		Remarks
	ECU INPUT SIGNALS	MAIN SIGNALS	
EBD WARN LAMP (On/Off)	▼	▼	Brake warning lamp
CRANKING SIG (On/Off)	▼	▼	Crank operation
4WD FAIL REQ (On/Off)	▼	▼	AWD fail-safe signal status
2WD/4WD (2WD/4WD)	▼	▼	Distinguish 2WD and AWD

NOTE:

A brief moment of On/Off condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is a operation for checking.

ACTIVE TEST MODE

CAUTION:

- **Never perform active test while driving vehicle.**
- **Make sure to completely bleed air from brake system.**
- **The active test cannot be started when ABS warning lamp, VDC OFF indicator lamp, SLIP indicator lamp and brake warning lamp is ON.**
- **ABS warning lamp, VDC OFF indicator lamp, SLIP indicator lamp and brake warning lamp are ON during active test.**

NOTE:

- When active test is performed while depressing the pedal, the pedal depression amount will change. This is normal. (Only solenoid valve and ABS motor.)
- "TEST IS STOPPED" in "ABS" with CONSULT is displayed 10 seconds after operation start.
- After "TEST IS STOPPED" in "ABS" with CONSULT is displayed, to perform test again.

Test Item

ABS SOLENOID VALVE

- Select "Up", "Keep" and "Down" of "ACTIVE TEST" in "ABS" with CONSULT. Then use screen monitor to check that solenoid valve operates as shown in the table below.

Test item	Display item	Display		
		Up	Keep	Down
FR RH SOL	FR RH IN SOL	Off	On	On
	FR RH OUT SOL	Off	Off	On*
FR LH SOL	FR LH IN SOL	Off	On	On
	FR LH OUT SOL	Off	Off	On*
RR RH SOL	RR RH IN SOL	Off	On	On
	RR RH OUT SOL	Off	Off	On*
RR LH SOL	RR LH IN SOL	Off	On	On
	RR LH OUT SOL	Off	Off	On*

*: On for 1 to 2 seconds after the select, and then Off.

NOTE:

A brief moment of On/Off condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is a operation for checking.

ABS SOLENOID VALVE (ACT)

- Select "Up", "ACT UP" and "ACT KEEP" of "ACTIVE TEST" in "ABS" with CONSULT. Then use screen monitor to check that solenoid valve operates as shown in the table below.

DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[WITH VDC]

Test item	Display item	Display		
		Up	ACT UP	ACT KEEP
FR RH ABS SOLENOID (ACT)	FR RH IN SOL	Off	Off	Off
	FR RH OUT SOL	Off	Off	Off
	CV1	Off	On	On
	SV1	Off	On*	Off
FR LH ABS SOLENOID (ACT)	FR LH IN SOL	Off	Off	Off
	FR LH OUT SOL	Off	Off	Off
	CV2	Off	On	On
	SV2	Off	On*	Off
RR RH ABS SOLENOID (ACT)	RR RH IN SOL	Off	Off	Off
	RR RH OUT SOL	Off	Off	Off
	CV2	Off	On	On
	SV2	Off	On*	Off
RR LH ABS SOLENOID (ACT)	RR LH IN SOL	Off	Off	Off
	RR LH OUT SOL	Off	Off	Off
	CV1	Off	On	On
	SV1	Off	On*	Off

*: On for 1 to 2 seconds after the select, and then Off.

NOTE:

A brief moment of On/Off condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is a operation for checking.

ABS MOTOR

- Select "On" and "Off" of "ACTIVE TEST" in "ABS" with CONSULT. Make sure motor relay and actuator relay operates as shown in table below.

Test item	Display item	Display	
		On	Off
ABS MOTOR	MOTOR RELAY	On	Off
	ACTUATOR RLY	On	On

NOTE:

A brief moment of On/Off condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is a operation for checking.

ECU IDENTIFICATION

ABS actuator and electric unit (control unit) part number can be read.

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[WITH VDC]

ECU DIAGNOSIS INFORMATION

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Reference Value

INFOID:000000006941637

VALUES ON THE DIAGNOSIS TOOL

CAUTION:

The display shows the control unit calculation data, so a normal value might be displayed even in the event the output circuit (harness) is open or short-circuited.

Monitor item	Display content	Data monitor	
		Condition	Reference value in normal operation
FR LH SENSOR	Wheel speed	Vehicle stopped	0 [km/h (MPH)]
		Vehicle running (Note 1)	Nearly matches the speedometer display (± 10% or less)
FR RH SENSOR	Wheel speed	Vehicle stopped	0 [km/h (MPH)]
		Vehicle running (Note 1)	Nearly matches the speedometer display (± 10% or less)
RR LH SENSOR	Wheel speed	Vehicle stopped	0 [km/h (MPH)]
		Vehicle running (Note 1)	Nearly matches the speedometer display (± 10% or less)
RR RH SENSOR	Wheel speed	Vehicle stopped	0 [km/h (MPH)]
		Vehicle running (Note 1)	Nearly matches the speedometer display (± 10% or less)
STOP LAMP SW	Brake pedal operation	When brake pedal is depressed	On
		When brake pedal is not depressed	Off
BATTERY VOLT	Battery voltage supplied to the ABS actuator and electric unit (control unit)	Ignition switch ON	10 – 16 V
GEAR	Gear position	Vehicle running	1 – 6
R POSI SIG	Select shift position	CVT shift position (R)	On
		CVT shift position (other R)	Off
N POSI SIG	Select shift position	CVT shift position (N)	On
		CVT shift position (other N)	Off
P POSI SIG	Select shift position	CVT shift position (P)	On
		CVT shift position (other P)	Off
SLCT LVR POSI	Select shift position	CVT shift position (P, R, N, D, L)	P R N D L
		Manual mode	##
OFF SW	VDC OFF switch ON/OFF status	VDC OFF switch ON (When VDC OFF indicator lamp is ON)	On
		VDC OFF switch OFF (When VDC OFF indicator lamp is OFF)	Off
YAW RATE SEN	Yaw rate detected by yaw rate/side/decel sensor	Vehicle stopped	Approx. 0 d/s
		Vehicle running	–100 to 100 d/s

A

B

C

D

E

BRC

G

H

I

J

K

L

M

N

O

P

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[WITH VDC]

Monitor item	Display content	Data monitor	
		Condition	Reference value in normal operation
DECEL G-SEN	Decel G detected by yaw rate/side/decel G sensor	Vehicle stopped	Approx. 0 G
		Vehicle running	-1.7 – +1.7 G
ACCEL POS SIG	Open/Close condition of throttle valve (Linked with accelerator pedal)	Accelerator pedal not depressed (Engine stopped)	0 %
		Depress accelerator pedal (Engine stopped)	0 - 100 %
SIDE G-SENSOR	Transverse G detected by yaw rate/side/decel G sensor	Vehicle stopped	Approx. 0 m/s ²
		Vehicle running	- 16.7 – 16.7 m/s ²
STR ANGLE SIG	Steering angle detected by steering angle sensor	Driving straight	-3.5 – +3.5°
		Turn 90 ° to right	Approx. -90 °
		Turn 90 ° to left	Approx. +90 °
ENGINE RPM	With engine running	With engine stopped	0 [tr/min (rpm)]
		Engine running	Almost in accordance with tachometer display
FLUID LEV SW	Brake fluid level switch signal status	When brake fluid level switch ON	On
		When brake fluid level switch OFF	Off
PRESS SENSOR	Brake fluid pressure detected by pressure sensor	With ignition switch ON and brake pedal released	Approx. 0 bar
		With ignition switch ON and brake pedal depressed	0 – 170 bar
FR RH IN SOL (Note 2)	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
FR RH OUT SOL (Note 2)	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
FR LH IN SOL (Note 2)	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
FR LH OUT SOL (Note 2)	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
RR RH IN SOL (Note 2)	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[WITH VDC]

Monitor item	Display content	Data monitor	
		Condition	Reference value in normal operation
RR RH OUT SOL (Note 2)	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
RR LH IN SOL (Note 2)	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
RR LH OUT SOL (Note 2)	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
MOTOR RELAY	Motor and motor relay operation	Ignition switch ON or engine running (ABS operated)	On
		Ignition switch ON or engine running (ABS not operated)	Off
ACTUATOR RLY (Note 2)	Actuator relay operation	Vehicle stopped (Engine running)	On
		Vehicle stopped (Ignition switch ON)	Off
ABS WARN LAMP	ABS warning lamp (Note 3)	When ABS warning lamp is ON	On
		When ABS warning lamp is OFF	Off
OFF LAMP	VDC OFF indicator lamp (Note 3)	When VDC OFF indicator lamp is ON	On
		When VDC OFF indicator lamp is OFF	Off
SLIP/VDC LAMP	SLIP indicator lamp (Note 3)	When SLIP indicator lamp is ON	On
		When SLIP indicator lamp is blinking	
		When SLIP indicator lamp is OFF	Off
CV1	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
CV2	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
SV1	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
SV2	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off

A

B

C

D

E

BRC

G

H

I

J

K

L

M

N

O

P

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[WITH VDC]

Monitor item	Display content	Data monitor	
		Condition	Reference value in normal operation
EBD SIGNAL	EBD operation	EBD is active	On
		EBD is inactive	Off
ABS SIGNAL	ABS operation	ABS is active	On
		ABS is inactive	Off
TCS SIGNAL	TCS operation	TCS is active	On
		TCS is inactive	Off
VDC SIGNAL	VDC operation	VDC is active	On
		VDC is inactive	Off
EBD FAIL SIG	EBD fail-safe signal	In EBD fail-safe	On
		EBD is normal	Off
ABS FAIL SIG	ABS fail-safe signal	In ABS fail-safe	On
		ABS is normal	Off
TCS FAIL SIG	TCS fail-safe signal	In TCS fail-safe	On
		TCS is normal	Off
VDC FAIL SIG	VDC fail-safe signal	In VDC fail-safe	On
		VDC is normal	Off
EBD WARN LAMP	Brake warning lamp (Note 3)	When brake warning lamp is ON	On
		When brake warning lamp is OFF	Off
CRANKING SIG	Crank operation	Crank is active	On
		Crank is inactive	Off
4WD FAIL REQ	AWD fail status	AWD fail	On
		AWD normal	Off
2WD/4WD	Drive axle	2WD model	2WD
		AWD model	4WD

NOTE:

- 1: Confirm tire pressure is normal.
- 2: A brief moment of On/Off condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is a operation for checking.
- 3: On and off timing for warning lamp and indicator lamp. Refer to [BRC-11, "System Description"](#).

Fail-Safe

INFOID:0000000006941639

ABS, EBD SYSTEM

If ABS malfunction electrically, ABS warning lamp, VDC OFF indicator lamp, SLIP indicator lamp will turn on. If EBD malfunction electrically, brake warning lamp, ABS warning lamp, VDC OFF indicator lamp and SLIP indicator lamp will turn on. Simultaneously, the VDC/TCS/ABS become one of the following conditions of the fail-safe function.

- For malfunction of ABS, only the EBD is activated and the condition of vehicle is the same condition of vehicles without TCS/ABS system.

NOTE:

ABS self-diagnosis sound may be heard. That is a normal condition because a self-diagnosis for "Ignition switch ON" and "The first starting" are being performed.

- For malfunction of EBD, EBD and ABS become inoperative, and the condition of vehicle is the same as the condition of vehicles without TCS/ABS, EBD system.

VDC/TCS

If VDC/TCS/ABS system malfunction electrically, VDC OFF indicator lamp, SLIP indicator lamp are turned on, and the condition of vehicle is the same as the condition of vehicles without VDC/TCS control.

CAUTION:

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[WITH VDC]

If the Fail-Safe function is activated, then perform self-diagnosis for "ABS" with CONSULT.

DTC Inspection Priority Chart

INFOID:000000007227892

When multiple DTCs are displayed simultaneously, check one by one depending on the following priority list.

Priority	Detected item (DTC)
1	- U1000 CAN COMM CIRCUIT - U1002 SYSTEM COMM(CAN)
2	C1110 CONTROLLER FAILURE
3	C1130 ENGINE SIGNAL 1
4	- C1109 BATTERY VOLTAGE [ABNORMAL] - C1111 PUMP MOTOR - C1140 ACTUATOR RLY
5	- C1101 RR RH SENSOR-1 - C1102 RR LH SENSOR-1 - C1103 FR RH SENSOR-1 - C1104 FR LH SENSOR-1 - C1105 RR RH SENSOR-2 - C1106 RR LH SENSOR-2 - C1107 FR RH SENSOR-2 - C1108 FR LH SENSOR-2 - C1113 G SENSOR - C1115 ABS SENSOR [ABNORMAL SIGNAL] - C1116 STOP LAMP SW - C1120 FR LH IN ABS SOL - C1121 FR LH OUT ABS SOL - C1122 FR RH IN ABS SOL - C1123 FR RH OUT ABS SOL - C1124 RR LH IN ABS SOL - C1125 RR LH OUT ABS SOL - C1126 RR RH IN ABS SOL - C1127 RR RH OUT ABS SOL - C1142 PRESS SEN CIRCUIT - C1143 ST ANG SEN CIRCUIT - C1144 ST ANG SEN SIGNAL - C1145 YAW RATE SENSOR - C1146 SIDE G-SEN CIRCUIT - C1160 DECEL G SEN SET - C1161 SIDE G SEN SET - C1162 PRESS SEN SET - C1164 CV1 - C1165 CV2 - C1166 SV1 - C1167 SV2
6	C1155 BR FLUID LEVEL LOW

DTC No. Index

INFOID:0000000006941640

DTC	Items (CONSULT screen terms)	Reference
C1101	RR RH SENSOR-1	BRC-39, "DTC Logic"
C1102	RR LH SENSOR-1	
C1103	FR RH SENSOR-1	
C1104	FR LH SENSOR-1	
C1105	RR RH SENSOR-2	BRC-42, "DTC Logic"
C1106	RR LH SENSOR-2	
C1107	FR RH SENSOR-2	
C1108	FR LH SENSOR-2	

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >


[WITH VDC]

DTC	Items (CONSULT screen terms)	Reference
C1109	BATTERY VOLTAGE [ABNORMAL]	BRC-47, "DTC Logic"
C1110	CONTROLLER FAILURE	BRC-49, "DTC Logic"
C1111	PUMP MOTOR	BRC-50, "DTC Logic"
C1113	G SENSOR	BRC-51, "DTC Logic"
C1115	ABS SENSOR [ABNORMAL SIGNAL]	BRC-53, "DTC Logic"
C1116	STOP LAMP SW	BRC-58, "DTC Logic"
C1120	FR LH IN ABS SOL	BRC-60, "DTC Logic"
C1121	FR LH OUT ABS SOL	BRC-62, "DTC Logic"
C1122	FR RH IN ABS SOL	BRC-60, "DTC Logic"
C1123	FR RH OUT ABS SOL	BRC-62, "DTC Logic"
C1124	RR LH IN ABS SOL	BRC-60, "DTC Logic"
C1125	RR LH OUT ABS SOL	BRC-62, "DTC Logic"
C1126	RR RH IN ABS SOL	BRC-60, "DTC Logic"
C1127	RR RH OUT ABS SOL	BRC-62, "DTC Logic"
C1130	ENGINE SIGNAL 1	BRC-64, "DTC Logic"
C1140	ACTUATOR RLY	BRC-65, "DTC Logic"
C1142	PRESS SEN CIRCUIT	BRC-66, "DTC Logic"
C1143	ST ANG SEN CIRCUIT	BRC-67, "DTC Logic"
C1144	ST ANG SEN SIGNAL	BRC-69, "DTC Logic"
C1145	YAW RATE SENSOR	BRC-51, "DTC Logic"
C1146	SIDE G-SEN CIRCUIT	
C1155	BR FLUID LEVEL LOW	BRC-70, "DTC Logic"
C1160	DECEL G SEN SET	BRC-73, "DTC Logic"
C1161	SIDE G SEN SET	BRC-74, "DTC Logic"
C1162	PRESS SEN SET	BRC-75, "DTC Logic"
C1164	CV1	BRC-76, "DTC Logic"
C1165	CV2	
C1166	SV1	BRC-77, "DTC Logic"
C1167	SV2	
U1000	CAN COMM CIRCUIT	BRC-78, "DTC Logic"
U1002	SYSTEM COMM(CAN)	BRC-79, "DTC Logic"

[WITH VDC]

Wiring Diagram

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P




BRAKE CONTROL SYSTEM

[WITH VDC]

< WIRING DIAGRAM >


BRAKE CONTROL SYSTEM

Connector No.	B4
Connector Name	WIRE TO WIRE
Connector Type	NS(BMW-OS)



Terminal No.	Color of Wire	Signal Name [Specification]
1	SB	-
2	W	-
3	Y	-
4	R	-
5	P	-
6	L	-
7	B	-
8	LG	-
9	V	-
10	BR	-
11	L	-
12	BR	-
13	P	-
14	GR	-
15	BR	-
16	G	-

Connector No.	B46
Connector Name	WIRE TO WIRE
Connector Type	RH12FB




Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	O	-
3	GR	-
4	BR	-
5	W	-
6	P	-

Connector No.	C2
Connector Name	WIRE TO WIRE
Connector Type	RH12MB



Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
2	SB	-
3	V	-
4	R	-
5	P	-
6	L	-
7	R	-
8	L	-
9	P	-

Connector No.	C5
Connector Name	REAR WHEEL SENSOR LH
Connector Type	RK02ML




Terminal No.	Color of Wire	Signal Name [Specification]
5	L	-
6	R	-

Connector No.	C6
Connector Name	REAR WHEEL SENSOR RH
Connector Type	RK02GY



Terminal No.	Color of Wire	Signal Name [Specification]
7	P	-
8	V	-

Connector No.	E10
Connector Name	BRAKE R INTELLIGENT POWER DISTRIBUTION MODULE (WIRING SIGNAL)
Connector Type	TH20FW-OS12-M4-1V



Terminal No.	Color of Wire	Signal Name [Specification]
4	LG	-
5	V	-
7	GR	-
10	BR	-
12	B	-
13	SB	-
15	W	-
16	R	-
19	Y	-
20	L	-
21	O	-
22	SB	-
23	GR	-
24	G	-
25	GR	-
26	Y	-
27	W	-
28	SB	-
30	BR	-
34	O	-
35	Y	-
38	G	-
38	W	-

Connector No.	E22
Connector Name	FRONT WHEEL SENSOR LH
Connector Type	RH02MB



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
2	V	-

Connector No.	E27
Connector Name	PARKING BRAKE SWITCH
Connector Type	P01FB-A



Terminal No.	Color of Wire	Signal Name [Specification]
1	P	-

JCFWA0470GB

BRAKE CONTROL SYSTEM

< WIRING DIAGRAM >

[WITH VDC]

BRAKE CONTROL SYSTEM

Connector No.	E36
Connector Name	ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)
Connector Type	AEZ22PB-AJ24-LH

Terminal No.	26	25	23	22	21	20	19	18	14	13
Signal Name [Specification]	WSS FL SIG (-)	WSS FL SIG (+)	WSS RL SIG (-)	WSS RL SIG (+)	WSS FR SIG (-)	WSS FR SIG (+)	WSS RR SIG (-)	WSS RR SIG (+)	WSS LR SIG (-)	WSS LR SIG (+)



Terminal No.	1	2	3	4	5	6	7	8	9	10	11	12	13	14	16	19	20	21	22	23	25	26
Color of Wire	R	Y	L	GR	B	W	LG	V	W	SB	P	V	B/W	G	SB	BR	GR	P	Y	L	W	B/W
Signal Name [Specification]	VALVE / ECU SUPPLY	WSS RL SIG (-)	WSS RL SIG (+)	CLUSTER SUPPLY	WSS FR SIG (-)	WSS FR SIG (+)	WSS RR SIG (-)	WSS RR SIG (+)	WSS FL SIG (-)	WSS FL SIG (+)	CLUSTER GND	WSS RR SIG (-)	MOTOR GND	MOTOR SUPPLY	BLS	CAN 2 H	IGN	CAN 1 L	VDC OFF SW	CAN 1 H	CAN 2 L	VALVE / ECU GND

Connector No.	E37
Connector Name	BRAKE FLUID LEVEL SWITCH
Connector Type	YV02FGY



Terminal No.	1	2
Signal Name [Specification]	Signal Name [Specification]	Signal Name [Specification]

1	P	B
2		

Connector No.	E39
Connector Name	FRONT WHEEL SENSOR RH
Connector Type	RH02MB



Terminal No.	3	4
Color of Wire	B	W
Signal Name [Specification]	Signal Name [Specification]	Signal Name [Specification]

Connector No.	E103
Connector Name	FUSE BLOCK (L/R)
Connector Type	NS16FW-CS



Terminal No.	1F	2F	4F	6F	8F	9F	11F	12F
Color of Wire	L	LG	BR	Y	R	GR	G	V
Signal Name [Specification]	Signal Name [Specification]	Signal Name [Specification]	Signal Name [Specification]	Signal Name [Specification]	Signal Name [Specification]	Signal Name [Specification]	Signal Name [Specification]	Signal Name [Specification]

Connector No.	E104
Connector Name	WIRE TO WIRE
Connector Type	NS16FW-CS



Terminal No.	1	2	3	4	6	7	8	9	10	11	12	13	14	15	16
Color of Wire	Y	SB	L	R	P	L	B/W	SB	GR	R	W	P	V	Y	L
Signal Name [Specification]	Signal Name [Specification]	Signal Name [Specification]	Signal Name [Specification]	Signal Name [Specification]	Signal Name [Specification]	Signal Name [Specification]	Signal Name [Specification]	Signal Name [Specification]	Signal Name [Specification]	Signal Name [Specification]	Signal Name [Specification]	Signal Name [Specification]	Signal Name [Specification]	Signal Name [Specification]	Signal Name [Specification]

Connector No.	E105
Connector Name	WIRE TO WIRE
Connector Type	TH17DMH-CS (0-43)



Terminal No.	3	5	8	11	12	13	14
Color of Wire	Y	LG	G	P	L	Y	O
Signal Name [Specification]	Signal Name [Specification]	Signal Name [Specification]	Signal Name [Specification]	Signal Name [Specification]	Signal Name [Specification]	Signal Name [Specification]	Signal Name [Specification]

15	BR	-
19	L	-
20	Y	-
21	BR	-
22	P	-
24	L	-
25	O	-
28	SB	-
29	W	-
30	Y	-
49	SB	-
50	GR	-
51	LG	-
52	V	-
53	GR	-
54	BR	-
55	Y	-
56	O	-
60	V	-
61	BR	-
62	O	-
63	W	-
64	SHIELD	-
66	W	-
67	BR	-
68	Y	-
69	SB	-
70	GR	-
71	SB	-
72	Y	-
75	BR	-
76	GR	-
77	O	-
78	Y	-
79	Y	-
80	Y	-
81	Y	-
82	LG	-
83	GR	-

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

BRC

JCFWA0471GB

BRAKE CONTROL SYSTEM

< WIRING DIAGRAM >

[WITH VDC]

BRAKE CONTROL SYSTEM

Connector No.	E116
Connector Name	STOP LAMP SWITCH
Connector Type	M04FW-LC



3	4
1	2

4	3	2	1
---	---	---	---



Connector No.	M5
Connector Name	VDC OFF SWITCH
Connector Type	TK06GY



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
2	LG	-
3	G	-
4	Y	-

Connector No.	M1
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS06FW-M2



3A	2A	1A
8A	7A	6A
5A	4A	3A

1	2	3	4
5	6	7	8

Connector No.	M11
Connector Name	WIRE TO WIRE
Connector Type	TH02FW-CS10-M3



Terminal No.	Color of Wire	Signal Name [Specification]
1A	Y	-
2A	G	-
3A	Y	-
4A	GR	-
5A	R	-
6A	W	-
7A	LG	-
8A	Y	-

Terminal No.	Color of Wire	Signal Name [Specification]
3	P	-
5	O	-
8	R	-
11	P	-
12	L	-
13	Y	-
14	Y	-
15	R	-
19	L	-
20	Y	-
21	BR	-
22	G	-
24	Y	-
25	L	-
28	BR	-
29	L	-
30	R	-
48	W	-

50	GR	-
51	LG	-
52	Y	-
53	V	-
54	SB	-
55	P	-
56	O	-
60	V	-
61	GR	-
62	O	-
63	W	-
64	SHIELD	-
66	W	-
67	R	-
68	W	-
69	P	-
70	G	-
71	G	-
72	BR	-
75	BR	-
76	R	-
77	G	-
78	Y	-
79	G	-
80	Y	-
81	Y	-
82	W	-
83	G	-

Connector No.	M30
Connector Name	STEERING ANGLE SENSOR
Connector Type	TH08FW-NH



1	2	3	4
5	6	7	8

Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
2	P	-
4	G	-
5	L	-

Connector No.	M34
Connector Name	COMBINATION METER
Connector Type	TH06FW-NH



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	BATTERY POWER SUPPLY
2	O	IGNITION SIGNAL
3	B	GROUND
4	B	GROUND
5	SB	ILLUMINATION CONTROL SIGNAL
8	SB	TRIP RESET SIGNAL
9	W	ILLUMINATION CONTROL SIGNAL
10	O	METER CONTROL SWITCH GROUND
11	L	ENTER SWITCH SIGNAL
12	R	SELECT SWITCH SIGNAL
13	V	ILLUMINATION CONTROL SWITCH SIGNAL (+)
14	GR	ILLUMINATION CONTROL SWITCH SIGNAL (-)
15	BR	AIR BAG SIGNAL
18	L	AMBIENT SENSOR SIGNAL
19	P	A/C AUTO AMP. CONNECTION RECOGNITION SIGNAL
20	Y	AMBIENT SENSOR GROUND
21	L	CAN-H
22	P	GROUND
23	B	FUEL LEVEL SENSOR GROUND
24	W	ALTERNATOR SIGNAL
25	BR	PARKING BRAKE SWITCH SIGNAL
26	G	BRAKE FLUID LEVEL SWITCH SIGNAL
27	V	ROOF STATUS SIGNAL
28	R	WASHER LEVEL SWITCH SIGNAL
29	P	VEHICLE SPEED SIGNAL (2-PULSE)
30	V	VEHICLE SPEED SIGNAL (8-PULSE)
32	LG	OVERDRIVE CONTROL SWITCH SIGNAL
34	G	FUEL LEVEL SENSOR SIGNAL
35	SB	SEAT BELT BUCKLE SWITCH SIGNAL (DRIVER SIDE)
36	R	SEAT BELT BUCKLE SWITCH SIGNAL (PASSENGER SIDE)


JCFWA0472GB

BRAKE CONTROL SYSTEM

< WIRING DIAGRAM >

[WITH VDC]

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P



JCFWA0473GB

BASIC INSPECTION

DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:000000006941480

PRECAUTIONS FOR DIAGNOSIS

Adjustment of Steering Angle Sensor

If steering angle sensor, steering system parts, suspension system parts, ABS actuator and electric unit (control unit) or tires have been replaced, or if wheel alignment has been adjusted, be sure to adjust neutral position of steering angle sensor before driving. Refer to [BRC-35, "Description"](#).

Calibration of Decel G Sensor


If yaw rate/side/decel G sensor or ABS actuator and electric unit (control unit) have been replaced, be sure to calibrate decel G sensor before driving. Refer to [BRC-37, "Description"](#).

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[WITH VDC]

OVERALL SEQUENCE



DETAILED FLOW

1.COLLECT THE INFORMATION FROM THE CUSTOMER

Get the detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred) using the diagnosis worksheet. Refer to [BRC-33, "Diagnostic Work Sheet"](#).

>> GO TO 2.

DIAGNOSIS AND REPAIR WORK FLOW

[WITH VDC]

< BASIC INSPECTION >

2.PERFORM THE SELF-DIAGNOSIS

Perform self-diagnosis for "ABS" with CONSULT.

Is there any DTC displayed?

- YES >> Record or print self-diagnosis results and freeze frame data (FFD). GO TO 3.
- NO >> GO TO 4.

3.PERFORM THE SYSTEM DIAGNOSIS

Perform the diagnosis applicable to the displayed DTC of "ABS" with CONSULT. Refer to [BRC-23, "DTC No. Index"](#).

>> GO TO 7.

4.CHECK THE SYMPTOM THAT IS NOT CONSIDERED A SYSTEM MALFUNCTION

Check that the symptom is a normal operation that is not considered a system malfunction. Refer to [BRC-97, "Description"](#).

Is the symptom a normal operation?

- YES >> GO TO 8.
- NO >> GO TO 5.

5.CHECK THE WARNING LAMP AND INDICATOR LAMP FOR ILLUMINATION

Check that the warning lamp and indicator lamp illuminate. Refer to [BRC-11, "System Description"](#).

Is ON/OFF timing normal?

- YES >> GO TO 6.
- NO >> GO TO 2.

6.PERFORM THE DIAGNOSIS BY SYMPTOM

Perform the diagnosis applicable to the symptom for "ABS" with CONSULT.

>> GO TO 7.

7.REPAIR OR REPLACE THE MALFUNCTIONING PARTS

Repair or replace the specified malfunctioning parts.

>> GO TO 8.

8.MEMORY CLEAR

Perform self-diagnosis memory clear for "ABS" with CONSULT.

>> GO TO 9.

9.FINAL CHECK

Perform the self-diagnosis again, and check that the malfunction is repaired completely.

Is no other DTC present and the repair completed?

- YES >> INSPECTION END
- NO >> GO TO 3.

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[WITH VDC]

Diagnostic Work Sheet

INFOID:000000006941481

Customer name MR/MS	Model & Year		VIN
Engine #	Trans.		Mileage
Incident Date	Manuf. Date		In Service Date
Symptoms	☐ Noise and vibration (from engine compartment) ☐ Noise and vibration (from axle)	☐ Warning / Indicator activate	☐ Firm pedal operation Large stroke pedal operation
	☐ TCS does not work (Rear wheels slip when accelerating)	☐ ABS does not work (Wheels lock when braking)	☐ Lack of sense of acceleration
Engine conditions	☐ When starting ☐ After starting		
Road conditions	☐ Low friction road (☐ Snow ☐ Gravel ☐ Other) ☐ Bumps / potholes		
Driving conditions	☐ Full-acceleration ☐ High speed cornering ☐ Vehicle speed: Greater than 10 km/h (6 MPH) ☐ Vehicle speed: 10 km/h (6 MPH) or less ☐ Vehicle is stopped		
Applying brake conditions	☐ Suddenly ☐ Gradually		
Other conditions	☐ Operation of electrical equipment ☐ Shift change ☐ Other descriptions		

SFIA3265E

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

BRC

ADDITIONAL SERVICE WHEN REPLACING ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< BASIC INSPECTION >

[WITH VDC]

ADDITIONAL SERVICE WHEN REPLACING ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Description

INFOID:000000006941482

Perform the steering angle sensor adjustment and decel G sensor calibration after replacing the ABS actuator and electric unit (control unit).

Special Repair Requirement

INFOID:000000006941483

1.PERFORM ADJUSTMENT OF STEERING ANGLE SENSOR AND CALIBRATION OF DECEL G SENSOR

Perform steering angle sensor adjustment and decel G sensor calibration.

- Adjustment of steering angle sensor: Refer to [BRC-35, "Description"](#).
- Calibration of decel G sensor: Refer to [BRC-37, "Description"](#).

>> INSPECTION END

ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

< BASIC INSPECTION >

[WITH VDC]

ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Description

INFOID:000000006941484

When doing work that applies to the list below, make sure to adjust neutral position of steering angle sensor before running vehicle.

×: Required –: Not required

Situation	Adjustment of steering angle sensor neutral position
Removing/Installing ABS actuator and electric unit (control unit)	—
Replacing ABS actuator and electric unit (control unit)	×
Removing/Installing steering angle sensor	×
Replacing steering angle sensor	×
Removing/Installing steering components	×
Replacing steering components	×
Removing/Installing suspension components	×
Replacing suspension components	×
Change tires to new ones	—
Tire rotation	—
Adjusting wheel alignment	×

Work Procedure

INFOID:000000006941485

ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

CAUTION:

**To adjust neutral position of steering angle sensor, make sure to use CONSULT.
(Adjustment cannot be done without CONSULT.)**

1.ALIGN THE VEHICLE STATUS

Stop the vehicle with front wheels in straight-ahead position.

>> GO TO 2.

2.PERFORM THE NEUTRAL POSITION ADJUSTMENT FOR THE STEERING ANGLE SENSOR

1. Select "ABS", "WORK SUPPORT" and "ST ANGLE SENSOR ADJUSTMENT" in order with CONSULT.
2. Select "START".

CAUTION:

Never touch steering wheel while adjusting steering angle sensor.

3. After approximately 10 seconds, select "END".

NOTE:

After approximately 60 seconds, it ends automatically.

4. Turn the ignition switch OFF, then turn it ON again.

CAUTION:

Be sure to perform above operation.

>> GO TO 3.

3.CHECK DATA MONITOR

1. Run the vehicle with front wheels in straight-ahead position, then stop.
2. Select "ABS", "DATA MONITOR" and "STR ANGLE SIG" in order with CONSULT, and check steering angle sensor signal.

STR ANGLE SIG : 0±3.5°

Is the steering angle within the specified range?

YES >> GO TO 4.

NO >> Perform the neutral position adjustment for the steering angle sensor again, GO TO 1.

ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

< BASIC INSPECTION >

[WITH VDC]

4. ERASE THE SELF-DIAGNOSIS MEMORY

Erase the self-diagnosis memories for "ABS" with CONSULT. Refer to [BRC-14. "CONSULT Function"](#).

Are the memories erased?

YES >> INSPECTION END

NO >> Check the items indicated by the self-diagnosis.

CALIBRATION OF DECEL G SENSOR

< BASIC INSPECTION >

[WITH VDC]

CALIBRATION OF DECEL G SENSOR

Description

INFOID:000000006941486

When doing work that applies to the list below, make sure to calibration of decel G sensor before running vehicle.

×: Required –: Not required

Situation	Calibration of decel G sensor
Removing/Installing ABS actuator and electric unit (control unit)	×
Replacing ABS actuator and electric unit (control unit)	×
Removing/Installing steering components	—
Removing/Installing suspension components	—
Change tires to new ones	—
Tire rotation	—
Adjusting wheel alignment	—
Removing/Installing yaw rate/side/decel G sensor	×
Replacing yaw rate/side/decel G sensor	×

Work Procedure

INFOID:000000006941487

CALIBRATION OF DECEL G SENSOR

CAUTION:

- To calibrate decel G sensor, make sure to use CONSULT.
(Calibration cannot be done without CONSULT.)
- Perform the G sensor calibration only with the vehicle parked on level surface.

1.ALIGN THE VEHICLE STATUS

Stop the vehicle with front wheels in straight-ahead position.

CAUTION:

- Keep all tires inflated to correct pressures. Adjust the tire pressure to the specified pressure value.
- Check that there is specified-load in vehicle other than the driver (or equivalent weight placed in driver's position).

>> GO TO 2.

2.PERFORM THE CALIBRATION OF DECEL G SENSOR

1. Select "ABS", "WORK SUPPORT" and "DECEL G SEN CALIBRATION" in order with CONSULT.
2. Select "START".
3. After approximately 10 seconds, select "END".

NOTE:

After approximately 60 seconds, it ends automatically.

4. Turn the ignition switch OFF, then turn it ON again.

CAUTION:

Be sure to perform above operation.

>> GO TO 3.

3.CHECK DATA MONITOR

1. Run the vehicle with front wheels in straight-ahead position, then stop.
2. Select "ABS", "DATA MONITOR" and "DECEL G-SEN" in order with CONSULT, and check decel G sensor signal.

DECEL G-SEN : ±0.08 G

Is the yaw rate/side/decel G within the specified range?

YES >> GO TO 4.

CALIBRATION OF DECEL G SENSOR

[WITH VDC]

< BASIC INSPECTION >

NO >> Perform the calibration of decel G sensor again, GO TO 1.

4. ERASE THE SELF-DIAGNOSIS MEMORY

Erase the self-diagnosis memories for "ABS" with CONSULT. Refer to [BRC-14, "CONSULT Function"](#).

Are the memories erased?

YES >> INSPECTION END

NO >> Check the items indicated by the self-diagnosis.

C1101, C1102, C1103, C1104 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

DTC/CIRCUIT DIAGNOSIS

C1101, C1102, C1103, C1104 WHEEL SENSOR

DTC Logic

INFOID:000000006941506

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1101	RR RH SENSOR-1	Circuit of rear RH wheel sensor is open or short circuit. Current signal from sensor is outside limits.	• Harness or connector • Wheel sensor • ABS actuator and electric unit (control unit) • Sensor rotor
C1102	RR LH SENSOR-1	Circuit of rear LH wheel sensor is open or short circuit. Current signal from sensor is outside limits.	
C1103	FR RH SENSOR-1	Circuit of front RH wheel sensor is open or short circuit. Current signal from sensor is outside limits.	
C1104	FR LH SENSOR-1	Circuit of front LH wheel sensor is open or short circuit. Current signal from sensor is outside limits.	

DTC CONFIRMATION PROCEDURE

1. DTC REPRODUCTION PROCEDURE

1. Start the engine and drive the vehicle at 30 km/h (19 MPH) or more for approximately 1 minute.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1101", "C1102", "C1103" or "C1104" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-39, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006941507

CAUTION:

Never check between wheel sensor harness connector terminals.

1. CHECK WHEEL SENSOR

1. Turn the ignition switch OFF.
2. Check wheel sensor for damage.

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2. REPLACE WHEEL SENSOR (1)

1. Replace wheel sensor.
 - Front: Refer to [BRC-98, "FRONT WHEEL SENSOR : Exploded View"](#).
 - Rear: Refer to [BRC-99, "REAR WHEEL SENSOR : Exploded View"](#).
2. Erase self-diagnosis result for "ABS".
3. Turn the ignition switch OFF, and wait 10 seconds or more.
4. Start the engine.
5. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
6. Stop the vehicle.
7. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1101", "C1102", "C1103" or "C1104" detected?

- YES >> GO TO 3.
NO >> INSPECTION END

3. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Check ABS actuator and electric unit (control unit) harness connector for disconnection or looseness.
3. Check wheel sensor harness connector for disconnection or looseness.

Is the inspection result normal?

C1101, C1102, C1103, C1104 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

YES >> GO TO 5.

NO >> Repair or replace error-detected parts, securely lock the connector, and GO TO 4.

4.PERFORM SELF-DIAGNOSIS (1)

1. Erase self-diagnosis result for "ABS" with CONSULT.
2. Turn the ignition switch OFF, and wait 10 seconds or more.
3. Start the engine.
4. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
5. Stop the vehicle.
6. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1101", "C1102", "C1103" or "C1104" detected?

YES >> GO TO 5.

NO >> INSPECTION END

5.CHECK TERMINAL

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector and then check ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.
3. Disconnect wheel sensor harness connector and check each wheel sensor pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair or replace error-detected parts and GO TO 6.

6.PERFORM SELF-DIAGNOSIS (2)

1. Connect ABS actuator and electric unit (control unit) harness connector.
2. Connect wheel sensor harness connector.
3. Erase self-diagnosis result for "ABS".
4. Turn the ignition switch OFF, and wait 10 seconds or more.
5. Start the engine.
6. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
7. Stop the vehicle.
8. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1101", "C1102", "C1103" or "C1104" detected?

YES >> GO TO 7.

NO >> INSPECTION END

7.CHECK WHEEL SENSOR HARNESS

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Disconnect wheel sensor harness connector.
4. Check continuity between ABS actuator and electric unit (control unit) harness connector and wheel sensor harness connector. (Check continuity when steering wheel is steered to RH and LH, or center harness in wheel housing is moved.)

Measurement connector and terminal for power supply circuit

ABS actuator and electric unit (control unit)		Wheel sensor		Continuity
Connector	Terminal	Connector	Terminal	
E36	9	E22 (Front LH wheel)	1	Existed
	5	E39 (Front RH wheel)	3	
	3	C5 (Rear LH wheel)	5	
	11	C6 (Rear RH wheel)	7	

C1101, C1102, C1103, C1104 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

Measurement connector and terminal for signal circuit

ABS actuator and electric unit (control unit)		Wheel sensor		Continuity
Connector	Terminal	Connector	Terminal	
E36	8	E22 (Front LH wheel)	2	Existed
	6	E39 (Front RH wheel)	4	
	2	C5 (Rear LH wheel)	6	
	12	C6 (Rear RH wheel)	8	

Is the inspection result normal?

YES >> GO TO 9.

NO >> Repair or replace error-detected parts and GO TO 8.

8.PERFORM SELF-DIAGNOSIS (3)

1. Connect ABS actuator and electric unit (control unit) harness connector.
2. Connect wheel sensor harness connector.
3. Erase self-diagnosis result for "ABS".
4. Turn the ignition switch OFF, and wait 10 seconds or more.
5. Start the engine.
6. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
7. Stop the vehicle.
8. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1101", "C1102", "C1103" or "C1104" detected?

YES >> GO TO 9.

NO >> INSPECTION END

9.REPLACE WHEEL SENSOR

1. Replace wheel sensor.
 - Front: Refer to [BRC-98, "FRONT WHEEL SENSOR : Exploded View"](#).
 - Rear: Refer to [BRC-99, "REAR WHEEL SENSOR : Exploded View"](#).
2. Erase self-diagnosis result for "ABS" with CONSULT.
3. Turn the ignition switch OFF, and wait 10 seconds or more.
4. Start the engine.
5. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
6. Stop the vehicle.
7. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1101", "C1102", "C1103" or "C1104" detected?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-101, "Exploded View"](#).

NO >> INSPECTION END

C1105, C1106, C1107, C1108 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

C1105, C1106, C1107, C1108 WHEEL SENSOR

DTC Logic

INFOID:000000006941511

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1105	RR RH SENSOR-2	Signal from rear RH wheel sensor does not match other 3 wheel speed signal.	• Harness or connector • Wheel sensor • Sensor rotor • ABS actuator and electric unit (control unit) • Sensor rotor
C1106	RR LH SENSOR-2	Signal from rear LH wheel sensor does not match other 3 wheel speed signal.	
C1107	FR RH SENSOR-2	Signal from front RH wheel sensor does not match other 3 wheel speed signal.	
C1108	FR LH SENSOR-2	Signal from front LH wheel sensor does not match other 3 wheel speed signal.	

DTC CONFIRMATION PROCEDURE

1.DTC REPRODUCTION PROCEDURE

1. Start the engine and drive the vehicle at 30 km/h (19 MPH) or more for approximately 1 minute.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1105", "C1106", "C1107" or "C1108" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-42, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006941512

CAUTION:

Never check between wheel sensor harness connector terminals.

1.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY SYSTEM

Check ABS actuator and electric unit (control unit) power supply system. Refer to [BRC-81, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace error-detected parts.

2.CHECK TIRE

1. Turn the ignition switch OFF.
2. Check tire air pressure, wear and size. Refer to [WT-51, "Tire Air Pressure"](#).

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Adjust air pressure or replace tire and GO TO 3.

3.CHECK DATA MONITOR (1)

1. Erase self-diagnosis result for "ABS" with CONSULT.
2. Turn the ignition switch OFF, and wait 10 seconds or more.
3. Start the engine.
4. Select "ABS" and "DATA MONITOR", check "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR" with CONSULT.

NOTE:

Set the "DATA MONITOR" recording speed to "10 msec".

5. Read a value (wheel speed) of both normal wheel sensors and error-detecting wheel sensor.

Regarding the deference at 30 km/h (19 MPH) between the wheel speed detected by the error detecting wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors, is the difference within 5%, respectively?

- YES >> GO TO 4.
NO >> GO TO 5.

C1105, C1106, C1107, C1108 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

4.PERFORM SELF-DIAGNOSIS (1)

1. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
2. Stop the vehicle.
3. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1105", "C1106", "C1107" or "C1108" detected?

YES >> GO TO 5.

NO >> INSPECTION END

5.CHECK WHEEL SENSOR

1. Turn the ignition switch OFF.
2. Check wheel sensor for damage.
3. Remove dust and foreign matter adhered to the sensor rotor with a vacuum dust collector through the wheel sensor mounting hole.

CAUTION:

Install wheel sensor with no backlash and float, and tighten the mounting bolt to the specified torque.

• Front: Refer to [BRC-98, "FRONT WHEEL SENSOR : Exploded View"](#).

• Rear: Refer to [BRC-99, "REAR WHEEL SENSOR : Exploded View"](#).

Is the inspection result normal?

YES >> GO TO 8.

NO >> GO TO 6.

6.REPLACE WHEEL SENSOR (1)

1. Replace wheel sensor.
 - Front: Refer to [BRC-98, "FRONT WHEEL SENSOR : Exploded View"](#).
 - Rear: Refer to [BRC-99, "REAR WHEEL SENSOR : Exploded View"](#).
2. Erase self-diagnosis result for "ABS" with CONSULT.
3. Turn the ignition switch OFF, and wait 10 seconds or more.
4. Start the engine.
5. Select "ABS" and "DATA MONITOR", check "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR" with CONSULT.

NOTE:

Set the "DATA MONITOR" recording speed to "10 msec".

6. Read a value (wheel speed) of both normal wheel sensors and error-detecting wheel sensor.

Regarding the deference at 30 km/h (19 MPH) between the wheel speed detected by the error detecting wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors, is the difference within 5%, respectively?

YES >> GO TO 7.

NO >> GO TO 19.

7.PERFORM SELF-DIAGNOSIS (2)

Ⓜ With CONSULT.

1. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
2. Stop the vehicle.
3. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1105", "C1106", "C1107" or "C1108" detected?

YES >> GO TO 19.

NO >> INSPECTION END

8.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Check ABS actuator and electric unit (control unit) harness connector for disconnection or looseness.
3. Check wheel sensor harness connector for disconnection or looseness.

Is the inspection result normal?

YES >> GO TO 11.

NO >> Repair or replace error-detected parts, securely lock the connector, and GO TO 9.

9.CHECK DATA MONITOR (2)

C1105, C1106, C1107, C1108 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

1. Erase self-diagnosis result for "ABS" with CONSULT.
2. Turn the ignition switch OFF, and wait 10 seconds or more.
3. Start the engine.
4. Select "ABS" and "DATA MONITOR", check "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR" with CONSULT.

NOTE:

Set the "DATA MONITOR" recording speed to "10 msec".

5. Read a value (wheel speed) of both normal wheel sensors and error-detecting wheel sensor.

Regarding the deference at 30 km/h (19 MPH) between the wheel speed detected by the error detecting wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors, is the difference within 5%, respectively?

YES >> GO TO 10.

NO >> GO TO 11.

10.PERFORM SELF-DIAGNOSIS (3)

1. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
2. Stop the vehicle.
3. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1105", "C1106", "C1107" or "C1108" detected?

YES >> GO TO 11.

NO >> INSPECTION END

11.CHECK TERMINAL

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector and then check ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.
3. Disconnect wheel sensor harness connector and check each wheel sensor pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> GO TO 14.

NO >> Repair or replace error-detected parts and GO TO 12.

12.CHECK DATA MONITOR (3)

1. Connect ABS actuator and electric unit (control unit) harness connector.
2. Connect wheel sensor harness connector.
3. Erase self-diagnosis result for "ABS" with CONSULT.
4. Turn the ignition switch OFF, and wait 10 seconds or more.
5. Start the engine.
6. Select "ABS" and "DATA MONITOR", check "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR" with CONSULT.

NOTE:

Set the "DATA MONITOR" recording speed to "10 msec".

7. Read a value (wheel speed) of both normal wheel sensors and error-detecting wheel sensor.

Regarding the deference at 30 km/h (19 MPH) between the wheel speed detected by the error detecting wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors, is the difference within 5%, respectively?

YES >> GO TO 13.

NO >> GO TO 14.

13.PERFORM SELF-DIAGNOSIS (4)

1. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
2. Stop the vehicle.
3. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1105", "C1106", "C1107" or "C1108" detected?

YES >> GO TO 14.

NO >> INSPECTION END

14.CHECK WHEEL SENSOR HARNESS

1. Turn the ignition switch OFF.

C1105, C1106, C1107, C1108 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Disconnect wheel sensor harness connector.
4. Check continuity between ABS actuator and electric unit (control unit) harness connector and the ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	9, 8	Ground	Not existed
	5, 6		
	3, 2		
	11, 12		

Is the inspection result normal?

YES >> GO TO 15.

NO >> Repair or replace error-detected parts and GO TO 15.

15.CHECK DATA MONITOR (4)

1. Connect ABS actuator and electric unit (control unit) harness connector.
2. Connect wheel sensor harness connector.
3. Erase self-diagnosis result for "ABS" with CONSULT.
4. Turn the ignition switch OFF, and wait 10 seconds or more.
5. Start the engine.
6. Select "ABS" and "DATA MONITOR", check "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR" with CONSULT.

NOTE:

Set the "DATA MONITOR" recording speed to "10 msec".

7. Read a value (wheel speed) of both normal wheel sensors and error-detecting wheel sensor.

Regarding the deference at 30 km/h (19 MPH) between the wheel speed detected by the error detecting wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors, is the difference within 5%, respectively?

YES >> GO TO 16.

NO >> GO TO 17.

16.PERFORM SELF-DIAGNOSIS (5)

1. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
2. Stop the vehicle.
3. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1105", "C1106", "C1107" or "C1108" detected?

YES >> GO TO 17.

NO >> INSPECTION END

17.REPLACE WHEEL SENSOR

1. Replace wheel sensor.
 - Front: Refer to [BRC-98. "FRONT WHEEL SENSOR : Exploded View"](#).
 - Rear: Refer to [BRC-99. "REAR WHEEL SENSOR : Exploded View"](#).
2. Erase self-diagnosis result for "ABS" with CONSULT.
3. Turn the ignition switch OFF, and wait 10 seconds or more.
4. Start the engine.
5. Select "ABS" and "DATA MONITOR", check "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR" with CONSULT.

NOTE:

Set the "DATA MONITOR" recording speed to "10 msec".

6. Read a value (wheel speed) of both normal wheel sensors and error-detecting wheel sensor.

Regarding the deference at 30 km/h (19 MPH) between the wheel speed detected by the error detecting wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors, is the difference within 5%, respectively?

YES >> GO TO 18.

NO >> GO TO 19.

C1105, C1106, C1107, C1108 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

18.PERFORM SELF-DIAGNOSIS (6)

1. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
2. Stop the vehicle.
3. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1105", "C1106", "C1107" or "C1108" detected?

YES >> GO TO 19.

NO >> INSPECTION END

19.REPLACE SENSOR ROTOR

1. Replace sensor rotor.
 - Front: Refer to [BRC-100, "FRONT SENSOR ROTOR : Exploded View"](#).
 - Rear: Refer to [BRC-100, "REAR SENSOR ROTOR : Exploded View"](#).
2. Erase self-diagnosis result for "ABS" with CONSULT.
3. Turn the ignition switch OFF, and wait 10 seconds or more.
4. Start the engine.
5. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
6. Stop the vehicle.
7. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1105", "C1106", "C1107" or "C1108" detected?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-101, "Exploded View"](#).

NO >> INSPECTION END

C1109 POWER AND GROUND SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

C1109 POWER AND GROUND SYSTEM

DTC Logic

INFOID:000000006941516

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1109	BATTERY VOLTAGE [ABNORMAL]	When the ABS actuator and electric unit (control unit) power supply is lower than normal.	• Harness or connector • ABS actuator and electric unit (control unit) • Fuse

DTC CONFIRMATION PROCEDURE

1.DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch OFF to ON.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1109" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-47, "Diagnosis Procedure"](#).
- NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006941517

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnection, looseness, etc.

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Repair or replace error-detected parts.

2.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY CIRCUIT AND GROUND CIRCUIT

1. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

ABS actuator and electric unit (control unit)		—	Condition	Voltage (Approx.)
Connector	Terminal			
E36	1	Ground	Ignition switch: OFF	Battery voltage

2. Turn the ignition switch ON.
CAUTION:
Never start the engine.
3. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

ABS actuator and electric unit (control unit)		—	Condition	Voltage (Approx.)
Connector	Terminal			
E36	1	Ground	Ignition switch: ON	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair or replace error-detected parts.

3.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Check the continuity between ABS actuator and electric unit (control unit) harness connector and ground.

C1109 POWER AND GROUND SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	13	Ground	Existed
	26		

Is the inspection result normal?

YES >> Check battery for terminal looseness, low voltage, etc. if any malfunction is found, repair error-detected parts.

NO >> Repair or replace error-detected parts.

C1110 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

C1110 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

DTC Logic

INFOID:000000006941521

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1110	CONTROLLER FAILURE	When there is an internal malfunction in the ABS actuator and electric unit (control unit).	ABS actuator and electric unit (control unit)

DTC CONFIRMATION PROCEDURE

1.DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1110" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-49, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006941522

1.REPLACE ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Replace ABS actuator and electric unit (control unit) when self-diagnostic result shows items other than those applicable.

>> Replace ABS actuator and electric unit (control unit). Refer to [BRC-101, "Exploded View"](#).

C1111 ABS MOTOR, MOTOR RELAY SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

C1111 ABS MOTOR, MOTOR RELAY SYSTEM

DTC Logic

INFOID:000000006941525

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1111	PUMP MOTOR	During the actuator motor operating with ON, when the actuator motor turns OFF, or when the control line for actuator motor relay is open.	• Harness or connector • ABS actuator and electric unit (control unit)
		During the actuator motor operating with OFF, when the actuator motor turns ON, or when the control line for relay is shorted to ground.	

DTC CONFIRMATION PROCEDURE

1.DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1111" detected?

YES >> Proceed to diagnosis procedure. Refer to [BRC-50, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006941526

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnect, looseness, etc.

Is the inspection result normal?

YES >> GO TO 2.
NO >> Replace or repair error-detected parts.

2.CHECK ABS MOTOR AND MOTOR RELAY POWER SUPPLY CIRCUIT

Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

ABS actuator and electric unit (control unit)		—	Voltage (Approx.)
Connector	Terminal		
E36	14	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.
NO >> Repair or replace error-detected parts.

3.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) GROUND CIRCUIT

Check the continuity between ABS actuator and electric unit (control unit) harness connector and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	13	Ground	Existed
	26		

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-101, "Exploded View"](#).
NO >> Repair or replace error-detected parts.

C1113, C1145, C1146 YAW RATE/SIDE/DECEL G SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

C1113, C1145, C1146 YAW RATE/SIDE/DECEL G SENSOR

DTC Logic

INFOID:000000006941530

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1113	G SENSOR	Decel G sensor is malfunctioning.	• Harness or connector • ABS actuator and electric unit (control unit) • Yaw rate/side/decel G sensor
C1145	YAW RATE SENSOR	• Yaw rate sensor is malfunctioning. • Yaw rate/side/decel G sensor power voltage is outside the standard. • Yaw rate/side/decel G sensor signal line is open or shorted.	
C1146	SIDE G-SEN CIRCUIT	Side G sensor is malfunctioning.	

DTC CONFIRMATION PROCEDURE

1. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1113", "C1145" or "C1146" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-51. "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006941531

CAUTION:

- Sudden turns (such as spin turns, acceleration turns), drifting, etc. may cause yaw rate/side/decel G sensor circuit indicate a malfunction. However this is not a malfunction if normal operation can be resumed after restarting engine.
- When on a turntable, such as at a parking structure entrance, or when on a moving object with engine running, the VDC OFF indicator lamp might turn on and self-diagnosis using the CONSULT yaw rate sensor system malfunction might be displayed, but in this case there is no malfunction with yaw rate/side/decel G sensor circuit. As soon as the vehicle leaves the turntable or moving object, restart the engine to return the system to normal.

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect yaw rate/side/decel G sensor connector.
4. Check terminal for deformation, disconnection, looseness, etc.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Replace or repair error-detected parts.

2. CHECK YAW RATE/SIDE/DECEL G SENSOR POWER SUPPLY CIRCUIT

1. Connect ABS actuator and electric unit (control unit) connector.
2. Turn the ignition switch ON.
CAUTION:
Never start the engine.
3. Check the voltage between yaw rate/side/decel G sensor harness connector and ground.

Yaw rate/side/decel G sensor		—	Voltage (Approx.)
Connector	Terminal		
M52	4	Ground	Battery voltage

4. Turn the ignition switch OFF.
5. Check the voltage between yaw rate/side/decel G sensor harness connector and ground.

C1113, C1145, C1146 YAW RATE/SIDE/DECEL G SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

Yaw rate/side/decel G sensor		—	Voltage (Approx.)
Connector	Terminal		
M52	4	Ground	0 V

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace error-detected parts.

3.CHECK YAW RATE/SIDE/DECEL G SENSOR GROUND CIRCUIT

Check the continuity between yaw rate/side/decel G sensor harness connector and ground.

Yaw rate/side/decel G sensor		—	Continuity
Connector	Terminal		
M52	1	Ground	Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace error-detected parts.

4.CHECK YAW RATE/SIDE/DECEL G SENSOR HARNESS

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check the continuity between yaw rate/side/decel G sensor harness connector and ABS actuator and electric unit (control unit) harness connector.

ABS actuator and electric unit (control unit)		Yaw rate/side/decel G sensor		Continuity
Connector	Terminal	Connector	Terminal	
E36	25	M52	2	Existed
	19		3	

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace error-detected parts.

5.CHECK DATA MONITOR

1. Connect yaw rate/side/decel G sensor harness connector.
2. Connect ABS actuator and electric unit (control unit) harness connector.
3. Select "ABS" and "DATA MONITOR" in order with CONSULT, select "YAW RATE SEN", "SIDE G-SEN" and "DECEL G-SEN", and check yaw rate/side/decel G sensor signal.

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-101, "Exploded View"](#).

NO >> Replace yaw rate/side/decel G sensor. Refer to [BRC-103, "Exploded View"](#).

C1115 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

C1115 WHEEL SENSOR

DTC Logic

INFOID:000000006941535

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1115	ABS SENSOR [ABNORMAL SIGNAL]	When wheel sensor input signal is malfunctioning.	• Harness or connector • Wheel sensor • ABS actuator and electric unit (control unit) • Sensor rotor

DTC CONFIRMATION PROCEDURE

1.DTC REPRODUCTION PROCEDURE

1. Start the engine and drive the vehicle at 30 km/h (19 MPH) or more for approximately 1 minute.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1115" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-53, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006941536

CAUTION:

For wheel sensor, never check between terminals.

1.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY SYSTEM

Check ABS actuator and electric unit (control unit) power supply system. Refer to [BRC-81, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace error-detected parts.

2.CHECK TIRE

1. Turn the ignition switch OFF.
2. Check tire air pressure, wear and size. Refer to [WT-51, "Tire Air Pressure"](#).

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Adjust air pressure or replace tire and GO TO 3.

3.CHECK DATA MONITOR (1)

1. Erase self-diagnosis result for "ABS" with CONSULT.
2. Turn the ignition switch OFF, and wait 10 seconds or more.
3. Start the engine.
4. Select "ABS" and "DATA MONITOR", check "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR" with CONSULT.

NOTE:

Set the "DATA MONITOR" recording speed to "10 msec".

5. Read a value (wheel speed) of both normal wheel sensors and error-detecting wheel sensor.

Regarding the deference at 30 km/h (19 MPH) between the wheel speed detected by the error detecting wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors, is the difference within 5%, respectively?

- YES >> GO TO 4.
NO >> GO TO 5.

4.PERFORM SELF-DIAGNOSIS (1)

1. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
2. Stop the vehicle.

< DTC/CIRCUIT DIAGNOSIS >

3. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1115" detected?

YES >> GO TO 5.

NO >> INSPECTION END

5.CHECK WHEEL SENSOR

1. Turn the ignition switch OFF.

2. Check wheel sensor for damage.

3. Remove dust and foreign matter adhered to the sensor rotor with a vacuum dust collector through the wheel sensor mounting hole.

CAUTION:

Install wheel sensor with no backlash and float, and tighten the mounting bolt to the specified torque.

• Front: Refer to [BRC-98, "FRONT WHEEL SENSOR : Exploded View"](#).

• Rear: Refer to [BRC-99, "REAR WHEEL SENSOR : Exploded View"](#).

Is the inspection result normal?

YES >> GO TO 8.

NO >> GO TO 6.

6.REPLACE WHEEL SENSOR (1)

1. Replace wheel sensor.

- Front: Refer to [BRC-98, "FRONT WHEEL SENSOR : Exploded View"](#).

- Rear: Refer to [BRC-99, "REAR WHEEL SENSOR : Exploded View"](#).

2. Erase self-diagnosis result for "ABS" with CONSULT.

3. Turn the ignition switch OFF, and wait 10 seconds or more.

4. Start the engine.

5. Select "ABS" and "DATA MONITOR", check "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR" with CONSULT.

NOTE:

Set the "DATA MONITOR" recording speed to "10 msec".

6. Read a value (wheel speed) of both normal wheel sensors and error-detecting wheel sensor.

Regarding the deference at 30 km/h (19 MPH) between the wheel speed detected by the error detecting wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors, is the difference within 5%, respectively?

YES >> GO TO 7.

NO >> GO TO 19.

7.PERFORM SELF-DIAGNOSIS (2)

1. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.

2. Stop the vehicle.

3. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1115" detected?

YES >> GO TO 19.

NO >> INSPECTION END

8.CHECK CONNECTOR

1. Turn the ignition switch OFF.

2. Check ABS actuator and electric unit (control unit) harness connector for disconnection or looseness.

3. Check wheel sensor harness connector for disconnection or looseness.

Is the inspection result normal?

YES >> GO TO 11.

NO >> Repair or replace error-detected parts, securely lock the connector, and GO TO 9.

9.CHECK DATA MONITOR (2)

1. Erase self-diagnosis result for "ABS" with CONSULT.

2. Turn the ignition switch OFF, and wait 10 seconds or more.

3. Start the engine.

4. Select "ABS" and "DATA MONITOR", check "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR" with CONSULT.

C1115 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

NOTE:

Set the "DATA MONITOR" recording speed to "10 msec".

- Read a value (wheel speed) of both normal wheel sensors and error-detecting wheel sensor.

Regarding the deference at 30 km/h (19 MPH) between the wheel speed detected by the error detecting wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors, is the difference within 5%, respectively?

YES >> GO TO 10.

NO >> GO TO 11.

10.PERFORM SELF-DIAGNOSIS (3)

- Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
- Stop the vehicle.
- Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1115" detected?

YES >> GO TO 11.

NO >> INSPECTION END

11.CHECK TERMINAL

- Turn the ignition switch OFF.
- Disconnect ABS actuator and electric unit (control unit) harness connector and then check ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.
- Disconnect wheel sensor harness connector and check each wheel sensor pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> GO TO 14.

NO >> Repair or replace error-detected parts and GO TO 12.

12.CHECK DATA MONITOR (3)

- Connect ABS actuator and electric unit (control unit) harness connector.
- Connect wheel sensor harness connector.
- Erase self-diagnosis result for "ABS" with CONSULT.
- Turn the ignition switch OFF, and wait 10 seconds or more.
- Start the engine.
- Select "ABS" and "DATA MONITOR", check "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR" with CONSULT.

NOTE:

Set the "DATA MONITOR" recording speed to "10 msec".

- Read a value (wheel speed) of both normal wheel sensors and error-detecting wheel sensor.

Regarding the deference at 30 km/h (19 MPH) between the wheel speed detected by the error detecting wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors, is the difference within 5%, respectively?

YES >> GO TO 13.

NO >> GO TO 14.

13.PERFORM SELF-DIAGNOSIS (4)

- Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
- Stop the vehicle.
- Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1115" detected?

YES >> GO TO 14.

NO >> INSPECTION END

14.CHECK WHEEL SENSOR HARNESS

- Turn the ignition switch OFF.
- Disconnect ABS actuator and electric unit (control unit) harness connector.
- Disconnect wheel sensor harness connector.
- Check continuity between ABS actuator and electric unit (control unit) harness connector and wheel sensor harness connector. (Check continuity when steering wheel is steered to RH and LH, or center harness in wheel housing is moved.)

C1115 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

Measurement connector and terminal for power supply circuit

ABS actuator and electric unit (control unit)		Wheel sensor		Continuity
Connector	Terminal	Connector	Terminal	
E36	9	E22 (Front LH wheel)	1	Existed
	5	E39 (Front RH wheel)	3	
	3	C5 (Rear LH wheel)	5	
	11	C6 (Rear RH wheel)	7	

Measurement connector and terminal for signal circuit

ABS actuator and electric unit (control unit)		Wheel sensor		Continuity
Connector	Terminal	Connector	Terminal	
E36	8	E22 (Front LH wheel)	2	Existed
	6	E39 (Front RH wheel)	4	
	2	C5 (Rear LH wheel)	6	
	12	C6 (Rear RH wheel)	8	

5. Check continuity between ABS actuator and electric unit (control unit) harness connector and the ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	9, 8	Ground	Not existed
	5, 6		
	3, 2		
	11, 12		

Is the inspection result normal?

YES >> GO TO 15.

NO >> Repair or replace error-detected parts and GO TO 15.

15.CHECK DATA MONITOR (4)

1. Connect ABS actuator and electric unit (control unit) harness connector.
2. Connect wheel sensor harness connector.
3. Erase self-diagnosis result for "ABS" with CONSULT.
4. Turn the ignition switch OFF, and wait 10 seconds or more.
5. Start the engine.
6. Select "ABS" and "DATA MONITOR", check "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR" with CONSULT.

NOTE:

Set the "DATA MONITOR" recording speed to "10 msec".

7. Read a value (wheel speed) of both normal wheel sensors and error-detecting wheel sensor.

Regarding the deference at 30 km/h (19 MPH) between the wheel speed detected by the error detecting wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors, is the difference within 5%, respectively?

YES >> GO TO 16.

NO >> GO TO 17.

16.PERFORM SELF-DIAGNOSIS (5)

1. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
2. Stop the vehicle.
3. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1115" detected?

YES >> GO TO 17.

NO >> INSPECTION END

17.REPLACE WHEEL SENSOR

C1115 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

1. Replace wheel sensor.
 - Front: Refer to [BRC-98, "FRONT WHEEL SENSOR : Exploded View"](#).
 - Rear: Refer to [BRC-99, "REAR WHEEL SENSOR : Exploded View"](#).
2. Erase self-diagnosis result for "ABS" with CONSULT.
3. Turn the ignition switch OFF, and wait 10 seconds or more.
4. Start the engine.
5. Select "ABS" and "DATA MONITOR", check "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR" with CONSULT.

NOTE:

Set the "DATA MONITOR" recording speed to "10 msec".

6. Read a value (wheel speed) of both normal wheel sensors and error-detecting wheel sensor.

Regarding the deference at 30 km/h (19 MPH) between the wheel speed detected by the error detecting wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors, is the difference within 5%, respectively?

YES >> GO TO 18.

NO >> GO TO 19.

18.PERFORM SELF-DIAGNOSIS (6)

1. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
2. Stop the vehicle.
3. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1115" detected?

YES >> GO TO 19.

NO >> INSPECTION END

19.REPLACE SENSOR ROTOR

1. Replace sensor rotor.
 - Front: Refer to [BRC-100, "FRONT SENSOR ROTOR : Exploded View"](#).
 - Rear: Refer to [BRC-100, "REAR SENSOR ROTOR : Exploded View"](#).
2. Erase self-diagnosis result for "ABS".
3. Turn the ignition switch OFF, and wait 10 seconds or more.
4. Start the engine.
5. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
6. Stop the vehicle.
7. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1115" detected?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-101, "Exploded View"](#).

NO >> INSPECTION END

C1116 STOP LAMP SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

C1116 STOP LAMP SWITCH

DTC Logic

INFOID:000000006941540

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1116	STOP LAMP SW	When a stop lamp switch signal is not input where the brake pedal is depressed.	• Harness or connector • Stop lamp switch • ABS actuator and electric unit (control unit)

DTC CONFIRMATION PROCEDURE

1.DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1116" detected?

YES >> Proceed to diagnosis procedure. Refer to [BRC-58, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006941541

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Disconnect stop lamp switch harness connector.
4. Check terminal for deformation, disconnection, looseness, etc.
5. Reconnect ABS actuator and electric unit (control unit) and stop lamp switch connectors securely.
6. Start the engine.
7. Repeat pumping brake pedal carefully several times, and perform self-diagnosis for "ABS" with CONSULT.

Is the inspection result normal?

YES >> GO TO 2.
NO >> Poor connection of connector terminal. Replace or repair error-detected parts.

2.CHECK STOP LAMP SWITCH CLEARANCE

Check stop lamp switch clearance. Refer to [BR-7, "Inspection and Adjustment"](#).

Is the inspection result normal?

YES >> GO TO 3.
NO >> Adjust stop lamp switch clearance. Refer to [BR-7, "Inspection and Adjustment"](#).

3.CHECK STOP LAMP SWITCH

Check stop lamp switch. Refer to [BRC-59, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4.
NO >> Repair or replace stop lamp switch.

4.CHECK STOP LAMP SWITCH CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

ABS actuator and electric unit (control unit)		—	Condition	Voltage (Approx.)
Connector	Terminal			
E36	16	Ground	Brake pedal is depressed	Battery voltage
			Brake pedal is released	0 V

C1116 STOP LAMP SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-101, "Exploded View"](#).
NO >> Repair or replace error-detected parts.

Component Inspection

INFOID:0000000006941542

1.CHECK STOP LAMP SWITCH

1. Turn the ignition switch OFF.
2. Disconnect stop lamp switch connector.
3. Check the continuity between stop lamp switch connector terminals.

Stop lamp switch	Condition	Continuity
Terminal		
1 – 2	Release stop lamp switch (When brake pedal is depressed.)	Existed
	Push stop lamp switch (When brake pedal is released.)	Not existed

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Replace stop lamp switch. Refer to [BR-18, "Exploded View"](#).

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

C1120, C1122, C1124, C1126 IN ABS SOL

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

C1120, C1122, C1124, C1126 IN ABS SOL

DTC Logic

INFOID:000000006941545

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1120	FR LH IN ABS SOL	When the control unit detects a malfunction in the front LH ABS IN valve circuit.	• Harness or connector • ABS actuator and electric unit (control unit)
C1122	FR RH IN ABS SOL	When the control unit detects a malfunction in the front RH ABS IN valve circuit.	
C1124	RR LH IN ABS SOL	When the control unit detects a malfunction in the rear LH ABS IN valve circuit.	
C1126	RR RH IN ABS SOL	When the control unit detects a malfunction in the rear RH ABS IN valve circuit.	

DTC CONFIRMATION PROCEDURE

1.DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1120", "C1122", "C1124" or "C1126" detected?

YES >> Proceed to diagnosis procedure. Refer to [BRC-60, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006941546

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnection, looseness, etc.

Is the inspection result normal?

YES >> GO TO 2.
NO >> Replace or repair error-detected parts.

2.CHECK SOLENOID, VDC SWITCH-OVER VALVE AND ACTUATOR RELAY POWER SUPPLY CIRCUIT

Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

ABS actuator and electric unit (control unit)		—	Voltage (Approx.)
Connector	Terminal		
E36	1	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.
NO >> Repair or replace error-detected parts.

3.CHECK SOLENOID, VDC SWITCH-OVER VALVE AND ACTUATOR RELAY GROUND CIRCUIT

Check the continuity between ABS actuator and electric unit (control unit) harness connector and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	13	Ground	Existed
	26		

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-101, "Exploded View"](#).

C1120, C1122, C1124, C1126 IN ABS SOL

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

NO >> Repair or replace error-detected parts.

A

B

C

D

E

BRC

G

H

I

J

K

L

M

N

O

P

C1121, C1123, C1125, C1127 OUT ABS SOL

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

C1121, C1123, C1125, C1127 OUT ABS SOL

DTC Logic

INFOID:000000006941550

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1121	FR LH OUT ABS SOL	When the control unit detects a malfunction in the front LH ABS OUT valve circuit.	• Harness or connector • ABS actuator and electric unit (control unit)
C1123	FR RH OUT ABS SOL	When the control unit detects a malfunction in the front RH ABS OUT valve circuit.	
C1125	RR LH OUT ABS SOL	When the control unit detects a malfunction in the rear LH ABS OUT valve circuit.	
C1127	RR RH OUT ABS SOL	When the control unit detects a malfunction in the rear RH ABS OUT valve circuit.	

DTC CONFIRMATION PROCEDURE

1.DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1121", "C1123", "C1125" or "C1127" detected?

YES >> Proceed to diagnosis procedure. Refer to [BRC-62, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006941551

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnection, looseness, etc.

Is the inspection result normal?

YES >> GO TO 2.
NO >> Replace or repair error-detected parts.

2.CHECK SOLENOID, VDC SWITCH-OVER VALVE AND ACTUATOR RELAY POWER SUPPLY CIRCUIT

Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

ABS actuator and electric unit (control unit)		—	Voltage (Approx.)
Connector	Terminal		
E36	1	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.
NO >> Repair or replace error-detected parts.

3.CHECK SOLENOID, VDC SWITCH-OVER VALVE AND ACTUATOR RELAY GROUND CIRCUIT

Check the continuity between ABS actuator and electric unit (control unit) harness connector and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	13	Ground	Existed
	26		

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-101, "Exploded View"](#).

C1121, C1123, C1125, C1127 OUT ABS SOL

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

NO >> Repair or replace error-detected parts.

- A
- B
- C
- D
- E
- BRC**
- G
- H
- I
- J
- K
- L
- M
- N
- O
- P

C1130 ENGINE SIGNAL

DTC Logic

INFOID:000000006941555

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1130	ENGINE SIGNAL 1	Major engine components are malfunctioning.	- ECM - ABS actuator and electric unit (control unit) - CAN communication line

DTC CONFIRMATION PROCEDURE

1. DTC REPRODUCTION PROCEDURE

- Turn the ignition switch ON.
- Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1130" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-64, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006941556

1. PERFORM ECM SELF-DIAGNOSIS

Perform self-diagnosis for "ENGINE" with CONSULT.

Is any item indicated on the self-diagnosis display?

- YES >> Check the malfunctioning system. Refer to [EC-64, "CONSULT Function"](#).
 NO >> GO TO 2.

2. PERFORM ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS (1)

- Erase self-diagnosis results for "ABS" with CONSULT.
- Turn the ignition switch OFF.
- Start the engine. Drive the vehicle for a while.
- Make sure that malfunction indicator lamp (MIL) turns OFF.

Is indicator lamp (MIL) turns OFF?

- YES >> GO TO 3.
 NO >> Refer to [EC-64, "CONSULT Function"](#).

3. PERFORM ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS (2)

Stop the vehicle. Perform self-diagnosis for "ENGINE" with CONSULT.

Is any item indicated on the self-diagnosis display?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-101, "Exploded View"](#).
 NO >> Repair or replace error-detected parts.

C1140 ACTUATOR RELAY SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

C1140 ACTUATOR RELAY SYSTEM

DTC Logic

INFOID:000000006941559

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1140	ACTUATOR RLY	When the control unit detects a malfunction in the actuator relay system.	• Harness or connector • ABS actuator and electric unit (control unit)

DTC CONFIRMATION PROCEDURE

1.DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1140" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-65, "Diagnosis Procedure"](#).
- NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006941560

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnection, looseness, etc.

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Replace or repair error-detected parts.

2.CHECK SOLENOID, VDC SWITCH-OVER VALVE AND ACTUATOR RELAY POWER SUPPLY CIRCUIT

Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

ABS actuator and electric unit (control unit)		—	Voltage (Approx.)
Connector	Terminal		
E36	1	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair or replace error-detected parts.

3.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) GROUND CIRCUIT

Check the continuity between ABS actuator and electric unit (control unit) harness connector and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	13	Ground	Existed
	26		

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-101, "Exploded View"](#).
- NO >> Repair or replace error-detected parts.

C1142 PRESS SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

C1142 PRESS SENSOR

DTC Logic

INFOID:000000006941564

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1142	PRESS SEN CIRCUIT	Pressure sensor signal line is open or shorted, or pressure sensor is malfunctioning.	• Harness or connector • Stop lamp switch • ABS actuator and electric unit (control unit)

DTC CONFIRMATION PROCEDURE

1.DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1142" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-66, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006941565

1.CHECK STOP LAMP SWITCH

Check stop lamp switch system. Refer to [BRC-58, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace error-detected parts.

2.CHECK DATA MONITOR

Check pressure sensor signal. Refer to [BRC-19, "Reference Value"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check brake pedal, brake booster and master cylinder for mount play, looseness, brake system fluid leakage, etc.
 - Brake fluid leakage: Refer to [BR-10, "Inspection"](#).
 - Brake pedal: Refer to [BR-19, "Inspection and Adjustment"](#).
 - Master cylinder: Refer to [BR-27, "Inspection"](#).
 - Brake booster: Refer to [BR-29, "Inspection and Adjustment"](#).

3.PERFORM ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS

Perform self-diagnosis for "ABS" with CONSULT.

Is any item indicated on the self-diagnosis display?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-101, "Exploded View"](#).
NO >> Repair or replace error-detected parts.

C1143 STEERING ANGLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

C1143 STEERING ANGLE SENSOR

DTC Logic

INFOID:000000006941569

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1143	ST ANG SEN CIRCUIT	Neutral position of steering angle sensor is dislocated, steering angle sensor is malfunctioning, or wheel alignment is outside specified range.	• Harness or connector • Steering angle sensor • ABS actuator and electric unit (control unit) • Wheel alignment

DTC CONFIRMATION PROCEDURE

1.DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1143" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-67, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006941570

1.CHECK WHEEL ALIGNMENT

Check wheel alignment. Refer to [FSU-7, "Inspection"](#) (front), [RSU-6, "Inspection"](#) (rear).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Adjust wheel alignment. Refer to [FSU-7, "Inspection"](#) (front), [RSU-6, "Adjustment"](#) (rear).

2.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect steering angle sensor connector.
4. Check terminal for deformation, disconnection, looseness, etc.

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Replace or repair error-detected parts.

3.CHECK STEERING ANGLE SENSOR HARNESS

1. Turn the ignition switch ON.
CAUTION:
Never start the engine.
2. Check the voltage between steering angle sensor harness connector and ground.

Steering angle sensor		—	Voltage (Approx.)
Connector	Terminal		
M30	4	Ground	Battery voltage

3. Turn ignition switch OFF.
4. Check the continuity between steering angle sensor harness connector and ground.

Steering angle sensor		—	Continuity
Connector	Terminal		
M30	1	Ground	Existed

Is the inspection result normal?

C1143 STEERING ANGLE SENSOR

[WITH VDC]

< DTC/CIRCUIT DIAGNOSIS >

- YES >> GO TO 4.
NO >> Repair or replace error-detected parts.

4.CHECK STEERING WHEEL PLAY

Check steering wheel play. Refer to [ST-31. "Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Repair or replace error-detected parts.

5.CHECK DATA MONITOR

1. Connect the ABS actuator and electric unit (control unit) harness connector.
2. Connect the steering angle sensor harness connector.
3. Check steering angle sensor signal. Refer to [BRC-19. "Reference Value"](#).

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-101. "Exploded View"](#).
NO >> Replace steering angle sensor. Refer to [BRC-104. "Exploded View"](#).

C1144 INCOMPLETE STEERING ANGLE SENSOR ADJUSTMENT

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

C1144 INCOMPLETE STEERING ANGLE SENSOR ADJUSTMENT

DTC Logic

INFOID:000000006941574

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1144	ST ANG SEN SIGNAL	Adjustment of steering angle sensor neutral position is not finished.	• Harness or connector • Steering angle sensor • ABS actuator and electric unit (control unit)

DTC CONFIRMATION PROCEDURE

1.DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Select "ABS", "WORK SUPPORT" and "ST ANGLE SENSOR ADJUSTMENT" in order with CONSULT, and perform adjust the neutral position of steering angle sensor.
3. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1144" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-69. "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006941575

1.CHECK STEERING ANGLE SENSOR

Check steering angle sensor. Refer to [BRC-67. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-101. "Exploded View"](#).
NO >> Repair or replace error-detected parts.

C1155 BRAKE FLUID LEVEL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

C1155 BRAKE FLUID LEVEL SWITCH

DTC Logic

INFOID:000000006941579

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1155	BR FLUID LEVEL LOW	Brake fluid level is low or communication line between the ABS actuator and electric unit (control unit) and brake fluid level switch is open or shorted.	• Harness or connector • ABS actuator and electric unit (control unit) • Brake fluid level low • Brake fluid level switch • Combination meter

DTC CONFIRMATION PROCEDURE

1.DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1155" detected?

YES >> Proceed to diagnosis procedure. Refer to [BRC-70, "Diagnosis Procedure"](#).

NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006941580

1.CHECK BRAKE FLUID LEVEL

1. Turn the ignition switch OFF.
2. Check brake fluid level. Refer to [BR-10, "Inspection"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Refill brake fluid. Refer to [BR-10, "Refilling"](#).

2.PERFORM SELF-DIAGNOSIS (1)

1. Erase self-diagnosis result for "ABS" with CONSULT.
2. Turn the ignition switch OFF, and wait 10 seconds or more.
3. Turn the ignition switch ON.

CAUTION:

Never start the engine.

4. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1155" detected?

YES >> INSPECTION END

NO >> GO TO 3.

3.CHECK BRAKE FLUID LEVEL SWITCH

Check brake fluids level switch. Refer to [BRC-72, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace sub tank. Refer to [BR-25, "Exploded View"](#). GO TO 4.

4.PERFORM SELF-DIAGNOSIS (2)

1. Erase self-diagnosis result for "ABS" with CONSULT.
2. Turn the ignition switch OFF, and wait 10 seconds or more.
3. Turn the ignition switch ON.

CAUTION:

Never start the engine.

4. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1155" detected?

YES >> INSPECTION END

C1155 BRAKE FLUID LEVEL SWITCH

[WITH VDC]

< DTC/CIRCUIT DIAGNOSIS >

NO >> GO TO 5.

5.CHECK CONNECTOR AND TERMINAL

1. Turn the ignition switch OFF.
2. Disconnect brake fluid level switch harness connector.
3. Check brake fluid level switch harness connector for disconnection or looseness.
4. Check brake fluid level switch pin terminals for damage or loose connection with harness connector.
5. Disconnect combination meter harness connector.
6. Check combination meter harness connector for disconnection or looseness.
7. Check combination meter pin terminals for damage or loose connection with harness connector.
8. Disconnect ABS actuator and electric unit (control unit) harness connector.
9. Check ABS actuator and electric unit (control unit) harness connector for disconnection or looseness.
10. Check ABS actuator and electric unit (control unit) harness connector pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair or replace error-detected parts. GO TO 6.

6.PERFORM SELF-DIAGNOSIS (3)

1. Connect brake fluid level switch harness connector.
2. Connect combination meter harness connector.
3. Connect ABS actuator and electric unit (control unit) harness connector.
4. Erase self-diagnosis result for "ABS" with CONSULT.
5. Turn the ignition switch OFF, and wait 10 seconds or more.
6. Turn the ignition switch ON.

CAUTION:

Never start the engine.

7. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1155" detected?

YES >> INSPECTION END

NO >> GO TO 7.

7.CHECK BRAKE FLUID LEVEL SWITCH HARNESS

1. Turn the ignition switch OFF.
2. Disconnect brake fluid level switch harness connector.
3. Disconnect ABS actuator and electric unit (control unit) harness connector.
4. Disconnect combination meter harness connector.
5. Check continuity between brake fluid level switch harness connector and ABS actuator and electric unit (control unit) harness connector.

Brake fluid level switch		ABS actuator and electric unit (control unit)		Continuity
Connector	Terminal	Connector	Terminal	
E37	1	M36	7	Existed

6. Check continuity between brake fluid level switch harness connector and ground.

Brake fluid level switch		—	Continuity
Connector	Terminal		
E37	1	Ground	Not existed

Is the inspection result normal?

YES >> GO TO 8.

NO >> Repair or replace error-detected parts.

8.CHECK BRAKE FLUID LEVEL SWITCH GROUND

Check continuity between brake fluid level switch harness connector and ground.

C1155 BRAKE FLUID LEVEL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

Brake fluid level switch		—	Continuity
Connector	Terminal		
E37	2	Ground	Existed

Is the inspection result normal?

YES >> GO TO 9.

NO >> Repair or replace error-detected parts.

9.CHECK COMBINATION METER

Check combination meter. Refer to [MWI-21, "CONSULT Function"](#).

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-101, "Exploded View"](#).

NO >> Repair or replace combination meter. Refer to [MWI-79, "Exploded View"](#).

Component Inspection

INFOID:000000006941581

1.CHECK BRAKE FLUID LEVEL SWITCH

1. Turn the ignition switch OFF.
2. Disconnect brake fluid level switch connector.
3. Check the continuity between brake fluid level switch connector terminals.

Brake fluid level switch	Condition	Continuity
Terminal		
1 – 2	When brake fluid is full in the sub tank.	Not existed
	When brake fluid is empty in the sub tank.	Existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace sub tank. Refer to [BR-25, "Exploded View"](#).

C1160 INCOMPLETE DECEL G SENSOR CALIBRATION

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

C1160 INCOMPLETE DECEL G SENSOR CALIBRATION

DTC Logic

INFOID:000000006941584

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1160	DECEL G SEN SET	Calibration of decel G sensor is not finished.	- yaw rate/side/decel G sensor - Harness or connector - ABS actuator and electric unit (control unit) - Incomplete decel G sensor calibration

DTC CONFIRMATION PROCEDURE

1.DTC REPRODUCTION PROCEDURE

- Turn the ignition switch ON.
- Select "ABS", "WORK SUPPORT" and "DECEL G SEN CALIBRATION" in order with CONSULT, and perform calibration of decel G sensor. Refer to [BRC-37, "Work Procedure"](#).
- Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1160" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-73, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006941585

1.CHECK YAW RATE/SIDE/DECEL G SENSOR

Check yaw rate/side/decel G sensor. Refer to [BRC-51, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-101, "Exploded View"](#).
NO >> Repair or replace error-detected parts.

C1161 INCOMPLETE SIDE G SENSOR CALIBRATION

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

C1161 INCOMPLETE SIDE G SENSOR CALIBRATION

DTC Logic

INFOID:000000006941588

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1161	SIDE G SEN SET	When there is an internal malfunction in the ABS actuator and electric unit (control unit).	ABS actuator and electric unit (control unit)

DTC CONFIRMATION PROCEDURE

1.DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1161" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-74, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006941589

1.CHECK YAW RATE/SIDE/DECEL G SENSOR

Replace ABS actuator and electric unit (control unit) when self-diagnostic result shows items other than those applicable.

>> Replace ABS actuator and electric unit (control unit). Refer to [BRC-101, "Exploded View"](#).

C1162 INCOMPLETE PRESSURE SENSOR CALIBRATION

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

C1162 INCOMPLETE PRESSURE SENSOR CALIBRATION

DTC Logic

INFOID:000000006941592

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1162	PRESS SEN SET	When there is an internal malfunction in the ABS actuator and electric unit (control unit).	ABS actuator and electric unit (control unit)

DTC CONFIRMATION PROCEDURE

1.DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1162" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-75, "Diagnosis Procedure"](#).
- NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006941593

1.REPLACE ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Replace ABS actuator and electric unit (control unit) when self-diagnostic result shows items other than those applicable.

>> Replace ABS actuator and electric unit (control unit). Refer to [BRC-101, "Exploded View"](#).

C1164, C1165 CV SYSTEM

DTC Logic

INFOID:000000006941596

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1164	CV1	VDC switch-over solenoid valve (CV1) on the primary side is open circuit or shorted, or the control line is open or shorted to the power supply or the ground.	• Harness or connector • ABS actuator and electric unit (control unit)
C1165	CV2	VDC switch-over solenoid valve (CV2) on the secondary side is open circuit or shorted, or the control line is open or shorted to the power supply or the ground.	

DTC CONFIRMATION PROCEDURE

1. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1164" or "C1165" detected?

YES >> Proceed to diagnosis procedure. Refer to [BRC-76, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006941597

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnection, looseness, etc.

Is the inspection result normal?

YES >> GO TO 2.
 NO >> Replace or repair error-detected parts.

2. CHECK SOLENOID, VDC SWITCH-OVER VALVE AND ACTUATOR RELAY POWER SUPPLY CIRCUIT

Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

ABS actuator and electric unit (control unit)		—	Voltage (Approx.)
Connector	Terminal		
E36	1	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.
 NO >> Repair or replace error-detected parts.

3. CHECK SOLENOID, VDC SWITCH-OVER VALVE AND ACTUATOR RELAY GROUND CIRCUIT

Check the continuity between ABS actuator and electric unit (control unit) harness connector and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	13	Ground	Existed
	26		

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-101, "Exploded View"](#).
 NO >> Repair or replace error-detected parts.

C1166, C1167 SV SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

C1166, C1167 SV SYSTEM

DTC Logic

INFOID:000000006941601

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1166	SV1	VDC switch-over solenoid valve (SV1) on the primary side is open circuit or shorted, or the control line is open or shorted to the power supply or the ground.	• Harness or connector • ABS actuator and electric unit (control unit)
C1167	SV2	VDC switch-over solenoid valve (SV2) on the secondary side is open circuit or shorted, or the control line is open or shorted to the power supply or the ground.	

DTC CONFIRMATION PROCEDURE

1.DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "C1166" or "C1167" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-77, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006941602

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnection, looseness, etc.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Replace or repair error-detected parts.

2.CHECK SOLENOID, VDC SWITCH-OVER VALVE AND ACTUATOR RELAY POWER SUPPLY CIRCUIT

Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

ABS actuator and electric unit (control unit)		—	Voltage (Approx.)
Connector	Terminal		
E36	1	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace error-detected parts.

3.CHECK SOLENOID, VDC SWITCH-OVER VALVE AND ACTUATOR RELAY GROUND CIRCUIT

Check the continuity between ABS actuator and electric unit (control unit) harness connector and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	13	Ground	Existed
	26		

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-101, "Exploded View"](#).
NO >> Repair or replace error-detected parts.

U1000 CAN COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

U1000 CAN COMM CIRCUIT

Description

INFOID:000000006941605

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

DTC Logic

INFOID:000000006941606

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
U1000	CAN COMM CIRCUIT	When ABS actuator and electric unit (control unit) is not transmitting or receiving CAN communication signal for 2 seconds or more.	• Harness or connector • CAN communication line • ABS actuator and electric unit (control unit)

DTC CONFIRMATION PROCEDURE

1.DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "U1000" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-78. "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006941607

1.PERFORM ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS

Perform self-diagnosis for "ABS" with CONSULT.

Is the inspection result normal?

- YES >> Refer to [LAN-15. "Trouble Diagnosis Flow Chart"](#).
NO >> INSPECTION END

U1002 SYSTEM COMM (CAN)

Description

INFOID:000000006941609

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

DTC Logic

INFOID:000000006941610

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
U1002	SYSTEM COMM(CAN)	When ABS actuator and electric unit (control unit) is not transmitting or receiving CAN communication signal of steering angle sensor for 2 seconds or less.	• Harness or connector • CAN communication line • ABS actuator and electric unit (control unit)

BRC

DTC CONFIRMATION PROCEDURE

1. DTC REPRODUCTION PROCEDURE

1. Turn the ignition switch ON.
2. Perform self-diagnosis for "ABS" with CONSULT.

Is DTC "U1002" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-79, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006941611

CAUTION:

- **Never apply 7.0 V or more to the measurement terminal.**
- **Use a tester with open terminal voltage of 7.0 V or less.**
- **Turn the ignition switch OFF and disconnect the battery cable from the negative terminal when checking the harness.**

1. CHECK CAN DIAGNOSIS SUPPORT MONITOR

1. Select "ABS" and "CAN Diagnosis Support Monitor" in order with CONSULT.
2. Check malfunction history between each control unit connected to ABS actuator and electric unit (control unit).

Check the result of "PAST"

All items are "OK">>Refer to [GI-40, "Intermittent Incident"](#).

"TRANSMIT DIAG" is other than "OK">>GO TO 2.

A control unit other than ABS actuator and electric unit (control unit) and "METER/M&A" are anything other than "OK">>GO TO 3.

2. CHECK TRANSMITTING SIDE UNIT

Check the ABS actuator and electric unit (control unit) harness connector terminals No. 21 and 23 for damage or loose connection.

Is the inspection result normal?

- YES >> Erase self-diagnosis results. Then perform self-diagnosis for "ABS" with CONSULT.
 NO >> Recheck terminals for damage or loose connection. Refer to [LAN-5, "Precautions for Harness Repair"](#).

3. CHECK APPLICABLE CONTROL UNIT

Check damage or loose connection of each CAN communication line harness connector terminals.

Is the inspection result normal?

U1002 SYSTEM COMM (CAN)

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

-
- | | |
|-----|---|
| YES | >> Erase self-diagnosis results. Then perform self-diagnosis for applicable control unit with CONSULT. |
| NO | >> Recheck terminals for damage or loose connection. Refer to LAN-5. "Precautions for Harness Repair" . |

POWER SUPPLY AND GROUND CIRCUIT

Diagnosis Procedure

INFOID:000000006941614

1.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) IGNITION POWER SUPPLY

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

ABS actuator and electric unit (control unit)		—	Voltage (Approx.)
Connector	Terminal		
E36	20	Ground	0 V

4. Turn the ignition switch ON.

CAUTION:

Never start the engine.

5. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

ABS actuator and electric unit (control unit)		—	Voltage (Approx.)
Connector	Terminal		
E36	20	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace error-detected parts.

2.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY

1. Turn the ignition switch OFF.
2. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

ABS actuator and electric unit (control unit)		—	Voltage (Approx.)
Connector	Terminal		
E36	1	Ground	Battery voltage

3. Turn the ignition switch ON.

CAUTION:

Never start the engine.

4. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

ABS actuator and electric unit (control unit)		—	Voltage (Approx.)
Connector	Terminal		
E36	1	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace error-detected parts.

3.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) GROUND

1. Turn the ignition switch OFF.
2. Check the continuity between ABS actuator and electric unit (control unit) harness connector and ground.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	13	Ground	Existed
	26		

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair or replace error-detected parts.

PARKING BRAKE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

PARKING BRAKE SWITCH

Component Function Check

INFOID:0000000006941616

1.CHECK PARKING BRAKE SWITCH OPERATION

Operate the parking brake pedal. Then check that the brake warning lamp in the combination meter turns ON/OFF correctly.

Condition	Brake warning lamp illumination status
When the parking brake pedal is operation	ON
When the parking brake pedal is not operation.	OFF

Is the inspection result normal?

YES >> INSPECTION END

NO >> Proceed to diagnosis procedure. Refer to [BRC-83, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000006941617

BRC

1.CHECK PARKING BRAKE SWITCH

Check parking brake switch. Refer to [BRC-83, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace parking brake switch. Refer to [PB-6, "Exploded View"](#).

2.CHECK COMBINATION METER

Check the indication and operation of combination meter are normal. Refer to [MWI-20, "On Board Diagnosis Function"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check combination meter. Refer to [MWI-21, "CONSULT Function"](#).

3.CHECK PARKING BRAKE SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect parking brake switch harness connector.
3. Disconnect combination meter harness connector.
4. Check the continuity between parking brake switch harness connector and combination meter harness connector.

Parking brake switch		Combination meter		Continuity
Connector	Terminal	Connector	Terminal	
E27	1	M34	26	Existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair or replace error-detected parts.

Component Inspection

INFOID:0000000006941618

1.CHECK PARKING BRAKE SWITCH

1. Turn the ignition switch OFF.
2. Disconnect parking brake switch harness connector.
3. Check the continuity between parking brake switch harness connector and ground.

PARKING BRAKE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

Parking brake switch		—	Condition	Continuity
Connector	Terminal			
E27	1	Ground	When the parking brake switch is operated.	Existed
			When the parking brake switch is not operated.	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace parking brake switch. Refer to [PB-6. "Exploded View"](#).

VDC OFF SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

VDC OFF SWITCH

Component Function Check

INFOID:000000006941620

1.CHECK VDC OFF SWITCH OPERATION

Turn ON/OFF the VDC OFF switch and check that the VDC OFF indicator lamp in the combination meter turns ON/OFF correctly.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Proceed to diagnosis procedure. Refer to [BRC-85. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000006941621

1.CHECK VDC OFF SWITCH

Check VDC OFF switch. Refer to [BRC-86. "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace VDC OFF switch.

2.CHECK VDC OFF SWITCH HARNESS

1. Disconnect ABS actuator and electric unit (control unit) harness connector.
2. Disconnect VDC OFF switch harness connector.
3. Check the continuity between VDC OFF switch harness connector and ABS actuator and electric unit (control unit) harness connector.

ABS actuator and electric unit (control unit)		VDC OFF switch		Continuity
Connector	Terminal	Connector	Terminal	
E36	22	M5	1	Existed

4. Check the continuity between ABS actuator and electric unit (control unit) harness connector and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	22	Ground	Not existed

5. Check the continuity between VDC OFF switch harness connector and ground.

VDC OFF switch		—	Continuity
Connector	Terminal		
M5	2	Ground	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace error-detected parts.

3.CHECK COMBINATION METER

1. Connect ABS actuator and electric unit (control unit) harness connector.
2. Connect VDC OFF switch harness connector.
3. Check the indication and operation of combination meter are normal. Refer to [MWI-20. "On Board Diagnosis Function"](#).

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair or replace combination meter.

VDC OFF SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

Component Inspection

INFOID:000000006941622

1.CHECK VDC OFF SWITCH

1. Turn the ignition switch OFF.
2. Disconnect VDC OFF switch harness connector.
3. Check the continuity between VDC OFF switch harness connector terminals.

VDC OFF switch	Condition	
Terminal		
1 – 2	When VDC OFF switch is hold pressed.	Existed
	When releasing VDC OFF switch.	Not existed

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Replace VDC OFF switch.

ABS WARNING LAMP

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

ABS WARNING LAMP

Component Function Check

INFOID:0000000006941624

1.CHECK ABS WARNING LAMP OPERATION

Check that the lamp illuminates for approximately 2 seconds after the ignition switch is turned ON.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Proceed to diagnosis procedure. Refer to [BRC-87, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000006941625

1.CHECK SELF-DIAGNOSIS

Perform self-diagnosis for "ABS" with CONSULT.

Is the inspection result normal?

YES >> Check combination meter. Refer to [MWI-21, "CONSULT Function"](#).

NO >> Check items displayed by self-diagnosis for "ABS" with CONSULT.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

BRC

BRAKE WARNING LAMP

Component Function Check

INFOID:000000006941628

1. BRAKE WARNING LAMP OPERATION CHECK 1

Check that the lamp illuminates for approximately 2 seconds after the ignition switch is turned ON.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Proceed to diagnosis procedure. Refer to [BRC-88, "Diagnosis Procedure"](#).

2. BRAKE WARNING LAMP OPERATION CHECK 2

Check that the brake warning lamp in the combination meter turns ON/OFF correctly when operating the parking brake pedal.

NOTE:

Brake warning lamp will turn on in case of parking brake operation (when switch is ON) or of brake fluid level switch operation (when brake fluid is insufficient).

Is the inspection result normal?

YES >> INSPECTION END

NO >> Check parking brake switch. Refer to [BRC-83, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000006941629

1. CHECK PARKING BRAKE SWITCH

Check that the brake warning lamp in the combination meter turns ON/OFF correctly when operating the parking brake pedal.

NOTE:

Brake warning lamp will turn on in case of parking brake operation (when switch is ON) or of brake fluid level switch operation (when brake fluid is insufficient).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check parking brake switch. Refer to [BRC-83, "Diagnosis Procedure"](#).

2. CHECK SELF-DIAGNOSIS

Perform self-diagnosis for "ABS" with CONSULT.

Is the inspection result normal?

YES >> Check combination meter. Refer to [MWI-21, "CONSULT Function"](#).

NO >> Check items displayed by self-diagnosis for "ABS" with CONSULT.

VDC OFF INDICATOR LAMP

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

VDC OFF INDICATOR LAMP

Component Function Check

INFOID:0000000006941632

1.VDC OFF INDICATOR LAMP OPERATION CHECK 1

Check that the lamp illuminates for approximately 2 seconds after the ignition switch is turned ON.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Proceed to diagnosis procedure. Refer to [BRC-89, "Diagnosis Procedure"](#).

2.VDC OFF INDICATOR LAMP OPERATION CHECK 2

Check that the VDC OFF indicator lamp in the combination meter turns ON/OFF correctly when operating the VDC OFF switch.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Check VDC OFF switch. Refer to [BRC-85, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000006941633

BRC

1.CHECK VDC OFF SWITCH

Check that the VDC OFF indicator lamp in the combination meter turns ON/OFF correctly when operating the VDC OFF switch.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check VDC OFF switch. Refer to [BRC-85, "Diagnosis Procedure"](#).

2.CHECK SELF-DIAGNOSIS

Perform self-diagnosis for "ABS" with CONSULT.

Is the inspection result normal?

YES >> Check combination meter. Refer to [MWI-21, "CONSULT Function"](#).

NO >> Check items displayed by self-diagnosis for "ABS" with CONSULT.

SLIP INDICATOR LAMP

Component Function Check

INFOID:000000006941635

1.CHECK SLIP INDICATOR LAMP OPERATION

Check that the lamp illuminates for approximately 2 seconds after the ignition switch is turned ON.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Proceed to diagnosis procedure. Refer to [BRC-90, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000006941636

1.CHECK SELF-DIAGNOSIS

Perform self-diagnosis for "ABS" with CONSULT.

Is the inspection result normal?

YES >> Check combination meter. Refer to [MWI-21, "CONSULT Function"](#).

NO >> Check items displayed by self-diagnosis for "ABS" with CONSULT.

EXCESSIVE ABS FUNCTION OPERATION FREQUENCY

< SYMPTOM DIAGNOSIS >

[WITH VDC]

SYMPTOM DIAGNOSIS

EXCESSIVE ABS FUNCTION OPERATION FREQUENCY

Description

INFOID:000000007227896

Diagnosis Procedure

INFOID:000000006941641

1.CHECK START

Check front and rear brake force distribution using a brake tester. Refer to [BR-45, "General Specifications"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check brake system.

2.CHECK FRONT AND REAR AXLE

Make sure that there is no excessive play in the front and rear axles.

- Front: Refer to [FAX-6, "Inspection"](#).
- Rear: Refer to [RAX-5, "Inspection"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace error-detected parts.

3.CHECK WHEEL SENSOR AND SENSOR ROTOR

Check the following.

- Wheel sensor installation for damage.
 - Front wheel sensor: Refer to [BRC-98, "FRONT WHEEL SENSOR : Exploded View"](#).
 - Rear wheel sensor: Refer to [BRC-99, "REAR WHEEL SENSOR : Exploded View"](#).
- Wheel sensor connector connection.
- Wheel sensor harness inspection.
- Sensor rotor installation for damage.
 - Front sensor rotor: Refer to [BRC-100, "FRONT SENSOR ROTOR : Exploded View"](#).
 - Rear sensor rotor: Refer to [BRC-100, "REAR SENSOR ROTOR : Exploded View"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace wheel sensor or sensor rotor.

- Front wheel sensor: Refer to [BRC-98, "FRONT WHEEL SENSOR : Exploded View"](#).
- Rear wheel sensor: Refer to [BRC-99, "REAR WHEEL SENSOR : Exploded View"](#).
- Front sensor rotor: Refer to [BRC-100, "FRONT SENSOR ROTOR : Exploded View"](#).
- Rear sensor rotor: Refer to [BRC-100, "REAR SENSOR ROTOR : Exploded View"](#).

4.CHECK ABS WARNING LAMP DISPLAY

Make sure that the ABS warning lamp is turned off after the ignition switch is turned ON or when driving.

Is the inspection result normal?

YES >> Normal

NO >> Perform self-diagnosis for "ABS" with CONSULT.

UNEXPECTED PEDAL REACTION

[WITH VDC]

< SYMPTOM DIAGNOSIS >

UNEXPECTED PEDAL REACTION

Description

INFOID:000000007227899

Diagnosis Procedure

INFOID:000000006941642

1.CHECK BRAKE PEDAL, BRAKE BOOSTER, BRAKE MASTER CYLINDER

Check brake pedal, brake booster, brake master cylinder mounting condition.

- Brake pedal: Refer to [BR-18, "Exploded View"](#).
- Brake booster: Refer to [BR-28, "Exploded View"](#).
- Brake master cylinder: Refer to [BR-25, "Exploded View"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace error-detected parts.

2.CHECK BRAKE PEDAL STROKE

Check brake pedal stroke. Refer to [BR-7, "Inspection and Adjustment"](#).

Is the stroke too large?

YES >> Bleed air from brake tube and hose. Refer to [BR-11, "Bleeding Brake System"](#).

NO >> GO TO 3.

3.CHECK FUNCTION

Disconnect ABS actuator and electric unit (control unit) connector to deactivate ABS. Check if braking force is normal in this condition. Connect connector after inspection.

Is the inspection result normal?

YES >> Normal

NO >> Check brake system.

THE BRAKING DISTANCE IS LONG

< SYMPTOM DIAGNOSIS >

[WITH VDC]

THE BRAKING DISTANCE IS LONG

Description

INFOID:000000007227900

Diagnosis Procedure

INFOID:000000006941643

CAUTION:

The stopping distance on slippery road surfaces might be longer with the ABS operating than when the ABS is not operating.

1.CHECK FUNCTION

Turn the ignition switch OFF and disconnect ABS actuator and electric unit (control unit) harness connector to deactivate ABS. In this condition, check stopping distance. After inspection, connect connector.

Is the inspection result normal?

YES >> Normal

NO >> Check brake system.

A

B

C

D

E

BRC

G

H

I

J

K

L

M

N

O

P

ABS FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[WITH VDC]

ABS FUNCTION DOES NOT OPERATE

Description

INFOID:000000007227901

Diagnosis Procedure

INFOID:000000006941644

CAUTION:

ABS does not operate when speed is 10 km/h (6 MPH) or lower.

1. CHECK ABS WARNING LAMP DISPLAY

Make sure that the ABS warning lamp turns OFF after ignition switch is turned ON or when driving.

Is the inspection result normal?

YES >> Normal

NO >> Perform self-diagnosis.

PEDAL VIBRATION OR ABS OPERATION SOUND OCCURS

< SYMPTOM DIAGNOSIS >

[WITH VDC]

PEDAL VIBRATION OR ABS OPERATION SOUND OCCURS

Description

INFOID:000000007227902

Diagnosis Procedure

INFOID:000000006941645

CAUTION:

Under the following conditions, ABS is activated and vibration is felt when brake pedal is lightly depressed (just place a foot on it). However, this is normal.

- When shifting gears
- When driving on slippery road
- During cornering at high speed
- When passing over bumps or grooves [at approximately 50 mm (1.97 in) or more]
- When pulling away just after starting engine [at approximately 10 km/h (6 MPH) or higher]

1. SYMPTOM CHECK 1

Check that there are pedal vibrations when the engine is started.

Do vibrations occur?

YES >> GO TO 2.

NO >> Inspect the brake pedal. Refer to [BR-19, "Inspection and Adjustment"](#).

2. SYMPTOM CHECK 2

Check that there are ABS operation noises when the engine is started.

Do the operation noises occur?

YES >> GO TO 3.

NO >> Perform self-diagnosis for "ABS" with CONSULT.

3. SYMPTOM CHECK 3

Check symptoms when electrical component (headlamps, etc.) switches are operated.

Do symptoms occur?

YES >> Check if there is a radio, antenna, antenna lead wire, or wiring close to the control unit. If there is, move it farther away.

NO >> Normal

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

VEHICLE JERKS DURING VDC/TCS/ABS CONTROL

< SYMPTOM DIAGNOSIS >

[WITH VDC]

VEHICLE JERKS DURING VDC/TCS/ABS CONTROL

Description

INFOID:000000007227903

Diagnosis Procedure

INFOID:000000006941646

1. SYMPTOM CHECK

Check if the vehicle jerks during VDC/TCS/ABS control.

Is the inspection result normal?

- YES >> Normal.
- NO >> GO TO 2.

2. CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT.

Are self-diagnosis results indicated?

- YES >> Check corresponding items, make repairs, and perform self-diagnosis for "ABS" with CONSULT.
- NO >> GO TO 3.

3. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Check terminal for deformation, disconnection, looseness, etc.
4. Securely connect connectors and perform self-diagnosis for "ABS" with CONSULT.

Are self-diagnosis results indicated?

- YES >> If poor contact, damage, open or short circuit of connector terminal is found, repair or replace.
- NO >> GO TO 4.

4. CHECK ECM AND TCM SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ENGINE" and "TRANSMISSION" with CONSULT.

Are self-diagnosis results indicated?

- YES >> Check the corresponding items.
- NO >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-101. "Exploded View"](#).

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[WITH VDC]

NORMAL OPERATING CONDITION

Description

INFOID:000000006941647

Symptom	Result
Slight vibrations are felt on the brake pedal and the operation noises occur, when VDC, TCS or ABS is activated.	This is a normal condition due to the VDC, TCS or ABS activation.
Stopping distance is longer than that of vehicles without ABS when the vehicle drives on rough, gravel, or snow-covered (fresh, deep snow) roads.	
The brake pedal moves and generates noises, when TCS or VDC is activated due to rapid acceleration or sharp turn.	
The brake pedal vibrates and motor operation noises occur from the engine room, after the engine starts and just after the vehicle starts.	This is a normal, and it is caused by the ABS operation check.
Depending on the road conditions, the driver may experience a sluggish feel.	This is normal, because TCS places the highest priority on the optimum traction (stability).
TCS may activate momentarily if wheel speed changes when driving over location where friction coefficient varies, when downshifting, or when fully depressing accelerator pedal.	
The ABS warning lamp, VDC OFF indicator lamp and SLIP indicator lamp may turn ON when the vehicle is subject to strong shaking or large vibration, such as when the vehicle is rotating on a turntable or located on a ship while the engine is running.	In this case, restart the engine on a normal road. If the normal condition is restored, there is no malfunction. At that time, erase the self-diagnosis memory.
VDC may not operate normally or the ABS warning lamp, VDC OFF indicator lamp, and SLIP indicator lamp may illuminate, when running on a special road that is extremely slanted (e.g. bank in a circuit course).	
A malfunction may occur in the yaw rate/side G sensor system, when the vehicle turns sharply, such as during a spin turn, axle turn, or drift driving, while the VDC function is off (VDC OFF indicator lamp illuminated).	
The vehicle speed will not increase even though the accelerator pedal is depressed, when inspecting the speedometer on a 2-wheel chassis dynamometer.	Normal (Deactivate the VDC/TCS function before performing an inspection on a chassis dynamometer.)

A

B

C

D

E

BRC

G

H

I

J

K

L

M

N

O

P


REMOVAL AND INSTALLATION

WHEEL SENSOR

FRONT WHEEL SENSOR

FRONT WHEEL SENSOR : Exploded View

INFOID:000000006941656



1. Front LH wheel sensor connector 2. Front LH wheel sensor

B. White line (slant line)

↶ : Vehicle front

Refer to [GI-4, "Components"](#) for symbol in the figure.

NOTE:

The above figure (front side) shows left side. Right side is the mirror image.

FRONT WHEEL SENSOR : Removal and Installation

INFOID:000000006941657

REMOVAL

Be careful with the following when removing sensor.

CAUTION:

- Never twist sensor harness as much as possible, when removing it. Pull sensors out without pulling sensor harness.
- Be careful to avoid damaging sensor edges or rotor teeth. Remove wheel sensor first before removing front or rear wheel hub. This is to avoid damage to sensor wiring and loss of sensor function.
- When you see the harness of the wheel sensor from the front side of the vehicle ensure that the white lines (B) are not twisted.

INSTALLATION

Be careful with the following when installing wheel sensor. Tighten installation bolts to the specified torques.

- When installing, make sure there is no foreign material such as iron chips on and in the mounting hole of the wheel sensor. Make sure no foreign material has been caught in the sensor rotor. Remove any foreign material and clean the mount.

WHEEL SENSOR

< REMOVAL AND INSTALLATION >


[WITH VDC]

- When installing wheel sensor, be sure to press rubber grommets in until they lock at locations shown above in the figure. When installed, harness must not be twisted.

REAR WHEEL SENSOR

REAR WHEEL SENSOR : Exploded View

INFOID:000000006941658



1. Rear RH wheel sensor
2. Rear RH wheel sensor connector
3. Rear LH wheel sensor connector
4. Rear LH wheel sensor

B. AWD models only C. White line (slant line)

⇐ : Vehicle front

Refer to [GI-4, "Components"](#) for symbol in the figure.

REAR WHEEL SENSOR : Removal and Installation

INFOID:000000006941659

REMOVAL

Be careful with the following when removing sensor.

CAUTION:

- **Never twist sensor harness as much as possible, when removing it. Pull sensors out without pulling sensor harness.**
- **Be careful to avoid damaging sensor edges or rotor teeth. Remove wheel sensor first before removing front or rear wheel hub. This is to avoid damage to sensor wiring and loss of sensor function.**

INSTALLATION

Be careful with the following when installing wheel sensor. Tighten installation bolts to the specified torques.

- When installing, make sure there is no foreign material such as iron chips on and in the mounting hole of the wheel sensor. Make sure no foreign material has been caught in the sensor rotor. Remove any foreign material and clean the mount.
- When installing wheel sensor, be sure to press rubber grommets in until they lock at locations shown above in the figure. When installed, harness must not be twisted.

SENSOR ROTOR

FRONT SENSOR ROTOR

FRONT SENSOR ROTOR : Exploded View

INFOID:000000006941660

Refer to [FAX-8, "Exploded View"](#).

FRONT SENSOR ROTOR : Removal and Installation

INFOID:000000006941661

REMOVAL

Sensor rotor cannot be disassembled. Remove the sensor rotor together with hub bearing assembly. Refer to [FAX-8, "Removal and Installation"](#).

INSTALLATION

Sensor rotor cannot be disassembled. Install the sensor rotor together with hub bearing assembly. Refer to [FAX-8, "Removal and Installation"](#).

REAR SENSOR ROTOR

REAR SENSOR ROTOR : Exploded View

INFOID:000000006941662

Refer to [RAX-7, "Exploded View"](#).

REAR SENSOR ROTOR : Removal and Installation

INFOID:000000006941663

REMOVAL

Sensor rotor cannot be disassembled. Remove the sensor rotor together with hub bearing assembly. Refer to [RAX-9, "Removal and Installation"](#).

INSTALLATION

Sensor rotor cannot be disassembled. Install the sensor rotor together with hub bearing assembly. Refer to [RAX-9, "Removal and Installation"](#).

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)


< REMOVAL AND INSTALLATION >

[WITH VDC]

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Exploded View

INFOID:000000006941664



1. ABS actuator and electric unit (control unit) 2. Bracket

- A. To rear RH brake caliper B. To rear LH brake caliper C. From master cylinder primary side
D. To front RH brake caliper E. To front LH brake caliper F. From master cylinder secondary side

⇐: Vehicle front

Refer to [GI-4, "Components"](#) for symbol in the figure.

Removal and Installation

INFOID:000000006941665

REMOVAL

CAUTION:

- Before servicing, disconnect the battery cable from negative terminal.
- To remove brake tube, use a flare nut wrench to prevent flare nuts and brake tube from being damaged. To install, use flare nut crowfoot and torque wrench.
- Never apply excessive impact to ABS actuator and electric unit (control unit), such as dropping it.
- Never remove and install actuator by holding harness.

1. Remove cowl top. Refer to [EXT-20, "Exploded View"](#).
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Loosen brake tube flare nuts, then remove brake tubes from ABS actuator and electric unit (control unit).
4. Remove ABS actuator and electric unit (control unit) bracket mounting nut.
5. Remove ABS actuator and electric unit (control unit) from vehicle.

INSTALLATION

Note the following, and install in the reverse order of removal.

CAUTION:

- Before servicing, disconnect the battery cable from negative terminal.

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)


[WITH VDC]

< REMOVAL AND INSTALLATION >

- To remove brake tube, use a flare nut wrench to prevent flare nuts and brake tube from being damaged. To install, use flare nut crowfoot and torque wrench.
- Never apply excessive impact to ABS actuator and electric unit (control unit), such as dropping it.
- Never remove and install actuator by holding harness.
- After work is completed, bleed air from brake tube. Refer to [BR-11, "Bleeding Brake System"](#).
- After installing harness connector in the ABS actuator and electric unit (control unit), make sure connector is securely locked.
- After removing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
- Calibration of decel G sensor: Refer to [BRC-37, "Description"](#).
- After replacing an ABS actuator and electric unit (control unit), be sure to perform the following procedure.
- Adjustment of steering angle sensor neutral position: Refer to [BRC-35, "Description"](#).
- Calibration of decel G sensor: Refer to [BRC-37, "Description"](#).

Install ABS actuator and electric unit (control unit) as per the following steps.

1. Temporarily tighten mounting bolt (1) because the bracket (2) is temporarily being hold.
2. Tighten mounting bolt (3) while holding the bracket.
3. Tighten mounting bolts to the specified torque in the order of (4), (1).



YAW RATE/SIDE/DECEL G SENSOR


< REMOVAL AND INSTALLATION >

[WITH VDC]

YAW RATE/SIDE/DECEL G SENSOR

Exploded View

INFOID:000000006941666



1. Yaw rate/side/decel G sensor
2. Connector

←: Vehicle front

Refer to [GI-4, "Components"](#) for symbol in the figure.

Removal and Installation

INFOID:000000006941667

REMOVAL

CAUTION:

Never drop or strike yaw rate/side/decel G sensor, or never use power tool etc., because yaw rate/side/decel G sensor is sensitive to the impact.

1. Remove center console assembly. Refer to [IP-20, "Exploded View"](#).
2. Disconnect yaw rate/side/decel G sensor harness connector.
3. Remove mounting nuts.
4. Remove yaw rate/side/decel G sensor.

INSTALLATION

Note the following, and install in the reverse order of removal.

CAUTION:

- **Never drop or strike yaw rate/side/decel G sensor, or never use power tool etc., because yaw rate/side/decel G sensor is sensitive to the impact.**
- **After removing/replacing a yaw rate/side/decel G sensor, be sure to perform the calibration of decel G sensor. Refer to [BRC-37, "Description"](#).**

STEERING ANGLE SENSOR


< REMOVAL AND INSTALLATION >

[WITH VDC]

STEERING ANGLE SENSOR

Exploded View

INFOID:000000006941668



1. Steering angle sensor

↩: Vehicle front

Removal and Installation

INFOID:000000006941669

REMOVAL

1. Remove spiral cable assembly. Refer to [SR-14, "Exploded View"](#).
2. Remove steering angle sensor from spiral cable assembly.

INSTALLATION

Note the following, and install in the reverse order of removal.

CAUTION:

- Never reuse steering angle sensor.
- After removing/replacing a steering angle sensor, be sure to perform the adjustment of steering angle sensor neutral position. Refer to [BRC-35, "Description"](#).

VDC OFF SWITCH

Removal and Installation

INFOID:000000007227905

REMOVAL

1. Remove lower instrument panel. Refer to [IP-13, "Removal and Installation"](#).
2. Remove VDC OFF switch.

INSTALLATION

Installation is the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

BRC