


DTC**B1630/23****Driver Side Rear Airbag Sensor Malfunction****DESCRIPTION**

The rear airbag sensor LH consists of the safing sensor, the diagnostic circuit, the lateral deceleration sensor, etc.


If the center airbag sensor assembly receives signals from the lateral deceleration sensor, it determines whether the SRS should be activated.

DTC B1630/23 is recorded when a malfunction is detected in the rear airbag sensor LH.

DTC No.	DTC Detection Condition	Trouble Area
B1630/23	- Rear airbag sensor LH malfunction - Center airbag sensor assembly malfunction	- Rear airbag sensor LH - Center airbag sensor assembly

WIRING DIAGRAM

INSPECTION PROCEDURE

1 CHECK DTC

- (a) Turn the power switch on (IG), and wait for at least 60 seconds.
- (b) Clear the DTCs stored in the memory (See page RS-41).
- (c) Turn the power switch off.
- (d) Turn the power switch on (IG), and wait for at least 60 seconds.
- (e) Check the DTCs (See page RS-41).

OK:**DTC B1630/23 is not output.****HINT:**

Codes other than DTC B1630/23 may be output at this time, but they are not related to this check.


OK

USE SIMULATION METHOD TO CHECK (See page RS-33)

NG**2 CONFIRM PART NUMBER OF REAR AIRBAG SENSOR**

- (a) Turn the power switch off.
- (b) Disconnect the negative (-) terminal cable from the battery, and wait for at least 90 seconds.
- (c) Check that the part number of the rear airbag sensor LH is equal to the number of the other side.

OK:**Those numbers are the same.****NG****Go to step 4****OK**

3 CHECK REAR AIRBAG SENSOR LH

- Interchange the rear airbag sensor RH with LH and connect the connectors to them.
- Connect the negative (-) terminal cable to the battery, and wait for at least 2 seconds.
- Turn the power switch on (IG), and wait for at least 60 seconds.
- Clear the DTCs stored in the memory (See page RS-41).
- Turn the power switch off.
- Turn the power switch on (IG), and wait for at least 60 seconds.
- Check the DTCs (See page RS-41).

Result

Result	Proceed to
DTC B1630/23 is output.	A
DTC B1635/24 is output.	B
DTC B1630/23 and B1635/24 are not output.	C

HINT:

Codes other than DTC B1630/23 and B1635/24 may be output at this time, but they are not related to this check.

- Turn the power switch off.
- Disconnect the negative (-) terminal cable from the battery, and wait for at least 90 seconds.
- Return the rear airbag sensor RH and LH to their original positions and connect the connectors to them.

A**Go to step 5****B****REPLACE REAR AIRBAG SENSOR LH (See page RS-435)****C****USE SIMULATION METHOD TO CHECK (See page RS-33)****4 REPLACE REAR AIRBAG SENSOR LH**


- Replace the rear airbag sensor LH (See page RS-435).

HINT:

Perform inspection using parts from a normal vehicle if possible.

NEXT

5 CHECK CENTER AIRBAG SENSOR ASSEMBLY



- Connect the negative (-) terminal cable to the battery, and wait for at least 2 seconds.
- Turn the power switch on (IG), and wait for at least 60 seconds.
- Clear the DTCs stored in the memory (See page [RS-41](#)).
- Turn the power switch off.
- Turn the power switch on (IG), and wait for at least 60 seconds.
- Check the DTCs (See page [RS-41](#)).

OK:

DTC B1630/23 is not output.

HINT:

Codes other than DTC B1630/23 may be output at this time, but they are not related to this check.

NG

REPLACE CENTER AIRBAG SENSOR ASSEMBLY (See page [RS-423](#))

OK

USE SIMULATION METHOD TO CHECK (See page [RS-33](#))