

DTC CHECK / CLEAR

1. DTC CHECK

HINT:

When DTC B1650/32 is detected as a result of troubleshooting for "AIRBAG SYSTEM", perform troubleshooting for the occupant classification system.

(a) Check for DTCs.

- (1) Connect the intelligent tester to the DLC3.
- (2) Turn the power switch on (IG).
- (3) Check the DTCs by following the prompts on the tester screen.

HINT:


Refer to the intelligent tester operator's manual for further details.

(b) Clear DTCs.

- (1) Connect the intelligent tester to the DLC3.
- (2) Turn the power switch on (IG).
- (3) Clear the DTCs by following the prompts on the tester screen.

HINT:


Refer to the intelligent tester operator's manual for further details.



DATA LIST / ACTIVE TEST

HINT:

By accessing the DATA LIST displayed on the intelligent tester, you can perform such functions as reading the values of switches and sensors without removing any parts. Reading the DATA LIST is the first step in troubleshooting is one method to save labor time.



1. DATA LIST FOR OCCUPANT CLASSIFICATION ECU

- Connect the intelligent tester to the DLC3.
- Turn the power switch on (IG).
- Turn the tester ON.
- Enter the following menus: DIAGNOSIS / OBD/ MOBD / OCCUPANT DETECT / DATA LIST.
- Check the values by referring to: the table below.

DATA LIST:

Tester Display	Measurement Item/Range	Normal Condition	Diagnostic Note
IG SW	Power switch condition/ ON: Power switch on (IG) OFF: Power switch off	ON/OFF	-
P BUCKLE SW	Passenger side buckle switch/ SET: The seat belt is fastened UNSET: The seat belt is not fastened NG: Data is not determined	SET/UNSET	-
PASSENGER CLASS	Passenger classification/ AM50: Adult (more than 54 kg (119.05 lb)) is seated AF05: Adult (36 to 54 kg (79.37 to 119.05 lb)) is seated CHILD: Child (less than 36 kg (79.37 lb)) is seated CRS: Child restraint system (less than 7 kg (15.43 lb)) and passenger side buckle switch is ON, then 7 to 36 kg (15.43 to 79.37 lb) is set OFF: Vacant	AM50/AF05/CHILD/CRS/OFF	-
SENS RANGE INF	Sensor range information/ OK: The value of a sensor is within the range NG: The value of a sensor is over the range	OK	-
FL SENS RANGE	Front left sensor range information/ OK: Sensor range is -17 to 27 kg (-37.48 to 59.52 lb) Min.: Less than -17 kg (-37.48 lb) Max.: More than 27 kg (59.52 lb)	OK	-

Tester Display	Measurement Item/Range	Normal Condition	Diagnostic Note
FR SENS RANGE	Front right sensor range information/ OK: Sensor range is -17 to 27 kg (-37.48 to 59.52 lb) Min.: Less than -17 kg (-37.48 lb) Max.: More than 27 kg (59.52 lb)	OK	-
RL SENS RANGE	Rear left sensor range information/ OK: Sensor range is -17 to 37 kg (-37.48 to 81.57 lb) Min.: Less than -17 kg (-37.48 lb) Max.: More than 37 kg (81.57 lb)	OK	-
RR SENS RANGE	Rear right sensor range information/ OK: Sensor range is -17 to 37 kg (-37.48 to 81.57 lb) Min.: Less than -17 kg (-37.48 lb) Max.: More than 37 kg (81.57 lb)	OK	-
FL SENS VOL	Front left sensor voltage/ Min.: 0 V Max.: 19.8 V	0 to 4.7 V	-
FR SENS VOL	Front right sensor voltage/ Min.: 0 V Max.: 19.8 V	0 to 4.7 V	-
RL SENS VOL	Rear left sensor voltage/ Min.: 0 V Max.: 19.8 V	0 to 4.7 V	-
RR SENS VOL	Rear right sensor voltage/ Min.: 0 V Max.: 19.8 V	0 to 4.7 V	-
FL SENS WEIGHT	Front left sensor weight information/ Min.: -17 kg (-37.48 lb) Max.: 27 kg (59.52 lb)	-17 to 27 kg (-37.48 to 59.52 lb)	-
FR SENS WEIGHT	Front right sensor weight information/ Min.: -17 kg (-37.48 lb) Max.: 27 kg (59.52 lb)	-17 to 27 kg (-37.48 to 59.52 lb)	-
RL SENS WEIGHT	Rear left sensor weight information/ Min.: -17 kg (-37.48 lb) Max.: 37 kg (81.57 lb)	-17 to 37 kg (-37.48 to 81.57 lb)	-
RR SENS WEIGHT	Rear right sensor weight information/ Min.: -17 kg (-37.48 lb) Max.: 37 kg (81.57 lb)	-17 to 37 kg (-37.48 to 81.57 lb)	-
TOTAL WEIGHT	Total weight information/ Min.: -68 kg (-149.91 lb) Max.: 128 kg (282.19 lb)	-68 to 128 kg (-149.91 to 282.19 lb)	-
#PRESENT CODES	Number of present DTC recorded/ Min.: 0, Max.: 255	0	-
#PAST CODES	Number of past DTC recorded/ Min.: 0, Max.: 255	0	-