

FAMILIARISATION

EXTERIOR

Directional lighting

This lighting automatically provides additional visibility when cornering.

» 81

Retractable roof

This equipment changes from the "coupé" configuration to the "cabriolet" configuration and vice versa with a single action.

» 6

Temporary tyre repair kit

This kit is a complete system, consisting of a compressor and an integrated filling product, for the temporary repair of a tyre.

» 129

Welcome lighting

This additional exterior and interior lighting, controlled remotely, makes your approach to the vehicle easier when the light is poor.

» 80, 85

Windstop

In the "cabriolet" configuration, this comfort equipment reduces air swirl at the front seats.

» 52



OPEN

Remote control key



A. Unfolding/Folding of the key.



Normal locking
(press once; fixed lighting of
the direction indicators).

or



Deadlocking of the vehicle
(press twice in succession;
fixed lighting of the direction
indicators).

Locking the vehicle using the remote
control or the key also locks the glove
box and the front armrest.

» 63



Unlocking and partial opening
of the boot
(press for more than two sec-
onds).



Complete or selective unlocking
of the vehicle
(rapid flashing of the direction
indicators).

When the light is poor, detected by a
sensor, the remote switching on of the
dipped headlamps, side lights and lat-
eral spotlights makes your approach to
the vehicle easier.


» 80



In the same way, the passenger com-
partment lighting, such as the courtesy
lights, the door sill lights and the foot-
well lights, comes on.

» 85

Fuel tank



1. Opening of the fuel filler flap.
2. Opening and hooking of the fuel
tank cap.

Capacity of the tank: approximately
60 litres.

» 76

OPEN


Retractable roof

Precautions to be taken before operating the roof

- ☞ Park the vehicle on level ground.
- ☞ Check that no objects could hinder the operation of the roof:
 - nothing should be placed on the moving rear shelf 1, on the boot screen 2 or on the side trims 3,
 - if luggage is transported in the boot, it must not lift the boot screen,
 - any objects, such as a jacket or umbrella, placed in the boot, must be secured using the luggage retaining net 4.
- ☞ Check that the boot screen 2 is secured firmly.
- ☞ Close the boot correctly.



The operation of the roof is the exclusive responsibility of the driver. To avoid any risk of injury when operating the roof, ensure that no one is standing near the moving parts. You are strongly advised not to operate the roof in strong winds.



When washing your vehicle:

- lock the vehicle using the remote control or the key,
- avoid spraying the upper part of the windows,
- keep the end of the high pressure nozzle at least 1 metre from the windows and door seals.

When the vehicle has been washed or after rain, wait until the roof has dried before opening it.

Preliminary conditions

- ☞ Switch on the ignition.
- ☞ Make absolutely sure that:
 - the vehicle is not in energy economy mode (refer to the corresponding section),
 - the battery voltage is sufficient (switching on of the roof control indicator light),
 - the roof fuse is in good condition (refer to the corresponding section),
 - the electric windows are initialised (see corresponding section),
 - the exterior temperature is higher than -15 °C.



It is preferable to operate the roof with the engine running and the vehicle stationary.

The roof can be operated at a speed below 6 mph (10 km/h).

After the roof has been operated fully four times in succession, the system switches to protection mode temporarily to avoid damage to the roof motors. Let the system rest for approximately ten minutes; if you are unable to operate the roof after this time, contact a PEUGEOT dealer.

OPEN

Retractable roof operations

Opening the roof



- ☞ Pull this control until the roof opening operation is complete.

The end of the manoeuvre is confirmed by an audible signal and a message on the multifunction display.

Closing the roof



- ☞ Press this control until the roof closing operation is complete.

The end of the manoeuvre is confirmed by an audible signal and a message on the multifunction display.



Change to "cabriolet" configuration:

- the four windows lower partially,
- the boot opens,
- the roof folds into the boot,
- the boot closes.

Change to "coupé" configuration:

- the four windows lower partially,
- the boot opens,
- the roof unfolds and locks automatically,
- the boot closes.

i If you continue to pull or press this control after the end of the manoeuvre, the four windows rise.

! To ensure that the roof operates correctly, do not release the control while the roof is moving.

However, in the event of any danger, release the control, the roof stops; then, once the danger had been eliminated, complete the movement required.



Operating fault

If a malfunction of the roof occurs, apply the handbrake, switch off the ignition, start the engine again, then start the operation required again.

If the problem persists, contact a PEUGEOT dealer.



The electric window controls and the control for all four windows are deactivated while the roof is in operation.



The roof's electronic control unit may stop the manoeuvre in progress as a precaution (example: door movement and roof manoeuvre in quick succession). In this case, release the control then operate it again to complete the required manoeuvre.

FAMILIARISATION

INTERIOR

Ambient lighting

This dimmed lighting of the passenger compartment facilitates visibility inside the vehicle when the light is poor.

» 85

Audio and telematics systems

This equipment benefits from the latest technology: MP3 compatible PC Sound, PC Bluetooth, PC Nav or PC Com 3D with 16/9 retractable colour screen, JBL audio system, auxiliary sockets.

PC Sound » 230

PC Nav » 202

PC Com 3D » 163

Secure storage compartments

The glove box and the front armrest are designed to remain locked, even in the "cabriolet" configuration. They can only be locked using the remote control or the key at the same time as the rest of the vehicle.

» 87, 88


"AIRWAVE" system

Incorporated in each front head restraint, this heating system improves your comfort around the neck in cold weather, particularly in the "cabriolet" configuration. It operates most effectively with the windstop installed in the raised position.

» 58




INSTRUMENTS AND CONTROLS



1. Steering lock and ignition.
2. Audio and telematics system steering wheel control.
3. Wipers/wash-wipe/trip computer controls.
4. Instrument panel.
5. Driver's air bag.
Horn.
6. Gear lever.
7. Handbrake.
8. 12 V accessories socket.
9. Heated seat control.
10. Exterior mirror controls.
Electric window controls.
11. Passenger air bag disarming.
12. Manual headlamp height adjustment.
13. Side adjustable and closing vent.
14. Front side window demisting vent.
15. Speaker (tweeter).
16. Windscreen demisting vent.

FAMILIARISATION

INSTRUMENTS AND CONTROLS



1. Steering wheel adjustment control.
2. Cruise control/speed limiter switches.
3. Lights and direction indicators controls.
4. Central adjustable and closing vents.
5. Multifunction display.
6. Sunshine sensor.
7. Passenger air bag.
8. Glove box/Audio/video sockets/ Fuse box.
9. Bonnet release.
10. Retractable roof control.
Control for all four windows.
11. Storage compartment or instrument panel navigator associated with the PC Com 3D.
12. "AIRWAVE" system controls.
13. Front armrest.
14. Front ashtray.
15. Heating/air conditioning controls.
16. Audio and telematics system.
17. Emergency call button.
Alarm button.
Central locking button.
Hazard warning lights button.
Dynamic stability control (ESP/ASR) button.
Parking assistance button.
PEUGEOT services button.

SIT COMFORTABLY

Front seats

Forwards-backwards



Height



Seat back angle






Manual adjustments

» 55



Electric adjustments

» 56



SIT COMFORTABLY

Front seats

Electric access to the rear seats



1. Control for release of the seat back and automatic forward movement of the seat.
2. Control for return of the seat to the initial position.

» 57



Other functions available...

Storing of driving positions (driver's electric seat).

» 59

"AIRWAVE" system.

Heated seats.

» 58

Steering wheel adjustment




1. Unlocking of the control.
2. Adjustment of the height and depth.
3. Locking of the control.



As a safety precaution, it is imperative that these operations are carried out when stationary.

» 62

Front armrest with lock



For your comfort, the height and the longitudinal position of the front armrest can be adjusted.

It also offers a storage compartment. As a security measure when in the "cabriolet" configuration, this is locked at the same time as the rest of the vehicle, using the remote control or the key only.

» 88

SIT COMFORTABLY

Exterior mirrors

Adjustment



- A. Selection of the mirror to be adjusted.
- B. Adjustment of the position of the mirror in all four directions.
- C. De-selection of the mirror.

» 60



Other functions available...

Folding/Unfolding.
Automatic tilting of the mirror in reverse gear for parking.

» 61

Interior mirror

Manual model



- 1. Selection of the "day" position of the mirror.
- 2. Directing of the mirror.

» 61



Automatic day/night model

- 1. Automatic mode On/Off.
- 2. Directing of the mirror.

» 62

Front seat belts



- A. Installation of the strap.
- B. Fastening of the buckle.
- C. Checking of the fastening by pulling the strap.

» 97

SEE CLEARLY

Lighting



Ring A

0 Lights off.

AUTO Automatic switching on of the lights.

☀ Side lights.

☀☀ Dipped/main beam headlamps.

Ring B

☀☀ Front and rear fog lamps.

» 77

Direction indicators



Raise or lower the lights stalk passing the point of resistance; the corresponding direction indicators will flash until the stalk is moved from this position.


"Motorway" function

Press the lights stalk up or down once, without passing the point of resistance; the corresponding direction indicators will flash three times.

The use of this function is available regardless of the speed, but you will find it particularly useful when changing lane on fast roads.

» 92

Wipers



Stalk A: windscreen wipers

» 82

Switching on "AUTO"

☞ Press the stalk down and release it.



Switching off "AUTO"

☞ Push the stalk up and return it to position "0".

» 83

VENTILATION

Recommended interior settings

I require...	Manual Air Conditioning				
	Air distribution	Air flow	Air recirculation/ Intake of outside air	Temperature	Manual A/C
HOT					—
COLD					ON
DEMISTING DE-ICING					ON

Automatic air conditioning

We recommend use of the fully automatic mode by pressing the **"AUTO"** button. In the "cabriolet" configuration, the system automatically adapts to the exterior climatic conditions.

FAMILIARISATION

MONITOR THOROUGHLY

Instrument panel



- A. With the ignition on, the needle should indicate the level of fuel remaining.
- B. With the engine running, its associated low level warning light should switch off.
- C. With the ignition on, the oil level indicator should display "OIL OK" for a few seconds.

If the levels are not correct, top up the levels which are low.

» 19


Warning lights



- 1. With the ignition on, the orange and red warning lights come on.
 - 2. With the engine running, these warning lights should switch off.
- If warning lights remain on, refer to the page concerned.

» 23

Controls bar



Lighting of the indicator light indicates the status of the corresponding function.

A. Emergency call in progress.

» 188

B. Disarming of the interior protection alarm.

» 68

C. Central locking.

» 73

D. Deactivation of the ESP/ASR system.

» 95

E. Deactivation of the visual and audible parking assistance.


» 119

F. Access to the PEUGEOT services.

» 188

KEEP YOUR PASSENGERS SAFE

Passenger's front air bag



1. Insertion of the key.
2. Selection of the position:
"OFF" (disarming), with "rear facing" child seat,
"ON" (activation), with front passenger or "forwards facing" child seat.
3. Removal of the key keeping the switch in this position.

» 100

Seat belts and passenger's front air bag




- A. Front and/or rear seat belts not fastened/unfastened warning light.
- B. Front left seat belt warning light.
- C. Front right seat belt warning light.
- D. Rear right seat belt warning light.
- E. Rear left seat belt warning light.
- F. Passenger's front air bag disarmed warning light.
- G. Passenger's front air bag activated warning light.

» 97, 101

START

Ignition switch



1. **Stop** position.
2. **Running** position.
3. **Starting** position.

i Avoid attaching any heavy objects to the key which would weigh down on its shaft in the ignition switch; this could cause a malfunction.

» 66

DRIVE SAFELY

Speed limiter "LIMIT"



1. Limiter mode Selection/Off.
 2. Decreasing of the programmed value.
 3. Increasing of the programmed value.
 4. Speed limiter On/Off.
- The values must be set with the engine running.

» 115

Cruise control "CRUISE"



1. Cruise control mode Selection/Off.
2. Programming a speed/Decreasing of the programmed value.
3. Programming a speed/Increasing of the programmed value.
4. Cruise control Off/Resume.

In order to be programmed or activated, the vehicle speed must be higher than 25 mph (40 km/h), with at least fourth gear engaged on the manual gearbox (second gear for the automatic gearbox).

» 117

Display on the instrument panel



The cruise control or speed limiter mode appears on the instrument panel when it is selected.



Cruise control



Speed limiter

PETROL - DIESEL MANUAL GEARBOX INSTRUMENT PANELS



Panel grouping together the vehicle operation indication dials and warning lights.

Dials

1. **Rev counter.**
Indicates the speed of rotation of the engine (x 1 000 rpm).
2. **Coolant temperature.**
Indicates the temperature of the engine coolant (°Celsius).
3. **Fuel level.**
Indicates the quantity of fuel remaining in the tank.
4. **Vehicle speed.**
Indicates the current speed of the moving vehicle (km/h or mph).

5. **Display.**
6. **Display zero reset button.**
Resets the selected function to zero (trip distance recorder or service indicator).
7. **Instrument panel lighting button.**
Adjusts the brightness of the lighting of the instruments and controls.



For further information, refer to the paragraph relating to the button or function and its associated display.

Display

- A. **Speed limiter**
or
Cruise control.
(km/h or mph)
- B. **Trip distance recorder.**
(km or miles)
The following three functions are displayed in succession when the ignition is switched on.
- C. **Service indicator.**
(km or miles) then,
Engine oil level indicator.
then
distance recorder.
(km or miles)

1 INSTRUMENTS and CONTROLS

PETROL - DIESEL MANUAL OR AUTOMATIC GEARBOX INSTRUMENT PANELS



Panel grouping together the vehicle operation indication dials and warning lights.

Dials

1. Rev counter.

Indicates the speed of rotation of the engine (x 1 000 rpm).

2. Coolant temperature.

Indicates the temperature of the engine coolant (°Celsius).

3. Fuel level.

Indicates the quantity of fuel remaining in the tank.

4. Vehicle speed.

Indicates the current speed of the moving vehicle (km/h or mph).

5. Small display.

6. Large display.

7. CHECK/display zero reset button.

Starts a manual CHECK.

Resets the function selected to zero (trip distance recorder or service indicator).

8. Instrument panel lighting button.

Adjusts the brightness of the lighting of the instruments and controls.



For further information, refer to the paragraph which relates to the button or function and its associated display.

Displays



A. Trip distance recorder.

(km or miles)

B. Distance recorder.

(km or miles)

The following two functions are displayed in succession when the ignition is switched on.

C. Service indicator.

(km or miles) then,

Engine oil level indicator.

The following functions are displayed in accordance with the selection.

- Warning lights/CHECK.
- Tyre under-inflation detection.
- Speed limiter/Cruise control.
- Automatic gearbox.
- Navigation - Guidance/Trip computer information.

PETROL - DIESEL MANUAL OR AUTOMATIC GEARBOX PC COM 3D INSTRUMENT PANELS



Panel grouping together the vehicle operation indication dials and warning lights.

Dials

1. **Rev counter.**
Indicates the speed of rotation of the engine (x 1 000 rpm).
2. **Coolant temperature.**
Indicates the temperature of the engine coolant (°Celsius).
3. **Fuel level.**
Indicates the quantity of fuel remaining in the tank.
4. **Vehicle speed.**
Indicates the current speed of the moving vehicle (km/h or mph).

5. **Small display.**
6. **PC Com 3D 16/9 large display.**
7. **CHECK/display zero reset button.**
Starts a manual CHECK.
Resets the function selected to zero (trip distance recorder or service indicator).
8. **Instrument panel lighting button.**
Adjusts the brightness of the lighting of the instruments and controls.

i For further information, refer to the paragraph which relates to the button or function and its associated display.

Displays



A. Trip distance recorder.
(km or miles)

B. Distance recorder.
(km or miles)

The following two functions are displayed in succession when the ignition is switched on.

C. Service indicator.
(km or miles) then,
Engine oil level indicator.

The following functions are displayed in accordance with the selection.

- **Warning lights/CHECK.**
- **Tyre under-inflation detection.**
- **Speed limiter/Cruise control.**
- **Automatic gearbox.**
- **Navigation - Guidance/Trip computer.**
- **Vehicle parameters.**

1 INSTRUMENTS and CONTROLS

The instrument panel navigator associated with the PC Com 3D



This group of buttons permits:

- **when stationary**, configuration of the vehicle's equipment and of the parameters of the display (languages, units...),
- **while driving**, scrolling of the active functions (trip computer, navigation...).

Controls

There are four buttons to control the instrument panel 16/9 large display:

1. access the general menu, confirm the selection,
2. move up through the menu,
3. move down through the menu,
4. return to the previous screen, exit from the menu.




The general menu and its associated functions can only be accessed when stationary, via buttons 1 to 4.

A message appears on the display, above a certain speed threshold, indicating that the general menu cannot be displayed.

The trip computer displays can only be accessed while driving, via buttons 2 and 3 (refer to the "Trip computer" paragraph).

General menu

- Press button 1 to gain access to the general menu and select one of the following functions:
 - "Vehicle parameters",
 - "Selection of the language",
 - "Selection of the units".
- Press button 2 or 3 to move on the screen.
- Press button 1 again to confirm the selection.



Vehicle parameters

This menu allows you to activate or deactivate certain driving and comfort equipment:

- selective unlocking (refer to the "Accesses" section),
- follow-me-home and welcome lighting (refer to the "Visibility" section),
- ambient lighting (refer to the "Visibility" section),
- daytime lights (refer to the "Visibility" section),
- directional headlamps (refer to the "Visibility" section).

Selection of the language

This menu allows you to select the language used by the display: Deutsch, English, Español, Français, Italiano, Nederlands, Portugues, Türkçe*.

Selection of the units

This menu allows you to select the units: temperature (°Celsius or °Fahrenheit) and consumption (l/100 km, mpg or km/l).

* According to country.

Indicator and warning lights

Visual indicators informing the driver that a system is in operation (operation or deactivation indicator lights) or of the occurrence of a fault (warning light).

When the ignition is switched on

The warning lights come on for a few seconds when the vehicle's ignition is switched on.

When the engine is started, these warning lights should switch off.

If they remain on, before moving off, consult the warning light concerned.

Associated warnings

The switching on of certain warning lights may be accompanied by an audible signal and a message on the multifunction display.



The warning lights may come on continuously or flash.

Certain warning lights may come on in two different modes. Only by relating the type of lighting to the operating status of the vehicle can it be ascertained whether the situation is normal or whether a fault has occurred.



Operation indicator lights

If one of the following indicator lights comes on, this confirms that the corresponding system has come into operation.

Common operation indicator lights



Left-hand direction indicator.



Dipped headlamps.



Main beam headlamps.



Handbrake applied.



Right-hand direction indicator.



Front fog lamps.



Rear fog lamp.



Diesel engine pre-heating.

Wait until this goes off before operating the starter.

1 INSTRUMENTS and CONTROLS

Specific operation indicator lights



Foot on brake.

Press the brake pedal to start the engine with the automatic gearbox.

The other indicator lights appear on the large display, located in the centre of the instrument panel.

AUTO



Automatic locking.

If this is displayed, it indicates that you have activated the automatic locking of the doors and boot while driving.

AUTO



Automatic wiping.

If this is displayed, it indicates that you have activated the automatic windscreen wiping.

AUTO



Automatic lighting.

If this is displayed, it indicates that you have activated the automatic switching on of the headlamps.



Speed limiter.

If this is displayed, it indicates that you have activated the speed limiter mode.



If this is displayed, it indicates that you can set the speed limiter speed value to be stored.



Cruise control.

If this is displayed, it indicates that you have activated the cruise control mode.



If this is displayed it indicates that you can set the cruise control speed value to be stored.

Automatic gearbox.



This display indicates the position that you have selected on the gear selection gate (P, R, N or D).



This display indicates the gear engaged in the automatic or manual operation programme.



This display indicates the operating programme selected (automatic, sport, snow or manual).

Deactivation warning lights

If one of the following warning lights comes on, this confirms that the corresponding system has been switched off intentionally.



Common deactivation warning lights



Passenger's air bag system deactivation.

The passenger's air bag system is put into service automatically when the vehicle is started.

A specific control, located on the passenger's side of the fascia, permits deactivation of the system. This is confirmed by continuous lighting of this warning light on the instrument panel or on the seat belt and passenger's front air bag warning lights display.



Dynamic stability control (ESP/ASR) deactivation

The ESP/ASR system is put into service automatically when the vehicle is started.

A specific button, located in the centre of the dashboard, permits deactivation of the system. This is confirmed by continuous lighting of this warning lamp and of the indicator lamp on the button.

From approximately 30 mph (50 km/h), the system is reactivated automatically.

Specific deactivation warning lights



The other warning lights appear on the large display, located in the centre of the instrument panel.



Automatic locking.

If this is displayed, it indicates that you have deactivated the automatic locking of the doors and boot while driving.



Automatic wiping.

If this is displayed, it indicates that you have deactivated the automatic windscreen wiping.



Automatic lighting.

If this is displayed, it indicates that you have deactivated the automatic switching on of the headlamps.



Speed limiter.

If this is displayed, it indicates that you have deactivated the speed limiter.



Cruise control.

If this is displayed, it indicates that you have deactivated the cruise control.

1 INSTRUMENTS and CONTROLS

Warning lights

When the engine is running or the vehicle is moving, the lighting of one of the following warning lights indicates the occurrence of a fault requiring intervention on the part of the driver.



Any fault resulting in the displaying of a warning light must be the subject of further diagnostics by reading the associated message on the multifunction display.

Should you encounter any problems, do not hesitate to contact a PEUGEOT dealer.

Common warning lights



Central alert.

Lighting is associated with the displaying of another warning light:

- punctured wheel,
- braking,
- power steering,
- engine oil pressure,
- coolant temperature,

stop the vehicle immediately and as safely as possible.



Service.

If this comes on, it indicates the occurrence of a problem in one of the systems which does not have a specific warning light.

In order to identify it, consult the message on the multifunction display.

After checking:

- that the doors, boot and bonnet are closed,
- the engine oil level,
- the screenwash fluid level,
- the remote control battery,
- the pressure of the tyres,
- the end of saturation of the particle emission filter (Diesel),

for any other situations, contact a PEUGEOT dealer.



Braking.

If this comes on, it indicates the occurrence of a fault in one of the braking systems:

- significant drop in the level in the circuit,
- electronic brake force distribution (EBFD) faulty (simultaneous lighting of the ABS warning light),

stop the vehicle immediately and as safely as possible.

When the vehicle is moving, check that the handbrake is fully released.



Anti-lock braking system (ABS).

If this comes on, it indicates the occurrence of a fault in the anti-lock braking system.

However, this does not prevent operation of the vehicle's assisted braking.



Dynamic stability control (ESP/ASR).

The ESP/ASR system is put into service automatically when the vehicle is started.

Unless the system has been deactivated, if this warning light and the indicator light on the button come on continuously, this indicates the occurrence of a fault in the ESP/ASR system.



Engine autodiagnosics system.

If this comes on, it indicates the occurrence of a fault in the engine management system.

If it flashes, it indicates the occurrence of a fault in the emission control system.



Low fuel level.

If this comes on, it indicates that you only have enough fuel left to drive approximately 30 miles (50 km).

The capacity of the tank is approximately 60 litres.



Maximum coolant temperature.

If this comes on, it indicates that the temperature in the cooling system is too high. Stop the vehicle immediately and as safely as possible.

Specific warning lights



Engine oil pressure.

If this comes on, it indicates the occurrence of a fault in the engine lubrication circuit. Stop the vehicle immediately and as safely as possible.



Battery charge.

If this comes on, it indicates the occurrence of a fault in the battery charging circuit (dirty or loose terminals, slack or cut alternator belt...).



Door open.

A door, the boot or the bonnet* is open:

- if the speed is below 6 mph (10 km/h), this warning light comes on continuously,
- if the speed is higher than 6 mph (10 km/h), this warning light comes on continuously, accompanied by an audible signal.



Air bags.

If this comes on, it indicates the occurrence of a fault in one of the air bag, roll-over hoop or seat belt pretensioner systems.



Seat belt not fastened/unfastened.

If this comes on, it indicates that the driver and/or the front passenger has not fastened or has unfastened his seat belt.

It also indicates that one or more rear passengers have unfastened their seat belt.



Water in diesel**.

If this comes on, it indicates the presence of water in the diesel filter.

There is a risk of damage to the injection system on Diesel engines.

* Only with alarm.

** According to country.

1 INSTRUMENTS and CONTROLS

Specific warning lights



Directional headlamps.

If this flashes, it indicates the occurrence of a fault in the directional headlamps system.

The other warning lights appear on the large display, located in the centre of the instrument panel.

Depending on the seriousness of the fault, they may be displayed in orange or red.



The displaying of certain warning lights may be accompanied by an audible signal and a message on the multifunction display.



Certain warning lights may be linked with those of the instrument panel.

If they are linked with the **STOP** warning light, stop the vehicle immediately and as safely as possible.



Service.

If this is displayed, it indicates the occurrence of a fault in one of the following:

- the engine management system,
- the emission control system.



Engine autodiagnosics system.

If this is displayed, it indicates the occurrence of a fault in the engine management system.



Battery charge.

If this is displayed, it indicates the occurrence of a fault in the battery charging circuit (dirty or loose terminals, slack or cut alternator belt...).



Engine oil pressure.

If this is displayed, it indicates the occurrence of a fault in the engine lubrication circuit. Stop the vehicle immediately and as safely as possible.



Engine oil level.

If this is displayed, it indicates an insufficient level of oil in the engine. Stop the vehicle immediately and as safely as possible.



Coolant temperature.

If this is displayed, it indicates that the temperature in the cooling system is too high. Stop the vehicle immediately and as safely as possible.

**Coolant level.**

If this is displayed, it indicates an insufficient level of coolant in the circuit. Stop the vehicle immediately and as safely as possible.

**Screenwash fluid level.**

If this is displayed, following an action on the wipers stalk, it indicates an insufficient level of fluid.

Fill the screenwash/headlamp wash fluid reservoir when you stop.

**Fuel level.**

If this is displayed, it indicates that there is only enough fuel remaining to drive approximately 30 miles (50 km).

The capacity of the tank is approximately 60 litres.

**Electronic immobiliser.**

If this is displayed, it indicates the occurrence of a fault in the electronic engine immobiliser system or that the remote control battery is flat.

**Door open.**

A door, the boot or the bonnet* is open:

- if the speed is below 6 mph (10 km/h), this warning light is displayed in orange,
- if the speed is higher than 6 mph (10 km/h), this warning light is displayed in red.

**Air bags.**

If this is displayed, it indicates the occurrence of a fault in one of the air bag, roll-over hoop or pre-tensioning seat belt systems.

**Braking.**

If this is displayed, it indicates the occurrence of a fault in one of the braking systems:

- significant drop in the level in the circuit,
- electronic brake force distribution (EBFD) faulty (simultaneous lighting of the ABS warning light).

Stop the vehicle immediately and as safely as possible.

If the vehicle is moving, check that the handbrake is released fully.

**Handbrake.**

If this is displayed, while the vehicle is moving, it indicates that the handbrake has not been released fully.

**Anti-lock braking system (ABS).**

If this is displayed, it indicates the occurrence of a fault in the anti-lock braking system.

However, this does not prevent operation of the vehicle's assisted braking.

**Dynamic stability control (ESP/ASR).**

The ESP/ASR system is put into service automatically when the vehicle is started.

Unless the system has been deactivated, if this warning light and the indicator light on the button come on, this indicates the occurrence of a fault in the ESP/ASR system.

**Ice warning.**

If this is displayed, it indicates that there is risk of the formation of ice on the road below a temperature of 3 °C.

Drive carefully.

**Power steering.**

If this is displayed, it indicates the occurrence of a fault in the power steering. Stop the vehicle immediately and as safely as possible.

* Only with alarm.

1 INSTRUMENTS and CONTROLS



Automatic gearbox.

If this is displayed, it indicates the occurrence of a fault in the automatic gearbox. The gearbox will then operate in down-grade mode, locked on 3rd gear. It may also be displayed if a door is opened.



Position P or N.

If this is displayed, it indicates that the gear lever must be placed in position **P** or **N** in order to start the engine.



Invalid value.

If this is displayed, it indicates the occurrence of a fault in the programme of the automatic gearbox.



Visual and/or audible parking assistance.

If this comes on, in forward and/or reverse gear, it indicates a fault in the parking assistance system.



Deflated wheel.

If this is displayed, it indicates an insufficient pressure in one or more wheels.

Check the pressure of the tyres as soon as possible.



Punctured wheel.

If this is displayed, it indicates that one or more wheels are punctured. Stop the vehicle immediately and as safely as possible. Change the damaged wheel and have it repaired by a PEUGEOT dealer.



Tyre under-inflation detection.

If this is displayed, it indicates the occurrence of a fault on one of the sensors or in the tyre under-inflation detection system.

It may also indicate the absence of a sensor when the spare wheel, which does not have a sensor, is fitted in place of a punctured wheel.



Automatic switching on of the lights.

If this comes on, it indicates the occurrence of a fault in the automatic switching on of the lights.

Use the other positions of the lights stalk.



Automatic headlamp adjustment.

If this is displayed, it indicates the occurrence of a fault in the automatic headlamp adjustment.



Water in diesel**.

If this is displayed, it indicates the presence of water in the diesel filter.

There is a risk of damage to the injection system on Diesel engines.



Particle emission filter (Diesel).

If this is displayed, linked with the service warning light, it indicates the start of saturation of the particle emission filter or a low diesel additive reservoir level.

As soon as traffic conditions permit, regenerate the filter by driving at a speed of at least 40 mph (60 km/h) until the service warning light is switched off.

If the service warning light is still displayed, the additive level is low. Have it topped up by a PEUGEOT dealer without delay.

** According to country.

Manual Check

System which informs the driver of the warnings present and of the activated or deactivated status of the functions.



☞ With the engine running, to start a manual check, press the **"CHECK/000"** button on the instrument panel.

If no "major" faults have been detected, **"CHECK OK"** appears on the large instrument panel display.

If a "minor" fault has been detected, the warning lights concerned then **"CHECK OK"** appear on the large instrument panel display. Consult a PEUGEOT dealer.

If a "major" fault has been detected, only the warning lights concerned appear on the large instrument panel display. Have it checked by a PEUGEOT dealer.

Coolant temperature indicator

System which informs the driver of the changes in the temperature of the engine coolant while driving.



With the engine running, when the needle is:

- in zone **A**, the temperature is correct,
- in zone **B**, the temperature is too high; the max temperature warning light **1** and the central **STOP** warning light come on, accompanied by an audible signal and a message on the multifunction display.

You MUST stop as soon as it is safe to do so.

Wait a few minutes before switching off the engine.

Consult a PEUGEOT dealer.

After driving for a few minutes, the temperature and pressure in the cooling system increase.

To top up the level:

- ☞ wait for the engine to cool,
- ☞ unscrew the cap by two turns to allow the pressure to drop,
- ☞ when the pressure has dropped, remove the cap,
- ☞ top up the level to the **"MAX"** mark.

1 INSTRUMENTS and CONTROLS

Service indicator

System which informs the driver when the next service is due, in accordance with the manufacturer's servicing schedule.

The point at which the service is due is calculated from the last indicator zero reset. It is determined by two parameters:

- the distance travelled,
- the time elapsed since the last service.



More than 1 800 miles (3 000 km) remain before the next service is due

When the ignition is switched on, no service information appears on the display.

Between 600 miles (1 000 km) and 1 800 miles (3 000 km) remain before the next service is due

For 5 seconds after the ignition is switched on, the spanner symbolising the service operations comes on. The distance recorder display line indicates the distance remaining before the next service is due.

Example: 2 800 km remain before the next service is due.

For 5 seconds after the ignition is switched on, the display indicates:



5 seconds after the ignition is switched on, **the spanner is switched off**; the distance recorder resumes its normal operation. The display then indicates the total and trip distances.



Less than 600 miles (1 000 km) remain before the next service is due

Example: 900 km remain before the next service is due.

For 5 seconds after the ignition is switched on, the display indicates:



5 seconds after the ignition is switched on, the distance recorder resumes its normal operation. **The spanner remains on** to indicate that a service must be carried out soon.



Service overdue

For 5 seconds after the ignition is switched on, the **spanner flashes** to indicate that the service must be carried out as soon as possible.

Example: the service is overdue by 300 miles (km).

For 5 seconds after the ignition is switched on, the display indicates:



5 seconds after the ignition is switched on, the distance recorder resumes its normal operation. **The spanner remains lit.**



The distance remaining may be weighted by the time factor, depending on the driver's driving habits.

Therefore, the spanner may also come on if you have exceeded the two year service interval.

Maintenance indicator zero reset



After each service, the maintenance indicator must be reset to zero.

The procedure for resetting to zero is as follows:

- ☞ switch off the ignition,
- ☞ press and hold the trip distance recorder zero reset button,
- ☞ switch on the ignition; the distance recorder display begins a countdown,
- ☞ when the display indicates "**=0**", release the button; the spanner disappears.



Following this operation, if you wish to disconnect the battery, lock the vehicle and wait at least five minutes for the zero reset to be taken into account.

Retrieving the service information

You can access the service information at any time.

- ☞ Press the trip distance recorder zero reset button.

The service information is displayed for a few seconds, then disappears.

1 INSTRUMENTS and CONTROLS

Engine oil level indicator

System which informs the driver of the validity or invalidity of the engine oil level.



This information is indicated for a few seconds when the ignition is switched on, after the service information.



The level read will only be correct if the vehicle is on level ground and the engine has been off for more than 15 minutes.

Oil level correct



Lack of oil



This is indicated by the flashing of "OIL", linked with the service warning light, accompanied by an audible signal and a message on the multifunction display.

If the lack of oil is confirmed by a check using the dipstick, it is essential that the level is topped up to prevent damage to the engine.

Oil level gauge fault



This is indicated by the flashing of "OIL-". Consult a PEUGEOT dealer.

Dipstick

Refer to the "Checks" section to locate the dipstick and the oil filler cap on your engine.



There are 2 marks on the dipstick:

- **A** = max; never exceed this level (risk of damage to the engine),
- **B** = min; top up the level via the oil filler cap, using the type of oil suited to your engine.

Total distance recorder

System which measures the total distance travelled by the vehicle during its life.



The total and trip distances are displayed for thirty seconds when the ignition is switched off, when the driver's door is opened and when the vehicle is locked or unlocked.

Trip distance recorder

System which measures a distance travelled during a day or other period since it was reset to zero by the driver.



With the ignition on, press the button until zeros appear.

Lighting rheostat

System for manual adjustment of the brightness of the instruments and controls in relation to the exterior brightness.



Activation

When the lights are on:

- ☞ press the button to change the brightness of the instruments and controls,
 - ☞ when the lighting reaches the minimum setting, release the button, then press again to increase it,
- or
- ☞ when the lighting reaches the maximum setting, release the button, then press again to reduce it,
 - ☞ when the lighting reaches the level of brightness required, release the button.

Deactivation

When the lights are off, or in day mode on vehicles fitted with daytime lights, pressing the button does not have any effect.

2 MULTIFUNCTION DISPLAYS

MONOCHROME SCREEN C (WITH PC SOUND)



Displays on the screen

This displays the following information:

- the time,
- the date,
- the outside temperature (this flashes if there is a risk of ice),
- the status of the accesses (doors, boot...),
- the audio sources (radio, CD...),
- the trip computer (refer to the end of the section).

Warning messages (e.g.: "Emission control system faulty") or information messages (e.g.: "Automatic switching on of the headlamps activated") may appear temporarily. These can be cleared by pressing the **"ESC"** button.

Controls



From the control panel of your PC Sound, you can:

- ☞ press the **"MENU"** button to gain access to the **general menu**,
- ☞ press the **"▲"** or **"▼"** buttons to scroll through the items on the screen,
- ☞ press the **"MODE"** button to change the permanent application (trip computer, audio source...),
- ☞ press the **"◀"** or **"▶"** buttons to change a setting value,
- ☞ press the **"OK"** button to confirm,
- or
- ☞ press the **"ESC"** button to abandon the operation in progress.

General menu



- ☞ Press the **"MENU"** button to gain access to the **general menu**:
 - audio functions,
 - vehicle diagnostics,
 - personalisation-configuration,
 - telephone (hands-free kit).
- ☞ Press the **"▲"** or **"▼"** buttons to select the menu required, then confirm by pressing the **"OK"** button.



"Audio functions" menu

With the PC Sound switched on, once this menu has been selected you can activate or deactivate the functions linked with use of the radio (RDS, REG, RadioText) or the CD (introsan, shuffle, CD repeat).

For further details concerning the "Audio functions" application, refer to the PC Sound part of the "Audio and Telematics" section.



"Vehicle diagnostics" menu

Once this menu has been selected, you can consult information concerning the status of the vehicle, such as the warnings log.


Warnings log

This summarises the active warning messages, displaying them in succession on the multifunction display.


- Press the **"MENU"** button to gain access to the general menu.
- Press the arrows, then the **"OK"** button to select the **"Vehicle diagnostics"** menu.



- On the **"Vehicle diagnostics"** menu, select the following application:



"Personalisation-Configuration" menu



Once this menu has been selected, you can gain access to the following functions:

- define the vehicle parameters,
- display configuration,
- selection of the language.

Define the vehicle parameters


Once this menu has been selected, you can activate or deactivate the following equipment:

- selective unlocking (refer to the "Access" section),
- "follow-me-home" and welcome lighting (refer to the "Visibility" section),
- ambient lighting (refer to the "Visibility" section),
- daytime lights (refer to the "Visibility" section).




Example: setting of the duration of the "follow-me-home" lighting


- Press the "▲" or "▼" buttons, then the "OK" button to select the menu required.



- Press the "▲" or "▼" buttons, then the "OK" button to select the "Follow-me-home lighting" line.



- Press the "◀" or "▶" buttons to set the value required (15, 30 or 60 seconds), then press the "OK" button to confirm.



- Press the "▲" or "▼" buttons, then the "OK" button to select the "OK" box and confirm or press the "ESC" button to cancel.

Display configuration

Once this menu has been selected, you can gain access to the following settings:

- brightness-video setting,
- date and time setting,
- selection of the units.

Selection of the language

Once this menu has been selected, you can change the language used by the display (Deutsch, English, Espanol, Français, Italiano, Nederlands, Portugues, Portugues-Brasil, Türkçe*).



"Telephone" menu

With the PC Sound switched on, once this menu has been selected you can configure your Bluetooth hands-free kit (matching), consult the various telephone directories (calls log, services...) and manage your communications (pick up, hang up, call waiting, secret mode...).

For further details concerning the "Telephone" application, refer to the PC Sound part of the "Audio and Telematics" section.



For safety reasons, it is imperative that configuration of the multifunction displays by the driver takes place when stationary.

* According to country.

16/9 RETRACTABLE COLOUR DISPLAY (WITH PC NAV)



Displays on the screen

When the screen is unfolded, it displays the following information automatically and directly:

- the time,
- the date,
- the altitude,
- the exterior temperature (the value displayed flashes if there is a risk of ice),
- the accesses check,
- the warning and vehicle function status messages, displayed temporarily,
- the audio functions,
- the trip computer information,
- the satellite navigation system information.

Controls



From the PC Nav control panel, to select one of the applications:

- ☞ press the dedicated **"RADIO"**, **"MUSIC"**, **"NAV"**, **"TRAFFIC"**, **"SETUP"** or **"PHONE"** button to gain access to the corresponding menu,
 - ☞ turn the navigator to move the selection,
 - ☞ press the navigator to confirm the selection,
- or
- ☞ press the **"ESC"** button to abandon the current operation and return to the previous display.

For further details concerning these applications, refer to the PC Nav part of the "Audio and Telematics" section.

i For operation of the retractable display (opening, closing, adjustment of the position, etc.), refer to the paragraph "Access to the retractable display".

"SETUP" menu



Press the **"SETUP"** button to gain access to the **"SETUP"** menu. This allows you to select from the following functions:

- "Languages",
- "Date and time",
- "Display",
- "Vehicle parameters",
- "Units",
- "System parameters".

Languages

This menu allows you to select the language used by the display: Deutsch, English, Español, Français, Italiano, Nederlands, Polski, Portugues, Türkçe*.

Date and time

This menu allows you to set the date and time, the format of the date and the format of the time (refer to the PC Nav part of the "Audio and Telematics" section).

Display

This menu allows you to set the brightness of the screen, the screen colour scheme and the colour of the map (day/night or auto mode).

Vehicle parameters

This menu allows you to activate or deactivate certain driving and comfort equipment:

- selective unlocking (refer to the "Accesses" section),
- follow-me-home and welcome lighting (refer to the "Visibility" section),
- ambient lighting (refer to the "Visibility" section),
- daytime lights (refer to the "Visibility" section),
- directional headlamps (refer to the "Visibility" section).

Units

This menu allows you to select the units: temperature (°C or °F) and consumption (km/l, l/100 or mpg).

System parameters

This menu allows you to restore the factory configuration, display the software version and activate the scrolling text.



For safety reasons, it is imperative that configuration of the multifunction displays by the driver is carried out when stationary.

* According to country.

16/9 HIGH DEFINITION RETRACTABLE COLOUR DISPLAY (WITH PC COM 3D)



Displays on the screen

When the screen is unfolded, it displays the following information automatically and directly:

- the time,
- the date,
- the altitude,
- the exterior temperature (the value displayed flashes if there is a risk of ice),
- the accesses check,
- the warning and vehicle function status messages, displayed temporarily,
- the audio functions,
- the telephone and address book information,
- the satellite navigation system information.

Controls



From the PC Com 3D control panel, to select one of the applications:

- ☞ press the dedicated **"RADIO"**, **"MEDIA"**, **"NAV"**, **"TRAFFIC"**, **"ADDR BOOK"** or **"SETUP"** button to gain access to the corresponding menu,
 - ☞ turn the navigator to move the selection,
 - ☞ press the navigator to confirm the selection,
- or
- ☞ press the **"ESC"** button to abandon the current operation and return to the previous display.

For further details concerning these applications, refer to the PC Com 3D part of the "Audio and Telematics" section.

i For operation of the retractable display (opening, closing, adjustment of the position, etc.), refer to the paragraph "Access to the retractable display".

"SETUP" menu



Press the **"SETUP"** button to gain access to the **"SETUP"** menu. This allows you to select from the following functions:

- "Languages and voice functions",
- "Date and time",
- "Display",
- "Units",
- "System parameters".

Languages and voice functions

This menu allows you to:

- select the language used by the display (Deutsch, English, Espanol, Français, Italiano, Nederlands, Polski, Portugues, Türkçe*),
- select the voice recognition parameters (activation/deactivation, advice on use, personal voice programming, etc.),
- set the volume of the voice synthesiser.

Date and time

This menu allows you to set the date and time, the format of the date and the format of the time (refer to the PC Com 3D part of the "Audio and Telematics" section).



For safety reasons, it is imperative that configuration of the multifunction displays by the driver is carried out when stationary.

Display

This menu allows you to set the brightness of the screen, the screen colour scheme and the colour of the map (day/night or auto mode).

Units


This menu allows you to select the units: temperature (°C or °F) and distance (km or miles).

System parameters

This menu allows you to restore the factory configuration, display the software version and activate the scrolling text.

* According to country.

Access to the retractable screen



This screen is opened and stored automatically.

However, you can also open it, store it and adjust it using the various manual controls:

- opening or storing by means of control **A**,
- angle adjustments by means of control **B**.

It is also fitted with safety auto-reverse protection.

Opening the screen

☞ With the screen stored, press control **A** to open it.

The screen opens automatically when the ignition is switched on, when the audio and telematics system is switched on, when an outgoing telephone call is made, when a voice command is given and when a warning message linked with the STOP warning light is received.



If you close the screen during operation of the audio and telematics system, it will only re-open automatically when an outgoing telephone call is made, when a voice command is given or when a warning message linked with the STOP warning light is received.

Closing the screen

☞ With the screen open, press control **A** to store it.

The screen is stored automatically when the ignition is switched off, after approximately three seconds, if the audio and telematics system is off.

Safety auto-reverse


If the screen meets an obstacle as it opens or closes, the movement stops immediately and is reversed by a few millimetres.

After clearing the obstacle, issue the command required again.



If you wish the screen to open or close automatically when the audio and telematics system is switched on or off, the screen must not be closed when the audio and telematics system is operating.

Adjusting the position of the screen



When the screen is open, you can adjust it precisely in different ways:

☞ press the corresponding part of control **B** to move the screen towards you or towards the windscreen,

or

☞ push or pull the screen gently by hand.

Storing the position of the screen

The system has four pre-set positions in its memory.

Each time the screen is closed, the system stores the last position of the screen.

Each time the screen is re-opened, the system returns the screen to the pre-set position closest to that stored.

2 MULTIFUNCTION DISPLAYS

TRIP COMPUTER

System which provides current information concerning the route travelled (range, consumption...).

Monochrome screen C



Instrument panel large display



Instrument panel PC Com 3D 16/9 large display



Depending on your vehicle's equipment, the trip computer information appears on the multifunction screen or on the large display on the instrument panel.

Data displays

With the monochrome screen C or the instrument panel large display



Press the button, located at the end of the **wipers stalk**, to display the various trip computer tabs in succession.

With the instrument panel PC Com 3D 16/9 large display



Press the up and down arrows on the navigator, associated with the PC Com 3D, to display the various trip computer tabs in succession.



- The current information tab with:
 - the range,
 - the current consumption,
 - the distance remaining to be travelled.



- The route "1" tab with:
 - the distance travelled,
 - the average consumption,
 - the average speed, for the first route.



- The route "2" tab with:
 - the distance travelled,
 - the average consumption,
 - the average speed, for the second route.

Pressing the button again takes you to a black screen. A further press returns you to the normal display.

Route zero reset

With the monochrome screen C or the instrument panel large display



When the route required is displayed, press the control for more than two seconds.

With the instrument panel PC Com 3D 16/9 large display



When the required route is displayed, press the "OK" button on the navigator, associated with the PC Com 3D.

Routes "1" and "2" are independent but their use is identical.

Route "1" permits, for example, daily calculations, and route "2" monthly calculations.

A few definitions...



Range

(km or miles)

This indicates the distance which can still be travelled with the fuel remaining in the tank in relation to the average consumption over the last few miles (kilometres) travelled.



This figure may vary following a change in the style of driving or the relief, resulting in a significant change in the current consumption.

When the range falls below 20 miles (30 km), dashes are displayed. After filling with at least 5 litres of fuel, the range is recalculated and is displayed when it exceeds 60 miles (100 km).



If dashes are displayed continuously while driving in place of the digits, contact a PEUGEOT dealer.



Current consumption

(l/100 km or km/l or mpg)

This is the average quantity of fuel consumed during the last few seconds.



This function is only displayed from 20 mph (30 km/h).



Average consumption

(l/100 km or km/l or mpg)

This is the average quantity of fuel consumed since the last trip computer zero reset.



Distance travelled

(km or miles)

This indicates the distance travelled since the last trip computer zero reset.



Average speed

(km/h or mph)

This is the average speed calculated since the last trip computer zero reset (ignition on).



Distance remaining to destination

(km or miles)

This is the distance remaining to be travelled to the final destination. It is either calculated instantly by the navigation system, if guidance is activated, or entered by the user.

If the distance is not entered, dashes are displayed in place of the digits.



VENTILATION

System which creates and maintains comfortable conditions in the vehicle's passenger compartment.

Air intake

The air circulating in the passenger compartment is filtered and originates either from the outside via the grille located at the base of the windscreen or from the inside in air recirculation mode.

Air treatment

The incoming air follows various routes depending on the controls selected by the driver:

- direct arrival in the passenger compartment (air intake),
- passage through a heating circuit (heating),
- passage through a cooling circuit (air conditioning).

The temperature control enables you to obtain the level of comfort required by mixing the air of the various circuits.

The air distribution control enables you to diffuse the air in the passenger compartment combining several air vents.

The air flow control enables you to increase or reduce the speed of the ventilation blower.

Control panel

The controls of this system are grouped together on control panel **A** on the centre console. Depending on the model, the functions offered are:

- the level of comfort required,
- the air flow,
- the air distribution,
- the de-icing and demisting,
- the manual or automatic air conditioning controls.

Air diffusion

1. Windscreen de-icing or demisting vents.
2. Front side window de-icing or demisting vents.
3. Side adjustable and closing vents.
4. Central adjustable and closing vents.
5. Air outlets to the front footwells.
6. Adjustable and closing vents for the rear passengers.
7. Air outlets to the rear footwells.



RECOMMENDATIONS FOR VENTILATION AND AIR CONDITIONING

In order for these systems to be fully effective, follow the operation and maintenance rules below:

- ☞ If the interior temperature remains very high after the vehicle has been parked in the sun for a considerable time, do not hesitate to ventilate the passenger compartment for a few minutes.
Place the air flow control at a sufficient level to provide an adequate renewal of air in the passenger compartment.
- ☞ To obtain an even air distribution, take care not to obstruct the exterior air intake grilles located at the base of the windscreen, the nozzles, the vents and the air outlets, as well as the air extractor located in the boot.
- ☞ Do not cover the sunshine sensor, located on the fascia; this is used for regulation of the air conditioning system.
- ☞ Operate the air conditioning system for 5 to 10 minutes, once or twice a month to keep it in perfect working order.
- ☞ Ensure that the passenger compartment filter is in good condition and have the filter elements replaced regularly (refer to the "Checks" section).
- ☞ We recommend the use of a combined passenger compartment filter. Thanks to its second special active filter, it contributes to the purification of the air breathed by the occupants and the cleanness of the passenger compartment (reduction of allergic symptoms, bad odours and greasy deposits).
- ☞ To guarantee correct operation of the air conditioning system, you are also advised to have it checked regularly.
- ☞ If the system does not produce cold air, do not use it and contact a PEUGEOT dealer.

In the "cabriolet" configuration, installing the windstop and using the "AIRWAVE" systems improves comfort.

When towing the maximum load on a steep gradient in high temperatures, switching off the air conditioning permits the recovery of engine power and therefore improvement of the towing capacity.

The condensation created by the air conditioning results in a discharge of water under the vehicle which is perfectly normal.



The air conditioning system does not contain chlorine and does not present any danger to the ozone layer.

MANUAL AIR CONDITIONING



The air conditioning can only operate with the engine running.

1. Temperature adjustment



- Turn the dial from blue (cold) to red (hot) to adjust the temperature to your requirements.

2. Air flow adjustment



- Turn the dial from position 1 to position 5 to obtain a comfortable air flow.



If you place the air flow control in position 0 (deactivation of the system), the temperature is no longer maintained at a comfortable level. However, a slight flow of air, due to the movement of the vehicle, can still be felt.

3. Air distribution adjustment



Windscreen and side windows.



Windscreen, side windows and footwells.



Footwells.
(vents closed)



Central and side vents.



The air distribution can be adapted by placing the dial in an intermediate position.

4. Air intake/Air recirculation

The intake of exterior air prevents misting of the windscreen and side windows.

The recirculation of interior air insulates the passenger compartment from exterior odours and smoke.

Return to exterior air intake as soon as possible to prevent deterioration of the air quality and avoid misting.



- Press the button to recirculate the interior air. The indicator light comes on to confirm this.

Press the button again to permit the intake of exterior air. The indicator light switches off to confirm this.

De-icing - Demisting

The symbols on the control panel indicate the position of the controls for rapid de-icing or demisting of the windscreen and side windows:

- ☞ place the air intake control **4** in the "Exterior air intake" position (indicator light off),
- ☞ place the air distribution dial **3** in the "Windscreen position",
- ☞ place the air flow dial **2** in position 5 (maximum),
- ☞ place the temperature dial **1** in the red position (hot),
- ☞ close the central vents,
- ☞ switch on the air conditioning by pressing the "**A/C**" button.

5. Air conditioning On/Off



The air conditioning is designed to operate effectively in all seasons, with the windows closed.

It enables you to:

- lower the temperature, in summer,
- increase the effectiveness of the de-misting in winter, above 0 °C.

Switching on

- ☞ Press the "**A/C**" button, the associated indicator light comes on.

The air conditioning does not operate when the air flow adjustment control 2 is in position "0".

Switching off

- ☞ Press the "**A/C**" button again, the associated indicator light switches off.

REAR SCREEN DE-ICING



The control button is located on the heating or air conditioning system control panel.

Switching on

The rear screen de-icing can only operate when the engine is running.

- ☞ Press this button to de-ice the rear screen and the exterior mirrors. The indicator light associated with the button comes on.

Switching off

The de-icing switches off automatically to prevent an excessive consumption of current.

- ☞ It is possible to stop the de-icing operation before it is switched off automatically by pressing the button again. The indicator light associated with the button switches off.



If the engine is switched off before the de-icing is switched off automatically, de-icing will resume next time the engine is switched on.

The de-icing is deactivated when the retractable roof is stored in the boot.



- ☞ Switch off the de-icing of the rear screen and exterior mirrors as soon as you consider this necessary as lower current consumption results in reduced fuel consumption.

De-icing - Demisting

The symbols on the control panel indicate the position of the controls for rapid de-icing or demisting of the windscreen and side windows:

- ☞ place the air intake control **4** in the "Exterior air intake" position (indicator light off),
- ☞ place the air distribution dial **3** in the "Windscreen position",
- ☞ place the air flow dial **2** in position 5 (maximum),
- ☞ place the temperature dial **1** in the red position (hot),
- ☞ close the central vents,
- ☞ switch on the air conditioning by pressing the "**A/C**" button.

5. Air conditioning On/Off



The air conditioning is designed to operate effectively in all seasons, with the windows closed.

It enables you to:

- lower the temperature, in summer,
- increase the effectiveness of the de-misting in winter, above 0 °C.

Switching on

- ☞ Press the "**A/C**" button, the associated indicator light comes on.

The air conditioning does not operate when the air flow adjustment control 2 is in position "0".

Switching off

- ☞ Press the "**A/C**" button again, the associated indicator light switches off.

REAR SCREEN DE-ICING



The control button is located on the heating or air conditioning system control panel.

Switching on

The rear screen de-icing can only operate when the engine is running.

- ☞ Press this button to de-ice the rear screen and the exterior mirrors. The indicator light associated with the button comes on.

Switching off

The de-icing switches off automatically to prevent an excessive consumption of current.

- ☞ It is possible to stop the de-icing operation before it is switched off automatically by pressing the button again. The indicator light associated with the button switches off.



If the engine is switched off before the de-icing is switched off automatically, de-icing will resume next time the engine is switched on.

The de-icing is deactivated when the retractable roof is stored in the boot.



- ☞ Switch off the de-icing of the rear screen and exterior mirrors as soon as you consider this necessary as lower current consumption results in reduced fuel consumption.

DUAL ZONE AUTOMATIC AIR CONDITIONING



The air conditioning only operates when the engine is running.

Automatic operation

1. Automatic comfort programme



- ☞ Press the **"AUTO"** button. The indicator light on the button comes on.

We recommend the use of this mode: it permits automatic and optimised adjustment of all of the functions, passenger compartment temperature, air flow, air distribution and air recirculation, in accordance with the comfort value that you have chosen.

This system is designed to operate effectively in all seasons, with automatic adaptation in the "cabriolet" configuration.



When the engine is cold, to prevent too great a distribution of cold air, the air flow will reach its optimum level gradually.

In cold weather, it favours the distribution of warm air to the windscreen, side windows and footwells only.

2. Driver's side adjustment

3. Passenger side adjustment



The driver and his front passenger can each adjust the temperature to their requirements.

The value indicated on the display corresponds to a level of comfort and not to a temperature in degrees Celsius or Fahrenheit.

- ☞ Turn control **2** or **3** to the left or to the right respectively to decrease or increase this value.

A setting around the value 21 provides optimum comfort. However, depending on your requirements, a setting between 18 and 24 is normal.

You are advised to avoid a left/right setting difference of more than 3.



On entering the vehicle, if the interior temperature is much colder or warmer than the comfort value, there is no need to change the value displayed in order to obtain the comfort required. The system corrects the difference in temperature automatically and as quickly as possible.

4. Automatic visibility programme



The automatic comfort programme may not be sufficient to quickly demist or de-ice the windscreen and side windows (humidity, several passengers, ice, etc.).

- ☞ In this case, select the automatic visibility programme.

The system automatically controls the air conditioning, the air flow and the air intake and provides optimum distribution of the ventilation to the windscreen and side windows.

- ☞ To switch it off, press the **"visibility"** button again or press the **"AUTO"** button, the indicator light on the button switches off and the indicator light on the **"AUTO"** button comes on.

Manual operation

If you wish, you can make a different choice from that offered by the system by changing a setting. The other functions will still be controlled automatically.

- Pressing the **"AUTO"** button returns the system to completely automatic operation.



For maximum cooling or heating of the passenger compartment, it is possible to exceed the minimum value 14 or the maximum value 28.

- Turn control **2** or **3** to the left until **"LO"** is displayed or to the right until **"HI"** is displayed.

5. Air conditioning On/Off



- Press this button to switch off the air conditioning.

Switching the system off could result in discomfort (humidity, condensation).

- Press this button again to return to automatic operation of the air conditioning. The indicator light on the **"A/C"** button comes on.

6. Air distribution adjustment



- Press one or more buttons to direct the air flow towards:

- the windscreen and side windows (de-icing or demisting),
- the windscreen, the side windows and the vents,
- the windscreen, the side windows, the vents and the footwells,
- the vents and the footwells,
- the vents,
- the footwells,
- the windscreen, the side windows and the footwells.

7. Air flow adjustment



- Turn this control to the left to decrease the air flow or to the right to increase the air flow.

The air flow indicator lights, between the two fans, come on progressively in relation to the value requested.

8. Air intake/Air recirculation



- Press this button for recirculation of the interior air. The indicator light on the button comes on.

Air recirculation enables the passenger compartment to be isolated from exterior odours and smoke.

- As soon as possible, press this button again to permit the intake of outside air and prevent condensation. The indicator light on the button switches off.



Avoid prolonged recirculation of interior air (risk of condensation and deterioration of the air quality).

9. Mono zone/Dual zone



- Press this button to equalise the comfort value on the passenger side with that on the driver's side (mono zone). The indicator light on the button comes on.

Switching the system off

- Turn the air flow control to the left until all of the indicator lights switch off.

This action switches off all of the functions of the system.

Temperature related comfort is no longer guaranteed but a slight flow of air, due to the movement of the vehicle, can still be felt.

- Turn the air flow dial to the right or press the **"AUTO"** button to reactivate the system with the values set before it was switched off.



Avoid driving for prolonged periods with the system off.

FITTING/REMOVING THE WINDSTOP

In the "cabriolet" configuration, the windstop improves comfort in the passenger compartment.

The vertical part of the windstop can be folded down to improve rear visibility during manoeuvres.

It is supplied folded in four.

Windstop folded




Windstop unfolded



Fitting

- ☞ Unfold each of the two parts fully.




- ☞ Clip the ends of the assembly until a click is heard.
- ☞ Unfold the windstop by opening the two parts to 90° until a click is heard.



- ☞ Unfold the windstop frame guides.
- ☞ Engage the guides in the points located behind each corner of the back of the rear bench seat.



- ☞ Engage the shafts of the windstop frame in the openings in the rear side trim so that the red indicators are concealed.



When installing the windstop for the first time:

- ☞ position a size 10 open-ended spanner on the hexagonal part of the shaft,
- ☞ tighten or slacken without forcing on each side to adjust the depth setting.
- ☞ Lastly, always check that the windstop is retained securely before use in the "cabriolet" configuration.



Removal

- ☞ Press and pull on the shaft supports to release the shafts from the openings in the rear side trim; the red indicators then become visible.



It is not necessary to remove the windstop when operating the roof.


- ☞ Pull the windstop forwards to release the guides from the points, located behind each corner of the back of the rear bench seat.
- ☞ Fold the windstop frame guides.



- ☞ Fold the windstop closing the two large parts on themselves.
- ☞ Unclip each end individually.



- ☞ Fold each of the two parts on themselves.



Storing



In the storage box (version equipped with a temporary tyre repair kit)

- ☞ Raise the boot carpet and hook its handle on the boot seal.
- ☞ Store the folded windstop in the corresponding recess in the box.
- ☞ Lower the boot carpet.

In the boot (version equipped with a spare wheel)

- ☞ Stow the folded windstop securing it using the luggage retaining net.

FRONT SEATS

Seat consisting of a seat cushion and a seat back which can be adjusted to adapt your position for ease of driving and comfort.

Manual adjustments

Forwards-backwards adjustment

- ☞ Raise the control and slide the seat forwards or backwards.



Driver's or passenger's seat height adjustment

- ☞ Pull the control upwards to raise or push it downwards to lower, as many times as necessary, to obtain the position required.



Seat back angle adjustment

- ☞ Push the control rearwards.



FRONT SEATS

Seat consisting of a seat cushion and a seat back which can be adjusted to adapt your position for ease of driving and comfort.

Electric adjustments


Forwards-backwards adjustment

- ☞ Push the control forwards or rearwards to slide the seat.



Seat cushion height and angle adjustment

- ☞ Tilt the rear part of the control upwards or downwards to obtain the required height.
- ☞ Tilt the front part of the control upwards or downwards to obtain the required angle.



The electrical functions of the seat are deactivated approximately one minute after the ignition is switched off. To reactivate them, switch on the ignition.

Seat back angle adjustment

- ☞ Tilt the control forwards or rearwards to adjust the angle of the seat back.




Additional manual adjustments

Access to the rear seats

- ☞ Pull the control upwards to fold the seat back, then move the seat forward.

When putting the seat back in place, move it back holding it by the centre of the seat back, the seat returns to its initial position.



! No person or object should prevent the seat slide from returning to its initial position; the return to this position is necessary for longitudinal locking.

Additional electric adjustments

Access to the rear seats

- ☞ Pull the control **A** upwards to fold the seat back, the seat moves forward automatically.

When putting the seat back in place, press the control **B** until the seat returns to its initial position.



i This function is deactivated while driving.

Controlling the "AIRWAVE" system

When the engine is running, the "AIRWAVE" system, located in the head restraint of each front seat, can be controlled separately to produce heated blown air directed towards the neck of each occupant.



Use the corresponding adjustment dial, placed on the centre console, to set the temperature and flow of blown air required:

- 0:** Off.
- 1:** Low.
- 2:** Medium.
- 3:** High.

i The blown air arrives after a few seconds to avoid a sudden change between the exterior temperature and the temperature required.



Use the direction dial, placed on each vent, to direct the output of the blown air upwards, to the centre or downwards.



Do not use the "AIRWAVE" system if a child seat is installed on the front passenger seat.

Heated seats control

With the engine running, the front seats can be heated separately.

Use the adjustment dial, placed on the side of each front seat, to switch on and select the level of heating required:

- 0:** Off.
- 1:** Low.
- 2:** Medium.
- 3:** High.



Storing driving positions

System which takes into account the electrical settings of the driver's seat and exterior mirrors. It enables you to store up to two positions using the buttons on the side of the driver's seat and two further driving positions using the two remote control keys.



Storing a position

Using buttons M/1/2

- ☞ Switch on the ignition.
- ☞ Adjust your seat and your exterior mirrors.
- ☞ Press button **M**, then press button **1** or **2** within four seconds.

An audible signal is heard indicating that the storing has been taken into account.

Using the remote control keys

When the vehicle is locked, the remote control key stores the position of the driver's seat and exterior mirrors. Each remote control key can store one specific setting.

- i** Storing a new position cancels the previous position.

Recalling a stored position

Using buttons M/1/2

- ☞ Press and hold button **1** or **2** until the audible signal is heard indicating the end of the adjustment.

- !** When the ignition is off, after a few consecutive position recalls, the function will be deactivated until the engine is started, to prevent discharging of the battery.

Using the remote control keys

When the vehicle is unlocked, the driver's seat and the exterior mirrors return to the position stored by the remote control key.

REAR SEATS

Fixed two-seat bench fitted with roll-over bars to guarantee your protection should the vehicle roll over.



The rear head restraints are fixed and cannot be adjusted. They incorporate the roll-over hoops (refer to the section "Safety - § Roll-over hoops").

The rear bench seat may be fitted with a retractable comfort armrest in the centre of the seat back.

- !** Do not place any covering on the rear head restraints. Use a special cover recommended by the PEUGEOT network.

Storing driving positions

System which takes into account the electrical settings of the driver's seat and exterior mirrors. It enables you to store up to two positions using the buttons on the side of the driver's seat and two further driving positions using the two remote control keys.



Storing a position

Using buttons M/1/2

- ☞ Switch on the ignition.
- ☞ Adjust your seat and your exterior mirrors.
- ☞ Press button **M**, then press button **1** or **2** within four seconds.

An audible signal is heard indicating that the storing has been taken into account.

Using the remote control keys

When the vehicle is locked, the remote control key stores the position of the driver's seat and exterior mirrors. Each remote control key can store one specific setting.

- i** Storing a new position cancels the previous position.

Recalling a stored position

Using buttons M/1/2

- ☞ Press and hold button **1** or **2** until the audible signal is heard indicating the end of the adjustment.

- !** When the ignition is off, after a few consecutive position recalls, the function will be deactivated until the engine is started, to prevent discharging of the battery.

Using the remote control keys

When the vehicle is unlocked, the driver's seat and the exterior mirrors return to the position stored by the remote control key.

REAR SEATS

Fixed two-seat bench fitted with roll-over bars to guarantee your protection should the vehicle roll over.



The rear head restraints are fixed and cannot be adjusted. They incorporate the roll-over hoops (refer to the section "Safety - § Roll-over hoops").

The rear bench seat may be fitted with a retractable comfort armrest in the centre of the seat back.

- !** Do not place any covering on the rear head restraints. Use a special cover recommended by the PEUGEOT network.

MIRRORS



Exterior mirrors

Each fitted with an adjustable mirror permitting the lateral rearward vision necessary for overtaking or parking. They can also be folded for parking in confined spaces.

Adjustment



- ☞ Move control **A** to the right or to the left to select the corresponding mirror.
- ☞ Move control **B** in all four directions to adjust.
- ☞ Return control **A** to the central position.



The objects observed are, in reality, closer than they appear.

Take this into account in order to correctly judge the distance of vehicles approaching from behind.

Folding

- ☞ from outside: lock the vehicle using the remote control or the key.
- ☞ from inside: with the ignition on, pull control **A** rearwards.



If the mirrors are folded using control **A**, they will not unfold when the vehicle is unlocked. Pull again on control **A**.

Unfolding

- ☞ from outside: unlock the vehicle using the remote control or the key.
- ☞ from inside: with the ignition on, pull control **A** rearwards.



The folding and unfolding of the exterior mirrors using the remote control can be deactivated by a PEUGEOT dealer.

Automatic tilting in reverse gear

System which provides a view of the ground during parking manoeuvres in reverse gear.



Programming

- ☞ With the engine running, engage reverse gear.
- ☞ Select and adjust the left-hand and right-hand mirrors in succession.

The adjustment is stored immediately.

Switching on

- ☞ With the engine running, engage reverse gear.
- ☞ Move control **A** to the right or to the left to select the corresponding mirror.

The glass of the mirror selected tilts downwards, in accordance with its programming.

Switching off

- ☞ Exit reverse gear and wait ten seconds.
 - or
 - ☞ Return control **A** to the central position.
- The mirror glass returns to its initial position.
The mirror glass also returns to its initial position:
- if the speed exceeds 6 mph (10 km/h),
 - if the engine is switched off.

Interior mirror

Adjustable mirror providing a central rearward view.

Manual model

The mirror is fitted with a night-time anti-dazzle device.



Adjustment

- ☞ Adjust the mirror so that the glass is directed correctly in the "day" position.

Day/night position

- ☞ Pull the lever to change to the "night" anti-dazzle position.
- ☞ Push the lever to change to the normal "day" position.



As a safety precaution, the mirrors must be adjusted to reduce the "blind spot".

Automatic tilting in reverse gear

System which provides a view of the ground during parking manoeuvres in reverse gear.



Programming

- ☞ With the engine running, engage reverse gear.
- ☞ Select and adjust the left-hand and right-hand mirrors in succession.

The adjustment is stored immediately.

Switching on

- ☞ With the engine running, engage reverse gear.
- ☞ Move control **A** to the right or to the left to select the corresponding mirror.

The glass of the mirror selected tilts downwards, in accordance with its programming.

Switching off

- ☞ Exit reverse gear and wait ten seconds.
 - or
 - ☞ Return control **A** to the central position.
- The mirror glass returns to its initial position.
The mirror glass also returns to its initial position:
- if the speed exceeds 6 mph (10 km/h),
 - if the engine is switched off.

Interior mirror

Adjustable mirror providing a central rearward view.

Manual model

The mirror is fitted with a night-time anti-dazzle device.



Adjustment

- ☞ Adjust the mirror so that the glass is directed correctly in the "day" position.

Day/night position

- ☞ Pull the lever to change to the "night" anti-dazzle position.
- ☞ Push the lever to change to the normal "day" position.



As a safety precaution, the mirrors must be adjusted to reduce the "blind spot".

Automatic day/night model

System which automatically and progressively changes between day and night use.



In order to prevent dazzle, the interior mirror glass darkens automatically depending on the intensity of the light from the rear.

It lightens when the light (light beam of following vehicles, sun...) decreases, so guaranteeing optimum visibility.

Switching on

☞ Switch on the ignition and press switch **1**.

The indicator lamp **2** comes on and the mirror operates automatically.

Switching off

☞ Press switch **1**.

The indicator lamp **2** switches off and the mirror remains in its lightest state.



In order to guarantee optimum visibility when manoeuvring the vehicle, the mirror lightens automatically when reverse gear is engaged.

STEERING WHEEL ADJUSTMENT

The height and depth of the steering wheel can be adjusted to adapt the driving position to the size of the driver.



Adjustment

- ☞ **When stationary**, pull the control to unlock the steering wheel.
- ☞ Adjust the height and depth.
- ☞ Push the control to lock the steering wheel.



As a safety precaution, it is imperative that these operations are carried out while the vehicle is stationary.

Automatic day/night model

System which automatically and progressively changes between day and night use.



In order to prevent dazzle, the interior mirror glass darkens automatically depending on the intensity of the light from the rear.

It lightens when the light (light beam of following vehicles, sun...) decreases, so guaranteeing optimum visibility.

Switching on

☞ Switch on the ignition and press switch **1**.

The indicator lamp **2** comes on and the mirror operates automatically.

Switching off

☞ Press switch **1**.

The indicator lamp **2** switches off and the mirror remains in its lightest state.



In order to guarantee optimum visibility when manoeuvring the vehicle, the mirror lightens automatically when reverse gear is engaged.

STEERING WHEEL ADJUSTMENT

The height and depth of the steering wheel can be adjusted to adapt the driving position to the size of the driver.



Adjustment

- ☞ **When stationary**, pull the control to unlock the steering wheel.
- ☞ Adjust the height and depth.
- ☞ Push the control to lock the steering wheel.



As a safety precaution, it is imperative that these operations are carried out while the vehicle is stationary.

REMOTE CONTROL KEY

System which permits central unlocking and locking of the vehicle using the lock or from a distance, as well as of the interior storage compartments (glove box and front armrest). It is also used to locate and start the vehicle, as well as providing protection against theft.



Unlocking the vehicle

Unfolding the key

- ☞ First press button **A** to unfold the key.

Complete unlocking using the remote control



- ☞ Press the open padlock to unlock the vehicle.

Complete unlocking using the key

- ☞ Turn the key to the left in the driver's door lock to unlock the vehicle.

Unlocking is confirmed by rapid flashing of the direction indicators for approximately two seconds.

The central unlocking also unlocks the glove box and the front armrest compartment.

According to version, the exterior mirrors unfold at the same time.

Selective unlocking using the remote control



- ☞ Press the open padlock once to unlock the driver's door only.
- ☞ Press the open padlock again to unlock the passenger's door and the boot.

Selective unlocking using the key

- ☞ Turn the key to the left in the driver's door lock once to unlock the driver's door only.
- ☞ Turn the key to the left in the driver's door lock again to unlock the passenger's door and the boot.

Each unlocking is confirmed by rapid flashing of the direction indicators for approximately two seconds.

According to version, the exterior mirrors unfold at the same time as the first unlocking action.



The complete or selective unlocking parameter is set via the multifunction display configuration menu.

Complete unlocking is activated by default.

Unlocking and partial opening of the boot



- ☞ Press this button for more than two seconds to unlock the boot. The boot opens slightly.

This action unlocks the vehicle first.

Locking the vehicle

Normal locking using the remote control



- ☞ Press the closed padlock to lock the vehicle completely.

Normal locking using the key

- ☞ Turn the key to the right in the driver's door lock to lock the vehicle completely.

Locking is confirmed by fixed lighting of the direction indicators for approximately two seconds.

The central locking also locks the glove box and the front armrest compartment.

According to version, the exterior mirrors fold at the same time.



If one of the doors or the boot is still open, the central locking does not take place.

After unlocking the vehicle, if none of the accesses - door or boot - are opened within thirty seconds, the vehicle will re-lock automatically.



The folding and unfolding of the exterior mirrors using the remote control can be deactivated by a PEUGEOT dealer.

Deadlocking using the remote control



- ☞ Press the closed padlock to lock the vehicle completely.
- ☞ Press the closed padlock again within five seconds to deadlock the vehicle.

Deadlocking using the key

- ☞ Turn the key to the right in the driver's door lock to lock the vehicle completely.
- ☞ Turn the key to the right again within five seconds to deadlock the vehicle.

Deadlocking is confirmed by fixed lighting of the direction indicators for approximately two seconds.

According to version, the exterior mirrors fold at the same time.



Deadlocking renders the exterior and interior door controls inoperative.

It also deactivates the manual central control button.

Therefore, never leave anyone inside the vehicle when it is deadlocked.



Folding the key

☞ First press button **A** to fold the key.

Locating your vehicle



☞ Press the closed padlock to locate your locked vehicle in a car park.

This is indicated by lighting of the courtesy lights, the lateral spotlights and the dipped headlamps and flashing of the direction indicators for a few seconds.

Anti-theft protection

Electronic engine immobiliser

The key contains an electronic chip which has a special code. When the ignition is switched on, this code must be recognised in order for starting to be possible.

This electronic engine immobiliser locks the engine management system a few minutes after the ignition is switched off and prevents starting of the engine by anyone who does not have the key.



In the event of a malfunction, you are informed by lighting of this warning lamp, an audible signal and a message on the multifunction screen.

In this case, your vehicle does not start; contact a PEUGEOT dealer as soon as possible.

**Lost keys**

Visit a PEUGEOT dealer with the vehicle's V5 registration document and your personal identification documents.

The PEUGEOT dealer will be able to retrieve the key code and the transponder code required to order a replacement key.

Remote control

The high frequency remote control is a sensitive system; do not operate it while it is in your pocket as there is a possibility that it may unlock the vehicle, without you being aware of it.

Do not repeatedly press the buttons of your remote control out of range and out of sight of your vehicle. You run the risk of stopping it from working and the remote control would have to be reinitialised.

The remote control does not operate when the key is in the ignition, even when the ignition is switched off, except for reinitialisation.

Locking the vehicle

Driving with the doors locked may make access to the passenger compartment by the emergency services more difficult in an emergency.

As a safety precaution (with children on board), remove the key from the ignition when you leave the vehicle, even for a short time.

Anti-theft protection

Do not make any modifications to the electronic engine immobiliser system; this could cause malfunctions.

When purchasing a second-hand vehicle

Have the key codes memorised by a PEUGEOT dealer, to ensure that the keys in your possession are the only ones which can start the vehicle.



Do not throw the remote control batteries away, they contain metals which are harmful to the environment.

Take them to an approved collection point.



Folding the key

☞ First press button **A** to fold the key.

Locating your vehicle



☞ Press the closed padlock to locate your locked vehicle in a car park.

This is indicated by lighting of the courtesy lights, the lateral spotlights and the dipped headlamps and flashing of the direction indicators for a few seconds.

Anti-theft protection

Electronic engine immobiliser

The key contains an electronic chip which has a special code. When the ignition is switched on, this code must be recognised in order for starting to be possible.

This electronic engine immobiliser locks the engine management system a few minutes after the ignition is switched off and prevents starting of the engine by anyone who does not have the key.



In the event of a malfunction, you are informed by lighting of this warning lamp, an audible signal and a message on the multifunction screen.

In this case, your vehicle does not start; contact a PEUGEOT dealer as soon as possible.

**Lost keys**

Visit a PEUGEOT dealer with the vehicle's V5 registration document and your personal identification documents.

The PEUGEOT dealer will be able to retrieve the key code and the transponder code required to order a replacement key.

Remote control

The high frequency remote control is a sensitive system; do not operate it while it is in your pocket as there is a possibility that it may unlock the vehicle, without you being aware of it.

Do not repeatedly press the buttons of your remote control out of range and out of sight of your vehicle. You run the risk of stopping it from working and the remote control would have to be reinitialised.

The remote control does not operate when the key is in the ignition, even when the ignition is switched off, except for reinitialisation.

Locking the vehicle

Driving with the doors locked may make access to the passenger compartment by the emergency services more difficult in an emergency.

As a safety precaution (with children on board), remove the key from the ignition when you leave the vehicle, even for a short time.

Anti-theft protection

Do not make any modifications to the electronic engine immobiliser system; this could cause malfunctions.

When purchasing a second-hand vehicle

Have the key codes memorised by a PEUGEOT dealer, to ensure that the keys in your possession are the only ones which can start the vehicle.



Do not throw the remote control batteries away, they contain metals which are harmful to the environment.

Take them to an approved collection point.

Starting the vehicle

- ☞ Insert the key in the ignition switch. The system recognises the starting code.
- ☞ Turn the key fully towards the fascia to position **3 (Starting)**.
- ☞ When the engine starts, release the key.



Switching the vehicle off

- ☞ Immobilise the vehicle.
- ☞ Turn the key fully towards you to position **1 (Stop)**.
- ☞ Remove the key from the ignition switch.



Key left in the "Ignition" position

If the key has been left in the ignition switch, the ignition will be switched off automatically after one hour.

To switch the ignition back on, turn the key to position **1 (Stop)**, then back to position **2 (Ignition)**.

Remote control problem

Following disconnection of the vehicle battery, replacement of the remote control battery or in the event of a remote control malfunction, you can no longer unlock, lock or locate your vehicle.

- ☞ First of all, use the key in the lock to unlock or lock your vehicle.
 - ☞ Then, reinitialise the remote control.
- If the problem persists, contact a PEUGEOT dealer as soon as possible.

Reinitialisation

- ☞ Switch off the ignition.
- ☞ Turn the key to position **2 (Ignition)**.
- ☞ Press the closed padlock immediately for a few seconds.
- ☞ Switch off the ignition and remove the key from the ignition switch.

The remote control is fully operational again.

Changing the battery



Battery ref.: CR 1620/3 volts.

This replacement battery is available from PEUGEOT dealers.



If the battery is flat, you are informed by lighting of this warning light, an audible signal and a message on the multifunction display.

- ☞ Unclip the casing using a coin at the notch.
- ☞ Slide the flat battery out of its location.
- ☞ Slide the new battery into its location observing the original direction.
- ☞ Clip the casing.
- ☞ Reinitialise the remote control.

ALARM

System which protects and dissuades against the theft of your vehicle. It provides two types of protection, exterior and interior, as well as an anti-tamper function.

Exterior protection

The system detects opening of the vehicle.

The alarm is triggered if anyone tries to enter the vehicle by forcing a door, the boot or the bonnet.

Interior protection

The system detects any variation in the volume in the passenger compartment.

The alarm is triggered if anyone breaks a window or moves inside the vehicle.

If you wish to leave a pet in the vehicle or a window partially open, deactivate the interior protection.

Anti-tamper function

The system detects the putting out of service of its components.

The alarm is triggered if anyone tries to put the wires of the siren, the central control or the battery out of service.



Do not make any modifications to the alarm system, this could cause malfunctions.

Locking the vehicle with full alarm



Activation

- ☞ Switch off the ignition and get out of the vehicle.
- ☞ Lock or deadlock the vehicle using the locking button on the remote control.

The alarm is activated; the indicator light on button **A** flashes once per second.

Deactivation

- ☞ Unlock the vehicle using the unlocking button on the remote control.

The alarm is deactivated; the indicator light on button **A** switches off.

Locking the vehicle with exterior protection alarm only

Deactivation of the interior protection

- ☞ Switch off the ignition.
- ☞ Within ten seconds, press button **A** until the indicator light is lit continuously.
- ☞ Get out of the vehicle.
- ☞ Lock or deadlock the vehicle using the locking button on the remote control.

The exterior protection alarm alone remains activated; the indicator light on button **A** flashes once per second.



In order to be taken into account, this deactivation must be carried out each time the ignition is switched off.

In the "cabriolet" configuration, the interior protection is deactivated automatically.

Reactivation of the interior protection

- ☞ Unlock the vehicle using the unlocking button on the remote control.
- ☞ Relock the vehicle using the remote control.

The alarm is activated again with both types of protection; the indicator light on button **A** switches off.

Triggering of the alarm

This is indicated by sounding of the siren and flashing of the direction indicators for approximately thirty seconds. After it has been triggered, the alarm is again operational.



If the alarm is triggered ten times in succession, the eleventh time will result in it becoming inactive.

If the indicator light on button **A** flashes rapidly, this indicates that the alarm was triggered during your absence. When the ignition is switched on, this flashing stops immediately.

To avoid triggering the alarm when washing your vehicle, lock it using the key.

Do not activate the alarm before disconnecting the battery, otherwise the siren will sound.

Failure of the remote control

- ☞ Unlock the vehicle using the key in the driver's door lock.
- ☞ Open the door; the alarm is triggered.
- ☞ Switch on the ignition; the alarm stops.

Locking the vehicle without alarm

- ☞ Lock or deadlock the vehicle using the key in the driver's door lock.

Malfunction

When the ignition is switched on, lighting of the indicator light on button **A** for ten seconds indicates a siren fault.

Have it checked by a PEUGEOT dealer.

Automatic operation*

Depending on the legislation in force in your country, one of these cases may occur:

- 45 seconds after the vehicle is locked using the remote control, the alarm is activated, regardless of the status of the doors and boot.
- 2 minutes after the last door or the boot is closed, the alarm is activated.
- ☞ To avoid triggering the alarm on entering the vehicle, first press the unlocking button on the remote control.

* According to country.

WINDOW MECHANISMS

System which opens or closes a window manually or automatically. It is fitted with a system which protects against pinching on the front windows and a system which controls all four windows on all models.



1. Driver's electric window switch.
2. Passenger's electric window switch.
3. Rear right electric window switch.
4. Rear left electric window switch.
5. Deactivation of the rear electric window switches.

One-touch electric windows

You have two options:

- **manual mode**
 - ☞ Press or pull switch **1** gently. The window stops as soon as the switch is released.
- **automatic mode**
 - ☞ Press or pull switch **1** fully. The window opens or closes completely when the switch is released.
 - ☞ Pressing the switch again stops the movement of the window.

Front windows safety auto-reverse

In automatic mode, when the front window rises and meets an obstacle it stops and partially lowers again.

i If the window opens unintentionally when closing (for example, in the presence of ice):

- ☞ press the switch until the window opens completely,
- ☞ then pull the switch immediately until the window closes,
- ☞ continue to pull the switch for approximately three seconds after the window has closed.

The safety auto-reverse function is not active during these operations.

i The rear windows do not have an automatic mode or safety auto-reverse function for raising.

Approximately 45 seconds after removing the ignition key or opening a door none of the windows can be opened or closed. The ignition must be switched back on in order to open or close the windows.

Deactivation of the rear electric window controls

- ☞ For the safety of your children, press switch **5** to deactivate the rear electric window switches regardless of their position.

When the indicator light is on, the rear switches are deactivated.

When the indicator light is off, the rear switches are activated.

Switch for all four windows

This switch opens or closes all of the windows at once.



- ☞ Press switch **6** and release it. The windows open completely.
- ☞ Pressing the switch again stops the movement of the windows.

or

- ☞ Pull switch **6** and hold it in this position. The windows close completely.
- ☞ If you release the switch before the windows have closed completely, the windows stop.



This switch is operated under the full responsibility of the driver.

Reinitialisation

Following reconnection of the battery or in the event of a malfunction you must reinitialise the operation of the electric windows:

- ☞ release the switch and pull it again until it closes completely,
- ☞ hold the switch for approximately three seconds after closing,
- ☞ press the switch to lower the window automatically,
- ☞ when the window has reached the low position, press the switch again for approximately one second.

The safety auto-reverse function is not active during these operations.



This procedure reinitialises the operation of the electric windows and the automatic partial opening of the door windows.



Always remove the key from the ignition when leaving the vehicle, even for a short time.

In the event of contact during operation of the windows, you must reverse the movement of the window. To do this, press the switch concerned.

When the driver operates the passenger electric window switches, he must ensure that no one is preventing correct closing of the windows.


The driver must ensure that the passengers use the electric windows correctly.

Be aware of children when operating the windows.

DOORS

Opening

From outside



- ☞ After unlocking the vehicle completely using the remote control or the key, take hold of the door handle then pull it.

The window lowers automatically by a few millimetres to permit opening of the door.

- i** If you leave the door open for more than one minute, the window rises again. Pull the handle again to reactivate the system.

When the selective unlocking is activated, the first press of the remote control unlocking button permits unlocking of the driver's door only.

From inside



- ☞ Pull the door control to open the door; this unlocks this vehicle completely.

The window lowers automatically by a few millimetres to permit opening of the door.

- i** With the selective unlocking activated:
- the driver's door control unlocks the driver's door only.
 - the passenger's door control unlocks the passenger's door and the boot.

- !** The interior door controls do not operate when the vehicle is dead-locked.

Closing

The window rises automatically after a few seconds and adjusts to provide perfect sealing when closed.

When a door is not closed correctly:



- **when the engine is running**, this warning light comes on, accompanied by a message on the multi-function display for a few seconds,
- **when the vehicle is moving** (speed higher than 6 mph (10 km/h)), this warning light comes on, accompanied by an audible signal and a message on the multifunction display for a few seconds.

- !** When washing your vehicle:
- first lock the vehicle using the remote control or the key,
 - avoid spraying the upper part of the windows,
 - keep the end of the high pressure nozzle at least 1 metre from the windows and door seals.

Manual centralised control

System which provides full manual locking or unlocking of the doors and boot from the inside.



Locking

☞ Press button **A** to lock the vehicle. The red indicator light on the button comes on.

i If one of the doors or the boot is open, the central locking from the inside does not take place.

Unlocking

☞ Press button **A** again to unlock the vehicle.

The red indicator light on the button switches off.

i If the vehicle is locked or dead-locked from the outside, the red indicator light flashes and button **A** is inactive.

☞ In this case, use the remote control or the key to unlock the vehicle.

! The glove box and the front arm-rest compartment are not locked so that they remain accessible.

Central automatic control

System which provides full automatic locking or unlocking of the doors and boot while driving.

You can activate or deactivate this function.

Locking

When the speed exceeds 6 mph (10 km/h), the doors and boot lock automatically.

! If one of the doors is open, the automatic central locking does not take place.

If the boot is open, the automatic central locking of the doors is active.

Unlocking

☞ Above 6 mph (10 km/h), press button **A** to unlock the doors and boot temporarily.

Activation



- ☞ Press button **A** for more than two seconds.

A confirmation message appears on the multifunction display.

Deactivation

- ☞ Press button **A** again for more than two seconds.

A confirmation message appears on the multifunction display.

Emergency control

System which locks or unlocks the doors mechanically in the event of a malfunction of the central locking.

Locking the driver's door

- ☞ Insert the key in the lock, then turn it to the right.

Unlocking the driver's door

- ☞ Insert the key in the lock, then turn it to the left.

Locking the passenger door



- ☞ Insert the key in the lock, located on the edge of the door, then turn it **one eighth of a turn**.

Unlocking the passenger door

- ☞ Pull the interior door opening control.

BOOT

Unlocking and partially opening the boot



- Press this button for more than two seconds to unlock the boot. The boot opens slightly.

This action also unlocks the doors.

Opening

- After unlocking the boot or the vehicle using the remote control or the key, press the opening control while raising the tailgate.



If a battery failure occurs, the boot is locked. Consult a PEUGEOT dealer.

Boot anti-theft protection

The boot is designed to remain impregnable, even in the "cabriolet" configuration, if the vehicle is locked.

So, when the vehicle is locked and the roof is open, the boot cannot be unlocked:

- by means of the interior door opening control,
- by pressing the manual centralised control **A**, when the key is not in the ignition switch.



Closing

- Lower the tailgate using the interior grab handle.



If the tailgate is not closed correctly:



- when the engine is running**, this warning light comes on, accompanied by a message on the multifunction display for a few seconds,
- when the vehicle is moving** (speed above 6 mph (10 km/h)), this warning light comes on, accompanied by an audible signal and a message on the multifunction display for a few seconds.



When the selective unlocking is activated, the boot can be opened at the second press of the unlocking button on the remote control.

FUEL TANK

Capacity of the tank: approximately 60 litres.

Low fuel level



When the fuel tank minimum level is reached, this warning light comes on on the instrument panel, accompanied by an audible signal and a message on the multifunction display.

You have enough fuel left to drive approximately 30 miles (50 km).

If you run out of fuel, refer to the "Checks - § Running out of fuel" section also.

Operating fault

A fuel gauge malfunction is indicated by the return of the fuel level indicator needle to zero.

Consult a PEUGEOT dealer.



The key cannot be removed from the lock until the cap is put back on the tank.

Filling


A label affixed to the inside of the flap reminds you of the type of fuel to be used according to your engine.

To fill the tank safely:

- ☞ **it is essential that the engine is switched off,**
- ☞ open the fuel filler flap,
- ☞ insert the key in the cap, then turn it to the left,



- ☞ remove the cap and secure it on the hook, located on the inside of the flap,
- ☞ fill the tank, but **do not continue after the 3rd cut-off of the nozzle;** this could cause malfunctions.



When filling is complete:

- ☞ put the cap back in place,
- ☞ turn the key to the right, then remove it from the cap,
- ☞ close the flap.

LIGHTING CONTROLS

System for selection and control of the various front and rear lamps providing the vehicle's lighting.

Main lighting

The various front and rear lamps of the vehicle are designed to adapt the driver's visibility progressively in relation to the climatic conditions:

- sidelamps, to be seen,
- dipped headlamps to see without dazzling other drivers,
- main beam headlamps to see clearly when the road is clear,
- directional headlamps for improved visibility when cornering.

Additional lighting

Other lamps are fitted to fulfil the requirements of particular driving conditions:

- a rear foglamp to be seen from a distance,
- front foglamps for even better forward vision,
- daytime running lamps to be seen during the day.

Programming

Various automatic lighting control modes are also available depending on options:

- guide-me-home lighting,
- automatic lighting,
- directional lighting.

Model without AUTO lighting



Model with AUTO lighting



Manual controls

The lighting commands are issued directly by the driver by means of the ring **A** and the stalk **B**.

A. main lighting mode selection ring, with:

O lamps off,

AUTO automatic switching on of the lamps,

 sidelamps only,

 dipped headlamps or main beam headlamps.

B. stalk for switching headlamps by pulling: dipped headlamps/main beam headlamps.

In the lamps off and sidelamps modes, the driver can switch on the main beam headlamps temporarily ("headlamp flash") by maintaining a pull on the stalk.

Displays

Lighting of the corresponding indicator lamp on the instrument panel confirms the selective switching on of the lighting selected.

C. fog lamps selection ring.

The fog lamps operate with the dipped and main beam headlamps.



 front and rear fog lamps

- ☞ To switch on the fog lamps, turn the ring **C** forwards.
- ☞ To switch off the rear fog lamp, turn the ring **C** rearwards twice in succession.

When the lights are switched off automatically (with AUTO model) or when the dipped headlamps are switched off manually, the fog lamps and the side lights will remain on.

- ☞ Turn the ring rearwards to switch off the fog lamps, the side lights will then switch off.



In good or rainy weather, both day and night, the front fog lamps and the rear fog lamp are prohibited. In these situations, the power of their beams may dazzle other drivers.

Do not forget to switch off the front fog lamps and the rear fog lamp when they are no longer necessary.

**Lights on buzzer**

The triggering of an audible signal when a front door is opened warns the driver that he has forgotten to switch off his vehicle's lights, with the ignition off and in manual lights mode.

In this case, switching off the lights stops the audible signal.

With the ignition off, if the dipped headlamps remain on, they will switch off automatically after thirty minutes to prevent discharging of the battery.

Daytime lights

System which permits automatic switching on of the special lights at the front, so that you can be seen during the daytime.

On vehicles fitted with daytime lights, the corresponding lights come on when the vehicle is started*.

The instruments and controls (instrument panel, multifunction display, air conditioning control panel, ...) are not lit, except on switching to the automatic switching on of the lights mode or when the lights are switched on manually.

Programming

In countries in which this function is not imposed by regulations, you can activate or deactivate it via the multifunction display configuration menu.

In countries in which it is imposed by regulations:

- by default, this function is activated,
- the side lights and the number plate lights are also switched on.

* According to country.

Manual follow-me-home lighting

The temporary maintaining of the dipped headlamps lighting after the vehicle's ignition has been switched off makes the driver's exit easier when the light is poor.



Switching on

- ☞ With the ignition off, "flash" the headlamps using the lights stalk **B**.
- ☞ A second "headlamp flash" switches the function off again.

Switching off

The manual follow-me-home lighting switches off automatically after a set time.

Automatic lighting

The side lights and dipped headlamps are switched on automatically, without any action on the part of the driver, when a low level of external light is detected or in certain cases of activation of the windscreen wipers.

As soon as the brightness returns to a sufficient level or after the windscreen wipers are switched off, the lights are switched off automatically.



Activation

- ☞ Turn ring **A** to the "AUTO" position. The automatic lighting is accompanied by a message on the multifunction display.

Deactivation

- ☞ Turn ring **A** to a position other than "AUTO". Deactivation is accompanied by a message on the multifunction display.

Coupling with the automatic "Follow-me-home" lighting

Association with the automatic lighting provides the "follow-me-home" lighting with the following additional options:

- selection of the duration of maintaining of the lighting for 15, 30 or 60 seconds in the vehicle parameters on the multifunction display configuration menu,
- automatic activation of "follow-me-home" lighting when automatic lighting is in operation.

Operating fault



In the event of a malfunction of the brightness sensor, the lights come on, this warning light is displayed on the instrument panel and/or a message appears on the multifunction display, accompanied by an audible signal. Consult a PEUGEOT dealer.



In fog or snow, the brightness sensor may detect sufficient light. Therefore, the lights will not come on automatically.

Do not cover the brightness sensor, coupled with the rain sensor and located in the centre of the windscreen behind the interior mirror; the associated functions would no longer be controlled.

Exterior welcome lighting

The remote switching on of the lights and lateral spotlights makes your approach to the vehicle easier in poor light when in automatic switching on of the lights mode.

Switching on

✎ Press the open padlock on the remote control.

The dipped headlamps and the side lights come on, as well as the lateral spotlights, located in the exterior mirrors; your vehicle is also unlocked.

Switching off

The exterior welcome lighting switches off automatically after a set time, when the ignition is switched on or on locking the vehicle.

Programming



The duration of maintaining of the lighting is selected via the multifunction display configuration menu.



The duration of the welcome lighting is associated with and identical to that of the automatic follow-me-home lighting.

MANUAL ADJUSTMENT OF THE HEADLAMPS



To avoid dazzling other road users, the height of the halogen bulb headlamps must be adjusted according to the load in the vehicle.

- 0. 1 or 2 people in the front seats.
- 3 people.
- 1. 4 people.
- Intermediate setting.
- 2. 4 people + maximum authorised loads.
- Intermediate setting.
- 3. Driver + maximum authorised loads.



Initial setting is position "0".

Manual follow-me-home lighting

The temporary maintaining of the dipped headlamps lighting after the vehicle's ignition has been switched off makes the driver's exit easier when the light is poor.



Switching on

- ☞ With the ignition off, "flash" the headlamps using the lights stalk **B**.
- ☞ A second "headlamp flash" switches the function off again.

Switching off

The manual follow-me-home lighting switches off automatically after a set time.

Automatic lighting

The side lights and dipped headlamps are switched on automatically, without any action on the part of the driver, when a low level of external light is detected or in certain cases of activation of the windscreen wipers.

As soon as the brightness returns to a sufficient level or after the windscreen wipers are switched off, the lights are switched off automatically.



Activation

- ☞ Turn ring **A** to the "AUTO" position. The automatic lighting is accompanied by a message on the multifunction display.

Deactivation

- ☞ Turn ring **A** to a position other than "AUTO". Deactivation is accompanied by a message on the multifunction display.

Coupling with the automatic "Follow-me-home" lighting

Association with the automatic lighting provides the "follow-me-home" lighting with the following additional options:

- selection of the duration of maintaining of the lighting for 15, 30 or 60 seconds in the vehicle parameters on the multifunction display configuration menu,
- automatic activation of "follow-me-home" lighting when automatic lighting is in operation.

Operating fault



In the event of a malfunction of the brightness sensor, the lights come on, this warning light is displayed on the instrument panel and/or a message appears on the multifunction display, accompanied by an audible signal. Consult a PEUGEOT dealer.



In fog or snow, the brightness sensor may detect sufficient light. Therefore, the lights will not come on automatically.

Do not cover the brightness sensor, coupled with the rain sensor and located in the centre of the windscreen behind the interior mirror; the associated functions would no longer be controlled.

Exterior welcome lighting

The remote switching on of the lights and lateral spotlights makes your approach to the vehicle easier in poor light when in automatic switching on of the lights mode.

Switching on

✎ Press the open padlock on the remote control.

The dipped headlamps and the side lights come on, as well as the lateral spotlights, located in the exterior mirrors; your vehicle is also unlocked.

Switching off

The exterior welcome lighting switches off automatically after a set time, when the ignition is switched on or on locking the vehicle.

Programming



The duration of maintaining of the lighting is selected via the multifunction display configuration menu.



The duration of the welcome lighting is associated with and identical to that of the automatic follow-me-home lighting.

MANUAL ADJUSTMENT OF THE HEADLAMPS



To avoid dazzling other road users, the height of the halogen bulb headlamps must be adjusted according to the load in the vehicle.

- 0. 1 or 2 people in the front seats.
- 3 people.
- 1. 4 people.
- Intermediate setting.
- 2. 4 people + maximum authorised loads.
- Intermediate setting.
- 3. Driver + maximum authorised loads.



Initial setting is position "0".

Exterior welcome lighting

The remote switching on of the lights and lateral spotlights makes your approach to the vehicle easier in poor light when in automatic switching on of the lights mode.

Switching on

✎ Press the open padlock on the remote control.

The dipped headlamps and the side lights come on, as well as the lateral spotlights, located in the exterior mirrors; your vehicle is also unlocked.

Switching off

The exterior welcome lighting switches off automatically after a set time, when the ignition is switched on or on locking the vehicle.

Programming



The duration of maintaining of the lighting is selected via the multifunction display configuration menu.



The duration of the welcome lighting is associated with and identical to that of the automatic follow-me-home lighting.

MANUAL ADJUSTMENT OF THE HEADLAMPS



To avoid dazzling other road users, the height of the halogen bulb headlamps must be adjusted according to the load in the vehicle.

- 0. 1 or 2 people in the front seats.
- 3 people.
- 1. 4 people.
- Intermediate setting.
- 2. 4 people + maximum authorised loads.
- Intermediate setting.
- 3. Driver + maximum authorised loads.



Initial setting is position "0".

AUTOMATIC ADJUSTMENT OF THE DIRECTIONAL HEADLAMPS



In order to avoid causing a nuisance to other road users, this system corrects the height of the xenon headlamps beam automatically and when stationary, in relation to the load in the vehicle.



If a malfunction occurs, this warning light and/or the service warning light is displayed on the instrument panel, accompanied by an audible signal and a message on the multifunction display.

The system then places your headlamps in the lowest position.



Do not touch the xenon headlamps. Consult a PEUGEOT dealer.

DIRECTIONAL LIGHTING

When the dipped or main beam headlamps are on, this function enables the light beam to follow the direction of the road.

The use of this function, coupled with the xenon headlamps only, considerably improves the quality of your lighting when cornering.

with directional lighting



without directional lighting



Programming



The function is activated or deactivated via the multi-function display configuration menu.

Operating fault



If a malfunction occurs, this warning light flashes on the instrument panel, accompanied by a message on the multifunction display.

Consult a PEUGEOT dealer.



When stationary or moving at very low speed or when reverse gear is engaged, the function is inactive.

The status of the function remains in the memory when the ignition is switched off.

AUTOMATIC ADJUSTMENT OF THE DIRECTIONAL HEADLAMPS



In order to avoid causing a nuisance to other road users, this system corrects the height of the xenon headlamps beam automatically and when stationary, in relation to the load in the vehicle.



If a malfunction occurs, this warning light and/or the service warning light is displayed on the instrument panel, accompanied by an audible signal and a message on the multifunction display.

The system then places your headlamps in the lowest position.



Do not touch the xenon headlamps. Consult a PEUGEOT dealer.

DIRECTIONAL LIGHTING

When the dipped or main beam headlamps are on, this function enables the light beam to follow the direction of the road.

The use of this function, coupled with the xenon headlamps only, considerably improves the quality of your lighting when cornering.

with directional lighting



without directional lighting



Programming



The function is activated or deactivated via the multi-function display configuration menu.

Operating fault



If a malfunction occurs, this warning light flashes on the instrument panel, accompanied by a message on the multifunction display.

Consult a PEUGEOT dealer.



When stationary or moving at very low speed or when reverse gear is engaged, the function is inactive.

The status of the function remains in the memory when the ignition is switched off.

WIPER CONTROLS


System for selection and control of the various windscreen wiping modes for the elimination of rain and cleaning.

The vehicle's windscreen wipers are designed to improve the driver's visibility progressively in relation to the climatic conditions.


Programming

An automatic control mode is also available, such as automatic wiping for the windscreen wipers.

Model with intermittent wiping



Model with AUTO wiping



Manual controls

The wiper commands are issued directly by the driver by means of the control **A**.

Windscreen wipers

A. wiping speed selection control:

- 2** fast (heavy rain),
- 1** normal (moderate rain),
- I** intermittent (proportional to the speed of the vehicle),
- 0** park,
- ↓** single wipe (press downwards),
- or

AUTO ↓ automatic, then single wipe (see next page).

Windscreen and headlamp wash



☞ Pull the windscreen wiper stalk towards you. The windscreen wash then the windscreen wipers operate for a fixed period.

If the dipped headlamps are on, the headlamp washers operate at the same time.

Screenwash/headlamp wash low



In the case of vehicles fitted with headlamp washers, when the minimum level of the reservoir is reached, this warning light and/or the service warning light is displayed on the instrument panel, accompanied by an audible signal and a message on the multifunction display.

Next time you stop, fill the screenwash/headlamp wash reservoir.

The warning light is displayed when the ignition is switched on, or every time the stalk is operated, until the reservoir is filled.

Automatic windscreen wiping

The windscreen wipers operate automatically, without any action on the part of the driver, if rain is detected (sensor behind the interior mirror), adapting their speed to the intensity of the rainfall.



Activation

This is controlled manually by the driver by pushing stalk **A** to the "AUTO" position.

It is accompanied by a message on the multifunction screen.



Switching off

This is controlled manually by the driver by moving stalk **A** upwards and returning it to position "0".

It is accompanied by a message on the multifunction screen.



The automatic wiping must be reactivated if the ignition has been off for more than one minute, by pushing stalk **A** downwards.

Operating fault

If an automatic wiping malfunction occurs, the wipers will operate in intermittent mode.

Have it checked by a PEUGEOT dealer.



Do not cover the rain sensor, linked with the brightness sensor and located in the centre of the windscreen behind the interior mirror.

Switch off the automatic wiping when using an automatic car wash.

In winter, it is advisable to wait until the windscreen is completely clear of ice before activating the automatic wiping.

Special position of the windscreen wipers



In the minute following switching off of the ignition, any action on the stalk positions the wipers in the centre of the windscreen.

This action enables you to position the wiper blades for winter parking, cleaning or replacement.

To park the wipers after this has been done, switch on the ignition and operate the stalk.




For optimum and lasting wiping of the "flat-blade" wiper blades, it is advisable to:

- handle them with care,
- clean them regularly using soapy water,
- change them approximately every 6 months,
- avoid using them to retain card-board on the windscreen.

COURTESY LIGHTS

Selection and control of the various passenger compartment lights.



1. Front courtesy light
2. Map reading lights
3. Rear courtesy light

Front and rear courtesy lights



In this position, the courtesy light comes on gradually:

- when the vehicle is unlocked,
- when the key is removed from the ignition,
- when the remote control locking button is activated, in order to locate your vehicle.

It switches off gradually:

- when the vehicle is locked,
- when the ignition is switched on,
- 30 seconds after the last door is closed.



Permanently off.



Permanent lighting.



In permanent lighting mode, different lighting times are available:

- with the ignition off, approximately ten minutes,
- in energy economy mode, approximately thirty seconds,
- with the engine running, unlimited.

Map reading lights



With the ignition on, press the corresponding switch.

Windscreen and headlamp wash



☞ Pull the windscreen wiper stalk towards you. The windscreen wash then the windscreen wipers operate for a fixed period.

If the dipped headlamps are on, the headlamp washers operate at the same time.

Screenwash/headlamp wash low



In the case of vehicles fitted with headlamp washers, when the minimum level of the reservoir is reached, this warning light and/or the service warning light is displayed on the instrument panel, accompanied by an audible signal and a message on the multifunction display.

Next time you stop, fill the screenwash/headlamp wash reservoir.

The warning light is displayed when the ignition is switched on, or every time the stalk is operated, until the reservoir is filled.

Automatic windscreen wiping

The windscreen wipers operate automatically, without any action on the part of the driver, if rain is detected (sensor behind the interior mirror), adapting their speed to the intensity of the rainfall.



Activation

This is controlled manually by the driver by pushing stalk **A** to the "AUTO" position.

It is accompanied by a message on the multifunction screen.



Switching off

This is controlled manually by the driver by moving stalk **A** upwards and returning it to position "0".

It is accompanied by a message on the multifunction screen.



The automatic wiping must be reactivated if the ignition has been off for more than one minute, by pushing stalk **A** downwards.

Operating fault

If an automatic wiping malfunction occurs, the wipers will operate in intermittent mode.

Have it checked by a PEUGEOT dealer.



Do not cover the rain sensor, linked with the brightness sensor and located in the centre of the windscreen behind the interior mirror.

Switch off the automatic wiping when using an automatic car wash.

In winter, it is advisable to wait until the windscreen is completely clear of ice before activating the automatic wiping.

Special position of the windscreen wipers



In the minute following switching off of the ignition, any action on the stalk positions the wipers in the centre of the windscreen.

This action enables you to position the wiper blades for winter parking, cleaning or replacement.

To park the wipers after this has been done, switch on the ignition and operate the stalk.



For optimum and lasting wiping of the "flat-blade" wiper blades, it is advisable to:

- handle them with care,
- clean them regularly using soapy water,
- change them approximately every 6 months,
- avoid using them to retain card-board on the windscreen.

COURTESY LIGHTS

Selection and control of the various passenger compartment lights.



1. Front courtesy light
2. Map reading lights
3. Rear courtesy light

Front and rear courtesy lights



In this position, the courtesy light comes on gradually:

- when the vehicle is unlocked,
- when the key is removed from the ignition,
- when the remote control locking button is activated, in order to locate your vehicle.

It switches off gradually:

- when the vehicle is locked,
- when the ignition is switched on,
- 30 seconds after the last door is closed.



Permanently off.



Permanent lighting.



In permanent lighting mode, different lighting times are available:

- with the ignition off, approximately ten minutes,
- in energy economy mode, approximately thirty seconds,
- with the engine running, unlimited.

Map reading lights



With the ignition on, press the corresponding switch.

AMBIENT LIGHTING

The dimmed passenger compartment lighting improves visibility in the vehicle when the light is poor.



Switching on

At night, the footwell lighting and the front courtesy light ambient lamp **A** come on automatically when the side lights are switched on.

Switching off

The ambient lighting switches off automatically when the side lights are switched off.

Programming



The function is activated or deactivated via the multifunction display configuration menu.

This function is activated by default.

INTERIOR WELCOME LIGHTING

The remote switching on of the passenger compartment lighting makes your approach to the vehicle easier in poor light when in automatic switching on of the lights mode.

Switching on

Press the open padlock on the remote control.

The front door sill lighting, the footwell lighting and the courtesy lights come on; your vehicle is also unlocked.

Switching off

The interior welcome lighting switches off automatically after a set time or when one of the doors is opened.

Programming




The duration of maintaining of the lighting is selected via the multifunction display configuration menu.



The duration of the welcome lighting is associated with and identical to that of the automatic follow-me-home lighting.

BOOT LIGHTING



Your vehicle is fitted with two boot lights; one in the left-hand boot side trim and a second in the tailgate interior trim.

They come on automatically when the boot is opened and switch off automatically when the boot is closed.

They cannot be deactivated manually.



Different lighting times are available:

- when the ignition is off, approximately ten minutes,
- in energy economy mode, approximately thirty seconds,
- when the engine is running, no limit.




INTERIOR LAYOUT

1. **Sun visor**
(see details on following page)
2. **Storage compartment**
3. **Storage compartment**
4. **Glove box with lock and air conditioning**
(see details on following page)
5. **Large door trays**
6. **Small door trays**
7. **Ashtray with light**
(see details on following page)
8. **Storage compartment with non-slip carpet**
9. **12 V accessories socket**
(see details on following page)
10. **Front armrest with lock**
(see details on following page)
11. **Storage box**
(see details on following page)

SUN VISOR

Component which protects against sunlight from the front or the side, also equipped with an illuminated courtesy mirror.



☞ With the ignition on, raise the concealing flap; the mirror is lit automatically.

This sun visor is also equipped with a ticket holder.

GLOVE BOX WITH LOCK AND AIR CONDITIONING



Its lid has areas for storing a pen, a pair of spectacles, tokens, cards, a can...

It is also locked or unlocked when the vehicle is locked or unlocked using the remote control or the key.

☞ To open the glove box, raise the handle.

The light comes on when the lid is opened.

If the vehicle is fitted with air conditioning, it provides access to the air vent **A**, which can be opened or closed, distributing the same conditioned air as the vents in the passenger compartment.

It also permits access to the fascia fuse box (refer to the section "Practical information - § Changing a fuse").

FRONT ARMREST WITH LOCK

Comfort and storage device for the driver and front passenger.


The height and longitudinal position of the armrest cover can be adjusted for greater comfort.

Its compartment is also locked or unlocked when the vehicle is locked or unlocked using the remote control or the key.



Height adjustment

- ☞ Raise the cover to the required position (low, intermediate or high).
- ☞ If you raise the cover slightly beyond the high position, guide it when lowering it to the low position.



Longitudinal adjustment

- ☞ Slide the cover fully forwards or rearwards.

Storage



It can hold up to 6 CDs.

- ☞ Raise the lever 1.
- ☞ Raise the cover fully.

USB PLUG - READER



This connection box, consisting of a USB port, is located in the front armrest.

It permits the connection of portable equipment, such as an iPod® digital audio player of generation 5 or later or a USB stick.

It reads the audio file formats (mp3, ogg, wma, wav...) which are transmitted to your audio equipment and played via the vehicle's speakers.

You can manage these files using the steering wheel controls or the audio equipment control panel and display them on the multifunction screen.

When it is in use, the portable equipment charges automatically.

For further details concerning the use of this equipment, refer to the PC Sound part of the "Audio and Telematics" section.

STORAGE BOX

Storage area, located at the rear of the front armrest, for the rear passengers.



- ☞ To empty the box, after opening, press the tab and remove it.

12 V ACCESSORIES SOCKET



- ☞ To connect a 12 V accessory (max power: 120 Watts), remove the cover and connect a suitable adaptor.

ASHTRAY WITH LIGHT



- ☞ Pull the drawer to gain access to the ashtray.
- ☞ To empty the ashtray, after opening, press the tab and remove the ashtray.

MATS

Removable component which protects the carpet against exterior dirt.

Fitting


When fitting the mat for the first time, on the driver's side, use only the fixings provided in the wallet attached.

The other mats are simply placed on the carpet.

Removal

To remove the mat on the driver's side:

- ☞ move the seat as far back as possible,
- ☞ unclip the fixings,
- ☞ remove the mat.



Refitting

To refit the mat on the driver's side:

- ☞ position the mat correctly,
- ☞ refit the fixings by pressing,
- ☞ check that the mat is secured correctly.




To avoid any risk of jamming of the pedals:

- only use mats which are suited to the fixings already present in the vehicle; it is imperative that these are used,
- never fit one mat on top of another.

SUN VISOR

Component which protects against sunlight from the front or the side, also equipped with an illuminated courtesy mirror.



☞ With the ignition on, raise the concealing flap; the mirror is lit automatically.

This sun visor is also equipped with a ticket holder.

GLOVE BOX WITH LOCK AND AIR CONDITIONING



Its lid has areas for storing a pen, a pair of spectacles, tokens, cards, a can...

It is also locked or unlocked when the vehicle is locked or unlocked using the remote control or the key.

☞ To open the glove box, raise the handle.

The light comes on when the lid is opened.

If the vehicle is fitted with air conditioning, it provides access to the air vent **A**, which can be opened or closed, distributing the same conditioned air as the vents in the passenger compartment.

It also permits access to the fascia fuse box (refer to the section "Practical information - § Changing a fuse").

FRONT ARMREST WITH LOCK

Comfort and storage device for the driver and front passenger.


The height and longitudinal position of the armrest cover can be adjusted for greater comfort.

Its compartment is also locked or unlocked when the vehicle is locked or unlocked using the remote control or the key.



Height adjustment

- ☞ Raise the cover to the required position (low, intermediate or high).
- ☞ If you raise the cover slightly beyond the high position, guide it when lowering it to the low position.



Longitudinal adjustment

- ☞ Slide the cover fully forwards or rearwards.

Storage



It can hold up to 6 CDs.

- ☞ Raise the lever 1.
- ☞ Raise the cover fully.

USB PLUG - READER



This connection box, consisting of a USB port, is located in the front armrest.

It permits the connection of portable equipment, such as an iPod® digital audio player of generation 5 or later or a USB stick.

It reads the audio file formats (mp3, ogg, wma, wav...) which are transmitted to your audio equipment and played via the vehicle's speakers.

You can manage these files using the steering wheel controls or the audio equipment control panel and display them on the multifunction screen.

When it is in use, the portable equipment charges automatically.

For further details concerning the use of this equipment, refer to the PC Sound part of the "Audio and Telematics" section.

STORAGE BOX

Storage area, located at the rear of the front armrest, for the rear passengers.



- ☞ To empty the box, after opening, press the tab and remove it.

12 V ACCESSORIES SOCKET



- ☞ To connect a 12 V accessory (max power: 120 Watts), remove the cover and connect a suitable adaptor.

ASHTRAY WITH LIGHT



- ☞ Pull the drawer to gain access to the ashtray.
- ☞ To empty the ashtray, after opening, press the tab and remove the ashtray.

MATS

Removable component which protects the carpet against exterior dirt.

Fitting


When fitting the mat for the first time, on the driver's side, use only the fixings provided in the wallet attached.

The other mats are simply placed on the carpet.

Removal

To remove the mat on the driver's side:

- ☞ move the seat as far back as possible,
- ☞ unclip the fixings,
- ☞ remove the mat.



Refitting

To refit the mat on the driver's side:

- ☞ position the mat correctly,
- ☞ refit the fixings by pressing,
- ☞ check that the mat is secured correctly.



To avoid any risk of jamming of the pedals:

- only use mats which are suited to the fixings already present in the vehicle; it is imperative that these are used,
- never fit one mat on top of another.



BOOT LAYOUT

1. **Stowing rings**
2. **Luggage retaining net**
(see details on following page)
3. **Boot screen**
(see details on following page)
4. **Storage net**
5. **Luggage retaining strap**
6. **Storage box (version fitted with a temporary tyre repair kit)**
(see details on following page)
or
Tool box (version fitted with a uniform spare wheel)
(refer to the section "Practical information - § Changing a wheel")

Luggage retaining net



Hooked onto the stowing rings, this enables you to secure your luggage.

Storage box



- ☞ Raise the boot carpet to gain access to the storage box.
- ☞ Hook the boot carpet on the boot seal using its handle.

This has areas for storing the windstop and two warning triangles.

By removing this box you gain access to the temporary tyre repair kit and the tools.

Boot screen



In the "cabriolet" configuration, this defines the luggage space in the boot.

- ☞ When the boot screen is unfolded, check that the luggage:
 - never raises it,
 - is never placed on top of it.



The load space cover must always be unfolded before a roof opening manoeuvre is triggered (refer to the "Familiarisation - § Opening" section).

DIRECTION INDICATORS

Selection of the left or right direction indicators to signal a change of direction of the vehicle.



- ☞ Lower the lights stalk fully when moving to the left.
- ☞ Raise the lights stalk fully when moving to the right.



If you forget to cancel the direction indicators for more than twenty seconds, the volume of the audible signal will increase if the speed is above 40 mph (60 km/h).

HAZARD WARNING LAMPS

A visual warning by means of the direction indicators to alert other road users to a vehicle breakdown, towing or accident.



- ☞ Press the button, the direction indicators flash.

They can operate with the ignition off.

Automatic lighting of hazard warning lamps

When braking in an emergency, depending on the deceleration, the hazard warning lamps come on.

They will switch off automatically the first time you accelerate.

- ☞ If they do not, press button **A** to switch the direction indicators off.



As a safety precaution in a traffic jam, switch on the hazard warning lamps if you are the last in the queue.

HORN

Audible warning to alert other road users to an imminent danger.



- ☞ Press one of the spokes of the steering wheel.



Use the horn moderately and only in the following cases:

- immediate danger,
- when passing a cyclist or pedestrian,
- when approaching an area where there is no visibility.

TYRE UNDER-INFLATION DETECTION

System which automatically checks the pressure of the tyres while driving.



Sensors fitted in each valve trigger a warning in the event of malfunction (speed above 12 mph (20 km/h)).

i The tyre under-inflation detection system is an aid to driving which does not replace the need for the driver to be vigilant or to drive responsibly.

Flat tyre



This warning light is displayed on the instrument panel and/or a message appears on the multifunction display, accompanied by an audible signal, to locate the wheel concerned.

☞ Check the tyre pressures as soon as possible.

This check must be carried out when the tyres are cold.

Puncture



The **STOP** warning light comes on and/or this warning light is displayed on the instrument panel, accompanied by an audible signal and a message on the multifunction display locating the wheel concerned.

- ☞ Stop immediately, avoiding any sudden movement of the steering wheel and the brakes.
- ☞ Change the damaged wheel (punctured or very deflated tyre), and have the tyre pressure checked as soon as possible.

Sensor(s) not detected or faulty



This warning light is displayed on the instrument panel and/or a message appears on the multifunction display, accompanied by an audible signal, to locate the wheel or wheels which are not detected or to indicate a fault in the system. Contact a PEUGEOT dealer to replace the faulty sensor(s).



This message is also displayed when one of the wheels is away from the vehicle (being repaired) or when one or more wheels without a sensor are fitted.

The spare wheel is not fitted with a sensor.



All repairs and changing of tyres on a wheel fitted with this system must be carried out by a PEUGEOT dealer.

If, when changing a tyre, you install a wheel which is not detected by your vehicle (example: fitting of snow tyres), you must have the system reinitialised by a PEUGEOT dealer.



This system does not eliminate the need to have the tyre pressure checked regularly (refer to the "Identification features" paragraph) to ensure that the optimum dynamic performance of the vehicle is maintained and prevent premature wear of the tyres, particularly in arduous driving conditions (heavy load, high speed).

The tyre pressures must be checked cold, at least once a month. Remember to check the pressure of the spare wheel.

The tyre under-inflation detection system may experience temporary interference due to radioelectric emissions on a frequency close to that used by the system.

BRAKING ASSISTANCE SYSTEMS

Group of supplementary systems which help you to obtain optimum braking in complete safety in emergency situations:

- anti-lock braking system (ABS),
- electronic brake force distribution (EBFD),
- emergency braking assistance (EBA).

Anti-lock braking system and electronic brake force distribution

Linked systems which improve the stability and manoeuvrability of your vehicle when braking, in particular on poor or slippery surfaces.

Activation

The anti-lock braking system comes into operation automatically when there is a risk of wheel lock.

Normal operation of the ABS may make itself felt by slight vibration of the brake pedal.



When braking in an emergency, press very firmly without releasing the pressure.

Operating fault



If this warning lamp comes on, accompanied by an audible signal and a message on the multifunction screen, it indicates a malfunction of the anti-lock braking system which could result in loss of control of the vehicle when braking.



If this warning lamp comes on, together with the **STOP** and **ABS** warning lamps, accompanied by an audible signal and a message on the multifunction screen, it indicates a malfunction of the electronic brake force distribution which could result in loss of control of the vehicle when braking.

You MUST stop as soon as it is safe to do so.

In both cases, contact a PEUGEOT dealer.



When replacing wheels (tyres and rims), ensure that they conform to the manufacturer's recommendations.

Emergency braking assistance

System which, in an emergency, enables you to obtain the optimum braking pressure more quickly, thus reducing the stopping distance.

Activation

It is triggered by the speed at which the brake pedal is pressed.

The effect of this is a reduction in the resistance of the pedal and an increase in braking efficiency.



When braking in an emergency, press firmly without releasing the pressure.

TRAJECTORY CONTROL SYSTEMS

Anti-skid regulation (ASR) and electronic stability programme (ESP)

The anti-skid regulation (also known as Traction Control) optimises traction to prevent skidding of the wheels, by acting on the brakes of the driving wheels and on the engine.

The electronic stability programme acts on the brake of one or more wheels and on the engine to keep the vehicle on the trajectory required by the driver.

Activation

These systems are activated automatically each time the vehicle is started.

They come into operation in the event of a grip or trajectory problem.



This is indicated by flashing of this warning lamp on the instrument panel.

Deactivation

In exceptional conditions (starting a vehicle which is bogged down, stuck in snow, on soft ground...), it may be advisable to deactivate the ASR and ESP systems, so that the wheels can move freely and regain grip.



☞ Press the **"ESP OFF"** button, located in the centre of the dashboard.



If this warning lamp comes on in the instrument panel and the indicator lamp on the button comes on, this indicates that the ASR and ESP systems are deactivated.

Reactivation

These systems are reactivated automatically each time the ignition is switched back on or from 30 mph (50 km/h).

☞ Press the **"ESP OFF"** button again to reactivate them manually.

Operating fault



If this warning lamp comes on, accompanied by an audible signal and a message on the multi-function screen, this indicates a malfunction of these systems.

Have the systems checked by a PEUGEOT dealer.



The ESP/ASR systems offer exceptional safety in normal driving, but this should not encourage the driver to take extra risks or drive at high speed.


The correct functioning of these systems depends on observation of the manufacturer's recommendations regarding the wheels (tyres and rims), the braking components, the electronic components and the PEUGEOT assembly and operation procedures.

After an impact, have these systems checked by a PEUGEOT dealer.

ROLL-OVER BARS

System which protects all of the occupants restrained by their seat belt should the vehicle roll over.

The roll-over bars are incorporated in the back of the rear bench seat. Their presence is indicated by the words "Rollover Protection".



Activation

They are triggered simultaneously should the vehicle roll over.

Operating fault



If this warning light comes on on the instrument panel, accompanied by an audible signal and a message on the multifunction display, contact a PEUGEOT dealer to have the system checked.



In order to guarantee the correct operation and the deployment of the roll-over bars if roll-over is detected, the following conditions must be complied with:

- no accessory which is not recommended by PEUGEOT should be in contact with or fixed to the roll-over bars,
- no object should block or stop the movement of the roll-over bars,
- the area above the roll-over bars should be clear of any objects.

SEAT BELTS

Front seat belts

The front seat belts are fitted with a pretensioning and force limiting system.

This system improves safety in the front seats in the event of a front impact. Depending on the severity of the impact, the pretensioning system instantly tightens the seat belts against the body of the occupants.

The pretensioning seat belts are active when the ignition is on.

The force limiter reduces the pressure of the seat belt on the chest of the occupant, so increasing his protection.

Fastening



- ☞ Pull the strap, then insert the tongue in the buckle.
- ☞ Check that the seat belt is fastened correctly by pulling the strap.

Unfastening

- ☞ Press the red button on the buckle.
- ☞ Guide the seat belt as it rolls up.

Seat belt not fastened/unfastened warning light



When the ignition is switched on, this warning light comes on, either on the instrument panel or on the seat belt and passenger's front air bag warning lights display, if the driver and/or the front passenger has not fastened his seat belt.

From approximately 12 mph (20 km/h) this warning light flashes for two minutes accompanied by an audible signal of increasing volume. Once these two minutes have elapsed, this warning light remains on until the driver and/or the front passenger fastens his seat belt.

Seat belt not fastened/unfastened warning lights display



1. Front and/or rear seat belts not fastened/unfastened warning light.
2. Front left seat belt warning light.
3. Front right seat belt warning light.
4. Rear right seat belt warning light.
5. Rear left seat belt warning light.

The corresponding warning light 2 or 3 comes on in red on the seat belt and passenger's front air bag warning lights display if the seat belt is not fastened or is unfastened.

Rear seat belts

The rear seats are each fitted with a three-point inertia reel seat belt with force limiter.

Fastening

- ✎ Remove the strap from the guide **A** before use.
- ✎ Pull the strap, then insert the tongue in the buckle.
- ✎ Check that the seat belt is fastened correctly by pulling the strap.

Unfastening

- ✎ Press the red button on the buckle.
- ✎ Guide the seat belt as it rolls up.



In the "cabriolet" configuration, if the rear seats are not occupied, slide the straps in the guides **A** to prevent fluttering of the rear seat belts (leather seats only).

Seat belt unfastened warning light



This warning light comes on, either on the instrument panel or on the seat belt and passenger's front air bag warning lights display, when one or more rear passengers unfasten their seat belt.

From approximately 12 mph (20 km/h), this warning light flashes for two minutes accompanied by an audible signal of increasing volume. Once these two minutes have elapsed, this warning light remains on until the one or more rear passengers fasten their seat belt.

Seat belt unfastened warning lights display



When the ignition is switched on, with the engine running or the vehicle moving at a speed below approximately 12 mph (20 km/h), the corresponding warning lights **4** and **5** come on in red for approximately 30 seconds, if the seat belt is not fastened.

When the vehicle is moving at a speed of more than approximately 12 mph (20 km/h), the corresponding warning light **4** or **5** comes on in red, accompanied by an audible signal and a message on the multifunction display, if a rear passenger has unfastened his seat belt.



The driver must ensure that passengers use the seat belts correctly and that they are all restrained securely before setting off.

Wherever you are seated in the vehicle, always fasten your seat belt, even for short journeys.

Do not invert the seat belt buckles as they will not fulfil their role fully.

The seat belts are fitted with an inertia reel permitting automatic adjustment of the length of the strap to your size. The seat belt is stored automatically when not in use.

Before and after use, ensure that the seat belt is reeled in correctly.

The lower part of the strap must be positioned as low as possible on the pelvis.

The upper part must be positioned in the hollow of the shoulder.

The inertia reels are fitted with an automatic locking device which comes into operation in the event of a collision, emergency braking or if the vehicle rolls over. You can release the device by pulling rapidly on the strap and releasing it.

In order to be effective, a seat belt:

- must be tightened as close to the body as possible,
- must restrain one person of adult size only,
- must not bear any trace of cuts or fraying,
- must be pulled in front of you with a smooth movement, checking that it does not twist,
- must not be altered or modified to avoid altering its performance.

In accordance with current safety regulations, all repairs and checks must be carried out by a PEUGEOT dealer who guarantees that the work is carried out correctly.

Have your seat belts checked regularly by a PEUGEOT dealer and particularly if the straps show signs of damage.

Clean the seat belt straps with soapy water or a textile cleaning product, sold by PEUGEOT dealers.

After folding or moving a seat or rear bench seat, ensure that the seat belt is positioned and reeled in correctly.

Recommendations for children

Use a suitable child seat if the passenger is less than 12 years old or shorter than one and a half metres.

Never use the same seat belt to secure more than one person.

Never allow a child to travel on your lap.

Depending on the nature and seriousness of the impacts,

the pre-tensioning device may be triggered before and independently of the airbags. Triggering of the pre-tensioners is accompanied by a slight discharge of harmless smoke and a noise, due to the activation of the pyrotechnic cartridge incorporated in the system.

In all cases, the airbag warning lamp comes on.

Following an impact, have the seat belts system checked, and if necessary replaced, by a PEUGEOT dealer.

AIR BAGS

The air bags have been designed to maximise the safety of the occupants in the event of violent collisions. They supplement the action of the force-limiting seat belts.

In this case, the electronic detectors record and analyse the front and side impacts suffered in the impact detection zones:


- in the event of a serious impact, the air bags are deployed instantaneously and protect the occupants of the vehicle; immediately after the impact, the air bags deflate rapidly so that they do not hinder the visibility of the occupants or their possible exit from the vehicle,
- in the event of a minor impact or rear impact and in certain roll-over conditions, the air bags will not be deployed; the seat belt alone is sufficient to provide maximum protection in these situations.



The air bags do not operate when the ignition is off.

This equipment only operates once. If a second impact occurs (during the same or a subsequent accident), the air bag will not operate.

Impact detection zones



A. Front impact zone.

B. Side impact zone.



The deployment of one or more air bags is accompanied by a slight discharge of harmless smoke and a noise, due to the activation of the pyrotechnic cartridge incorporated in the system.


This smoke is not harmful, but sensitive individuals may experience some irritation.

The noise of the detonation may result in a slight loss of hearing for a short time.

Front air bags

System which protects the driver and front passenger in the event of a serious front impact in order to limit the risk of injury to the head and chest.

The driver's air bag is incorporated in the centre of the steering wheel; the front passenger's air bag is incorporated in the fascia above the glove box.



Activation


The air bags are triggered simultaneously, unless the passenger's front air bag is disarmed, in the event of a serious front impact applied to all or part of the front impact zone A, in the longitudinal centreline of the vehicle on a horizontal plane and directed from the front to the rear of the vehicle.

The front air bag inflates between the front occupant of the vehicle and the fascia to cushion his forward movement.

Deactivation

Only the passenger's front air bag can be disarmed:

- **with the ignition off**, insert the key in the passenger air bag disarming switch 1,
- turn it to the **"OFF"** position,
- then, remove the key keeping the switch in this position.



 According to version, this warning light comes on either on the instrument panel or on the seat belt and passenger's front air bag warning lights display when the ignition is on and until the air bag is re-armed.



To guarantee the safety of your child, it is imperative that the passenger's front air bag is disarmed when you install a "rear facing" child seat on the front passenger seat.

Otherwise, the child would risk being seriously injured or killed if the air bag were triggered.

Reactivation

When you remove the child seat, turn switch 1 to the **"ON"** position to re-arm the air bag and so guarantee the safety of your front passenger in the event of an impact.



With the ignition on, this warning light comes on on the seat belt and passenger's front air bag warning lights display for approximately one minute, if the passenger's front air bag is activated.

Operating fault



If this warning light comes on on the instrument panel, accompanied by an audible warning and a message on the multifunction display, contact a PEUGEOT dealer to have the system checked. The air bags may no longer be triggered in the event of a serious impact.



If this warning light flashes, contact a PEUGEOT dealer. The passenger's front air bag may no longer be triggered in the event of a serious impact.



If at least one of the two air bag warning lights come on continuously, do not install a child seat on the front passenger seat. Have the system checked by a PEUGEOT dealer.

Side air bags

System which protects the driver and front passenger in the event of a serious side impact in order to limit the risk of injury to the pelvis, chest and head.

The side air bags are incorporated on the door side:

- on the one hand, in the front seat back frame (chest-pelvis air bag),
- on the other hand, in the front head restraint (head air bag).




Activation

The side air bags are triggered unilaterally in the event of a serious side impact applied to all or part of the side impact zone **B**, perpendicular to the longitudinal centreline of the vehicle on a horizontal plane and directed from the outside towards the inside of the vehicle.

The side air bags inflate between the front occupant of the vehicle and the corresponding door trim pad.



Impact detection zones



A. Front impact zone.

B. Side impact zone.



In the event of a light impact or bump to the side of the vehicle or if the vehicle rolls over, the air bags may not be triggered.

In the event of a rear or front collision, the air bags are not triggered.

Operating fault



If this warning light on the instrument panel comes on, accompanied by an audible signal and a message on the multifunction display, contact a PEUGEOT dealer to have the system checked. The air bags may no longer be triggered in the event of a serious impact.



For the airbags to be fully effective, observe the following safety rules:

Sit in a normal upright position.

Wear a correctly adjusted seat belt.

Do not leave anything between the occupants and the airbags (a child, pet, object...). This could hamper the operation of the airbags or injure the occupants.

After an accident or if the vehicle has been stolen or broken into, have the airbag systems checked.

All work on the airbag system is strictly forbidden unless it is carried out by qualified personnel of the PEUGEOT network.

Even if all of the precautions mentioned are observed, a risk of injury or of minor burns to the head, chest or arms when an airbag is triggered cannot be ruled out. The bag inflates almost instantly (within a few milliseconds) then deflates within the same time discharging the hot gas via openings provided for this purpose.

Front airbags

Do not drive holding the steering wheel by its spokes or resting your hands on the centre part of the wheel.

Passengers must not place their feet on the dashboard.

If possible, do not smoke as deployment of the airbags can cause burns or the risk of injury from a cigarette or pipe.

Never remove or pierce the steering wheel or hit it violently.

Side air bags

Put approved covers only on the seats. These will not hinder inflation of the side air bags. Consult a PEUGEOT dealer.

Do not fix or glue anything to the seat backs. This could cause injury to the chest or arms if the side air bag is triggered.

Do not fix or glue anything to the front head restraints. This could cause injury to the head if the side air bag is triggered.

Do not sit with the upper part of the body any nearer to the door than necessary.

GENERAL POINTS RELATING TO CHILD SEATS

Although one of PEUGEOT's main criteria when designing your vehicle, the safety of your children also depends on you.

For maximum safety, please follow these precautions:

- in accordance with European regulations, **all children under the age of 12 or less than one and a half metres tall must travel in approved child seats suited to their weight**, on seats fitted with a seat belt or ISOFIX mountings*,
- **statistically, the safest seats in your vehicle for the transportation of children are the rear seats**,
- **a child weighing less than 9 kg must travel in the "rearwards-facing" position both in the front and in the rear.**

i **PEUGEOT recommends** that children should travel in the **rear seats** of your vehicle:

- **"rearwards-facing"** up to the age of 2,
- **"forwards-facing"** over the age of 2.

INSTALLING A CHILD SEAT USING A THREE POINT SEAT BELT

"Rearwards-facing"

When a "rearwards-facing" child seat is installed on the **front passenger seat**, it is essential that the passenger airbag is deactivated. Otherwise, **the child would risk being seriously injured or killed if the airbag were to inflate.**



"Forwards-facing"

When a "forwards-facing" child seat is installed on the **front passenger seat**, adjust the vehicle's seat to the intermediate longitudinal position with the seat back upright and leave the passenger airbag activated.




Intermediate longitudinal position



* The rules for transporting children are specific to each country. Refer to the current legislation in your country.



Passenger air bag OFF



CHILD SEATS RECOMMENDED BY PEUGEOT

PEUGEOT offers a complete range of recommended child seats which are secured using a **three point seat belt**:

Group 0: from birth to 10 kg
Group 0+: from birth to 13 kg



L1
"RÖMER
Baby-Safe Plus"
 Installed in the
 rearwards-facing
 position.

Groups 1, 2 and 3: from 9 to 36 kg



L2
"KIDDY Life"
 The use of the
 restraining cushion
 is compulsory for
 the transportation
 of young children
 (from 9 to 18 kg).

Groups 2 and 3: from 15 to 36 kg




L3
"RECARO Start".



L4
"KLIPPAN Optima"
 From the age
 of 6 years
 (approximately
 22 kg), the booster
 is used on its own.



Passenger air bag OFF



CHILD SEATS RECOMMENDED BY PEUGEOT

PEUGEOT offers a complete range of recommended child seats which are secured using a **three point seat belt**:

Group 0: from birth to 10 kg
Group 0+: from birth to 13 kg



L1
"RÖMER
Baby-Safe Plus"
 Installed in the
 rearwards-facing
 position.

Groups 1, 2 and 3: from 9 to 36 kg



L2
"KIDDY Life"
 The use of the
 restraining cushion
 is compulsory for
 the transportation
 of young children
 (from 9 to 18 kg).

Groups 2 and 3: from 15 to 36 kg



L3
"RECARO Start".



L4
"KLIPPAN Optima"
 From the age
 of 6 years
 (approximately
 22 kg), the booster
 is used on its own.

LOCATION OF CHILD SEATS SECURED USING THE SEAT BELT

In accordance with European regulations, this table indicates the options for the installation of child seats secured using the seat belt and universally approved (a) in relation to the weight of the child and the seat in the vehicle.

Seat		Weight of the child/indicative age			
		Less than 13 kg (groups 0 (b) and 0+) Up to 1 year approx	From 9 to 18 kg (group 1) From 1 to 3 years approx	From 15 to 25 kg (group 2) From 3 to 6 years approx	From 22 to 36 kg (group 3) From 6 to 10 years approx
Front passenger seat (c)		U (R)	U (R)	U (R)	U (R)
Rear side seats (d)		U	U	U	U

(a) Universal child seat: child seat which can be installed in all vehicles using the seat belt.

(b) Group 0: from birth to 10 kg. Infant car seats and "car" cots cannot be installed on the front passenger seat.

(c) Consult the legislation in force in your country before installing your child on this seat.

(d) To install a child seat, move the front seat forward, then put the seat back in the upright position to leave enough space for the child seat and the child's legs. The front seat can be moved further forward than the intermediate longitudinal position.

U: seat suitable for the installation of a child seat secured using the seat belt and universally approved "rear facing" and/or "forward facing".

U (R): identical to **U**, with the vehicle's seat adjusted to its highest position.



ADVICE ON CHILD SEATS

The incorrect installation of a child seat in a vehicle compromises the child's protection in the event of an accident.

When installing a child seat using the seat belt, ensure that the seat belt is tightened correctly on the child seat and that it secures the child seat firmly on the vehicle's seat.

Remember to fasten the seat belts or the child seat harnesses **keeping the slack** in relation to the child's body **to a minimum**, even for short journeys.

For optimum installation of the "forward facing" child seat, ensure that the back of the child seat is in contact with the back of the vehicle's seat and that the head restraint does not cause any discomfort.

Children under the age of 10 must not travel in the "forward facing" position on the front passenger seat, unless the rear seats are already occupied by other children, cannot be used or are absent.

Disarm the passenger air bag when a "rear facing" child seat is installed on the front seat. Otherwise, the child would risk being seriously injured or killed if the air bag were to inflate.

Do not use the passenger's "AIRWAVE" system if a child seat is installed on the front seat.

Installing a booster seat

The chest part of the seat belt must be positioned on the child's shoulder without touching the neck.

Ensure that the lap part of the seat belt passes correctly over the child's thighs.

PEUGEOT recommends the use of a booster seat which has a back, fitted with a seat belt guide at shoulder level.


As a safety precaution, do not leave:

- one or more children alone and unsupervised in a vehicle,
- a child or an animal in a vehicle which is exposed to the sun, with the windows closed,
- the keys within reach of children inside the vehicle.

"ISOFIX" MOUNTINGS

Your vehicle has been approved in accordance with the **new ISOFIX regulation**.

The seats, represented below, are fitted with regulation ISOFIX mountings:



These are two rings **A** for each seat, located between the seat back and seat cushion of the vehicle's seat.

The ISOFIX child seats are fitted with two locks which are secured easily on these rings **A**.



This ISOFIX mounting system guarantees reliable, safe and fast fitting of the child seat in your vehicle.



The incorrect installation of a child seat in a vehicle compromises the protection of the child in the event of a collision.



To find out which ISOFIX child seats can be installed in your vehicle, consult the summary table for the location of the ISOFIX child seats.

ISOFIX CHILD SEAT RECOMMENDED BY PEUGEOT AND APPROVED FOR YOUR VEHICLE**RÖMER Duo Plus ISOFIX**
(size category **B1**)**Group 1: from 9 to 18 kg**

Installed in the forwards facing position only.

Secured without the upper strap.

Three child seat body angles: sitting, reclining and lying positions.

Adjust the vehicle's front seat so that the child's feet do not touch the seat back.



This child seat can also be used on seats which are not fitted with ISOFIX mountings. In this case, it is essential that it is secured to the vehicle's seat by means of the seat belt.

Follow the instructions for fitting the child seat indicated in the seat manufacturer's installation guide.

ISOFIX CHILD SEAT RECOMMENDED BY PEUGEOT AND APPROVED FOR YOUR VEHICLE**RÖMER Duo Plus ISOFIX**
(size category **B1**)**Group 1: from 9 to 18 kg**

Installed in the forwards facing position only.

Secured without the upper strap.

Three child seat body angles: sitting, reclining and lying positions.

Adjust the vehicle's front seat so that the child's feet do not touch the seat back.



This child seat can also be used on seats which are not fitted with ISOFIX mountings. In this case, it is essential that it is secured to the vehicle's seat by means of the seat belt.

Follow the instructions for fitting the child seat indicated in the seat manufacturer's installation guide.

SUMMARY TABLE FOR THE LOCATION OF ISOFIX CHILD SEATS

In accordance with European Regulations, this table indicates the options for installing ISOFIX child seats on seats in the vehicle fitted with ISOFIX mountings.

In the case of universal and semi-universal ISOFIX child seats, the ISOFIX size category, determined by a letter from **A** to **G**, is indicated on the child seat next to the ISOFIX logo.

	Weight of the child/indicative age									
	Less than 10 kg (group 0) Up to approx. 6 months		Less than 10 kg (group 0) Less than 13 kg (group 0+) Up to approx. 1 year			From 9 to 18 kg (group 1) From approx. 1 to 3 years				
Type of ISOFIX child seat	Infant car seat*		"rear facing"			"rear facing"		"forward facing"		
ISOFIX size category	F	G	C	D	E	C	D	A	B	B1
ISOFIX child seats universal and semi-universal which can be installed on the rear side seats	X		IL-SU			IL-SU		IL-SU		

IL-SU: seat suitable for the installation of an Isofix **S**emi-**U**niversal seat either:

- "rear facing" fitted with a support,
- "forward facing" fitted with a support.

X: seat which is not suitable for the installation of an ISOFIX seat of the size category indicated.

* Infant car seats and "car" cots cannot be installed on the front passenger seat.

PARKING BRAKE

Mechanical brake to hold the vehicle when stationary.



Applying

- ☞ Pull the parking brake to immobilise your vehicle.

Releasing

- ☞ Pull on the handle and press the button **A** to release the parking brake.



When the vehicle is being driven, if this warning lamp and the **STOP** warning lamp come on, accompanied by an audible signal and a message on the multi-function screen, this indicates that the parking brake is still on or has not been properly released.




When parking on a slope, direct your wheels against the pavement, pull the parking brake on and engage a gear.

6-SPEED MANUAL GEARBOX

Engaging reverse gear

- ☞ Raise the ring under the knob and push the gear lever to the left then forwards.



Only engage reverse gear when the vehicle is stationary with the engine at idle.



As a safety precaution and to facilitate starting of the engine:

- always select neutral,
- press the clutch pedal.


"PORSCHE TIPTRONIC SYSTEM" AUTOMATIC GEARBOX

Four or six speed automatic gearbox which offers a choice between the comfort of fully automatic operation, enhanced by sport and snow programmes, or manual gear changing.

Therefore, four driving modes are offered:


- **automatic** operation for electronic management of the gears by the gearbox,
- **sport** programme for a more dynamic style of driving,
- **snow** programme to improve driving when traction is poor,
- **manual** operation for sequential changing of the gears by the driver.

Gear selection gate




1. Gear lever.
2. Button "S" (**sport**).
3. Button "❄" (**snow**).

Gear lever



- P.** Park.
- Immobilisation of the vehicle, hand-brake on or off.
 - Starting the engine.
- R.** Reverse.
- Reversing manoeuvres, vehicle stationary, engine at idle.
- N.** Neutral.
- Immobilisation of the vehicle, hand-brake on.
 - Starting the engine.
- D.** Automatic operation.
- M.+/-** Manual operation with sequential changing of the four or six gears.
- ☞ Press forwards to change up through the gears.
- or
- ☞ Press rearwards to change down through the gears.

Displays on the instrument panel



When you move the lever in the gate to select a position, the corresponding indicator light is displayed on the instrument panel.

- P.** Park
- R.** Reverse
- N.** Neutral
- D.** Drive (Automatic driving)
- S.** **Sport** programme
- ❄.** **Snow** programme
- 1 to 4.** Gear engaged during
- 1 to 6.** manual operation
- .** Invalid value during manual operation

Foot on brake



- ☞ Press the brake pedal when this indicator light flashes (e.g.: starting the engine).

Moving off

- ☞ Apply the handbrake.
- ☞ Select position **P** or **N**.
- ☞ Start the engine.

If this procedure is not followed, an audible signal is heard, accompanied by a message on the multifunction display.

- ☞ With the engine running, press the brake pedal.
- ☞ Release the handbrake.
- ☞ Select position **R**, **D** or **M**.
- ☞ Gradually release the brake pedal.

The vehicle moves off immediately.

i If position **N** is engaged inadvertently while driving, allow the engine to return to idle then engage position **D** to accelerate.

! When the engine is running at idle, with the brakes released, if position **R**, **D** or **M** is selected, the vehicle moves even without the accelerator being pressed.

When the engine is running, never leave children in the vehicle without supervision.

When carrying out maintenance with the engine running, apply the handbrake and select position **P**.

Automatic operation

- ☞ Select position **D** for **automatic** changing of the four or six gears.

The gearbox then operates in auto-adaptive mode, without any intervention on the part of the driver. It continuously selects the most suitable gear according to the style of driving, the profile of the road and the load in the vehicle.

For maximum acceleration without touching the lever, press the accelerator pedal down fully (kick down). The gearbox changes down automatically or maintains the gear selected until the maximum engine speed is reached.

On braking, the gearbox changes down automatically to provide efficient engine braking.

If you release the accelerator sharply, the gearbox will not change to a higher gear for safety reasons.



Never select position **N** while the vehicle is moving.

Never select positions **P** or **R** unless the vehicle is completely stationary.

Sport and snow programmes

These two special programmes supplement the automatic operation in very specific conditions of use.

Sport programme "S"

- ☞ Press button **"S"**, after starting the engine.

The gearbox automatically favours a dynamic style of driving.



S appears on the instrument panel.

Snow programme "❄"

- ☞ Press button **"❄"**, after starting the engine.

The gearbox adapts to driving on slippery roads.

This programme improves starting and drive when traction is poor.



❄ appears on the instrument panel.

Return to automatic operation

- ☞ At any time, press the button selected again to quit the programme engaged and return to auto-adaptive mode.

Manual operation

- ☞ Select position **M** for **sequential** changing of the four or six gears.
- ☞ Push the lever towards the **+** sign to change up a gear.
- ☞ Pull the lever towards the **-** sign to change down a gear.

It is only possible to change from one gear to another if the vehicle speed and engine speed permit; otherwise, the gearbox will operate temporarily in automatic mode.



D disappears and the gears engaged appear in succession on the instrument panel.

In the event of under-revving or over-revving, the gear selected flashes for a few seconds, then the actual gear engaged is displayed.

It is possible to change from position **D** (automatic) to position **M** (manual) at any time.

When the vehicle is stationary or moving very slowly, the gearbox selects gear **M1** automatically.

The sport and snow programmes do not operate in manual mode.

Invalid value during manual operation



This symbol is displayed if a gear is not engaged correctly (selector between two positions).

Stopping the vehicle

Before switching off the engine, you can engage position **P** or **N** to place the gearbox in neutral.

In both cases, apply the handbrake to immobilise the vehicle.



If the lever is not in position **P**, when the driver's door is opened or approximately 45 seconds after the ignition is switched off, an audible signal is heard and a message appears.

- ☞ Return the lever to position **P**; the audible signal stops and the message disappears.

Operating fault



When the ignition is on, the lighting of this warning light, accompanied by an audible signal and a message on the multi-function display, indicates a gearbox malfunction.

In this case, the gearbox switches to emergency mode and is locked in 3rd gear. You may feel a substantial knock when changing from **P** to **R** and from **N** to **R**. This will not cause any damage to the gearbox.

Do not exceed 60 mph (100 km/h), local speed restrictions permitting.

Have it checked by a PEUGEOT dealer.

This warning light may also come on if a door is opened.



If the battery is flat and the lever is in position **P**, it will not be possible to change to another position.

Above all, do not force the lever as this could damage the gearbox.

SPEED LIMITER

System which prevents the vehicle from exceeding the speed programmed by the driver.

When the programmed speed limit is reached, pressing the accelerator pedal no longer has any effect.

The speed limiter is **switched on** manually: it requires a programmed speed of at least 20 mph (30 km/h).

The speed limiter is **switched off** by manual operation of the control.

The programmed speed can be exceeded temporarily by pressing the accelerator firmly.

To return to the programmed speed, simply slow down to a speed below the programmed speed.

The programmed speed remains in the memory when the ignition is switched off.


Steering wheel controls



The controls of this system are grouped together on stalk **A**.

1. Speed limiter mode selection dial
2. Value decrease button
3. Value increase button
4. Speed limiter on/off button

Displays on the instrument panel



The programmed information is grouped together on the instrument panel display.

5. Speed limiter on/off indication
6. Speed limiter mode selection indication
7. Programmed speed value



The speed limiter cannot, in any circumstances, replace the need to respect speed limits, nor can it replace the need for vigilance and responsibility on the part of the driver.



Programming

- ☞ Turn dial **1** to the **"LIMIT"** position: the speed limiter mode is selected but is not switched on (OFF).

You do not have to switch the speed limiter on in order to set the speed.

- ☞ Set the speed value by pressing button **2** or **3** (e.g.: 55 mph (90 km/h)).

You can then change the programmed speed using buttons **2** and **3**:

- by + or - 1 mph (km/h) = short press,
- by + or - 5 mph (km/h) = long press,
- in steps of + or - 5 mph (km/h) = maintained press.

- ☞ Switch the speed limiter on by pressing button **4**.
- ☞ Switch the speed limiter off by pressing button **4**: the display confirms that it has been switched off (OFF).
- ☞ Switch the speed limiter back on by pressing button **4** again.

Exceeding the programmed speed

Pressing the accelerator pedal to exceed the programmed speed will not have any effect unless you press the pedal **firmly** past the **point of resistance**.

The speed limiter is deactivated temporarily and the programmed speed, which is still displayed, flashes.

Returning to the programmed speed, by means of intentional or unintentional deceleration of the vehicle, automatically cancels the flashing of the programmed speed.

Return to normal driving

- ☞ Turn dial **1** to the **"0"** position: the speed limiter mode is deselected. The display returns to the distance recorder.



Operating fault

In the event of a speed limiter malfunction, the speed is cleared resulting in flashing of the dashes.

Have the system checked by a PEUGEOT dealer.



On a steep descent or in the event of sharp acceleration, the speed limiter will not be able to prevent the vehicle from exceeding the programmed speed.

To avoid any risk of jamming of the pedals:

- ensure that the mat is positioned correctly,
- do not fit one mat on top of another.

CRUISE CONTROL

System which automatically maintains the speed of the vehicle at the value programmed by the driver, without any action on the accelerator pedal.

The cruise control is **switched on** manually: it requires a minimum vehicle speed of 25 mph (40 km/h) and the engaging:

- of fourth gear on the manual gearbox,
- of second gear on the automatic gearbox, in sequential driving mode,
- of position **D** on the automatic gearbox.

The cruise control is **switched off** manually or by pressing the brake or clutch pedal or on triggering of the ESP system for safety reasons.

It is possible to exceed the programmed speed temporarily by pressing the accelerator pedal.

To return to the programmed speed, simply release the accelerator pedal.

Switching off the ignition cancels any programmed speed value.

Steering wheel controls



The controls of this system are grouped together on lever **A**.

1. Cruise control mode selection dial
2. Speed programming/value decrease button
3. Speed programming/value increase button
4. Cruise control off/resume button



The cruise control cannot, in any circumstances, replace the need to respect speed limits, nor can it replace the need for vigilance and responsibility on the part of the driver.

You are advised to keep your feet near the pedals at all times.

Displays on the instrument panel



The programmed information is grouped together on the instrument panel display.

5. Cruise control off/resume indication
6. Cruise control mode selection indication
7. Programmed speed value



Programming

☞ Turn dial **1** to the **"CRUISE"** position: the cruise control mode is selected but is not switched on (OFF).

☞ Set the programmed speed by accelerating to the required speed, then press button **2** or **3** (e.g.: 70 mph (110 km/h)).

You can then change the programmed speed using buttons **2** and **3**:

- by + or - 1 mph (km/h) = short press,
- by + or - 5 mph (km/h) = long press,
- in steps of + or - 5 mph (km/h) = maintained press.

☞ Switch off the cruise control by pressing button **4**: the display confirms that it has been switched off (OFF).

☞ Switch the cruise control back on by pressing button **4** again.

Exceeding the programmed speed

Intentional or unintentional exceeding of the programmed speed results in flashing of this speed on the display.

Return to the programmed speed, by means of intentional or unintentional deceleration of the vehicle, automatically cancels the flashing of the speed.

Return to normal driving

☞ Turn dial **1** to the **"0"** position: the cruise control mode is deselected. The display returns to the distance recorder.



Operating fault

In the event of a cruise control malfunction, the speed is cleared resulting in flashing of the dashes.

Have it checked by a PEUGEOT dealer.



When the cruise control is switched on, be careful if you maintain the pressure on one of the programmed speed changing buttons: this may result in a very rapid change in the speed of your vehicle.

Do not use the cruise control on slippery roads or in heavy traffic.

On a steep descent, the cruise control will not be able to prevent the vehicle from exceeding the programmed speed.

To avoid any risk of jamming of the pedals:

- ensure that the mat is positioned correctly,
- never fit one mat on top of another.

VISUAL AND AUDIBLE FRONT AND/OR REAR PARKING ASSISTANCE

System consisting of four proximity sensors, installed in the front and/or rear bumper.



It detects any obstacle (person, vehicle, tree, barrier...) located behind the vehicle, however, it will not be able to detect obstacles located immediately below the bumper.



An object, such as a stake, a roadworks cone or any other similar object may be detected at the start of the manoeuvre but may no longer be detected when the vehicle moves nearer to it.

The parking assistance is **switched on**:

- by engaging reverse gear,
- at a speed below 6 mph (10 km/h) in forward gear.

This is accompanied by an audible signal and/or displaying of the vehicle on the multifunction screen.



The proximity information is indicated by:

- an audible signal which becomes more rapid as the vehicle approaches the obstacle,
- a diagram on the multifunction screen, with blocks which move closer to the vehicle.

The obstacle is located in relation to the emission of the audible signal by the speakers; front or rear and right or left.

When the distance between the vehicle and the obstacle is less than approximately thirty centimetres, the audible signal becomes continuous and/or the "Danger" symbol appears, depending on the multifunction screen version.

The parking assistance is **switched off**:

- when you exit reverse gear,
- when the speed is higher than 6 mph (10 km/h) in forward gear,
- when the vehicle has been stationary for more than three seconds in forward gear.



The parking assistance system cannot, in any circumstances, replace the need for vigilance and responsibility on the part of the driver.

Deactivation



- Press button **A**, the warning lamp comes on, the system is fully deactivated.

i The system will be deactivated automatically when a trailer is being towed or when a bicycle carrier is fitted (vehicle fitted with a towbar or bicycle carrier recommended by PEUGEOT).

Reactivation

- Press button **A** again, the warning lamp switches off, the system is re-activated.

Operating fault



If an operating fault occurs, this warning lamp is displayed on the instrument panel and/or a message appears on the multi-function screen, accompanied by an audible signal (short beep), when reverse gear is engaged.

Consult a PEUGEOT dealer.



In bad weather or in winter, ensure that the sensors are not covered with mud, ice or snow. When reverse gear is engaged, an audible signal (long beep) indicates that the sensors may be dirty.


When the vehicle is being driven at a speed below approximately 6 mph (10 km/h), certain sources of noise (motorcycles, lorries, pneumatic drills, ...) may trigger the reversing audible signal.

BONNET

Protects the components of the engine and provides access for checking levels.

Opening

- ☞ Open the front left door.
- ☞ Pull the interior control **A**, located at the bottom of the door frame.
- ☞ Push the exterior control **B** to the left and raise the bonnet.



- ☞ Unclip the strut **C** from its housing.
- ☞ Fix the strut in the notch to hold the bonnet open.



The location of the interior control prevents opening of the bonnet while the front left door is closed.

Closing

- ☞ Take the strut out of the support notch.
- ☞ Clip the strut in its housing.
- ☞ Lower the bonnet and release it at the end of its travel.
- ☞ Pull on the bonnet to check that it is secured correctly.

RUNNING OUT OF FUEL (DIESEL)

If your vehicle is fitted with an HDI engine, the fuel circuit must be reprimed if you run out of fuel.

This system consists of a repriming pump, a transparent pipe and a degas screw under the bonnet (refer to the corresponding graphic).

1.6 litre Turbo HDI 16V engine

- ☞ Fill the fuel tank with at least five litres of diesel.
- ☞ Open the bonnet.
- ☞ Unclip the style cover to gain access to the repriming pump.
- ☞ Squeeze and release the repriming pump until fuel appears in the transparent pipe with the green connector.
- ☞ Operate the starter until the engine starts.
- ☞ Put the style cover back in position and clip it in place.
- ☞ Close the bonnet.



If the engine does not start at the first attempt, do not try again. Operate the repriming pump again, then the starter.

2 litre Turbo HDI 16V engine

- ☞ Fill the fuel tank with at least five litres of diesel.
- ☞ Open the bonnet.
- ☞ Unclip the style cover to gain access to the repriming pump.
- ☞ Slacken the degas screw.
- ☞ Squeeze and release the repriming pump until fuel appears in the transparent pipe with the green connector.
- ☞ Retighten the degas screw.
- ☞ Operate the starter until the engine starts.
- ☞ Put the style cover back in position and clip it in place.
- ☞ Close the bonnet.



If the engine does not start at the first attempt, do not try again. Operate the repriming pump again, then the starter.



PETROL ENGINES

They allow you access for checking the level of the various fluids and for replacing certain components.

- | | | |
|--|---------------------------|---------------------------|
| 1. Power steering reservoir. | 4. Brake fluid reservoir. | 8. Dipstick. |
| 2. Screenwash and headlamp wash reservoir. | 5. Battery/Fuses. | 9. Engine oil filler cap. |
| 3. Coolant reservoir. | 6. Fuse box. | |
| | 7. Air filter*. | |

* According to engine.



DIESEL ENGINES

They allow you access for checking the level of the various fluids, for replacing certain components and for repriming the fuel.

- | | | |
|--|---------------------------|---------------------------|
| 1. Power steering reservoir. | 4. Brake fluid reservoir. | 8. Dipstick. |
| 2. Screenwash and headlamp wash reservoir. | 5. Battery/Fuses. | 9. Engine oil filler cap. |
| 3. Coolant reservoir. | 6. Fuse box. | 10. Repriming pump*. |
| | 7. Air filter*. | 11. Degas screw*. |

* According to engine.

CHECKING LEVELS

Check all of these levels regularly and top them up if necessary, unless otherwise indicated.

If a level drops significantly, have the corresponding circuit checked by a PEUGEOT dealer.

Oil level



The reading will only be correct if the vehicle is on level ground and the engine has been off for more than 15 minutes.

The check is carried out either when the ignition is switched on using the oil level indicator on the instrument panel, or using the dipstick.

Between two oil changes, the consumption should not exceed 0.5 litre per 600 miles (1.000 km).

Draining the engine

Refer to the servicing booklet for details of the interval for this operation.

In order to maintain the reliability of the engine and emission control system, the use of additives in the engine oil is prohibited.

Oil specification

The oil must correspond to your engine and conform to the manufacturer's recommendations.

Brake fluid level



The brake fluid level should be close to the "MAX" mark. If it is not, check the brake pad wear.

Draining the circuit

Refer to the servicing booklet for details of the interval for this operation.

Fluid specification

The brake fluid must conform to the manufacturer's recommendations and fulfil the DOT4 standards.

Power steering fluid level



The power steering fluid level should be close to the "MAX" mark. Unscrew the cap, with the engine cold, to check the level.

Coolant level



The coolant level should be close to the "MAX" mark but should never exceed it.

When the engine is warm, the temperature of the coolant is regulated by the fan. This can operate with the ignition off.

On vehicles which are fitted with a particle emission filter, the fan may operate after the vehicle has been switched off, even if the engine is cold.

In addition, as the cooling system is pressurised, wait at least one hour after switching off the engine before carrying out any work.

To avoid any risk of scalding, unscrew the cap by two turns to allow the pressure to drop. When the pressure has dropped, remove the cap and top up the level.

Draining the circuit

The coolant does not have to be changed.

Fluid specification

The coolant must conform to the manufacturer's recommendations.

Screenwash and headlamp wash fluid



In the case of vehicles fitted with headlamp washers, the minimum level of this fluid is indicated by an audible signal and a message on the multi-function display.

Top up the level when you stop the vehicle.

Fluid specification

For optimum cleaning and to avoid freezing, this fluid must not be topped up or replaced with water.

Diesel additive level (Diesel engine with particle emission filter)

A low additive level is indicated by lighting of the service warning lamp, accompanied by an audible warning and a message on the multifunction screen.

Topping up

This additive must be topped up by a PEUGEOT dealer without delay.

Used products



Avoid prolonged contact of used oil or fluids with the skin.
Most of these fluids are harmful to health or indeed very corrosive.



Do not discard used oil or fluids into sewers or onto the ground.
Take used oil to a PEUGEOT dealer (France) or an authorised waste disposal site.

CHECKS

Unless otherwise indicated, check these components in accordance with the Maintenance and Warranty Guide and according to your engine.

Otherwise, have them checked by a PEUGEOT dealer.

Battery



The battery does not require any maintenance.

However, check that the terminals are clean and correctly tightened, particularly in summer and winter.

When carrying out work on the battery, refer to the "Practical information" section for details of the precautions to be taken before disconnecting the battery and following its reconnection.

Air filter and passenger compartment filter



Refer to the Maintenance and Warranty Guide for details of the replacement intervals for these components.

Depending on the environment (e.g. dusty atmosphere) and the use of the vehicle (e.g. city driving), **replace them twice as often if necessary** (refer to the "Engines" paragraph).

A clogged cabin filter may have an adverse effect on the performance of the air conditioning system and generate undesirable odours.

Oil filter



Replace the oil filter each time the engine oil is changed.

Refer to the Maintenance and Warranty Guide for details of the replacement interval for this component.

Particle emission filter (Diesel)

It is imperative that the maintenance of the particle emission filter is carried out by a PEUGEOT dealer.



Following prolonged operation of the vehicle at very low speed or at idle, you may, in exceptional circumstances, notice the emission of water vapour at the exhaust on acceleration. This does not affect the behaviour of the vehicle or the environment.

Diesel additive level (Diesel engine with particle emission filter)

A low additive level is indicated by lighting of the service warning lamp, accompanied by an audible warning and a message on the multifunction screen.

Topping up

This additive must be topped up by a PEUGEOT dealer without delay.

Used products



Avoid prolonged contact of used oil or fluids with the skin.
Most of these fluids are harmful to health or indeed very corrosive.



Do not discard used oil or fluids into sewers or onto the ground.
Take used oil to a PEUGEOT dealer (France) or an authorised waste disposal site.

CHECKS

Unless otherwise indicated, check these components in accordance with the Maintenance and Warranty Guide and according to your engine.

Otherwise, have them checked by a PEUGEOT dealer.

Battery



The battery does not require any maintenance.

However, check that the terminals are clean and correctly tightened, particularly in summer and winter.

When carrying out work on the battery, refer to the "Practical information" section for details of the precautions to be taken before disconnecting the battery and following its reconnection.

Air filter and passenger compartment filter



Refer to the Maintenance and Warranty Guide for details of the replacement intervals for these components.

Depending on the environment (e.g. dusty atmosphere) and the use of the vehicle (e.g. city driving), **replace them twice as often if necessary** (refer to the "Engines" paragraph).

A clogged cabin filter may have an adverse effect on the performance of the air conditioning system and generate undesirable odours.

Oil filter



Replace the oil filter each time the engine oil is changed.

Refer to the Maintenance and Warranty Guide for details of the replacement interval for this component.

Particle emission filter (Diesel)

It is imperative that the maintenance of the particle emission filter is carried out by a PEUGEOT dealer.



Following prolonged operation of the vehicle at very low speed or at idle, you may, in exceptional circumstances, notice the emission of water vapour at the exhaust on acceleration. This does not affect the behaviour of the vehicle or the environment.

Manual gearbox



The gearbox does not require any maintenance (no oil change).

Refer to the Maintenance and Warranty Guide for the details of the level checking interval for this component.

Automatic gearbox



The gearbox does not require any maintenance (no oil change).

Refer to the Maintenance and Warranty Guide for details of the level checking interval for this component.

Brake pads



Brake wear depends on the style of driving, particularly in the case of vehicles used in town, over short distances. It may be necessary to have the condition of the brakes checked, even between vehicle services.

Unless there is a leak in the circuit, a drop in the brake fluid level indicates that the brake pads are worn.

Brake disc wear



For information relating to checking the brake disc wear, contact a PEUGEOT dealer.

Parking brake



If a loss of effectiveness of this system is noticed, the parking brake must be checked, even between two services.

This system must be checked by a PEUGEOT dealer.



Only use products recommended by PEUGEOT or products of equivalent quality and specifications.

In order to optimise the operation of units as important as the braking system, PEUGEOT selects and offers very specific products.

To avoid damaging the electrical units, the use of a high pressure washer in the engine compartment is strictly **prohibited**.

TEMPORARY TYRE REPAIR KIT

Complete system consisting of a compressor and a bottle of filling product which permits **temporary repair** of the tyre so that you can drive to the nearest garage.



The kit is located in the boot under the floor. It is installed in the tool box, located under the storage box.



This repair kit is available from PEUGEOT dealers.

It is designed to repair holes of a maximum diameter of 6 mm, located exclusively on the tyre tread or shoulder. Avoid removing any foreign bodies which have penetrated the tyre.

Using the kit

- ✎ Switch off the ignition.
- ✎ Tick the wheel to be repaired on the speed limitation sticker enclosed then affix the sticker to the vehicle's steering wheel to remind you that a wheel is in temporary use.
- ✎ Clip the bottle 1 on the compressor 2.
- ✎ Check that the switch A is tilted to position "0".
- ✎ Connect the pipe of the bottle 1 to the valve of the tyre to be repaired.
- ✎ Unwind the pipe of the compressor 2 fully, then connect it to the bottle.
- ✎ Connect the compressor's electric plug to the vehicle's 12 V socket.
- ✎ Start the vehicle and leave the engine running.




- Switch on the compressor by tilting the switch **A** to position "1" until the tyre pressure reaches 2.0 bars.



If this pressure has not been reached after approximately five to ten minutes, the tyre cannot be repaired; contact a PEUGEOT dealer to have your vehicle repaired.


- Remove the compressor and store the bottle in the plastic bag, supplied in the kit, to avoid staining your vehicle with traces of fluid.
- Drive immediately for approximately two miles (three kilometres), at reduced speed (between 10 and 35 mph [20 and 60 km/h]), to fill the puncture.
- Stop to check the repair and the pressure.



- Connect the compressor pipe directly to the valve of the repaired wheel.



- ☞ Connect the compressor's electric plug to the vehicle's 12 V socket again.
- ☞ Start the vehicle again and leave the engine running.



- ☞ Adjust the pressure using the compressor (to inflate: switch **A** in position "1"; to deflate: switch **A** in position "0" and press button **B**), in accordance with the vehicle's tyre pressure label (located on the door aperture on the driver's side), then remember to check that the leak is filled correctly (no further loss of pressure after several miles [kilometres]).
- ☞ Remove the compressor, then store the whole kit.
- ☞ Drive at reduced speed (50 mph [80 km/h] max) for no more than approximately 125 miles (200 km).
- ☞ Visit a PEUGEOT dealer as soon as possible to have the tyre repaired or replaced by a technician.



Take care, the bottle of fluid contains ethylene-glycol. This product is harmful if swallowed and causes irritation to the eyes. Keep it out of reach of children.

The expiry date of the fluid is indicated on the base of the bottle.

The bottle is designed for a single use; even if only partly used, it must be replaced.

After use, do not discard the bottle into the environment, take it to a PEUGEOT dealer or to an organisation responsible for its collection.

Do not forget to obtain a new bottle of filling product, available from PEUGEOT dealers.



If the vehicle is fitted with tyre under-inflation detection, the tyre under-inflation warning light will remain on after the wheel has been repaired until the system is reinitialised by a PEUGEOT dealer.

CHANGING A WHEEL

Procedure for changing a faulty wheel for the spare wheel using the tools provided with the vehicle.

Access to the tools



The tools are installed in the boot under the floor.

To gain access to them:

- ☞ change to the "coupé" configuration,
- ☞ open the boot,
- ☞ raise the floor,
- ☞ secure it by hooking its handle on the boot seal,
- ☞ unclip and remove the box containing the tools.

List of tools



All of these tools are specific to your vehicle. Do not use them for other purposes.

1. Wheelbrace.
Permits removal of the wheel trim and removal of the wheel fixing bolts.
2. Jack with integral handle.
Permits raising of the vehicle.
3. "Bolt cover" tool.
Permits removal of the bolt protectors (covers) on alloy wheels.
4. Centring guide.
Permits the refitting of an alloy wheel on the hub.

5. Socket for the anti-theft bolts (located in the glove box).
Permits adaptation of the wheel-brace to the special "anti-theft" bolts.

Other accessories



6. Removable towing eye.
Refer to the paragraph "Towing the vehicle".



Wheel with trim

When removing the wheel, detach the trim first using the wheelbrace 1 pulling at the valve passage hole.

When refitting the wheel, refit the trim starting by placing its notch facing the valve and press around its edge with the palm of your hand.

Access to the spare wheel



The spare wheel is installed in the boot under the floor.

According to country, the spare wheel may be steel or alloy.

To gain access to it, refer to the paragraph "Access to the tools" on the previous page.



Fixing the steel spare wheel

If your vehicle is fitted with alloy wheels, it is normal to notice, when tightening the bolts on fitting, that the washers do not come into contact with the steel spare wheel. The wheel is secured by the conical contact of each bolt.

Taking out the wheel

- ✎ Unscrew the yellow central bolt.
- ✎ Raise the spare wheel towards you from the rear.
- ✎ Take the wheel out of the boot.




Putting the wheel back in place

- ✎ Put the wheel back in its housing.
- ✎ Unscrew the yellow central bolt by a few turns then put it in place in the centre of the wheel.
- ✎ Tighten fully until the central bolt clicks to retain the wheel correctly.



- ✎ Put the box back in place in the centre of the wheel and clip it.



Tyre under-inflation detection

The spare wheel is not fitted with a sensor. The punctured wheel must be repaired by a PEUGEOT dealer.

Removing the wheel



Parking the vehicle

Immobilise the vehicle where it does not block traffic: the ground must be level, stable and non-slippery ground.

Apply the handbrake, switch off the ignition and engage first gear* to lock the wheels.

If necessary, place a chock under the wheel diagonally opposite the wheel to be changed.

It is imperative that you ensure that the occupants get out of the vehicle and wait where they are safe.

Never go underneath a vehicle raised using a jack; use an axle stand.

List of operations

- ☞ Remove the chromed bolt cover from each of the bolts using the tool 3.
- ☞ Fit the anti-theft socket 5 on the wheelbrace 1 to unlock the anti-theft bolt.
- ☞ Unlock the other bolts using the wheelbrace 1 only.
- ☞ Place the jack 2 in contact with one of the two front **A** or rear **B** locations provided on the underframe, whichever is closest to the wheel to be changed.
- ☞ Extend the jack 2 until its base plate is in contact with the ground. Ensure that the centreline of the jack base plate is directly below the location **A** or **B** used.
- ☞ Raise the vehicle until there is sufficient space between the wheel and the ground to admit the spare (not punctured) wheel easily.
- ☞ Remove the bolts and store them in a clean place.
- ☞ Remove the wheel.

* position **P** for the automatic gearbox.



Fitting the wheel



List of operations

- ☞ Put the wheel in place on the hub using the centring guide 4.
- ☞ Screw in the bolts by hand to the stop.
- ☞ Pre-tighten the anti-theft bolt using the wheelbrace 1 fitted with the anti-theft socket 5.
- ☞ Pre-tighten the other bolts using the wheelbrace 1 only.

- ☞ Lower the vehicle fully.
- ☞ Fold the jack 2 and detach it.



After changing a wheel

To store the punctured wheel in the boot correctly, first remove the central cover.

Have the tightening of the bolts and the pressure of the spare wheel checked by a PEUGEOT dealer without delay.

Have the punctured wheel repaired without delay and replace it on the vehicle as soon as possible.

When the spare wheel is different from the other wheels, we strongly recommend that you drive with particular care.

- ☞ Lock the anti-theft bolt using the wheelbrace 1 fitted with the anti-theft socket 5.
- ☞ Lock the other bolts using the wheelbrace 1 only.
- ☞ Refit the chromed bolt covers on each of the bolts.
- ☞ Store the tools in the box.

CHANGING A BULB

Procedure for replacing a faulty bulb with a new bulb without the use of tools.

i In some climatic conditions (e.g. low temperature or humidity), the presence of misting on the internal surface of the glass of the headlamps and rear lamps is normal; it disappears after the lamps have been on for a few minutes.

! The headlamps are fitted with polycarbonate glass with a protective coating:

- ☞ **do not clean them using a dry or abrasive cloth, nor with a detergent or solvent product,**
- ☞ use a sponge and soapy water,
- ☞ when using a high pressure washer on persistent marks, do not direct at the lamps or their outlines for too long, so as not to damage their coating and their seals.



☞ Do not touch the bulb directly with your fingers, use lint-free cloths.

Changing a halogen bulb should only be done after the headlamp has been switched off for a few minutes (risk of serious burns).

It is imperative to use only anti-ultraviolet (UV) type bulbs in order not to damage the headlamp.

Front lights

Model with halogen lights



1. Direction indicators (PY 21 W amber).
2. Dipped headlamps (H7 - 55 W).
3. Main beam headlamps (H1 - 55 W).
4. Daytime/side lights (P21/5 W).
5. Fog lamps (H8 - 35 W).

Model with xenon lights and directional headlamps




1. Direction indicators (PY 21 W SV silver).
2. Dipped/main beam headlamps (D1S-35 W).
3. Additional main beam headlamps (H1-55 W).
4. Daytime/side lights (P21/5 W).
5. Fog lamps (H8-35 W).



Risk of electrocution

Xenon bulbs (D1S-35 W) must be replaced by a PEUGEOT dealer.

Changing direction indicator bulbs




- ☞ Turn the bulb holder a quarter of a turn and extract it.
 - ☞ Pull the bulb and change it.
- To refit, carry out these operations in reverse order.

i Amber or silver coloured bulbs, such as the direction indicators, must be replaced with bulbs of identical specifications and colour.

! When refitting, close the plastic cover carefully to guarantee the sealing of the headlamp.


Changing dipped headlamp bulbs

- ☞ Remove the protective plastic cover by pulling on the tab.
 - ☞ Disconnect the bulb connector.
 - ☞ Compress the springs to release the bulb.
 - ☞ Extract the bulb and change it.
- To refit, carry out these operations in reverse order.



Changing main beam headlamp bulbs

- ☞ Remove the protective plastic cover by pulling on the tab.
 - ☞ Disconnect the bulb connector.
 - ☞ Compress the springs to release the bulb.
 - ☞ Remove the bulb and change it.
- To refit, carry out these operations in reverse order.



Changing daytime/side light bulbs

- ☞ Remove the protective plastic cover by pulling on the tab.
- ☞ Disconnect the bulb connector.
- ☞ Turn the bulb holder a quarter of a turn and extract it.
- ☞ Pull the bulb and change it.

To refit, carry out these operations in reverse order.



Changing integrated direction indicator side repeaters



- ✎ Insert a screwdriver towards the centre of the repeater between the repeater and the base of the mirror.
 - ✎ Tilt the screwdriver to extract the repeater and remove it.
 - ✎ Disconnect the repeater connector.
- To refit, carry out these operations in reverse order.
Contact a PEUGEOT dealer to obtain replacement repeaters.

Changing the lateral spotlights




For the replacement of this type of diodes bulb, contact a PEUGEOT dealer.

Changing fog lamp bulbs



To replace these bulbs consult a PEUGEOT dealer.

Rear lights



1. Brake lights (diodes).
2. Side lights (diodes).
3. Direction indicators (diodes).
4. Fog lamp (P21 W).
5. Reversing light (P21 W).

Changing brake lights, side lights and direction indicators



For the replacement of this type of diodes light, contact a PEUGEOT dealer.

Changing the fog lamp and reversing light

These two bulbs are changed from outside the rear bumper:

- ☞ turn the bulb holder one quarter of a turn and remove it,
- ☞ turn the bulb one quarter of a turn and change it.

To refit, carry out these operations in reverse order.




On the left-hand side, take care not to touch the silencer; risk of burns, if you change the bulb after switching off the ignition.

Changing the third brake light (diodes)



For the replacement of this type of diodes light, contact a PEUGEOT dealer.

Changing the number plate light bulbs (W 5 W)



- ✎ Insert a thin screwdriver in one of the exterior holes of the lens.
- ✎ Push it towards the outside to unclip it.
- ✎ Remove the lens.
- ✎ Pull the bulb and change it.



High pressure washing

When using this type of washing on stubborn dirt, do not persist on the headlamps, the lights and their surrounds to avoid damaging their varnish and their seal.

CHANGING A FUSE

Procedure for replacing a faulty fuse with a new fuse to rectify a failure of the corresponding function.



Access to the tools

The extraction pliers and the spare fuses are installed on the back of the fascia fuse box cover.

To gain access to them:

- ☞ open the glove box lid,
- ☞ push the opening guide to the left past the first notch,
- ☞ open the glove box lid fully,
- ☞ turn the screw a quarter of a turn to the left,

- ☞ unclip the fuse box cover by pulling at the top right,
- ☞ remove the cover completely,
- ☞ remove the pliers.

Changing a fuse

Before changing a fuse, the cause of the failure must be identified and rectified.

- ☞ Identify the faulty fuse by checking the condition of its filament.



Correct



Incorrect

- ☞ Use the special pliers to extract the fuse from its housing.
- ☞ Always replace the faulty fuse with a fuse of the same rating.
- ☞ Check the correspondence between the number etched on the box, the rating etched on the fuse and the tables below.



Installing electrical accessories

Your vehicle's electrical system is designed to operate with standard or optional equipment.

Before installing other electrical equipment or accessories on your vehicle, contact a PEUGEOT dealer.



PEUGEOT will not accept responsibility for the cost incurred in repairing your vehicle or for rectifying malfunctions resulting from the installation of accessories not supplied and not recommended by PEUGEOT and not installed in accordance with its instructions, in particular when the combined consumption of all of the additional equipment connected exceeds 10 milliamperes.


Fascia fuses

The fuse box is placed in the lower section of the fascia (left-hand side).



Access to the fuses


☞ refer to the paragraph "Access to the tools".



Fuse tables

Fuse N°	Rating	Functions
G36	30 A	Driver and passenger heated seats.
G37	5 A	Trailer fuse box.
G38	30 A	Driver's seat memory unit.
G39	-	Not used.
G40	30 A	Hi-Fi amplifier, passenger's seat memory unit.

Fuse N°	Rating	Functions
F1	-	Not used.
F2	-	Not used.
F3	5 A	Air bags and pretensioners control unit.
F4	10 A	Clutch pedal and dual-function brake switches, electrochromatic interior mirror, air conditioning, steering wheel angle sensor, automatic gearbox, switching and protection unit.
F5	30 A	Front one-touch electric windows, folding mirrors supply.
F6	30 A	Rear one-touch electric windows, exterior door opening controls.
F7	5 A	Front and rear courtesy lights, map reading lights, sun visor lighting, glove box lighting.



Fuse N°	Rating	Functions
F8	20 A	Audio equipment, audio/telephone, multifunction display, tyre under-inflation detection, interior storage compartments.
F9	30 A	Front 12 V socket, lighter.
F10	15 A	Steering wheel controls, alarm siren, alarm control unit.
F11	15 A	Low current ignition switch.
F12	15 A	Instrument panel, seat belt and passenger's front air bag warning lights display, air conditioning, driver's seat memory unit, retractable roof unit.
F13	5 A	Engine fuse box, air bags.
F14	15 A	Multifunction display, amplifier, hands-free kit, rain/brightness sensor, parking assistance control unit, passenger's seat memory unit.
F15	30 A	Locking and deadlocking.
F17	40 A	Rear screen and exterior mirrors de-icing.
SH	-	PARC shunt.


Engine compartment fuses

The fuse box is placed in the engine compartment near the battery (left-hand side).




Access to the fuses

- ✦ Unclip the cover.
- ✦ Change the fuse (see corresponding paragraph).
- ✦ When you have finished, close the cover carefully to guarantee the sealing of the fuse box.



Fuse table

Fuse N°	Rating	Functions
F1	20 A	Engine control unit supply, injection pump and EGR solenoid valves (2 l HDI 16V), injectors (2 l HDI 16V).
F2	15 A	Horn.
F3	10 A	Front wash-wipe.
F4	20 A	Headlamp wash.
F5	15 A	Purge canister, turbine discharge and Turbo pressure regulation solenoid valves (1.6 l THP 16V), oil vapour heater (1.6 l THP 16V), diesel heater (1.6 l HDI 16V).
F6	10 A	Vehicle speed sensor, ABS/ESP control unit.
F7	10 A	Power steering control unit, automatic gearbox, engine coolant level detector.
F8	25 A	Starter control.
F9	10 A	Diagnostic socket, directional headlamps, air flow sensor (Diesel), particle emission filter pump (Diesel), exterior mirror controls.
F10	30 A	Engine control unit actuators (petrol: ignition coils, solenoid valves, oxygen sensors, injectors, heaters, fuel pump, controlled thermostat) (Diesel: solenoid valves, heaters).
F11	40 A	Air conditioning blower.



Fuse N°	Rating	Functions
F12	30 A	Windscreen wipers slow/fast speed.
F13	40 A	Built-in systems interface supply (ignition positive).
F14	-	Not used.
F15	10 A	Right-hand main beam headlamp.
F16	10 A	Left-hand main beam headlamp.
F17	15 A	Left-hand dipped headlamp.
F18	15 A	Right-hand dipped headlamp.
F19	15 A	Oil vapour heater (1.6 I VTi 16V), purge canister solenoid valve (1.6 I VTi 16V), oxygen sensors (petrol), air cooling solenoid valves (Diesel).
F20	10 A	Controlled thermostat, variable timing solenoid valves, Turbo pressure regulation solenoid valve (Diesel), engine coolant level detector (Diesel).
F21	5 A	Fan assembly relay supply, Valvetronic relay control (1.6 I VTi 16V), Turbo cooling (1.6 I THP 16V), air flow sensor (1.6 I HDI 16V).




Table of mini and midi-fuses above the battery

Fuse N°	Rating	Functions
F1	15 A	Automatic gearbox.
F2	15 A	Diagnostic socket, daytime lights.
F3	5 A	Dual-function brake switch.
F4	-	Not used.
F5*	80 A	Power steering electropump assembly.
F6*	70 A	Heating unit (Diesel).
F7*	100 A	Switching and protection unit.
F8*	50 A	Driver and passenger "AIRWAVE" systems.
F9	-	Not used.
F10*	30 A	Valvetronic electric motor (1.6 I THP 16V).

Table of maxi-fuses

Fuse N°	Rating	Functions
MF1*	50 A	Retractable roof electropump assembly and unit.
MF2*	50 A	Passenger compartment fuse box.
MF3*	50 A	Fan assembly.
MF4*	80 A	Built-in systems interface.
MF5*	80 A	Built-in systems interface.
MF6*	40 A	ABS/ESP control unit.
MF7*	30 A	ABS/ESP solenoid valves.
MF8*	-	Not used.

* The maxi-fuses provide additional protection for the electrical systems. All work on the maxi-fuses must be carried out by a PEUGEOT dealer.

BATTERY

Procedure for charging your battery when it is flat or for starting the engine using another battery.

Access to the battery




The battery is located under the bonnet. To gain access to it:


- ☞ open the bonnet using the interior lever, then the exterior lever,
- ☞ secure the bonnet strut,
- ☞ remove the plastic cover to gain access to the two terminals,
- ☞ unclip the fuse box to remove the battery, if necessary.

Starting using another battery

- ☞ Connect the red cable to the positive terminal (+) of the flat battery **A**, then to the positive terminal (+) of the slave battery **B**.



- ☞ Connect one end of the green or black cable to the negative terminal (-) of the slave battery **B**.
- ☞ Connect the other end of the green or black cable to the earth point **C** on the broken down vehicle.



- ☞ Operate the starter, let the engine run.
- ☞ Wait until the engine returns to idle and disconnect the cables.

Charging the battery using a battery charger

- ✎ Disconnect the battery from the vehicle.
- ✎ Follow the instructions for use provided by the manufacturer of the charger.
- ✎ Reconnect starting with the negative terminal (-).
- ✎ Check that the terminals and connectors are clean. If they are covered with sulphate (whitish or greenish deposit), remove them and clean them.



The batteries contain harmful substances such as sulphuric acid and lead. They must be disposed of in accordance with regulations and must not, in any circumstances, be discarded with household waste.

Take used remote control batteries and vehicle batteries to a special collection point.



To avoid discharging the battery, do not leave the lights on repeatedly with the ignition off (refer to the "Energy economy mode" paragraph).

It is advisable to disconnect the battery if the vehicle is to be left unused for more than one month.



Do not disconnect the terminals while the engine is running.
Do not charge the batteries without disconnecting the terminals first.

Before disconnecting the battery

Wait 2 minutes after switching off the ignition before disconnecting the battery.

Close the roof, the windows and the doors before disconnecting the battery.

Following reconnection of the battery

Following reconnection of the battery, switch on the ignition and wait 1 minute before starting to permit initialisation of the electronic systems. However, if slight difficulties are encountered following this operation, contact a PEUGEOT dealer.

Referring to the corresponding section, you must yourself reinitialise:

- the remote control key,
- the electric windows and the automatic partial opening of the door windows,
- the GPS satellite navigation system.

LOAD REDUCTION MODE

System which manages the use of certain functions in relation to the level of charge remaining in the battery.

When the vehicle is being driven, the load reduction function temporarily deactivates certain functions, such as the air conditioning, the "AIRWAVE" systems, the rear screen de-icing...

The deactivated functions are reactivated automatically as soon as conditions permit.



At the risk of discharging the battery, the deactivated functions can be reactivated manually.

Charging the battery using a battery charger

- ✎ Disconnect the battery from the vehicle.
- ✎ Follow the instructions for use provided by the manufacturer of the charger.
- ✎ Reconnect starting with the negative terminal (-).
- ✎ Check that the terminals and connectors are clean. If they are covered with sulphate (whitish or greenish deposit), remove them and clean them.



The batteries contain harmful substances such as sulphuric acid and lead. They must be disposed of in accordance with regulations and must not, in any circumstances, be discarded with household waste.

Take used remote control batteries and vehicle batteries to a special collection point.



To avoid discharging the battery, do not leave the lights on repeatedly with the ignition off (refer to the "Energy economy mode" paragraph).

It is advisable to disconnect the battery if the vehicle is to be left unused for more than one month.



Do not disconnect the terminals while the engine is running.
Do not charge the batteries without disconnecting the terminals first.

Before disconnecting the battery

Wait 2 minutes after switching off the ignition before disconnecting the battery.

Close the roof, the windows and the doors before disconnecting the battery.

Following reconnection of the battery

Following reconnection of the battery, switch on the ignition and wait 1 minute before starting to permit initialisation of the electronic systems. However, if slight difficulties are encountered following this operation, contact a PEUGEOT dealer.

Referring to the corresponding section, you must yourself reinitialise:

- the remote control key,
- the electric windows and the automatic partial opening of the door windows,
- the GPS satellite navigation system.

LOAD REDUCTION MODE

System which manages the use of certain functions in relation to the level of charge remaining in the battery.

When the vehicle is being driven, the load reduction function temporarily deactivates certain functions, such as the air conditioning, the "AIRWAVE" systems, the rear screen de-icing...

The deactivated functions are reactivated automatically as soon as conditions permit.



At the risk of discharging the battery, the deactivated functions can be reactivated manually.

ENERGY ECONOMY MODE

System which manages the duration of use of certain functions to conserve a sufficient level of charge in the battery.

After the engine has stopped, you can still use functions such as the audio and telematics system, windscreen wipers, dipped headlamps, courtesy lights, etc. for a maximum combined duration of thirty minutes.

Switching to economy mode

Once the thirty minutes are over, a message appears on the multi-function display indicating that the vehicle has switched to economy mode and the active functions are put on standby.



If the telephone is being used at this time:

- it will be maintained for 5 minutes with the hands-free kit of your PC Sound or PC Nav,
- it will still be possible to finish the call with the PC Com 3D.

Exiting economy mode

These functions are reactivated automatically next time the vehicle is driven.

☞ In order to resume the use of these functions immediately, start the engine and let it run:

- for less than ten minutes, to use the equipment for approximately five minutes,
- for more than ten minutes, to use the equipment for up to approximately thirty minutes.



Let the engine run for the duration specified to ensure that the battery charge is sufficient.

Do not repeatedly and continuously restart the engine in order to charge the battery.

A flat battery prevents the engine from starting (refer to the "Battery" paragraph).

CHANGING A WIPER BLADE

Procedure for replacing a worn wiper blade with a new one without the use of tools.

Before removing a front wiper blade

☞ Within one minute after switching off the ignition, operate the wipers stalk to position the wiper blades in the centre of the windscreen.

Removing a front wiper blade

- ☞ Raise the corresponding wiper arm.
- ☞ Unclip the wiper blade and remove it.

Fitting a front wiper blade

- ☞ Check the size of the wiper blade as the shorter blade is fitted on the right-hand side of the vehicle.
- ☞ Put the corresponding new wiper blade in place and clip it.
- ☞ Fold down the wiper arm carefully.

After fitting a front wiper blade

- ☞ Switch on the ignition.
- ☞ Operate the wipers stalk again to park the wiper blades.

TOWING THE VEHICLE

Procedure for having your vehicle towed or for towing another vehicle using a removable towing eye.

Access to the tools



The towing eye is installed in the boot under the floor.

To gain access to it:

- ☞ change to the "coupé" configuration,
- ☞ open the boot,
- ☞ raise the floor,
- ☞ secure it by hooking its handle on the boot seal,
- ☞ remove the towing eye from the holder.

Towing your vehicle



- ☞ On the front bumper, unclip the cover by pressing at the bottom.
- ☞ Screw the towing eye in fully.
- ☞ Install the towbar.
- ☞ Switch on the hazard warning lights on the towed vehicle.



- ☞ Place the gear lever in neutral (position **N** on the automatic gearbox).

Failure to observe this special condition could result in damage to certain braking components and the absence of braking assistance the next time the engine is started.

Towing another vehicle



- ☞ On the rear bumper, unclip the cover by pressing at the bottom.
- ☞ Screw the towing eye in fully.
- ☞ Install the towbar.
- ☞ Switch on the hazard warning lights on the towed vehicle.



When towing with all four wheels on the ground, always use a towbar.

When towing with only two wheels on the ground, always use professional lifting equipment.

When towing with the engine off, there is no longer any braking or steering assistance.

TOWING A TRAILER, A CARAVAN, ETC.

Towbar suited to the attachment of a trailer or caravan with additional signalling and lighting.



Your vehicle is primarily designed for transporting people and luggage, but it may also be used for towing a trailer.

i We recommend the use of genuine PEUGEOT towbars and their harnesses that have been tested and approved from the design stage of your vehicle, and that the fitting of the towbar is entrusted to a PEUGEOT dealer.

If the trailer is not fitted by a PEUGEOT dealer, it is imperative that it is fitted using the electrical pre-equipment installed at the rear of the vehicle, in accordance with the manufacturer's instructions.

Driving with a trailer subjects the towing vehicle to more significant stress and its driver must be particularly careful.

Driving advice

Distribution of loads

☞ Distribute the load in the trailer so that the heaviest items are as close as possible to the axle and the nose weight approaches the maximum permitted without exceeding it.

Air density decreases with altitude, thus reducing engine performance. Above 1 000 metres, the maximum towing load must be reduced by 10 % and so on for every 1 000 metres of altitude.

Refer to the "Technical Data" section for details of the weights and towing loads which apply to your vehicle.

Side wind

☞ Take into account the increased sensitivity to side wind.

Cooling

Towing a trailer on a slope increases the temperature of the coolant.

As the fan is electrically controlled, its cooling capacity is not dependent on the engine speed.

☞ To lower the engine speed, reduce your speed.

The maximum towing load on a long slope depends on the gradient and the ambient temperature.

In all cases, pay attention to the coolant temperature.



☞ If the warning lamp and the **STOP** warning lamp come on, stop the vehicle and switch off the engine as soon as possible.

Braking

Towing a trailer increases the braking distance.

Tyres

☞ Check the tyre pressures of the towing vehicle and of the trailer, observing the recommended pressures.

Lighting

☞ Check the electrical signalling on the trailer.



The rear parking assistance will be deactivated automatically if an original PEUGEOT towbar is used.

VERY COLD CLIMATE SCREEN*

Removable device which prevents the accumulation of snow at the radiator cooling fan.



Fitting

- ☞ Offer up the very cold climate screen to the front of the lower section of the front bumper.
- ☞ Press on its periphery to clip its fixing clips one by one.

Removal

- ☞ Use a screwdriver as a lever to unclip each fixing clip in turn.



Do not forget to remove the very cold climate screen:

- when the outside temperature exceeds 10 °C,
- when towing,
- at speeds higher than 75 mph (120 km/h).

ACCESSORIES

You can obtain a wide range of accessories and original parts from the PEUGEOT network.

These accessories and parts have been tested and approved for reliability and safety.

They are all adapted to your vehicle and benefit from PEUGEOT's recommendation and warranty.

The product range offered by PEUGEOT Accessories is structured around 5 categories: PROTECTION - TOURING - IN-CAR TECHNOLOGY - STYLING - UNIVERSAL.

"Protection":



anti-theft alarm, window engraving, wheel locks, breathalyser, first aid kit, warning triangle, safety jacket, stolen vehicle tracking system, temporary tyre repair kit, snow chains.

"Touring":



mats**, boot tray, windstop.

For leisure pursuits: bicycle carrier on towbar, booster seats and child seats.

Trailer towbar which must be fitted by the PEUGEOT network.

** To avoid any risk of jamming of the pedals:

- ensure that the mat is positioned and secured correctly,
- never fit one mat on top of another.

* According to country.

VERY COLD CLIMATE SCREEN*

Removable device which prevents the accumulation of snow at the radiator cooling fan.



Fitting

- ☞ Offer up the very cold climate screen to the front of the lower section of the front bumper.
- ☞ Press on its periphery to clip its fixing clips one by one.

Removal

- ☞ Use a screwdriver as a lever to unclip each fixing clip in turn.



Do not forget to remove the very cold climate screen:

- when the outside temperature exceeds 10 °C,
- when towing,
- at speeds higher than 75 mph (120 km/h).

ACCESSORIES

You can obtain a wide range of accessories and original parts from the PEUGEOT network.

These accessories and parts have been tested and approved for reliability and safety.

They are all adapted to your vehicle and benefit from PEUGEOT's recommendation and warranty.

The product range offered by PEUGEOT Accessories is structured around 5 categories: PROTECTION - TOURING - IN-CAR TECHNOLOGY - STYLING - UNIVERSAL.

"Protection":



anti-theft alarm, window engraving, wheel locks, breathalyser, first aid kit, warning triangle, safety jacket, stolen vehicle tracking system, temporary tyre repair kit, snow chains.

"Touring":



mats**, boot tray, windstop.

For leisure pursuits: bicycle carrier on towbar, booster seats and child seats.

Trailer towbar which must be fitted by the PEUGEOT network.

** To avoid any risk of jamming of the pedals:

- ensure that the mat is positioned and secured correctly,
- never fit one mat on top of another.

* According to country.

"In-car technology":

audio systems, satellite navigation systems, hands-free kit, speakers, DVD player, connection kit for MP3 player or portable CD player, USB Box, rear parking assistance.

"Styling":

alloy wheels.



Depending on the country in which the vehicle is sold, it is compulsory to have a safety jacket, warning triangle and spare bulbs available in the vehicle.

**Installation of radiocommunication transmitters**

It is advisable to contact a representative of the PEUGEOT marque before installing accessory radio-communication transmitters with an external aerial on your vehicle.

The PEUGEOT network will provide you with the specifications (frequency band, maximum output power, aerial position, special installation conditions) of the transmitters which can be fitted, in accordance with the Vehicle Electromagnetic Compatibility Directive (2004/104/CE).

"Universal":

screenwash, interior and exterior maintenance and cleaning products.



The fitting of electrical equipment or accessories which are not recommended by PEUGEOT may result in a failure of your vehicle's electronic system.

Please note this specific warning. You are advised to contact a representative of the Marque to be shown the range of recommended equipment and accessories.

MODELS:	ENGINES AND GEARBOXES		
Model codes: 4B...	5FS-C	5FX-H	5FT-F
PETROL ENGINES	1.6 litre VTi 16V 120 bhp	1.6 litre THP 16V 150 bhp	1.6 litre THP 16V 140 bhp
Cubic capacity (cm ³)	1 598	1 598	
Bore x stroke (mm)	77 x 85.8	77 x 85.8	
Max power: EU standard (kW)	88	110	103
Max power engine speed (rpm)	6 000	5 800	6 000
Max torque: EU standard (Nm)	160	240	
Max torque engine speed (rpm)	4 250	1 400	
Fuel	Unleaded	Unleaded	
Catalytic converter	Yes	Yes	
GEARBOXES	Manual (5-speed)	Manual (6-speed)	Auto. (4-speed)
OIL CAPACITIES (in litres)			
Engine (with cartridge replacement)	4.25	4.25	4.25
Gearbox - Final drive	1.9	1.9	-

MODELS:	ENGINES AND GEARBOXES		
Model codes: 4B...	9HR-H	RHR-H	RHR-J
DIESEL ENGINES	1.6 litre Turbo HDI 16V 110 bhp	2 litres Turbo HDI 16V 136 bhp	
Cubic capacity (cm ³)	1 560	1 997	
Bore x stroke (mm)	75 x 88.3	85 x 88	
Max power: EU standard (kW)	82	103	100
Max power engine speed (rpm)	4 000	4 000	
Max torque: EU standard (Nm)	270	320	
Max torque engine speed (rpm)	1 750	2 000	
Fuel	Diesel	Diesel	
Catalytic converter	Yes	Yes	
Particle emission filter	Yes	Yes	
GEARBOXES	Manual (6-speed)	Manual (6-speed)	Auto. (6-speed)
OIL CAPACITIES (in litres)			
Engine (with cartridge replacement)	3.75	5.25	5.25
Gearbox - Final drive	1.9	2.4	-

CONSUMPTION			In accordance with directive 80/1268/CEE			
Petrol engines	Gearboxes	Model codes: 4B...	Urban driving M.P.G. (litres/100 km)	Extra-urban driving M.P.G. (litres/100 km)	Mixed driving M.P.G. (litres/100 km)	Emission of CO ₂ by weight (g/km)
1.6 litre VTi 16V 120 bhp	Manual	5FS-C	-	-	-	-
1.6 litre THP 16V 150 bhp	Manual	5FX-H	10.7	5.6	7.5	177
1.6 litre THP 16V 140 bhp	Auto.	5FT-F	11.8	6.0	8.1	192

Fuel consumption values correct at time of printing.

These consumption values were established in accordance with EC Directive 80/1268 (as amended). They may vary depending on the style of driving, traffic conditions, weather conditions, the load in the vehicle, the maintenance of the vehicle and the use of the equipment.

Quality of the fuel used for petrol engines

The petrol engines are perfectly compatible with E5 type petrol biofuels (containing 5 % ethanol), conforming to European standard EN 228.

E85 type fuels (containing up to 85 % ethanol) are reserved exclusively for vehicles marketed for the use of this type of fuel (BioFlex vehicles). The quality of the ethanol must comply with European standard EN 15376.

For Brazil only, special vehicles are marketed to run on fuels containing up to 100 % ethanol (type E100).

CONSUMPTION			In accordance with directive 80/1268/CEE			
Diesel engines	Gearboxes	Model codes: 4B...	Urban driving M.P.G. (litres/100 km)	Extra-urban driving M.P.G. (litres/100 km)	Mixed driving M.P.G. (litres/100 km)	Emission of CO ₂ by weight (g/km)
1.6 litre Turbo HDI 16V 110 bhp	Manual	9HR-H	-	-	-	-
2 litre Turbo HDI 16V 136 bhp	Manual	RHR-H	7.8	4.8	5.9	155
	Auto.	RHR-J	9.6	5.5	7.0	185

Fuel consumption values correct at time of printing.

These consumption values were established in accordance with EC Directive 80/1268 (as amended). They may vary depending on the style of driving, traffic conditions, weather conditions, the load in the vehicle, the maintenance of the vehicle and the use of the equipment.

Quality of the fuel used for Diesel engines

The Diesel engines are perfectly compatible with biofuels which conform to current and future European standards (diesel fuel which complies with standard EN 590 mixed with a biofuel which complies with standard EN 14214) which can be distributed at the pumps (possible incorporation of 0 to 7 % Fatty Acid Methyl Ester).

The use of any other type of (bio)fuel (vegetable or animal oils, domestic fuel...) is strictly prohibited (risk of damage to the engine and fuel circuit).

WEIGHTS AND TOWED LOADS (in kg)

Petrol engines	1.6 litre VTi 16V 120 bhp	1.6 litre THP 16V 150 bhp	1.6 litre THP 16V 140 bhp
Gearboxes	Manual	Manual	Auto.
Model codes: 4B...	5FS-C	5FX-H	5FT-F
- Unladen weight	1 480	1 512	1 523
- Kerb weight	1 555	1 587	1 598
- Payload	405	428	432
- Gross vehicle weight (GVW)	1 885	1 940	1 955
- Gross train weight (GVW) on a 12 % gradient	2 985	3 340	3 225
- Braked trailer (within GTW limit) on a 10 % or 12 % gradient	1 100	1 400	1 270
- Braked trailer* (with load transfer within GTW limit)	1 200	1 400	1 270
- Unbraked trailer	750	750	750
- Recommended nose weight	64	64	64

* The weight of the braked trailer can be increased, within the GTW limit, on condition that the GVW of the towing vehicle is reduced by the same amount; warning: towing with a lightly loaded towing vehicle may have an adverse effect on its road holding.

The GTW and towed load values indicated apply up to a maximum altitude of 1 000 metres; the towed load mentioned must be reduced by 10 % for every additional 1 000 metres.

The speed of a towing vehicle must not exceed 60 mph (100 km/h) (comply with the legislation in force in your country).

High exterior temperatures may result in a reduction in the performance of the vehicle to protect the engine; when the exterior temperature is higher than 37 °C, limit the towed weight.

WEIGHTS AND TOWED LOADS (in kg)

Diesel engines	1.6 litre Turbo HDI 16V 110 bhp	2 litre Turbo HDI 16V 136 bhp	
Gearboxes	Manual	Manual	Auto.
Model codes: 4B...	9HR-H	RHR-H	RHR-J
- Unladen weight	1 525	1 599	1 620
- Kerb weight	1 600	1 674	1 695
- Payload	400	421	420
- Gross vehicle weight (GVW)	1 925	2 020	2 040
- Gross train weight (GTW) on a 12 % gradient	3 025	3 420	3 440
- Braked trailer (within GTW limit) on a 10 % or 12 % gradient	1 100	1 400	1 400
- Braked trailer* (with load transfer within GTW limit)	1 200	1 400	1 400
- Unbraked trailer	750	750	750
- Recommended nose weight	64	64	64


* The weight of the braked trailer can be increased, within the GTW limit, on condition that the GVW of the towing vehicle is reduced by the same amount; warning: towing with a lightly loaded towing vehicle may have an adverse effect on its road holding.

The GTW and towed load values indicated apply up to a maximum altitude of 1 000 metres; the towed load mentioned must be reduced by 10 % for every additional 1 000 metres.

The speed of a towing vehicle must not exceed 60 mph (100 km/h) (comply with the legislation in force in your country).

High exterior temperatures may result in a reduction in the performance of the vehicle to protect the engine; when the exterior temperature is higher than 37 °C, limit the towed weight.

DIMENSIONS (IN MM)



IDENTIFICATION FEATURES

Various visible marking elements for the identification and tracking of your vehicle.

A. Chassis number under the bonnet.

This number is etched on the bodywork near the damper support.

To gain access to it, raise the plastic cover.

B. Chassis number on the windscreen lower crossmember.

This number is indicated on a gummed label which is visible through the windscreen.

C. Manufacturer's label.

This number is indicated on a self-destructing label affixed to the door aperture, below the door striker, on the right-hand side.

D. Tyre/paint label.

This label is affixed to the door aperture, on the driver's side.

It bears the following information:

- the tyre inflation pressures with and without load,
- the wheel rim and tyre sizes,
- the brands of tyre recommended by the manufacturer,
- the inflation pressure of the spare wheel,
- the paint colour reference.




Wheels which are fitted with 225/40 R18 tyres cannot be fitted with snow chains. For further information, contact a PEUGEOT dealer.



The inflation pressure must be checked when the tyres are cold, at least once a month.



If the inflation pressure is too low, this increases fuel consumption.



PC Com 3D

MULTIMEDIA AUDIO EQUIPMENT/BLUETOOTH TELEPHONE

GPS EUROPE

CONTENTS



The PC Com 3D is protected in such a way that it will only operate in your vehicle. If it is to be installed in another vehicle, contact a PEUGEOT dealer for configuration of the system.



For safety reasons, it is imperative that the driver carries out operations which require prolonged attention while the vehicle is stationary. When the engine is switched off and to prevent discharging of the battery, the PC Com 3D switches off following the activation of the Energy Economy mode.




Certain functions described in this handbook will become available during the course of the year.

- **01 First steps** pg. 164
- **02 General operation** pg. 166
- **03 Navigation - Guidance** pg. 169
- **04 Traffic information** pg. 177
- **05 Radio** pg. 178
- **06 Music media players** pg. 179
- **07 Making a telephone call** pg. 184
- **08 Configuration** pg. 189
- **09 Voice commands and steering wheel controls** pg. 190
- **10 Display flow charts** pg. 193
- **Frequently asked questions** pg. 197

01 FIRST STEPS

PC Com 3D CONTROL PANEL



Short press: clears the last character.



Long press: activates the voice recognition.

1. CD eject.

2. RADIO: access to the "Radio" Menu.
Displaying of the list of stations in alphabetical order (FM waveband) or frequency order (AM waveband).

MEDIA: access to the "Media" Menu (Audio CD, Jukebox, External Device).
Displaying of the list of tracks. Change of source.

NAV: access to the "Navigation" Menu and displaying of the last destinations.

ESC: abandon the operation in progress.
Long press: return to the main display.

TRAFFIC: access to the "Traffic" Menu (function described in detail in sections 02 and 10).

ADDR BOOK: access to the "Address book" Menu (function described in detail in section 10).

SETUP: access to the "SETUP" Menu (configuration) (function described in detail in sections 02 and 10).
Long press: GPS coverage.

3. Audio settings (Balance/Fader, Bass/Treble, Musical Ambience...).

4. Volume adjustment.
Short press: mute.

5. Automatic search for a radio station on a lower frequency.
Selection of the previous CD or MP3 track.

6. Automatic search for a radio station on a higher frequency.
Selection of the next CD or MP3 track.

7. Normal display or black screen.

8. Selection of the successive displaying on the screen of "MAP"/"NAV" (if navigation is in progress)/"TEL" (if a conversation is in progress)/"RADIO" or "MEDIA" currently being played.

9. PICK UP: access to the "Phone" menu.
With Bluetooth connection, accept an incoming call.

10. HANG UP: access to the "Phone" menu.
Hang up the current call or refuse an incoming call, with Bluetooth connection.

11. Telephone numeric keypad, pre-selection of 10 radio frequencies.

12. SD card reader.

FIRST STEPS 01

PC Com 3D NAVIGATOR



13. OK: confirmation of the highlighted item on the screen.

- 4-direction navigator: press to the left/right.

When the "RADIO" screen is displayed: selection of the previous/next frequency.

When "MEDIA" is displayed: selection of the previous/next track.

When "MAP" or "NAV" is displayed: horizontal movement of the map.

- 4-direction navigator: press up/down.

When "RADIO" is displayed: selection of the previous/next radio station on the list.

When the "MEDIA" screen is displayed: selection of the previous/next MP3 directory or CD.

When "MAP" or "NAV" is displayed: vertical movement of the map.

Switch to the next or previous page of a menu.

14. Rotation of the ring:

When the "RADIO" screen is displayed: selection of the previous/next radio station on the list.

When the "MEDIA" screen is displayed: selection of the previous/next CD or MP3 track.

When "MAP" or "NAV" is displayed: front/rear map zoom.

02 GENERAL OPERATION

DISPLAY ACCORDING TO THE CONTEXT

Press the MODE button several times in succession to gain access to the following displays:

RADIO/MUSIC MEDIA/VIDEO



TELEPHONE

(If a conversation is in progress)




FULL SCREEN MAP



NAVIGATION

(If guidance is in progress)



SETUP:

access to the "SETUP" Menu: system language and voice functions, voice initialisation (section 09), date and time, display, unit and system parameters. Long press: access to the GPS coverage and to the demonstration mode.



TRAFFIC:

access to the "Traffic" Menu: displaying of the current traffic alerts.



MEDIA:

"Audio DVD" menu
"DVD-Video" menu



For maintenance of the screen, the use of a soft, non-abrasive cloth (spectacles cloth) is recommended, without any additional product.



For a detailed global view of the menus available, refer to the "Display flow charts" section of this handbook.



GENERAL OPERATION 02

DISPLAY ACCORDING TO THE CONTEXT



Pressing OK permits access to short-cut menus according to the display on the screen.

NAVIGATION (IF GUIDANCE IS IN PROGRESS):

- 1 ABORT GUIDANCE
- 1 REPEAT ADVICE
- 1 BLOCK ROAD
- 2 UNBLOCK
- 2 MORE
- 2 LESS
- 2 CALCULATE
- 2 ZOOM/SCROLL
- 2 BROWSE ROUTE
- 1 ROUTE INFO
- 2 SHOW DESTINATION
- 2 TRIP INFO
- 3 Route type



- 3 Avoid
- 3 Satellites
- 3 Stopovers
- 2 BROWSE ROUTE
- 2 ZOOM/SCROLL
- 1 VOICE ADVICE
- 1 ROUTE OPTIONS
- 2 ROUTE TYPE
- 2 ROUTE DYNAMICS
- 2 AVOIDANCE CRITERIA
- 2 RECALCULATE

TELEPHONE:

- 1 END CALL
- 1 HOLD CALL
- 1 DIAL
- 1 DTMF-TONES
- 1 PRIVATE MODE
- 1 MICRO OFF

MUSIC MEDIA PLAYERS:

- 1 TA
- 1 PLAY OPTIONS
- 2 NORMAL ORDER
- 2 RANDOM TRACK
- 2 SCAN
- 1 SELECT MEDIA

RADIO:

- 1 IN FM MODE
- 2 TA
- 2 RDS
- 2 RADIOTEXT
- 2 REGIONAL PROG.
- 2 AM
- 1 IN AM MODE
- 2 TA
- 2 REFRESH AM LIST
- 2 FM

02 GENERAL OPERATION

DISPLAY ACCORDING TO THE CONTEXT



FULL SCREEN MAP:

1 ABORT GUIDANCE/RESUME GUIDANCE

1 SET DESTINATION/ADD STOPOVER

1 POIS NEARBY

1 POSITION INFO

2 OPTIONS

3 Navigate to

3 Dial

3 Save position

3 Zoom/Scroll

1 MAP SETTINGS

2 2D MAP

2 2.5D MAP

2 3D MAP

2 NORTH UP

2 HEADING UP

1 ZOOM/SCROLL



AUDIO DVD:

1 STOP

2 GROUP

3 Group 1..2/n

2 PLAY OPTIONS

3 Normal order/Random track/Scan

1 TA

2 SELECT MEDIA

VIDEO DVD:

1 PLAY

2 STOP

2 DVD MENUS

3 DVD menu

3 DVD top menu

3 List of titles

3 List of chapters

2 DVD OPTIONS

3 Audio

3 Subtitles

3 Angle

Example




03 NAVIGATION - GUIDANCE

SELECTING A DESTINATION

The "NAVIGATION" voice commands are listed in section 09.

During guidance, a long press on the end of the lights stalk repeats the last guidance instruction.

1



Press the NAV button.



The list of the last 20 destinations appears under the "Navigation" Menu function.

2



Press the NAV button again or select the "Navigation" Menu function and press OK to confirm.

"NAVIGATION" MENU



3



Select the "Destination input" function and press OK to confirm.

DESTINATION INPUT




4



Select the "Address input" function and press OK to confirm.

ADDRESS INPUT



5



Once the country has been selected, turn the ring and select the town function. Press OK to confirm.




6



Select the letters of the town one by one confirming each time by pressing OK.



A pre-set list (by entering the first few letters) of the towns in the country selected can be accessed via the LIST button on the virtual keypad.



It is possible to scroll the map using the 4-direction navigator. It is possible to select its orientation via the short-cut menu of the "Full screen map". Press OK then select "Map Settings" and confirm.

7



Turn the ring and select OK. Press OK to confirm.



To speed up the process, the post code can be entered directly after selecting the "Postal code" function. Use the virtual keypad to enter the letters and digits.

8



Repeat steps 5 to 7 for the "Street" and "House number" functions.



Select the "Save to address book" function to record the address entered in a directory file. Press OK to confirm the selection. The PC Com 3D permits the recording of more than 4 000 contact files.

i

To delete a destination; from steps 1 to 3, select "Choose from last destinations". A long press on one of the destinations displays a list of actions from which you can select:

DELETE ENTRY

DELETE LIST

9



Then select "Start route guidance" and the press OK to confirm.

START ROUTE GUIDANCE



10



Select the route type: "Fast route", "Short route", or "Optimized route" and press OK to confirm.



11



Select the road with the colour corresponding to the route chosen and press OK to confirm and start guidance.



It is also possible to select a destination via "Choose from address book" or "Choose from last destinations", by selecting a junction, a town centre, geographic coordinates, or directly on the "Map".

CHOOSE FROM ADDRESS BOOK


CHOOSE FROM LAST DESTINATIONS

03 NAVIGATION - GUIDANCE

ROUTE OPTIONS

When the map is displayed on the screen, you can select "Map Settings" then "2D Map/2.5D Map/3D Map/North Up/Heading Up". The displaying of buildings in 3D mode depends on the progress of the town mapping.

1



Press the NAV button.



2



Press the NAV button again or select the "Navigation" Menu function and press OK to confirm.

"NAVIGATION" MENU



3



Select the "Route options" function and press OK to confirm.

ROUTE OPTIONS



4



Select the "Route type" function and press OK to confirm. This function allows you to change the route type.

ROUTE TYPE



5



Select the "Route dynamics" function. This function provides access to the "Traffic independent", "Semi-dynamic" and "Dynamic" options.

ROUTE DYNAMICS



6



Select the "Avoidance criteria" function. This function provides access to the "Avoid" options (motorways, toll roads, ferries, tunnels).

AVOIDANCE CRITERIA



7



Turn the ring and select the "Recalculate" function to take into account the route options selected. Press OK to confirm.

RECALCULATE



ADDING A STOPOVER

Stopovers can be added to or deleted from the route once the destination has been selected.

1



Press the NAV button.



2



Press the NAV button again or select the "Navigation" Menu function and press OK to confirm.

"NAVIGATION" MENU



3



Select the "Stopovers" function and press OK to confirm.

STOPOVERS



4



Select the "Add stopover" function (5 stopovers maximum) and press OK to confirm.

ADD STOPOVER



5



Enter a new address, for example.

ADDRESS INPUT



6



Once the new address has been entered, select "Start route guidance" and press OK to confirm.

START ROUTE GUIDANCE



7



Position the stopover on the list and press OK to confirm.



8

Repeat operations 1 to 7 as many times as necessary then select "Recalculate" and press OK to confirm.




To change the stopovers, repeat operations 1 to 3 and select "Rearrange route" (select a stopover, delete it or move it on the list using the ring to change the order, confirm its new position and finish with "Recalculate").

03 NAVIGATION - GUIDANCE

SEARCHING FOR POINTS OF INTEREST

The points of interest (POIs) indicate all of the service locations in the vicinity (hotels, various businesses, airports...).

1



Press the NAV button.



2



Press the NAV button again or select the "Navigation" Menu function and press OK to confirm.

"NAVIGATION" MENU



3



Select the "POI search" function and press OK to confirm.

POI SEARCH



4



Select the "POI nearby" function to search for POIs around the vehicle.

POI NEARBY



5



Select the "POI near destination" function to search for POIs near the point of arrival of the route.

POI NEAR DESTINATION



6



Select the "POI in city" function to search for POIs in the city required. Select the country then enter the name of the city using the virtual keypad.

POI IN CITY



A list of cities present in the country selected can be accessed via the LIST button on the virtual keypad.

7



Select the "POI in country" function to search for POIs in the country required.

POI IN COUNTRY



8



Select the "POI near route" function to search for POIs near the route.

POI NEAR ROUTE



03 NAVIGATION - GUIDANCE

This icon appears when several POIs are grouped together in the same area. Zooming in on this icon shows details of the POIs.



List of POIs

-   Service station
-  LPG station
-   Garage
-  PEUGEOT
-  Motor racing circuit
-  Covered car park
-   Car park
-  Rest area
-   Hotel
-   Restaurant
-  Refreshment area
-  Picnic area
-  Cafeteria

-   Airport
-  Railway station
-  Bus station
-  Port
-   Industrial estate
-  Supermarket
-  Bank
-  Vending machine
-   Tennis court
-  Swimming pool
-  Golf course
-  Winter sports resort
-  Theatre

-  Cinema
-  Camp site
-  Theme parks
-   Hospital
-  Pharmacy
-  Police station
-  School
-  Post office
-   Museum
-   Tourist information
-  Automatic speed camera*
-  Red light camera*
-  Hazardous location*

* according to availability in the country

03 NAVIGATION - GUIDANCE

UPDATING THE HAZARDOUS LOCATION POIs

1



Download the "Hazardous location POIs" update file onto an SD card or USB stick from the Internet. This service will be available on www.peugeot.fr, www.peugeot.co.uk then gradually deployed to all of the other countries.

2



Insert the medium (SD card or USB stick) containing the POI database into the system's SD card reader or USB reader.

3



Press NAV, select "Navigation" Menu, then "Update personal POI".

"NAVIGATION" MENU

UPDATE PERSONAL POI



4



Select the medium ("USB" or "SD-Card") used and press OK.



5

Successful downloading is confirmed by a message.

03 NAVIGATION - GUIDANCE

SPOKEN INSTRUCTION SETTINGS

1



When the navigation is displayed on the screen, press OK then select or deselect "Voice advice" to activate or deactivate the spoken guidance instructions. Use the volume button to adjust the volume.



3




Select the "Settings" function and press OK to confirm.

SETTINGS



POINTS OF INTEREST AND HAZARD LOCATIONS SETTINGS

1



Press the NAV button.



2



Press the NAV button again or select the "Navigation" Menu function and press OK to confirm.

NAVIGATION MENU



4



Select the "POI categories on Map" function to select the POIs to be displayed on the map by default.

POI CATEGORIES ON MAP



5



Select "Set parameters for risk areas" to gain access to the "Display on map", "Visual alert" and "Sound alert" functions.

SET PARAMETERS FOR RISK AREAS



04 TRAFFIC INFORMATION

CONFIGURE THE FILTERING AND DISPLAYING OF THE TMC MESSAGES

1



Press the TRAFFIC button.



The list of TMC messages appears under the "Traffic" Menu sorted in order of proximity.

2



Press the TRAFFIC button again or select the "Traffic" Menu function and press OK to confirm.



"TRAFFIC" MENU

i



The TMC icon, at the bottom left of the screen, may appear in 3 different forms:

- No TMC station available,
- TMC station available, no message on route,
- TMC station available and messages on route (if guidance is active).

The filters are independent and their results are concealed.

We recommend:

- a filter over 6 miles (10 km) around the vehicle in heavy traffic,
- a filter over 30 miles (50 km) around the vehicle or a filter on the route on motorway journeys.

3



Select "Select preferred list" MESSAGE FILTERING and press OK to confirm.



4



Select the filter of your choice:

ALL MESSAGES ON ROUTE

WARNINGS MESSAGES ON ROUTE

ONLY WARNING MESSAGES

ALL MESSAGES



5



Select "Geo. Filter".

GEO. FILTER



When all of the messages on the route are selected, the addition of a geographic filter is recommended (within a radius of 3 miles (5 km) for example) to reduce the number of messages displayed on the map. The geographic filter follows the movement of the vehicle.

05 RADIO

The external environment (hill, building, tunnel, underground car park...) may interfere with the reception, including in RDS following mode. This phenomenon is a normal result of the way in which radio waves are transmitted and does not in any way indicate a failure of the audio equipment.

SELECTING A STATION

1



Press the RADIO button to display the list of stations received locally sorted in alphabetical order. Select the station required by turning the ring and press to confirm.



While listening to the radio, press buttons ►► ◄◄ for the automatic search for a lower or higher frequency.



When the "RADIO" screen is displayed, turn the ring or use the ►-direction navigator to select the previous or next station on the list.



Press one of the buttons on the numeric keypad for more than 2 seconds to store the current station. A bleep confirms that it has been stored. Press the button on the numeric keypad to recall the stored radio station.

RDS - REGIONAL MODE - TRAFFIC INFO

1




When the current radio station is displayed on the screen, press OK.



2

The radio source short-cuts menu appears and provides access to the following short-cuts:



3



Select the function required and press OK to confirm to gain access to the corresponding settings.



The RDS, if displayed, allows you to continue listening to the same station by means of the frequency following. However, in certain conditions, this RDS station cannot be followed throughout the entire country as radio stations do not cover 100 % of the territory. This explains the loss of reception of the station during a journey.

06 MUSIC MEDIA PLAYERS

CD, MP3/WMA CD, MP3/WMA SD CARD/ USB READER INFORMATION AND ADVICE



The MP3 format, an abbreviation of MPEG 1,2 & 2.5 Audio Layer 3 and the WMA format, an abbreviation of Windows Media Audio and the property of Microsoft, are audio compression standards which permit the recording of several tens of music files on a single disc.



In order to be able to play a recorded CDR or CDRW, when recording it is preferable to select the ISO 9660 level 1, 2 or Joliet standard.

If the disc is recorded in another format it may not be played correctly.

It is recommended that the same recording standard is always used for an individual disc, with as low a speed as possible (4x maximum) for optimum sound quality.

In the particular case of a multi-session CD, the Joliet standard is recommended.



The audio equipment will only play audio files with the extension ".mp3" with a speed of between 8 Kbps and 320 Kbps and the extension ".wma" with a speed of between 5 Kbps and 384 Kbps. It also supports the VBR (Variable Bit Rate) mode. No other type of file (.mp4, .m3u...) can be played.



It is advisable to restrict file names to 20 characters, without using of special characters (e.g.: " " ?; ù) to avoid any playing and displaying problems.



During play, exit the "SD-Card" or "USB" source before removing the SD card or the USB stick from its reader.



To avoid any risk of theft, remove the SD card or the USB stick when you leave your vehicle with the roof open.

SELECTING/PLAYING CD, MP3/WMA CD, MP3/WMA SD CARD/ USB READER

MP3 CDs, SD cards or USB peripherals are the compatible sources.

1

Insert the audio or MP3 CD in the player, the SD card in the card reader or the USB peripheral in the USB reader. Play begins automatically.



!

The list of tracks or MP3/WMA files appears under "Media" Menu.

2



Press this button.




3



When the "MEDIA" screen is displayed, turn the ring up or down to select the previous or next compatible source.



4



Press the MEDIA button.



5



Press the MEDIA button again or select the "Media" Menu function and press OK to confirm.

"MEDIA" MENU



6



Select the "Select media" function and press OK to confirm.

SELECT MEDIA



7



Select the music source required. Press OK to confirm. Play begins.



!

The playing and displaying of an MP3/WMA compilation may depend on the recording programme and/or the parameters used. We recommend the ISO 9660 recording standard.

06 MUSIC MEDIA PLAYERS

VIEWING A VIDEO DVD

- 1 Insert the DVD in the player. Play begins automatically.



- 2 If the DVD does not appear on the screen, press the MODE button to gain access to the "MEDIA" screen which displays the DVD screen.



- 3 Press the MEDIA button to gain access to the "DVD" menu at any time, or to the functions of the "Media" Menu which adjust the video (brightness/contrast, image format...).



-  The 4-direction navigator and the chromed ring allow you to move the DVD selection cursor. Change chapter by pressing the ►► or ◀◀ button.

-  Select the video source required ("DVD-Video", "External device (AV)"). Press OK to confirm. Play begins.

USING THE EXTERNAL DEVICE (AUX) AUDIO/VIDEO/RCA CABLE NOT SUPPLIED

- 1 Connect the portable equipment (MP3 player, camcorder, camera...) to the RCA socket (white and red for audio; red and yellow for video) in the glove box using a JACK/RCA audio cable.

- 2  Press the MEDIA button then press it again or select the "Media" Menu function and press OK to confirm.



-  If the external device is not activated, select "Ext. Device (Aux) management" to activate it.

- 3  Select "Select media" then "External device (AV)" and press OK to activate it.

EXTERNAL DEVICE



- 4  Select the AUX music source and press OK to confirm. Play begins automatically.



-  The displaying and management of the controls are operated via the portable equipment.

JUKEBOX

COPYING A CD, A USB STICK OR AN SD CARD ONTO THE HARD DISC

1




Insert an audio/MP3 CD, a USB stick or an SD card.



!

Check that the active MEDIA source is that of the medium used (CD, USB or SD card).

2



Press the MEDIA button. Press the MEDIA button again or select "Media" Menu and press OK to confirm.



3



Select "Jukebox management" then "Add files" and press OK at each step to confirm.

ADD FILES



4



Select "Add files from MP3-Disc" for example and press OK to validate.

ADD FILES FROM MP3-DISC



5



Select the tracks required then "Rip selection" or select all of the tracks using "Rip all".



6



Select "[New folder]" to create a new folder or select an existing folder (created previously).

[NEW FOLDER]



7



"Do you want to change the names of the tracks that will be ripped?": select "Yes" to change them or "No".

YES

NO



8



To copy an MP3 CD, then select "Real time ripping", "Fast ripping"/ "High quality (192 kbit/sec)" or "Standard quality (128 kbit/sec)" then select "Start ripping".



9




Confirm the warning message by pressing "OK" to start the copy.

OK



JUKEBOX RENAMING AN ALBUM

1



Press the MEDIA button.



2



Press the MEDIA button again or select "Media" Menu and press OK to confirm.



3



Select the "Jukebox management" function and press OK to confirm.

JUKEBOX MANAGEMENT



4



Select "Modify content" and press OK confirm.

MODIFY CONTENT




JUKEBOX LISTENING TO THE JUKEBOX

1



Press the MEDIA button. Press the MEDIA button again or select "Media" Menu and press OK to confirm.



!

Check that the active source is not the Jukebox in order to be able to rename or delete a track/directory.

2



Select "Jukebox management" and press OK to confirm.



3



Select "Play options" and press OK to confirm. Select "Folders & Files" or "Playlists" then press OK to confirm.



☀

Press the ESC button to return to the first file level. Playlists can be created in the Jukebox.

"Media" Menu> Jukebox management> Create new playlist. Add the tracks required one by one then save the change. The "Playlists" play mode must then be selected.

07 MAKING A TELEPHONE CALL

CHOOSING BETWEEN THE BLUETOOTH TELEPHONE/INTERNAL TELEPHONE

1



To activate the Bluetooth telephone or the internal telephone, press PICK UP TEL.



2



Select "Phone" menu, then "Select phone" then choose between "Telephone off", "Use Bluetooth phone" or "Use internal phone". Press OK at each step to confirm.



!

The system can only be connected to one Bluetooth telephone and one SIM card (Internal telephone) at the same time. In this case, the phone book is synchronised with the Bluetooth telephone.

07 MAKING A TELEPHONE CALL

CONNECTING A BLUETOOTH TELEPHONE

The services available via the telephone depend on the network, the SIM card and the compatibility of the Bluetooth equipment used. Refer to your telephone's manual and your operator to check which services you have access to. A list of mobile telephones which offer the best range of services is available from dealers.



For safety reasons and because they require prolonged attention on the part of the driver, the operations for pairing the Bluetooth mobile telephone to the hands-free system of the PC Com 3D must be carried out with the vehicle stationary and the ignition on.

1

Activate the telephone's Bluetooth function. The last telephone connected is reconnected automatically.



2



Press the TEL button.



3



If no telephone is connected, the system prompts you to "Connect phone". Select "Yes" and press OK to confirm.



The list of telephones connected previously (4 maximum) appears on the multifunction display. Select the telephone required then select "Connect phone" for a new connection. Select "Delete pairing" to cancel the connection to the telephone.

4



For a first connection, select "Search phone" and press OK to confirm. Then select the name of the telephone.

SEARCH PHONE



5



Enter the authentication code on the telephone. The code to be entered is displayed on the screen.



Once the telephone has been connected, the PC Com 3D can synchronise the address book and the call list. This synchronisation may take a few minutes.

1



To change the telephone connected, press the TEL button, then select "Phone" menu, then "Select phone" then "Connect Bluetooth phone" then select the telephone required or "Search phone". Press OK at each step to confirm.



07 MAKING A TELEPHONE CALL

USING THE INTERNAL TELEPHONE WITH SIM CARD


If you have declined to use the internal telephone for personal calls, you can still connect a Bluetooth telephone to receive your calls on the vehicle's audio system.

1



Extract the holder by pressing the eject button.

2



Install the SIM card in the holder and then insert it in the slot.

3

To remove the SIM card, repeat step 1.



For safety reasons and because they require prolonged attention on the part of the driver, the SIM card installation operations must be carried out when stationary.

1



Enter the PIN code on the keypad then select OK and confirm.

REMEMBER PIN



When entering your PIN code, tick the "Remember PIN" tab to gain access to the telephone without having to enter this code when it is used subsequently.

2



The system asks "Do you want to switch to the internal phone?", select "Yes" if you wish to use your SIM card for your personal calls. Otherwise, only the emergency call and the services will use the SIM card.



Once the SIM card has been installed, the system can synchronise the address book and the call list. This synchronisation may take a few minutes.

RECEIVING A CALL

- 1 An incoming call is announced by a ring and a superimposed display on the screen.

- 2 Select the "Yes" tab to accept or "No" to refuse and confirm by pressing OK.



YES NO



- 3 The PICK UP TEL button accepts, the HANG UP TEL button refuses the incoming call.




To hang up, press the HANG UP TEL button or press OK and select "End call" then confirm by pressing OK.

END CALL



- 4 Press the end of the steering wheel control to accept the call or end the call in progress.



MAKING A CALL

- 1 Press the PICK UP TEL button.



- 2 The list of the last 20 calls made and received in the vehicle appears under "Phone" menu. You can select a number and press OK to make the call.

- 2 Select the "Phone" menu function and press OK to confirm.



"PHONE" MENU



- 3 Select "Dial number", then dial the telephone number using the virtual keypad.



DIAL NUMBER



- 4 It is also possible to select a number from the address book. You can select "Dial from address book". The PC Com 3D permits the recording of up to 4 096 entries.

- 5 Press the end of the steering wheel control for more than two seconds to gain access to the address book.



Warning, the emergency call and the services are only active if the internal telephone is used with a valid SIM card. With a Bluetooth telephone and without a SIM card, these services are not operational.

EMERGENCY CALL EXCEPT PC Com 3D CONTROL PANEL

SOS



In an emergency, press the SOS button until an audible signal is heard and a "Confirmation/Cancellation" screen is displayed (if valid SIM card inserted). A call is made to the emergency services (112). In certain countries*, this emergency call is made directly by the PEUGEOT Emergency team which locates the vehicle and alerts the appropriate emergency services as quickly as possible.



If necessary, the internal telephone is activated automatically to make an emergency call.

* On condition that the PEUGEOT Emergency contract has been signed. This is free and of unlimited duration. Consult a PEUGEOT dealer.

CONSULTING THE SERVICES



Press this button to gain access to the PEUGEOT services*.



Select "Customer call" to request any information about the PEUGEOT marque.

CUSTOMER CALL



Select "PEUGEOT Assistance" to make a breakdown assistance call.

PEUGEOT ASSISTANCE



* These services and options are subject to conditions and availability.

08 CONFIGURATION

SETTING THE DATE AND TIME

1



Press the SETUP button.



2



Select the "Date & Time" function and press OK to confirm.

DATE & TIME



3



Select the "Set date & time" function and press OK to confirm.

SET DATE & TIME



4



Set the parameters using the ring and move on to the next by moving the 4-direction navigator. Press OK to confirm.



This function provides access to the options according to the SETUP flow chart.

Principle of the GPS synchro (GMT):

1. Confirm the "Synchronise with GPS" selection, the time is then set to GMT universal time, the date is also updated.
2. Using the 4-direction navigator, move to the time fields and press OK.
3. You can then use the ring to set the time to the time zone of your choice.

Take care when changing between summer/winter time, the time zone must be changed again manually.

5



Select the "Date format" function and press OK to confirm.
Select the format required using the ring and press OK to confirm.



6



Select the "Time format" function and press OK to confirm.
Select the format required using the ring and press OK to confirm.



Pressing the SETUP button for more than 2 seconds permits access to:

DESCRIPTION OF THE UNIT

GPS COVERAGE

DEMO MODE

09 VOICE COMMANDS AND STEERING WHEEL CONTROLS

STEERING WHEEL CONTROLS

Wipers stalk: displaying of "RADIO" and "MEDIA".

Lights stalk: activation of the voice command by means of a short press; indication of the current navigation instruction by means of a long press.

RADIO: selection of the next stored station.

Audio CD: selection of the next track.

If "MEDIA" is displayed on the screen:

MP3 CD/CARD/JUKEBOX: selection of the next directory.

CD CHANGER: selection of the next CD.

Selection of the next entry in the address book.

RADIO: automatic search for a higher frequency.

CD/SD CARD/JUKEBOX/CD CHANGER: selection of the next track.

CD/SD CARD/JUKEBOX/CD CHANGER: continuous press: fast forward play.

Volume increase.

- Change the sound source.
- Make a call from the address book.
- Pick up/Hang up the telephone.
- Press for more than 2 seconds: access to the address book.

Mute: by pressing the volume increase and decrease buttons simultaneously.

Restore the sound: by pressing one of the two volume buttons.

Volume decrease.

RADIO: selection of the previous stored station.

Audio CD: selection of the previous track.

If "MEDIA" is displayed on the screen:

MP3 CD/SD CARD/JUKEBOX: selection of the previous directory.


CD CHANGER: selection of the previous CD.

Selection of the previous entry in the address book.

RADIO: automatic search for a lower frequency.

CD/SD CARD/JUKEBOX/CD CHANGER: selection of the previous track.

CD/SD CARD/JUKEBOX/CD CHANGER: continuous press: fast backward play.



VOICE COMMANDS - VOICE RECO. INITIATION



1

Before using the system for the first time, you are advised to listen to, say and repeat the instructions for use.

2



Press the SETUP button and select the "Language & Speech" function. Turn the ring and select "Voice control". Activate the voice recognition. Select "Tutorial".



The phrases to be spoken according to the context are indicated in the tables below. Speak and PC Com 3D acts.



Long press: activates the voice recognition.

CONTEXT	SAY	ACTION
GENERAL	Help address book Help voice control Help media Help navigation Help telephone Help radio Cancel Correction	Access to the address book help Access to the voice reco help Access to the media management help Access to the guidance, navigation help Access to the telephone help Access to the radio help To cancel a voice command which is in progress Request to correct the last voice recognition carried out Clear
RADIO	Select station Station <tts:stationName> Read out station list Enter frequency Select wave band AM FM TA on TA off	Select a radio station Select a radio station using its RDS description <tts:station Name> from the RADIO list Listen to the list of stations available Listen to the frequency of the current radio station Choose the frequency waveband (AM or FM) Change the frequency waveband to AM Change the frequency waveband to FM Activate the Traffic Info (TA) Deactivate the Traffic Info
NAVIGATION	Destination input Voice advice off Voice advice on Save address Start guidance Abort guidance Navigate entry POI Search	Command to enter a new destination address Deactivate the spoken guidance instructions Activate the spoken guidance instructions Save an address in the address book Start guidance (once the address has been entered) Stop the guidance Start guidance to a file in the address book Start guidance to a point of interest

VOICE COMMANDS - VOICE RECO. INITIATION



CONTEXT	SAY	ACTION
MEDIA	Media Select media Single slot Jukebox USB External device Changer SD-Card Track <1 - 1000> Disc <1 - 6> Folder <1 - 1000>	Select the MEDIA source Choose a source Select the CD player source Select the Jukebox source Select the USB reader source Select the audio AUX input source Select the CD changer source Select the SD card source Select a specific track (number between 1 and 1 000) on the active MEDIUM Select a CD (number between 1 and 6) in the CD changer to be activated Select a Folder (number between 1 and 1 000) on the active MEDIUM
TELEPHONE	Phone menu Enter number Phone book Dial Save number Accept Reject	Open the Telephone Menu Enter a telephone number to be called Open the phone book Make a call Save a number in the phone book Accept an incoming call Refuse an incoming call
ADDRESS BOOK	Address book menu Call <entry> Navigate <entry>	Open the address book Call file using its description <file> as described in the address book Start guidance to an address in the address book using its description <file>

10 DISPLAY FLOW CHARTS



1 MAIN FUNCTION

- 2 CHOICE A
- 3 choice A1
- 3 choice A2
- 2 CHOICE B...

TRAFFIC

1 "TRAFFIC" MENU

2 SELECT PREFERRED LIST

- 3 Messages on route
- 3 Only warnings on route
- 3 All warning messages
- 3 All messages
- 3 Geo. Filter
 - 4 Deactivate PIN
 - 4 Within 2 miles (3 km)
 - 4 Within 3 miles (5 km)
 - 4 Within 6 miles (10 km)
 - 4 Within 30 miles (50 km)

2 READ OUT SETTINGS

- 3 On confirmation
- 3 Incoming messages

2 TMC STATION INFORMATION

MEDIA

1 "MEDIA" MENU

2 SELECT MEDIA

- 3 Audio CD/MP3-Disc/DVD-Audio/DVD-Video
- 3 Changer
- 3 Jukebox (Folders & Files)
- 3 SD-Card
- 3 USB
- 3 External device (audio/AV)

2 JUKEBOX MANAGEMENT

- 3 Add files
- 3 Create folder
- 3 Modify content
- 3 Edit playlist
- 3 Play options
 - 4 Folders & Files
 - 4 Playlists
- 3 Memory capacity

2 SOUND SETTINGS

Refer to the "Sound settings" menu details of which are shown on the next page.

2 VIDEO SETTINGS

- 3 Aspect ratio
- 3 Menu language
- 3 Display
 - 4 Brightness
 - 4 Contrast
 - 4 Colour

3 AUX standard

3 Reset video settings

2 EXT. DEVICE (AUX) MANAGEMENT

- 3 Off/Audio/Audio and Video (AV)



1 "RADIO" MENU

2 WAVEBAND

3 FM

3 AM

2 MANUAL TUNE

2 SOUND SETTINGS

Refer to the "Sound settings" menu below.

1 "SOUND SETTINGS" MENU

2 BALANCE/FADER

2 BASS/TREBLE

2 EQUALIZER

3 Linear

3 Classic

3 Jazz

3 Rock/Pop

3 Techno

3 Vocal

2 MUTE REAR SPEAKERS

2 LOUDNESS

2 SPEED DEPENDENT VOLUME

2 RESET SOUND SETTINGS



1 "NAVIGATION" MENU

2 ABORT GUIDANCE/RESUME GUIDANCE

2 DESTINATION INPUT

3 Address input

4 Country

4 City

4 Street

4 House number

4 Start route guidance

4 Postal code

4 Save to address book

4 Intersection

4 City district

4 Geo position

4 Map

3 Navigate HOME

3 Choose from last destinations

3 Choose from address book

2 STOPOVERS

3 Add stopover

4 Address input

4 Navigate HOME

4 Choose from address book

4 Choose from last destinations

3 Rearrange route

3 Replace stopover

3 Delete stopover

3 Recalculate

4 Fast route

4 Short route

4 Optimized route

2 POI SEARCH

3 POI nearby

3 POI near destination

3 POI in city

3 POI in country

3 POI near route

2 ROUTE OPTIONS

3 Route type

4 POI near destination

4 Short route

4 Optimized route

4 Subscr. service

2 SETTINGS

3 Route dynamics

4 Traffic independent

4 Semi-dynamic

4 Dynamic

3 Avoidance criteria

4 Avoid motorways

4 Avoid toll roads

4 Avoid tunnels

4 Avoid ferries

3 Recalculate



1 "ADDRESS BOOK" MENU

2 CREATE NEW ENTRY

2 SHOW MEMORY STATUS

2 EXPORT ADDRESS BOOK

2 DELETE ALL VOICE ENTRIES

2 DELETE ALL ENTRIES

2 DELETE FOLDER "MY ADDRESSES"



1 "PHONE" MENU

2 DIAL NUMBER

2 DIAL FROM ADDRESS BOOK

2 CALL LISTS

2 MESSAGES

2 SELECT PHONE

3 Telephone off

3 Use Bluetooth phone

3 Use internal phone

3 Connect Bluetooth phone

4 Search phone

5 Disconnect phone

5 Rename phone

5 Delete pairing

5 Delete all pairings

5 Show details

2 SETTINGS

3 Automatic answering system

3 Select ring tone

3 Phone/Ring tone volume

3 Enter mailbox number

3 Internal phone settings

4 Automatically accept call

4 Signal waiting call (?)

5 Show status

5 Activate waiting call

5 Deactivate waiting call

4 Call forward (?)

5 Show status

5 Activate call forward

5 Deactivate call forward

4 Suppress own number

4 Select network

5 Set network automatically

5 Set network manually

5 Search for networks

4 PIN settings

5 Change PIN

5 Activate PIN

5 Deactivate PIN

5 Remember PIN

4 SIM-card memory status



1 "SETUP" MENU

2 LANGUAGE & SPEECH

3 Menu language

- 4 Deutsch
- 4 English
- 4 Español
- 4 Français
- 4 Italiano
- 4 Nederlands
- 4 Polski
- 4 Portuguese

3 Voice control

- 4 Voice control active
- 4 Tutorial
 - 5 Basics
 - 5 Examples
 - 5 Tips
- 4 Speaker adaptation
 - 5 New speaker adaptation
 - 5 Delete speaker adaptation

3 Voice output volume

2 DATE & TIME

3 Set date & time

3 Date format

3 Time format

2 DISPLAY

3 Brightness

3 Colour

- 4 Steel
- 4 blue light (only in day mode)
- 4 Orange Ray
- 4 Blue Flame

3 Map colour

- 4 Day mode for map
- 4 Night mode for map
- 4 Auto. Day/Night for map

2 UNITS

3 Temperature

- 4 Celsius
- 4 Fahrenheit

3 Metric/Imperial

- 4 km
- 4 Miles

2 SYSTEM

3 Factory reset

3 Software version

3 Automatic scrolling

FREQUENTLY ASKED QUESTIONS

The table below groups together the answers to the most frequently asked questions concerning the PC Com 3D.


QUESTION	RESPONSE	SOLUTION
There is a difference in sound quality between the different audio sources (radio, CD, CD changer...).	For optimum sound quality, the audio settings (Volume, Bass, Treble, Ambience, Loudness) can be adapted to the different sound sources, which may result in audible differences when changing source (radio, CD, CD changer...).	Check that the audio settings (Volume, Bass, Treble, Ambience, Loudness) are adapted to the sources listened to. It is advisable to set the AUDIO functions (Bass, Treble, Front-Rear Balance, Left-Right Balance) to the middle position, select the musical ambience "Linear" and set the loudness correction to the "Active" position in CD mode or to the "Inactive" position in radio mode.
The CD is ejected automatically or is not played by the player.	The CD is inserted upside down, is unplayable, does not contain any audio data or contains an audio format which the player cannot play. The CD is protected by an anti-pirating protection system which is not recognised by the audio equipment.	- Check that the CD is inserted in the player the right way up. - Check the condition of the CD: the CD cannot be played if it is too damaged. - Check the content in the case of a recorded CD: consult the advice in the "Audio" section. - The audio equipment's CD player does not play DVDs. - Due to inadequate quality, certain recorded CDs will not be played by the audio system. - The CD changer does not play MP3 CDs.
The CD player sound is poor.	The CD used is scratched or of poor quality.	Insert good quality CDs and store them in suitable conditions.
	The audio equipment settings (bass, treble, ambiences) are unsuitable.	Set the treble or bass level to 0, without selecting an ambience.

QUESTION	RESPONSE	SOLUTION
The stored stations do not function (no sound, 87.5 Mhz is displayed...)	An incorrect waveband is selected.	Press RADIO, select "Radio" Menu then "Waveband" to return to the waveband on which the stations are stored.
The quality of reception of the radio station listened to gradually deteriorates or the stored stations do not function (no sound, 87.5 Mhz is displayed...).	The vehicle is too far from the transmitter used by the station listened to or there is no transmitter in the geographical area through which the vehicle is travelling.	Activate the "RDS" function by means of the short-cut menu to enable the system to check whether there is a more powerful transmitter in the geographical area.
	The environment (hills, buildings, tunnels, basement car parks...) block reception, including in RDS mode.	This phenomenon is normal and does not indicate a failure of the audio equipment.
	The aerial is absent or has been damaged (for example when going through a car wash or into an underground car park).	Have the aerial checked by a PEUGEOT dealer.
Sound cut-outs of 1 to 2 seconds in radio mode.	During this brief sound cut-out, the RDS searches for any frequency permitting better reception of the station.	Deactivate the "RDS" function by means of the short-cut menu if the phenomenon is too frequent and always on the same route.
With the engine off, the system switches off after a few minutes of use.	When the engine is switched off, the system's operating time depends on the battery charge. The switch-off is normal: the system switches to economy mode and switches off to prevent discharging of the vehicle's battery.	Start the vehicle's engine to increase the battery charge.

QUESTION	RESPONSE	SOLUTION
The "TA" box is ticked. However, certain traffic jams along the route are not indicated in real time.	On starting, it is several minutes before the system begins to receive the traffic information.	Wait until the traffic information is being received correctly (displaying of the traffic information symbols on the map).
	In certain countries, only major routes (motorways...) are listed for the traffic information.	This phenomenon is normal. The system is dependent on the traffic information available.
The time taken to calculate a route sometimes seems longer than usual.	The performance of the system may slow down temporarily if a CD/DVD is being copied onto the Jukebox at the same time as a route is being calculated.	Wait until the CD/DVD has been copied or stop the copying before starting the guidance function.
Does the emergency call function work without a SIM card?	No, European regulations impose the presence of a SIM card in order to make an emergency call.	Insert a valid SIM card in the slot.
The altitude is not displayed.	On starting, the initialisation of the GPS may take up to 3 minutes to receive more than 4 satellites correctly.	Wait until the system has started up completely. Check that there is a GPS coverage of at least 4 satellites (long press on the SETUP button, then select "GPS coverage").
	Depending on the geographical environment (tunnel...) or the weather, the conditions of reception of the GPS signal may vary.	This phenomenon is normal. The system is dependent on the conditions of reception of the GPS signal.
The route calculation is not successful.	The exclusion criteria may conflict with the current location (exclusion of toll roads on a toll motorway).	Check the exclusion criteria on the "Navigation" Menu ("Route options" - "Avoidance criteria").

QUESTION	RESPONSE	SOLUTION
There is a long waiting period following the insertion of a CD or SD card.	When a new medium is inserted, the system reads a certain amount of data (directory, title, artist, etc.). This may take a few seconds.	This phenomenon is normal.
I cannot connect my Bluetooth telephone.	The telephone's Bluetooth function may be switched off or the equipment may not be visible.	- Check that your telephone's Bluetooth function is switched on. - Check that your telephone is visible.
	The Bluetooth telephone is not compatible with the system.	A list of compatible Bluetooth mobile telephones is available from the dealer network.
The system does not play the DVD.	The region protection may not be compatible.	Insert DVDs which have compatible region protection.
I cannot copy the CD to the Jukebox.	The wrong source is selected.	Change the active source to CD.
	The CD is copy-protected.	It is normal that a protected CD cannot be copied.
The system does not receive SMS.	The Bluetooth mode does not permit sending of the SMS to the system.	Use your SIM card and the internal telephone.
	The SIM card used is a twin card.	Use the original SIM card to receive the SMS.

QUESTION	RESPONSE	SOLUTION
I cannot update the hazardous location POIs.	The "Navigation" Menu - "Update personal POI" is not displayed. An error message is displayed at the end of the procedure.	Check that the medium used for the update (SD card or USB stick) is inserted correctly. - Start the procedure again in full. - Consult a PEUGEOT dealer if the problem persists. - Check that the data on the MEDIUM is supplied by an official partner of PEUGEOT.
The voice frequencies (DTMF) are not active when I am communicating and I press numbers on the keypad.	The numeric buttons on the keypad are only active for calls if the display is in telephone mode.	To activate them, press the MODE button until the telephone is displayed on the screen.
An accident area which does not concern me is displayed on the screen.	The accident areas are displayed near a point defined on the map and in relation to a direction of travel.	The alert may be triggered when travelling under a road or near a road which has a speed camera.



PC Nav

MULTIMEDIA AUDIO EQUIPMENT/BLUETOOTH TELEPHONE

GPS EUROPE BY SD CARD

CONTENTS

- **01 First steps** pg. 203
- **02 General operation** pg. 205
- **03 Navigation - Guidance** pg. 207
- **04 Traffic information** pg. 214
- **05 Radio** pg. 215
- **06 Music media players** pg. 216
- **07 Bluetooth telephone** pg. 219
- **08 Configuration** pg. 221
- **09 Steering wheel controls** pg. 223
- **10 Display flow charts** pg. 224
- **Frequently asked questions** pg. 227



The PC Nav is protected in such a way that it will only operate in your vehicle. If it is to be installed in another vehicle, contact a PEUGEOT dealer for configuration of the system.





For safety reasons, it is imperative that the driver carries out operations which require prolonged attention while the vehicle is stationary. When the engine is switched off and to prevent discharging of the battery, the PC Nav switches off following the activation of the Energy Economy mode.



Certain functions described in this handbook will become available during the course of the year.


FIRST STEPS 01

PC NAV CONTROL PANEL



01 FIRST STEPS

PC NAV CONTROL PANEL




1. Engine not running
- Short press: on/off.
- Long press: CD pause, mute for the radio.
Engine running
- Short press: CD pause, mute for the radio.
- Long press: reinitialisation of the system.
2. Volume adjustment.
3. Access to the RADIO menu. Displaying of the list of stations.
4. Access to the MUSIC menu. Displaying of the tracks.
- 3 - 4 Long press: access to the settings: front/rear and left/right balance, bass/treble, equalizer, loudness, automatic volume adjustment, initialise the settings.
5. Access to the SETUP menu.
Long press: access to the GPS coverage and the demonstration mode.
6. Access to the PHONE menu. Displaying of the call list.
7. Access to the MODE menu.
Selection of the successive displaying of:
Radio, Map, NAV (if navigation is in progress), Telephone (if a conversation is in progress), Trip Computer.
Long press: displaying of a black screen (DARK).
8. Access to the NAVIGATION menu.
Displaying of the last destinations.
9. Access to the TRAFFIC menu.
Displaying of the current traffic alerts.
10. ESC: abandon the operation in progress.
11. CD eject.
12. Selection of the previous/next radio station from the list.
Selection of the previous/next CD.
Selection of the previous/next MP3 directory.
Selection of the previous/next page of a list.
13. Selection of the previous/next radio station.
Selection of the previous/next CD or MP3 track.
Selection of the previous/next line of a list.
14. Buttons 1 to 6:
Selection of the stored radio station.
Selection of the CD in the CD changer.
Long press: storing of the current radio station.
15. SD card reader.
16. Dial for selection on the display on the screen and according to the context of the menu.
Short press: confirmation.

GENERAL OPERATION 02

Press the **MODE** button several times in succession to gain access to the following menus:

RADIO/MUSIC MEDIA PLAYERS




TELEPHONE

(If a conversation is in progress)



TRIP COMPUTER



FULL SCREEN MAP



NAVIGATION (If guidance is in progress)



SETUP:

system language, date and time, display, vehicle parameters, units and system parameters, DEMONSTRATION mode.



TRAFFIC:

TMC information and messages



For maintenance of the screen, the use of a soft, non-abrasive cloth (spectacles cloth) is recommended, without any additional product.



For a detailed global view of the menus available, refer to section 10.

02 GENERAL OPERATION

DISPLAY ACCORDING TO THE CONTEXT



A press on the OK dial to permits access to short-cut menus according to the display on the screen.

NAVIGATION (IF GUIDANCE IS IN PROGRESS):

- 1 ABORT GUIDANCE
- 1 REPEAT ADVICE
- 1 BLOCK ROAD
- 1 ROUTE INFO
 - 2 show dest.
 - 2 trip info
 - 3 route type
 - 3 avoidance criteria
 - 3 satellites
 - 2 zoom/scroll
- 1 VOICE ADVICE
- 1 ROUTE OPTIONS

TRIP COMPUTER:

- 1 ALERT LOG
- 1 STATUS OF FUNCTIONS

TELEPHONE:

- 1 END CALL
- 1 HOLD CALL
- 1 DIAL
- 1 DTMF TONES
- 1 PRIVATE MODE
- 1 MICRO OFF

MUSIC MEDIA PLAYERS:

- 1 TA
- 1 PLAY OPTIONS
 - 2 normal
 - 2 random track
 - 2 repeat folder
 - 2 track intro
- 1 SELECT MUSIC

RADIO:

- 1 IN FM MODE
 - 2 TA
 - 2 RDS
 - 2 radiotext
 - 2 regional prog. (REG)
 - 2 AM
- 1 IN AM MODE
 - 2 TA
 - 2 refresh AM list
 - 2 FM

FULL SCREEN MAP:


- 1 ABORT/RESUME GUIDANCE
- 1 SET DESTINATION
- 1 POIS NEARBY
- 1 POSITION INFO
- 1 MAP SETTINGS
- 1 ZOOM/SCROLL

03 NAVIGATION - GUIDANCE


SELECTING A DESTINATION

Insert the SD card in the front panel reader and leave it there to use the Navigation functions.
The navigation SD card data must not be changed.
The map data updates are available from PEUGEOT dealers.

1



Press the NAV button.



The list of the last 20 destinations appears under the NAVIGATION MENU function.

2



Press the NAV button again or select the NAVIGATION MENU function and press the dial to confirm.

NAVIGATION MENU



3



Select the DESTINATION INPUT function and press the dial to confirm.

DESTINATION INPUT



4



Select the NEW DESTINATION INPUT function and press the dial to confirm.

NEW DESTINATION INPUT



5



Once the country has been selected, turn the dial and select the town function. Press the dial to confirm.




6



Select the letters of the town one by one confirming each time by pressing the dial.



A pre-set list (by entering the first few letters) of the towns in the country selected can be accessed via the LIST button on the virtual keypad.




During guidance, pressing the end of the lights stalk repeats the last guidance instruction.

7



Turn the dial and select OK.
Press the dial to confirm.




To speed up the process, the post code can be entered directly after selecting the POST CODE function. Use the virtual keypad to enter the letters and digits.

8



Repeat steps 5 to 7 for the STREET
and N° functions.



Select the SAVE TO ADDRESS BOOK function to record the address entered in a directory file. Press the dial to confirm the selection. PC Nav permits the recording of up to 4 000 contact files.

i

To clear a destination; from steps 1 to 3, select FROM LAST DESTINATIONS.
A long press on one of the destinations displays a list of actions from which you can select DELETE DESTINATION/CLEAR LAST DESTINATIONS.

9



Then select START ROUTE GUIDANCE and press the dial to confirm.


START ROUTE GUIDANCE



10



Select the route type:
FAST ROUTE, SHORT ROUTE or
OPTIMISED ROUTE and press the
dial to confirm.



It is also possible to select a destination FROM ADDRESS BOOK or FROM LAST DESTINATIONS.

FROM ADDRESS BOOK

FROM LAST DESTINATIONS




You can zoom in/zoom out on the map using the dial.
It is possible to scroll the map or select its orientation via the short-cut menu of the FULL SCREEN MAP. Press the dial then select MAP SETTINGS or ZOOM/SCROLL and confirm.

03 NAVIGATION - GUIDANCE


ROUTE OPTIONS

The route selected by the PC Nav audio/telephone depends directly on the route options. Changing these options may change the route completely.

1



Press the NAV button.



2



Press the NAV button again or select the NAVIGATION MENU function and press the dial to confirm.

NAVIGATION MENU



3



Select the ROUTE OPTIONS function and press the dial to confirm.

ROUTE OPTIONS



4



Select the ROUTE TYPE function and press the dial to confirm. This function allows you to change the route type.

ROUTE TYPE




5



Select the ROUTE DYNAMICS function. This function provides access to the TRAFFIC INDEPENDENT or SEMI-DYNAMIC options.

ROUTE DYNAMICS



6



Select the AVOIDANCE CRITERIA function. This function provides access to the AVOID options (motorways, toll roads, ferries).

AVOIDANCE CRITERIA



7



Turn the dial and select the RECALCULATE function to take into account the route options selected. Press the dial to confirm.

RECALCULATE



ADDING A STOPOVER

Stopovers can be added to the route once the destination has been selected.


ADDING A STOPOVER

Stopovers can be added to the route once the destination has been selected.

1




Press the NAV button.



1




Press the NAV button.



2  Press the NAV button again or select the NAVIGATION MENU function and press the dial to confirm.

NAVIGATION MENU




2  Press the NAV button again or select the NAVIGATION MENU function and press the dial to confirm.

NAVIGATION MENU


2  Press the NAV button again or select the NAVIGATION MENU function and press the dial to confirm.

NAVIGATION MENU



4  Select the ADD A STOPOVER function (5 stopovers maximum) and press the dial to confirm.

ADD A STOPOVER




4  Select the ADD A STOPOVER function (5 stopovers maximum) and press the dial to confirm.

ADD A STOPOVER

4  Select the ADD A STOPOVER function (5 stopovers maximum) and press the dial to confirm.

ADD A STOPOVER




5



Enter a new address, for example.

ENTER AN NEW ADDRESS



5



Enter a new address, for example.


ENTER AN NEW ADDRESS

5




Enter a new address, for example.

ENTER AN NEW ADDRESS



6  Once the new address has been entered, select OK and press the dial to confirm.






6  Once the new address has been entered, select OK and press the dial to confirm.




6  Once the new address has been entered, select OK and press the dial to confirm.





7

Select RECALCULATE and press the dial to confirm.





7

Select RECALCULATE and press the dial to confirm.

7

Select RECALCULATE and press the dial to confirm.




 The stopover must be completed or deleted in order for the guidance to continue to the next destination. Otherwise, the PC Nav will always return you to the previous stopover.

03 NAVIGATION - GUIDANCE

SEARCHING FOR POINTS OF INTEREST


The points of interest (POIs) indicate all of the service locations in the vicinity (hotels, various businesses, airports...).

- 1  Press the NAV button.




- 2  Press the NAV button again or select the NAVIGATION MENU function and press the dial to confirm.

NAVIGATION MENU



- 3  Select the SEARCH POINTS OF INTEREST function and press the dial to confirm.

SEARCH POINTS OF INTEREST



- 4  Select the POI NEARBY function to search for POIs around the vehicle.

POI NEARBY



- 5  Select the POI NEAR DESTINATION function to search for POIs near the point of arrival of the route.

POI NEAR DESTINATION



- 6  Select the POI IN CITY function to search for POIs in the city required. Select the country then enter the name of the city using the virtual keypad.

POI IN CITY



A list of cities present in the country selected can be accessed via the LIST button on the virtual keypad.

- 7  Select the POI IN COUNTRY function to search for POIs in the country required.

POI IN COUNTRY



- 8  Select the POI NEAR ROUTE function to search for POIs near the route.

POI NEAR ROUTE



03 NAVIGATION - GUIDANCE

This icon appears when several POIs are grouped together in the same area. Zooming in on this icon shows details of the POIs.



List of POIs

-   Service station
-  LPG station
-   Garage
-  PEUGEOT
-  Motor racing circuit
-  Covered car park
-   Car park
-  Rest area
-   Hotel
-   Restaurant
-  Refreshment area
-  Picnic area
-  Cafeteria

-   Airport
-  Railway station
-  Bus station
-  Port
-   Industrial estate
-  Supermarket
-  Bank
-  Vending machine
-   Tennis court
-  Swimming pool
-  Golf course
-  Winter sports resort
-  Theatre

-  Cinema
-  Camp site
-  Theme parks
-   Hospital
-  Pharmacy
-  Police station
-  School
-  Post office
-   Museum
-   Tourist information
-  Automatic speed camera*
-  Red light camera*
-  Hazardous location*


* according to availability in the country

03 NAVIGATION - GUIDANCE


NAVIGATION SETTINGS

Contact a PEUGEOT dealer for details of the procedure for obtaining the HAZARDOUS LOCATION POIs.
The updating of the HAZARDOUS LOCATION POIs requires an SDHC (High Capacity) compatible reader.

1



Press the NAV button.



2



Press the NAV button again or select the NAVIGATION MENU function and press the dial to confirm.

NAVIGATION MENU




3



Select the SETTINGS function and press the dial to confirm.

SETTINGS



4



Select the NAVI VOLUME function and turn the dial to set the volume of each voice synthesiser (traffic information, alert messages...).

NAVI VOLUME



5



Select the POI CATEGORIES ON MAP function to select the POIs to be displayed on the map by default.

POI CATEGORIES ON MAP



6



Select HAZARDOUS LOCATION POIs to gain access to the DISPLAY ON MAP, VISUAL ALERT and SOUND ALERT functions.

HAZARDOUS LOCATION POIs




04 TRAFFIC INFORMATION

CONFIGURE THE FILTERING AND DISPLAYING OF THE TMC MESSAGES

1



Press the TRAFFIC button.




The list of TMC messages appears under the TRAFFIC MENU sorted in order of proximity.

2



Press the TRAFFIC button again or select the TRAFFIC MENU function and press the dial to confirm.

TRAFFIC MENU



The TMC icon, at the bottom left of the screen, may appear in 3 different forms:

- No TMC station available,
- TMC station available, no message on route,
- TMC station available and messages on route (if guidance is active).

The filters are independent and their results are cumulative.

We recommend a filter on the route and a filter around the vehicle of:

- 2 miles (3 km) or 3 miles (5 km) for a region with heavy traffic,
- 6 miles (10 km) for a region with normal traffic,
- 30 miles (50 km) for long journeys (motorway).

3



Select the filter of your choice:

ALL MESSAGES ON ROUTE

WARNING MESSAGES ON ROUTE

ONLY WARNING MESSAGES

ALL MESSAGES

The messages appear on the map and on the list.

To exit, press ESC.



4



Select the GEOGRAPHICAL FILTER (NONE) function and press the dial to confirm.

GEOGRAPHICAL FILTER (NONE)



5



On the list which appears, select the radius of the filter (in miles (km)) required in accordance with the route. Press the dial to confirm the selection. When all of the messages on the route are selected, the addition of a geographical filter is recommended (within a radius of 3 miles (5 km) for example) to reduce the number of messages displayed on the map. The geographical filter follows the movement of the vehicle.



05 RADIO


The external environment (hill, building, tunnel, underground car park...) may interfere with the reception, including in RDS following mode. This phenomenon is a normal result of the way in which radio waves are transmitted and does not in any way indicate a failure of the audio equipment.

SELECTING A STATION


1




Press the RADIO button to display the list of stations received locally sorted in alphabetical order. Select the station required by turning the dial and press to confirm.



While listening to the radio, press one of the buttons to select the previous or next station on the list.



A long press of one of the buttons starts the automatic search for a station with a lower or higher frequency.



Press one of the buttons on the numeric keypad for more than 2 seconds to store the current station. Press the button on the numeric keypad to recall the stored radio station.

RDS - REGIONAL MODE - TRAFFIC INFO

1




When the current radio station is displayed on the screen, press the dial.



2

The radio source short-cuts menu appears and provides access to the following short-cuts:



3



Select the function required and press the dial to confirm to gain access to the corresponding settings.



The RDS, if displayed, allows you to continue listening to the same station by means of the frequency following. However, in certain conditions, this RDS station cannot be followed throughout the entire country as radio stations do not cover 100 % of the territory. This explains the loss of reception of the station during a journey.

06 MUSIC MEDIA PLAYERS

CD, MP3/WMA CD, MP3/WMA SD CARD INFORMATION AND ADVICE



The MP3 format, an abbreviation of MPEG 1,2 & 2.5 Audio Layer 3 and the WMA format, an abbreviation of Windows Media Audio and the property of Microsoft, are audio compression standards which permit the recording of several tens of music files on a single disc.



In order to be able to play a recorded CDR or CDRW, when recording it is preferable to select the ISO 9660 level 1, 2 or Joliet standard.

If the disc is recorded in another format it may not be played correctly.

It is recommended that the same recording standard is always used for an individual disc, with as low a speed as possible (4x maximum) for optimum sound quality.

In the particular case of a multi-session CD, the Joliet standard is recommended.

If the GPS is used, the navigation SD card must remain in the PC Nav reader.
In this case, it is not possible to play an SD card containing MP3 files.



The PC Nav will only play audio files with the extension ".mp3" with a speed of between 8 Kbps and 320 Kbps and the extension ".wma" with a speed of between 5 Kbps and 384 Kbps.
It also supports the VBR (Variable Bit Rate) mode.
No other type of file (.mp4, .m3u...) can be played.



It is advisable to restrict file names to 20 characters, without using of special characters (e.g.: " " ? ; ù) to avoid any playing and displaying problems.



During play, exit the SD Card mode before removing the SD card from its reader.



To avoid any risk of theft, remove the SD card when you leave your vehicle with the roof open.


SELECTING/PLAYING MUSIC

CD, MP3/WMA CD, MP3/WMA SD CARD

1



Press the MUSIC button.



!

The list of tracks or MP3/WMA files appears under MUSIC MENU.

2



Press the MUSIC button again or select the MUSIC MENU function and press the dial to confirm.

MUSIC MENU




3



Select the SELECT MUSIC function and press the dial to confirm.

SELECT MUSIC



4




Select the music source required: CD, MP3/WMA CD, MP3/WMA SD CARD... Press the dial to confirm. Play begins.



5




Press the up or down button to select the next/previous folder.



6



Press one of the buttons to select a music track. Press and hold one of the buttons for fast forward or rewind play.



The playing and displaying of an MP3/WMA compilation may depend on the recording programme and/or the parameters used. We recommend the ISO 9660 recording standard.

06 MUSIC MEDIA PLAYERS

USING THE EXTERNAL DEVICE (AUX) AUDIO/RCA CABLE NOT SUPPLIED


1

Connect the portable equipment (MP3/WMA player...) to the audio sockets (white and red, RCA type) in the glove box using a JACK/RCA audio cable.

2



Press the MUSIC button then press it again or select the MUSIC MENU function and press the dial to confirm.



3



Select the EXTERNAL DEVICE function and press the dial to activate it.

EXTERNAL DEVICE



4



Select the AUX music source and press the dial to confirm. Play begins automatically.



!

The displaying and management of the controls are operated via the portable equipment.

07 BLUETOOTH TELEPHONE



CONNECTING A TELEPHONE

The services available depend on the network, the SIM card and the compatibility of the Bluetooth equipment used. Refer to your telephone's manual and your operator to check which services you have access to. A list of mobile telephones which offer the best range of services is available from dealers.



For safety reasons and because they require prolonged attention on the part of the driver, the operations for pairing the Bluetooth mobile telephone to the hands-free system of the PC Nav must be carried out with the vehicle stationary and the ignition on.

1


Activate the telephone's Bluetooth function. The last telephone connected is reconnected automatically.



2



Press the PHONE button.




3



Select the TELEPHONE MENU function and press the dial to confirm.

TELEPHONE MENU




The list of telephones connected previously (4 maximum) appears on the multifunction display. Select the telephone required for a new connection.

4



For a first connection, select **SEARCH PHONE** and press the dial to confirm. Then select the name of the telephone.

SEARCH PHONE



5



Enter the authentication code on the telephone. The code to be entered is displayed on the screen.



Once the telephone has been connected, PC Nav can synchronise the address book and the call list. This synchronisation may take a few minutes.

1



To change the telephone connected, press the PHONE button, then select **TELEPHONE MENU** and press the dial to confirm.



2



Select **CONNECT PHONE**. Select the telephone and press to confirm.

CONNECT PHONE



RECEIVING A CALL

1

An incoming call is announced by a ring and a superimposed display on the multifunction display.

2



Select the YES tab to accept or NO to refuse and confirm by pressing the dial.

YES NO



3



To hang up, press the PHONE button or press the dial and select END CALL then confirm by pressing the dial.

END CALL



Press the end of the steering wheel control to accept the call or end the call in progress.




MAKING A CALL

1



Press the PHONE button.



The list of the last 20 calls made and received in the vehicle appears under TELEPHONE MENU. You can select a number and press the dial to make the call.

2



Select the TELEPHONE MENU function and press the dial to confirm.

TELEPHONE MENU



3



Select DIAL NUMBER, then dial the telephone number using the virtual keypad.

DIAL NUMBER



It is also possible to select a number from the address book. You can select DIAL FROM ADDRESS BOOK. PC Nav permits the recording of up to 4 000 entries.




Press the end of the steering wheel control for more than two seconds to gain access to the address book.

08 CONFIGURATION


SETTING THE DATE AND TIME

This function provides access to the options: SYSTEM LANGUAGE, DATE AND TIME, DISPLAY (BRIGHTNESS, COLOUR, MAP COLOUR), VEHICLE PARAMETERS, UNITS, SYSTEM PARAMETERS.

1



Press the SET UP button.



2



Select the DATE AND TIME function and press the dial to confirm.

DATE AND TIME



3



Select the SET DATE AND TIME function and press the dial to confirm.


SET DATE AND TIME



4



Set the parameters one by one using the direction arrows and confirm by means of the dial.



5



Select the DATE FORMAT function and press the dial to confirm.



6



Confirm the format required using the dial.
Select the TIME FORMAT function and press the dial to confirm.



Confirm the format required using the dial.
Pressing the SET UP button for more than 2 seconds permits access to:

DESCRIPTION OF THE UNIT

GPS COVERAGE

DEMO MODE

TRIP COMPUTER/VEHICLE PARAMETERS

VEHICLE DIAGNOSTICS



- The "vehicle" tab:
The range, the current consumption and the distance remaining.
- The "1" (trip 1) tab with :
The average speed, the average consumption and the distance travelled calculated over route "1".
- The "2" (trip 2) tab with the same functions for a second route.



Each press of the button at the end of the wiper stalk displays the different trip computer information in succession, according to the screen.

A FEW DEFINITIONS



Range: displays the distance which can be travelled with the remaining fuel detected in the tank, based on the average consumption over the last few miles (kilometres).

This displayed value may vary significantly following a change in the vehicle speed or the relief of the route.

When the range falls below 20 miles (30 km), dashes are displayed.

After filling with at least 5 litres of fuel, the range is recalculated and is displayed when it exceeds 60 miles (100 km).

If, whilst driving, dashes are displayed continuously in place of the digits, contact a PEUGEOT dealer.

Current fuel consumption: only calculated and displayed above 20 mph (30 km/h).

Average fuel consumption: this is the average fuel consumption since the last trip computer zero reset.

Distance travelled: calculated since the last trip computer zero reset.

Distance remaining to the destination: calculated with reference to the final destination, entered by the user. If guidance is activated, the navigation system calculates it as a current value.

Average speed: this is the average speed calculated since the last trip computer zero reset (ignition on).

09 STEERING WHEEL CONTROLS

RADIO: selection of the next stored station.
MP3/WMA SD CARD: selection of the next directory.
CD CHANGER: selection of the next CD.
Selection of the next entry in the address book.

RADIO: change to the next radio station on the list.
Long press: automatic search for a higher frequency.
CD/MP3 SD CARD/CD CHANGER: selection of the next track.
CD/MP3 SD CARD/CD CHANGER: continuous press: fast forward play.

Volume increase.

- Change the sound source.
- Make a call from the address book.
- Pick up/Hang up the telephone.
- Press for more than 2 seconds: access to the address book.


Mute: by pressing the volume increase and decrease buttons simultaneously.

Restore the sound: by pressing one of the two volume buttons.

Volume decrease.

RADIO: selection of the previous stored station.
MP3/WMA SD CARD: selection of the previous directory.
CD CHANGER: selection of the previous CD.
Selection of the previous entry in the address book.

RADIO: change to the previous radio station on the list.
Long press: automatic search for a lower frequency.
CD/MP3 SD CARD/CD CHANGER: selection of the previous track.
CD/MP3 SD CARD/CD CHANGER: continuous press: fast backward play.



10 DISPLAY FLOW CHARTS



1 MAIN FUNCTION

- 2 CHOICE A
- 3 choice A1
- 3 choice A2
- 2 CHOICE B...



1 "TRAFFIC" MENU

- 2 MESSAGES ON ROUTE
- 2 ONLY WARNINGS ON ROUTE
- 2 ALL WARNING MESSAGES
- 2 ALL MESSAGES
- 2 GEOGRAPHICAL FILTER
 - 3 none
 - 3 within 2 miles (3 km)
 - 3 within 3 miles (5 km)
 - 3 within 6 miles (10 km)
 - 3 within 30 miles (50 km)



1 "MUSIC" MENU

- 2 SELECT MUSIC
- 2 SOUND SETTINGS
 - 3 balance/fader
 - 3 bass/treble
 - 3 equalizer
 - 4 none
 - 4 classical
 - 4 jazz
 - 4 rock/pop
 - 4 techno
 - 4 vocal
 - 3 loudness
- 3 initialise sound settings



1 "RADIO" MENU

- 2 WAVEBAND
 - 3 FM
 - 3 AM
- 2 MANUAL TUNE
- 2 SOUND SETTINGS
 - 3 balance/fader
 - 3 bass/treble
 - 3 equalizer
 - 4 none
 - 4 classical
 - 4 jazz
 - 4 rock/pop
 - 4 techno
 - 4 vocal
 - 3 loudness
- 3 initialise sound settings



- 1 **"NAVIGATION" MENU**
- 2 **ABORT/RESUME GUIDANCE**
- 2 **DESTINATION INPUT**
- 3 **address input**
- 4 country
- 4 city
- 4 street
- 4 number
- 4 start route guidance
- 4 post code
- 4 add to address book
- 4 intersection
- 4 city district
- 4 geo position
- 4 map
- 3 **navigate HOME**
- 3 **choose from address book**
- 3 **choose from last destinations**

- 2 **STOPOVERS**
- 3 **add stopover**
- 4 address input
- 4 navigate HOME
- 4 choose from address book
- 4 choose from last destinations
- 3 **rearrange route**
- 3 **replace stopover**
- 3 **delete stopover**
- 3 **recalculate**
- 4 fast route
- 4 short route
- 4 optimised route
- 2 **POI SEARCH**
- 3 **POI nearby**
- 3 **POI near destination**
- 3 **POI in city**
- 3 **POI in country**
- 3 **POI near route**

- 2 **ROUTE OPTIONS**
- 3 **route type**
- 4 fast route
- 4 short route
- 4 optimised route
- 2 **SETTINGS**
- 3 **route dynamics**
- 4 traffic independent
- 4 semi-dynamic
- 3 **avoidance criteria**
- 4 avoid motorways
- 4 avoid toll roads
- 4 avoid ferries
- 3 **recalculate**

PHONE

1 "TELEPHONE" MENU

2 DIAL NUMBER

2 DIAL FROM ADDRESS BOOK

2 CALL LIST

2 CONNECT PHONE

3 search phone

3 phones connected

4 disconnect phone

4 rename phone

4 delete pairing

4 delete all pairings

4 show details

2 SETTINGS

3 select ring tone

3 phone/ring tone volume

3 enter mailbox number

SETUP

1 SETUP

2 SYSTEM LANGUAGE

3 deutsch

3 english

3 espanol

3 français

3 italiano

3 nederlands

3 polski

3 portuguese

2 DATE AND TIME

3 set date and time

3 date format

3 time format

2 DISPLAY

3 brightness

3 colour

4 pop titanium

4 toffee

4 blue steel

4 technogrey

4 dark blue

3 map colour

4 day mode for map

4 night mode for map

4 auto. day/night for map

2 VEHICLE PARAMETERS

3 vehicle information

4 alert log

4 status of functions

2 UNITS

3 temperature

4 celsius

4 fahrenheit

3 Distance

4 km and l/100

4 km and km/l

4 miles (mi) and MPG

2 SYSTEM PARAMETERS

3 factory reset

3 software version

3 automatic scrolling


FREQUENTLY ASKED QUESTIONS

The table below groups together the answers to the most frequently asked questions concerning the PC Nav.

QUESTION	ANSWER	SOLUTION
There is a difference in sound quality between the different audio sources (radio, CD, CD changer...).	For optimum sound quality, the audio settings (Volume, Bass, Treble, Ambience, Loudness) can be adapted to the different sound sources, which may result in audible differences when changing source (radio, CD, CD changer...).	Check that the audio settings (Volume, Bass, Treble, Ambience, Loudness) are adapted to the sources listened to. It is advisable to set the AUDIO functions (Bass, Treble, Front-Rear Balance, Left-Right Balance) to the middle position, select the musical ambience "None" and set the loudness correction to the "Active" position in CD mode or to the "Inactive" position in radio mode.
The CD is ejected automatically or is not played by the player.	The CD is inserted upside down, is unplayable, does not contain any audio data or contains an audio format which the player cannot play. The CD is protected by an anti-pirating protection system which is not recognised by the audio equipment.	- Check that the CD is inserted in the player the right way up. - Check the condition of the CD: the CD cannot be played if it is too damaged. - Check the content in the case of a recorded CD: consult the advice in the Audio section. - The audio equipment's CD player does not play DVDs. - Due to inadequate quality, certain recorded CDs will not be played by the audio system. - The CD changer does not play MP3 CDs.
The CD player sound is poor.	The CD used is scratched or of poor quality.	Insert good quality CDs and store them in suitable conditions.
	The audio equipment settings (bass, treble, ambiences) are unsuitable.	Set the treble or bass level to 0, without selecting an ambience.

QUESTION	ANSWER	SOLUTION
The quality of reception of the radio station listened to gradually deteriorates or the stored stations do not function (no sound, 87.5 Mhz is displayed...).	The vehicle is too far from the transmitter used by the station listened to or there is no transmitter in the geographical area through which the vehicle is travelling.	Activate the RDS function to enable the system to check whether there is a more powerful transmitter in the geographical area.
	The environment (hills, buildings, tunnels, basement car parks...) block reception, including in RDS mode.	This phenomenon is normal and does not indicate a failure of the audio equipment.
	The aerial is absent or has been damaged (for example when going through a car wash or into an underground car park).	Have the aerial checked by a PEUGEOT dealer.
Sound cut-outs of 1 to 2 seconds in radio mode.	During this brief sound cut-out, the RDS searches for any frequency permitting better reception of the station.	Deactivate the RDS function if the phenomenon is too frequent and always on the same route.
With the engine off, the audio equipment switches off after a few minutes of use.	When the engine is switched off, the audio equipment operating time depends on the battery charge. The switch-off is normal: the audio equipment switches to economy mode and switches off to prevent discharging of the vehicle's battery.	Start the vehicle's engine to increase the battery charge.

QUESTION	ANSWER	SOLUTION
The TRAFFIC INFO box is ticked. However, certain traffic jams along the route are not indicated in real time.	On starting, it is several minutes before the system begins to receive the traffic information.	Wait until the traffic information is being received correctly (displaying of the traffic information symbols on the map).
	In certain countries, only major routes (motorways, ...) are listed for the traffic information.	This phenomenon is normal. The system is dependent on the traffic information available.
The time taken to calculate a route sometimes seems longer than usual.	The performance of the system may slow down temporarily if a CD/DVD is being copied onto the Jukebox at the same time as a route is being calculated.	Wait until the CD/DVD has been copied or stop the copying before starting the guidance function.
The altitude is not displayed.	On starting, the initialisation of the GPS may take up to 3 minutes to receive more than 4 satellites correctly.	Wait until the system has started up completely. Check that there is a GPS coverage of at least 4 satellites (long press on the MENU button, then select AUDIO/TELEPHONE DIAGNOSTICS, then GPS COVERAGE).
	Depending on the geographical environment (tunnel, ...) or the weather, the conditions of reception of the GPS signal may vary.	This phenomenon is normal. The system is dependent on the conditions of reception of the GPS signal.
The route calculation is not successful.	The exclusion criteria may conflict with the current location (exclusion of toll roads on a toll motorway).	Check the exclusion criteria.
There is a long waiting time after inserting a CD or SD card.	When a new medium is inserted, the system reads a certain amount of data (directory, title, artist, etc.). This may take a few seconds.	This phenomenon is normal.
I cannot connect my Bluetooth telephone.	The telephone's Bluetooth function may be deactivated or the equipment may not be visible.	- Check that your telephone's Bluetooth function is activated. - Check that your telephone is visible.



PC Sound

CONTENTS

- **01 First steps** pg. 231
- **02 General menu** pg. 232
- **03 Audio** pg. 233
- **04 USB player - PC Plug** pg. 236
- **05 PC Bluetooth** pg. 239
- **06 Control short-cuts** pg. 241
- **07 Configuration** pg. 242
- **08 Display flow charts** pg. 243
- **Frequently asked questions** pg. 276



Your PC Sound is coded in such a way that it will only operate in your vehicle. If it is to be installed in another vehicle, contact a PEUGEOT dealer for configuration of the system.



For safety reasons, the driver must carry out operations which require prolonged attention while the vehicle is stationary.
When the engine is switched off and to prevent discharging of the battery, your PC Sound may switch off after a few minutes.

01 FIRST STEPS



1. On/Off and volume adjustment.
2. CD eject.
3. Selection of the display on the screen from the modes: Audio (AUDIO), Trip Computer (TRIP) and Telephone (TEL) functions.
4. Selection of the source: radio, audio CD/MP3 CD, USB, Jack connection, Streaming.
5. Selection of the FM1, FM2, FMast and AM wavebands.
6. Setting the audio options: front/rear balance, left/right balance, loudness, sound ambiances.
7. Displaying of the list of local stations, of the tracks on the CD or of the MP3 directories.
8. Abandon current operation.
9. TA (Traffic Announcement) function on/off.
Long press: access to the PTY (TYpes of radio Programme) mode.
10. Confirmation.
11. Automatic search for a lower/higher frequency.
Selection of previous/next CD, MP3 or USB track.
12. Selection of a lower/higher radio frequency.
Selection of the previous/next MP3 directory.
Selection of the previous/next directory/genre/artist/playlist on the USB equipment.
13. Displaying of the general menu.
14. Buttons 1 to 6:
Selection of a stored radio station.
Long press: storing of a station.
15. The DARK button changes the display on the screen to improve driving comfort at night.
1st press: lighting of the top banner only.
2nd press: displaying of a black screen.
3rd press: return to the standard display.

02 GENERAL MENU

AUDIO FUNCTIONS:
radio, CD, USB options.

TELEPHONE:
Bluetooth, matching, management
of a communication and
transmission of .mp3 files.

> MONOCHROME DISPLAY C



VEHICLE DIAGNOSTICS:
warnings.

PERSONALISATION-CONFIGURATION:
vehicle parameters, display, languages.



For a detailed global view of the
menus available, refer to the
"Display flow charts" section of
this PC Sound chapter.

03 AUDIO




RADIO SELECTING A STATION

1



Press the SOURCE button several times in succession and select the radio.



2




Press the BAND AST button to select a waveband: FM1, FM2, FMast, AM.



3




Briefly press one of the buttons to carry out an automatic search of the radio stations.




4



Press one of the buttons to carry out a manual search of the radio stations.



Press the LIST REFRESH button to display the list of stations received locally (30 stations maximum). To update this list, press for more than two seconds.



RDS

The external environment (hills, buildings, tunnels, basement car parks) may block reception, including in RDS mode. This is a normal effect of the way in which radio waves are transmitted and does not indicate any failure of the audio equipment.

1




Press the MENU button.



2



Select AUDIO FUNCTIONS then press OK.




3



Select the FM WAVEBAND PREFERENCES function then press OK.

FM WAVEBAND PREFERENCES




4



Select ACTIVATE FREQUENCY FOLLOWING (RDS) then press OK. RDS appears on the display.

ACTIVATE FREQUENCY FOLLOWING (RDS)



!

The RDS, if displayed, enables you to continue listening to the same station by automatic retuning to alternative frequencies. However, in certain conditions, coverage of an RDS station may not be assured throughout the country as radio stations do not cover 100 % of the territory. This explains the loss of reception of the station during a journey.

CD PLAYING A CD




Insert circular compact discs only.
Some anti-pirating systems, on original discs or CDs copied using a personal recorder, may cause faults which are no reflection on the quality of the original player.
Without pressing the EJECT button, insert a CD in the player, play begins automatically.

1




To play a disc which has already been inserted, press the SOURCE button several times in succession and select CD.



2



Press one of the buttons to select a track on the CD.
Press the LIST REFRESH button to display the list of tracks on the CD.
Press and hold one of the buttons for fast forward or backward.



MP3 CD PLAYING AN MP3 COMPILATION



Insert an MP3 compilation in the player.
The audio equipment searches for all of the music tracks, which may take anything between a few seconds and several tens of seconds, before play begins.




On a single disc, the CD player can read up to 255 MP3 files spread over 8 directory levels. However, it is advisable to keep to a limit of two levels to reduce the access time before the CD is played.
While the CD is being played, the directory flow chart is not followed. All of the files are displayed on a single level.

1




To play a disc which has already been inserted, press the SOURCE button several times in succession and select CD.



2



Press one of the buttons to select a track on the CD.
Press the LIST REFRESH button to display the list of directories of the MP3 compilation.
Press and hold one of the buttons for fast forward or backward.



03 AUDIO

CD MP3 INFORMATION AND ADVICE



The MP3 format, an abbreviation of MPEG 1.2 & 2.5 Audio Layer 3, is an audio compression standard which permits the recording of several tens of music files on a single disc.



In order to be able to play a recorded CDR or CDRW, when recording it is preferable to select standards ISO 9660 level 1.2 or Joliet.

If the disc is recorded in another format, it may not be played correctly.

It is recommended that the same recording standard is always used for an individual disc, with as low a speed as possible (4x maximum) for optimum sound quality.

In the particular case of a multi-session CD, the Joliet standard is recommended.



The audio equipment will only play files with the extension ".mp3" with a sampling rate of 22.05 KHz or 44.1 KHz. No other type of file (.wma, .mp4, .m3u...) can be played.



It is advisable to restrict file names to 20 characters without using special characters (e.g. " " ? ; ù) to avoid any playing or displaying problems.

04 USB Player - Plug

USING THE USB SOCKET - PLUG

1

This unit consists of a USB port and a Jack socket*. It reads audio file formats (.mp3, .ogg, .wma, .wav...) which are transmitted from portable equipment such as a digital player or a USB stick to your PC Sound to be listened to via the vehicle's speakers.



2

USB stick (1.1, 1.2 and 2.0) or Ipod® of generation 5 or later:

- the playlists accepted are of the type m3u, .pls, .wpl,
- the Ipod® lead is essential,
- navigation through the file base is by means of the steering wheel controls,
- the battery of the portable equipment can charge automatically.



3

Other Ipod® players of earlier generations and players using the MTP protocol*:

- play via Jack-Jack lead only (not supplied),
- navigation through the file base is from the portable equipment.



The list of compatible equipment is available from PEUGEOT dealers.

CONNECTING A USB STICK

1

Connect the stick to the socket, directly or using a lead. If the audio equipment is switched on, the USB source is detected as soon as it is connected. Play begins automatically after a delay which depends on the capacity of the USB stick.

The file formats recognised are .mp3 (mpeg1 layer 3 only), .wma (standard 9 only), .wav and .ogg.



!

The system puts together playlists (temporary memory) created over a period which depends on the capacity of the USB equipment. The other sources are available during this time. The playlists are updated each time the Ignition is switched off or each time a USB stick is connected. When connecting for the first time, the tracks are classified by folder. When you reconnect, the classification system selected previously is retained.

* According to vehicle.

04 USB Player - Plug

USING THE USB SOCKET - PLUG


2

Press and hold LIST to display the different classifications.
Select by Folder/Artist/Genre/Playlist, press OK to select the classification required, then press OK again to confirm.

OK




- by Folder: all folders containing audio files recognised on the peripheral device, classified in alphabetical order without following the flow chart.
- by Artist: all of the artist names defined in the ID3 Tags, classified in alphabetical order.
- by Genre: all of the genres defined in the ID3 Tags.
- by Playlist: in accordance with the playlists recorded on the USB device.



3




Press LIST briefly to display the list of Folders/Genres/Artists/Playlists on the USB equipment.
Navigate through the list using the left/right and up/down buttons.
Confirm the selection by pressing OK.



4




Press one of these buttons to gain access to the previous/next track on the classification list currently being played.
Press and hold one of the buttons for fast forward or rewind play.



5



Press one of these buttons to gain access to the previous/next Genre, Folder, Artist or Playlist on the classification list currently being played.



CONNECTING AN IPOD® VIA THE USB SOCKET

1

The lists available are Artist, Genre and Playlist (as defined on the iPod®).
Selection and Navigation are described in steps 1 to 5 above.

!

Do not connect a hard disc or USB devices other than audio equipment to the USB socket. This could damage your installation.

USING THE AUXILIARY INPUT (AUX) JACK SOCKET OR RCA SOCKET (according to vehicle)



The auxiliary input, JACK and RCA, permits the connection of portable equipment (MP3 player...).



Do not connect a single piece of equipment via the USB socket and the JACK socket at the same time.

1


Connect the portable equipment (MP3 player...) to the JACK socket or to the audio sockets (white and red, RCA type) using a suitable cable (not supplied).



2



Press the SOURCE button several times in succession and select AUX.



ADJUSTING THE VOLUME OF THE AUXILIARY SOURCE

1

First adjust the volume of your portable equipment.



2



Then adjust the volume of your audio equipment.



The controls are displayed and managed via the portable equipment.



05 BLUETOOTH

BLUETOOTH TELEPHONE SCREEN C



The services offered depend on the network, the SIM card and the compatibility of the Bluetooth equipment used. Consult your telephone's manual and your operator to find out which services are available to you. A list of mobile telephones which offer the best range of services is available from the network. Consult a PEUGEOT dealer.

PAIRING A TELEPHONE




For safety reasons and because they require prolonged attention on the part of the driver, the operations for pairing of the Bluetooth mobile telephone with the Bluetooth hands-free system of your audio equipment must be carried out with the vehicle stationary and the ignition on.

1



Press the MENU button.



2

Activate the telephone's Bluetooth function.




3



In the menu, select:

- Bluetooth telephone function - Audio
- Bluetooth configuration
- Perform a Bluetooth search



4

A window is displayed with "Searching..."

5

The first 4 telephones recognised are displayed in this window.



The TELEPHONE menu permits access to the following functions in particular: Directory*, Call list, Pairing management.

* if your telephone hardware is fully compatible.

6

Select the telephone to be connected from the list. Only one telephone can be connected at a time.

7

A virtual keypad is displayed on the screen: enter a code with at least 4 digits. Confirm by pressing Ok.



8

A message is displayed on the screen of the telephone chosen: to accept the pairing, enter the same code on the telephone, then confirm by pressing Ok. If pairing fails, the number of attempts is not limited.



9

"Pairing of Name_telephone successful" appears on the screen.

10

The automatic connection authorised is only active after the telephone has been configured. The directory and the call list can be accessed after the synchronisation period.

The pairing can also be initiated from the telephone.

BLUETOOTH AUDIO STREAMING (AVAILABLE DURING THE YEAR)

RECEIVING A CALL


- 1 An incoming call is announced by a ring and a superimposed display on the multifunction screen.

2



Select the YES tab on the display using the buttons and confirm by pressing OK.

YES



Press the steering wheel control OK to accept the call.



MAKING A CALL

- 1 From the Bluetooth telephone function Audio menu, select Manage the telephone call then call, call list or directory.

2

Press the end of the steering wheel control for more than two seconds to gain access to your directory.
Or
To dial a number, use your telephone's keypad, with the vehicle stationary.



Wireless transmission of the telephone's music files via the audio equipment. The telephone must be able to manage the appropriate bluetooth profiles (Profiles A2DP/AVRCP).

1

Initiate the pairing between the telephone and the vehicle. This pairing can be initiated from the vehicle's telephone function menu or via the telephone's keypad. See steps 1 to 10 on the previous pages. During the pairing phase, the vehicle must be stationary with the key in the ignition.



2


Select the telephone to be connected from the telephone function menu.
The audio system connects to a newly paired telephone automatically.



3



Activate the streaming source by pressing the SOURCE button*. The tracks to be played can be controlled as usual via the buttons on the Radio control panel and the steering wheel controls**. The contextual information can be displayed on the screen.




* In certain cases, playing of the Audio files must be initiated from the keypad.

** If the telephone supports the function.

06 CONTROL SHORT-CUTS

STEERING WHEEL CONTROLS



07 CONFIGURATION



ADJUSTING THE DATE AND TIME

1



Press the MENU button.




2



Using the arrows, select the PERSONALISATION-CONFIGURATION function.




PERSONALISATION-CONFIGURATION



3



Press to confirm the selection.




4



Using the arrows, select the DISPLAY CONFIGURATION function.

DISPLAY CONFIGURATION



5



Press to confirm the selection.




6



Using the arrows, select the ADJUST DATE AND TIME function.


ADJUST DATE AND TIME



7



Press to confirm the selection.




8



Adjust the settings one by one confirming by pressing the OK button. Next select the OK tab on the display then confirm.

OK



08 DISPLAY FLOW CHART monochrome C



1 AUDIO FUNCTIONS

2 FM BAND PREFERENCES

3 alternative frequencies (RDS)

4 activate/deactivate

3 regional mode (REG)

4 activate/deactivate

3 radio-text information (RDTXT)

4 activate/deactivate

2 AUDIO CD PREFERENCES

3 track random play (RDM)

4 activate/deactivate



1 VEHICLE DIAGNOSTICS

2 WARNING LOG

3 diagnostics



1 PERSONALISATION-CONFIGURATION

2 DEFINE THE VEHICLE PARAMETERS*

2 DISPLAY CONFIGURATION

3 video brightness adjustment

4 normal video

4 inverse video

4 brightness (- +) adjustment

3 date and time adjustment

3 day/month/year adjustment

4 hour/minute adjustment

4 choice of 12 h/24 h mode

3 choice of units

4 l/100 km - mpg - km/l

4 °Celsius/°Fahrenheit

2 CHOICE OF LANGUAGE



1 BLUETOOTH TELEPHONE

1 BLUETOOTH CONFIGURATION

2 CONNECT/DISCONNECT AN EQUIPMENT

3 Telephone function

3 Audio Streaming function

2 CONSULT THE PAIRED EQUIPMENT

2 DELETE A PAIRED EQUIPMENT

2 PERFORM A BLUETOOTH SEARCH

1 CALL

2 CALLS LIST

2 DIRECTORY

1 MANAGE THE TELEPHONE CALL

2 TERMINATE THE CURRENT CALL

2 ACTIVATE SECRET MODE


* The parameters vary according to vehicle (refer to the "Multifunction displays" section).

FREQUENTLY ASKED QUESTIONS

The table below groups together the answers to the most frequently asked questions concerning your PC Com and your PC Sound.

QUESTION	RESPONSE	SOLUTION
There is a difference in sound quality between the different audio sources (radio, CD...).	For optimum sound quality, the audio settings (Volume, Bass, Treble, Ambience, Loudness) can be adapted to the different sound sources, which may result in audible differences when changing source (radio, CD...).	Check that the audio settings (Volume, Bass, Treble, Ambience, Loudness) are adapted to the sources listened to. It is advisable to set the AUDIO functions (Bass, Treble, Front-Rear Balance, Left-Right Balance) to the middle position, select the musical ambience "None" and set the loudness correction to the "Active" position in CD mode or to the "Inactive" position in radio mode.
The CD is ejected automatically or is not played by the player.	The CD is inserted upside down, is unplayable, does not contain any audio data or contains an audio format which the player cannot play. The CD is protected by an anti-pirating protection system which is not recognised by the audio equipment.	- Check that the CD is inserted in the player the right way up. - Check the condition of the CD: the CD cannot be played if it is too damaged. - Check the content in the case of a recorded CD: consult the advice in the "Audio" section. - The audio equipment's CD player does not play DVDs. - Due to inadequate quality, certain recorded CDs will not be played by the audio system.
The CD player sound is poor.	The CD used is scratched or of poor quality.	Insert good quality CDs and store them in suitable conditions.
	The audio equipment settings (bass, treble, ambiances) are unsuitable.	Set the treble or bass level to 0, without selecting an ambience.

QUESTION	RESPONSE	SOLUTION
The stored stations do not function (no sound, 87.5 Mhz is displayed...)	An incorrect waveband is selected.	Press the BAND AST button to return to the waveband (AM, FM1, FM2, FMAST) on which the stations are stored.
The traffic announcement (TA) is displayed. I do not receive any traffic information.	The radio station is not part of the regional traffic information network.	Tune to a radio station which broadcasts traffic information.
The quality of reception of the radio station listened to gradually deteriorates or the stored stations do not function (no sound, 87.5 Mhz is displayed...).	The vehicle is too far from the transmitter used by the station listened to or there is no transmitter in the geographical area through which the vehicle is travelling.	Activate the RDS function to enable the system to check whether there is a more powerful transmitter in the geographical area.
	The environment (hills, buildings, tunnels, basement car parks...) block reception, including in RDS mode.	This phenomenon is normal and does not indicate a failure of the audio equipment.
	The aerial is absent or has been damaged (for example when going through a car wash or into an underground car park).	Have the aerial checked by a PEUGEOT dealer.
Sound cut-outs of 1 to 2 seconds in radio mode.	During this brief sound cut-out, the RDS searches for any frequency permitting better reception of the station.	Deactivate the RDS function if the phenomenon is too frequent and always on the same route.
With the engine off, the audio equipment switches off after a few minutes of use.	When the engine is switched off, the audio equipment operating time depends on the battery charge. The switch-off is normal: the audio equipment switches to economy mode and switches off to prevent discharging of the vehicle's battery.	Start the vehicle's engine to increase the battery charge.
The message "the audio system is overheated" appears on the display.	In order to protect the installation if the surrounding temperature is too high, the audio equipment switches to an automatic thermal protection mode leading to a reduction of the volume or stopping of the playing of the CD.	Switch the audio system off for a few minutes to allow the system to cool.



PC Com

MULTIMEDIA AUDIO EQUIPMENT/TELEPHONE
JUKEBOX FUNCTION (10 GB)/GPS (EUROPE)



The PC Com is coded in such a way that it will only operate in your vehicle. If it is to be installed in another vehicle, contact a PEUGEOT dealer for configuration of the system.



For safety reasons, it is imperative that the driver carries out operations which require prolonged attention while the vehicle is stationary.
When the engine is switched off and to prevent discharging of the battery, the PC Com may switch off after a few minutes.

CONTENTS

- **01 First steps** pg. 246
- **02 General menu** pg. 247
- **03 GPS** pg. 248
- **04 Traffic information** pg. 257
- **05 Audio/Video** pg. 259
- **06 Telephone** pg. 266
- **07 Control short-cuts** pg. 269
- **08 Configuration** pg. 271
- **09 Display flow charts** pg. 272
- **Frequently asked questions** pg. 276

01 FIRST STEPS



1. Ejection of the CD.
2. Selection of the source: radio, Jukebox, CD and auxiliary (AUX, if activated on the configuration menu).
Long press: CD copy to hard disc.
3. Long press on the SOS button: emergency call.
4. Selection of the display on the screen from the modes: TRIP, TEL., NAV and AUDIO.
5. Modification of the screen display.
Long press: reinitialisation of the PC Com.
6. On/Off and Volume adjustment.
7. Selection of the wavebands FM1, FM2, FMast, AM.
8. TA (Traffic Announcement) function on/off.
Long press: access to the PTY (radio Programme TYpes) mode.
9. Access to the "PEUGEOT" services menu.
10. Cancellation of the current operation.
Long press: return to the current application.
11. Automatic search for a lower/higher frequency.
Selection of the previous/next CD, MP3 or Jukebox track.
12. Displaying of the general menu.
13. Keypad for entering descriptions by successive presses.
14. Selection of the previous/next MP3/Jukebox directory.
15. Audio option adjustments: front/rear, left/right balance, loudness, sound ambiances.
16. Selection and confirmation.
17. SIM card slot.
18. Displaying of the list of local radio stations, of the tracks on the CD or of the MP3/Jukebox directories.
Long press: updating of the local radio stations.

GENERAL MENU 02



For maintenance of the display, the use of a soft, non-abrasive cloth (spectacles cloth) is recommended without any additional product.

TRAFFIC INFORMATION:
TMC information,
messages.

MAP: orientation, details,
display.

NAVIGATION GUIDANCE:
GPS, stages, options.

VEHICLE DIAGNOSTICS:
warnings log, status of the
functions.

AUDIO FUNCTIONS: radio,
CD, Jukebox, options.

TELEMATIC: telephone,
directory, SMS.

CONFIGURATION: vehicle,
display, time, languages,
voice, auxiliary socket (AUX)
parameters.

VIDEO: activation,
parameters.

03 GPS



SELECTING A DESTINATION

For a detailed global view of the menus available, refer to the "Display flow charts" section of this PC Com chapter.

1



Press the MENU button.



2



Turn the dial and select the
NAVIGATION GUIDANCE function.



3



Press the dial to confirm the selection.



4



Turn the dial and select the
DESTINATION CHOICE function.

DESTINATION CHOICE



5



Press the dial to confirm the selection.



6



Turn the dial and select the
ENTER AN ADDRESS function.

ENTER AN ADDRESS



7



Press the dial to confirm the selection.




8



When the country has been selected,
turn the dial and select the TOWN
function.

TOWN





9



Press the dial to confirm the selection.



10



Turn the dial and select the letters of the town one by one confirming each time by pressing the dial.

PARIS



To speed up the process, the POST CODE can be entered instead of the name of the town. Use the alphanumeric keypad to enter the letters and digits and "*" to correct.



11



Select OK and press the dial to confirm.

OK



12

Repeat steps 8 to 12 for the ROAD and N° functions.

13



Select OK on the ENTER AN ADDRESS page.



14



Press the dial to confirm the selection.

OK



Select the STORE function to record the address entered in a directory record and press the dial to confirm the selection. The points of interest (POI) indicate all of the service locations in the vicinity (hotels, various businesses, airports...).

STORE

POI

03 GPS



GUIDANCE OPTIONS

The route chosen by the PC Com depends directly on the guidance options. Changing these options may completely change the route.

1



Press the MENU button.



2



Turn the dial and select the NAVIGATION GUIDANCE function.



3



Press the dial to confirm the selection.



4



Turn the dial and select the GUIDANCE OPTIONS function.

GUIDANCE OPTIONS



5



Press the dial to confirm the selection.



6



Turn the dial and select the DEFINE CALCULATION CRITERIA function.

DEFINE CALCULATION CRITERIA



7



Press the dial to confirm the selection.



8



Turn the dial and select, for example, the DISTANCE/TIME function.

DISTANCE/TIME



GUIDANCE SPEECH SYNTHESIS



9



Press the dial to confirm the selection.




10



Turn the dial and select the **TRAFFIC INFO** function if it is not ticked.

TRAFFIC INFO



Tick this box for optimum operation of the traffic information, diversions will be suggested.

11



Press the dial to confirm the selection.



12



Select **OK** and press the dial to confirm.

OK



1



Press the **MENU** button.



2



Turn the dial and select the **NAVIGATION GUIDANCE** function.



3



Press the dial to confirm the selection.



4



Turn the dial and select the **GUIDANCE OPTIONS** function.

GUIDANCE OPTIONS



5



Press the dial to confirm the selection.




03 GPS



GUIDANCE SPEECH SYNTHESIS



During the announcements, the volume of each speech synthesis function (guidance, traffic information...) can be adjusted directly.




6



Select the ADJUST SPEECH SYNTHESIS function and press the dial to confirm.

ADJUST SPEECH SYNTHESIS



7



Select the DEACTIVATE function and press the dial to confirm.

DEACTIVATE




8



Select OK and press the dial to confirm.

OK



ACTIONS ON THE MAP

1




Press the MENU button.



2



Turn the dial and select the MAP function.



3



Press the dial to confirm the selection.




4



Turn the dial and select the MAP DETAILS function. Permits selection of the services which can be seen on the map (hotels, restaurants...).

MAP DETAILS



03 GPS



3D VIEW

For improved visibility, beyond the scale of 10 km, the map automatically switches to North Orientation.

1




Press the MENU button.



2



Turn the dial and select the MAP function.



3



Press the dial to confirm the selection.




4



Turn the dial and select the MAP ORIENTATION function.

MAP ORIENTATION



5



Press the dial to confirm the selection.



6



Turn the dial and select the 3D VIEW tab.

3D VIEW



7



Select OK and press the dial to confirm.

OK



03 GPS




DISPLAYING THE MAP IN A WINDOW OR IN FULL SCREEN MODE



1



Press the MENU button.



2



Turn the dial and select the MAP function.



3



Press the dial to confirm the selection.



4



Turn the dial and select the
DISPLAY MAP function.

DISPLAY MAP



5



Press the dial to confirm the selection.



6



Turn the dial and select the
MAP IN WINDOW or
FULL SCREEN MAP tab.

MAP IN WINDOW

FULL SCREEN MAP



7



Select OK and press the dial to
confirm.

OK



03 GPS



List of POI

-  Flying club
-  Airport
-  Lay-by
-  Bowling alley
-  Casino
-  Business park
-  Sports centre
-  Town centre
-  Cinema
-  Sports complexes
-  Culture/Museum
-  Vineyard
-  Garage

-  Station
-  Dock station
-  Bus station
-  Hospitals
-  Hotels
-  Vehicle hire
-  Town halls
-  Historical monuments
-  Tourist information
-  Theme park
-  Park/Garden
-  Park and ride
-  Car park

-  Covered parking
-  Skating rink
-  Ports
-  Restaurant
-  Shopping
-  Show/Exhibition
-  Winter sports centre
-  Service station
-  Supermarkets
-  Golf course
-  Tourism
-  University
-  Night life

03 GPS



ADDING A STAGE

1



During guidance, press the MENU button.



2



Turn the dial and select the NAVIGATION GUIDANCE function.



3



Press the dial to confirm the selection.



4



Turn the dial and select the JOURNEY LEGS AND ROUTE function.

JOURNEY LEGS AND ROUTE



5



Press the dial to confirm the selection.



6



Select the ADD A STAGE function (9 stages maximum) and press the dial to confirm.

ADD A STAGE



7



Enter for example a new address.

NEW ADDRESS



8



When the new address has been entered, select OK and press the dial to confirm.



9



Select OK and press the dial to confirm the order of the stages.



The stage must be completed or deleted before the guidance can continue to the next destination. Otherwise, the PC Com will always guide you back to the previous stage.

04 TRAFFIC INFORMATION



ACTIVATING THE FILTER ON THE ROUTE

We recommend a filter on the route and a filter around the vehicle of:

- 5 km or 10 km for a region with heavy traffic,
- 20 km for a region with a normal level of traffic,
- 100 km for long journeys (motorway).

1



Press the MENU button.



2



Turn the dial and select the TRAFFIC INFORMATION function.



3



Press the dial to confirm the selection.



4



Turn the dial and select the FILTER TRAFFIC INFORMATION function.

FILTER TRAFFIC INFORMATION



5



Press the dial to confirm the selection.



6



Select the GEOGRAPHIC FILTER function and press the dial to confirm.

GEOGRAPHIC FILTER



7



Turn the dial and select the ON THE ROUTE tab.



8



Select OK and press the dial to confirm.

OK



04 TRAFFIC INFORMATION




CONFIGURING THE TMC MESSAGE ANNOUNCEMENTS

We recommend that you do not tick the NEW MESSAGE DISPLAY tab for regions with heavy traffic.

1



Press the MENU button.



2



Turn the dial and select the TRAFFIC INFORMATION function.



3



Press the dial to confirm the selection.



4



Turn the dial and select the CONFIGURE MESSAGE ANNOUNCEMENT function.

CONFIGURE MESSAGE ANNOUNCEMENT



5



Press the dial to confirm the selection.



6



Select the READ MESSAGES tab.


The Traffic Information Messages will be read by the voice synthesiser.

READ MESSAGES



Select the NEW MESSAGE DISPLAY tab.
The traffic information messages are extended to the filters selected (geographic...) and can also be displayed when guidance is not active.

NEW MESSAGE DISPLAY



7



Select OK and press the dial to confirm.

OK





05 AUDIO/VIDEO




The external environment (hills, buildings, tunnels, basement car parks, ...) may block reception, including in RDS mode. This is a normal effect of the way in which radio waves are transmitted and does not indicate any failure of the audio equipment.

RADIO SELECTING A STATION


- 1 Press the SOURCE button several times in succession and select the RADIO.




- 2 Press the BAND button to select a waveband: FM1, FM2, FMast, AM.




- 3 Briefly press one of the buttons to carry out an automatic search of the radio stations.



- 4 Press one of the buttons to carry out a manual search of the radio stations.



-  Press the LIST button to display the list of stations received locally (60 maximum). To update this list, press for more than two seconds.



RDS

- 1 Press the MENU button.



- 2 Select AUDIO FUNCTIONS then press OK.



- 3 Select the FM BAND PREFERENCES function then press OK.



FM BAND PREFERENCES



- 4 Select ACTIVATE FREQUENCY FOLLOWING (RDS) then press OK. RDS appears on the display.



ACTIVATE FREQUENCY FOLLOWING (RDS)



-  The RDS, if displayed, enables you to continue listening to the same station by means of frequency following. However, in certain conditions, this RDS station is not followed throughout the country as radio stations do not cover 100 % of the territory. This explains the loss of reception of the station during a journey.

05 AUDIO/VIDEO



MP3 CD INFORMATION AND ADVICE



The MP3 format, an abbreviation of MPEG 1.2 & 2.5 Audio Layer 3, is an audio compression standard which permits the recording of several tens of music files on a single disc.



In order to be able to play a recorded CDR/DVDR or CDRW/DVDRW, when recording it is preferable to select standards ISO 9660 level 1.2 or Joliet. If the disc is recorded in another format, it may not be played correctly. It is recommended that the same recording standard is always used for an individual disc, with as low a speed as possible (4x maximum) for optimum sound quality. In the particular case of a multi-session CD, the Joliet standard is recommended.



The audio equipment will only play audio files with the extension ".mp3" with a sampling rate of 22.05 KHz or 44.1 KHz. No other type of file (.wma, .mp4, .m3u...) can be played.




It is advisable to restrict file names to 20 characters without using special characters (e.g.: " " ? ; ù) to avoid any playing or displaying problems.

CD PLAYING A CD OR AN MP3 COMPILATION




Insert circular compact discs only. Some anti-pirating systems, on original discs or CDs copied using a personal recorder, may generate malfunctions regardless of the quality of the original player. Insert an audio CD or an MP3 compilation in the player, play begins automatically.

1




If the player already contains a disc, press the SOURCE button several times in succession and select CD to listen to it.



2



Press one of the buttons to select a track on the CD. Press the LIST button to display the list of tracks on the CD or of the directories of the MP3 compilation.



The playing and displaying of an MP3 compilation may depend on the recording programme and/or the parameter settings used. We recommend use of the ISO 9660 recording standard.


JUKEBOX FUNCTION

COPYING A CD ONTO THE HARD DISC

1



Insert a CD or an MP3 compilation and press the MENU button.



2



Select AUDIO FUNCTIONS and press the dial to confirm.



3



Select COPY CD TO JUKEBOX and press the dial to confirm.

COPY CD TO JUKEBOX



4



Select COMPLETE CD to copy the entire CD and press the dial to confirm.

COMPLETE CD



5



Select CREATE ALBUM and press the dial to confirm.

CREATE ALBUM



The AUTO CREATION tab automatically copies the CD by default into an album of the type "album n°...".

6



Select the letters one by one and select OK to confirm.

OK



The audio or MP3 CD is copied onto the hard disc. Copying may take approximately 20 minutes depending on the duration of the CD. During this copying phase, it is not possible to listen to the albums previously recorded on the hard disc or the CDs.



If it is not an MP3 CD, the Jukebox automatically compresses the CD in MP3 format. The compression may take approximately 20 minutes depending on the duration of the CD. During this compression phase, it is possible to listen to the CD or to albums previously recorded on the hard disc.



A long press on the SOURCE button starts the copying of the CD.




When copying an MP3 CD, the Jukebox only retains the last album level. It is not possible to copy files from the Jukebox to a CD. The STOP THE CD COPY action does not delete the files which have already been transferred onto the jukebox hard disc.

JUKEBOX FUNCTION RENAMING AN ALBUM

1



Press the MENU button.



2



Select AUDIO FUNCTIONS and press the dial to confirm.



3



Select the JUKEBOX function and press the dial to confirm.

JUKEBOX



4



Select the JUKEBOX MANAGEMENT function and press the dial to confirm.

JUKEBOX MANAGEMENT



5



Select the album to be renamed and press the dial to confirm.



6



Select the RENAME tab and press the dial to confirm.

RENAME



7



Turn the dial and select the letters of the album title one by one confirming each time by pressing the dial.



Use the alphanumeric keypad to enter the letters of the album title one by one.

JUKEBOX FUNCTION

LISTENING TO THE JUKEBOX

1



Select OK and press the dial to confirm.

OK



To rename the tracks of an album, follow the same procedure, selecting the tracks to be renamed. Use the ESC button to exit from the list of tracks.




Select the DELETE function to delete an album or a track from the Jukebox.

DELETE




1



Press the SOURCE button several times in succession and select the JUKEBOX function.

JUKEBOX



2



Press the LIST button.



3



Turn the dial to select the files.



Press the ESC button to return to the first file level.

VIDEO MENU

You can connect video equipment (camcorder, digital camera, DVD player...) to the three audio/video sockets, located in the glove box.

1



After connecting the video equipment, press the MENU button.



2



Turn the dial and select the VIDEO function.



3



Press the dial to confirm the selection.



4



Turn the dial and select the **ACTIVATE VIDEO MODE** function to activate/deactivate the video.

ACTIVATE VIDEO MODE



5



Press the dial to confirm the selection.



6



Turn the dial and select the **VIDEO PARAMETERS** function to set the display format, the brightness, the contrast and the colours.

VIDEO PARAMETERS



7



Press the dial to confirm the selection.



Pressing the "MODE" or "DARK" button disconnects the displaying of the video.



Pressing the "SOURCE" button several times in succession permits the selection of an audio source other than that of the video.



Videos can only be displayed when stationary.

USING THE AUXILIARY INPUT (AUX) JACK/RCA AUDIO CABLE NOT SUPPLIED



Press the MENU button then select the CONFIGURATION function, then SOUNDS, then ACTIVATE AUXILIARY SOURCE to activate the auxiliary input of the PC Com.

1


Connect the portable equipment (MP3 player...) to the audio sockets (white and red, RCA type) located in the glove box using a JACK/RCA audio cable.



2



Press the SOURCE button several times in succession and select AUX.



The displaying and management of the commands takes place via the portable equipment.




It is not possible to copy the files onto the hard disc from the auxiliary input.

06 TELEPHONE



INSTALLING YOUR SIM CARD (NOT SUPPLIED)



1



Access the slot by pressing the button using the tip of a pen.



2



Install the SIM card in the holder and then insert it in the slot.



3

To remove the SIM card, repeat step 1.



Your SIM card must be installed and removed with the PC Com switched off and the ignition off.

ENTERING THE PIN CODE

1



Enter the PIN code on the keypad.

PIN CODE



2



Confirm the PIN code by pressing button #.



When entering your PIN code, tick the STORE PIN tab to gain access to the telephone without having to enter this code when it is used subsequently.

06 TELEPHONE



CALLING A CONTACT

1



Press the PICK UP button to display the superimposed telephone menu.



2



Turn the dial and select the DIAL function.



DIAL

3



Press the dial to confirm the selection.



4



Dial the telephone number of your contact using the alphanumeric keypad.



5



Press the PICK UP button to call the number dialled.



6



Press the HANG UP button to end the call.



ACCEPTING OR REFUSING A CALL



Press the PICK UP button to accept a call.



Press the HANG UP button to refuse a call.



Press the end of the steering wheel stalk for more than 2 seconds to access the telephone menu: calls log, directory, voice mailbox.




EMERGENCY CALL



In an emergency, press the SOS button until an audible signal is heard and a CONFIRMATION/ CANCELLATION screen is displayed (if valid SIM card inserted). A call is made to the emergency services (112).

In certain countries*, this emergency call is made directly by the PEUGEOT Emergency team which locates the vehicle and alerts the appropriate emergency services as quickly as possible.



* On condition that the PEUGEOT Emergency contract has been signed. This is free and of unlimited duration. Consult a PEUGEOT dealer.



When the PEUGEOT Emergency contract has been signed, it is recommended that an initial call is made to the PEUGEOT Emergency team.

CONSULTING THE SERVICES



Press this button to gain access to the PEUGEOT services*.



Select "Customer call" to request any information about the PEUGEOT marque.

CUSTOMER CALL



Select "PEUGEOT Assistance" to make a breakdown assistance call. PEUGEOT Assistance.


PEUGEOT ASSISTANCE



* These services and options are subject to conditions and availability.

07 CONTROL SHORT- CUTS

STEERING WHEEL CONTROLS



VOICE COMMANDS DISPLAYING THE LIST AND USING THEM



1



To display the list of available voice commands, press the end of the lights stalk to start the voice recognition, then say HELP or WHAT CAN I SAY.



For the same operation, press and hold the MENU button and select the function VOICE COMMANDS LIST.



VOICE COMMANDS LIST

2



Press the end of the lights stalk to start the voice recognition.
Say the words one by one and wait for the audible confirmation signal between each word.
The list which follows is exhaustive.

LEVEL 1	LEVEL 2	LEVEL 3
display	audio guidance navigation trip computer telephone	
call	description	
guide to	description	
traffic info	display read	
CD player/jukebox	random play list track number previous/next track directory (MP3 CD) scan	1 ... 20 previous/next repeat
navigation	stop/resume directory show zoom out/in	destination description vehicle
radio	autostore list memory previous/next	1 ... 6
SMS/message	display read	
telephone	voice mailbox last number voice message service directory	description

08 CONFIGURATION



ADJUSTING THE DATE AND TIME

1



Press the MENU button.



2



Turn the dial and select the CONFIGURATION function.



3



Press the dial to confirm the selection.



4



Turn the dial and select the DISPLAY CONFIGURATION function.

DISPLAY CONFIGURATION



5



Press the dial to confirm the selection.



6



Turn the dial and select the ADJUST THE DATE AND TIME function.

ADJUST THE DATE AND TIME



7



Press the dial to confirm the selection.



8



Adjust the parameters one by one confirming by pressing the dial. Next select the OK tab on the display then confirm.

OK





NAVIGATION - GUIDANCE

SELECT DESTINATION

- 3 enter an address
 - 4 country:
 - 4 town:
 - 4 road:
 - 4 N°/_:
 - 4 curr. loc
 - 4 Archive
 - 4 POI
 - 5 near
 - 5 on the route
 - 5 around current place
 - 5 search by name

 GPS coordinates

2 directory



1 MAIN FUNCTION

2 CHOICE A

- 3 choice A1
3 choice A2
2 CHOICE B...

- 3 previous destinations
- 2 JOURNEY LEGS AND ROUTE
- 3 add a stage
- 4 enter an address
- 4 directory
- 4 previous destinations
- 3 order/delete journey legs
- 3 divert route
- 3 chosen destination
- 2 GUIDANCE OPTIONS
- 3 define calculation criteria
- 4 fastest
- 4 shortest
- 4 distance/time
- 4 with tolls
- 4 with ferry
- 4 traffic info

- 3 set speech synthesis
- 3 activate/deactivate road names
- 3 map data base description
- 3 delete last destinations
- A STOP/RESUME GUIDANCE



MAP

MAP ORIENTATION

- vehicle direction
- north direction
- 3D view

MAP DETAILS

- | | |
|---|--------------------------------------|
| 3 | administration and safety |
| 4 | town halls, town centre |
| 4 | universities, colleges |
| 4 | hospitals |
| 3 | hotels, restaurants and shops |
| 4 | hotels |
| 4 | restaurants |
| 4 | vineyards |

- 4 business centres
- 4 supermarkets, shopping
- 3 **culture, tourism and shows**
 - 4 tourism
 - 4 culture and museums
 - 4 casinos and nightlife
 - 4 cinemas and theatres
 - 4 shows and exhibitions
- 3 **sports and open air centres**
 - 4 sports centres
 - 4 golf courses
 - 4 skating rinks, bowling alleys
 - 4 winter sports resorts
 - 4 parks, gardens
 - 4 theme parks
- 3 **transport and automobile**
 - 4 airports, ports
 - 4 stations, bus stations
 - 4 vehicle rental
 - 4 lay-bys, car parks
 - 4 service stations, garages

- 2 **DISPLAY MAP**
 - 3 full screen map
 - 3 map in window
- 2 **MOVE THE MAP**



- 1 **TRAFFIC INFORMATION**
- 2 **READ MESSAGES**
- 2 **FILTER TRAFFIC INFORMATION**
 - 3 **geographic filter**

- 4 around the vehicle
- 4 around location
- 4 on the route

- 3 **road information**
 - 4 traffic information

- 4 road closure
- 4 size limit
- 4 road condition
- 4 weather and visibility

- 3 **urban/city information**
 - 4 parking
 - 4 public transport
 - 4 demonstrations

- 2 **CONFIGURE MESSAGE ANNOUNCEMENT**
 - 3 read messages
 - 3 new message display
- 2 **SELECT TMC STATION**
 - 3 automatic TMC
 - 3 manual TMC
 - 3 list of TMC stations



- 1 **AUDIO FUNCTIONS**
- 2 **RADIO FAVOURITES**
 - 3 enter a frequency
 - 3 activate/deactivate RDS mode
 - 3 activate/deactivate regional mode
 - 3 display/hide radio text
- 2 **CD, JUKEBOX FAVOURITES**
 - 3 activate/deactivate IntrosCAN (SCN)
 - 3 activate/deactivate random mode (RDM)
 - 3 activate/deactivate Repeat (RPT)
 - 3 activate/deactivate display of CD info
- 2 **STOP THE COPY**
- 2 **COPY CD TO JUKEBOX**
 - 3 copy complete CD

3 multiple selection

3 current album

3 current track

2 JUKEBOX

3 jukebox management

3 jukebox configuration

4 hi-fi (320 kbps)

4 high (192 kbps)

4 normal (128 kbps)

3 delete jukebox data

2 PLAYLIST MANAGEMENT



1 TELEMATICS

2 CALL

3 call list

3 dial

3 directory

3 mailbox

3 services

4 customer contact centre

4 PEUGEOT assistance

4 messages received

2 DIRECTORY

3 managing directory files

4 consult or modify a file

4 add a file

4 delete a file

4 delete all files

3 configure directory

4 select a directory

4 name directory

4 select starting directory

3 file transfer

4 exchange by infrared

5 send all records

5 send one record

5 receive by infrared

4 exchange with SIM card

5 send all records to SIM

5 send one record to SIM

5 receive all SIM files

5 receive a SIM file

2 TEXT MESSAGES (SMS)

3 read received text messages

3 send a text message

3 write a text message

3 delete list of text messages

2 TELEPHONE FUNCTIONS

3 network

4 network search mode

5 automatic mode

5 manual mode

4 networks available

3 length of calls

4 zero reset

3 manage PIN code

4 activate/deactivate

4 save PIN number

4 modify PIN code

3 call options

4 configure calls

5 display my number

5 automatic reply after x ring(s)

4 ring options

5 for voice calls

5 for text messages (SMS)

6 text message ring

3 call diversion to mailbox n°

3 delete calls log



1 CONFIGURATION

2 DISPLAY CONFIGURATION

3 choose colour

3 adjust luminosity

3 set date and time

3 select units

2 SOUND

3 voice commands setting

3 speech synthesis setting

4 guidance instructions volume

4 other message volume

4 select female/male voice

3 activate/deactivate auxiliary source

2 SELECT LANGUAGE

2 DEFINE VEHICLE PARAMETERS*



1 VIDEO

2 ACTIVATE VIDEO MODE

2 VIDEO PARAMETERS

3 display formats

3 adjust luminosity

3 set colours

3 set contrasts



1 VEHICLE DIAGNOSTICS

2 ALERT LOG

2 STATUS OF FUNCTIONS*

2 RESET TYRE PRESS. DETEC. SYS.*



Press the MENU button for more than 2 seconds to gain access to the next flow chart.

1 VOICE COMMANDS LIST

1 AUDIO/TELEPHONE DIAGNOSTICS

2 GPS COVERAGE

2 UNIT BACKUP POWER

2 UNIT DESCRIPTION

1 NAVIGATION DEMONSTRATION

1 SERVICES CONFIGURATION



Press the Music button several times in succession to access the following settings.

MUSICAL AMBIENCE

BASS

TREBLE

LOUDNESS CORRECTION

FR - RR BALANCE

LH - RH BALANCE

AUTO VOLUME CORRECTION



Each audio source (Radio, CD, MP3, Jukebox) has its own separate settings.

* The parameters vary according to vehicle (refer to the "Multifunction displays" chapter).

FREQUENTLY ASKED QUESTIONS

The table below groups together the answers to the most frequently asked questions concerning your PC Com and your PC Sound.

QUESTION	RESPONSE	SOLUTION
There is a difference in sound quality between the different audio sources (radio, CD...).	For optimum sound quality, the audio settings (Volume, Bass, Treble, Ambience, Loudness) can be adapted to the different sound sources, which may result in audible differences when changing source (radio, CD...).	Check that the audio settings (Volume, Bass, Treble, Ambience, Loudness) are adapted to the sources listened to. It is advisable to set the AUDIO functions (Bass, Treble, Front-Rear Balance, Left-Right Balance) to the middle position, select the musical ambience "None" and set the loudness correction to the "Active" position in CD mode or to the "Inactive" position in radio mode.
The CD is ejected automatically or is not played by the player.	The CD is inserted upside down, is unplayable, does not contain any audio data or contains an audio format which the player cannot play. The CD is protected by an anti-pirating protection system which is not recognised by the audio equipment.	- Check that the CD is inserted in the player the right way up. - Check the condition of the CD: the CD cannot be played if it is too damaged. - Check the content in the case of a recorded CD: consult the advice in the "Audio" section. - The audio equipment's CD player does not play DVDs. - Due to inadequate quality, certain recorded CDs will not be played by the audio system.
The CD player sound is poor.	The CD used is scratched or of poor quality.	Insert good quality CDs and store them in suitable conditions.
	The audio equipment settings (bass, treble, ambiances) are unsuitable.	Set the treble or bass level to 0, without selecting an ambience.

QUESTION	RESPONSE	SOLUTION
The stored stations do not function (no sound, 87.5 Mhz is displayed...)	An incorrect waveband is selected.	Press the BAND AST button to return to the waveband (AM, FM1, FM2, FMAST) on which the stations are stored.
The traffic announcement (TA) is displayed. I do not receive any traffic information.	The radio station is not part of the regional traffic information network.	Tune to a radio station which broadcasts traffic information.
The quality of reception of the radio station listened to gradually deteriorates or the stored stations do not function (no sound, 87.5 Mhz is displayed...).	The vehicle is too far from the transmitter used by the station listened to or there is no transmitter in the geographical area through which the vehicle is travelling.	Activate the RDS function to enable the system to check whether there is a more powerful transmitter in the geographical area.
	The environment (hills, buildings, tunnels, basement car parks...) block reception, including in RDS mode.	This phenomenon is normal and does not indicate a failure of the audio equipment.
	The aerial is absent or has been damaged (for example when going through a car wash or into an underground car park).	Have the aerial checked by a PEUGEOT dealer.
Sound cut-outs of 1 to 2 seconds in radio mode.	During this brief sound cut-out, the RDS searches for any frequency permitting better reception of the station.	Deactivate the RDS function if the phenomenon is too frequent and always on the same route.
With the engine off, the audio equipment switches off after a few minutes of use.	When the engine is switched off, the audio equipment operating time depends on the battery charge. The switch-off is normal: the audio equipment switches to economy mode and switches off to prevent discharging of the vehicle's battery.	Start the vehicle's engine to increase the battery charge.
The message "the audio system is overheated" appears on the display.	In order to protect the installation if the surrounding temperature is too high, the audio equipment switches to an automatic thermal protection mode leading to a reduction of the volume or stopping of the playing of the CD.	Switch the audio system off for a few minutes to allow the system to cool.

The table below groups together the answers to the most frequently asked questions concerning your PC Com.

QUESTION	RESPONSE	SOLUTION
The TRAFFIC INFO box is ticked. However, certain traffic jams along the route are not indicated in real time.	On starting, it is several minutes before the system begins to receive the traffic information.	Wait until the traffic information is being received correctly (displaying of the traffic information symbols on the map).
	In certain countries, only major routes (motorways, ...) are listed for the traffic information.	This phenomenon is normal. The system is dependent on the traffic information available.
The time taken to calculate a route sometimes seems longer than usual.	The performance of the system may slow down temporarily if a CD is being copied onto the Jukebox at the same time as a route is being calculated.	Wait until the CD has been copied or stop the copying before starting the guidance function.
Does the emergency call function work without a SIM card?	No, European regulations impose the presence of a SIM card in order to make an emergency call.	Insert a valid SIM card in the slot on your PC Com.
My SIM card is not recognised.	The audio equipment accepts 3.3 V SIM cards, the old 5 V and 1.8 V SIM cards are not recognised.	Contact your telephone operator.
After changing a wheel, the system loses its location.	Your PC Com uses the wheel rotation information to improve the GPS locating function. If a wheel is changed or deflates suddenly, the system recalculates the location. For approximately ten minutes, this recalculation may affect the quality of the locating function.	Wait until the system has completed its recalculation.
The location on the map is incorrect or inaccurate. The altitude is not displayed.	On starting, the initialisation of the GPS may take up to 3 minutes to receive more than 3 satellites correctly.	Wait until the system has started up completely. Check that there is a GPS coverage of at least 3 satellites (long press on the MENU button, then select AUDIO/TELEPHONE DIAGNOSTICS, then GPS COVERAGE).
	Depending on the geographical environment (tunnel, ...) or the weather, the conditions of reception of the GPS signal may vary.	This phenomenon is normal. The system is dependent on the conditions of reception of the GPS signal.