

List of Cancel Code

CRUISE CONTROL SYSTEM (DIAGNOSTICS)

8. List of Cancel Code

A: LIST

NOTE:

- The cancel code is registered even when cancel is performed intentionally by the driver.
- Cancel codes are cleared if the ignition switch is turned to OFF.
- If a different cancel code is input after a cancel code (latest code) has been input, the latest code is overwritten.
- If the cruise indicator light is flashing, a malfunction is occurring in the system or cruise control related switch. The cancel code at this time is saved even after ignition switch OFF as a memory code of a past malfunction.
- To display a cancel code, use the Subaru Select Monitor to read the code after the cruise control is deactivated during a driving test.

Cancel code	Item	Contents of diagnosis	Reference
11	Main Switch	Main switch of cruise control command switch is turned to OFF, and then the cruise control is released.	This code is displayed without operating the main switch. <Ref. to CC(diag)-15, DTC 11, Diagnostic Procedure without Diagnostic Trouble Code (DTC).>
12	Stop Light & Brake Switch	Stop light switch or brake switch is turned to ON, and then the cruise control is released.	This code is displayed without depressing the brake pedal. <Ref. to CC(diag)-17, DTC 12, Diagnostic Procedure without Diagnostic Trouble Code (DTC).>
13	Clutch Switch	Clutch switch is turned to ON, and then the cruise control is released.	This code is displayed without depressing the clutch pedal. <Ref. to CC(diag)-19, DTC 13, Diagnostic Procedure without Diagnostic Trouble Code (DTC).>
14	Neutral Position Switch	Neutral position switch is turned to ON, and then the cruise control is released.	This code is displayed without shifting to neutral position. <Ref. to CC(diag)-21, DTC 14, Diagnostic Procedure without Diagnostic Trouble Code (DTC).>
15	Cancel Switch	Cancel switch is turned to ON, and then the cruise control is released.	This code is displayed without operating the cancel switch. <Ref. to CC(diag)-22, DTC 15, Diagnostic Procedure without Diagnostic Trouble Code (DTC).>
16	Ignition Switch	Ignition switch is turned to OFF, and then the cruise control is released.	This code is displayed without operating the ignition switch. <Ref. to CC(diag)-23, DTC 16, Diagnostic Procedure without Diagnostic Trouble Code (DTC).>

List of Cancel Code

CRUISE CONTROL SYSTEM (DIAGNOSTICS)

Cancel code	Item	Contents of diagnosis	Reference
21	Cruise control switch malfunction when ignition switch is turned to ON	When the ignition switch is turned to ON, each switch of cruise control command switch is already turned to ON.	This code is displayed when the ignition switch is turned to ON without operating the cruise control command switch. <Ref. to CC(diag)-23, DTC 21, Diagnostic Procedure without Diagnostic Trouble Code (DTC).>
22	Abnormality of change in vehicle speed	Malfunction of vehicle speed signal variation is detected.	<Ref. to CC(diag)-24, DTC 22, Diagnostic Procedure without Diagnostic Trouble Code (DTC).>
24	Cruise Control Related Switch Malfunction	Open circuit of cruise control switch is detected during cruise driving. (The system is judged as model without cruise control.)	This code is displayed with normal operation. <Ref. to CC(diag)-24, DTC 24, Diagnostic Procedure without Diagnostic Trouble Code (DTC).>
25	Brake Switch Input Circuit Malfunction	Malfunction of brake switch input circuit in ECM is detected.	<Ref. to CC(diag)-24, DTC 25, Diagnostic Procedure without Diagnostic Trouble Code (DTC).>
31	Abnormal engine speed Signal	- Abnormal increase of engine speed is detected. - Gear is placed in Neutral, 1st or Reverse position.	Cruise in 2nd shift position or more. <Ref. to CC(diag)-24, DTC 31, Diagnostic Procedure without Diagnostic Trouble Code (DTC).>
32	Out of vehicle speed range of cruise control operation	- Controlled vehicle speed decreased under the limit during cruising. - Set operation was performed at vehicle speed unavailable for setting. - RESUME operation was performed without memorized vehicle speed.	This code is displayed, though the vehicle speed is increased to the speed available for cruise set and set operation was performed again. <Ref. to CC(diag)-24, DTC 32, Diagnostic Procedure without Diagnostic Trouble Code (DTC).>
34	Prohibition of cruise control at continuing big Accel. angle	The vehicle has been driven at higher speed than set vehicle speed for an abnormally long time (approximately 10 minutes) during cruise driving.	This code is displayed when driving for a long period of time at higher speed than appropriate cruise set vehicle speed by operating accelerator pedal. In this case, the cruise setting is deactivated. <Ref. to CC(diag)-24, DTC 34, Diagnostic Procedure without Diagnostic Trouble Code (DTC).>

List of Cancel Code

CRUISE CONTROL SYSTEM (DIAGNOSTICS)

Cancel code	Item	Contents of diagnosis	Reference
35	Prohibition when vehicle speed feedback is impossible	Set vehicle speed cannot be kept because of some reasons (steep uphill, parking brake, abnormal decrease of engine output, etc.) during cruise driving.	This code is displayed when driving condition is not suitable for cruise control. Perform cruise set operation again after clearing the possible cause. <Ref. to CC(diag)-25, DTC 35, Diagnostic Procedure without Diagnostic Trouble Code (DTC).>
41	VDC/TCS Operating	Vehicle dynamics control (VDC) or TCS is operated during cruise driving or cruise setting.	This code is displayed when driving condition is not suitable for cruise control. Perform cruise set operation again after clearing the possible cause. <Ref. to CC(diag)-25, DTC 41, Diagnostic Procedure without Diagnostic Trouble Code (DTC).>
43	ABS/VDC Failure	ABS or Vehicle dynamics control (VDC) system malfunction is detected during cruise driving or cruise setting.	<Ref. to CC(diag)-25, DTC 43, Diagnostic Procedure without Diagnostic Trouble Code (DTC).>
44	Body Integrated unit Failure	Body integrated unit system malfunction is detected during cruise driving or cruise setting.	<Ref. to CC(diag)-25, DTC 44, Diagnostic Procedure without Diagnostic Trouble Code (DTC).>
45	Meter Failure	Combination meter malfunction is detected during cruise driving or cruise setting.	<Ref. to CC(diag)-25, DTC 45, Diagnostic Procedure without Diagnostic Trouble Code (DTC).>
61	Brake switch abnormal	Malfunction in the stop light & brake switch is detected.	<Ref. to CC(diag)-25, DTC 61, Diagnostic Procedure without Diagnostic Trouble Code (DTC).>
62	Neutral switch Failure	Neutral position switch malfunction is detected.	<Ref. to CC(diag)-25, DTC 62, Diagnostic Procedure without Diagnostic Trouble Code (DTC).>
63	Abnormality 1 of change in vehicle speed	Malfunction of vehicle speed signal variation is detected.	<Ref. to CC(diag)-25, DTC 63, Diagnostic Procedure without Diagnostic Trouble Code (DTC).>
64	Engine Sensor Failure	Malfunction related to engine is detected.	<Ref. to CC(diag)-25, DTC 64, Diagnostic Procedure without Diagnostic Trouble Code (DTC).>
65	Abnormality 1 of switches related to cruise control 1	Cruise control command switch malfunction is detected. (While the switch is pressed ON for a long time (approximately two minutes), stuck ON condition is detected.)	<Ref. to CC(diag)-26, DTC 65, Diagnostic Procedure without Diagnostic Trouble Code (DTC).>
66	Cruise Control Calculation Error	Cruise control calculation (microcomputer) malfunction is detected.	<Ref. to CC(diag)-26, DTC 66, Diagnostic Procedure without Diagnostic Trouble Code (DTC).>