

BRAKE SYSTEM

32149-01

PRECAUTION

- Care must be taken to replace each part properly as it could affect the performance of the brake system and result in a driving hazard. Replace the parts with parts having the same part number or equivalent.
- It is very important to keep parts and the area clean when repairing the brake system.
- When air remains in the brake line or disconnecting the brake line, bleed the air.
- Wash brake fluid off immediately if it adheres to any painted surface.
- Prevent brake fluid from adhering to electronic parts.
- If the vehicle is equipped with a mobile communication system, refer to the precaution in the INTRODUCTION section.
- When disconnecting the negative (-) battery terminal, initialize the following system after the terminal is reconnected.

System Name	See Page
Power Window Control System	01-5

cardiagn.com

PROBLEM SYMPTOMS TABLE

Use the table below to help find the cause of the problem. The numbers indicate the probability of the problems in descending order. Check each part in order. If necessary, replace these parts.

Symptom	Suspected Area	See page
Low pedal or spongy pedal	1. Fluid leaks for brake system	—
	2. Air in brake system	32-4
	3. Piston seals (Worn or damaged)	32-50
		32-57
	4. Master cylinder (faulty)	32-29
		32-36
Brake drag	5. Push rod (Out of adjustment)	32-16
	6. Strike simulator cylinder (faulty)	32-45
	1. Brake pedal free play (Minimal)	32-16
	2. Parking brake pedal travel (Out of adjustment)	33-2
	3. Parking brake cable (Sticking)	33-19
		33-23
		33-26
	4. Rear brake shoe clearance (Out of adjustment)	33-33
	5. Pad (Cracked or distorted)	32-50
		32-57
Brake pull	6. Piston (Stuck)	32-50
		32-57
	7. Piston (Frozen)	32-50
		32-57
	8. Booster push rod (Out adjustment)	32-16
	9. Master cylinder (Faulty)	32-29
		32-36
	1. Piston (Stuck)	32-50
		32-57
	2. Pad (Oily)	32-50
		32-57
	3. Piston (Frozen)	32-50
		32-57
	4. Disc (Scored)	32-50
		32-57
	5. Pad (Cracked or distorted)	32-50
		32-57

BRAKE - BRAKE SYSTEM

Hard pedal but brake inefficient	1. Brake pedal (Out of adjustment, Faulty)	32-16
	2. Piston (Stuck)	32-50
		32-57
	3. Pad (Cracked or distorted)	32-50
		32-57
	4. Pad (Glanzed)	32-50
		32-57
	5. Pad (Oily)	32-50
		32-57
	6. Disc (Oily)	32-50
		32-57
	7. Push rod (Out of adjustment)	32-16
Noise from brakes	1. Pad (Cracked or distorted)	32-50
		32-57
	2. Installation bolt (Loose)	32-50
		32-57
	3. Disc (Scored)	32-50
		32-57
	4. Pad support plate (Loose)	32-50
		32-57
	5. Sliding pin (Worn)	32-50
		32-57
	6. Pad (dirty)	32-50
		32-57
	7. Pad (Glanzed)	32-50
		32-57
	8. Anti-squeal shim (Damaged)	32-50
		32-57

BRAKE FLUID BLEEDING

3214B-01

CAUTION:


Bleeding without the intelligent tester II may result in the air not being completely bled. As this can result in an accident, be sure to use the intelligent tester II for air bleeding.

NOTICE:

- Move the shift lever to the P position and apply the parking brake before bleeding air.
- Add brake fluid carefully so that it remains between MIN and MAX lines of the reservoir while bleeding air.
- Brake fluid may overflow when bleeding the brake actuator hose. Do not place the fluid can on the reservoir inlet.
- If the pump motor operates while there is air remaining inside the brake actuator hose, the air will enter the actuator, resulting in difficulty in air bleeding. Remove the motor relay No.1 and No.2 until instructed to reinstall them in order to prevent air from coming into the brake actuator hose.
- Actuator pump motor and master pressure cut-off solenoid can operate through a supplemental power source even if the power switch is off.
- A buzzer may sound due to the accumulator pressure decline during air bleeding, however, keep on bleeding.
- DTCs for things such as the motor relay No.1 and No.2 malfunction and a pressure sensor malfunction are stored after bleeding. Clear the DTCs when instructed during or after bleeding.
- Bleed the brake actuator hose if air enters as a result of the decline of reservoir fluid.

1. PREPARATION

- (a) Move the shift lever to the P position and apply the parking brake.



- (b) Connect the intelligent tester II to the DLC3 with the power switch off as shown in the illustration.
- (c) Turn the power switch on (IG) and turn on the intelligent tester II.

NOTICE:

Do not start the engine.

- (d) Select "DIAGNOSTIC MENU" → "ABS/VSC" → "AIR BLEEDING" on the intelligent tester II.

AIR BLEEDING

1. Usual
2. Actuator
3. Master Cylinder
or Stroke Simulator

Select the work No.

1

2

3

PRESS [ENTER]

(e) Select "AIR BLEEDING".

- (1) Select "Usual" if the front/rear brakes were removed, installed or disassembled.

HINT:

Go to "4. BLEED FRONT AND REAR BRAKE SYSTEMS" if "Usual" is selected.

- (2) Select "Actuator" if the actuator is removed, installed or replaced.

NOTICE:

Be sure to release the pressure out of the actuator before removing. See "5. BLEED BRAKE ACTUATOR" for bleeding instructions.

HINT:

Go to "5. BLEED BRAKE ACTUATOR" if "Actuator" is selected.

- (3) Select "Master Cylinder or Stroke Simulator" if the brake master cylinder or the brake stroke simulator was removed, installed or replaced.

HINT:


Go to "6. BLEED MASTER CYLINDER/STROKE SIMULATOR" if "Master Cylinder or Stroke Simulator" is selected.

- (f) Return to "MENU" and bleed the air again if the display shown on the left appears during air bleeding.

FAILED

This command can
not be available.

PRESS [ENTER]



- (g) Remove and install the relays as shown in the illustration if instructed to remove and install motor relays No.1 and No.2 by the intelligent tester II.



2. FILL RESERVOIR WITH BRAKE FLUID

NOTICE:

Wash brake fluid off immediately if it adheres to any painted surface.

- (a) Add brake fluid into the reservoir.

Fluid: SAE J1703 or FMVSS No. 116 DOT3



3. BLEED MASTER CYLINDER

HINT:

- If the master cylinder has been disassembled or if the reservoir becomes empty, bleed the air out of the master cylinder.
 - Illustration on the left is for LHD.
- (a) Disconnect the brake lines from the master cylinder.
SST 09023-00100
- (b) Slowly depress and hold the brake pedal.
- (c) Cover the outer holes with your fingers, and release the brake pedal.
- (d) Repeat (b) and (c) 3 or 4 times.
- (e) Connect the brake lines from the master cylinder.
SST 09023-00100
- Torque: 15 N·m (155 kgf·cm, 11 ft·lbf)**

OPERATION

1. Turn the IG OFF.
2. Remove the motor relays No.1 and No.2.
3. Turn the IG ON.

PRESS [ENTER]

4. BLEED FRONT AND REAR BRAKE SYSTEMS

NOTICE:

Wash brake fluid off immediately if it adheres to any painted surface.

HINT:

Bleed the air out of the front and rear brake systems in accordance with the display on the left.

- (a) Remove the motor relays No.1 and No.2.

NOTICE:

- **Remove motor relays No.1 and No.2 before bleeding the air out of the front brake system.**
- **Be sure to turn the power switch off before removing motor relays No.1 and No.2.**

OPERATION

Perform the usual
air bleeding for
FR and FL wheels.

PRESS [ENTER]

- (b) Bleed the air out of the FR/FL wheels if the display shown on the left appears.

- (1) Remove the bleeder plug cap.
- (2) Connect the vinyl tube to the bleeder plug.
- (3) Depress the brake pedal several times, then loosen the bleeder plug with the pedal depressed.
- (4) When the fluid stops coming out, tighten the bleeder plug, and then release the brake pedal.

Torque: 8.4 N·m (86 kgf·cm, 74 in.·lbf)

- (5) Repeat (3) and (4) until all the air in the fluid is completely bled out.
- (6) Install the bleeder plug cap.
- (7) Repeat the previous procedures to bleed the air out of the brake line for each wheel.

- (c) Install the motor relays No.1 and No.2.

NOTICE:

- **Install motor relays No.1 and No.2 before bleeding the air out of the rear brake system.**
- **Be sure to turn the power switch off before installing motor relays No.1 and No.2.**

OPERATION

1. Turn the IG OFF.
2. Install the motor relays No.1 and No.2.
3. Turn the IG ON.

PRESS [ENTER]

- (d) Bleed the air out of the RL wheel if the display shown on the left appears.

- (1) Remove the bleeder plug cap of RL wheel.
- (2) Connect the vinyl tube to the bleeder plug of RL wheel.
- (3) Depress the brake pedal and loosen the bleeder plug of RL wheel until all the air in the fluid is completely bled out.

NOTICE:

Do not pump the brake pedal. Hold the brake pedal depressed when bleeding the air out of the rear brake systems.

HINT:

The actuator motor relay starts operation and oil pressure is applied to the rear brake systems if the brake pedal is depressed, which allows air bleeding through the bleeder plug.

- (4) Tighten the bleeder plug if the air is completely bled out.

Torque: 8.4 N·m (86 kgf·cm, 74 in.·lbf)

OPERATION

Hold the brake
pedal depressed and
loosen the bleeder
plug of RL wheel
until all the air
in the fluid is
completely bled
out.

PRESS [ENTER]

OPERATION

Hold the brake pedal depressed and loosen the bleeder plug of RR wheel until all the air in the fluid is completely bled out.

PRESS [ENTER]

(e) Bleed the air out of the RR wheel if the display shown on the left appears.

- (1) Remove the bleeder plug cap of RR wheel.
- (2) Connect the vinyl tube to the bleeder plug of RR wheel.
- (3) Depress the brake pedal and loosen the bleeder plug of RR wheel until all the air in the fluid is completely bled out.

NOTICE:

Do not pump the brake pedal. Hold the brake pedal depressed when bleeding the air out of the rear brake systems.

HINT:

The actuator motor relay starts operation and oil pressure is applied to the rear brake systems if the brake pedal is depressed, which allows air bleeding through the bleeder plug.

Air Bleeding is
COMPLETE.

PRESS [ENTER]

(f) The air bleeding of the front and rear brake system finishes if the display shown on the left appears.

INFORMATION

Do you wish to refresh the high pressure line?

This operation will take 20 seconds.

PRESS [ENTER]

5. BLEED BRAKE ACTUATOR**NOTICE:**

Wash brake fluid off immediately if it adheres to any painted surface.

HINT:

Bleed the air out of the brake actuator in accordance with the display on the left.

(a) Refresh the high pressure line.

NOTICE:

Be sure to perform this procedure before replacement, removal or installation of the actuator.

HINT:

- Decrease the internal pressure by performing this procedure.
- Count down from 20 seconds.

OPERATION

1. Turn the IG OFF.
2. Remove the motor relays No.1 and No.2
3. Turn the IG ON.
4. Confirm ABS pump motor runs and stops.

PRESS [ENTER]

(b) Follow the procedures shown on the display on the left.

NOTICE:

Be sure to remove motor relays No.1 and No.2 before removing the actuator for replacement, removal or installation.

OPERATION

Perform the usual
air bleeding for
FR and FL wheels.

PRESS [ENTER]

(c) Follow the procedures shown on the display on the left.

HINT:

See "4. BLEED FRONT AND REAR BRAKE SYSTEMS" for bleeding the air out of the front brake system.

INFORMATION

Do you wish to
bleed the air out
of the drain line?

This command
activates solenoids
(SLRFR, SLRFL,
SLRRR and SLRRL).

PRESS [ENTER]

(d) Bleed the air out of the drain line.

NOTICE:

Be sure to perform this procedure if air remains in the actuator hose.

HINT:

Fluid inside the actuator hose returns to the reservoir tank when performing this procedure.

OPERATION

1. Depress the brake pedal 30 times in 30 seconds.
2. Turn the IG OFF.
3. Install the motor relays No.1 and No.2
4. Turn the IG ON.

PRESS [ENTER]

- (e) Depress the brake pedal 30 times within 30 seconds while the solenoid is operating.

HINT:

The solenoid stops operation automatically after approximately 30 seconds.

- (f) Install the motor relays No.1 and No.2.

NOTICE:

- **Install motor relays No.1 and No.2 before bleeding the air out of the rear brake system.**
- **Be sure to turn the power switch off before installing motor relays No.1 and No.2.**

OPERATION

Hold the brake pedal depressed and loosen the bleeder plug of RL wheel until all the air in the fluid is completely bled out.

PRESS [ENTER]

- (g) Bleed the air out of the rear brake RL wheel.

HINT:

See "4. BLEED FRONT AND REAR BRAKE SYSTEMS" for bleeding the air out of the rear brake system.

OPERATION

Hold the brake pedal depressed and loosen the bleeder plug of RR wheel until all the air in the fluid is completely bled out.

PRESS [ENTER]

- (h) Bleed the air out of the rear brake RR wheel.

HINT:

See "4. BLEED FRONT AND REAR BRAKE SYSTEMS" for bleeding the air out of the rear brake system.

OPERATION

Loosen the bleeder
plug of FL wheel.

PRESS [ENTER]

- (i) Loosen the bleeder plug of FL wheel.

INFORMATION

Do you wish to
bleed the air out
of the power
supply line?

This command
activates solenoids
(SMC2 and SLAFL).

PRESS [ENTER]

- (j) Bleed the air out of the power supply line.

HINT:

Air can be bled out of the high pressure line inside the actuator when performing this procedure.

OPERATION

Tighten the bleeder
plug of FL wheel.

PRESS [ENTER]

- (k) Tighten the bleeder plug of FL wheel.
Torque: 8.4 N·m (86 kgf·cm, 74 in.·lbf)

INFORMATION
(*2)

Do you wish to
bleed the air out
of the stroke
simulator line?

This command
activates solenoids
(SMC2 and SCSS).

PRESS [ENTER]

(I) Bleed the air out of the stroke simulator line.

HINT:

- See "6. BLEED BRAKE MASTER CYLINDER/STROKE SIMULATOR" for bleeding the air out of the stroke simulator.
- Bleed the air out of the stroke simulator twice.
- The number of times air is bled is displayed as 1/2 (first) and 2/2 (second).

OPERATION
(*2)

Depress the brake
pedal 20 times in
20 seconds.

PRESS [ENTER]

(1) Depress the brake pedal 20 times in 20 seconds.

HINT:

Depress the brake pedal 20 times at 1 second intervals, holding the pedal down on the last time.

OPERATION
(*2)

Perform the usual
air bleeding for
FL wheel.

PRESS [ENTER]

(2) Perform the usual air bleeding for FL wheel.

HINT:

- Loosen the bleeder plug of the FL wheel and bleed the air with the brake pedal depressed.
- See "4. BLEED FRONT AND REAR BRAKE SYSTEMS" for bleeding instructions.

INFORMATION
(* / 5)

Do you wish to
refresh the
high pressure line?

This operation
will take
20 seconds.

PRESS [ENTER]

OPERATION
(* / 5)

1. Turn the IG OFF,
and ON again.
2. Confirm the ABS
motor pump runs and
stops.

PRESS [ENTER]

OPERATION

1. Turn the IG OFF.
2. Remove the motor
relays No.1 and
No.2.
3. Turn the IG ON.

PRESS [ENTER]

(m) Refresh the high pressure line.

NOTICE:

Keep the fluid inside the reservoir above the "LOW" level by replenishing.

HINT:

- Accumulator pressure is released and accumulated repeatedly, which circulates the fluid inside the accumulator when performing this procedure.
- The high pressure line is refreshed 5 times. The number of times refreshed is displayed as 1/5 (first), 2/5 (second) and so on.
- Count down from 20 seconds.

(n) Turn the power switch off. Turn the power switch on (IG) and check if the ABS motor pump runs and stops.

HINT:

The pump motor rotates and the accumulator is pressurized every time turning the power switch from off to on (IG).

(o) Return to "MENU".

6. BLEED MASTER CYLINDER/STROKE SIMULATOR

NOTICE:

Wash brake fluid off immediately if it adheres to any painted surface.

HINT:

Bleed the air out of the master cylinder/stroke simulator in accordance with the display shown on the left.

(a) Remove the motor relays No.1 and No.2.

NOTICE:

- **Remove motor relays No.1 and No.2 before bleeding the air out of the front brake system.**
- **Be sure to turn the power switch off before removing motor relays No.1 and No.2.**

OPERATION

Perform the usual
air bleeding for
FR and FL wheels.

PRESS [ENTER]

- (b) Bleed the air out of the FR/FL wheels in accordance with the display shown on the left.

HINT:

- Air can be completely bled out of the master cylinder by performing this procedure.
- See "4. BLEED FRONT AND REAR BRAKE SYSTEMS" for bleeding instructions.

OPERATION

1. Turn the IG OFF.
2. Install the motor relays No.1 and No.2.
3. Turn the IG ON.

PRESS [ENTER]

- (c) Install the motor relays No.1 and No.2.

NOTICE:

- **Install motor relays No.1 and No.2 before bleeding the air out of the stroke simulator.**
- **Be sure to turn the power switch off before installing motor relays No.1 and No.2.**

INFORMATION
(*2)

Do you wish to
bleed the air out
of the stroke
simulator line?

This command
activates solenoids
(SMC2 and SCSS).

PRESS [ENTER]

- (d) Bleed the air out of the stroke simulator line.

HINT:

- Bleed the air out of the stroke simulator twice.
- The number of times air is bled is displayed as 1/2 (first) and 2/2 (second).

OPERATION
(*2)

Depress the brake
pedal 20 times in
20 seconds.

PRESS [ENTER]

- (1) Depress the brake pedal 20 times in 20 seconds.

HINT:

Depress the brake pedal 20 times at 1 second intervals, holding the pedal down on the last time.

OPERATION
(*2)

Perform the usual
air bleeding for
FL wheel.

PRESS [ENTER]

- (2) Perform the usual air bleeding for FL wheel.

HINT:

- Loosen the bleeder plug of the FL wheel and bleed the air with the brake pedal depressed.
- See "4. BLEED FRONT AND REAR BRAKE SYSTEMS" for bleeding instructions.



Air Bleeding is
COMPLETE.

PRESS [ENTER]

- (e) The air bleeding of the master cylinder/stroke simulator finishes if the display shown on the left appears.

7. CHECK AND CLEAR DTC (SEE PAGE 05-738)

BRAKE PEDAL ADJUSTMENT



1. CHECK AND ADJUST BRAKE PEDAL HEIGHT

NOTICE:

Pull up the floor carpet and dash panel insulator assy, and then check and adjust the brake pedal height.



- Remove instrument panel finish panel LWR. (see page 71-7)
- Inspect brake pedal height.
Pedal height from the top of the asphalt sheet: 138 to 148 mm (5.433 to 5.827 in.)
- Adjust brake pedal height.
 - Disconnect the connector from the stop lamp switch.
 - Loosen the stop lamp switch lock nut. Turn the switch in order to give the pedal some free play.
 - Loosen the clevis lock nut. Turn the push rod and adjust the pedal height.
 - Tighten the clevis lock nut.

Torque: 26 N·m (265 kgf·cm, 19 ft·lbf)

- Turn the stop lamp switch so that the clearance between its thread portion tip and the area where the pedal makes contact is between 0.5 to 2.4 mm (0.020 to 0.095 in.). Tighten the lock nut.

Torque: 26 N·m (265 kgf·cm, 19 ft·lbf)

- Connect the connector to the stop lamp switch.
- Connect the intelligent tester II to the DLC3.
- Loosen the stroke sensor set bolts.



- (9) Turn the power switch on. Read the stroke sensor 1 value displayed on the data monitor using the intelligent tester II. Slowly turn the stroke sensor to the right and left to adjust it to the standard value.

Standard value: 0.8 to 1.2 V


- (10) Tighten the stroke sensor set bolts.

Torque: 9.3 N·m (95 kgf·cm, 82 in.-lbf)

CAUTION:

Do not depress the brake pedal after the power switch turns on.

- (11) Carry out system initialization. (see page 05-721)
 (d) Install instrument panel finish panel LWR.



2. CHECK PEDAL FREE PLAY

- (a) Depress the brake pedal several times strongly after the engine stops.
 (b) Check the brake pedal free play.

Pedal free play: 0.5 to 4 mm (0.02 to 0.16 in.)

If incorrect, proceed to the following step.


- (1) Check the stop lamp switch clearance.

Stop lamp switch clearance:

0.5 to 2.4 mm (0.020 to 0.095 in.)

If the clearance is OK, then troubleshoot the brake system.

If incorrect, adjust the stop lamp switch clearance.



3. CHECK PEDAL RESERVE DISTANCE

- (a) Release the parking brake pedal.
- (b) With engine running, depress the pedal and measure the pedal reserve distance, as shown in the illustration.

Pedal reserve distance from the top of the asphalt sheet:

196 N (20 kgf, 44.1 lbf):

More than 101 mm (4.0 in.) (RHD)

More than 104 mm (4.1 in.) (LHD)


NOTICE:

Pull up the floor carpet and dash panel insulator assy, and then check the brake pedal reserve distance.

HINT:


If incorrect, troubleshoot the brake system ([see page 32-2](#)).

COMPONENTS



cardiagn.com

LHD:



N·m (kgf·cm, ft·lbf) : Specified torque

◆ Non-reusable part

← Lithium soap base glycol grease


F46137

OVERHAUL

1. REMOVE INSTRUMENT PANEL SUB-ASSY W/PASSENGER AIRBAG ASSY (SEE PAGE 71-7)


HINT:

Refer to the procedures from the removal of the instrument panel register assy No.1 up until the removal of the instrument panel sub-assy w/passenger airbag assy.





2. REMOVE MASTER CYLINDER PUSH ROD CLEVIS


- Remove the brake pedal return spring.
- Remove the clip and brake master cylinder push rod pin.
- Separate the push rod clevis from the brake pedal sub-assy.




3. REMOVE BRAKE PEDAL SUPPORT SUB-ASSY

- Disconnect the connector from the stop lamp switch assy.
- Disconnect the connector from the brake pedal stroke sensor.
- Remove the bolt from the instrument panel upper panel side.






- (d) Remove the 4 nuts and the brake pedal support sub-assy.





4. REMOVE BRAKE PEDAL PAD



5. REMOVE STOP LAMP SWITCH ASSY


- (a) Loosen the stop lamp switch lock nut and remove the stop lamp switch assy from the brake pedal support sub-assy.





6. REMOVE BRAKE PEDAL STROKE SENSOR ASSY

- (a) Remove the 2 bolts and separate the brake pedal stroke sensor from the brake pedal support sub-assy.



7. REMOVE BRAKE PEDAL SUB-ASSY


- (a) Remove the nut from the brake pedal shaft.
- (b) Remove the brake pedal shaft and separate the brake pedal from the brake pedal support sub-assy.
- (c) Remove the 2 brake pedal bushes from the brake pedal sub-assy.
- (d) Remove the brake pedal shaft collar from the brake pedal shaft.

8. INSTALL BRAKE PEDAL SUB-ASSY

- (a) Apply lithium soap base glycol grease to the 2 new brake pedal bushes. Install the brake pedal bushes to the brake pedal sub-assy.
- (b) Install the brake pedal shaft collar to the brake pedal shaft.
- (c) Install the brake pedal to the brake pedal support with the brake pedal shaft and a nut.

Torque: 37 N·m (375 kgf·cm, 27 ft·lbf)

RHD:



P

G28750


9. INSTALL BRAKE PEDAL STROKE SENSOR ASSY

- (a) Install the brake pedal stroke sensor to the brake pedal support sub-assy with the 2 bolts.

HINT:

Tighten the bolts when checking and adjusting the brake pedal height.


LHD:



P

F46144

RHD:



P

G28749


10. INSTALL STOP LAMP SWITCH ASSY

- (a) Turn the stop lamp switch assy clockwise and install it to the brake pedal support sub-assy.

HINT:

Tighten the lock nut when checking and adjusting the brake pedal height.


LHD:



P

F46143



11. INSTALL BRAKE PEDAL PAD



12. INSTALL BRAKE PEDAL SUPPORT SUB-ASSY

- (a) Install the brake pedal support with the 4 nuts.


Torque: 13 N·m (130 kgf·cm, 9 ft·lbf)





- (b) Install the brake pedal support from the instrument panel side with a bolt.

Torque: 24 N·m (241 kgf·cm, 18 ft·lbf)

- (c) Connect the connector to the stop lamp switch assy.
(d) Connect the connector to the brake pedal stroke sensor.



**13. INSTALL MASTER CYLINDER PUSH ROD CLEVIS**

- (a) Apply lithium soap base glycol grease to the circumference of the brake master cylinder push rod pin.
- (b) Install the push rod clevis to the brake pedal with the brake master cylinder push rod pin.
- (c) Install the clip and brake pedal return spring.

14. INSTALL INSTRUMENT PANEL SUB-ASSY W/PASSENGER AIRBAG ASSY**15. CHECK AND ADJUST BRAKE PEDAL HEIGHT (SEE PAGE 32-16)****16. CHECK PEDAL FREE PLAY (SEE PAGE 32-16)****17. CHECK PEDAL RESERVE DISTANCE (SEE PAGE 32-16)**

BRAKE MASTER CYLINDER SUB-ASSY (RHD)

3214F-01

ON-VEHICLE INSPECTION

NOTICE:

The DTC may be stored after inspection. Be sure to clear the DTC and check that a normal system code is output after the inspection is finished.

1. INSPECT BRAKE MASTER CYLINDER

- (a) Check battery voltage

Standard Value: 10 to 14 V (during engine stop)

- (b) Connect intelligent tester II and pedal effort gauge

(1) Connect the pedal effort gauge.

(2) Move the shift lever to the P position. Apply the parking brake and connect the intelligent tester II to the DLC3.

(3) Turn the power switch on (IG).

(4) Clear the DTC ([see page 05-738](#)).

- (c) Check operation w/o brake booster

(1) Check and adjust brake pedal height ([see page 32-16](#)).

(2) Check pedal free play ([see page 32-16](#)).

(3) Check pedal reserve distance ([see page 32-16](#)).

(4) Turn on the intelligent tester II and select "ECB INVALID" to prohibit the brake control (ECB).

(5) Monitor "MAS CYL PRS 1", "MAS CYL PRS 2", "PEDAL STROKE" and "PEDAL STROKE 2" using the intelligent tester II.


(6) Check the value output from "MAS CYL PRS 1", "MAS CYL PRS 2", "PEDAL STROKE" and "PEDAL STROKE 2" by depressing the brake pedal.

Standard Value:

Pedal Effort N (kgf, lbf)	MAS CYL PRS 1 (V)	MAS CYL PRS 2 (V)	PEDAL STROKE (V)	PEDAL STROKE 2 (V)
200 (20.4, 45)	0.9 - 1.2	0.9 - 1.2	1.7 - 2.1	2.9 - 3.3
500 (51, 112)	1.7 - 2.2	1.7 - 2.2	1.9 - 2.3	2.7 - 3.1

- (7) Finish the brake control prohibition on the intelligent tester II.


COMPONENTS



G26778

REPLACEMENT

1. REMOVE FR WIPER ARM LH (SEE PAGE 66-16)
2. REMOVE FR WIPER ARM RH (SEE PAGE 66-16)
3. REMOVE HOOD TO COWL TOP SEAL (SEE PAGE 66-16)
4. REMOVE COWL TOP VENTILATOR LOUVER LH (SEE PAGE 66-16)
5. REMOVE COWL TOP VENTILATOR LOUVER RH (SEE PAGE 66-16)
6. REMOVE WINDSHIELD WIPER MOTOR & LINK ASSY (SEE PAGE 66-16)



7. BRAKE CONTROL (ECB) OFF

NOTICE:

Prohibit the brake control (ECB) certainly before bleeding the brake fluid.


- (a) With the power switch off to prohibit brake control, remove the motor relays No.1 and No.2.

NOTICE:

If the pump motor operates while there is air remaining inside the brake actuator hose, the air will enter the actuator, resulting in difficulty in air bleeding.


HINT:

Brake control (ECB) can be prohibited by selecting "ECB INVALID" on the intelligent tester II.




8. REMOVE COWL TOP PANEL SUB-ASSY OUTER FRONT

- (a) Remove the 2 bolts and separate the engine room R/B No.2.



- (b) Remove the 3 clamps from the cowl top panel sub-assy outer front.




- (c) Remove the 7 bolts and separate the cowl top panel sub-assy outer front.

9. DRAIN BRAKE FLUID


NOTICE:

Wash brake fluid off immediately if it adheres to any painted surface.




10. REMOVE BRAKE MASTER CYLINDER SUB-ASSY


- (a) Remove the brake pedal return spring.
 (b) Remove the clip and brake master cylinder push rod pin, and separate the push rod clevis from the brake pedal.




- (c) Remove the 2 clips and separate the brake master cylinder reservoir tubes No.1 and No.2.




- (d) Remove the 2 clips and separate the brake master cylinder reservoir tubes No.1 and No.2 from the brake master cylinder sub-assy.




- (e) Using SST, separate the front brake tube No.1 and No.2 from the brake master cylinder sub-assy.
SST 09023-00100




- (f) Remove the 2 nuts, and remove the brake mater cylinder gasket and brake master cylinder sub-assy from the bracket.



- (g) Remove the screw, and remove the brake master cylinder union No.1 and 2 grommets from the brake master cylinder sub-assy.



- (h) Loosen the clevis lock nut and remove the brake master cylinder push rod clevis.



11. INSTALL BRAKE MASTER CYLINDER SUB-ASSY


- (a) Install the brake master cylinder push rod clevis to the brake master cylinder sub-assy, and fix by the lock nut.

HINT:


After adjusting the brake pedal height, torque the lock nut.

- (b) Apply lithium soap base glycol grease to the 2 new grommets.
(c) Install the brake master cylinder union No.1 and 2 grommets to the brake master cylinder sub-assy with a screw.


Torque: 1.8 N·m (18 kgf·cm, 16 in.·lbf)




- (d) Placing the gasket in between, install the brake master cylinder sub-assy to the bracket with 2 nuts.
Torque: 13 N·m (127 kgf·cm, 9 ft·lbf)




- (e) Using SST, connect the 2 brake tubes to the brake master cylinder sub-assy.
 SST 09023-00100
Torque: 15 N·m (155 kgf·cm, 11 ft·lbf)




- (f) Connect the brake master cylinder reservoir tubes No.1 and No.2 to the brake master cylinder sub-assy and hold it there with clips.



- (g) Connect the brake master cylinder reservoir tubes No.1 and No.2 to the brake master cylinder reservoir assy w/ bracket and hold it there with clips.




- (h) Install the push rod clevis with the brake master cylinder push rod pin to the brake pedal.
 (i) Install the clip and brake pedal return spring.




12. INSTALL COWL TOP PANEL SUB-ASSY OUTER FRONT

- (a) Install the cowl top panel sub-assy outer front with the 7 bolts.

Torque: 6.4 N·m (65 kgf·cm, 57 in·lbf)



- (b) Install the 3 clamps to the cowl top panel sub-assy outer front.



- (c) Install the engine room R/B No.2 with the 2 bolts.

Torque: 8.4 N·m (86 kgf·cm, 74 in·lbf)

13. INSTALL WINDSHIELD WIPER MOTOR & LINK ASSY (SEE PAGE 66-16)

14. INSTALL FR WIPER ARM LH (SEE PAGE 66-16)

15. INSTALL FR WIPER ARM RH (SEE PAGE 66-16)

16. FILL RESERVOIR WITH BRAKE FLUID (SEE PAGE 32-4)

17. BLEED MASTER CYLINDER (SEE PAGE 32-4)

SST 09023-00100

18. BLEED MASTER CYLINDER /STROKE SIMULATOR (SEE PAGE 32-4)

19. CHECK BRAKE FLUID LEAKAGE

20. CHECK FLUID LEVEL IN RESERVOIR

21. CHECK AND ADJUST BRAKE PEDAL HEIGHT (SEE PAGE 32-16)

22. CHECK PEDAL FREE PLAY (SEE PAGE 32-16)

23. CHECK PEDAL RESERVE DISTANCE (SEE PAGE 32-16)

24. CHECK AND CLEAR DTC (SEE PAGE 05-738)

BRAKE MASTER CYLINDER SUB-ASSY (LHD)

3214I-01

ON-VEHICLE INSPECTION

NOTICE:

The DTC may be stored after inspection. Be sure to clear the DTC and check that a normal code system is output after the inspection is finished.

1. INSPECT BRAKE MASTER CYLINDER

- (a) Check battery voltage

Standard Value: 10 to 14 V (during engine stop)

- (b) Connect intelligent tester II and pedal effort gauge

- (1) Connect the pedal effort gauge.
- (2) Move the shift lever to the P position. Apply the parking brake and connect the intelligent tester II to the DLC3.
- (3) Turn the power switch on (IG).
- (4) Clear the DTC ([see page 05-738](#)).

- (c) Check operation w/o brake booster


- (1) Check and adjust brake pedal height ([see page 32-16](#)).
- (2) Check pedal free play ([see page 32-16](#)).
- (3) Check pedal reserve distance ([see page 32-16](#)).
- (4) Turn on the intelligent tester II and select "ECB INVALID" to prohibit the brake control (ECB).
- (5) Monitor "MAS CYL PRS 1", "MAS CYL PRS 2", "PEDAL STROKE" and "PEDAL STROKE 2" using the intelligent tester II.
- (6) Check the value output from "MAS CYL PRS 1", "MAS CYL PRS 2", "PEDAL STROKE" and "PEDAL STROKE 2" by depressing the brake pedal.

Standard Value:

Pedal Effort N (kgf, lbf)	MAS CYL PRS 1 (V)	MAS CYL PRS 2 (V)	PEDAL STROKE (V)	PEDAL STROKE 2 (V)
200 (20.4, 45)	0.9 - 1.2	0.9 - 1.2	1.7 - 2.1	2.9 - 3.3
500 (51, 112)	1.7 - 2.2	1.7 - 2.2	1.9 - 2.3	2.7 - 3.1

- (7) Finish the brake control prohibition on the intelligent tester II.

COMPONENTS




P

F46135

REPLACEMENT

1. REMOVE FR WIPER ARM LH (SEE PAGE 66-16)
2. REMOVE FR WIPER ARM RH (SEE PAGE 66-16)
3. REMOVE HOOD TO COWL TOP SEAL (SEE PAGE 66-16)
4. REMOVE COWL TOP VENTILATOR LOUVER LH (SEE PAGE 66-16)
5. REMOVE COWL TOP VENTILATOR LOUVER RH (SEE PAGE 66-16)
6. REMOVE WINDSHIELD WIPER MOTOR & LINK ASSY (SEE PAGE 66-16)



7. BRAKE CONTROL (ECB) OFF

NOTICE:

Prohibit the brake control (ECB) certainly before bleeding the brake fluid.


- (a) With the power switch off to prohibit brake control, remove the motor relays No.1 and No.2.

NOTICE:

If the pump motor operates while there is air remaining inside the brake actuator hose, the air will enter the actuator, resulting in difficulty in air bleeding.


HINT:

Brake control (ECB) can be prohibited by selecting "ECB INVALID" on the intelligent tester II.




8. REMOVE COWL TOP PANEL SUB-ASSY OUTER FRONT

- (a) Remove the 2 bolts and separate the engine room R/B No.2.



- (b) Remove the 3 clamps from the cowl top panel sub-assy outer front.



- (c) Remove the 7 bolts and separate the cowl top panel sub-assy outer front.

9. REMOVE W/CONVERTER INVERTER ASSY (SEE PAGE 21-25)

HINT:

Refer to the procedures from the removal of the engine undercover LH up until the removal of the inverter assy with converter.


10. DRAIN BRAKE FLUID

NOTICE:

Wash brake fluid off immediately if it adheres to any painted surface.


11. REMOVE INSTRUMENT PANEL REGISTER ASSY NO.1 (SEE PAGE 71-7)

12. REMOVE INSTRUMENT PANEL FINISH PANEL SUB-ASSY LOWER (SEE PAGE 71-7)




13. REMOVE BRAKE MASTER CYLINDER SUB-ASSY


- (a) Remove the brake return spring.
 (b) Remove the clip and brake master cylinder push rod pin, and separate the push rod clevis from the brake pedal.




- (c) Remove the 4 clips and 2 reservoir tube hoses.




- (d) Remove the bolt from the actuator bracket.
 (e) Using SST, remove the front brake tube No.1.
 SST 09023-00100




- (f) Using SST, separate the front brake tube No.2 from the clamp and brake master cylinder sub-assy.
SST 09023-00100




- (g) Remove the 2 nuts, and remove the brake master cylinder gasket and brake master cylinder sub-assy from the bracket.








- (h) Using SST, remove the brake tube and 2 way from the brake master cylinder sub-assy.
SST 09023-00100



- (i) Remove the screw, and remove the brake master cylinder union No.1 and 2 grommets from the brake master cylinder sub-assy.



- (j) Loosen the clevis lock nut and remove the brake master cylinder push rod clevis.



14. INSTALL BRAKE MASTER CYLINDER SUB-ASSY

- (a) Install the brake master cylinder push rod clevis to the brake master cylinder sub-assy, and fix by the lock nut.

HINT:

After adjusting the brake pedal height, torque the lock nut.

- (b) Apply lithium soap base glycol grease to the 2 new grommets.
(c) Install the brake master cylinder union No.1 and 2 grommets to the brake master cylinder sub-assy with a screw.

Torque: 1.8 N·m (18 kgf·cm, 16 in·lbf)

- (d) Using SST, install the brake tube and 2 way to the brake master cylinder sub-assy.

SST 09023-00100

Torque: 15 N·m (155 kgf·cm, 11 ft·lbf)

- (e) Placing the gasket in between, install the brake master cylinder sub-assy to the bracket with 2 nuts.

Torque: 13 N·m (127 kgf·cm, 9 ft·lbf)

- (f) Using SST, connect the front brake tube No.2 to the clamp and brake master cylinder sub-assy.

SST 09023-00100

Torque: 15 N·m (155 kgf·cm, 11 ft·lbf)


- (g) Using SST, connect the front brake tube No.1.

SST 09023-00100


Torque: 15 N·m (155 kgf·cm, 11 ft·lbf)

- (h) Install the bolt to the actuator bracket.

Torque: 5.0 N·m (51 kgf·cm, 44 in·lbf)




- (i) Connect the 2 reservoir tube hoses and hold them there with clips.



- (j) Install the push rod clevis with the brake master cylinder push rod pin to the brake pedal.
 (k) Install the clip and brake pedal return spring.


15. INSTALL W/CONVERTER INVERTER ASSY (SEE PAGE 21-25)




16. INSTALL COWL TOP PANEL SUB-ASSY OUTER FRONT

- (a) Install the cowl top panel sub-assy outer front with the 7 bolts.

Torque: 6.4 N·m (65 kgf·cm, 57 in·lbf)



- (b) Install the 3 clamps to the cowl top panel sub-assy outer front.



- (c) Install the engine room R/B No.2 with the 2 bolts.
Torque: 8.4 N·m (86 kgf·cm, 74 in·lbf)

17. INSTALL WINDSHIELD WIPER MOTOR & LINK ASSY (SEE PAGE 66-16)
18. INSTALL FR WIPER ARM LH (SEE PAGE 66-16)
19. INSTALL FR WIPER ARM RH (SEE PAGE 66-16)
20. FILL RESERVOIR WITH BRAKE FLUID (SEE PAGE 32-4)
21. BLEED MASTER CYLINDER (SEE PAGE 32-4)
SST 09023-00100
22. BLEED MASTER CYLINDER /STROKE SIMULATOR (SEE PAGE 32-4)
23. CHECK BRAKE FLUID LEAKAGE
24. CHECK FLUID LEVEL IN RESERVOIR
25. CHECK AND ADJUST BRAKE PEDAL HEIGHT (SEE PAGE 32-16)
26. CHECK PEDAL FREE PLAY (SEE PAGE 32-16)
27. CHECK PEDAL RESERVE DISTANCE (SEE PAGE 32-16)
28. INSTALL INSTRUMENT PANEL FINISH PANEL SUB-ASSY LOWER
29. INSTALL INSTRUMENT PANEL REGISTER ASSY NO.1
30. CHECK AND CLEAR DTC (SEE PAGE 05-738)

BRAKE STROKE SIMULATOR CYLINDER SUB-ASSY

ON-VEHICLE INSPECTION

3214L-01

NOTICE:

The DTC may be stored after inspection. Be sure to clear the DTC and check that a normal system code is output after the inspection is finished.

1. INSPECT STROKE SIMULATOR

- (a) Check battery voltage

Standard Value: 10 to 14 V (during engine stop)

- (b) Connect intelligent tester II and pedal effort gauge

- (1) Connect the pedal effort gauge.
- (2) Move the shift lever to the P position. Apply the parking brake and connect the intelligent tester II to the DLC3.
- (3) Turn the power switch on (IG).
- (4) Clear the DTC (see page 05-738).

- (c) Check operation w/o brake booster (see page 32-27).

- (1) Check and adjust brake pedal height (see page 32-16).
- (2) Check pedal free play (see page 32-16).
- (3) Check pedal reserve distance (see page 32-16).
- (4) Turn on the intelligent tester II and select "ECB INVALID" to prohibit the brake control (ECB).
- (5) Monitor "MAS CYL PRS 1", "MAS CYL PRS 2", "PEDAL STROKE" and "PEDAL STROKE 2" using the intelligent tester II.
- (6) Check the value output from "MAS CYL PRS 1", "MAS CYL PRS 2", "PEDAL STROKE" and "PEDAL STROKE 2" by depressing the brake pedal.

Standard Value:

Pedal Effort N (kgf, lbf)	MAS CYL PRS 1 (V)	MAS CYL PRS 2 (V)	PEDAL STROKE (V)	PEDAL STROKE 2 (V)
200 (20.4, 45)	0.9 - 1.2	0.9 - 1.2	1.7 - 2.1	2.9 - 3.3
500 (51, 112)	1.7 - 2.2	1.7 - 2.2	1.9 - 2.3	2.7 - 3.1

- (7) Finish the brake control prohibition on the intelligent tester II.


- (d) Check operation w/ brake booster

- (1) Turn on the power switch.
- (2) Turn on the intelligent tester II and monitor the value of "PEDAL STROKE" and "PEDAL STROKE 2".
- (3) Depress the brake pedal 4 to 5 times.
- (4) Check the value output from "PEDAL STROKE" and "PEDAL STROKE 2" by depressing the brake pedal.

Pedal Effort N (kgf, lbf)	PEDAL STROKE (V)	PEDAL STROKE 2 (V)
50 (5.1, 11)	1.1 - 1.7	3.3 - 3.8
100 (10.2, 22)	1.3 - 1.8	3.2 - 3.7
150 (15.3, 34)	1.4 - 1.8	3.2 - 3.6
200 (20.4, 45)	1.4 - 1.8	3.2 - 3.6

COMPONENTS


RHD:



N·m (kgf·cm, ft·lbf) : Specified torque

G26777

LHD:



N·m (kgf·cm, ft·lbf) : Specified torque

F46825

REPLACEMENT

1. REMOVE FR WIPER ARM LH (SEE PAGE 66-16)
2. REMOVE FR WIPER ARM RH (SEE PAGE 66-16)
3. REMOVE HOOD TO COWL TOP SEAL (SEE PAGE 66-16)
4. REMOVE COWL TOP VENTILATOR LOUVER LH (SEE PAGE 66-16)
5. REMOVE COWL TOP VENTILATOR LOUVER RH (SEE PAGE 66-16)
6. REMOVE WINDSHIELD WIPER MOTOR & LINK ASSY (SEE PAGE 66-16)
7. BRAKE CONTROL (ECB) OFF (SEE PAGE 32-29)


NOTICE:

Prohibit the brake control (ECB) certainly before bleeding the brake fluid.

8. REMOVE COWL TOP PANEL SUB-ASSY OUTER FRONT (SEE PAGE 32-29)
9. DRAIN BRAKE FLUID


NOTICE:

Wash brake fluid off immediately if it adheres to any painted surface.




10. REMOVE FRONT BRAKE TUBE NO.2 (RHD STEERING POSITION TYPE)

- (a) Using SST, remove the front brake tube No.2 from the brake master cylinder assy and brake stroke simulator.
SST 09023-00100




11. REMOVE BRAKE STROKE SIMULATOR CYLINDER SUB-ASSY (RHD STEERING POSITION TYPE)


- (a) Using SST, separate the front brake tube No.9 and connector.
SST 09023-00100



- (b) Remove the 2 nuts and 2 bolts, and remove the brake stroke simulator with bracket.




- (c) Remove the 2 bolts and clamp of connector, and remove the bracket from the brake stroke simulator.
- (d) Remove the 2 stud bolts from the brake stroke simulator.




12. REMOVE BRAKE STROKE SIMULATOR CYLINDER SUB-ASSY (LHD STEERING POSITION TYPE)


- (a) Using SST, separate the 2 brake tubes from the brake stroke simulator.
SST 09023-00100



- (b) Remove the 2 nuts and 2 bolts, and remove the brake stroke simulator with bracket.




- (c) Remove the 2 bolts and clamp of connector, and remove the bracket from the brake stroke simulator.
- (d) Remove the 2 stud bolts from the brake stroke simulator.




13. INSTALL BRAKE STROKE SIMULATOR CYLINDER SUB-ASSY (RHD STEERING POSITION TYPE)

- (a) Install the 2 stud bolts to the brake stroke simulator.
Torque: 5.0 N·m (51 kgf·cm, 44 in.·lbf)
- (b) Install the brake stroke simulator to the bracket with the 2 bolts.
Torque: 6.0 N·m (61 kgf·cm, 53 in.·lbf)
- (c) Install the connector clamp of brake stroke simulator to the bracket.



- (d) Install the brake stroke simulator and bracket to the body with the 2 nuts and 2 bolts.


Torque: 8.5 N·m (87 kgf·cm, 75 in·lbf)



- (e) Using SST, install the front brake tube No.9 and connect the connector.

SST 09023-00100

Torque: 15 N·m (155 kgf·cm, 11 ft·lbf)



14. INSTALL BRAKE STROKE SIMULATOR CYLINDER SUB-ASSY (LHD STEERING POSITION TYPE)


- (a) Install the 2 stud bolts to the brake stroke simulator.

Torque: 5.0 N·m (51 kgf·cm, 44 in·lbf)

- (b) Install the brake stroke simulator to the bracket with the 2 bolts.


Torque: 6.0 N·m (61 kgf·cm, 53 in·lbf)

- (c) Install the connector clamp of brake stroke simulator to the bracket.



- (d) Install the brake stroke simulator and bracket to the body with the 2 nuts and 2 bolts.


Torque: 8.5 N·m (87 kgf·cm, 75 in·lbf)



- (e) Using SST, install the 2 brake tubes to the brake stroke simulator.

SST 09023-00100

Torque: 15 N·m (155 kgf·cm, 11 ft·lbf)



15. INSTALL FRONT BRAKE TUBE NO.2 (RHD STEERING POSITION TYPE)

- (a) Using SST, install the front brake tube No.2 to the brake master cylinder assy and brake stroke simulator.


SST 09023-00100

Torque: 15 N·m (155 kgf·cm, 11 ft·lbf)

16. INSTALL COWL TOP PANEL SUB-ASSY OUTER FRONT ([SEE PAGE 32-29](#))
17. INSTALL WINDSHIELD WIPER MOTOR & LINK ASSY ([SEE PAGE 66-16](#))
18. INSTALL FR WIPER ARM LH ([SEE PAGE 66-16](#))
19. INSTALL FR WIPER ARM RH ([SEE PAGE 66-16](#))
20. FILL RESERVOIR WITH BRAKE FLUID ([SEE PAGE 32-4](#))
21. BLEED MASTER CYLINDER /STROKE SIMULATOR ([SEE PAGE 32-4](#))
22. CHECK BRAKE FLUID LEAKAGE
23. CHECK FLUID LEVEL IN RESERVOIR
24. CHECK AND CLEAR DTC ([SEE PAGE 05-738](#))
25. SYSTEM INITIALIZATION ([SEE PAGE 05-721](#))
26. CHECK OPERATION ([SEE PAGE 32-42](#))

FRONT BRAKE COMPONENTS

3208U-03



F47466

OVERHAUL

HINT:

If work that does not involve brake fluid bleeding, such as disc brake pad replacement, is started 2 minutes or more after the power switch is turned off, brake control (ECB) prohibition is not necessary.

1. **REMOVE FRONT WHEEL**
2. **BRAKE CONTROL (ECB) OFF (SEE PAGE 32-29)**


NOTICE:

Prohibit the brake control (ECB) certainly before bleeding the brake fluid.

3. **DRAIN BRAKE FLUID**

NOTICE:

Wash brake fluid off immediately if it adheres to any painted surface.



4. **REMOVE FRONT DISC BRAKE CYLINDER SUB-ASSY**

- (a) Remove the union bolt and gasket, and separate the flexible hose No.1 from the front disc brake cylinder assy.
- (b) Hold the front disc brake cylinder slide pin using a wrench. Remove the 2 bolts and separate the front disc brake cylinder.

5. **REMOVE DISC BRAKE PAD KIT FRONT (PAD ONLY)**

- (a) Remove the 2 front disc brake pads from the front disc brake cylinder mounting.

6. **REMOVE ANTI SQUEAL SHIM KIT FRONT**


- (a) Remove the 2 anti squeal shims No.1 and 2 anti squeal shims No.2 from the front disc brake pads.

7. **REMOVE FRONT DISC BRAKE PAD SUPPORT PLATE NO.1**

- (a) Remove the pad support plate No.1 from the front disc brake cylinder mounting.

8. **REMOVE FRONT DISC BRAKE PAD SUPPORT PLATE NO.2**

- (a) Remove the pad support plate No.2 from the front disc brake cylinder mounting.




9. **REMOVE FRONT DISC BRAKE CYLINDER SLIDE PIN**

- (a) Pull off the 2 front disc brake cylinder slide pins from the front disc brake cylinder mounting.


10. **REMOVE FRONT DISC BRAKE BUSH DUST BOOT**

- (a) Remove the 2 bush dust boots from the front disc brake cylinder mounting.




11. REMOVE FRONT DISC BRAKE CYLINDER MOUNTING LH

- (a) Remove the 2 bolts and front disc brake cylinder mounting.



12. REMOVE CYLINDER BOOT

- (a) Remove the set ring and cylinder boot from the front disc brake cylinder assy.



13. REMOVE FRONT DISC BRAKE PISTON

- (a) Place a wooden block wrapped in a cloth between the front disc brake piston and front disc brake cylinder to prevent them from being damaged.
- (b) Put air into the front disc brake cylinder gradually so that the piston does not protrude using compressed air.

CAUTION:

Be careful not to pinch fingers.

NOTICE:


Do not spatter fluid.

14. REMOVE PISTON SEAL

- (a) Remove the piston seal from the front disc brake cylinder using a screwdriver.

NOTICE:

Do not damage the inside of the cylinder or the seal groove.




15. REMOVE FRONT DISC BRAKE BLEEDER PLUG CAP

16. REMOVE FRONT DISC BRAKE BLEEDER PLUG

17. INSPECT BRAKE CYLINDER AND PISTON

- (a) Check that the side of the front disc brake piston and the inside of the cylinder are not damaged. If necessary, replace the front disc brake cylinder sub-assy and front disc brake piston.

**18. INSPECT PAD LINING THICKNESS**

- (a) Using a ruler, measure the pad lining thickness.

Standard thickness: 11.0 mm (0.433 in.)

Minimum thickness: 1.0 mm (0.039 in.)

HINT:

If the disc brake pad thickness is at the minimum or less, replace the disc brake pad.


19. INSPECT FRONT DISC BRAKE PAD SUPPORT PLATE NO.1

- (a) Clean the area where the front disc brake support plate No.1 contacts the brake pad using brake cleaner. Check that there are no deformations, cracks or rust.
- (b) Check that there is no looseness or deformation with the front disc brake cylinder mounting installed.
- (c) Make sure that the support has sufficient rebound when installing the pad. Check that the pad does not easily drop after installation.

20. INSPECT FRONT DISC BRAKE PAD SUPPORT PLATE NO.2

HINT:

Check the pad support plate No.1 and No.2 using the same steps.

**21. INSPECT DISC THICKNESS**


- (a) Using a micrometer, measure the disc thickness.

Standard thickness: 22.0 mm (0.866 in.)

Minimum thickness: 20.0 mm (0.787 in.)

HINT:

If the disc plate thickness is at the minimum or less, replace the disc plate.

**22. REMOVE FRONT DISC**

HINT:


Put matchmarks on the disc and axle hub.

23. INSTALL FRONT DISC

- (a) Aligning the matchmarks, install the front disc.

NOTICE:

When installing a new disc, select the position where the disc has the minimum runout.

**24. INSPECT DISC RUNOUT**


- (a) Check the looseness of the front wheel bearing and runout in the axle hub before inspecting the disc runout (see page 30-2).
- (b) Hold the front disc with the hub nuts.
Torque: 103 N·m (1,050 kgf·cm, 76 ft·lbf)
- (c) Holding a dial indicator 10 mm away from the outer edge of the front disc, measure the disc runout.
Maximum disc runout: 0.05 mm (0.0020 in.)

NOTICE:

If the runout exceeds the maximum value, change the installation positions of the disc and axle so that the runout will become minimal. If the runout exceeds even when the installation positions are changed or if disc thickness does not exceed the limit, shave the disc. If disc thickness exceeds the limit, replace the disc.

25. TEMPORARILY TIGHTEN FRONT DISC BRAKE BLEEDER PLUG**26. INSTALL FRONT DISC BRAKE BLEEDER PLUG CAP****27. INSTALL PISTON SEAL**

- (a) Apply lithium soap base glycol grease around the new piston seal and install it into the brake cylinder groove securely.

**28. INSTALL FRONT DISC BRAKE PISTON**

- (a) Check the side of the front disc brake piston for any scratch.

NOTICE:

Replace the front disc brake piston with a new one if there is any scratch on it.

- (b) Apply lithium soap base glycol grease to the inside of the new cylinder boot and install it to the front disc brake piston.


NOTICE:

Install the cylinder boot securely into the front disc brake piston groove.

- (c) Apply lithium soap base glycol grease around the front disc brake piston and install it to the front disc brake cylinder.

NOTICE:

- Do not install the piston forcibly into the front disc brake cylinder.
- Do not damage the piston tip during installation.
- Do not push the piston directly using hard or sharp tools.

**29. INSTALL CYLINDER BOOT**

- (a) Install the cylinder boot to the disc brake cylinder groove.

NOTICE:

Install the cylinder boot securely into the disc brake cylinder and piston groove.

- (b) Install the new front disc brake piston set ring to the front disc brake cylinder using a screwdriver.


NOTICE:

Do not damage the cylinder boot.


30. INSTALL FRONT DISC BRAKE CYLINDER MOUNTING LH

- (a) Install the front disc brake cylinder mounting with the 2 bolts.

Torque: 109 N·m (1,114 kgf·cm, 81 ft·lbf)

**31. INSTALL FRONT DISC BRAKE BUSH DUST BOOT**

- (a) Apply lithium soap base glycol grease to seal surface of 2 new bush dust boots.
- (b) Install the 2 bush dust boots to the front disc brake cylinder mounting.

**32. INSTALL FRONT DISC BRAKE CYLINDER SLIDE PIN**

- (a) Apply lithium soap base glycol grease to the sliding and fitting portion of the front disc brake cylinder slide pin.
- (b) Push the front disc brake cylinder slide pin into the disc brake bush dust boot and install it.

33. INSTALL FRONT DISC BRAKE PAD SUPPORT PLATE NO.1

- (a) Install the pad support plate No.1 to the front disc brake cylinder mounting.

34. INSTALL FRONT DISC BRAKE PAD SUPPORT PLATE NO.2


- (a) Install the pad support plate No.2 to the front disc brake cylinder mounting.

35. INSTALL ANTI SQUEAL SHIM KIT FRONT

- (a) Apply disc brake grease to the area where the anti squeal shim No.1 makes contact.
- (b) Install the 2 anti squeal shims No.1 and 2 anti squeal shims No.2 to the front disc brake pads.

36. INSTALL DISC BRAKE PAD KIT FRONT (PAD ONLY)

- (a) Install the 2 front disc brake pads to the front disc brake cylinder mounting.

**37. INSTALL FRONT DISC BRAKE CYLINDER SUB-ASSY**


- (a) Install the front disc brake cylinder assy with the 2 bolts.
Torque: 34 N·m (347 kgf·cm, 25 ft·lbf)
- (b) Placing the new gasket in between, connect the flexible hose No.1 to the front disc brake cylinder assy with the union bolt.

Torque: 33 N·m (337 kgf·cm, 24 ft·lbf)

- 38. FILL RESERVOIR WITH BRAKE FLUID (SEE PAGE 32-4)**
- 39. BLEED FRONT AND REAR BRAKE SYSTEMS (SEE PAGE 32-4)**
- 40. CHECK BRAKE FLUID LEAKAGE**
- 41. CHECK FLUID LEVEL IN RESERVOIR**
- 42. INSTALL FRONT WHEEL**
Torque: 103 N·m (1,050 kgf·cm, 76 ft·lbf)
- 43. CHECK AND CLEAR DTC (SEE PAGE 05-738)**

REAR DISC BRAKE COMPONENTS

3209D-02



F42256

OVERHAUL


HINT:

- Use the same procedures for the RH side and LH side.
- If work that does not involve brake fluid bleeding, such as disc brake pad replacement, is started 2 minutes or more after the power switch is turned off, brake control (ECB) prohibition is not necessary.

1. **REMOVE REAR WHEEL**
2. **BRAKE CONTROL (ECB) OFF (SEE PAGE 32-29)**
3. **DRAIN BRAKE FLUID**


NOTICE:

Wash brake fluid off immediately if it adheres to any painted surface.



4. REMOVE DISC BRAKE PAD KIT REAR (PAD ONLY)

- (a) Remove the clip, the anti-rattle spring No.1 and No.2
- (b) Remove the 2 pad guide pins and the 2 disc brake pads with anti-squeal shim.
- (c) Remove the 2 anti-squeal shims from each pad.



5. REMOVE DISC BRAKE CYLINDER ASSY REAR LH

- (a) Remove the union bolt and the gasket from the disc brake cylinder assy rear LH, then disconnect the flexible hose.

HINT:

Both 1-piece and 2-piece type gaskets exist.


- (b) Remove the 2 bolts and disc brake cylinder assy rear LH.

6. REMOVE REAR DISC BRAKE CYLINDER MOUNTING COLLAR

- (a) Remove the 2 collars from the disc brake cylinder assy rear LH.


7. REMOVE REAR DISC BRAKE BUSH DUST BOOT

- (a) Remove the 3 bush dust boots.



8. REMOVE CYLINDER BOOT

- (a) Using a screwdriver, remove the set ring and the cylinder boot.



9. REMOVE REAR DISC BRAKE PISTON

- Place a piece of shop rag or similar, between the piston and the disc brake cylinder.
- Use compressed air to remove the piston from the disc brake cylinder.

CAUTION:

Do not place your fingers in front of the piston when using compressed air.

NOTICE:


Do not spatter the brake fluid.

10. REMOVE PISTON SEAL

- Using a screwdriver, remove the piston seal from the disc brake cylinder.

NOTICE:

Do not damage the inner cylinder and cylinder groove.




11. REMOVE REAR DISC BRAKE BLEEDER PLUG

- Remove the bleeder plug cap and the bleeder plug from the disc brake cylinder.

12. INSPECT BRAKE CYLINDER AND PISTON

- Check the cylinder bore and piston for rust or scoring.

If necessary, replace the brake cylinder and piston.



13. INSPECT PAD LINING THICKNESS


- Using a ruler, measure the pad lining thickness.

Standard thickness: 10.0 mm (0.394 in.)

Minimum thickness: 1.0 mm (0.039 in.)

HINT:

If the pad lining thickness is equal to the minimum thickness or less, replace the brake pad.



14. INSPECT DISC THICKNESS

- Using a micrometer, measure the disc thickness.


Standard thickness: 9.0 mm (0.354 in.)

Minimum thickness: 7.5 mm (0.295 in.)

HINT:

If the disc thickness is less than the minimum, replace the disc.

15. REMOVE PARKING BRAKE SHOE ADJUSTING HOLE PLUG

**16. REMOVE REAR DISC**


- (a) Put matchmarks on the disc and the axle hub.
- (b) Remove the disc.

17. INSTALL REAR DISC

- (a) Aligning the matchmarks, install the disc.

HINT:

Select the installation position where the front disc has the minimum runout.

18. INSTALL PARKING BRAKE SHOE ADJUSTING HOLE PLUG**19. INSPECT DISC RUNOUT**

- (a) Check the looseness of the front wheel bearing and runout in the axle hub before inspecting the disc runout (see page 30-2).

- (b) Hold the front disc with the hub nuts.

Torque: 103 N·m (1,050 kgf·cm, 76 ft·lbf)

- (c) Holding a dial indicator 10 mm away from the outer edge of the front disc, measure the disc runout.

Maximum disc runout: 0.15 mm (0.0059 in.)

NOTICE:

If the runout exceeds the maximum value, change the installation positions of the disc and axle so that the runout will become minimal. If the runout exceeds the maximum even when the installation positions are changed or if disc thickness does not exceed the limit, shave the disc. If disc thickness exceeds the limit, replace the disc.

20. TEMPORARILY TIGHTEN REAR DISC BRAKE BLEEDER PLUG

- (a) Temporarily install the rear disc brake bleeder plug to the disc brake cylinder assy rear LH.
- (b) Temporarily install the bleeder plug cap to the bleeder plug.

21. INSTALL PISTON SEAL


- (a) Apply lithium soap base glycol grease to a new piston seal.
- (b) Install the piston seal to the disc brake cylinder assy rear LH.

22. INSTALL REAR DISC BRAKE PISTON

- (a) Apply lithium soap base glycol grease to the rear disc brake piston.
- (b) Install the piston to the disc brake cylinder assy rear LH.

NOTICE:

Do not install the piston forcibly in the disc brake cylinder.

**23. INSTALL CYLINDER BOOT**

- Apply lithium soap base glycol grease to a new cylinder boot.
- Install the cylinder boot to the disc brake cylinder.

HINT:

Install the boot securely onto the grooves of the cylinder and the piston.


- Using a screwdriver, install the set ring.

NOTICE:


Do not damage the cylinder boot.

24. INSTALL REAR DISC BRAKE BUSH DUST BOOT

- Apply lithium soap base glycol grease to the seal surface of 3 new bush dust boots.
- Install the 3 bush dust boots to the disc brake cylinder.

**25. INSTALL REAR DISC BRAKE CYLINDER MOUNTING COLLAR**

- Install the 2 collars to the disc brake cylinder assy rear LH.

**26. INSTALL DISC BRAKE CYLINDER ASSY REAR LH**

- Install the disc brake cylinder assy rear LH with 2 bolts.
Torque: 47 N·m (475 kgf·cm, 34 ft·lbf)
- Connect the flexible hose with the union bolt and a new gasket.

Torque: 30 N·m (310 kgf·cm, 22 ft·lbf)

HINT:

- Both 1-piece and 2-piece type gaskets exist.
- Install the flexible hose lock securely in the lock hole in the disc brake cylinder.

27. INSTALL DISC BRAKE PAD KIT REAR (PAD ONLY)**NOTICE:**


When replacing worn pads, the anti-squeal shims must be replaced together with the pads.

- (a) Apply disc brake grease to the inside of the anti-squeal shims and install them to each of the 2 brake pads.
- (b) Install the inner pad with the pad wear indicator plate facing upward, and install the outer pad.

NOTICE:

There should be no oil or grease on the friction surface of the pads and the disc.

- (c) Install the 2 pad guide pins.



- (d) Install the anti-rattle springs No.1, No.2 and the clip.

- 28. FILL RESERVOIR WITH BRAKE FLUID ([SEE PAGE 32-4](#))
- 29. BLEED FRONT AND REAR BRAKE SYSTEMS ([SEE PAGE 32-4](#))
- 30. CHECK BRAKE FLUID LEAKAGE
- 31. CHECK FLUID LEVEL IN RESERVOIR
- 32. INSTALL REAR WHEEL
Torque: 103 N·m (1,050 kgf·cm, 76 ft·lbf)
- 33. CHECK AND CLEAR DTC ([SEE PAGE 05-738](#))

BRAKE ACTUATOR ASSY

3214P-01

ON-VEHICLE INSPECTION

1. INSPECT BRAKE ACTUATOR OPERATION

(a) Pre-check preparation

- (1) Move the shift lever to the P position. Apply the parking brake and connect the intelligent tester II to the DLC3.
- (2) Turn the power switch on (IG).
- (3) Turn on the intelligent tester II. Select "MAS CYL PRS 1", "MAS CYL PRS2", "FR PRESS SENS", "FL PRESS SENS", "RR PRESS SENS" and "RL PRESS SENS".

(b) Check FR system solenoid (SLA**, SLR**, SMC1, SMC2)

- (1) Select "SLAFR CUR". → Set the current to 1.2 A → Enter and check the output voltage.

NOTICE:

Do not depress the brake pedal.

HINT:

- It takes approximately 35 seconds to complete the check.
- If incorrect, troubleshoot the brake system ([see page 05-729](#)).

Standard value:

Sensor	10 to 20 sec. after check start (V)	35 sec. or more after check start (V)
MAS CYL PRS 1	0.3 – 0.7	0.3 – 0.7
MAS CYL PRS 2	0.3 – 0.7	0.3 – 0.7
FR PRESS SENS	2.5 – 4.5	0.3 – 0.7
FL PRESS SENS	0.3 – 0.7	0.3 – 0.7
RR PRESS SENS	0.3 – 0.7	0.3 – 0.7
RL PRESS SENS	0.3 – 0.7	0.3 – 0.7

(c) Check FL system solenoid (SLA**, SLR**, SMC1, SMC2)

- (1) Select "SLAFL CUR". → Set the current to 1.2 A. → Enter and check the output voltage.

NOTICE:

Do not depress the brake pedal.

HINT:

- It takes approximately 35 seconds to complete the check.
- If incorrect, troubleshoot the brake system ([see page 05-729](#)).

Standard value:

Sensor	10 to 20 sec. after check start (V)	35 sec. or more after check start (V)
MAS CYL PRS 1	0.3 – 0.7	0.3 – 0.7
MAS CYL PRS 2	0.3 – 0.7	0.3 – 0.7
FR PRESS SENS	0.3 – 0.7	0.3 – 0.7
FL PRESS SENS	2.5 – 4.5	0.3 – 0.7
RR PRESS SENS	0.3 – 0.7	0.3 – 0.7
RL PRESS SENS	0.3 – 0.7	0.3 – 0.7

(d) Check RR system solenoid (SLA**, SLR**, SMC1, SMC2)

- (1) Select "SLARR CUR". → Set the current to 1.2 A. → Enter and check the output voltage.

NOTICE:

Do not depress the brake pedal.

HINT:

- It takes approximately 35 seconds to complete the check.
- If incorrect, troubleshoot the brake system ([see page 05-729](#)).

Standard value:

Sensor	10 to 20 sec. after check start (V)	35 sec. or more after check start (V)
MAS CYL PRS 1	0.3 - 0.7	0.3 - 0.7
MAS CYL PRS 2	0.3 - 0.7	0.3 - 0.7
FR PRESS SENS	0.3 - 0.7	0.3 - 0.7
FL PRESS SENS	0.3 - 0.7	0.3 - 0.7
RR PRESS SENS	2.5 - 4.5	0.3 - 0.7
RL PRESS SENS	0.3 - 0.7	0.3 - 0.7

(e) Check RL system solenoid (SLA**, SLR**, SMC1, SMC2)

- (1) Select "SLARL CUR". → Set the current to 1.2 A. → Enter and check the output voltage.

NOTICE:

Do not depress the brake pedal.

HINT:

- It takes approximately 35 seconds to complete the check.
- If incorrect, troubleshoot the brake system ([see page 05-729](#)).

Standard value:

Sensor	10 to 20 sec. after check start (V)	35 sec. or more after check start (V)
MAS CYL PRS 1	0.3 - 0.7	0.3 - 0.7
MAS CYL PRS 2	0.3 - 0.7	0.3 - 0.7
FR PRESS SENS	0.3 - 0.7	0.3 - 0.7
FL PRESS SENS	0.3 - 0.7	0.3 - 0.7
RR PRESS SENS	0.3 - 0.7	0.3 - 0.7
RL PRESS SENS	2.5 - 4.5	0.3 - 0.7

(f) Check SMC1, SMC2

- (1) Select and enter "ECB INVALID" to prohibit the brake control (ECB) on the intelligent tester II menu screen.
- (2) Check that the ECB warning light comes on.
- (3) Check the output voltage by depressing the pedal.

Standard:

Difference in output voltage between "MAS CYL PRS 1" and "FR PRESS SENS" is less than 0.4 V.

Difference in the output voltage between "MAS CYL PRS 2" and "FL PRESS SENS" is less than 0.4 V.


- (4) Enter the return key on the intelligent tester II and cancel brake control prohibition (ECB INVALID).

2. INSPECT PRESSURE SENSOR OPERATION

- (a) Check battery voltage

Standard Value: 10 to 14 V (during engine stop)

- (b) Connect the hydro booster pressure gauge and pedal effort gauge.



- (1) Install LSPV gauge (SST) and brake pedal effort gauge.
SST 09709-29018
 - (2) Bleed the air out of the front brake and rear brake systems.
 - (3) Move the shift lever to the P position. Connect the intelligent tester II to the DLC3 with the parking brake applied.
 - (4) Turn the power switch on (IG).
 - (5) Clear the DTC ([see page 05-738](#)).
- (c) Check wheel cylinder pressure sensor and master pressure sensor.
- (1) Turn on the intelligent tester II. Select and enter "MAS CYL PRS 1", "MAS CYL PRS 2", "FR PRESS SENS", "FL PRESS SENS", "RR PRESS SENS" and "RL PRESS SENS" into the data monitor.
 - (2) Check the brake effort, pressure gauge reading, and output pressure voltage.

If incorrect, troubleshoot the brake system ([see page 05-729](#)).

Standard value:

Brake effort N (kgf, lbf)	MAS CYL PRS 1 (V)	MAS CYL PRS 2 (V)
200 (20.4, 45)	0.9 – 1.2	0.9 – 1.2
500 (51, 112)	1.7 – 2.2	1.7 – 2.2

Brake effort N (kgf, lbf)	Front right wheel hydraulic pressure MPa (kgf/cm ² , psi)	FR PRESS SENS (V)
50 (5.1, 11)	3 (30.6, 435)	1.0 – 1.2
100 (10.2, 22)	5.9 (59.8, 851)	1.6 – 1.8
150 (15.3, 34)	7.9 (80.2, 1141)	2.0 – 2.2
200 (20.4, 45)	9.9 (101.0, 1437)	2.35 – 2.6

Brake effort N (kgf, lbf)	Front left wheel hydraulic pressure MPa (kgf/cm ² , psi)	FL PRESS SENS (V)
50 (5.1, 11)	3 (30.6, 435)	1.0 – 1.2
100 (10.2, 22)	5.9 (59.8, 851)	1.6 – 1.8
150 (15.3, 34)	7.9 (80.2, 1141)	2.0 – 2.2
200 (20.4, 45)	9.9 (101.0, 1437)	2.35 – 2.6

Brake effort N (kgf, lbf)	Rear right wheel hydraulic pressure MPa (kgf/cm ² , psi)	RR PRESS SENS (V)
50 (5.1, 11)	3.8 (38.7, 550)	1.15 – 1.35
100 (10.2, 22)	4 (40.8, 580)	1.25 – 1.5
150 (15.3, 34)	4 (40.8, 580)	1.25 – 1.5
200 (20.4, 45)	4 (40.8, 580)	1.25 – 1.5

Brake effort N (kgf, lbf)	Rear left wheel hydraulic pressure MPa (kgf/cm ² , psi)	RL PRESS SENS (V)
50 (5.1, 11)	3.8 (38.7, 550)	1.15 – 1.35
100 (10.2, 22)	4 (40.8, 580)	1.25 – 1.5
150 (15.3, 34)	4 (40.8, 580)	1.25 – 1.5
200 (20.4, 45)	4 (40.8, 580)	1.25 – 1.5

- (d) Check accumulator (ACC) pressure sensor
 - (1) Move the shift lever to the P position. Apply the parking brake and connect the intelligent tester II.
 - (2) Turn the power switch on (IG).
 - (3) Turn on the intelligent tester II. Select and enter the accumulator (ACC) pressure sensor 1 ("ACC PRESS SENS") into the data monitor.
 - (4) Temporarily operate the pump motor by depressing the brake pedal 4 to 5 times.
 - (5) After confirming that the pump motor stops, check the pressure output voltage.

If incorrect, troubleshoot the brake system ([see page 05-729](#)).

Standard Value: 2.6 to 3.8 V

REPLACEMENT

1. REMOVE FR WIPER ARM LH (SEE PAGE 66-16)
2. REMOVE FR WIPER ARM RH (SEE PAGE 66-16)
3. REMOVE HOOD TO COWL TOP SEAL (SEE PAGE 66-16)
4. REMOVE COWL TOP VENTILATOR LOUVER LH (SEE PAGE 66-16)
5. REMOVE COWL TOP VENTILATOR LOUVER RH (SEE PAGE 66-16)
6. REMOVE WINDSHIELD WIPER MOTOR & LINK ASSY (SEE PAGE 66-16)
7. PERFORM ACCUMULATOR PRESSURE DOWN

NOTICE:

Carry out accumulator zero down and lower the internal pressure before removing the brake actuator.


- (a) Move the shift lever to the P position. Apply the parking brake and connect the intelligent tester II to the DLC3.
- (b) Turn on the power switch.
- (c) Turn on the intelligent tester II. Select "ZERO DOWN".

NOTICE:

Keep the fluid inside the reservoir above the "LOW" level by replenishing.

HINT:

- Accumulator pressure is released and accumulated repeatedly, which circulates the fluid inside the accumulator when performing this procedure.
- The pump motor rotates and the accumulator is pressurized every time turning the power switch from off to on (IG).
- (d) Turn the power switch off.



8. BRAKE CONTROL (ECB) OFF

NOTICE:

- Prohibit the brake control (ECB) certainly before air bleeding.
- Be sure to remove the motor relays No.1 and No.2 first, then the brake actuator.
- (a) With the power switch off to prohibit brake control, remove the motor relays No.1 and No.2.


NOTICE:

If the pump motor operates while there is air remaining inside the brake actuator hose, the air will enter the actuator, resulting in difficulty in air bleeding.

9. REMOVE COWL TOP PANEL SUB-ASSY OUTER FRONT (SEE PAGE 32-29)
10. REMOVE W/CONVERTER INVERTER ASSY (SEE PAGE 21-25)
11. DRAIN BRAKE FLUID


NOTICE:

Wash brake fluid off immediately if it adheres to any painted surface.




12. SEPARATE WATER W/MOTOR & BRACKET PUMP ASSY

- (a) Remove the 2 bolts and connector, separate the heater water pump assy from the gusset assy.




- (b) Remove the 3 clamps and bolt, and remove the heater hose bracket from the gusset assy.




13. REMOVE BRAKE ACTUATOR WITH BRACKET


- (a) Release the lock and separate the connector from the brake actuator assy.
 (b) Remove the clip and separate the brake actuator hose No.2 from the brake actuator assy.




- (c) Using SST, separate the front brake tube No.5 from the brake actuator assy and front brake flexible hose.
 SST 09023-00100
 (d) Remove the bolt and front brake tube No.5 from the bracket of the brake actuator assy.




- (e) Using SST, separate the front brake tube No.1. (LHD)
SST 09023-00100
- (f) Remove the bolt and the front brake tube No.1 from the bracket of the brake actuator assy (LHD).




- (g) Remove the 3 nuts and separate the brake actuator tube assy.




- (h) Remove the brake tube clamp bracket bolt. (Except Australia (RHD))
- (i) Using SST, remove the 5 brake tubes. (Except Australia (RHD))
SST 09023-00100




- (j) Remove the 2 brake tube clamp bracket bolt. (Australia)
- (k) Using SST, remove the 5 brake tubes. (Australia)
SST 09023-00100



- (l) Using SST, remove the bolt and the 4 brake tubes from the brake stroke simulator and brake actuator assy. (LHD)
SST 09023-00100





- (m) Remove the bolt, 2 nuts and the brake actuator assy with gusset assy.




14. REMOVE BRAKE ACTUATOR ASSY


- (a) Remove the 2 bolts and brake actuator damper.




- (b) Remove the bolt, nut and the bracket from the brake actuator assy.



- (c) Remove the 2 nuts, bolt and the brake actuator assy from the gusset assy.



- (d) Remove the bolt and brake actuator bracket No.2 from the brake actuator assy.



15. DISPOSE OF BRAKE ACTUATOR ASSY


- (a) Using a drill, slowly make a hole at the radius indicated at the middle of A in the illustration and bleed the charged gas.

NOTICE:

Be sure to wear protective glasses as fragments may fly out due to pressure.

HINT:


- The hole may be drilled up to approximately 5 mm to 10 mm away from the point indicated by A without problem.
- The gas is nitrogen, which is colorless, odorless, and harmless.



16. INSTALL BRAKE ACTUATOR ASSY

- (a) Aligning the positioning pin, install the brake actuator bracket No.2 to the brake actuator assy with the bolt.

Torque: 18 N·m (184 kgf·cm, 13 ft·lbf)




- (b) Aligning the positioning pin, install the brake actuator assy to the gusset assy with the 2 nuts and bolt.

Torque: 7.5 N·m (76 kgf·cm, 66 in·lbf)

NOTICE:

Tighten the nuts and bolt in the order shown in the illustration.




- (c) Install the bracket to the brake actuator assy with the bolt and nut.

Torque: 18 N·m (184 kgf·cm, 13 ft·lbf)

NOTICE:

Tighten the nuts and bolt in the order shown in the illustration.





- (d) Install the brake actuator damper to the brake actuator assy with the 2 bolts.

Torque: 18 N·m (184 kgf·cm, 13 ft·lbf)

NOTICE:


Tighten the bolts in the order shown in the illustration.



17. INSTALL BRAKE ACTUATOR WITH BRACKET

- (a) Install the brake actuator assy and the gusset assy with the bolt and 2 nuts.

Torque: 20 N·m (200 kgf·cm, 15 ft·lbf)




- (b) Using SST, install the 5 brake tubes. (Except Australia (RHD))

SST 09023-00100

Torque: 15 N·m (155 kgf·cm, 11 ft·lbf)

- (c) Set the brake tube with the clamp bracket bolt. (Except Australia (RHD))

Torque: 5.0 N·m (51 kgf·cm, 44 in·lbf)




- (d) Using SST, install the 5 brake tubes. (Australia)
SST 09023-00100

Torque: 15 N·m (155 kgf·cm, 11 ft·lbf)


- (e) Set the brake tube with the 2 clamp bracket bolts. (Australia)

Torque: 5.0 N·m (51 kgf·cm, 44 in·lbf)




- (f) Using SST, install the 4 brake tube to the brake stroke simulator and brake actuator assy. (LHD)
SST 09023-00100

Torque: 15 N·m (155 kgf·cm, 11 ft·lbf)



- (g) Install the brake actuator tube assy with the 2 nuts.

Torque: 8.5 N·m (87 kgf·cm, 75 in·lbf)




- (h) Set the brake actuator tube assy with the nut.

Torque: 8.5 N·m (87 kgf·cm, 75 in·lbf)

NOTICE:

Press the brake actuator tube assy so that there is no clearance between the bracket and the actuator tube assy as shown in the illustration, and tighten the nut.




- (i) Using SST, install the front brake tube No.1 to the brake actuator and 2 way. (LHD)
SST 09023-00100


Torque: 15 N·m (155 kgf·cm, 11 ft·lbf)

- (j) Install the bolt and the front brake tube No.1 to the bracket of the brake actuator assy.


Torque: 5.0 N·m (51 kgf·cm, 44 in·lbf)



- (k) Using SST, install the front brake tube No.5.
SST 09023-00100
Torque: 15 N·m (155 kgf·cm, 11 ft·lbf)
- (l) Install the bracket of front brake tube No.5 with the bolt.
Torque: 5.0 N·m (51 kgf·cm, 44 in·lbf)




- (m) Install the connector to the brake actuator assy, and fix it with the lock.
- (n) Install the brake actuator hose No.2 to the brake actuator assy with the clip.



18. CONNECT WATER W/MOTOR & BRACKET PUMP ASSY

- (a) Install the heater hose bracket to the gusset assy with the 3 clamps and bolt.



- (b) Install the heater water pump assy with 2 bolts.
NOTICE:
Tighten bolt A and then bolt B.
- (c) Connect the connector to the heater water pump assy.

19. INSTALL W/CONVERTER INVERTER ASSY (SEE PAGE 21-25)**HINT:**


Refer to the procedures from the installation of the inverter assy with converter up until the installation of the engine under cover LH.

20. INSTALL COWL TOP PANEL SUB-ASSY OUTER FRONT (SEE PAGE 32-29)**21. INSTALL WINDSHIELD WIPER MOTOR & LINK ASSY (SEE PAGE 66-16)****22. INSTALL FR WIPER ARM LH (SEE PAGE 66-16)****23. INSTALL FR WIPER ARM RH (SEE PAGE 66-16)****24. FILL RESERVOIR WITH BRAKE FLUID (SEE PAGE 32-4)****25. BLEED BRAKE ACTUATOR (SEE PAGE 32-4)****26. CHECK BRAKE FLUID LEAKAGE****27. CHECK FLUID LEVEL IN RESERVOIR****28. CHECK AND CLEAR DTC (SEE PAGE 05-738)****29. SYSTEM INITIALIZATION (SEE PAGE 05-721)****30. ACTIVE TEST (SEE PAGE 05-744)**

FRONT SPEED SENSOR REPLACEMENT


32167-01

1. REMOVE FRONT WHEEL
2. REMOVE FRONT FENDER LINER



3. REMOVE FRONT SPEED SENSOR


- (a) Disconnect the connector of the speed sensor front.



- (b) Remove the bolt A and the bolt B. Remove the speed sensor front clamps from the body and front shock absorber.

HINT:


The bolt A is tightened together with the brake flexible hose clamp.



- (c) Remove the clip from the front shock absorber.
- (d) Remove the bolt and speed sensor front.

NOTICE:

Do not attach any foreign matter to the tip or connecting portion of the speed sensor front.



4. INSTALL FRONT SPEED SENSOR

NOTICE:

Do not twist the speed sensor front wire harnesses during installation.

- (a) Install the speed sensor front with the bolt.

Torque: 8.0 N·m (82 kgf·cm, 71 in·lbf)


NOTICE:

Check that there is no foreign matter attached to the tip and connecting portion of the speed sensor front.

HINT:

Clean the connecting portion of the speed sensor front.

- (b) Install the clip to the front shock absorber.



- (c) Install the speed sensor front clamps to the body and front shock absorber with a bolt A and a bolt B.


Torque:

8.0 N·m (82 kgf·cm, 71 in·lbf) (bolt A)

19 N·m (192 kgf·cm, 14 ft·lbf) (bolt B)

NOTICE:

Tighten the bolt B together with the brake flexible hose clamp and speed sensor front clamp. The brake flexible hose clamp should be placed above.



- (d) Connect the connector of speed sensor front.

5. INSTALL FRONT FENDER LINER

6. INSTALL FRONT WHEEL


Torque: 103 N·m (1,050 kgf·cm, 76 ft·lbf)

7. CHECK ABS SPEED SENSOR SIGNAL ([SEE PAGE 05-724](#))

SKID CONTROL SENSOR REPLACEMENT

32145-01

1. REMOVE REAR WHEEL
2. SEPARATE REAR DISC BRAKE CALIPER ASSY LH (SEE PAGE 30-27)
3. REMOVE REAR DISC
4. SEPARATE SKID CONTROL SENSOR WIRE
5. REMOVE REAR AXLE HUB & BEARING ASSY (SEE PAGE 30-27)



6. REMOVE SKID CONTROL SENSOR

- (a) Install the 4 hub nuts to the 4 rear axle hub bolts. Placing an aluminum plate below the rear axle hub and bearing assy, place them into the vice.


NOTICE:

Replace the rear axle hub and bearing assy if it is dropped or receives a strong shock.

- (b) Remove the 2 pins from the SST (09520-00031) and separate the attachment (09521-00010) using a pin punch (3 mm) or hammer.
- (c) Remove the speed sensor from the rear axle hub and bearing assy using the SST and 2 bolts (90101-12007).
SST 09520-00031 (09520-00040), 09521-00020, 09950-00020

NOTICE:

- Pull the speed sensor off straight, being careful not to make contact with the skid control sensor rotor.
- If the speed sensor rotor is damaged or deformed, replace the rear axle hub and bearing assy.
- Do not scratch the area where the speed sensor contacts the rear axle hub and bearing assy.
- Do not attach foreign matter to the speed sensor rotor.



7. INSTALL SKID CONTROL SENSOR

- (a) Wipe off sealant attached to the speed sensor's fitting surface with white gasoline.


NOTICE:

Prevent foreign matter from attaching to the sensor rotor.

- (b) Install the speed sensor to the rear axle hub and bearing assy. The speed sensor connector should be placed in the lowest position.

HINT:

The narrow side of the rear axle hub and bearing assy should be placed below.



- (c) Press the new speed sensor so that it becomes flat with the rear axle hub and bearing using the SST and a press.
SST 09214-76011

NOTICE:



- Do not use a hammer on the speed sensor.
- Check that there is no foreign matter such as iron chips on the speed sensor's detecting portion.
- Slowly press the speed sensor in straight.

8. INSTALL REAR AXLE HUB & BEARING ASSY ([SEE PAGE 30-27](#))
9. INSTALL SKID CONTROL SENSOR WIRE
10. INSTALL REAR DISC
11. INSTALL REAR DISC BRAKE CALIPER ASSY LH ([SEE PAGE 30-27](#))
12. INSTALL REAR WHEEL
Torque: 103 N·m (1,050 kgf·cm, 76 ft·lbf)
13. INSPECT REAR WHEEL ALIGNMENT ([SEE PAGE 27-3](#))
14. CHECK ABS SPEED SENSOR SIGNAL ([SEE PAGE 05-724](#))



BRAKE PEDAL STROKE SENSOR ASSY REPLACEMENT

3214Y-01

1. REMOVE INSTRUMENT PANEL REGISTER ASSY NO.1 (SEE PAGE 71-7)
2. REMOVE INSTRUMENT PANEL FINISH PANEL SUB-ASSY LOWER (SEE PAGE 71-7)



3. REMOVE BRAKE PEDAL STROKE SENSOR ASSY
 - (a) Disconnect the connector of the brake pedal stroke sensor.
 - (b) Remove the 2 bolts and brake pedal stroke sensor.



4. INSTALL BRAKE PEDAL STROKE SENSOR ASSY
 - (a) New brake pedal stroke sensor.
 - (1) Install the brake pedal stroke sensor to the brake pedal support with the 2 bolts.

Torque: 9.3 N·m (95 kgf·cm, 82 in·lbf)



NOTICE:

- Engage the brake pedal stroke sensor lever with the brake pedal groove.
 - Check that there is no foreign matter attached to the brake pedal stroke sensor's contacting surface.
- (2) Strongly depress the brake pedal and break the brake pedal stroke sensor lever set pin.
 - (3) Remove the broken lever set pin.
 - (4) Connect the brake pedal stroke sensor connector.

- (b) Reuse of brake pedal stroke sensor.
- (1) Temporarily install the brake pedal stroke sensor to the brake pedal support with 2 bolts.

NOTICE:

- Engage the brake pedal stroke sensor lever with the brake pedal groove.
 - Check that there is no foreign matter attached to the brake pedal stroke sensor's contacting surface.
- (2) Connect the intelligent tester II to the DLC3.
- (3) Connect the connector of the brake pedal stroke sensor.



- (4) Turn the power switch on (IG). Reading the stroke sensor 1 value shown on the data monitor, turn the stroke sensor slowly to the right and left to adjust it to the standard value.

Standard value: 0.8 to 1.2 V

- (5) Tighten the bolts.

Torque: 9.3 N·m (95 kgf·cm, 82 in·lbf)

NOTICE:

Do not depress the brake pedal after turning the power switch on (IG).

- (c) Carry out system initialization ([see page 05-721](#)).

5. INSTALL INSTRUMENT PANEL FINISH PANEL SUB-ASSY LOWER
6. INSTALL INSTRUMENT PANEL REGISTER ASSY NO.1

SKID CONTROL ECU ASSY (RHD)


REPLACEMENT

3214T-01

1. DISCONNECT BATTERY NEGATIVE TERMINAL (SEE PAGE 01-5)
2. REMOVE INSTRUMENT PANEL SUB-ASSY W/PASSENGER AIRBAG ASSY (SEE PAGE 71-7)


HINT:

Refer to the procedures from the removal of the instrument panel register assy No.1 up until the removal of the instrument panel sub-assy w/ passenger airbag assy.



3. REMOVE SKID CONTROL ECU ASSY

- (a) Remove the 3 clamps.
- (b) Disconnect the connector from the skid control computer assy.
- (c) Remove the nut, the bolt and the skid control computer assy.



4. INSTALL SKID CONTROL ECU ASSY

- (a) Install the skid control computer assy with the nut and bolt.
Torque: 5.0 N·m (51 kgf·cm, 44 in·lbf)
- (b) Connect the connector to the skid control computer assy.
- (c) Install the 3 clamps.

5. INSTALL INSTRUMENT PANEL SUB-ASSY W/PASSENGER AIRBAG ASSY
6. CONNECT BATTERY NEGATIVE TERMINAL
7. PERFORM INITIALIZATION (SEE PAGE 01-5)
8. SYSTEM INITIALIZATION (SEE PAGE 05-721)
9. PERFORM YAWRATE SENSOR ZERO POINT CALIBRATION (SEE PAGE 05-723)
10. CHECK AND CLEAR DTC (SEE PAGE 05-738)

SKID CONTROL ECU ASSY (LHD)

REPLACEMENT


3214U-01

1. DISCONNECT BATTERY NEGATIVE TERMINAL (SEE PAGE 01-5)
2. REMOVE INSTRUMENT PANEL SUB-ASSY W/PASSENGER AIRBAG ASSY (SEE PAGE 71-7)

HINT:


Refer to the procedures from the removal of the instrument panel register assy No.1 up until removal of the instrument panel sub-assy w/ passenger airbag assy.

3. REMOVE STEERING COLUMN ASSY (SEE PAGE 50-8)



4. REMOVE SKID CONTROL ECU ASSY

- (a) Disconnect the clamp of wire harness and the skid control buzzer from the skid control computer bracket.
- (b) Disconnect the connector from the skid control computer.
- (c) Remove the 3 nuts and the skid control computer assy.



5. INSTALL SKID CONTROL ECU ASSY

- (a) Install the skid control computer assy with the 3 nuts.
Torque: 5.0 N·m (51 kgf·cm, 44 in·lbf)
- (b) Connect the connector to the skid control computer assy.
- (c) Install the clamp of wire harness and the skid control buzzer to the skid control computer bracket.

6. INSTALL STEERING COLUMN ASSY (SEE PAGE 50-8)
7. INSTALL INSTRUMENT PANEL SUB-ASSY W/PASSENGER AIRBAG ASSY
8. CONNECT BATTERY NEGATIVE TERMINAL
9. PERFORM INITIALIZATION (SEE PAGE 01-5)
10. SYSTEM INITIALIZATION (SEE PAGE 05-721)
11. PERFORM YAWRATE SENSOR ZERO POINT CALIBRATION (SEE PAGE 05-723)
12. CHECK AND CLEAR DTC (SEE PAGE 05-738)


BRAKE CONTROL POWER SUPPLY ASSY REPLACEMENT

3214V-01


1. REMOVE REAR SEAT CUSHION ASSY (SEE PAGE 72-9)
2. REMOVE DECK TRIM SIDE PANEL ASSY RH (SEE PAGE 76-29)

HINT:

Refer to the procedures from the removal of the rear door scuff plate RH up until the removal of the deck trim side panel assy RH.



3. REMOVE BRAKE CONTROL POWER SUPPLY ASSY
 - (a) Disconnect the connector and remove the 3 bolts and the brake control power supply assy.




4. INSTALL BRAKE CONTROL POWER SUPPLY ASSY
 - (a) Install the brake control power supply assy with the 3 bolts.
Torque: 19 N·m (194 kgf·cm, 14 ft·lbf)
 - (b) Connect the connector to the brake control power supply assy.

5. INSTALL DECK TRIM SIDE PANEL ASSY RH
6. INSTALL REAR SEAT CUSHION ASSY (SEE PAGE 72-9)
7. CHECK AND CLEAR DTC (SEE PAGE 05-738)

YAWRATE SENSOR REPLACEMENT

3214W-01

1. REMOVE CONSOLE PANEL SUB-ASSY UPPER ([SEE PAGE 71-17](#))
2. REMOVE CONSOLE BOX POCKET ([SEE PAGE 71-17](#))
3. REMOVE CONSOLE BOX CARPET ([SEE PAGE 71-17](#))
4. REMOVE CONSOLE BOX ASSY RR ([SEE PAGE 71-17](#))



5. REMOVE YAWRATE SENSOR

- (a) Disconnect the connector and remove the 2 bolts and the yawrate sensor assy.


6. INSTALL YAWRATE SENSOR

- (a) Install the yawrate sensor assy with 2 bolts.
Torque: 19 N·m (194 kgf·cm, 14 ft·lbf)
- (b) Connect the connector of yawrate sensor assy.
7. INSTALL CONSOLE BOX ASSY RR
8. INSTALL CONSOLE BOX CARPET
9. INSTALL CONSOLE BOX POCKET
10. INSTALL CONSOLE PANEL SUB-ASSY UPPER
11. PERFORM YAWRATE SENSOR ZERO POINT CALIBRATION ([SEE PAGE 05-723](#))
12. CHECK AND CLEAR DTC ([SEE PAGE 05-738](#))

STEERING SENSOR REPLACEMENT

3214X-01

1. DISCONNECT BATTERY NEGATIVE TERMINAL (SEE PAGE 60-1)
2. REMOVE STEERING WHEEL COVER LOWER NO.2
3. REMOVE STEERING WHEEL COVER LOWER NO.3
4. REMOVE HORN BUTTON ASSY (SEE PAGE 60-20)
5. REMOVE STEERING WHEEL ASSY (SEE PAGE 50-8)
SST 09950-50013 (09951-05010, 09952-05010, 09953-05020, 09954-05021)
6. REMOVE TILT LEVER BRACKET (SEE PAGE 50-8)
7. REMOVE STEERING COLUMN COVER (SEE PAGE 50-8)
8. REMOVE SPIRAL CABLE SUB-ASSY (SEE PAGE 60-29)
9. REMOVE STEERING SENSOR
 - (a) Unclamp the 6 claws and remove the steering sensor from the spiral cable.



10. INSTALL STEERING SENSOR

- (a) Aligning the 2 locating pins as shown in the illustration, engage the 6 claws and install the steering sensor to the spiral cable.

11. INSPECT SPIRAL CABLE SUB-ASSY (SEE PAGE 60-29)
12. PLACE FRONT WHEELS FACING STRAIGHT AHEAD
13. INSTALL SPIRAL CABLE SUB-ASSY (SEE PAGE 60-29)
14. CENTER SPIRAL CABLE (SEE PAGE 60-29)
15. INSTALL STEERING COLUMN COVER (SEE PAGE 50-8)
16. INSTALL TILT LEVER BRACKET (SEE PAGE 50-8)
17. INSTALL STEERING WHEEL ASSY (SEE PAGE 50-8)
18. INSTALL HORN BUTTON ASSY (SEE PAGE 60-20)
19. INSPECT HORN BUTTON ASSY (SEE PAGE 60-14)
20. CONNECT BATTERY NEGATIVE TERMINAL
21. PERFORM INITIALIZATION (SEE PAGE 01-5)
22. INSPECT SRS WARNING LIGHT (SEE PAGE 05-1171)