

DTC	B1835/58	Short in Front Passenger Side Curtain Shield Squib Circuit
DTC	B1836/58	Open in Front Passenger Side Curtain Shield Squib Circuit
DTC	B1837/58	Short to GND in Front Passenger Side Curtain Shield Squib Circuit
DTC	B1838/58	Short to B+ in Front Passenger Side Curtain Shield Squib Circuit

RS

DESCRIPTION


The front passenger side curtain shield squib circuit consists of the center airbag sensor assembly and the curtain shield airbag assembly RH.

The circuit instructs the SRS to deploy when deployment conditions are met.

These DTCs are recorded when a malfunction is detected in the front passenger side curtain shield squib circuit.

DTC No.	DTC Detection Condition	Trouble Area
B1835/58	- The center airbag sensor assembly receives a line short circuit signal 5 times in the front passenger side curtain shield squib circuit during primary check. - Front passenger side curtain shield squib malfunction - Center airbag sensor assembly malfunction	- Floor wire - Curtain shield airbag assembly RH (Front passenger side curtain shield squib) - Center airbag sensor assembly
B1836/58	- The center airbag sensor assembly receives an open circuit signal in the front passenger side curtain shield squib circuit for 2 seconds. - Front passenger side curtain shield squib malfunction - Center airbag sensor assembly malfunction	- Floor wire - Curtain shield airbag assembly RH (Front passenger side curtain shield squib) - Center airbag sensor assembly
B1837/58	- The center airbag sensor assembly receives a short circuit to ground signal in the front passenger side curtain shield squib circuit for 0.5 seconds. - Front passenger side curtain shield squib malfunction - Center airbag sensor assembly malfunction	- Floor wire - Curtain shield airbag assembly RH (Front passenger side curtain shield squib) - Center airbag sensor assembly
B1838/58	- The center airbag sensor assembly receives a short circuit to B+ signal in the front passenger side curtain shield squib circuit for 0.5 seconds. - Front passenger side curtain shield squib malfunction - Center airbag sensor assembly malfunction	- Floor wire - Curtain shield airbag assembly RH (Front passenger side curtain shield squib) - Center airbag sensor assembly

WIRING DIAGRAM




INSPECTION PROCEDURE

HINT:

- Perform the simulation method by selecting the "check mode" (signal check) with the intelligent tester (See page [RS-37](#)).
- After selecting the "check mode" (signal check), perform the simulation method by wiggling each connector of the airbag system or driving the vehicle on a city or rough road (See page [RS-37](#)).

1 CHECK CURTAIN SHIELD AIRBAG ASSEMBLY RH (FRONT PASSENGER SIDE CURTAIN SHIELD SQUIB)



- (a) Turn the ignition switch to the LOCK position.
- (b) Disconnect the negative (-) terminal cable from the battery, and wait for at least 90 seconds.
- (c) Disconnect the connectors from the curtain shield airbag assembly RH.
- (d) Connect the white wire side of SST (resistance 2.1 Ω) to connector "C".

CAUTION:

Never connect a tester to the curtain shield airbag assembly RH (front passenger side curtain shield squib) for measurement, as this may lead to a serious injury due to airbag deployment.

NOTICE:

- Do not forcibly insert the SST into the terminals of the connector when connecting.
- Insert straight the SST into the terminals of the connector.

SST 09843-18060

- (e) Connect the negative (-) terminal cable to the battery, and wait for at least 2 seconds.
- (f) Turn the ignition switch to the ON position, and wait for at least 60 seconds.
- (g) Clear the DTCs stored in the memory (See page RS-34).
- (h) Turn the ignition switch to the LOCK position.
- (i) Turn the ignition switch to the ON position, and wait for at least 60 seconds.
- (j) Check the DTCs (See page RS-34).

OK:

DTC B1835, B1836, B1837, B1838 or 58 is not output.

HINT:

Codes other than DTC B1835, B1836, B1837, B1838 and 58 may be output at this time, but they are not related to this check.

NG

Go to step 2

OK

REPLACE CURTAIN SHIELD AIRBAG ASSEMBLY RH

2 CHECK CONNECTOR

- (a) Turn the ignition switch to the LOCK position.
- (b) Disconnect the negative (-) terminal cable from the battery, and wait for at least 90 seconds.
- (c) Disconnect the SST from connector "C".

RS

cardiagn.com

- (d) Check that the floor wire connectors (on the curtain shield airbag assembly RH side) are not damaged.

OK:

The lock button is not disengaged, or the claw of the lock is not deformed or damaged.

RS


NG

REPAIR OR REPLACE FLOOR WIRE

OK

3

CHECK FLOOR WIRE (FRONT PASSENGER SIDE CURTAIN SHIELD SQUIB CIRCUIT)



- (a) Disconnect the connectors from the center airbag sensor assembly.
- (b) Check for a short to B+ in the circuit.
- (1) Connect the negative (-) terminal cable to the battery, and wait for at least 2 seconds.
 - (2) Turn the ignition switch to the ON position.
 - (3) Measure the voltage according to the value(s) in the table below.

Standard voltage

Tester connection	Condition	Specified condition
C20-1 (ICR+) - Body ground	Ignition switch ON	Below 1 V
C20-2 (ICR-) - Body ground	Ignition switch ON	Below 1 V

- (c) Check for an open in the circuit.
- (1) Turn the ignition switch to the LOCK position.
 - (2) Disconnect the negative (-) terminal cable from the battery, and wait for at least 90 seconds.
 - (3) Measure the resistance according to the value(s) in the table below.

Standard resistance

Tester connection	Condition	Specified condition
C20-1 (ICR+) - C20-2 (ICR-)	Always	Below 1 Ω

- (d) Check for a short to ground in the circuit.
- (1) Measure the resistance according to the value(s) in the table below.

Standard resistance

Tester connection	Condition	Specified condition
C20-1 (ICR+) - Body ground	Always	1 M Ω or higher
C20-2 (ICR-) - Body ground	Always	1 M Ω or higher

- (e) Check for a short in the circuit.
- (1) Release the activation prevention mechanism built into connector "B" (See page RS-26).
 - (2) Measure the resistance according to the value(s) in the table below.

Standard resistance

Tester connection	Condition	Specified condition
C20-1 (ICR+) - C20-2 (ICR-)	Always	1 M Ω or higher

NG


REPAIR OR REPLACE FLOOR WIRE

OK

4

CHECK CENTER AIRBAG SENSOR ASSEMBLY

RS



- Connect the connectors to the curtain shield airbag assembly RH and the center airbag sensor assembly.
- Connect the negative (-) terminal cable to the battery, and wait for at least 2 seconds.
- Turn the ignition switch to the ON position, and wait for at least 60 seconds.
- Clear the DTCs stored in the memory (See page RS-34).
- Turn the ignition switch to the LOCK position.
- Turn the ignition switch to the ON position, and wait for at least 60 seconds.
- Check the DTCs (See page RS-34).

OK:

DTC B1835, B1836, B1837, B1838 or 58 is not output.

HINT:

Codes other than DTC B1835, B1836, B1837, B1838 and 58 may be output at this time, but they are not related to this check.

NG

REPLACE CENTER AIRBAG SENSOR ASSEMBLY

OK

USE SIMULATION METHOD TO CHECK