

DTC	B1796	Sleep Operation Failure of Occupant Classification ECU
-----	-------	--

DESCRIPTION

RS

During sleep mode, the occupant classification ECU reads the condition of each sensor while the ignition switch is off.
In this mode, if the occupant classification ECU detects an internal malfunction, DTC B1796 is output.

DTC No.	DTC Detecting Condition	Trouble Area
B1796	Occupant classification ECU malfunction	Occupant classification ECU

INSPECTION PROCEDURE

1	CHECK DTC
---	-----------

- (a) Turn the ignition switch to the ON position.
- (b) Clear the DTCs stored in memory (See page [RS-194](#)).
HINT:
First clear DTCs stored in the occupant classification ECU and then in the center airbag sensor assembly.
- (c) Turn the ignition switch to the LOCK position, and wait for at least 10 seconds.
- (d) Turn the ignition switch to the ON position.
- (e) Check the DTCs (See page [RS-194](#)).
OK:
DTC B1796 is not output.
HINT:
Codes other than DTC B1796 may be output at this time, but they are not related to this check.

OK

USE SIMULATION METHOD TO CHECK

NG

2	REPLACE OCCUPANT CLASSIFICATION ECU
---	-------------------------------------

- (a) Turn the ignition switch to the LOCK position.
- (b) Disconnect the negative (-) terminal cable from the battery.
- (c) Replace the occupant classification ECU (See page [RS-332](#)).
HINT:
Perform the inspection using parts from a normal vehicle if possible.

NEXT

3	PERFORM ZERO POINT CALIBRATION
---	--------------------------------

- (a) Connect the negative (-) terminal cable to the battery.
- (b) Connect the intelligent tester to the DLC3.
- (c) Turn the ignition switch to the ON position.

- (d) Using the intelligent tester, perform "Zero point calibration" (See page [RS-187](#)).

OK:

The "COMPLETED" is displayed.

NEXT

4

PERFORM SENSITIVITY CHECK

- (a) Using the intelligent tester, perform "Sensitivity check" (See page [RS-187](#)).

Standard values:

27 to 33 kg (59.52 to 72.75 lb)

NEXT

END

RS