

# OPEL MOVANO

Owner's Manual



Wir leben Autos.





---

# Contents

|                                |     |
|--------------------------------|-----|
| Introduction .....             | 2   |
| In brief .....                 | 6   |
| Keys, doors and windows .....  | 19  |
| Seats, restraints .....        | 36  |
| Storage .....                  | 58  |
| Instruments and controls ..... | 66  |
| Lighting .....                 | 85  |
| Climate control .....          | 92  |
| Driving and operating .....    | 103 |
| Vehicle care .....             | 128 |
| Service and maintenance .....  | 162 |
| Technical data .....           | 165 |
| Customer information .....     | 184 |
| Index .....                    | 186 |

## Introduction

|               |                             |                      |                      |                      |
|---------------|-----------------------------|----------------------|----------------------|----------------------|
| Fuel          | Designation                 | <input type="text"/> |                      |                      |
| Engine oil    | Grade                       | <input type="text"/> |                      |                      |
|               | Viscosity                   | <input type="text"/> |                      |                      |
| Tyre pressure | Tyre size                   |                      | Front                | Rear                 |
|               | Summer tyres                | <input type="text"/> | <input type="text"/> | <input type="text"/> |
|               | Winter tyres                | <input type="text"/> | <input type="text"/> | <input type="text"/> |
| Weights       | Gross vehicle weight rating | <input type="text"/> |                      |                      |
|               | - Kerb weight, basic model  | <input type="text"/> |                      |                      |
|               | = Loading                   | <input type="text"/> |                      |                      |

## Vehicle specific data

Please enter your vehicle's data on the previous page to keep it easily accessible. This information is available in the sections "Service and maintenance" and "Technical data" as well as on the identification plate.

## Introduction

Your vehicle is a designed combination of advanced technology, safety, environmental friendliness and economy.

This Owner's Manual provides you with all the necessary information to enable you to drive your vehicle safely and efficiently.

Make sure your passengers are aware of the possible risk of accident and injury which may result from improper use of the vehicle.

You must always comply with the specific laws and regulations of the country that you are in. These laws may differ from the information in this Owner's Manual.

When this Owner's Manual refers to a workshop visit, we recommend your Opel Service Partner.

All Opel Service Partners provide first-class service at reasonable prices. Experienced mechanics trained by Opel work according to specific Opel instructions.

The customer literature pack should always be kept ready to hand in the vehicle.

## Using this manual

- This manual describes all options and features available for this model. **Certain descriptions, including those for display and menu functions, may not apply to your vehicle due to model variant, country specifications, special equipment or accessories.**
- The "In brief" section will give you an initial overview.
- The table of contents at the beginning of this manual and within each section shows where the information is located.

- The index will enable you to search for specific information.
- This Owner's Manual depicts left-hand drive vehicles. Operation is similar for right-hand drive vehicles.
- The Owner's Manual uses the factory engine designations. The corresponding sales designations can be found in the section "Technical data".
- Directional data, e.g. left or right, or front or back, always relate to the direction of travel.
- The vehicle display screens may not support your specific language.
- Display messages and interior labelling are written in **bold** letters.

## Danger, Warnings and Cautions

### Danger

Text marked  **Danger** provides information on risk of fatal injury. Disregarding this information may endanger life.

**⚠ Warning**

Text marked **⚠ Warning** provides information on risk of accident or injury. Disregarding this information may lead to injury.

**Caution**

Text marked **Caution** provides information on possible damage to the vehicle. Disregarding this information may lead to vehicle damage.

## Symbols

Page references are indicated with ⇨.  
⇨ means "see page".

We wish you many hours of  
pleasurable driving.

**Adam Opel AG**




## In brief

## Initial drive information

### Vehicle unlocking

#### Unlocking with key



Turn the key in the driver's door lock.  
Open the doors by pulling the handles.

### Unlocking with remote control



Press button  to unlock the front doors. Press again to unlock entire vehicle.

Open the doors by pulling the handles.

Press button ; only the load compartment and sliding side doors are unlocked.

Radio remote control ⇨ 19, Central locking system ⇨ 20, Anti-theft alarm system ⇨ 28.

## Seat adjustment

### Seat positioning




Pull handle, slide seat, release handle.

Seat position ⇨ 37, Seat adjustment ⇨ 38.

### **⚠ Danger**

Do not sit nearer than 25 cm from the steering wheel, to permit safe airbag deployment.

### Seat backrests



Pull lever, adjust inclination and release lever. Allow the seat to engage audibly.

Seat position ⇨ 37, Seat adjustment ⇨ 38.

### Seat height




Lever motion

up = seat higher

down = seat lower

Seat position ⇨ 37, Seat adjustment ⇨ 38.

## Head restraint adjustment



Press release catch, adjust height, engage.

Head restraints ⇨ 36.

## Seat belt




Pull out the seat belt and engage in belt buckle. The seat belt must not be twisted and must fit close against the body. The backrest must not be tilted back too far (maximum approx. 25 °).

To release belt, press red button on belt buckle.

Seat position ⇨ 37, Seat belts ⇨ 44, Airbag system ⇨ 46.

## Mirror adjustment

### Interior mirror




To reduce dazzle, adjust the lever on the underside of the mirror housing.

Interior mirror ⇨ 32.

## Exterior mirrors


### Manual adjustment



Swivel mirror in required direction.

Exterior mirrors ⇨ 30.


### Electric adjustment



Select the relevant exterior mirror and adjust it.

Convex exterior mirrors ⇨ 30,  
Electric adjustment ⇨ 30, Folding  
exterior mirrors ⇨ 31, Heated  
exterior mirrors ⇨ 31.

## Steering wheel adjustment




Unlock lever, adjust steering wheel, then engage lever and ensure it is fully locked.


Do not adjust steering wheel unless vehicle is stationary and steering wheel lock has been released.

Airbag system ⇨ 46, Ignition  
positions ⇨ 104.


## Instrument panel overview



|          |                                               |     |           |                                               |     |           |                                                            |     |
|----------|-----------------------------------------------|-----|-----------|-----------------------------------------------|-----|-----------|------------------------------------------------------------|-----|
| <b>1</b> | Fixed air vents .....                         | 101 | <b>6</b>  | Horn .....                                    | 67  | <b>18</b> | Cruise control and speed limiter .....                     | 118 |
| <b>2</b> | Headlight range adjustment .....              | 86  |           | Driver airbag .....                           | 47  |           | Manual transmission automated, Winter and Laden modes .... | 113 |
|          | Ultrasonic parking assist .....               | 121 | <b>7</b>  | Remote control on steering wheel .....        | 66  |           | Idle speed control .....                                   | 104 |
|          | Traction control system .....                 | 116 |           | Cruise control .....                          | 118 |           | Stop-start system .....                                    | 105 |
|          | Electronic stability program .....            | 117 | <b>8</b>  | Windscreen wiper, windscreen washer system .. | 67  | <b>19</b> | Ignition switch with steering wheel lock .....             | 104 |
| <b>3</b> | Side air vents .....                          | 101 |           | Trip computer .....                           | 82  | <b>20</b> | Steering column controls .....                             | 67  |
| <b>4</b> | Light switch .....                            | 85  | <b>9</b>  | Coin tray .....                               | 58  | <b>21</b> | Steering wheel adjustment ..                               | 66  |
|          | Turn and lane-change signals .....            | 87  | <b>10</b> | Power outlet .....                            | 69  | <b>22</b> | Bonnet release lever .....                                 | 129 |
|          | High beam and low beam, headlight flash ..... | 86  | <b>11</b> | Centre air vents .....                        | 101 | <b>23</b> | Auxiliary heater .....                                     | 97  |
|          | Sidelights .....                              | 85  | <b>12</b> | Front passenger airbag .....                  | 47  | <b>24</b> | Storage compartment .....                                  | 58  |
|          | Automatic light control .....                 | 85  |           | Storage compartment .....                     | 58  |           | Fuse box .....                                             | 145 |
|          | Exit lighting .....                           | 90  | <b>13</b> | Glovebox .....                                | 59  |           |                                                            |     |
|          | Front fog lights .....                        | 87  | <b>14</b> | Cupholders .....                              | 59  |           |                                                            |     |
|          | Rear fog light .....                          | 88  | <b>15</b> | Climate control system .....                  | 92  |           |                                                            |     |
| <b>5</b> | Instruments .....                             | 71  | <b>16</b> | Cigarette lighter .....                       | 70  |           |                                                            |     |
|          | Transmission display .....                    | 73  |           | Power outlet .....                            | 69  |           |                                                            |     |
|          | Driver Information Centre .....               | 80  | <b>17</b> | Gear lever, Manual transmission .....         | 110 |           |                                                            |     |
|          |                                               |     |           | Manual transmission automated .....           | 111 |           |                                                            |     |



## Exterior lighting



Turn light switch:

**O** = Off

 = Sidelights

 = Headlights


**AUTO** = Automatic light control:  
Headlights are switched  
on and off automatically.

 = Front fog lights

 = Rear fog lights

Lighting ⇨ 85, Headlight warning  
device ⇨ 82.

## Front and rear fog lights




Turn light switch:

 = Front fog lights

 = Rear fog lights


## Headlight flash, high beam and low beam



Pull lever.

High beam ⇨ 86, Headlight flash  
⇨ 86.

### Turn and lane-change signals



lever up = right turn signal  
lever down = left turn signal

Turn and lane-change signals  
⇨ 87.

### Hazard warning flashers



Operated with the  button.  
Hazard warning flashers ⇨ 87.

### Horn



Press .

## Washer and wiper systems

### Windscreen wiper



**0** = off


 = timed interval wiping or automatic wiping with rain sensor

**1** = slow

**2** = fast

Windscreen wiper, automatic wiping with rain sensor ⇨ 67, Wiper blade replacement ⇨ 135.

### Windscreen washer



Pull lever.


short = wiper swipes once and washer fluid is sprayed onto the windscreen

long = wiper swipes for a few strokes and washer fluid is sprayed onto the windscreen

Windscreen washer ⇨ 67, Wiper blade replacement ⇨ 135, Washer fluid ⇨ 132.

## Climate control

### Heated rear window, heated exterior mirrors



Heating is operated by pressing the  button.

Heated exterior mirrors ⇨ 31,  
Heated rear window ⇨ 34.

## Demisting and defrosting the windows



- Air distribution to .
- Set temperature control to warmest level.
- Set fan speed to highest level.
- Cooling **AC** on.
- Press button .

Climate control system ⇨ 92.

Vehicles with Electronic climate control, press button .

Temperature and air distribution are set automatically and the fan runs at a high speed.

Electronic climate control system

⇨ 94.

## Transmission

### Manual transmission




Reverse: with the vehicle stationary, depress clutch pedal and then pull up the collar on the selector lever and engage the gear.

If the gear does not engage, set the lever to neutral, release the clutch pedal and depress again; then repeat gear selection.

Manual transmission ⇨ 110.

## Manual transmission automated



- N** = neutral  
**●** = drive  
**+** = higher gear  
**-** = lower gear  
**A/M** = switch between automatic and manual mode  
**R** = reverse gear


Manual transmission automated  
 ⇨ 111.

## Starting off

### Check before starting off

- Tyre pressure and condition ⇨ 147, ⇨ 183.
- Engine oil level and fluid levels ⇨ 130.
- All windows, mirrors, exterior lighting and number plates are free from dirt, snow and ice and are operational.
- Proper position of mirrors, seats and seat belts ⇨ 30, ⇨ 37, ⇨ 45.
- Brake function at low speed, particularly if the brakes are wet.

## Starting the engine



- Turn key to position **A**
  - move the steering wheel slightly to release the steering wheel lock
  - operate clutch and brake
  - do not operate accelerator pedal
  - turn the key to position **M** for preheating and wait until control indicator  extinguishes in the Driver Information Centre
  - turn key to position **D** and release
- Starting the engine ⇨ 104.

## Stop-start system



If the vehicle is at low speed or in standstill and certain conditions are fulfilled, activate an Autostop as follows:

- Depress the clutch pedal
- shift the selector lever to **N**
- release the clutch pedal

An Autostop is indicated when **A** illuminates green in the instrument cluster.

To restart the engine, depress the clutch pedal again.

Stop-start system ⇨ 105.

## Parking

- Always apply parking brake without pressing release button. Apply as firmly as possible on a downhill slope or uphill slope. Depress foot brake at the same time to reduce operating force.
- Switch off the engine. Turn the ignition key to position **St** and remove it. Turn the steering wheel until the steering wheel lock is felt to engage.
- If the vehicle is on a level surface or uphill slope, engage first gear before switching off the ignition. On an uphill slope, turn the front wheels away from the kerb.

If the vehicle is on a downhill slope, engage reverse gear before switching off the ignition. Turn the front wheels towards the kerb.

- Lock the vehicle and activate the anti-theft alarm system ⇨ 28 with button **Ⓜ** on the remote control.

- Do not park the vehicle on an easily ignitable surface. The high temperature of the exhaust system could ignite the surface.
- Close the windows.
- The engine cooling fans may run after the engine has been switched off ⇨ 129.
- After running at high engine speeds or with high engine loads, operate the engine briefly at a low load or run in neutral for approx. 30 seconds before switching off, in order to protect the turbocharger.

Keys, locks ⇨ 19, Laying the vehicle up for a long period of time ⇨ 128.

## Keys, doors and windows

|                        |    |
|------------------------|----|
| Keys, locks .....      | 19 |
| Doors .....            | 24 |
| Vehicle security ..... | 27 |
| Exterior mirrors ..... | 30 |
| Interior mirrors ..... | 32 |
| Windows .....          | 32 |
| Roof .....             | 35 |

## Keys, locks

### Keys

#### Replacement keys

The key number is specified in the Car Pass or on a detachable tag.

The key number must be quoted when ordering replacement keys as it is a component of the immobiliser system.

Locks ⇨ 159.

### Car Pass

The Car Pass contains security related vehicle data and should therefore be kept in a safe place.

When the vehicle is taken to a workshop, this vehicle data is needed in order to perform certain operations.

## Radio remote control



Used to operate:

- Central locking system
- Anti-theft locking system
- Anti-theft alarm system

Depending on model, the vehicle may use a 2-button or 3-button remote control.

The remote control has a range of approx. 5 metres. It can be affected by external influences. The hazard warning flashers confirm operation.

Handle with care, protect it from moisture and high temperatures and avoid unnecessary operation.

### Fault

If the central locking system cannot be operated with the remote control, it may be due to the following:

- Range exceeded.
- Battery voltage too low.
- Frequent, repeated operation of the remote control while not in range, which will require reprogramming by a workshop.
- Interference from higher-power radio waves from other sources.

Unlocking ⇨ 20.

### Remote control battery replacement

Replace the battery as soon as the range reduces.



Batteries do not belong in household waste. They must be disposed of at an appropriate recycling collection point.



Remove screw and open battery compartment by inserting a coin into the slot and twisting.

Replace the battery (battery type CR2016), paying attention to the installation position.

Reattach both halves of cover ensuring it engages correctly.

Replace screw and tighten.

### Central locking system

Unlocks and locks the front doors, sliding side doors and load compartment.

With the 3-button remote control, the front doors and sliding side doors/load compartment can be unlocked and locked separately.

For safety reasons, the vehicle cannot be locked if the key is in the ignition switch.

## Unlocking the vehicle

### Unlocking with 2-button remote control



Press button : All doors and the load compartment are unlocked.

### Unlocking with 3-button remote control



Depending on vehicle configuration:

- Press button : Front doors are unlocked.

Press  again: Sliding side doors and the load compartment are also unlocked.

- Press button : All doors and the load compartment are unlocked.

If no door is opened within approx. 2 minutes after the vehicle has been unlocked, the vehicle is re-locked automatically.

## Locking the vehicle

Close all doors and load compartment. If the doors are not closed properly, the central locking system will not work.

### Locking with 2-button remote control



Press button : All doors and the load compartment are locked.

### Locking with 3-button remote control



Press button : All doors and the load compartment are locked.

#### Note

Where fitted, alarm monitoring of the passenger compartment  28 is switched off by pressing and holding button  (which is confirmed by an audible signal).

If this was done unintentionally, unlock the doors again and press button  briefly to lock the vehicle.

### Load compartment

Locking and unlocking load compartment with 2-button remote control



Press button  or  once: Load compartment is locked or unlocked.

### Locking and unlocking load compartment with 3-button remote control



Depending on vehicle configuration:

- Press button : Load compartment is locked or unlocked.
- Press button : Load compartment and sliding side doors are locked or unlocked.

### Central locking switch

Locks or unlocks the doors and load compartment from the passenger compartment.



Press the  switch to lock or unlock. LED in switch illuminates when the vehicle is locked.

### Fault in remote control system

#### Unlocking

Manually unlock the front door by turning the key in the lock.

Switch on the ignition and press the central locking switch  to open all doors and the load compartment.

#### Locking

Manually lock the front door by turning the key in the lock.

### Fault in central locking system

#### Unlocking

Manually unlock the front door by turning the key in the lock. The other doors can be opened by pulling the interior handles.

#### Locking

Push inside locking knob of all doors except driver's door. Then close the driver's door and lock it from the outside with the key.

### Automatic locking

#### Automatic locking after driving off

This security feature can be configured to automatically lock all doors and the load compartment as soon as the vehicle is driven.



#### Activation

With the ignition switched on, press and hold  on the central locking switch for approx. 5 seconds. An audible signal confirms activation.

#### Deactivation

With the ignition switched on, press and hold  for approx. 5 seconds. An audible signal confirms deactivation.

## Child locks

### Warning

Use the child locks whenever children are occupying the rear seats.



Press down the child lock, door cannot be opened from the inside. Raise to deactivate.

## Doors

### Sliding door



The sliding side door can be locked from inside the vehicle with the interior lock switch.

Ensure the side door is fully closed and secure before driving the vehicle.

## Power sliding door

### Opening



With the parking brake applied, press switch on instrument panel to open the power sliding door automatically; the LED in the switch flashes during operation.


### Closing

Press switch again; the LED flashes and a chime sounds during operation.

**⚠ Warning**

Take care when operating the power sliding door. Risk of injury, particularly to children.

Keep a close watch on the moving door when operating. Ensure that nothing becomes trapped during operation and no one is standing within the moving area.

**Emergency exit**

In an emergency release the interior handle.



Using the handle, manually slide the door backwards to open.

**Maintenance**

It is the owner's responsibility to have the drive belt replaced after every 15000 cycles, and for this purpose a counter is incorporated in the lower B-pillar. Seek the assistance of a workshop.

If the drive belt should fail, the door may still be opened and closed manually.

**Power side step**

The power side step operates automatically when the power sliding door is opened or closed.

**⚠ Warning**

Ensure there is adequate clearance to allow the power side step to fully extend and retract without obstruction.

**Rear doors**

To open the right-hand rear door, pull the outside handle.

The door is opened from inside the vehicle by pulling the interior handle.



The left-hand rear door is released using the lever.

**⚠ Warning**

The rear lights may be obscured if the rear doors are open and the vehicle is parked on the roadside.

Make other road users aware of the vehicle, by using a warning triangle or other equipment specified in the road traffic regulations.

The doors are retained in the 90° position by locking stays.



To open the doors to 180° or further, release locking stays from the catches on the door frames and swing doors open to the desired position.



When opening the doors to 270°, the doors are retained in the fully open position by magnets on the body side.

**⚠ Warning**

Ensure extended opening doors are secured when fully opened.

Opened doors may slam closed due to the force of the wind!


When closing the doors, secure each locking stay to the catch on the door frame.

Close the left-hand door before the right-hand door.

## Bus

It is possible to prevent the rear doors from being opened from the inside.

All doors must be properly closed and automatic locking deactivated ⇨ 23.



To lock the rear doors, press I on button 1 warning light 2 will flash once and an acoustic alarm will sound.



Warning light on the rear door will illuminate.

To unlock the rear doors, press 0 on button 1 warning light on the rear door extinguishes.

## Fault

In the event of a fault in the system, warning light 2 illuminates in conjunction with an acoustic alarm. Have the cause of the fault in the system remedied by a workshop.

## Vehicle security

### Anti-theft locking system

#### ⚠ Warning

Do not use the system if there are people in the vehicle! The doors cannot be unlocked from the inside.

The system deadlocks the doors. All doors must be closed or the system cannot be activated.

#### Note

The anti-theft locking system cannot be activated when the hazard warning lights or sidelights are switched on.

Activation and deactivation are not possible with the central locking switch.

## Activation



Press button  twice.

## Deactivation

Unlock the doors with button  on the remote control.

## Anti-theft alarm system

The anti-theft alarm system is operated in conjunction with the central locking system.

It monitors:

- Doors, tailgate, bonnet
- Passenger compartment

- Load compartment
- Vehicle inclination, e.g. if it is raised
- Ignition
- Interruption of alarm siren power supply

## Activation

All doors and the bonnet must be closed.



Press button  to activate anti-theft alarm system. Hazard warning lights flash twice to confirm activation.

If the hazard warning lights do not flash upon activation, a door or the bonnet is not fully closed.

## Deactivation

Unlocking the vehicle or switching on the ignition deactivates the anti-theft alarm system. Hazard warning lights flash once to confirm deactivation.

### Note

If the alarm has been triggered, unlocking the vehicle with the key will not stop the alarm siren. To stop the siren, switch on the ignition. The hazard warning lights will not flash upon deactivation if the alarm has been triggered.

## Activation without monitoring of passenger compartment

Switch off monitoring of the passenger compartment when people or animals are being left in the vehicle, or if the auxiliary heater  97 is set for a timed or remote controlled start.



Depending on vehicle configuration:

- press and hold button , or
- switch ignition on and off twice quickly, then close doors and activate the anti-theft alarm system.

An audible signal will sound as confirmation.

The status will remain until the doors are unlocked.

### Activation without monitoring of vehicle inclination

Additionally, disable monitoring of vehicle inclination because of high volume ultrasonic signals or movements triggering the alarm, e.g. when the vehicle is on a ferry or train:

Switch ignition on and off three times in quick succession, then close doors and activate the anti-theft alarm system.

An audible signal will sound as confirmation.

The status will remain until the doors are unlocked.

### Alarm

When triggered, the alarm sounds via a separate battery-backed power sounder, and the hazard warning lights flash simultaneously. The number and duration of alarm signals are stipulated by legislation.

If the vehicle battery is disconnected or its power supply is interrupted, the alarm siren will be triggered. First

deactivate the anti-theft alarm system if the vehicle battery must be disconnected.

To silence the alarm siren (if triggered) and therefore deactivate the anti-theft alarm system, reconnect vehicle battery and unlock vehicle with remote control button  (or switch on the ignition).

### Immobiliser

The system is part of the ignition switch and checks whether the vehicle is allowed to be started with the key being used.

The immobiliser is activated automatically after the key has been removed from the ignition switch and also if the key is left in the ignition switch when the engine is turned off.


If the engine cannot be started, switch off the ignition and remove key, wait approx. 2 seconds and then repeat the start attempt. If start attempt is unsuccessful, attempt to start the engine using the spare key and seek the assistance of a workshop.

**Note**

The immobiliser does not lock the doors. You should always lock the vehicle after leaving it and switch on the anti-theft alarm system ⇨ 20, ⇨ 28.

**Exterior mirrors****Convex shape**

The convex exterior mirror reduces blind spots. The shape of the mirror makes objects appear smaller, which will affect the ability to estimate distances.

**Manual adjustment**

Adjust mirrors by swivelling in required direction.  
The lower mirrors are not adjustable.

**Electric adjustment**

Select the relevant exterior mirror by switching the control to the left or right, then swivel the control to adjust the mirror.

No mirror is selected when the control is in the centre position.


The lower mirrors are not adjustable.

## Folding



For pedestrian safety, the exterior mirrors will swing out of their normal mounting position if they are struck with sufficient force. Reposition the mirror by applying slight pressure to the mirror housing.

## Heated



Operated by pressing the  button on either system.



Heating functions with the engine running. It is switched off automatically after a short time.

Climate control system ⇨ 92.

Electronic climate control system ⇨ 94.

## Interior mirrors

### Manual anti-dazzle



To reduce dazzle, adjust the lever on the underside of the mirror housing.

## Windows

### Manual windows

The door windows can be opened or closed with the window winders.

### Power windows

#### Warning

Take care when operating the power windows. Risk of injury, particularly to children.

Keep a close watch on the windows when closing them. Ensure that nothing becomes trapped in them as they move.

Switch on ignition to operate power windows.



Operate the switch for the respective window by pushing to open or pulling to close.

For vehicles with automatic feature for the driver's door window; when opening pull or press the switch again to stop window movement.


In the event of closing difficulties due to frost or the like, operate the switch several times to close the window in stages.

## Rear windows

### Sliding side windows




Press catch and slide window to open. Ensure catch engages when closing.



Press catch and slide window to open. Ensure catch engages when closing.

## Opening side windows




Pull handle to open window.

## Emergency exit



To provide an emergency exit from the vehicle, use hammer **1** to strike glass **2**.

## Heated rear window



Operated by pressing the  button on either system.



Heating functions with the engine running. It is switched off automatically after a short time.

Climate control system ⇨ 92.

Electronic climate control system ⇨ 94.

## Sun visors

The sun visors can be folded down or swivelled to the side to prevent dazzling.

If the sun visors have integral mirrors, the mirror covers should be closed when driving.

Sun visors also feature a holder for parking tickets etc.

## Roof

### Glass panel

### Emergency exit



In an emergency, the glass can be broken. Use the hammer to break the glass panel ⇨ 33.

## Seats, restraints


|                        |    |
|------------------------|----|
| Head restraints .....  | 36 |
| Front seats .....      | 37 |
| Rear seats .....       | 42 |
| Seat belts .....       | 44 |
| Airbag system .....    | 46 |
| Child restraints ..... | 49 |

## Head restraints

### Position


#### Warning

Only drive with the head restraint set to the proper position.



The upper edge of the head restraint should be at upper head level. If this is not possible for extremely tall people, set to highest position, and set to lowest position for small people.

## Height adjustment




Pull up to raise or press the catch and lower head restraint. Ensure the head restraint engages.

### Note

Approved accessories may only be attached to the front passenger seat head restraint if the seat is not in use.

## Removal



Press both catches, pull the head restraint upwards and remove.

Stow head restraints securely in load compartment. Do not drive with head restraints removed if the seat is occupied.

## Front seats

### Seat position

#### Warning

Only drive with the seat correctly adjusted.



- Sit with buttocks as far back against the backrest as possible. Adjust the distance between the seat and the pedals so that legs are slightly angled when pressing the pedals. Slide the front passenger seat as far back as possible.

- Sit with shoulders as far back against the backrest as possible. Set the backrest rake so that it is possible to reach the steering wheel with arms slightly bent. Maintain contact between shoulders and the backrest when turning the steering wheel. Do not angle the backrest too far back. We recommend a maximum rake of approx. 25°.
- Adjust the steering wheel ⇄ 66.
- Set seat height high enough to have a clear field of vision on all sides and of all display instruments. There should be at least one hand of clearance between head and the roof frame. Thighs should rest lightly on the seat without pressing into it.
- Adjust the head restraint ⇄ 36.
- Adjust the height of the seat belt ⇄ 45.
- Adjust the lumbar support so that it supports the natural shape of the spine ⇄ 38.

## Seat adjustment

### Danger

Do not sit nearer than 25 cm from the steering wheel, to permit safe airbag deployment.

### Warning

Never adjust seats while driving as they could move uncontrollably.

## Seat positioning




Pull handle, slide seat, release handle.

### Suspension seat positioning



Pull handle, slide seat, release handle.

## Seat backrests



Pull lever, adjust inclination and release lever. Allow the seat to engage audibly.


**Suspension seat backrests**

Pull lever, adjust inclination and release lever. Allow the seat to engage audibly.

**Seat height**

Lever motion

up = seat higher  
down = seat lower

**Suspension seat height**

Pull up front release lever up to adjust height of front part of seat.

Pull up rear release lever to adjust height of rear part of seat.

### Lumbar support



Adjust lumbar support to suit personal requirements.

Increasing and decreasing support: turn the handwheel while relieving the load on the backrest.

### Suspension seat lumbar support



Adjust lumbar support to suit personal requirements.

Operate hand pump repeatedly (located on underside of unit) to increase firmness.

Press release button (located at front of unit) to decrease firmness.

### Suspension seat sensitivity



Rotate knob to adjust the sensitivity of the suspension seat.

Turn right = More stiff


Turn left = Less stiff

## Armrest



Armrest can be folded up when not required.

## Heating



Press the  button for the respective seat. Press the  button again to switch off.

Seat heating is thermostatically controlled and switches off automatically when seat temperature is sufficient.

Control indicator in the button illuminates when the system is on, not just when heating is active.

Prolonged use of the highest setting for people with sensitive skin is not recommended.

Seat heating is operational when the engine is running.

## Rear seats

### Rear seat access



To facilitate access to the rear seats, pull release lever and fold the seat backrest forwards.

#### **⚠ Warning**


Ensure that the backrest returns to its correct position and the seat belt buckles engage securely.

Fitting seat belt ⇨ 45.

### Removable rear seats

#### Removal

On some variants, the cargo area can be increased by removing the rear seats.



- Raise lever **1** on both sides of the seat; the pins **2** visibly protrude to indicate that the seat is unlocked.
- Move the seat towards the rear to release from the floor anchor points.
- Lift seat to remove.


#### **⚠ Warning**

Removable rear seats are heavy! Do not attempt to remove without assistance.


#### Installation

#### **Caution**

The rear seats are not interchangeable and must be fitted back into their original position.



Position the seat guides immediately behind the front floor anchor points, and slide forwards to engage.



The seat locks automatically and the pins 3 will no longer be visible, to indicate that the seat is locked.


### Caution

When installing the rear seats, ensure they are properly located on the floor anchor points and that the locking catches are fully engaged.

## Bus

### Removal

Using the tool from the tool kit located in the glovebox, turn levers to unlock the seat.



1. Release the outboard fixing.
2. Release the inboard fixing.
3. Lift the seat from the outboard side and move the seat towards the centre of the vehicle.

### ⚠ Warning

Removable rear seats are heavy!  
Do not attempt to remove without assistance.

### Installation

1. Position the seat over the anchor points.
2. Lower the seat until it engages.
3. Ensure the seat is locked securely in position.

## Seat belts



The seat belts are locked during heavy acceleration or deceleration of the vehicle, holding the occupants in the sitting position. Therefore, the risk of injury is considerably reduced.

### **⚠ Warning**

Fasten seat belt before each trip. In the event of an accident, people not wearing seat belts endanger their fellow occupants and themselves.

Seat belts are designed to be used by only one person at a time. Child restraint system ⇨ 49.

Periodically check all parts of the belt system for damage and proper functionality.

Have damaged components replaced. After an accident, have the belts and triggered belt pretensioners replaced by a workshop.

### **Note**

Make sure that the belts are not damaged by shoes or sharp-edged objects or trapped. Prevent dirt from getting into the belt retractors.

Seat belt reminder 🚨 ⇨ 76.

### **Belt force limiters**

On the front seats, stress on the body is reduced by the gradual release of the belt during a collision.

### **Belt pretensioners**

In the event of a head-on or rear-end collision of a certain severity, the front seat belts are tightened.

### **⚠ Warning**

Incorrect handling (e.g. removal or fitting of belts) can trigger the belt pretensioners.

Deployment of the belt pretensioners is indicated by continuous illumination of control indicator 🚨 ⇨ 76.

Triggered belt pretensioners must be replaced by a workshop. Belt pretensioners can only be triggered once.

### **Note**

Do not affix or install accessories or other objects that may interfere with the operation of the belt pretensioners. Do not make any modifications to belt pretensioner components as this will invalidate the vehicle type approval.

## Three-point seat belt

### Fitting



Withdraw the belt from the retractor, guide it untwisted across the body and insert the latch plate into the buckle. Tighten the lap belt regularly whilst driving by pulling the shoulder belt.




Loose or bulky clothing prevents the belt from fitting snugly. Do not place objects such as handbags or mobile phones between the belt and your body.

### Warning

The belt must not rest against hard or fragile objects in the pockets of your clothing.

### Height adjustment



1. Pull belt out slightly.
2. Press button.
3. Adjust height and engage.

Adjust the height so that the belt lies across the shoulder. It must not lie across the throat or upper arm.

Do not adjust while driving.

## Removing



30054

To release belt, press red button on belt buckle.

## Using the seat belt while pregnant



### ⚠ Warning

The lap belt must be positioned as low as possible across the pelvis to prevent pressure on the abdomen.

## Airbag system

The airbag system consists of a number of individual systems depending on the scope of equipment.

When triggered the airbags inflate within milliseconds. They also deflate so quickly that it is often unnoticeable during the collision.

### ⚠ Warning

If handled improperly the airbag systems can be triggered in an explosive manner.

### Note

The airbag systems and belt pretensioner control electronics are located in the centre console area. Do not put any magnetic objects in this area.

Do not fix any objects onto the airbag covers and do not cover them with other materials.

Each airbag is triggered only once. Have deployed airbags replaced by a workshop. Furthermore, it may be necessary to have the steering wheel, the instrument panel, parts of the panelling, the door seals, handles and the seats replaced.

Do not make any modifications to the airbag system as this will invalidate the vehicle type approval.

When the airbags inflate escaping hot gases may cause burns.

Control indicator  for airbag systems  76.

## Front airbag system

The front airbag system consists of one airbag in the steering wheel and one in the instrument panel on the front passenger side. These can be identified by the word **AIR BAG**.



There is also a warning label on the side of the instrument panel, visible when the front passenger door is open.

The front airbag system is triggered in the event of an accident of a certain severity. The ignition needs to be switched on.

The inflated airbags cushion the impact, thereby reducing the risk of injury to the upper body and head of the front seat occupants considerably.


### Warning

Optimum protection is only provided when the seat is in the proper position  37.

Keep the area in which the airbag inflates clear of obstructions.

Fit the seat belt correctly and engage securely. Only then the airbag is able to protect.

## Side airbag system



The side airbag system consists of an airbag in each front seat backrest. This can be identified by the word **AIRBAG**.

The side airbag system is triggered in the event of an accident of a certain severity. The ignition needs to be switched on.

The inflated airbags cushion the impact, thereby reducing the risk of injury to the upper body and pelvis in the event of a side-on collision considerably.

### Warning

Keep the area in which the airbag inflates clear of obstructions.

### Note

Only use protective seat covers that have been approved for the vehicle. Be careful not to cover the airbags.

## Airbag deactivation

Front airbag and side airbag systems for the front passenger seat have to be deactivated if a child restraint

system is to be fitted on this seat. The belt pretensioners and all driver airbag systems will remain active.



The front passenger airbag system can be deactivated via a switch on the side of the instrument panel.



With the front door open, push switch in and rotate anti-clockwise to the **OFF** position.

Front passenger seat airbags are deactivated and will not inflate in the event of a collision. Control indicator  illuminates continuously alongside the information display or on the instrument panel and a corresponding message appears in the Driver Information Centre.

A child restraint system can be installed in accordance with the installation locations chart ⇨ 51. An adult must not occupy the front passenger seat.

**⚠ Danger**

Risk of fatal injury for a child using a child restraint system together with activated front passenger airbag.

Risk of fatal injury for an adult person with deactivated front passenger airbag.

As long as control indicator  is not illuminated, the airbag systems for the front passenger seat will inflate in the event of a collision.

If control indicator  remains illuminated together with , this indicates a fault within the system. Seek the assistance of a workshop.

Change status only when the vehicle is stopped with the ignition off. Status remains until the next change.

Control indicator for airbag deactivation  76.

**Child restraints****Child restraint systems**

We recommend the Opel child restraint system which is tailored specifically to the vehicle.

When a child restraint system is being used, pay attention to the following usage and installation instructions and also those supplied with the child restraint system.

Always comply with local or national regulations. In some countries, the use of child restraint systems is forbidden on certain seats.

**⚠ Warning**

When using a child restraint system on the front passenger seat, the airbag systems for the front passenger seat must be deactivated; if not, the triggering of the airbags poses a risk of fatal injury to the child.

This is especially the case if rear-facing child restraint systems are used on the front passenger seat.

Airbag deactivation  48.

**Selecting the right system**

The rear seats are the most convenient location to fasten a child restraint system.

Children should travel facing rearwards in the vehicle as long as possible. This makes sure that the child's backbone, which is still very weak, is under less strain in the event of an accident.

Suitable are restraint systems that comply with ECE 44-03 or ECE 44-04. Check local laws and regulations for mandatory use of child restraint systems.

Ensure that the child restraint system to be installed is compatible with the vehicle type.

Ensure that the mounting location of the child restraint system within the vehicle is correct.

Allow children to enter and exit the vehicle only on the side facing away from the traffic.

When the child restraint system is not in use, secure the seat with a seat belt or remove it from the vehicle.

**Note**

Do not stick anything on the child restraint systems and do not cover them with any other materials.

A child restraint system which has been subjected to stress in an accident must be replaced.

## Child restraint installation locations

### Permissible options for fitting a child restraint system

#### Front seats - All variants

| Weight and age class                                         | Single seat - front passenger side <sup>1)</sup> |                 | Bench seat - front passenger side |                         |                       |                      |
|--------------------------------------------------------------|--------------------------------------------------|-----------------|-----------------------------------|-------------------------|-----------------------|----------------------|
|                                                              | without airbag                                   | with airbag     | without airbag<br>centre          | without airbag<br>outer | with airbag<br>centre | with airbag<br>outer |
| <b>Group 0: up to 10 kg</b><br>or approx. 10 months          | U                                                | U <sup>2)</sup> | U                                 | U                       | U <sup>2)</sup>       | U <sup>2)</sup>      |
| <b>Group 0+: up to 13 kg</b><br>or approx. 2 years           |                                                  |                 |                                   |                         |                       |                      |
| <b>Group I: 9 to 18 kg</b><br>or approx. 8 months to 4 years | U                                                | U <sup>2)</sup> | U                                 | U                       | U <sup>2)</sup>       | U <sup>2)</sup>      |
| <b>Group II: 15 to 25 kg</b><br>or approx. 3 to 7 years      | U                                                | U <sup>2)</sup> | U                                 | U                       | U <sup>2)</sup>       | U <sup>2)</sup>      |
| <b>Group III: 22 to 36 kg</b><br>or approx. 6 to 12 years    |                                                  |                 |                                   |                         |                       |                      |

<sup>1)</sup> If adjustable, ensure seat is in its rearmost position. Make sure vehicle seat belt is as straight as possible between shoulder and upper anchorage point.

<sup>2)</sup> Ensure the front passenger airbag system is deactivated when installing a child restraint in this position.

| Crew cab - rear seats                                 |               |        |
|-------------------------------------------------------|---------------|--------|
| Weight and age class                                  | 2nd row seats |        |
|                                                       | Outer         | Centre |
| Group 0: up to 10 kg<br>or approx. 10 months          | U             | X      |
| Group 0+: up to 13 kg<br>or approx. 2 years           |               |        |
| Group I: 9 to 18 kg<br>or approx. 8 months to 4 years | U             | X      |
| Group II: 15 to 25 kg<br>or approx. 3 to 7 years      | U             | X      |
| Group III: 22 to 36 kg<br>or approx. 6 to 12 years    |               |        |

**Combi - rear seats**

| Weight and age class                                         | 2nd row seats             |                      |                              | 3rd row seats |
|--------------------------------------------------------------|---------------------------|----------------------|------------------------------|---------------|
|                                                              | Driver side<br>outer seat | Centre seat          | Passenger side<br>outer seat |               |
| <b>Group 0: up to 10 kg</b><br>or approx. 10 months          | U <sup>3)</sup> , +       | X                    | X                            | X             |
| <b>Group 0+: up to 13 kg</b><br>or approx. 2 years           |                           |                      |                              |               |
| <b>Group I: 9 to 18 kg</b><br>or approx. 8 months to 4 years | U <sup>4)</sup> , +       | UF <sup>4)</sup> , + | UF <sup>4)</sup>             | X             |
| <b>Group II: 15 to 25 kg</b><br>or approx. 3 to 7 years      | U <sup>4)</sup>           | UF <sup>4)</sup>     | UF <sup>4)</sup>             | X             |
| <b>Group III: 22 to 36 kg</b><br>or approx. 6 to 12 years    |                           |                      |                              |               |

<sup>3)</sup> Move the front seat as far forward as possible to install a rear facing child seat, then move back the seat in front in accordance with the child seat instructions.

<sup>4)</sup> Forward facing child seat; position the seatback of the child seat in contact with the seatback of the vehicle seat. Adjust the height of the headrest or remove it if necessary; do not push the seat in front of the child more than halfway back on its runners and do not recline the seatback more than 25°.

**Bus - rear seats****Weight and age class****Rear seats****Group 0: up to 10 kg**

or approx. 10 months

X

**Group 0+: up to 13 kg**

or approx. 2 years

**Group I: 9 to 18 kg**

or approx. 8 months to 4 years

X

**Group II: 15 to 25 kg**

or approx. 3 to 7 years

X

**Group III: 22 to 36 kg**

or approx. 6 to 12 years

U = Suitable for universal category restraint systems for use in this weight and age class, in conjunction with three-point seat belt.

UF = Suitable for universal category forward-facing restraint systems for use in this weight and age class, in conjunction with three-point seat belt.

⊕ = Suitable for ISOFIX child restraint system with mounting brackets and anchorage points, where fitted. When mounting an ISOFIX child restraint system, only systems that have been approved for the vehicle may be used. Refer to "Permissible options for fitting an ISOFIX child restraint system".

X = Seat position not suitable for children in this weight and age class.

# Permissible options for fitting an ISOFIX child restraint system

## Combi

| Weight class          | Size class | Fixture | Front seats | 2nd row seats             |             | 3rd row seats                |   |
|-----------------------|------------|---------|-------------|---------------------------|-------------|------------------------------|---|
|                       |            |         |             | Driver side<br>outer seat | Centre seat | Passenger side<br>outer seat |   |
| Group 0: up to 10 kg  | E          | ISO/R1  | X           | IL                        | X           | X                            | X |
| Group 0+: up to 13 kg | E          | ISO/R1  | X           | IL                        | X           | X                            | X |
|                       | D          | ISO/R2  | X           | IL                        | X           | X                            | X |
|                       | C          | ISO/R3  | X           | IL                        | X           | X                            | X |
| Group I: 9 to 18 kg   | D          | ISO/R2  | X           | IL                        | X           | X                            | X |
|                       | C          | ISO/R3  | X           | IL                        | X           | X                            | X |
|                       | B          | ISO/F2  | X           | IL, IUF                   | IL, IUF     | X                            | X |
|                       | B1         | ISO/F2X | X           | IL, IUF                   | IL, IUF     | X                            | X |
|                       | A          | ISO/F3  | X           | IL, IUF                   | IL, IUF     | X                            | X |

IL = Suitable for particular ISOFIX restraint systems of the 'specific-vehicle', 'restricted' or 'semi-universal' categories.  
The ISOFIX restraint system must be approved for the specific vehicle type.


IUF = Suitable for ISOFIX forward-facing child restraint systems of universal category approved for use in this weight class.

X = No ISOFIX child restraint system approved in this weight class.

**ISOFIX size class and seat device**

- A - ISO/F3 = Forward-facing child restraint system for children of maximum size in the weight class 9 to 18 kg.
- B - ISO/F2 = Forward-facing child restraint system for smaller children in the weight class 9 to 18 kg.
- B1 - ISO/F2X = Forward-facing child restraint system for smaller children in the weight class 9 to 18 kg.
- C - ISO/R3 = Rear-facing child restraint system for children of maximum size in the weight class up to 13 kg.
- D - ISO/R2 = Rear-facing child restraint system for smaller children in the weight class up to 13 kg.
- E - ISO/R1 = Rear-facing child restraint system for young children in the weight class up to 13 kg.

## ISOFIX child restraint systems




Fasten vehicle-approved ISOFIX child restraint systems to the ISOFIX mounting brackets.

When using ISOFIX mounting brackets for seat mounting, universally approved child restraint systems for ISOFIX may be used.

Permissible mounting locations for ISOFIX child restraint systems are marked in the tables by **+**, IL and IUF.

## Top-tether fastening eyes

Top-Tether fastening eyes are located on the back of the seat.



In addition to the ISOFIX mounting, fasten the Top-Tether strap to the Top-Tether fastening eyes. The strap must run between the two guide rods of the head restraint.

ISOFIX child restraint systems of universal category positions are marked in the table by IUF.

## Storage

|                            |    |
|----------------------------|----|
| Storage compartments ..... | 58 |
| Load compartment .....     | 61 |
| Roof rack system .....     | 64 |
| Loading information .....  | 64 |

## Storage compartments

### ⚠ Warning

Do not store heavy or sharp objects in the storage compartments. Otherwise, the storage compartment lid could open and vehicle occupants could be injured by objects being thrown around in the event of hard braking, a sudden change in direction or an accident.

## Instrument panel storage



Storage compartments, pockets and trays are located in the instrument panel.

A phone holder and/or a coin holder with a clip for holding tickets is located on the top of the instrument panel.

The tray located centrally on top of the instrument panel has a lid.

## Document holder



Withdraw the document holder from the instrument panel by pulling the base towards you and then swivelling it downwards.

To fold away, raise the base until the document holder is horizontal, then push fully in.

## Glovebox



The glovebox should be closed whilst driving.

Glovebox cooler ⇨ 102.

## Cupholders

Cupholders are located at either end of the instrument panel and centrally in the lower instrument panel.


The cupholders can also be used to hold the portable ashtray unit ⇨ 70.

## Front storage

Three coat hooks are located on the cabin bulkhead

The front door pockets contain bottle holders.


## Folding passenger seatback



The passenger seat backrest, when folded fully forwards, features storage compartments and drink holders.

The swivelling shelf, which can be used for writing or documents, must be returned to its original position before raising the seat backrest.

## Sunglasses storage



Fold down to open.


Do not use for storing heavy objects.

## Overhead console



The total weight in these compartments must not exceed 5 kg.

## Underseat storage



Using the two loops on the passenger seat cushion, pull the cushion forwards to gain access to the storage under the seat.

## Overcab storage



The total weight in this compartment must not exceed 35 kg.

## Rear storage


### Bus

Objects can be stored in the overhead storage racks above the rear passenger seating.

The total weight in each storage rack must not exceed 35 kg.

## Load compartment


### Lashing eyes



Lashing eyes are mounted in the load compartment to enable cargo to be secured in position using lashing straps or a luggage floor net.

The maximum force applied to the lashing eyes should not exceed 5000 N at 30°.

### Removable lashing eyes




To reposition, press down on the centre cap and slide to the desired position. Ensure the lashing eye engages correctly in the recess.

Loading information ⇨ 64.


## Cargo management system

### Moveable partition wall

The moveable partition wall can be used between the floor and roof rails.




To move, pull down on the latch to release and position the wall as required. Ensure the latch engages fully and the partition wall is upright.



Store the partition wall to one side of the load compartment when not in use.

### Telescopic blocking bars



The telescope blocking bars can be used in a vertical or horizontal position.

Ensure the blocking bars are fully engaged in the load rails before loading.

To release, press down on the lock and slide the bar at the same time.


Maximum loading 100 daN/700mm.

### Ratchet straps

Using the appropriate ratchet straps, objects can be secured to the removable lashing eyes in the side or floor load rails.



The maximum loading for the floor rails is 500 daN/700mm.



The maximum loading for the side rails is 100 daN/700mm.

Removable lashing eyes ⇨ 61,  
Loading information ⇨ 64.

## Safety net



Lower the safety net from the roof area and attach to the lashing eyes ⇨ 61.

Adjust the tension on the straps to ensure the load is secure.

When not in use the safety net should be stored in the roof area.

Loading information ⇨ 64.

## Warning triangle

The warning triangle can be accommodated in the space under the front seats.

Underseat storage ⇨ 60.

## First aid kit

The first aid kit can be accommodated in the space under the front seats or in the overhead console.

A label is located on the overhead console should the first aid kit be stored there.

Underseat storage ⇨ 60.


Overhead console ⇨ 60.

## Fire extinguisher

The fire extinguisher can be accommodated in the space under the front seats.



Using the two loops on the seat cushion, pull the cushion forwards to gain access.



An additional extinguisher may be located in the front door panel.

As a visible indication of this, a label is located on the overhead console.

## Roof rack system

### Roof rack

For safety reasons and to avoid damage to the roof, the vehicle approved roof rack system is recommended.

Follow the installation instructions and remove the roof rack when not in use.

## Loading information

- Heavy objects in the load compartment should be evenly distributed and placed as far forward as possible. If objects can be stacked, the heavier objects should be placed at the bottom.
- Secure objects with lashing straps attached to lashing eyes ➤ 61.
- Secure loose objects in load compartment to prevent sliding.
- The load must not obstruct the operation of the pedals, parking brake and gear selector, or hinder the freedom of movement of the driver. Do not place any unsecured objects in the interior.
- Do not drive with an open load compartment. In addition, the number plate is only distinguishable and illuminated correctly if the doors are closed.
- The payload is the difference between the permitted gross vehicle weight (see identification

plate ⇨ 166) and the EC kerb weight.

To calculate the EC kerb weight, enter the data for your vehicle in the Weights table at the front of this manual.

The EC kerb weight includes weights for the driver (68 kg), luggage (7 kg) and all fluids (tank 90% full).

Optional equipment and accessories increase the kerb weight.

- Driving with a roof load increases the sensitivity of the vehicle to cross-winds and has a detrimental effect on vehicle handling due to the vehicle's higher centre of gravity. Distribute the load evenly and secure it properly with retaining straps. Adjust the tyre pressure and vehicle speed according to the load conditions. Check and retighten the straps frequently.

Do not drive faster than 120 km/h.


- The permissible roof load (which includes the weight of the roof rack) is 200 kg for standard roof variants. The roof load is the combined weight of the roof rack and the load.

## Instruments and controls

|                                             |    |
|---------------------------------------------|----|
| Controls .....                              | 66 |
| Warning lights, gauges and indicators ..... | 71 |
| Information displays .....                  | 80 |
| Vehicle messages .....                      | 81 |
| Trip computer .....                         | 82 |
| Tachograph .....                            | 84 |

## Controls

### Steering wheel adjustment



Unlock lever, adjust steering wheel, then engage lever and ensure it is fully locked.

Do not adjust steering wheel unless vehicle is stationary and steering wheel lock has been released.

## Steering wheel controls



The cruise control and speed limiter can be operated via the controls on the steering wheel.

Cruise control and speed limiter  
➡ 118.

## Horn



Press .

The horn will sound regardless of ignition switch position.


## Steering column controls

The Infotainment system can also be operated via the controls on the steering column.

Further information is available in the Infotainment system manual.

## Windscreen wiper/washer


### Windscreen wiper



-  = timed interval wipe  
1 = slow  
2 = fast

Do not use if the windscreen is frozen.  
Switch off in car washes.

### Automatic wiping with rain sensor



 = Automatic wiping with rain sensor

The rain sensor detects the amount of water on the windscreen and automatically regulates the frequency of the windscreen wipers.

Automatic wiping will need to be reselected whenever the ignition has been switched off.

### Adjustable sensitivity of the rain sensor


Turn the adjuster wheel to adjust the sensitivity:

- Low sensitivity = turn adjuster wheel downwards
- High sensitivity = turn adjuster wheel upwards



Keep the sensor free from dust, dirt and ice.


### Windscreen washer



Pull lever. Washer fluid is sprayed onto the windscreen.

- short pull = wiper swipes once
- long pull = wiper swipes for a few strokes

### Outside temperature



A drop in temperature is indicated immediately and a rise in temperature after a time delay.

If outside temperatures drop to 3 °C, the °C flashes in the information display as a warning for icy road conditions. This will continue to flash until temperatures rise above 3 °C.

**⚠ Warning**

The road surface may already be icy even though the display indicates a few degrees above 0 °C.

**Clock**

Depending on vehicle, the current time and/or date may appear in the information display ↗ 81 or the Driver Information Centre ↗ 80.

**Set time and date in information display**

8:56 5.5°C  
07.04.2008

20003

Hours and minutes can be adjusted by pressing the appropriate buttons by the display or with the Infotainment system controls.

Further information is available in the Infotainment system manual.

**Set time in Driver Information Centre**

Display the clock function by pressing either button repeatedly on the end of the wiper lever. When the time flashes (after approx. 2 seconds):

- Press and hold the bottom button
- Hours flash

- Press top button to change hours
- Press and hold bottom button to set hours
- Minutes flash
- Press top button to change minutes
- Press and hold bottom button to set minutes and exit setting mode.

**Power outlets**

12 V power outlets are located in the instrument panel and in the rear of the vehicle.



Connecting electrical accessories while the engine is off will discharge the battery. Do not exceed the maximum power consumption of 120 watts. Do not connect any current-delivering accessories, e.g. electrical charging devices or batteries.

Electrical accessories that are connected must comply with the electromagnetic compatibility requirements laid down in DIN VDE 40 839.

Do not connect any current-delivering accessories, e.g. electrical charging devices or batteries.

### Caution

Do not damage the outlet by using unsuitable plugs.

## Cigarette lighter




Press in cigarette lighter. It switches off automatically once the element is glowing. Pull out lighter.

## Ashtrays

### Caution

To be used only for ash and not for combustible rubbish.

## Portable ashtray



Ashtray container for mobile use in the vehicle. To use, open cover.

## Warning lights, gauges and indicators

### Speedometer



Indicates vehicle speed.

Maximum speed may be restricted by a speed regulator. As a visible indication of this, a warning label is located on the instrument panel.

A warning buzzer will sound for 10 seconds if the vehicle briefly exceeds the set limit.

#### Note

Under certain conditions (e.g. steep inclines) the vehicle speed may exceed the set limit.

### Odometer



Displays the recorded distance.

### Trip odometer

The trip odometer displays the distance travelled since the last reset.

Press either button once on the end of the windscreen wiper lever to display the trip odometer.

To reset, with the trip odometer displayed, press and hold either button for a few seconds with the ignition on. The display will flash and the value will reset to zero.

### Tachometer



Displays the engine speed.

Drive in a low engine speed range for each gear as much as possible.

### Caution

If the needle is in the red warning zone, the maximum permitted engine speed is exceeded. Engine at risk.

## Fuel gauge



Displays fuel level in the tank.

Control indicator  illuminates if the level in the tank is low. Refuel immediately ⇨ 124.

Never run the tank dry. Diesel fuel system, bleeding ⇨ 134.

Because of the fuel remaining in the tank, the top-up quantity may be less than the specified tank capacity.

## Engine coolant temperature gauge



Displays the coolant temperature.

- left area = engine operating temperature not yet reached
- central area = normal operating temperature
- right area = temperature too high

Control indicator  illuminates if the temperature is too high ⇨ 77, ⇨ 78.

### Caution

If engine coolant temperature is too high, stop vehicle, switch off engine. Danger to engine. Check coolant level.

For physical reasons, the coolant temperature gauge shows the coolant temperature only if the coolant level is adequate.

## Engine oil level monitor

The engine oil level monitor is correct only if the vehicle is parked on a level surface with a cold engine.

If the engine oil level is correct when the ignition is switched on **OIL LEVEL CORRECT** appears briefly in the Driver Information Centre.

If the engine oil is above the minimum level, press the trip computer button on the end of the wiper lever within 30 seconds of switching on the

ignition. The message **OIL LEVEL** is displayed in combination with the squares that correspond to the oil level.

As the oil level diminishes, the squares in the display are replaced with dashes.

- = Maximum level
- - - = Intermediate level
- - - - - = Minimum level

If the minimum engine oil level is reached **TOP-UP OIL LEVEL** is displayed in combination with control indicator ⚠ after the ignition is switched on for 30 seconds. Check and top up engine oil ↗ 130.

To exit the oil level monitor display, press either trip computer button. Trip computer ↗ 82.

## Service display

When the ignition is switched on, the remaining distance before the next service is due may be shown briefly in the Driver Information Centre. Based

on driving conditions, the interval at which a service will be indicated can vary considerably.

When the remaining distance before the next service is less than 3000 km or 2 months, **SERVICE IN** appears in the Driver Information Centre.

When the distance reaches 0 km or the service date is due, control indicators ⚠ and ⚠ illuminate in the instrument cluster and **SERVICE DUE** appears in the Driver Information Centre.

The vehicle needs a service. Seek the assistance of a workshop.

## Resetting the service display

After a service, the service display must be reset.

If available, select the distance before service display in the Driver Information Centre, then press and hold either button on the end of the wiper lever until the distance before service is displayed continuously.

Trip computer ↗ 82.

## Transmission display



The mode or selected gear of the manual transmission automated is shown in the transmission display.

- R** = Reverse gear
- N** = Neutral
- A** = Automatic mode
- kg** = Laden mode
- ⚠ = Winter mode
- ⚠ = Apply footbrake
- ⚠ = Transmission electronics

Manual transmission automated  
↗ 111.

## Control indicators

The control indicators described are not present in all vehicles. The description applies to all instrument versions. When the ignition is switched on, most control indicators will illuminate briefly as a functionality test.

The control indicator colours mean:


red = danger, important  
reminder

yellow = warning, information, fault

green = confirmation of activation

blue = confirmation of activation

## Control indicators in the instrument cluster



## Turn signal

↔ flashes green.

Flashes if a turn signal or the hazard warning flashers are activated.

Rapid flashing: failure of a turn signal light or associated fuse.

An audible warning can be heard when the turn signals are on. When towing a trailer, the pitch of the audible warning changes.

Bulb replacement ⇨ 135.

Fuses ⇨ 143.

Turn signals ⇨ 87.

## Seat belt reminder

🚗 illuminates in red.

If the seat belt is not fastened, 🚗 will flash when vehicle speed exceeds approx. 16 km/h. An audible warning also sounds for approx. 90 seconds.

### ⚠ Warning

Fasten seat belt before each trip. In the event of an accident, people not wearing seat belts endanger their fellow occupants and themselves.

## Airbag and belt tensioners

🚗 illuminates yellow.

When the ignition is switched on, the control indicator illuminates briefly. If it does not illuminate or illuminates whilst driving, there is a fault in the airbag or pretensioner system. The airbags and belt pretensioners may fail to trigger in the event of an accident.

### ⚠ Warning

Have the cause of the fault remedied immediately by a workshop.

Deployment of the belt pretensioners or airbags is indicated by continuous illumination of 🚗.

Belt pretensioners, airbag system ⇨ 44, ⇨ 46.

## Airbag deactivation

🚗 illuminates yellow when the ignition is switched on and remains illuminated when the front passenger airbag has been deactivated ⇨ 48.

If control indicator 🚗 is illuminated in conjunction with 🚗, seek the assistance of a workshop.

### ⚠ Danger

Risk of fatal injury for a child using a child restraint system together with activated front passenger airbag.

Risk of fatal injury for an adult person with deactivated front passenger airbag.

Airbag system ⇨ 46, belt tensioners ⇨ 44, airbag deactivation ⇨ 48.

## Charging system

 illuminates red.

Illuminates when the ignition is switched on and extinguishes shortly after the engine starts.

### Illuminates when the engine is running

Stop, switch off engine. Battery is not charging. Engine cooling may be interrupted. Power to the brake servo unit may be cut. Seek the assistance of a workshop.

## Malfunction indicator light

 illuminates or flashes yellow.

Illuminates when the ignition is switched on and extinguishes shortly after the engine starts.

### Illuminates when the engine is running

Fault in the emission control system. The permitted emission limits may be exceeded. Seek the assistance of a workshop immediately.

## Flashes when the engine is running

Fault that could lead to catalytic converter damage. Ease up on the accelerator until the flashing stops. Seek the immediate assistance of a workshop.

## Service vehicle soon

 illuminates yellow.

Illuminates when the ignition is switched on and extinguishes shortly after the engine starts.

May illuminate in combination with another control indicator or a message in the Driver Information Centre. Seek the assistance of a workshop immediately.

## Stop engine

 illuminates red.

Illuminates for a few seconds when the ignition is switched on.

If  illuminates in combination with  or , stop engine immediately and seek the assistance of a workshop.

Depending on the type of fault, a warning message may also appear in the Driver Information Centre.

## Brake system

 illuminates red.

Illuminates when the parking brake is released if the brake fluid level is too low ⇨ 132.

### Warning

Stop. Do not continue your journey. Consult a workshop.

Illuminates after the ignition is switched on if the parking brake is applied ⇨ 115.

Brake system ⇨ 114.

## Brake pad wear

 illuminates yellow.

Illuminates when the brake pads are worn ⇨ 114.

Seek the assistance of a workshop.

## Antilock brake system (ABS)

 illuminates yellow.

Illuminates briefly after the ignition is switched on. The system is ready for operation when  extinguishes.

If control indicators  and  illuminate with the messages **CHECK ABS** and **CHECK ESP** in the Driver Information Centre, there is a fault in the ABS. The brake system remains operational but without ABS regulation.

If control indicators , ,  and  illuminate, the ABS and ESP are deactivated and the message **BRAKING FAULT** is displayed. Seek the assistance of a workshop.

Antilock brake system ⇨ 115.

## Upshift

 or  illuminates yellow.

Illuminates when gearshifting is recommended to improve fuel economy.

## Electronic Stability Program

 flashes or illuminates yellow.

Illuminates for a few seconds when the ignition is switched on.

### Flashing during driving

The system is actively engaged. Engine output may be reduced and the vehicle may be braked automatically to a small degree ⇨ 117.

### Illuminates during driving

The system is switched off. The message **ESP OFF** will also appear in the Driver Information Centre.

ESP®<sup>Plus</sup> ⇨ 117.

## Engine coolant temperature

 illuminates red.

**Illuminates when the engine is running**

Stop, switch off engine.

### Caution

Coolant temperature too high.

Check coolant level ⇨ 131.

If there is sufficient coolant, consult a workshop.

## Preheating

 illuminates yellow.

Preheating is activated. Only activates when outside temperature is low.

## Engine oil pressure

 illuminates red.

Illuminates when the ignition is switched on and extinguishes shortly after the engine starts.

## Illuminates when the engine is running

### Caution

Engine lubrication may be interrupted. This may result in damage to the engine and/or locking of the drive wheels.

1. Depress clutch.
2. Select neutral gear, set selector lever to **N**.
3. Move out of the flow of traffic as quickly as possible without impeding other vehicles.
4. Switch off ignition.

### ⚠ Warning

When the engine is off, considerably more force is needed to brake and steer.

Do not remove key until vehicle is stationary, otherwise the steering wheel lock could engage unexpectedly.

Check oil level before seeking assistance of a workshop ⇨ 130.

## Low fuel

 illuminates yellow.

Illuminates when level in fuel tank is too low.

Catalytic converter ⇨ 109.

Bleeding the diesel fuel system ⇨ 134.

## Drain fuel filter

 illuminates yellow.

Illuminates when the ignition is switched on and extinguishes shortly after the engine starts.

## Illuminates when the engine is running

Indicates the presence of water in the diesel. Seek the assistance of a workshop immediately.

## Stop-start system

Ⓐ illuminates or flashes yellow / green.

### Illuminates

Illuminates green during an Autostop.

If Ⓐ illuminates yellow there is a fault in the stop-start system. Seek the assistance of a workshop.

### Flashes

Flashes green during an automatic restart.

Stop-start system ⇨ 105.

## Exterior light

Ⓔ illuminates green.

Illuminated when the exterior lights are on ⇨ 85.

## High beam

Ⓔ illuminates blue.

Illuminated when high beam is on and during headlight flash ⇨ 86.

## Fog light

 illuminates green.

Illuminated when the front fog lights are on ⇨ 87.

## Rear fog light

 illuminates yellow.

Illuminated when the rear fog light is on ⇨ 88.

## Cruise control

,  illuminates green.

 illuminates green when a certain speed is stored.

 illuminates green when the system is on.

## Speed limiter

 illuminates yellow.

 illuminates yellow when the system is on.

Cruise control, Speed limiter ⇨ 118.

## Tachograph

T illuminates when there is a fault

⇨ 84.

## Door open

 illuminates red.

Illuminates when a door or the tailgate is open.

Vehicles with manual transmission automated; control indicator illuminates in transmission display indicating relevant open door.

## Information displays


### Driver Information Centre



Depending on vehicle configuration, the following items appear in the display:

- Outside temperature ⇨ 68
- Clock ⇨ 69
- Odometer, trip odometer ⇨ 71
- Engine oil level monitor ⇨ 72
- Service display ⇨ 73
- Vehicle messages ⇨ 81
- Trip computer ⇨ 82

## Triple-Info-Display



20003

Displays time, outside temperature and date when the ignition is on.

## Vehicle messages

Messages appear in the Driver Information Centre, in combination with control indicator  or STOP.

### Information messages

#### Information messages

---

BATTERY MODE: ECONOMY

ESP OFF

AUTO LIGHTS DEACTIVATED

OIL LEVEL CORRECT

### Fault messages

Displayed in combination with control indicator . Drive with caution and seek the assistance of a workshop.

To remove fault message, press either button on the end of the wiper lever. After a few seconds the message may disappear

automatically and  remains illuminated. The fault will then be stored in the on board system.

### Fault messages

---

CHECK ESP

CHECK FUEL FILTER

CHECK GEARBOX

CHECK AUTO LIGHTS

### Warning messages

These may appear with control indicator  or in combination with other warning messages, control indicators or an audible warning. Stop engine immediately and seek the assistance of a workshop.

### Warning messages

#### INJECTION FAULT

#### ENGINE OVERHEATING

#### GEARBOX OVERHEATING

## Warning chimes

### When starting the engine or whilst driving

- During operation of the turn and lane-change signals.
- If seat belt is not fastened.
- If a certain speed is exceeded with the parking brake applied.
- If the parking assist detects an object.
- If the vehicle has manual transmission automated and the clutch temperature is too high.
- In vehicles with manual transmission automated; when a door is open while neutral is not

selected. A corresponding message appears in the Driver Information Centre.

- If the vehicle speed briefly exceeds a set limit.
- During closing of the power sliding door.
- During activation and deactivation of alarm monitoring of vehicle inclination.

### When the vehicle is parked and/ or the driver's door is opened

- When the key is in the ignition switch.
- With exterior lights on.
- If the vehicle has manual transmission automated; neutral is not selected or the foot brake has not been depressed.

## Trip computer

The trip computer provides information on driving data, which is continually recorded and evaluated electronically.



Depending on vehicle, the following functions can be selected by pressing either button repeatedly on the end of the wiper lever:

- Fuel used
- Average consumption
- Instantaneous consumption
- Range

- Distance travelled
- Average speed
- Distance before service
- Clock
- Cruise control and speed limiter stored speed
- Fault and information messages

### Fuel used

Displays the amount of fuel consumed since the last reset.

The measurement can be restarted at any time by pressing and holding either button.

### Average consumption

The value is displayed after driving a distance of 400 metres.

Average consumption is displayed, taking into consideration the distance travelled and the fuel used since the last reset.

The measurement can be restarted at any time.

### Instantaneous consumption

The value is displayed after reaching a speed of 30 km/h.

### Range

The value is displayed after driving a distance of 400 metres.

The range is calculated from the current contents of the fuel tank and the average consumption since the last reset.

The range will not display if control indicator  is illuminated in the instrument cluster ➔ 79.

The measurement can be restarted at any time.

### Distance travelled

Displays the distance driven since the last reset.

The measurement can be restarted at any time.

### Average speed

The value is displayed after driving a distance of 400 metres.

The average speed since the last reset is displayed.

The measurement can be restarted at any time.

Interruptions in the journey with the ignition off are not included in the calculations.

### Reset trip computer information

To reset the trip computer, select one of its functions then press and hold either button on the end of the wiper lever.

The following trip computer information will be reset:

- Fuel used
- Average consumption
- Range
- Distance travelled
- Average speed

The trip computer will reset automatically when the maximum value of any of the parameters is exceeded.

**Interruption of power supply**

If the power supply has been interrupted or if the battery voltage has dropped too low, the values stored in the trip computer will be lost.

**Tachograph**

The tachograph is operated as described in the operating instructions supplied. Observe regulations regarding use.


Control indicator **T** illuminates in the instrument cluster in the event of a fault. Seek the assistance of a workshop.

## Lighting

|                         |    |
|-------------------------|----|
| Exterior lighting ..... | 85 |
| Interior lighting ..... | 88 |
| Lighting features ..... | 90 |

## Exterior lighting

### Light switch




Turn light switch:

|             |                           |
|-------------|---------------------------|
|             | = Off                     |
|             | = Sidelights              |
|             | = Headlights              |
| <b>AUTO</b> | = Automatic light control |
|             | = Front fog lights        |
|             | = Rear fog lights         |

High beam control indicator 79.

Low beam control indicator 79.

## Automatic light control



When the automatic light control function is switched on and the engine is running, the system switches between daytime running lights (where fitted) and headlights, depending on the lighting conditions.

For reasons of safety, the light switch should always remain in the **AUTO** position.

### Daytime running lights


Daytime running lights increase visibility of the vehicle during daylight.

The lights operate automatically when the ignition is switched on.

### Automatic headlight activation

During poor lighting conditions the headlights are switched on.

### High beam



To change between low and high beam, pull lever until a click is felt.

### Headlight flash

To activate the headlight flash, pull lever.

## Headlight range adjustment

### Manual headlight range adjustment



Adapt the headlight range to suit the vehicle load to prevent dazzling of oncoming traffic.

Turn knurled wheel to required position:

- 0 = Front seat occupied
- 4 = Loaded up to permissible maximum weight

## Headlights when driving abroad

The asymmetrical headlight beam extends visibility at the edge of the road at the passenger side.

However, when driving in countries where traffic drives on the opposite side of the road, adjust the headlights to prevent dazzling of oncoming traffic.

Have the headlights adjusted by a workshop.

## Adaptive forward lighting

### Cornering light


Depending on the steering angle, vehicle speed and gear selected when cornering, an additional light will illuminate the corner of the road.

## Hazard warning flashers



Operated with the  button.

## Turn and lane-change signals




Lever up = right turn signal  
Lever down = left turn signal

When the steering wheel is turned back, the lever automatically returns to its original position and the indicator is deactivated. This will not happen when making a minor steering manoeuvre such as lane changing.

When lane changing, move lever part way to first stop. When released, lever will spring back.

If the lever is moved past the first stop, the indicator is switched on constantly. Switch the indicator off manually by moving the lever to its original position.


## Front fog lights



Turn inner switch to position  and release.

Front fog lights will only operate when the ignition and headlights are switched on.

## Rear fog lights



Turn inner switch to position  and release.

Rear fog lights will only operate when the ignition and headlights are switched on.

## Reversing lights

The reversing lights come on when the ignition is on and reverse gear is selected.

## Misted light covers

The inside of the light covers may mist up briefly in poor, wet and cold weather conditions, in heavy rain or after washing. The mist disappears quickly by itself; to help, switch on the headlights.

## Interior lighting

### Interior lights

With the switch in its central position, the light functions as a courtesy light and illuminates when the front doors are opened.

When the front doors are closed, the courtesy light extinguishes after a delay.

### Front courtesy light



Operated with the  button.

The courtesy light extinguishes immediately when the ignition is switched on.

## Rear courtesy lights

### Bus

Low level and overhead courtesy lights are located in the rear passenger compartment.



Operate rocker switch on the instrument panel:

Press  = on

Press **OFF** = off

## Load compartment lighting

Load compartment lighting can be set to illuminate when the side and rear doors are opened, or switched on constantly.



Operated by pressing the switch:

- On constantly
- Controlled by the function of the interior light
- Off constantly

When the doors are closed, the courtesy light extinguishes after a delay or immediately after the ignition is switched on.

## Reading lights

### Front reading light



Operated with the  button.

The reading light can be directed as required.

## Rear reading lights

### Bus



Operate rocker switch on the instrument panel:


press  = on.  
press **OFF** = off.



Each reading light can then be operated individually and directed as required.

## Lighting features

### Exit lighting



Headlights come on for approx. 1 minute after the vehicle is parked and the system is activated.

### Activating

1. Switch off ignition.
2. Remove ignition key.
3. Pull turn signal lever towards steering wheel.

---

This action can be repeated up to four times to a maximum period of 4 minutes.

The lighting is turned off immediately by turning the light switch to any position and returning to **O**.

## Climate control

|                               |     |
|-------------------------------|-----|
| Climate control systems ..... | 92  |
| Air vents .....               | 101 |
| Maintenance .....             | 102 |

## Climate control systems

### Heating and ventilation system



Controls for:

- Temperature
- Fan speed
- Air distribution

Heated rear window  → 34.

### Temperature

red = warm  
blue = cold

Heating will not be fully effective until the engine has reached normal operating temperature.

### Fan speed

Adjust the air flow by switching the fan to the desired speed.

### Air distribution

-  = to head area
-  = to head area and foot well
-  = to foot well
-  = to windscreen, front door windows and foot well
-  = to windscreen and front door windows

Intermediate settings are possible.

### Demisting and defrosting the windows

- Set temperature control to warmest level.
- Set fan speed to highest level.
- Set air distribution control to .
- Switch on heated rear window .

- Open side air vents as required and direct them towards door windows.
- For simultaneous warming of the foot well, set air distribution control to .

## Air conditioning system



Additional to the heating and ventilation system, the air conditioning system has:

**AC** = cooling

 = air recirculation

## Cooling (AC)

Operated with the **AC** button and functional only when the engine and fan are running.

The air conditioning system cools and dehumidifies (dries) the air when outside temperature is a little above the freezing point. Therefore condensation may form and drip from under the vehicle.

If no cooling or drying is required, switch the cooling system off to save fuel.

### Note

If the climate control is set to maximal cooling while the ambient temperature is high, an Autostop may be inhibited until the requested temperature in the passenger compartment has been reached.

If the climate control is set to maximal cooling while the engine is in an Autostop, the engine may restart automatically.

Stop-start system ⇨ 105.

## Air recirculation system

Operated with the  button.

### Warning

The exchange of fresh air is reduced in air recirculation mode. In operation without cooling the air humidity increases, so the windows may mist up. The quality of the passenger compartment air deteriorates, which may cause the vehicle occupants to feel drowsy.

## Maximum cooling

Briefly open the windows so that hot air can disperse quickly.

- Cooling **AC** on.
- Air recirculation system  on.
- Set air distribution control to .
- Set temperature control to coldest level.
- Set fan speed to highest level.
- Open all air vents.

## Electronic climate control system



Controls for:

- Temperature
- Air distribution and menu selection
- Fan speed

**AUTO** = Automatic mode

☉ = air recirculation

☼☼☼ = demisting and defrosting

Heated rear window ☼☼☼ ⇨ 34.

The preselected temperature is automatically regulated. In the automatic mode the fan speed and air distribution automatically regulate the air flow.

The system can be manually adapted by use of air distribution and air flow controls.

The electronic climate control system is only fully operational when the engine is running.

For correct operation do not cover the sensor on the instrument panel.

### Automatic mode

Basic setting for maximum comfort:

- Press **AUTO** button.
- Open all air vents.
- **AC** on.
- Set desired temperature.

### Temperature preselection

Temperatures can be set to the desired value.

For reasons of comfort, change temperature only in small increments.

red = warm

blue = cold

Heating will not be fully effective until the engine has reached normal operating temperature.

If the minimum temperature of 15 °C is set, the electronic climate control system runs at maximum cooling.

If the maximum temperature of 27 °C is set, the electronic climate control system runs at maximum heating.

### Fan speed

The selected fan speed is indicated with ☼ in the display.

If the fan is switched off the air conditioning is also deactivated.

To return to automatic mode: Press **AUTO** button.

### Demisting and defrosting the windows

Press the ☼☼☼ button.

Temperature and air distribution are set automatically and the fan runs at a high speed.

To return to automatic mode: press button  or **AUTO**.

### Air distribution

Press  or  repeatedly.

Arrows shown in the display indicate the distribution settings.

### Cooling

The air conditioning system cools and dehumidifies (dries) when outside temperature is above a specific level. Therefore condensation may form and drip from under the vehicle.

If no cooling or drying is required press **AC OFF** to switch the cooling system off, thus saving fuel.

### Manual air recirculation mode

Operated with the  button.

#### Warning

The exchange of fresh air is reduced in air recirculation mode. In operation without cooling the air humidity increases, so the windows may mist up. The quality

of the passenger compartment air deteriorates, which may cause the vehicle occupants to feel drowsy.

### Rear heating system



If the engine is switched off, the rear compartment can be heated by the additional heating, through low level vents.

By programming values using the control panel, the user can adjust the time, day and temperature settings.

Heating will cease to operate if the vehicle fuel level drops too low.

During operation, power from the vehicle battery is used. For short journey times, check the battery regularly and recharge if necessary.

To ensure efficient performance, the low level air vents in the rear passenger compartment must not be obstructed.

#### Warning

Do not operate the system when refuelling, when dust or combustible vapours are present or in enclosed spaces (e.g. garage).

### Setting the time and day

Press button  until the time display flashes.

If the battery supply has been interrupted prior to its use press the  or  button briefly to make the time display flash.

Adjust the time using the  or  buttons.

The time is set when the displayed time stops flashing.

The display for the day will then flash: adjust the day using the ◀ or ▶ buttons.

The day is set when the display stops flashing.

The display will remain illuminated for approx. 15 seconds after the ignition is switched off.

### Operating the rear compartment additional heating

Press button  to operate heating.  will appear in the display to indicate that the heating is operating.

### Changing the period for which heating is operating

With the heating switched off (  extinguished in display), press ◀ button for briefly until the period for which heating is provided flashes in the display.

Use the ◀ or ▶ buttons to adjust the heating duration. The duration is set when the display extinguishes.

### Programming the heating mode

It is possible to store up to three programmes which allow the heating to be switched on.

Press **P** button the appropriate number of times to select the desired stored programme.

Press the ◀ or ▶ buttons briefly; the programming time flashes in the display.

Using the ◀ or ▶ buttons adjust to the desired time, then, as soon as the time display stops flashing, adjust the day using the ◀ or ▶ buttons.

The time and day are set when the display stops flashing.

### Recalling a programming mode

To activate a stored programme, press **P** button the appropriate number of times until the corresponding number appears on the display.

### Neutral position or no stored programme activated

Press **P** button until there is no stored programme number visible in the display.

### Adjusting the temperature

To adjust the temperature of the heating, turn the rotary knob located on the control panel.

|                     |                        |
|---------------------|------------------------|
| Turn clockwise      | = increase temperature |
| Turn anti-clockwise | = decrease temperature |

### Rear air conditioning system

The rear air conditioning system is actuated in conjunction with the front passenger compartment air conditioning system.

## Bus

### Rear air vents



Additional air conditioning is supplied to the rear passenger compartment via the overhead air vents.

### Fan speed



Adjust the air flow to select the desired speed.

turn clockwise = increase air flow  
turn anti-clockwise = decrease air flow

### Combi

Additional air conditioning is supplied to the rear passenger compartment via the air vents located above the driver and front passenger compartment.

With the front passenger compartment air conditioning system switched on, adjust the air flow to select the desired speed.

Ensure the air vents are open when in use, to prevent ice forming in the system due to lack of air movement.

## Auxiliary heater

### Coolant heater

The Eberspächer engine-independent, fuel-powered coolant heater provides rapid heating of the engine coolant to enable heating of the vehicle interior without the engine running.

#### Warning

Do not operate the system when refuelling, when dust or combustible vapours are present or in enclosed spaces (e.g. garage).

Before starting or programming the system to start, turn the vehicle's climate control system to heat and the air distribution to .

Switch off when not required. Heating stops automatically after the programmed runtime. It will also cease to operate if the vehicle fuel level drops too low.

During operation, power from the vehicle battery is used. The driving time should therefore be at least as long as the heating time. For short journey times, check the battery regularly and recharge if necessary.

To ensure efficient performance, briefly operate the auxiliary heater once a month.

### Control units

The timer or remote control unit turns the system on and off, and is used to programme specific departure times.

#### Timer



- |                                                                                                               |                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|---------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>1</b>                     | = Switches the control unit on/off and changes displayed information                                                                                                                                                                                                                                                                                                                                                                                                    |
| <b>2</b>  <b>Back button</b> | = Selects functions in the menu bar and adjusts values                                                                                                                                                                                                                                                                                                                                                                                                                  |
| <b>3</b> <b>Menu bar</b>                                                                                      | = Displays the selectable functions  ,  ,  ,  and  |
| <b>4</b>  <b>Next button</b> | = Selects functions in the menu bar and adjusts values                                                                                                                                                                                                                                                                                                                                                                                                                  |
| <b>5</b> <b>OK button</b>                                                                                     | = Confirms selection                                                                                                                                                                                                                                                                                                                                                                                                                                                    |

#### Remote control



The control buttons operate identically to the timer unit described previously.

To activate the remote control, press activation button  and release it when the menu bar appears in the display. The signal indicator and **SENd** appear briefly in the display, followed by the temperature.

### **⚠ Warning**

When refuelling, switch off the remote control unit as well as the heater!

To switch off, press and hold activation button  to prevent inadvertent operation.

The remote control has a maximum range of 600 metres. The range may be reduced due to environmental conditions and as the battery becomes weaker.



In addition to the remote control unit, the heating can also be switched on for 30 minutes, or off, using the button on the instrument panel.

### **Battery replacement**

Replace the battery when the range of the remote control is reduced or when the battery charge symbol flashes.

Open the cover using a coin and replace the battery (CR 2430 or equivalent), ensuring the new battery is correctly installed with the positive (+) side facing the positive terminals. Replace the cover securely.

Dispose of old batteries in accordance with environmental regulations.



Batteries do not belong in household waste. They must be disposed of at an appropriate recycling collection point.

### **Remote control fault displays**

|                  |                                   |
|------------------|-----------------------------------|
| <b>cobA</b>      | = Poor signal – adjust position   |
| <b>conP</b>      | = No signal – move closer         |
| <b>bALo</b>      | = Battery low – change battery    |
| <b>Err</b>       | = System error – consult workshop |
| <b>Add, AddE</b> | = System in learning mode         |

### **Teach remote control**

If the vehicle battery is reconnected, the LED in the instrument panel button illuminates and the system configures the remote control menu automatically. If the LED flashes, press **OK** button on remote control, select **Add** or **AddE** and confirm.

Additional remote control units may also be configured. Press the button until LED flashes, switch on the remote control, select **Add** and confirm.

**AddE** teaches the current remote control unit exclusively and blocks all previously configured units. **Add** teaches up to 4 remote control units, but only one unit can operate the system at any one time.

## Operation

### Heating

Select  in the menu bar and confirm. The predetermined heating duration, e.g. **L 30**, flashes in the display. The factory setting is 30 minutes.

To temporarily adjust the heating duration, adjust with the  or  button and confirm. The value can be set from 10 to 120 minutes. Due to the power consumption, note the heating duration.

To switch off, select  in the menu bar again and confirm.

### Ventilation

Select  in the menu bar and confirm.

The ventilation duration can be accepted or adjusted. The duration shown is accepted without confirmation.

To switch off, select  in the menu bar again and confirm.

### Programming P

Up to 3 preset departure times can be programmed, either during one day or over one week.

- Select **P** in the menu bar and confirm
- Select desired preset memory number **1**, **2** or **3** and confirm
- Select day and confirm
- Select hour and confirm
- Select minutes and confirm
- Select  or  and confirm
- If necessary, adjust the runtime duration prior to departure and confirm

The next preset memory number to be activated is underlined and the weekday is displayed. Repeat the procedure to programme the other preset memory numbers.

Pressing button  during the procedure will exit without storing programme adjustments.

To delete a preset departure time, follow the steps for programming until heating symbol  flashes. Press button  or  until **oFF** appears in the display and confirm.

Heating stops automatically 5 minutes after the programmed departure time.

### Note

The remote control system features a temperature sensor which calculates the runtime according to the ambient temperature and the desired heating level (ECO or HIGH). The system starts automatically between 5 and 60 minutes prior to the programmed departure time.

### Set weekday, time and heating duration

If the vehicle battery is disconnected or its voltage is too low, the unit will need to be reset.

- Select  and confirm
- Select weekday and confirm
- Change hours and confirm
- Change minutes and confirm
- Change the default heating duration and confirm

### Heating level

The preferred heating level for programmed departure times can be set to either ECO or HIGH.


Select  and confirm. ECO or HIGH flashes in the display. Adjust using the  or  button and confirm.

## Air vents

### Adjustable air vents

At least one air vent must be open while cooling is on in order to prevent the evaporator from icing up due to lack of air movement.

### Centre air vents




Press the vent to open.

Direct the flow of air by swivelling the vent.

Push vent to close.

### Side air vents



Press the vent to open.

Direct the flow of air by swivelling the vent.

Depending upon the position of the temperature control, air will be directed into the vehicle via the side air vents.

### Fixed air vents


Additional air vents are located beneath the windscreen and door windows and in the foot wells.

## Glovebox cooler

The air conditioning system can also keep the contents of the glovebox cool.

## Maintenance

### Air intake



The air intake in front of the windscreen in the engine compartment must be kept clear to allow air intake. Remove any leaves, dirt or snow.

### Pollen filter

The pollen filter cleans dust, soot, pollen and spores from the air entering the vehicle through the air intake.

## Air conditioning regular operation

In order to ensure continuously efficient performance, cooling must be operated for a few minutes once a month, irrespective of the weather and time of year. Operation with cooling is not possible when outside temperature is too low.

## Service

For optimal cooling performance, it is recommended that the climate control system be checked annually, starting three years after initial vehicle registration, including:

- Functionality and pressure test
- Heating functionality
- Leakage check
- Check of drive belts
- Cleaning of condenser and evaporator drainage
- Performance check

## Driving and operating

|                                          |     |
|------------------------------------------|-----|
| Driving hints .....                      | 103 |
| Starting and operating .....             | 103 |
| Engine exhaust .....                     | 109 |
| Manual transmission .....                | 110 |
| Manual transmission automa-<br>ted ..... | 111 |
| Brakes .....                             | 114 |
| Ride control systems .....               | 116 |
| Cruise control .....                     | 118 |
| Object detection systems .....           | 121 |
| Fuel .....                               | 123 |
| Towing .....                             | 125 |
| Auxiliary features .....                 | 127 |

## Driving hints

### Control of the vehicle

#### **Never coast with engine not running (except during Autostop)**

Many systems will not function in this situation (e.g. brake servo unit, power steering). Driving in this manner is a danger to yourself and others. All systems function during an Autostop, but there will be a controlled reduction in power steering assist and vehicle speed is reduced.

Stop-start system ⇨ 105.

#### **Pedals**

To ensure the pedal travel is uninhibited, there must be no mats in the area of the pedals.

#### **Power steering**

Never leave the steering wheel on full lock when the vehicle is stationary as this may damage the power steering pump.

## Starting and operating

### New vehicle running-in


Do not brake unnecessarily hard for the first few journeys and after new disc brake pads have been fitted.

During the first drive, smoke may occur because of wax and oil evaporating off the exhaust system. Park the vehicle in the open for a while after the first drive and avoid inhaling the fumes.

Do not drive the vehicle unnecessarily hard or at high engine speeds during the initial running-in period.


Fuel and engine oil consumption may be higher during the running-in period.

## Ignition switch positions



- St = Ignition off  
 A = Steering wheel lock released, ignition off  
 M = Ignition on, for diesel engine: preheating  
 D = Starting

## Starting the engine



Manual transmission: operate clutch.

Manual transmission automated: operate brake; transmission automatically shifts to N.

Do not accelerate.

Turn the key to position **M** for preheating, until control indicator  extinguishes from the Driver Information Centre.

Turn key to position **D** and release.

The increased engine speed automatically returns to normal idling speed as the engine temperature rises.

Start attempts should not last longer than 15 seconds. If engine does not start, wait 15 seconds before repeating starting procedure. If necessary, depress accelerator before repeating starting procedure.

Before restarting or to switch off the engine, turn key back to **St**.

## Idle speed control



To increase the idle speed press the switch. After a few seconds the function will be activated.

The function will be deactivated when:

- The clutch pedal is depressed
- The accelerator pedal is depressed
- MTA is not in neutral **N**
- Vehicle speed is above 0 km/h
- Control indicator ,  or **STOP** illuminate in the instrument cluster

To increase or decrease the fast idle speed rate, consult a workshop.

## Overrun cut-off

The fuel supply is automatically cut off during overrun, i.e. when the vehicle is driven with a gear engaged but accelerator is released.

## Stop-start system

The stop-start system helps to save fuel and to reduce the exhaust emission. When conditions allow, it switches off the engine as soon as the vehicle is at low speed or standstill, e.g. at a traffic light or in a traffic jam. It starts the engine automatically as soon as the clutch is depressed. A battery sensor ensures that an Autostop is only performed if the battery is sufficiently charged for a restart.

### Activation

The stop-start system is available as soon as the engine is started, the vehicle starts-off and the conditions as stated below in this section are fulfilled.

## Deactivation



Deactivate the stop-start system manually by pressing the stop-start  button. LED in the button illuminates when the system is deactivated.

### Autostop

If the vehicle is at low speed or standstill, activate an Autostop as follows:

- depress the clutch pedal
- shift the selector lever to **N**
- release the clutch pedal

The engine will be switched off while the ignition stays on if the required conditions are met.



An Autostop is indicated when (A) illuminates green in the instrument cluster.

During an Autostop, the brake performance will be maintained.

### Conditions for an Autostop

The stop-start system checks if each of the following conditions is fulfilled, otherwise an Autostop will be inhibited.

- The stop-start system is not manually deactivated
- the bonnet is fully closed
- the driver's door is closed or the driver's seat belt is fastened
- the battery is sufficiently charged and in good condition
- the engine is warmed up
- the engine coolant temperature is not too high
- the ambient temperature is not too low
- the defrosting function is not activated
- the climate control system does not inhibit an Autostop
- the brake vacuum is sufficient
- the vehicle has moved since the last Autostop
- the diesel particle filter self-cleaning function is in progress

An Autostop may be less available as the ambient temperature approaches freezing point.

Certain settings of the climate control system may inhibit an Autostop. See Climate control chapter for further information ⇨ 92.

Immediately after motorway driving an Autostop may be inhibited.

Autostop may also be inhibited temporarily if the battery has been recharged by an external source.

New vehicle running-in ⇨ 103.

### Battery discharge protection

To ensure reliable engine restarts, several battery discharge protection features are implemented as part of the stop-start system.

### Restart of the engine by the driver

Depress the clutch pedal to restart the engine. If the selector lever has been shifted out of **N** or other conditions are not met, start using the ignition key.

Control indicator (A) will extinguish in the instrument cluster when the engine restarts.

If the selector lever is shifted out of **N** before depressing the clutch first, a restart will not take place.

### Restart of the engine by the stop-start system

The selector lever has to be in **N** to enable an automatic restart.

If one of the following conditions occurs during an Autostop, the engine will be restarted automatically by the stop-start system. Control indicator (A) will flash green in the instrument cluster when the engine restarts automatically.

- The stop-start system is manually deactivated
- the engine temperature is too low
- the battery is discharged
- the brake vacuum is not sufficient
- the vehicle starts to move
- the defrosting function is activated
- the climate control system requests an engine start
- the predetermined timing has been exceeded

If an electrical accessory, e.g. a portable CD player, is connected to the power outlet, a brief power drop during restart might be noticeable.

If the Infotainment system is active, audio sound may briefly be reduced or broken during restart.

Warning chimes ⇨ 82.

### Parking

- Do not park the vehicle on an easily ignitable surface. The high temperature of the exhaust system could ignite the surface.
- Always apply parking brake without pressing release button. Apply as firmly as possible on a downhill or uphill slopes. Operate the foot brake at the same time to reduce operating force.
- Switch off the engine and ignition. Turn the steering wheel until the steering wheel lock is felt to engage.
- If the vehicle is on a level surface or uphill slope, engage first gear before switching off the ignition. On

an uphill slope, turn the front wheels away from the kerb.

If the vehicle is on a downhill slope, engage reverse gear before switching off the ignition. Turn the front wheels towards the kerb.

- Lock the vehicle and activate the anti-theft locking and anti-theft alarm systems.

### Air suspension

Operates automatically when the vehicle is driven. The air suspension system constantly adjusts the ride height according to the vehicle load.

For further information on the air suspension system, refer to the operating instructions supplied.

## Master switch

### Caution

The air suspension system must be switched off when the vehicle is being towed, jump-started, raised off the ground or transported.

Do not switch off the air suspension system when driving.



The master switch is located on the door pillar.

## Remote control



When increased ground clearance or improved vehicle access is required, the suspension can be raised or lowered using the remote control.

The remote control unit is magnetic and can be fixed to any metal part of the vehicle.

With the ignition switched on, press the appropriate button for 2 seconds to adjust the suspension height. Indicator light will flash intermittently while height adjustment is in progress and illuminates when complete.

Handle with care, protect from moisture and high temperatures and avoid unnecessary operation.

## Pre-programmed settings

Adjusts the suspension height to one of three pre-programmed positions. The buttons are only functional when the engine is running.

-  = lowered position
-  = normal position
-  = raised position

## Manual settings

Manual adjustment can only be performed when the vehicle is stationary.

Select by pressing button  for 2 seconds, then button  to raise, or button  to lower.

To exit, press any of the pre-programmed buttons.

When the vehicle is moving, manual adjustment will exit automatically. If the ignition is switched off, the vehicle will return to normal ride height when the ignition is switched back on.

## Service mode

Press button  for 5 seconds to put the vehicle into service mode. The indicator light will illuminate. When service mode has been activated, the air suspension master switch must be turned off.

To exit service mode, press button  again for 5 seconds.

## Fault

If a fault is detected,  button will flash intermittently. If the service mode has been activated and there is a fault ,  and  buttons will flash simultaneously.

Have the cause of the fault remedied by a workshop.

## Engine exhaust

### Danger

Engine exhaust gases contain poisonous carbon monoxide, which is colourless and odourless and could be fatal if inhaled.

If exhaust gases enter the interior of the vehicle, open the windows. Have the cause of the fault rectified by a workshop.

Avoid driving with an open load compartment, otherwise exhaust gases could enter the vehicle.

## Diesel particle filter

The diesel particle filter system filters harmful soot particles out of the exhaust gases. The system includes a self-cleaning function that runs automatically during driving without any notification. The filter is cleaned by periodically burning off the soot particles at high temperature. This

process takes place automatically and the emission of smells and smoke during this process is normal.

If cleaning of the filter is required and automatic cleaning does not occur, it will be indicated by the illumination of control indicator  in the instrument cluster. Seek the assistance of a workshop immediately.

## Catalytic converter

The catalytic converter reduces the amount of harmful substances in the exhaust gases.

### Caution

Fuel grades other than those listed on page ,  123,  168 could damage the catalytic converter or electronic components.

Unburnt petrol will overheat and damage the catalytic converter. Therefore avoid excessive use of the starter, running the fuel tank dry and starting the engine by pushing or towing.

In the event of misfiring, uneven engine running, a reduction in engine performance or other unusual problems, have the cause of the fault rectified by a workshop as soon as possible. In an emergency, driving can be continued for a short period, keeping vehicle speed and engine speed low.

If control indicator  flashes, the permitted emission limits may be exceeded. Lift your foot off the accelerator until  stops flashing and is steadily illuminated. Contact a workshop immediately.

Malfunction indicator light  77.

## Manual transmission



To engage reverse, with the vehicle stationary depress the clutch pedal, pull up the collar on the selector lever and engage the gear.

If the gear does not engage, set the lever in neutral, release the clutch pedal and depress again; then repeat gear selection.

Do not grind the clutch unnecessarily.

When operating, depress the clutch pedal completely. Do not use the pedal as a foot rest.

### Caution

It is inadvisable to drive with hand resting on the selector lever.

## Manual transmission automated

The manual transmission automated (MTA) permits manual (manual mode) or automatic gear shifting (automatic mode), both with automatic clutch control.

## Transmission display




Shows the mode and current gear.

## Starting the engine

Depress the foot brake when starting the engine. If the foot brake is not depressed,  illuminates in the transmission display and the engine cannot be started.

When the foot brake is depressed, the transmission automatically shifts to **N** (neutral); "N" appears in the transmission display and the engine can be started. There may be a slight delay.

## Selector lever



Always move the selector lever in the appropriate direction as far as it will go. Upon release, it automatically returns to the centre position.

**N** = Neutral.  
**A/** = Switch between automatic and manual mode.  
**M**

The transmission display shows "A" when in automatic mode.

**R** = Reverse gear.

Engage only when vehicle is stationary. The transmission display shows "R" when reverse gear is engaged.

**+** = Shift to a higher gear.

**-** = Shift to a lower gear.

## Starting off

When the engine is started, the transmission is in automatic mode. Depress the foot brake and move the selector lever towards **+** to engage first gear.

If **R** is selected, reverse gear is engaged. The vehicle starts to move when the foot brake is released. To

start off quickly, release the foot brake and accelerate immediately after engaging a gear.

In automatic mode the transmission shifts to other gears automatically, dependent on driving conditions.

To engage manual mode, move the selector lever towards **A/M**. The current gear will appear in the transmission display.

To engage first gear, depress foot brake and move selector lever towards **+** or **-**. Shift to a higher or lower gear by moving selector lever to **+** or **-**. Gears can be skipped by moving the selector lever repeatedly at short intervals.

### Stopping the vehicle

In automatic or manual mode, first gear is engaged and the clutch is released when the vehicle is stopped. In **R**, reverse gear remains engaged.

When stopping on gradients, engage parking brake or depress the foot brake. To prevent overheating of the clutch, an intermittent audible

warning may sound as a signal to depress the foot brake or apply the parking brake.

Switch off engine if stopping for a lengthy period, e.g. in traffic jams.

When the vehicle is parked and the driver's door is opened, a warning chime will sound if neutral is not selected or the foot brake has not been depressed.

### Engine braking

#### Automatic mode

When driving downhill, the manual transmission automated does not shift into higher gears until a fairly high engine speed has been reached. It shifts down in good time when braking.

#### Manual mode

To utilise the engine braking effect, select a lower gear in good time when driving downhill.

### Rocking the vehicle

Rocking the vehicle is only permissible if the vehicle is stuck in sand, mud, snow or a hole. Move the selector lever between **R** and **A/M** (or between **+** and **-**) in a repeat pattern, while applying light pressure to the accelerator pedal. Do not race the engine and avoid sudden acceleration.

### Parking

Apply the parking brake. The most recently engaged gear (see transmission display) remains engaged. With **N**, no gear is engaged.

When the ignition is switched off, the transmission no longer responds to movement of the selector lever.

If the ignition is not switched off, or the parking brake has not been applied, a warning chime will sound upon opening the driver's door.

## Manual mode

If a higher gear is selected when the engine speed is too low, or a lower gear when the speed is too high, the shift is not executed. This prevents the engine from running at too low or too high an engine speed.

If engine speed is too low, the transmission automatically shifts to a lower gear.

If engine speed is too high, the transmission only switches to a higher gear via kickdown.

## Electronic driving programmes

### Winter mode



Activate the Winter mode if you have problems starting off on a slippery road surface.

### Activation

Press the  button. Control indicator  is shown in the transmission display. The transmission switches to automatic mode and the vehicle starts off in a suitable gear.

### Deactivation

The Winter mode is switched off by:

- pressing the  button again,
- turning off the ignition,
- switching to manual mode.

In order to protect the transmission at extremely high clutch temperatures, an intermittent audible warning may sound. In such cases, depress the foot brake, select "N" and apply the parking brake to allow the clutch to cool down.

### Laden mode kg



It is possible to use the Laden mode in both manual and automatic modes. In both cases, the gearshifting patterns are adapted automatically for carrying an increased payload.

### Activation

Press the **kg** button. Control indicator **kg** is shown in the transmission display. The transmission will then select optimized gearshift patterns.

### Deactivation

The Laden mode is switched off by:

- pressing the **kg** button again,
- turning off the ignition.

### Kickdown

If the accelerator pedal is pressed past the pressure point, the transmission shifts to a lower gear depending on engine speed. Full engine power is available for acceleration.

If engine speed is too high the transmission switches to a higher gear, even in manual mode. Without kickdown this automatic shift is not effected in manual mode.

## Fault

In the event of a fault, control indicator  is shown in the transmission display. Continued driving is possible provided the vehicle is driven with care and anticipation.

Have the cause of the fault remedied by a workshop.

## Interruption of power supply

The clutch is not disengaged if there is an interruption of the power supply when a gear is engaged. The vehicle cannot move.

If the battery is discharged, start the vehicle using jump leads ⇨ 156.

If the cause of the fault is not a discharged battery, seek the assistance of a workshop.

If neutral cannot be selected, the vehicle must only be towed with the drive wheels raised off the ground ⇨ 158.

Towing the vehicle ⇨ 158.

## Brakes

The brake system comprises two independent brake circuits.

If a brake circuit fails, the vehicle can still be braked using the other brake circuit. However, braking effect is achieved only when you depress the brake pedal firmly. You need to use considerably more force for this. The braking distance is extended. Seek the assistance of a workshop before continuing your journey.

When the engine is not running, the support of the brake servo unit disappears once the brake pedal has been depressed once or twice. Braking effect is not reduced, but braking requires significantly greater force. It is especially important to bear this in mind when being towed.

Control indicator  ⇨ 77.

If the brake pads wear to a predetermined point, the braking system will require inspection. Seek the assistance of a workshop.

Control indicator  ⇨ 77.

## Antilock brake system

Antilock brake system (ABS) prevents the wheels from locking.

ABS starts to regulate brake pressure as soon as a wheel shows a tendency to lock. The vehicle remains steerable, even during hard braking.

ABS control is made apparent through a pulse in the brake pedal and the noise of the regulation process.

For optimum braking, keep the brake pedal fully depressed throughout the braking process, despite the fact that the pedal is pulsating. Do not reduce the pressure on the pedal.

Control indicator (ABS) ⇨ 78.

### Fault

If control indicators (ABS) and  illuminate with the messages **CHECK ABS** and **CHECK ESP** in the Driver Information Centre, there is a fault in the ABS. The brake system remains operational but without ABS regulation.


### Warning

If there is a fault in the ABS, the wheels may be liable to lock due to braking that is heavier than normal. The advantages of ABS are no longer available. During hard braking, the vehicle can no longer be steered and may swerve.

If control indicators (ABS), , (ESP) and STOP illuminate, the ABS and ESP are deactivated and the message **BRAKING FAULT** is shown in the Driver Information Centre. Seek the assistance of a workshop.

Have the cause of the fault remedied by a workshop.

## Parking brake



Always apply parking brake firmly without operating the release button, and apply as firmly as possible on a downhill or uphill slope.

To release the parking brake, pull the lever up slightly, press the release button and fully lower the lever.

To reduce the operating forces of the parking brake, depress the foot brake at the same time.

Control indicator (P) ⇨ 77.

## Brake assist

If the brake pedal is depressed quickly and forcefully, maximum brake force is automatically applied (full braking).

Maintain steady pressure on the brake pedal for as long as full braking is required. Maximum brake force is automatically reduced when the brake pedal is released.

## Ride control systems

### Traction Control system

The Traction control system (TC) is a component part of the Electronic stability program (ESP®<sup>Plus</sup>) which improves driving stability when necessary, regardless of the type of road surface or tyre grip, by preventing the drive wheels from spinning.

As soon as the drive wheels starts to spin, engine output is reduced and the wheel spinning the most is braked individually. This considerably improves the driving stability of the vehicle on slippery road surfaces.

TC is operational as soon as the ignition is switched on and control indicator  extinguishes in the instrument cluster.

When TC is active  flashes.

### Warning

Do not let this special safety feature tempt you into taking risks when driving.

Adapt speed to the road conditions.

Control indicator  78.

### Deactivation



When spinning of the drive wheels is required TC can be deactivated:

Press the  button. Control indicator  illuminates in the instrument cluster.

TC is reactivated by pressing the  button again. Control indicator  extinguishes in the instrument cluster. TC is also reactivated the next time the ignition is switched on.

When vehicle speed reaches 50 km/h the TC function will be restored automatically.

## Electronic stability program

The Electronic stability program (ESP®<sup>Plus</sup>) improves driving stability when necessary, regardless of the type of road surface or tyre grip. It also prevents the drive wheels from spinning.

As soon as the vehicle starts to swerve (understeer/oversteer), engine output is reduced and the wheels are braked individually. This considerably improves the driving stability of the vehicle on slippery road surfaces.

ESP®<sup>Plus</sup> is operational as soon as the ignition is switched on and control indicator  extinguishes in the instrument cluster.

When ESP®<sup>Plus</sup> comes into action  flashes.

### Warning

Do not let this special safety feature tempt you into taking risks when driving.

Adapt speed to the road conditions.

Control indicator   78.

## Deactivation



When spinning of the drive wheels is required ESP®<sup>Plus</sup> can be deactivated:

Press the  button. Control indicator  illuminates in the instrument cluster and the message **ESP OFF** appears in the Driver Information Centre.

ESP®<sup>Plus</sup> is reactivated by pressing the  button again. Control indicator  extinguishes in the instrument cluster. ESP®<sup>Plus</sup> is also reactivated the next time the ignition is switched on.

When vehicle speed reaches 50 km/h the ESP<sup>®</sup>Plus function will be restored automatically.

## Fault

If the system detects a fault, control indicator  illuminates in the instrument cluster and the message **CHECK ESP** appears in the Driver Information Centre.

Have the cause of the fault remedied by a workshop.

Vehicle messages ⇨ 81.

## Cruise control

The cruise control can store and maintain speeds of 30 km/h and above. Deviations from the stored speeds may occur when driving uphill or downhill.

For safety reasons the cruise control cannot be activated until the foot brake has been operated once.

Do not use the cruise control if it is not advisable to maintain a constant speed.

With manual transmission automated, only activate cruise control in automatic mode.

Control indicators  and  ⇨ 80.

## Activation



Press switch , control indicator  illuminates green in the instrument cluster.

Cruise control is now in standby mode and a corresponding message appears in the Driver Information Centre.



Accelerate to the desired speed and press switch **+** or **-**. The current speed is now stored and maintained and the accelerator pedal can be released.



Control indicator  illuminates green in the instrument cluster together with  and a corresponding message appears in the Driver Information Centre.

Vehicle speed can be increased by depressing the accelerator pedal. The stored speed flashes in the instrument cluster. When the accelerator pedal is released, the previously stored speed is resumed.

The speed is saved until the ignition is switched off.

### Increase speed

With cruise control active, the vehicle speed can be increased continuously or in small increments by holding down or tapping switch **+** repeatedly.

When the switch is released the current speed is stored and maintained.

Alternatively, accelerate to the desired speed and store by pressing switch **+**.

### Reduce speed

With cruise control active, the vehicle speed can be decreased continuously or in small increments by holding down or tapping switch **-** repeatedly.

When the switch is released the current speed is stored and maintained.

### Deactivation

Press switch **O**: cruise control is deactivated and the green control indicator  extinguishes in the instrument cluster.

Automatic deactivation:

- Vehicle speed drops below 30 km/h,
- The brake pedal is depressed,
- The clutch pedal is depressed,
- Selector lever in **N**.

The speed is stored and a corresponding message appears in the Driver Information Centre.

### Resume stored speed

Press switch **R** at a speed above 30 km/h.

If the stored speed is much higher than the current speed, the vehicle will accelerate powerfully until the stored speed is obtained.

### Deleting the stored speed

Press switch **⏏**: Green control indicators **⏏** and **⏏** extinguish in the instrument cluster.

### Cruise control speed limiter

The speed limiter prevents the vehicle exceeding a preset maximum speed above 30 km/h.

### Activation



Press switch **⏏**, control indicator **⏏** illuminates yellow in the instrument cluster.

Cruise control speed limiter function is now in standby mode and a corresponding message appears in the Driver Information Centre.

Accelerate to the desired speed and press switch **+** or **-**. The current speed is recorded.

The vehicle can be driven normally but it will not be possible to exceed the programmed speed limit except in an emergency.

Where the limit speed cannot be maintained, e.g. when driving on a steep decline, the limit speed will flash in the Driver Information Centre.

### Increase limit speed

The limit speed can be increased continuously or in small increments by holding down or tapping switch **+** repeatedly.

### Reduce limit speed

The limit speed can be decreased continuously or in small increments by holding down or tapping switch **-** repeatedly.

### Exceeding the limit speed

In the event of an emergency it is possible to exceed the limit speed by depressing the accelerator pedal firmly beyond the point of resistance.

The limit speed will flash in the Driver Information Centre during this period.

Release the accelerator pedal and the speed limiter function is reactivated once a speed lower than the limit speed is obtained.

### Deactivation

Press switch **O**: speed limiter is deactivated and the vehicle can be driven normally.

The limit speed is stored and a corresponding message appears in the Driver Information Centre.

### Reactivation

Press switch **R**. The speed limiter function is reactivated.

### Deleting the limit speed

Press switch .

Yellow control indicator  extinguishes in the instrument cluster.

## Object detection systems

### Parking assist

The parking assist makes reverse parking easier by measuring the distance between the rear of the vehicle and obstacles. It is the driver, however, who bears full responsibility for parking.



The system consists of four ultrasonic parking sensors in the rear bumper.

### Note

Attached parts in the detection area cause system malfunction.

### Activation

When reverse gear is engaged, the system switches itself on automatically. Readiness for operation is indicated by a brief acoustic alarm.

An obstacle is indicated by buzzers. The interval between the buzzers becomes shorter as the vehicle gets closer to the obstacle. When the distance is less than 30 cm, the buzzer is continuous.

### Warning

Under certain circumstances, various reflective surfaces on objects or clothing as well as external noise sources may cause the system to fail to detect obstacles.

## Deactivation



It is possible to deactivate or temporarily deactivate the system.

### Temporary deactivation

Temporarily deactivate the system by pressing the **P** button on the instrument panel with the ignition on and reverse gear engaged. Control indicator in the button illuminates.

When reverse gear is selected no acoustic signal will sound, indicating deactivation.

The function is reactivated by pressing button **P** again or the next time the ignition is switched on.

### Permanent deactivation

Permanently deactivate the system by pressing and holding the **P** button on the instrument panel for approx. 3 seconds with the ignition on and reverse gear engaged. Control indicator in the button illuminates continuously.

The system is deactivated and will not operate. When reverse gear is selected no acoustic signal will sound, indicating deactivation.

The function is reactivated by pressing and holding button **P** for approx. 3 seconds.

### Fault

If the system detects an operating fault, a continuous acoustic alarm will sound for approx. 5 seconds when selecting reverse gear. Consult a workshop to have the cause of the fault remedied.

## Caution

When reversing, the area should be free from obstacles which could impact on the underside of the vehicle.

Impact to the rear axle, which may not be visible, could lead to uncharacteristic changes in the vehicle handling. In the event of such an impact, consult a workshop.

## Rear view camera



The camera is typically installed under the number plate moulding with a display monitor fitted to the driver's sun visor.

### Functionality

The rear view camera system enables the driver to view the rear of the vehicle in the display monitor whilst reversing.

The system can be activated or deactivated by selecting the Start/Stop button located on the right-hand side of the display monitor.

The remaining buttons on the monitor enable the user to select source AV1 or AV2 and adjust the brightness and contrast of the display monitor.

To achieve the optimum visibility, the rear view camera must not be obscured by dirt, snow or ice.

#### Warning

The system is intended as a reversing aid and does not replace driver vision.

Do not let this feature tempt you into take risks when reversing.

Failure to use proper care when reversing may result in damage to the vehicle, injury, or death. Always check the outside, rearview mirrors and glance over your shoulder before reversing.

The driver assistance systems do not relieve the driver from full responsibility for vehicle operation.

## Fuel

### Fuel for diesel engines

Only use diesel fuel that complies with DIN EN 590. The fuel must have low sulphur content (max. 10 ppm). Equivalent standardised fuels with a biodiesel (= FAME according to EN14214) content of max. 7% by volume (like DIN 51628 or equivalent standards) may be used.

Do not use marine diesel oils, heating oils or entirely plant-based diesel fuels, such as rape seed oil or bio diesel, Aquazole and similar diesel-water emulsions. Diesel fuels must not be diluted with fuels for petrol engines.

The flow and filterability of diesel fuels are temperature-dependent. When temperatures are low, refuel with diesel fuel with guaranteed winter properties.

## Refuelling

### **⚠ Danger**

Before refuelling, switch off engine and any external heaters with combustion chambers (identified by sticker on fuel filler flap). Switch off any mobile phones.

Follow the operating and safety instructions of the filling station when refuelling.

### **⚠ Danger**

Fuel is flammable and explosive. No smoking. No naked flames or sparks.


If you can smell fuel in your vehicle, have the cause of this remedied immediately by a workshop.

### **Caution**

In case of misfuelling, do not switch on ignition.

The fuel tank filler neck with bayonet cap is located on the left front side of the vehicle.

The fuel filler flap can only be opened if the vehicle is unlocked and the door is opened. Open the fuel filler flap by hand.



Remove the fuel filler cap by turning it anti-clockwise.

The fuel filler cap can be hung on the lower hook of the fuel filler flap.

When refuelling is complete, replace the filler cap and turn it clockwise.

### **Caution**

Wipe off any overflowing fuel immediately.

## Fuel consumption - CO<sub>2</sub>-Emissions

The determination of fuel consumption is regulated by European directive 715/2007 692/2008 A.

The directive is oriented to actual driving practices: Urban driving is rated at approx.  $\frac{1}{3}$  and extra urban driving at approx.  $\frac{2}{3}$ . Cold starts and acceleration phases are also taken into consideration.

The specification of CO<sub>2</sub> emission is also a constituent of the directive.

Fuel consumption is dependent on personal driving style as well as road and traffic conditions.

The calculation of fuel consumption takes into account the vehicle's kerb weight, ascertained in accordance with the regulations. Optional equipment may result in slightly higher fuel consumption and CO<sub>2</sub> emission levels and a lower maximum speed.

## Towing

### General information

Only use towing equipment that has been approved for your vehicle. Entrust fitting of towing equipment at a later date to a workshop. It may be necessary to make changes that affect the cooling system, heat shields or other equipment.

### Driving characteristics and towing tips

In the case of trailers with brakes, attach the breakaway stopping cable.

Before attaching a trailer, lubricate the coupling ball. However, do not do so if a stabiliser, which acts on the coupling ball, is being used to reduce snaking movements. For trailers with low driving stability the use of a stabiliser is recommended.

A maximum speed of 80 km/h must not be exceeded, even in countries where higher speeds are permitted.

If the trailer starts snaking, drive more slowly, do not attempt to correct the steering and brake sharply if necessary.

When driving downhill, drive in the same gear as if driving uphill and drive at a similar speed.

Adjust tyre pressure to the value specified for full load ⇨ 183.

## Trailer towing

### Trailer loads

The permissible trailer loads are vehicle-dependent and engine-dependent maximum values which must not be exceeded. The actual trailer load is the difference between the actual gross weight of the trailer and the actual coupling socket load with the trailer coupled.

The permissible trailer loads are specified in the vehicle documents. In general, they are valid for gradients up to max. 12 %.

The permitted trailer load applies up to the specified incline and up to an altitude of 1000 metres above sea level. Since engine power decreases as altitude increases due to the air becoming thinner, therefore reducing climbing ability, the permissible gross train weight also decreases by 10 % for every 1000 metres of additional altitude. The gross train weight does not have to be reduced when driving on roads with slight inclines (less than 8 %, e.g. motorways).

The permissible gross train weight must not be exceeded. This weight is specified on the identification plate  
⇒ 166.

### Vertical coupling load

The vertical coupling load is the load exerted by the trailer on the coupling ball. It can be varied by changing the weight distribution when loading the trailer.

The maximum permissible vertical coupling load is specified on the towing equipment identification plate and in the vehicle documents. Always aim for the maximum load, especially

in the case of heavy trailers. The vertical coupling load should never fall below 25 kg.

In the case of trailer loads of 1200 kg or more, the vertical coupling load should not be less than 50 kg.

### Rear axle load

When the trailer is coupled and the towing vehicle fully loaded (including all occupants), the permissible rear axle load (see identification plate or vehicle documents) must not be exceeded.

## Towing equipment

| Caution                                                         |
|-----------------------------------------------------------------|
| When operating without a trailer, remove the coupling ball bar. |

### Towing equipment audible warning

For vehicles fitted with towing equipment, when connected to a trailer the pitch of the audible warning changes upon operation of the turn signals.

The pitch of the audible warning will change if a turn signal light on the trailer or the towing vehicle fails.

## Auxiliary features

### Power take-off



To activate, with the vehicle stationary and the engine idling:

- Select neutral (MTA = **N**)
- Depress the clutch pedal
- Press switch on the instrument panel
- Release clutch pedal

The engine idle speed increases to 1,200 rpm.

If the system does not operate, repeat the procedure or gradually release the clutch pedal.

To deactivate, depress the clutch pedal and press switch on the instrument panel.

## Vehicle care

|                           |     |
|---------------------------|-----|
| General Information ..... | 128 |
| Vehicle checks .....      | 129 |
| Bulb replacement .....    | 135 |
| Electrical system .....   | 143 |
| Vehicle tools .....       | 146 |
| Wheels and tyres .....    | 147 |
| Jump starting .....       | 156 |
| Towing .....              | 158 |
| Appearance care .....     | 159 |

## General Information

### Accessories and vehicle modifications

We recommend the use of Genuine Parts and Accessories and factory approved parts specific for your vehicle type. We cannot assess or guarantee reliability of other products - even if they have a regulatory or otherwise granted approval.

Do not make any modifications to the electrical system, e.g. changes of electronic control units (chip tuning).

## Vehicle storage

### Storage for a long period of time

The following tasks must be carried out if the vehicle is to be stored for several months:

- Wash and wax the vehicle.
- Have the wax in the engine compartment and underbody checked.
- Clean and preserve rubber seals.

- Change engine oil.
- Drain washer fluid reservoir.
- Check coolant antifreeze.
- Adjust tyre pressure to the value specified for full load.
- Park vehicle in a dry, well ventilated place. Engage first or reverse gear. Prevent the vehicle from rolling.
- Do not apply parking brake.
- Open bonnet, close all doors and lock the vehicle.
- Disconnect the clamp from the negative terminal of the vehicle battery. Beware that all systems are not functional, e.g. anti-theft alarm system.

### Putting back into operation

The following tasks must be carried out if the vehicle is being put back into operation:

- Connect the clamp to the negative terminal of the vehicle battery. Activate the electronics of the power windows.
- Check tyre pressure.

- Fill up the washer fluid reservoir.
- Check the engine oil level.
- Check the coolant level.
- Fit the number plate, if necessary.

## End-of-life vehicle recovery

Information on end-of-life vehicle recovery centres and the recycling of end-of-life vehicles is available on our website. Only entrust this work to an authorised recycling centre.

## Vehicle checks

### Performing work

#### Warning

Only perform engine compartment checks when the ignition is off.  
The cooling fan may start operating even if the ignition is off.

#### Danger

The ignition system generates extremely high voltages. Do not touch.


The caps for topping up the engine oil, the coolant, the washer fluid and the oil dipstick handle are yellow for ease of identification.

## Bonnet


### Opening



Pull the release lever and return it to its original position.



Pull the safety catch, located slightly left of centre, and open the bonnet.



Secure the bonnet support.

### Closing

Before closing the bonnet, press the support into the holder.

Lower the bonnet and allow it to drop into the catch. Check that the bonnet is engaged.

### Engine oil

Check the engine oil level manually on a regular basis to prevent damage to the engine.


Ensure that the correct specification of oil is used. Recommended fluids and lubricants ⇨ 163.

Check with the vehicle on a level surface. The engine must be at operating temperature and switched off for at least 10 minutes.

Pull out the dipstick, wipe it clean, insert it to the stop on the handle, pull out and read the engine oil level.

### Caution


It is the owner's responsibility to maintain the proper level of an appropriate quality oil in the engine.



When the engine oil level has dropped to the **MIN** mark, top up engine oil.

### Caution

Do not allow the engine oil level to drop below the minimum level!



We recommend the use of the same type of engine oil that was used at the last change.

The engine oil level must not exceed the maximum mark **MAX** on the dipstick.

### Caution

Overfilled engine oil must be drained or suctioned out.

A stabilization of the engine oil consumption will not take place until the vehicle has been driven several

thousand kilometres. Only then can the actual degree of consumption be established.

If consumption exceeds more than 0.5 litres every 1000 km after this running-in period, consult a workshop.

Capacities ⇨ 182, Engine oil level monitor ⇨ 72.

Fit the cap on straight and tighten it.

## Engine coolant

The coolant provides freeze protection down to approx. -28 °C.

### Caution

Only use approved antifreeze.

## Coolant level

### Caution

Too low a coolant level can cause engine damage.



If the cooling system is cold, the coolant level should be just above the **MINI** mark. Top up if the level is low.

### ⚠ Warning

Allow the engine to cool before opening the cap. Carefully open the cap, relieving the pressure slowly.

Top up with antifreeze. If no antifreeze is available, use clean tap water or distilled water. Install the cap tightly. Have the antifreeze

concentration checked and have the cause of the coolant loss remedied by a workshop.

If a substantial amount of coolant is required, it will be necessary to bleed any trapped air from the cooling system. Seek the assistance of a workshop.

## Power steering fluid



If the fluid level in the reservoir falls below the **MINI** mark consult a workshop.

## Washer fluid



Fill with clean water mixed with a suitable quantity of windscreen washer fluid which contains antifreeze.

## Brakes

A squealing noise, or illumination of brake pad wear control indicator (O) indicates that the brake lining is at its minimum thickness.

Continued driving is possible but have the brake linings replaced as soon as possible.


Once new brake linings are installed, do not brake unnecessarily hard for the first few journeys.

Brake pad wear indicator (O) ⇨ 77.

## Brake fluid

### ⚠ Warning

Brake fluid is poisonous and corrosive. Avoid contact with eyes, skin, fabrics and painted surfaces.



The brake fluid level must be between the **MIN** and **MAX** marks.

When topping up, ensure maximum cleanliness as contamination of the brake fluid can lead to brake system malfunctions. Have the cause of the loss of brake fluid remedied by a workshop.

Only use brake fluid approved for your vehicle.

Brake and clutch fluid ⇨ 163.

## Battery

The vehicle battery is maintenance-free.

Batteries do not belong in household waste. They must be disposed of at an appropriate recycling collection point.

Laying up the vehicle for more than 4 weeks can lead to battery discharge. Disconnect the clamp from the negative terminal of the vehicle battery.

Ensure the ignition is switched off before connecting or disconnecting the vehicle battery.

## Battery access



The battery is located behind a panel in the front left-hand door step. Remove the panel to access the battery.

## Warning label



Meaning of symbols:

- No sparks, naked flames or smoking.
- Always shield eyes. Explosive gases can cause blindness or injury.
- Keep the battery out of reach of children.
- The battery contains sulfuric acid which could cause blindness or serious burn injuries.

- See the Owner's Manual for further information.
- Explosive gas may be present in the vicinity of the battery.

## Battery maintenance


### **⚠ Danger**

Ensure adequate ventilation when charging the battery. There is a risk of explosion if gases generated during charging are allowed to accumulate!

## Additional battery

Depending on the vehicle's auxiliary equipment, certain models may have an additional battery mounted under the front seat.

## Diesel fuel filter




Drain diesel fuel filter of residual water at every engine oil change.

Place a container underneath the filter housing. Loosen the knurled screws on the filter cover and on the lower part of the filter by approx. one turn, to drain off the water.

The filter is drained as soon as diesel fuel emerges from the knurled screw at the bottom. Retighten the two screws.

Check diesel fuel filter at shorter intervals if the vehicle is subjected to extreme operating conditions.

## Diesel fuel system bleeding



If the fuel tank has been run dry, it will be necessary to air vent or bleed the diesel fuel system.

Fill the tank with fuel and proceed as follows:

1. Place a suitable container underneath the fuel filter vent screw to collect fuel.
2. Loosen the vent screw (arrowed) by one turn.


3. Manually operate the in-line supply pump slowly and steadily until fuel discharging from the loosened vent screw is free of air bubbles.

4. Retighten the vent screw.

If the engine cannot be started after several attempts to bleed the diesel fuel system, seek the assistance of a workshop.

## Wiper blade replacement

### Wiper blades on the windscreen



Lift wiper arm, press retaining clip towards wiper arm and detach wiper blade.


## Bulb replacement

Switch off the ignition and turn off the relevant switch or close the doors.

Only hold a new bulb at the base! Do not touch the bulb glass with bare hands.

Use only the same bulb type for replacement.

## Headlights




Headlights have separate systems for high beam **1** and low beam **2**.

## High beam



1. Remove headlamp protective cover.
2. Detach wiring connector from bulb.




3. Release spring clip.
4. Withdraw bulb from reflector housing.
5. Renew bulb and secure with spring clip.
6. Reattach wiring connector to bulb.
7. Replace headlamp protective cover.

## Low beam



1. Remove headlamp protective cover.
2. Detach wiring connector from bulb.
3. Rotate bulb holder anti-clockwise to disengage.
4. Withdraw bulb holder from reflector housing.




5. Detach bulb from bulb holder and renew the bulb.
6. Insert the bulb holder, engaging the two lugs in the reflector housing and rotate clockwise to secure.
7. Reattach wiring connector to bulb.
8. Replace headlamp protective cover.

## Sidelights




1. Remove protective cover.
2. Detach wiring connector from bulb.
3. Rotate bulb holder anti-clockwise to disengage.
4. Withdraw bulb holder from reflector housing.



5. Detach bulb from bulb holder and renew the bulb.
6. Insert the bulb holder, engaging the two lugs in the reflector housing and rotate clockwise to secure.
7. Reattach wiring connector to bulb.
8. Replace protective cover.


## Adaptive forward lighting

### Cornering light



Headlights have separate systems for high beam **1** and low beam **2**. The cornering light **3** is located between the headlights.

1. Remove protective cover.
2. Detach wiring connector from bulb.
3. Rotate bulb holder anti-clockwise to disengage.
4. Withdraw bulb holder from reflector housing.



5. Detach bulb from bulb holder and renew the bulb.
6. Insert the bulb holder, engaging the two lugs in the reflector housing and rotate clockwise to secure.
7. Reattach wiring connector to bulb.
8. Replace protective cover.


## Fog lights

Have bulbs replaced by a workshop.

## Front turn signal lights



1. Remove protective cover.
2. Detach wiring connector from bulb.
3. Rotate bulb holder anti-clockwise to disengage.
4. Withdraw bulb holder from reflector housing.



5. Detach bulb from bulb holder and renew the bulb.
6. Insert the bulb holder, engaging the two lugs in the reflector housing and rotate clockwise to secure.
7. Reattach wiring connector to bulb.
8. Replace protective cover.

## Tail lights


### Rear brake, tail, turn signal, reverse and fog tail lights



1. Remove the upper and lower trim panels from the rear pillar.
2. Unscrew the two nuts from the locating pins on the rear of the lamp assembly.
3. Withdraw the lamp assembly rearwards from the outer side.
4. Detach wiring connector from lamp assembly.



5. Remove the three screws from the rear of the lamp assembly.
6. Remove bulb holder from the lamp assembly.



7. Push bulb into socket slightly, rotate anti-clockwise, remove and renew bulb.  
Turn signal light (1)  
Tail and brake light (2)  
Reverse light (3)  
Rear fog light, may be on one side only (4)
8. Replace bulb holder in lamp assembly.
9. Replace the three screws on the rear of the lamp assembly.
10. Reattach wiring connector to lamp assembly.
11. Replace lamp assembly from the outer side into original position, ensuring that it is seated correctly.
12. Replace the two nuts onto the locating pins on the rear of the lamp assembly.
13. Install the upper and lower trim panels to the rear pillar.

## Side turn signal lights

1. Push the lamp assembly to the right and pull at the left-hand side of the lamp assembly to release from the aperture.




2. Detach wiring connector from lamp assembly.
3. Remove bulb holder from lamp assembly by rotating 90° and renew bulb.
4. Install bulb holder in lamp assembly.

5. Reattach wiring connector.
6. Install lamp assembly into aperture and push to the left to be secure.

## Mirror turn signal lights

1. Move the lower mirror assembly from the front to access the screw.
2. Remove the screw using a torx screwdriver.




3. Remove bulb holder from the rear of the lower mirror assembly.
4. Renew bulb.

5. Replace bulb holder.
6. Replace the screw.

## Centre high-mounted brake light



1. Remove cover from the inside of the rear door.
2. Unscrew the nut from the locating pin at the rear of the lamp assembly.



3. Remove the lamp assembly from the aperture on the outer side.
4. Detach wiring connector from lamp assembly.
5. Remove bulb holder from lamp assembly and renew bulb.
6. Install bulb holder in lamp assembly and reattach wiring connector to lamp assembly.
7. Replace lamp assembly into aperture, ensuring that it is seated correctly.

8. Replace the nut onto the locating pin on the rear of the lamp assembly.
9. Install cover on the inside of the rear door.

## Number plate light



1. Unclip lens using a flat blade screwdriver.
2. Remove cover and renew bulb.
3. Reinstall lens.


## Interior lights

### Front courtesy light




1. Remove lens using a flat blade screwdriver.
2. Renew bulb.
3. Reinstall lens.

### Load compartment light



1. Remove lamp assembly using a flat blade screwdriver.
2. Detach wiring connector from lamp assembly.
3. Remove lens cover and renew bulb.
4. Reattach wiring connector and reinstall lamp assembly.

### Front door panel light



1. Remove lamp assembly using a flat blade screwdriver.
2. Remove lens on lamp assembly.
3. Renew bulb and install lens.
4. Reinstall lamp assembly.

### Rear courtesy lights

Have bulbs replaced by a workshop.

### Glovebox light

Have bulbs replaced by a workshop.

## Instrument panel illumination

Have bulbs replaced by a workshop.

## Electrical system


### Fuses

Data on the replacement fuse must match the data on the defective fuse.

There are two fuse boxes in the vehicle:

- on the left-hand side of the instrument panel, behind the trim panel.
- in the engine compartment located below the coolant expansion tank.

Before replacing a fuse, turn off the respective switch and the ignition.




A blown fuse can be recognised by its melted wire. Do not replace the fuse until the cause of the fault has been remedied.

It is advisable to carry a full set of fuses. Consult a workshop.


Some functions are protected by several fuses.

Fuses may also be inserted without existence of a function.

## Fuse extractor



30042



30042



30044

To help in replacing fuses, a fuse extractor is located in the instrument panel fuse box.

Place the fuse extractor on the various types of fuse from the top or side, and withdraw fuse.

## Engine compartment fuse box

Located below the coolant expansion tank.

Some circuits may be protected by several fuses.

Due to restricted accessibility, have fuses replaced by a workshop.

| Symbol | Circuit           |
|--------|-------------------|
|        | Right side lights |
|        | Left side lights  |
|        | Right low beam    |
|        | Left low beam     |
|        | Front fog light   |
|        | Left high beam    |
|        | Right high beam   |
|        | ABS               |
|        | Windscreen wiper  |
|        | Air conditioning  |
|        | Heated windscreen |

## Instrument panel fuse box



Located behind the trim panel on the left-hand side of the instrument panel. Pull upper part of trim panel to remove.

Do not store any objects behind this panel.

Some circuits may be protected by several fuses.

### Symbol Circuit


|                             |                                                                                     |
|-----------------------------|-------------------------------------------------------------------------------------|
|                             | Infotainment system, seat heating, vehicle display screen, audio connections, alarm |
|                             | Power outlet                                                                        |
|                             | Cigarette lighter                                                                   |
|                             | Instrument panel                                                                    |
|                             | Central locking                                                                     |
|                             | Turn signals, rear fog lights, body control module                                  |
| <b>DIAG</b>                 | Diagnostic connector                                                                |
|                             | ABS, Electronic stability program                                                   |
|                             | Interior lights, brake lights                                                       |
|                             | Body control module                                                                 |
| <b>STOP</b>                 | Brake light                                                                         |
| <small>ALIM<br/>UCH</small> | Body control module, power windows, air conditioning                                |
|                             | Left heated rear window                                                             |

### Symbol Circuit

|            |                                    |
|------------|------------------------------------|
|            | Right heated rear window           |
|            | Windscreen washer                  |
|            | Electronic immobiliser             |
|            | Heated seats                       |
| <b>FBL</b> | Cornering light                    |
|            | Hands-free connection              |
| <b>T</b>   | Tachograph                         |
| <b>PTO</b> | Power take-off                     |
|            | Horn                               |
|            | Preheating, diesel fuel filter     |
|            | Climate control fan                |
| <b>ADP</b> | Additional adaptations             |
|            | Power windows, body control module |

## Vehicle tools

### Tools



The jack, wheel wrench, adapter, hub cap hook, wrench and towing eye are contained in a unit, stowed under the front seat.



Vehicles with Rear-wheel drive: A hydraulic jack and a set of extension pieces for use with the jack are also included.



To access this unit, slide the seat fully forwards and fold down the backrest.

Tyre repair kit ⇨ 149.

Spare wheel ⇨ 154.

## Wheels and tyres

### Tyre condition, wheel condition

Drive over edges slowly and at right angles if possible. Driving over sharp edges can cause tyre and wheel damage. Do not trap tyres on the kerb when parking.

Regularly check the wheels for damage. Seek the assistance of a workshop in the event of damage or unusual wear.

### Tyres

Factory-fitted tyres are matched to the chassis and offer optimum driving comfort and safety.

### Winter tyres

Winter tyres improve driving safety at temperatures below 7 °C and should therefore be fitted on all wheels.

In accordance with country-specific regulations, a notice indicating the maximum permissible speed for the tyres must be affixed within the driver's field of vision.

### Tyre designations

E.g. **215/65 R 16 C 109 R**

**215** = Tyre width, mm

**65** = Cross-section ratio (tyre height to tyre width), %

**R** = Belt type: Radial

**RF** = Type: RunFlat

**16** = Wheel diameter, inches

**C** = Cargo or commercial use

**88** = Load index e.g. 109 is equivalent to approx. 1030 kg

**R** = Speed code letter

Speed code letter:

**Q** = up to 160 km/h

**S** = up to 180 km/h

**T** = up to 190 km/h

**H** = up to 210 km/h

**V** = up to 240 km/h

**W** = up to 270 km/h

## Tyre pressure

Check the pressure of cold tyres at least every 14 days and before any long journey. Do not forget the spare wheel.

Tyre pressures ⇨ 183.

The tyre pressure data refers to cold tyres. It applies to summer and winter tyres.

Always inflate the spare tyre to the pressure specified for full load.

Incorrect tyre pressures will impair safety, vehicle handling, comfort and fuel economy and will increase tyre wear.

### Warning

If the pressure is too low, this can result in considerable tyre warm-up and internal damage, leading to tread separation and even to tyre blow-out at high speeds.

### Rear-wheel drive, with twin rear wheels

When inflating the outer tyre, the inflation tube should be passed between the two wheels.

### Tread depth

Check tread depth at regular intervals.

Tyres should be replaced for safety reasons at a tread depth of 2-3 mm (4 mm for winter tyres).

For safety reasons it is recommended that the tread depth of the tyres on one axle should not vary by more than 2 mm.



The legally permissible minimum tread depth (1.6 mm) has been reached when the tread has worn down as far as one of the tread wear indicators (TWI). Their position is indicated by markings on the sidewall.

Tyres age, even if they are not used. We recommend tyre replacement every 6 years.

### Changing tyre and wheel size

If tyres of a different size than those fitted at the factory are used, it may be necessary to reprogramme the speedometer as well as the nominal tyre pressure and make other vehicle modifications.

#### Warning

Use of unsuitable tyres or wheels may lead to accidents and will invalidate the vehicle type approval.

### Wheel covers

Wheel covers and tyres that are factory approved for the respective vehicle and comply with all of the relevant wheel and tyre combination requirements must be used.

If the wheel covers and tyres used are not factory approved, the tyres must not have a rim protection ridge.

Wheel covers must not impair brake cooling.

**⚠ Warning**

Use of unsuitable tyres or wheel covers could lead to sudden pressure loss and thereby accidents.

## Tyre chains



Tyre chains are only permitted on the drive wheels.

On vehicles with twin rear wheels, tyre chains are only permitted on the outer wheels.

Always use fine mesh chains that add no more than 15 mm to the tyre tread and the inboard sides (including chain lock).

**⚠ Warning**

Damage may lead to tyre blowout.

Wheel covers on steel wheels may come into contact with parts of the chains. In such cases, remove the wheel covers.

Tyre chains may only be used at speeds up to 50 km/h and, when travelling on roads that are free of snow, they may only be used for brief periods since they are subject to rapid wear on a hard road and may snap.

The use of tyre chains is not permitted on the temporary spare wheel.

## Tyre repair kit

Minor damage to the tyre tread or sidewall can be repaired with the tyre repair kit.

Do not remove foreign bodies from the tyres.

Tyre damage exceeding 4 mm or that is at the tyre's sidewall near the rim cannot be repaired with the tyre repair kit.

**⚠ Warning**

Do not drive faster than 80 km/h.  
Do not use for a lengthy period.  
Steering and handling may be affected.

If the vehicle has a flat tyre:


Apply the parking brake and engage first gear or reverse gear.

The tyre repair kit is located under the front seat. Slide seat forwards fully and fold backrest down to access kit.




30057

1. Remove the compressor from the tyre repair kit.
2. Remove the electrical connection cable and air hose from the compartments on the underside of the compressor.




30058

3. Screw the compressor air hose to the connection on the sealant bottle.
4. Fit the sealant bottle into the retainer on the compressor. Set the compressor near the tyre in such a way that the sealant bottle is upright.
5. Unscrew valve cap from defective tyre.




30059

6. Screw the filler hose to the tyre valve.
7. The switch on the compressor must be set to O.



8. Connect the red **+** power supply lead on the compressor to the jump start terminal ⇨ 156.
9. Connect the black **-** power supply lead to a vehicle grounding point, such as the engine block or an engine mounting bolt.

To avoid discharging the battery, we recommend running the engine.



10. Set the rocker switch on the compressor to I. The tyre is filled with sealant.

11. The compressor pressure gauge briefly indicates up to 6 bar. Then the pressure starts to drop.
12. All of the sealant is pumped into the tyre. Then the tyre is inflated.



13. The prescribed tyre pressure should be obtained within 10 minutes. Tyre pressure ⇨ 183. When the correct pressure is obtained, switch off the compressor.


If the prescribed tyre pressure is not obtained within 10 minutes, remove the tyre repair kit. Move the vehicle one tyre rotation (approx. 2 metres). Reattach the

tyre repair kit and continue the filling procedure for 10 minutes. If the prescribed tyre pressure is still not obtained, the tyre is too badly damaged. Seek the assistance of a workshop.

Drain excess tyre pressure with the button above the pressure indicator.

Do not run the compressor for longer than 10 minutes.

14. Detach the tyre repair kit. Screw the tyre inflation hose to the free connection on the sealant bottle. This prevents sealant from escaping. Stow tyre repair kit under the front seat.
15. Remove any excess sealant using a cloth.
16. Take the label indicating maximum permitted speed from the tyre repair kit and affix in the driver's field of view.



17. Continue driving immediately so that the sealant is evenly distributed throughout the tyre. After driving approx. 10 km, but no more than 10 minutes, stop and check tyre pressure using the compressor. Screw compressor air hose directly onto tyre valve and compressor when doing this.
18. If the tyre pressure is more than 3.1 bar, set it to the correct value. Repeat the procedure until there is no more loss of pressure. If the tyre pressure has fallen below 3.1 bar, the vehicle must

not be driven. Seek the assistance of a workshop.

19. Stow tyre repair kit under the front seat.

### **Warning**

Do not allow the sealant to contact skin, eyes or clothing. If swallowed seek medical assistance immediately.

### **Note**

The driving characteristics of the repaired tyre are severely affected, therefore have this tyre replaced.

If unusual noise is heard or the compressor becomes hot, turn compressor off for at least 30 minutes.

The built-in safety valve opens at a pressure of 7 bar.

Note the expiry date of the kit. After this date its sealing capability is no longer guaranteed. Pay attention to storage information on sealant bottle.

Replace the used sealant bottle. Dispose of the bottle as prescribed by applicable laws.

The compressor and sealant can be used from approx. -30 °C.

The adapters supplied can be used to pump up other items e.g. footballs, air mattresses, inflatable dinghies etc. They are located on the underside of the compressor. To remove, screw on compressor air hose and withdraw adapter.

## **Wheel changing**

Some vehicles are equipped with a tyre repair kit instead of a spare wheel  
 ⇨ 149.

Make the following preparations and observe the following information:



- Park the vehicle on a level, firm and non-slippery surface. The front wheels must be in the straight-ahead position.
- Apply the parking brake and engage first gear or reverse gear.
- Switch off the air suspension system ⇨ 107.

- Remove the spare wheel ⇨ 154.
- Never change more than one wheel at a time.
- Use the jack only to change wheels in case of puncture, not for seasonal winter or summer tyre change.
- If the ground on which the vehicle is standing is soft, a solid board (max. 1 cm thick) should be placed under the jack.
- No people or animals may be in the vehicle when it is jacked-up.
- Never crawl under a jacked-up vehicle.
- Do not start the engine when the vehicle is raised on the jack.
- Clean wheel bolts/nuts and their threads before mounting the wheel.

### **⚠ Warning**

Do not grease wheel bolt, wheel nut and wheel nut cone.

1. Remove the wheel cover using the hook supplied. Vehicle tools ⇨ 146.
2. Install the wheel wrench ensuring that it locates securely and loosen each wheel bolt/nut by half a turn.




3. Vehicles with Front-wheel drive:

Raise vehicle by placing lifting pad spigot of the jack under the jacking hole located nearest the wheel concerned.

Ensure the jack is positioned correctly. The jack base must be on the ground directly below the jacking hole in a manner that prevents it from slipping.

Attach wheel wrench onto the jack and raise the vehicle by turning the wrench until the wheel is clear of the ground.



Vehicles with Rear-wheel drive:

Pay attention to the operating instructions supplied with the hydraulic jack and assemble the parts required as specified.

Position the adapter at the jacking hole located nearest the wheel concerned.

Ensure the jack is positioned correctly. The jack head must be level with the jacking hole. Pump the jack by pressing the wheel wrench, to position the base plate correctly.

Raise the vehicle by pressing the wheel wrench until the wheel is clear of the ground.

4. Unscrew wheel bolts/nuts completely and wipe clean with a cloth.

Put wheel bolts/nuts somewhere where the threads will not be soiled.

5. Change the wheel.
6. Screw in the wheel bolts/nuts.
7. Lower vehicle.
8. Install the wheel wrench ensuring that it locates securely and tighten each wheel bolt/nut in a crosswise sequence. Tightening torque is: 172 Nm (Front-wheel drive), 235 Nm (Rear-wheel drive with twin rear wheels), 264 Nm (Rear-wheel drive with single rear wheels).
9. Refit wheel cover.

10. Stow the replaced wheel ↗ 154 and the vehicle tools ↗ 146.

11. Have the new wheel balanced on the vehicle. Check the tyre pressure of the installed tyre ↗ 183 and also the wheel bolt/nut torque as soon as possible.

Have the defective tyre renewed or repaired.


## Spare wheel

Some vehicles are equipped with a tyre repair kit instead of a spare wheel ↗ 149.

Use of a spare wheel that is smaller than the other wheels or together with winter tyres could affect driveability. Have the defective tyre replaced as soon as possible.

The spare wheel is held under the vehicle frame using a winch and secured by tightening a cable using the wheel wrench and adapter.


It may be necessary to jack the vehicle up to gain access to the spare wheel on a fully loaded vehicle with a flat rear tyre.



To release the spare wheel, loosen cable using the wheel wrench and adapter and lower the wheel fully.


### Caution

Only use the wheel wrench and adapter to lower the spare wheel. The use of pneumatic tools is prohibited. This may result in damage to the winch cable and equipment.



Place wheel upright, remove pin from retainer and release the wheel from the cable.

Twin rear wheel vehicles have an additional mounting plate attached to the spare wheel. Before using the wheel, undo the nut and remove the mounting plate.



When reinstalling a spare wheel, attach the mounting plate and secure with the nut.

When installing a spare wheel, route the cable from the back and through the centre of the wheel. Attach the retainer and pin, ensuring it is correctly positioned and that the front of the wheel will be facing downwards. Tighten cable using the wheel wrench and adapter until the wheel is secured.

## Summer and winter tyres

If you use winter tyres, the spare wheel may still be fitted with a summer tyre.

If you use the spare wheel when it is fitted with a summer tyre the vehicle's driveability may be affected, especially on slippery road surfaces.

## Directional tyres

Fit directional tyres such that they roll in the direction of travel. The rolling direction is indicated by a symbol (e.g. an arrow) on the sidewall.

The following applies to tyres fitted opposing the rolling direction:

- Driveability may be affected. Have the defective tyre renewed or repaired as soon as possible.
- Do not drive faster than 80 km/h.
- Drive particularly carefully on wet and snow-covered road surfaces.

## Jump starting

Do not start with a quick charger.

A vehicle with a discharged battery can be started using jump leads and the battery of another vehicle.

### Warning

Be extremely careful when starting with jump leads. Any deviation from the following instructions can lead to injuries or damage caused by battery explosion or damage to the electrical systems of both vehicles.

### Warning

Avoid contact with eyes, skin, fabrics, and painted surfaces. The fluid contains sulphuric acid which can cause injuries and damage in the event of direct contact.

### Caution

The air suspension system must be switched off prior to jump starting.

- Never expose the battery to naked flames or sparks.
- A discharged battery can already freeze at a temperature of 0 °C. Defrost the frozen battery before connecting jump leads.
- Avoid contact with eyes, skin, fabrics and painted surfaces. The fluid contains sulphuric acid which can cause injuries and damage in the event of direct contact.
- Wear eye protection and protective clothing when handling a battery.
- Use a booster battery with the same voltage (12 volts). Its capacity (Ah) must not be much less than that of the discharged battery.
- Use jump leads with insulated terminals and a cross section of at least 25 mm<sup>2</sup>.

- Do not disconnect the discharged battery from the vehicle.
- Switch off all unnecessary electrical consumers.
- Switch off the air suspension system.
- Do not lean over the battery during jump starting.
- Do not allow the terminals of one lead to touch those of the other lead.
- The vehicles must not come into contact with each other during the jump starting process.
- Apply the parking brake, transmission in neutral.

### Jump start terminal




In the event of a discharged battery, the jump start terminal enables the vehicle to be started without the need to access the battery inside the vehicle.

The jump start terminal is located in the engine compartment and identified by a "+" sign on the red insulating cover. Lift the red insulating cover to access the terminal connector.

Ensure the red insulating cover is latched back into position when not in use.

### Jump starting procedure



Lead connection order:

1. Connect the red lead to the positive terminal of the booster battery.
2. Connect the other end of the red lead to the jump start terminal of the vehicle with the discharged battery.
3. Connect the black lead to the negative terminal of the booster battery.
4. Connect the other end of the black lead to a vehicle grounding point, such as the engine block or an

engine mounting bolt. Connect as far away from the discharged battery as possible, however at least 60 cm.

Route the leads so that they cannot catch on rotating parts in the engine compartment.

To start the engine:

1. Start the engine of the vehicle providing the jump start.
2. After 5 minutes, start the other engine. Start attempts should be made for no longer than 15 seconds at an interval of 1 minute.
3. Allow both engines to idle for approx. 3 minutes with the leads connected.
4. Switch on electrical consumers (e.g. headlights, heated rear window) of the vehicle receiving the jump start.
5. Reverse above sequence exactly when removing leads.

## Towing

### Towing the vehicle

The towing eye is stowed with the vehicle tools ⇨ 146.



Disengage the cover using a suitable tool and remove.

Screw the towing eye clockwise into the front towing point and tighten fully using the wheel wrench.

Attach a tow rope - or better still a tow rod - to the towing eye, never to the bumper or front suspension units.

### Caution

Do not tow the vehicle from the rear. The front towing eye must only be used for towing and not recovering a vehicle.

Switch on ignition to release steering wheel lock and to permit operation of brake lights, horn and windscreen wipers.

Switch off the air suspension system ⇨ 107.

Transmission in neutral.

If neutral cannot be selected on vehicles with MTA transmission, the vehicle must only be towed with the drive wheels raised off the ground.

### Caution

Drive slowly. Do not drive jerkily. Excessive tractive force can damage the vehicle.

When the engine is not running, considerably more force is needed to brake and steer.

To prevent the entry of exhaust fumes from the towing vehicle, switch on the air recirculation system and close the windows.

Seek the assistance of a workshop.

After towing, unscrew the towing eye and refit the cover.

## Towing another vehicle



Attach a tow rope - or better still a tow rod - to the rear towing eye, never to the rear axle and suspension units.

The rear towing eye must only be used for towing and not recovering a vehicle.

### Caution

Drive slowly. Do not drive jerkily. Excessive tractive force can damage the vehicle.

## Appearance care

### Exterior care

#### Locks

The locks are lubricated at the factory using a high quality lock cylinder grease. Use de-icing agent only when absolutely necessary, as this has a degreasing effect and impairs lock function. After using de-icing agent, have the locks regreased by a workshop.

#### Washing

The paintwork of your vehicle is exposed to environmental influences. Wash and wax your vehicle regularly. When using automatic vehicle washes, select a programme that includes waxing.

Bird droppings, dead insects, resin, pollen and the like should be cleaned off immediately, as they contain aggressive constituents which can cause paint damage.

If using a vehicle wash, comply with the vehicle wash manufacturer's instructions. The windscreen wipers must be switched off. Remove antenna and external accessories such as roof racks etc..

If you wash your vehicle by hand, make sure that the insides of the wheel housings are also thoroughly rinsed out.

Clean edges and folds on opened doors and the bonnet as well as the areas they cover.

### Caution

Always use a cleaning agent with a pH value of 4 to 9.

Do not use cleaning agents on hot surfaces.

Have the door hinges of all doors greased by a workshop.

Do not clean the engine compartment with a steam-jet or high-pressure jet cleaner.

Thoroughly rinse and leather-off the vehicle. Rinse leather frequently. Use separate leathers for painted and glass surfaces: remnants of wax on the windows will impair vision.

Do not use hard objects to remove spots of tar. Use tar removal spray on painted surfaces.

### Exterior lights

Headlight and other light covers are made of plastic. Do not use any abrasive or caustic agents, do not use an ice scraper, and do not clean them dry.

### Polishing and waxing

Wax the vehicle regularly (at the latest when water no longer beads). Otherwise, the paintwork will dry out.

Polishing is necessary only if the paint has become dull or if solid deposits have become attached to it.

Paintwork polish with silicone forms a protective film, making waxing unnecessary.

Plastic body parts must not be treated with wax or polishing agents.

### Windows and windscreen wiper blades

Use a soft lint-free cloth or chamois leather together with window cleaner and insect remover.

When cleaning the rear window, make sure the heating element inside is not damaged.

For mechanical removal of ice, use a sharp-edged ice scraper. Press the scraper firmly against the glass so that no dirt can get under it and scratch the glass.

Clean smearing wiper blades with a soft cloth and window cleaner.

### Wheels and tyres

Do not use high-pressure jet cleaners.

Clean rims with a pH-neutral wheel cleaner.

Rims are painted and can be treated with the same agents as the body.

## Paintwork damage

Rectify minor paintwork damage with a touch-up pen before rust forms. Have more extensive damage or rust areas repaired by a workshop.

## Underbody

Some areas of the vehicle underbody have a PVC undercoating while other critical areas have a durable protective wax coating.

After the underbody is washed, check the underbody and have it waxed if necessary.

Bitumen/rubber materials could damage the PVC coating. Have underbody work carried out by a workshop.

Before and after winter, wash the underbody and have the protective wax coating checked.

## Towing equipment

Do not clean the coupling ball bar with a steam-jet or high-pressure jet cleaner.

## Interior care

### Interior and upholstery

Only clean the vehicle interior, including the instrument panel fascia and panelling, with a dry cloth or interior cleaner.

The instrument panel should only be cleaned using a soft damp cloth.

Clean fabric upholstery with a vacuum cleaner and brush. Remove stains with an upholstery cleaner.

Clothing fabrics may not be colourfast. This could cause visible discolourations, especially on light-coloured upholstery. Removable stains and discolourations should be cleaned as soon as possible.

Clean seat belts with lukewarm water or interior cleaner.

### Caution

Close Velcro fasteners as open Velcro fasteners on clothing could damage seat upholstery.

The same applies to clothing with sharp-edged objects, like zips or belts or studded jeans.

## Plastic and rubber parts

Plastic and rubber parts can be cleaned with the same cleaner as used to clean the body. Use interior cleaner if necessary. Do not use any other agent. Avoid solvents and petrol in particular. Do not use high-pressure jet cleaners.

## Service and maintenance

|                                                |     |
|------------------------------------------------|-----|
| General information .....                      | 162 |
| Recommended fluids, lubricants and parts ..... | 163 |

## General information

### Service information

In order to ensure economical and safe vehicle operation and to maintain the value of your vehicle, it is of vital importance that all maintenance work is carried out at the proper intervals as specified.

The detailed, up-to-date service schedule for the vehicle is available at the workshop.

Service display ⇨ 73.

Engine identification ⇨ 166.

### European service intervals - except Bus

Maintenance of your vehicle is required every 40000 km or after 1 year, whichever occurs first, unless otherwise indicated by the service display.

### European service intervals - Bus only

Maintenance of your vehicle is required every 30000 km or after 1 year, whichever occurs first, unless otherwise indicated by the service display.

The European service intervals are valid for the following countries:

Andorra, Austria, Belgium, Croatia, Czech Republic, Denmark, Estonia, Finland, France, Germany, Greece, Hungary, Iceland, Ireland, Israel, Italy, Latvia, Liechtenstein, Lithuania, Luxembourg, Netherlands, Norway, Poland, Portugal, Slovakia, Slovenia, Spain, Sweden, Switzerland, United Kingdom.

### Romania and Bulgaria service intervals

Maintenance of your vehicle is required every 30000 km or after 1 year, whichever occurs first, unless otherwise indicated by the service display.

### **Russia, Ukraine and Turkey service intervals**

Maintenance of your vehicle is required every 20000 km or after 1 year, whichever occurs first, unless otherwise indicated by the service display.

### **International service intervals**

Maintenance of your vehicle is required every 15000 km or after 1 year, whichever occurs first, unless otherwise indicated by the service display.

The International service intervals are valid for the following countries:

Albania, Bosnia-Herzegovina, Cyprus, Kosovo, Macedonia, Malta, Montenegro, Serbia, South Africa.

### **Confirmations**

Confirmation of service is recorded in the Service and Warranty Booklet. The date and mileage is completed with the stamp and signature of the servicing workshop.

Make sure that the Service and Warranty Booklet is completed correctly as continuous proof of service is essential if any warranty or goodwill claims are to be met, and is also a benefit when selling the vehicle.

### **Service display**

The service interval is based on several parameters depending on usage.

The service display, located in the Driver Information Centre, indicates when the next service is due. Seek the assistance of a workshop.

Service display ⇨ 73.

Engine oil level monitor ⇨ 72.

## **Recommended fluids, lubricants and parts**

### **Recommended fluids and lubricants**

Only use products that meet the recommended specifications. Damage resulting from the use of products not in line with these specifications will not be covered by the warranty.

#### **⚠ Warning**

Operating materials are hazardous and could be poisonous. Handle with care. Pay attention to information given on the containers.

### **Engine oil**

Engine oil is identified by its quality and its viscosity. Quality is more important than viscosity when selecting which engine oil to use. The oil quality ensures e.g. engine cleanliness, wear protection and oil

aging control, whereas viscosity grade gives information on the oil's thickness over a temperature range.

Dexos is the newest engine oil quality that provides optimum protection for diesel engines. If it is unavailable, engine oils of other listed qualities have to be used.

Select the appropriate engine oil based on its quality and on the minimum ambient temperature ➞ 167.

### **Topping up engine oil**

Engine oils of different manufacturers and brands can be mixed as long as they comply with the required engine oil quality and viscosity.

Use of engine oil with only ACEA A1/B1 or only A5/B5 quality is prohibited, since it can cause long-term engine damage under certain operating conditions.

Select the appropriate engine oil based on its quality and on the minimum ambient temperature ➞ 167.

### **Additional engine oil additives**

The use of additional engine oil additives could cause damage and invalidate the warranty.

### **Engine oil viscosity grades**

The SAE viscosity grade gives information of the thickness of the oil.

Multigrade oil is indicated by two figures, e.g. SAE 5W-30. The first figure, followed by a W, indicates the low temperature viscosity and the second figure the high temperature viscosity.

Select the appropriate viscosity grade depending on the minimum ambient temperature ➞ 167.

All of the recommended viscosity grades are suitable for high ambient temperatures.

### **Coolant and antifreeze**

Use only silicate-free long life coolant (LLC) antifreeze approved for the vehicle, consult a workshop.

The system is factory filled with coolant designed for excellent corrosion protection and frost

protection down to approx. -28 °C.

This concentration should be maintained all year round. The use of additional coolant additives that intend to give additional corrosion protection or seal against minor leaks can cause function problems. Liability for consequences resulting from the use of additional coolant additives will be rejected.

### **Brake fluid**

Only use DOT4+ brake fluid approved for the vehicle, consult a workshop.

Over time, brake fluid absorbs moisture which will reduce braking effectiveness. The brake fluid should therefore be replaced at the specified interval.

Brake fluid should be stored in a sealed container to avoid water absorption.

Ensure brake fluid does not become contaminated.

## Technical data

|                              |     |
|------------------------------|-----|
| Vehicle identification ..... | 165 |
| Vehicle data .....           | 167 |

## Vehicle identification

### Vehicle Identification Number



The Vehicle Identification Number (VIN) is visible through the windscreen.




The VIN is also displayed behind a removable plastic cover on the front right hand door step. Unclip the covers using a flat blade screwdriver to access.

## Identification plate



The identification plate is located on the right hand door pillar.



Information on identification plate<sup>1)</sup>:

- 1 = Vehicle identification number
- 2 = Permissible gross vehicle weight rating in kg
- 3 = Permissible gross train weight in kg
- 4 = Maximum permissible front axle load in kg
- 5 = Maximum permissible rear axle load in kg
- 6 = Trim code
- 7 = Technical specifications of vehicle, including: Vehicle paint code, equipment level and vehicle type

- 8 = Additional equipment specification
- 9 = Fabrication number
- 10 = Interior trim code

The combined total of front and rear axle loads must not exceed the permissible gross vehicle weight. For example, if the front axle is bearing its maximum permissible load, the rear axle can only bear a load that is equal to the gross vehicle weight minus the front axle load.

The technical data is determined in accordance with European Community standards. We reserve the right to make modifications. Specifications in the vehicle documents always have priority over those given in this manual.

## Engine identifier code and engine number

Stamped on the engine cylinder block and on a label attached to the timing chain cover, depending on variant.

<sup>1)</sup> The identification plate on your vehicle may differ from the illustration shown.

## Vehicle data

### Recommended fluids and lubricants

#### Required engine oil quality

##### Engine oil quality

dexos 2



In case dexos quality is unavailable you may use max. 1 litre engine oil quality ACEA C3 once between each oil change.

In case dexos quality is unavailable in International countries you may use the oil qualities listed below:

##### Engine oil quality

GM-LL-A/B-025



ACEA A3/B4



diesel engines without DPF

ACEA C3



diesel engines with DPF

#### Engine oil viscosity grades

##### Ambient temperature

down to -25 °C

SAE 5W-30 or SAE 5W-40

below -25 °C

SAE 0W-30 or SAE 0W-40

## Engine data

| Sales designation                      | 2.3 CDTI <sup>2)</sup> | 2.3 CDTI <sup>2)</sup> | 2.3 CDTI <sup>2)</sup> |
|----------------------------------------|------------------------|------------------------|------------------------|
| Engine identifier code                 | M9T                    | M9T                    | M9T                    |
| Number of cylinders                    | 4                      | 4                      | 4                      |
| Piston displacement [cm <sup>3</sup> ] | 2299                   | 2299                   | 2299                   |
| Engine power [kW] (brake horse power)  | 74 (100)               | 92 (125)               | 107 (146)              |
| at rpm                                 | 3500                   | 3500                   | 3500                   |
| Torque [Nm]                            | 285                    | 310                    | 350                    |
| at rpm                                 | 1250 - 2000            | 1250 - 2500            | 1500 - 2750            |
| Fuel type                              | Diesel                 | Diesel                 | Diesel                 |

<sup>2)</sup> With or without diesel particle filter.

## Vehicle weight

### Kerb weight, basic model

| Model | Drive wheels      | Length | Roof height | Gross vehicle weight | Kerb weight <sup>3)4)</sup> |
|-------|-------------------|--------|-------------|----------------------|-----------------------------|
| Van   | Front-wheel drive | L1     | H1          | 2800                 | 1806                        |
|       |                   |        |             | 3300                 | 1811                        |
|       |                   |        |             | 3500                 | 1816                        |
|       |                   |        | H2          | 2800                 | 1834                        |
|       |                   |        |             | 3300                 | 1839                        |
|       |                   |        |             | 3500                 | 1844                        |
|       |                   | L2     | H2          | 3300                 | 1885                        |
|       |                   |        |             | 3500                 | 1890                        |
|       |                   |        | H3          | 3300                 | 1921                        |
|       |                   |        |             | 3500                 | 1931                        |
|       |                   | L3     | H2          | 3500                 | 1970                        |
|       |                   |        | H3          | 3500                 | 2010                        |

<sup>3)</sup> Kerb weight and gross vehicle weight increase on models fitted with bad road equipment package - refer to identification plate.

| Model | Drive wheels     | Length | Roof height | Gross vehicle weight | Kerb weight <sup>3)4)</sup> |
|-------|------------------|--------|-------------|----------------------|-----------------------------|
| Van   | Rear-wheel drive | L3     | H2          | 3500 <sup>5)</sup>   | 2110                        |
|       |                  |        |             | 3500 <sup>6)</sup>   | 2246                        |
|       |                  |        |             | 4500                 | 2246                        |
|       |                  |        | H3          | 3500 <sup>5)</sup>   | 2148                        |
|       |                  |        |             | 3500 <sup>6)</sup>   | 2279                        |
|       |                  |        |             | 4500                 | 2279                        |
|       |                  | L4     | H2          | 3500 <sup>6)</sup>   | 2324                        |
|       |                  |        |             | 4500                 | 2324                        |
|       |                  |        | H3          | 3500 <sup>6)</sup>   | 2366                        |
|       |                  |        |             | 4500                 | 2366                        |

4) Minimum vehicle weight according to type approval, including all fluids, vehicle tools and a 90% fuel load. Excludes the weight of the driver and deletable options, e.g. spare wheel, bulkhead and sliding side door. Final weight may vary according to the specification of the vehicle, e.g. options, deleted options and accessories.

3) Kerb weight and gross vehicle weight increase on models fitted with bad road equipment package - refer to identification plate.

5) With Single rear wheels.

6) With Twin rear wheels.

| Model        | Drive wheels      | Length | Roof height | Gross vehicle weight | Kerb weight <sup>(3)4)</sup> |
|--------------|-------------------|--------|-------------|----------------------|------------------------------|
| Platform Cab | Front-wheel drive | L1     | H1          | 3500                 | 1570                         |
|              |                   | L2     | H1          | 3500                 | 1578                         |
|              |                   |        | H2          | 3500                 | 1593                         |
|              |                   | L3     | H1          | 3500                 | 1599                         |
|              |                   |        | H2          | 3500                 | 1613                         |
| Model        | Drive wheels      | Length | Roof height | Gross vehicle weight | Kerb weight <sup>(3)4)</sup> |
| Chassis Cab  | Front-wheel drive | L2     | H1          | 3500                 | 1686                         |
|              |                   | L3     | H1          | 3500                 | 1707                         |

<sup>3)</sup> Kerb weight and gross vehicle weight increase on models fitted with bad road equipment package - refer to identification plate.

<sup>4)</sup> Minimum vehicle weight according to type approval, including all fluids, vehicle tools and a 90% fuel load. Excludes the weight of the driver and deletable options, e.g. spare wheel, bulkhead and sliding side door. Final weight may vary according to the specification of the vehicle, e.g. options, deleted options and accessories.

| Model       | Drive wheels     | Length | Roof height | Gross vehicle weight | Kerb weight <sup>3)4)</sup> |
|-------------|------------------|--------|-------------|----------------------|-----------------------------|
| Chassis Cab | Rear-wheel drive | L2     | H1          | 3500 <sup>5)</sup>   | 1835                        |
|             |                  | L3     | H1          | 3500 <sup>5)</sup>   | 1860                        |
|             |                  |        |             | 3500 <sup>6)</sup>   | 1975                        |
|             |                  |        |             | 4500 <sup>6)</sup>   | 1975                        |
|             |                  | L4     | H1          | 3500 <sup>6)</sup>   | 2005                        |
|             |                  |        |             | 4500 <sup>6)</sup>   | 2005                        |

| Model    | Drive wheels      | Length | Roof height | Gross vehicle weight | Kerb weight <sup>3)4)</sup> |
|----------|-------------------|--------|-------------|----------------------|-----------------------------|
| Crew Cab | Front-wheel drive | L2     | H1          | 3500                 | 1887                        |
|          |                   | L3     | H1          | 3500                 | 1915                        |

<sup>3)</sup> Kerb weight and gross vehicle weight increase on models fitted with bad road equipment package - refer to identification plate.

<sup>4)</sup> Minimum vehicle weight according to type approval, including all fluids, vehicle tools and a 90% fuel load. Excludes the weight of the driver and deletable options, e.g. spare wheel, bulkhead and sliding side door. Final weight may vary according to the specification of the vehicle, e.g. options, deleted options and accessories.

<sup>5)</sup> With Single rear wheels.

<sup>6)</sup> With Twin rear wheels.

| Model    | Drive wheels      | Length | Roof height | Gross vehicle weight | Kerb weight <sup>(3)4)</sup> |
|----------|-------------------|--------|-------------|----------------------|------------------------------|
| Crew Cab | Rear-wheel drive  | L2     | H1          | 3500 <sup>5)</sup>   | 2037                         |
|          |                   | L3     | H1          | 3500 <sup>5)</sup>   | 2068                         |
|          |                   |        |             | 3500 <sup>6)</sup>   | 2154                         |
|          |                   |        |             | 4500 <sup>6)</sup>   | 2154                         |
|          |                   | L4     | H1          | 3500 <sup>6)</sup>   | 2223                         |
|          |                   |        |             | 4500 <sup>6)</sup>   | 2223                         |
| Model    | Drive wheels      | Length | Roof height | Gross vehicle weight | Kerb weight <sup>(3)4)</sup> |
| Bus      | Front-wheel drive | L3     | H2          | 3900                 | 2493                         |

<sup>3)</sup> Kerb weight and gross vehicle weight increase on models fitted with bad road equipment package - refer to identification plate.

<sup>4)</sup> Minimum vehicle weight according to type approval, including all fluids, vehicle tools and a 90% fuel load. Excludes the weight of the driver and deletable options, e.g. spare wheel, bulkhead and sliding side door. Final weight may vary according to the specification of the vehicle, e.g. options, deleted options and accessories.

<sup>5)</sup> With Single rear wheels.

<sup>6)</sup> With Twin rear wheels.

## Vehicle dimensions

Van, Doublecab

Front-wheel drive

Gross vehicle weight

| Size                                    | 2800,<br>3300,<br>3500<br>L1 | 3300,<br>3500<br>L2     | 3500<br>L3 |
|-----------------------------------------|------------------------------|-------------------------|------------|
| Length [mm]                             | 5048                         | 5548                    | 6198       |
| Width without mirrors [mm]              | 2070                         | 2070                    | 2070       |
| Width with mirrors [mm]                 | 2470                         | 2470                    | 2470       |
| Height - unladen (without antenna) [mm] | 2303                         | -                       | -          |
| H1                                      |                              |                         |            |
| H2                                      | 2496/2500 <sup>7)</sup>      | 2496/2499 <sup>7)</sup> | 2488       |
| H3                                      | -                            | 2745/2749 <sup>7)</sup> | 2744       |
| Wheelbase [mm]                          | 3182                         | 3682                    | 4332       |
| Track width [mm]                        | 1750                         | 1750                    | 1750       |
| Front                                   |                              |                         |            |
| Rear                                    | 1730                         | 1730                    | 1730       |

<sup>7)</sup> 3500 GVW.

## Van, Doublecab

## Rear-wheel drive

## Gross vehicle weight

3500,  
45003500,  
45003500,  
4500

## Size

L3

L3

L4

Length [mm]

6198

6198

6848

Width without mirrors [mm]

2070

2070

2070

Width with mirrors [mm]

2470

2470

2470

Height - unladen (without antenna) [mm]

2527<sup>8)</sup>/2549<sup>9)</sup>

2549

2557

H2

H3

2786<sup>8)</sup>/2815<sup>9)</sup>

2815

2808

Wheelbase [mm]

3682

3682

4332

Track width [mm]

1750

1750

1750

Front

Rear

1730<sup>8)</sup>/1612<sup>9)</sup>

1612

1612

8) With Single rear wheels.

9) With Twin rear wheels.

| Combi                                   | Front-wheel drive |               |
|-----------------------------------------|-------------------|---------------|
|                                         | 2800,<br>3500     | 2800,<br>3500 |
| Size                                    | L1                | L2            |
| Length [mm]                             | 5048              | 5548          |
| Width without exterior mirrors [mm]     | 2020              | 2020          |
| Width with mirrors [mm]                 | 2470              | 2470          |
| Height - unladen (without antenna) [mm] | 2303              | -             |
| H1                                      |                   |               |
| H2                                      | -                 | 2502          |
| Wheelbase [mm]                          | 3182              | 3682          |
| Track width [mm]                        | 1750              | 1750          |
| Front                                   |                   |               |
| Rear                                    | 1730              | 1730          |

| Chassis Cab                                   | Front-wheel drive |      | Rear-wheel drive    |                     |                               |                               |                               |
|-----------------------------------------------|-------------------|------|---------------------|---------------------|-------------------------------|-------------------------------|-------------------------------|
|                                               | 3500              | 3500 | 3500 <sup>10)</sup> | 3500 <sup>10)</sup> | 3500 <sup>11)</sup> ,<br>4500 | 3500 <sup>11)</sup> ,<br>4500 | 3500 <sup>11)</sup> ,<br>4500 |
| Size                                          | L2                | L3   | L2                  | L3                  | L2                            | L3                            | L4                            |
| Length [mm]                                   | 5643              | 6293 | 5643                | 6293                | 5819                          | 6192                          | 6842                          |
| Width without mirrors [mm]                    | 2070              | 2070 | 2070                | 2070                | 2070                          | 2070                          | 2070                          |
| Width with mirrors [mm]                       | 2470              | 2470 | 2470                | 2470                | 2470                          | 2470                          | 2470                          |
| Height - unladen (without antenna) [mm]<br>H1 | 2265              | 2258 | 2284                | 2276                | 2400                          | 2283                          | 2273                          |
| Wheelbase [mm]                                | 3682              | 4332 | 3682                | 4332                | 3682                          | 3682                          | 4332                          |
| Track width [mm]<br>Front                     | 1750              | 1750 | 1750                | 1750                | 1750                          | 1750                          | 1750                          |
| Rear                                          | 1730              | 1730 | 1730                | 1730                | 1612                          | 1612                          | 1612                          |

<sup>10)</sup> With Single rear wheels.

<sup>11)</sup> With Twin rear wheels.

| Crew Cab                                      | Front-wheel drive |      | Rear-wheel drive    |                     | 3500 <sup>13)</sup> ,<br>4500 | 3500 <sup>13)</sup> ,<br>4500 |
|-----------------------------------------------|-------------------|------|---------------------|---------------------|-------------------------------|-------------------------------|
| Gross vehicle weight                          | 3500              | 3500 | 3500 <sup>12)</sup> | 3500 <sup>12)</sup> | 4500                          | 4500                          |
| Size                                          | L2                | L3   | L2                  | L3                  | L3                            | L4                            |
| Length [mm]                                   | 5643              | 6293 | 5643                | 6293                | 6192                          | 6842                          |
| Width without mirrors [mm]                    | 2070              | 2070 | 2070                | 2070                | 2070                          | 2070                          |
| Width with mirrors [mm]                       | 2470              | 2470 | 2470                | 2470                | 2470                          | 2470                          |
| Height - unladen (without antenna) [mm]<br>H1 | 2272              | 2263 | 2295                | 2285                | 2283                          | 2273                          |
| Wheelbase [mm]                                | 3682              | 4332 | 3682                | 4332                | 3682                          | 4332                          |
| Track width [mm]<br>Front                     | 1750              | 1750 | 1750                | 1750                | 1750                          | 1750                          |
| Rear                                          | 1730              | 1730 | 1730                | 1730                | 1612                          | 1612                          |

<sup>12)</sup> With Single rear wheels.

<sup>13)</sup> With Twin rear wheels.

| <b>Platform Cab</b>                     | <b>Front-wheel drive</b> |             |
|-----------------------------------------|--------------------------|-------------|
| <b>Gross vehicle weight</b>             | <b>3500</b>              | <b>3500</b> |
| <b>Size</b>                             | <b>L2</b>                | <b>L3</b>   |
| Length [mm]                             | 5530                     | 6180        |
| Width without mirrors [mm]              | 2070                     | 2070        |
| Width with mirrors [mm]                 | 2470                     | 2470        |
| Height - unladen (without antenna) [mm] | 2270                     | 2264        |
| H1                                      |                          |             |
| H2                                      | 2463                     | 2457        |
| Wheelbase [mm]                          | 3682                     | 4332        |
| Track width [mm]                        | 1750                     | 1750        |
| Front                                   |                          |             |
| Rear                                    | 1730                     | 1730        |

| Bus                                     | Front-wheel drive | Rear-wheel drive |
|-----------------------------------------|-------------------|------------------|
| Gross vehicle weight                    | 3900              | 4500             |
| Size                                    | L3                | L4               |
| Length [mm]                             | 6198              | 6848             |
| Width without mirrors [mm]              | 2070              | 2070             |
| Width with mirrors [mm]                 | 2470              | 2470             |
| Wheelbase [mm]                          | 4332              | 4332             |
| Height - unladen (without antenna) [mm] | 2488              | -                |
| H2                                      |                   |                  |
| H3                                      | -                 | 2808             |
| Track width [mm]                        | 1750              | 1750             |
| Front                                   |                   |                  |
| Rear                                    | 1730              | 1612             |

## Loadspace dimensions

| Van                                      | Front-wheel drive |      |      |      |
|------------------------------------------|-------------------|------|------|------|
| Length                                   | L2                |      | L3   |      |
| Roof height                              | H2                | H3   | H2   | H3   |
| Gross vehicle weight                     | 3300,<br>3500     | 3500 | 3500 | 3500 |
| Maximum rear door aperture height [mm]   | 1820              | 1820 | 1820 | 1820 |
| Rear door aperture width (at floor) [mm] | 1580              | 1580 | 1580 | 1580 |
| Maximum load area height [mm]            | 1894              | 2144 | 1894 | 2144 |
| Maximum load area width [mm]             | 1765              | 1765 | 1765 | 1765 |
| Width between wheel arches [mm]          | 1380              | 1380 | 1380 | 1380 |
| Maximum load floor length [mm]           | 3083              | 3083 | 3733 | 3733 |

| Van                                      | Rear-wheel drive |      |      |      |      |      |
|------------------------------------------|------------------|------|------|------|------|------|
| Length                                   | L3               |      |      |      | L4   |      |
| Roof height                              | H2               |      | H3   |      | H2   | H3   |
| Gross vehicle weight                     | 3500             | 4500 | 3500 | 4500 | 4500 | 4500 |
| Maximum rear door aperture height [mm]   | 1724             | 1724 | 1724 | 1724 | 1724 | 1724 |
| Rear door aperture width (at floor) [mm] | 1580             | 1580 | 1580 | 1580 | 1580 | 1580 |
| Maximum load area height [mm]            | 1798             | 1798 | 2048 | 2048 | 1798 | 2048 |
| Maximum load area width [mm]             | 1765             | 1765 | 1765 | 1765 | 1765 | 1765 |
| Width between wheel arches [mm]          | 1380             | 1080 | 1380 | 1080 | 1080 | 1080 |
| Maximum load floor length [mm]           | 3733             | 3733 | 3733 | 3733 | 4383 | 4383 |

## Capacities

| Engine                          | M9T                                           |
|---------------------------------|-----------------------------------------------|
| Engine oil including filter [l] | Front-wheel drive 8.0<br>Rear-wheel drive 8.9 |
| between MIN and MAX [l]         | 1.5 - 2.0                                     |
| Fuel tank, nominal capacity [l] | 80 or 105                                     |

## Tyre pressures

### Front-wheel drive

| Engine | Gross Vehicle Weight | Tyre         | Tyre pressure with full load <sup>14)</sup> |                         |
|--------|----------------------|--------------|---------------------------------------------|-------------------------|
|        |                      |              | Front<br>[kPa/bar] (psi)                    | Rear<br>[kPa/bar] (psi) |
| M9T    | 2800                 | 215/65 R16 C | 340/3.4 (49)                                | 360/3.6 (52)            |
|        | 3300                 | 215/65 R16 C | 360/3.6 (52)                                | 430/4.3 (62)            |
|        | 3500                 | 225/65 R16 C | 380/3.8 (55)                                | 460/4.6 (68)            |

### Rear-wheel drive, with single rear wheels

| Engine | Gross Vehicle Weight | Tyre         | Tyre pressure with full load <sup>14)</sup> |                         |
|--------|----------------------|--------------|---------------------------------------------|-------------------------|
|        |                      |              | Front<br>[kPa/bar] (psi)                    | Rear<br>[kPa/bar] (psi) |
| M9T    | 3500                 | 235/65 R16 C | 360/3.6 (52)                                | 450/4.5 (65)            |

### Rear-wheel drive, with twin rear wheels

| Engine | Gross Vehicle Weight | Tyre         | Tyre pressure with full load <sup>14)</sup> |                         |
|--------|----------------------|--------------|---------------------------------------------|-------------------------|
|        |                      |              | Front<br>[kPa/bar] (psi)                    | Rear<br>[kPa/bar] (psi) |
| M9T    | 3500                 | 195/75 R16 C | 420/4.2 (61)                                | 420/4.2 (61)            |
|        | 4500                 | 195/75 R16 C | 420/4.2 (61)                                | 420/4.2 (61)            |

<sup>14)</sup> The spare wheel should be set to the highest applicable pressure shown in the table.

## Customer information

Vehicle data recording and privacy ..... 184

## Vehicle data recording and privacy

### Event data recorders

#### Data storage modules in the vehicle

A large number of electronic components of your vehicle contain data storage modules temporarily or permanently storing technical data about the condition of the vehicle, events and errors. In general, this technical information documents the condition of parts, modules, systems or the environment:

- Operating conditions of system components (e.g. filling levels)
- Status messages of the vehicle and its single components (e.g. number of wheel revolutions / rotational speed, deceleration, lateral acceleration)
- Dysfunctions and defects in important system components

- Vehicle reactions in particular driving situations (e.g. inflation of an airbag, activation of the stability regulation system)
- Environmental conditions (e.g. temperature)

These data are exclusively technical and help identifying and correcting errors as well as optimizing vehicle functions.

Motion profiles indicating travelled routes cannot be created with these data.

If services are used (e.g. repair works, service processes, warranty cases, quality assurance), employees of the service network (manufacturer included) are able to read out this technical information from the event and error data storage modules applying special diagnostic devices. If required, you will receive further information at these workshops. After an error has been corrected, the data are deleted from the error storage module or they are constantly overwritten.

When using the vehicle, situations may occur in which these technical data related to other information (accident report, damages on the vehicle, witness statements etc.) may be associated with a specific person - possibly, with the assistance of an expert.

Additional functions contractually agreed upon with the client (e.g. vehicle location in emergency cases) allow the transmission of particular vehicle data from the vehicle.

## **Radio Frequency Identification (RFID)**

RFID technology is used in some vehicles for functions such as ignition system security. It is also used in connection with conveniences such as radio remote controls for door locking/unlocking and starting, and in-vehicle transmitters for garage door openers. RFID technology in Opel vehicles does not use or record personal information or link with any other Opel system containing personal information.

# Index

## A

|                                                |         |
|------------------------------------------------|---------|
| Accessories and vehicle<br>modifications ..... | 128     |
| Adaptive forward lighting .....                | 86, 138 |
| Adjustable air vents .....                     | 101     |
| Airbag and belt tensioners .....               | 76      |
| Airbag deactivation .....                      | 48, 76  |
| Airbag system .....                            | 46      |
| Air conditioning regular<br>operation .....    | 102     |
| Air conditioning system .....                  | 93      |
| Air intake .....                               | 102     |
| Air suspension .....                           | 107     |
| Alert .....                                    | 82      |
| Antifreeze .....                               | 131     |
| Antilock brake system .....                    | 115     |
| Antilock brake system (ABS) .....              | 78      |
| Anti-theft alarm system .....                  | 28      |
| Anti-theft locking system .....                | 27      |
| Appearance care .....                          | 159     |
| Armrest .....                                  | 41      |
| Ashtrays .....                                 | 70      |
| Automatic light control .....                  | 85      |
| Automatic locking .....                        | 23      |
| Auxiliary heater .....                         | 97      |

## B

|                              |     |
|------------------------------|-----|
| Battery .....                | 133 |
| Battery, jump starting ..... | 156 |

|                        |          |
|------------------------|----------|
| Belts .....            | 44       |
| Bonnet .....           | 129      |
| Brake assist .....     | 116      |
| Brake fluid .....      | 132, 163 |
| Brake pad wear .....   | 77       |
| Brakes .....           | 114, 132 |
| Brake system .....     | 77       |
| Bulb replacement ..... | 135      |

## C

|                                                 |     |
|-------------------------------------------------|-----|
| Capacities .....                                | 182 |
| Cargo management system .....                   | 61  |
| Car Pass .....                                  | 19  |
| Catalytic converter .....                       | 109 |
| Central locking system .....                    | 20  |
| Centre high-mounted brake<br>light .....        | 141 |
| Changing tyre and wheel size .....              | 148 |
| Charging system .....                           | 77  |
| Child locks .....                               | 24  |
| Child restraint installation<br>locations ..... | 51  |
| Child restraint systems .....                   | 49  |
| Cigarette lighter .....                         | 70  |
| Cleaning the vehicle .....                      | 159 |
| Climate control .....                           | 15  |
| Clock .....                                     | 69  |
| Control indicators .....                        | 74  |
| Control of the vehicle .....                    | 103 |
| Convex shape .....                              | 30  |

|                             |         |
|-----------------------------|---------|
| Coolant.....                | 131     |
| Coolant and antifreeze..... | 163     |
| Coolant heater.....         | 97      |
| Cornering light.....        | 138     |
| Coupling ball bar.....      | 126     |
| Cruise control .....        | 80, 118 |
| Cupholders .....            | 59      |

## D

|                                                  |     |
|--------------------------------------------------|-----|
| Danger, Warnings and Cautions ...                | 3   |
| Dashboard.....                                   | 10  |
| Diesel fuel filter .....                         | 134 |
| Diesel fuel system bleeding .....                | 134 |
| Diesel particle filter .....                     | 109 |
| Door open .....                                  | 80  |
| Drain fuel filter .....                          | 79  |
| Driver Information Centre.....                   | 80  |
| Driving characteristics and<br>towing tips ..... | 125 |
| Driving hints.....                               | 103 |

## E

|                                      |         |
|--------------------------------------|---------|
| Electric adjustment .....            | 30      |
| Electronic climate control system .. | 94      |
| Electronic driving programmes ..     | 113     |
| Electronic Stability Program .....   | 78, 117 |
| Emergency exit.....                  | 35      |
| End-of-life vehicle recovery .....   | 129     |
| Engine compartment fuse box ...      | 144     |
| Engine coolant .....                 | 131     |

|                                           |               |
|-------------------------------------------|---------------|
| Engine coolant temperature .....          | 78            |
| Engine coolant temperature<br>gauge ..... | 72            |
| Engine data .....                         | 168           |
| Engine exhaust .....                      | 109           |
| Engine identification.....                | 166           |
| Engine oil .....                          | 130, 163, 167 |
| Engine oil level monitor.....             | 72            |
| Engine oil pressure .....                 | 78            |
| Event data recorders.....                 | 184           |
| Exhaust gases.....                        | 109           |
| Exit lighting .....                       | 90            |
| Exterior care .....                       | 159           |
| Exterior light .....                      | 79            |
| Exterior lighting .....                   | 13            |
| Exterior mirrors.....                     | 30            |

## F

|                                |         |
|--------------------------------|---------|
| Fault .....                    | 114     |
| Fire extinguisher.....         | 63      |
| First aid kit .....            | 63      |
| Fixed air vents .....          | 101     |
| Fog light .....                | 80      |
| Fog lights.....                | 87, 138 |
| Folding .....                  | 31      |
| Front airbag system .....      | 47      |
| Front fog lights .....         | 87      |
| Front storage.....             | 59      |
| Front turn signal lights ..... | 138     |

|                                                         |          |
|---------------------------------------------------------|----------|
| Fuel consumption - CO <sub>2</sub> -<br>Emissions ..... | 124      |
| Fuel for diesel engines .....                           | 123      |
| Fuel gauge .....                                        | 72       |
| Fuse box.....                                           | 144, 145 |
| Fuses .....                                             | 143      |

## G

|                           |     |
|---------------------------|-----|
| Gauges.....               | 71  |
| General information ..... | 125 |
| Glass panel .....         | 35  |
| Glovebox .....            | 59  |
| Glovebox cooler .....     | 102 |

## H

|                                      |         |
|--------------------------------------|---------|
| Hand brake - see Parking brake. .... | 115     |
| Hazard warning flashers .....        | 87      |
| Headlight flash .....                | 86      |
| Headlight range adjustment .....     | 86      |
| Headlights.....                      | 86, 135 |
| Headlights when driving abroad ..    | 86      |
| Head restraint adjustment .....      | 8       |
| Head restraints .....                | 36      |
| Heated .....                         | 31      |
| Heated exterior mirrors.....         | 31      |
| Heated rear window .....             | 34      |
| Heating .....                        | 41      |
| Heating and ventilation system ...   | 92      |
| High beam .....                      | 79, 86  |
| Horn .....                           | 14, 67  |

**I**

|                                     |         |
|-------------------------------------|---------|
| Identification plate .....          | 166     |
| Idle speed control.....             | 104     |
| Ignition switch positions .....     | 104     |
| Immobiliser .....                   | 29      |
| Instrument panel fuse box .....     | 145     |
| Instrument panel illumination ..... | 143     |
| Instrument panel overview .....     | 10      |
| Instrument panel storage.....       | 58      |
| Interior care .....                 | 161     |
| Interior lights .....               | 88, 142 |
| Interior mirrors.....               | 32      |
| Interruption of power supply .....  | 114     |
| Introduction .....                  | 3       |
| ISOFIX child restraint systems .... | 57      |

**J**

|                     |     |
|---------------------|-----|
| Jump starting ..... | 156 |
|---------------------|-----|

**K**

|            |    |
|------------|----|
| Keys ..... | 19 |
|------------|----|

**L**

|                                |    |
|--------------------------------|----|
| Lashing eyes .....             | 61 |
| Light covers, misted.....      | 88 |
| Lighting.....                  | 85 |
| Light switch .....             | 85 |
| Load compartment lighting..... | 89 |
| Loading information .....      | 64 |
| Low fuel .....                 | 79 |

**M**

|                                   |        |
|-----------------------------------|--------|
| Malfunction indicator light ..... | 77     |
| Manual adjustment .....           | 30     |
| Manual anti-dazzle .....          | 32     |
| Manual mode .....                 | 113    |
| Manual transmission .....         | 110    |
| Manual transmission               |        |
| automated .....                   | 111    |
| Manual windows .....              | 32     |
| Messages.....                     | 81     |
| Mirror adjustment .....           | 8      |
| Mirrors.....                      | 30, 32 |
| Misted light covers .....         | 88     |

**N**

|                              |     |
|------------------------------|-----|
| New vehicle running-in ..... | 103 |
| Number plate light .....     | 141 |

**O**

|                           |          |
|---------------------------|----------|
| Octane rating.....        | 168      |
| Odometer .....            | 71       |
| Oil.....                  | 130      |
| Oil, engine.....          | 163, 167 |
| Oil level.....            | 72       |
| Oil pressure.....         | 78       |
| Outside temperature ..... | 68       |
| Overcab storage .....     | 60       |
| Overhead console .....    | 60       |
| Overrun cut-off .....     | 105      |

**P**

|                           |         |
|---------------------------|---------|
| Parking .....             | 18, 107 |
| Parking assist .....      | 121     |
| Parking brake .....       | 115     |
| Particulate filter.....   | 109     |
| Performing work .....     | 129     |
| Pollen filter .....       | 102     |
| Power outlets .....       | 69      |
| Power side step.....      | 24      |
| Power sliding door.....   | 24      |
| Power steering fluid..... | 132     |
| Power take-off.....       | 127     |
| Power windows .....       | 32      |
| Preheating .....          | 78      |

**R**

|                                               |     |
|-----------------------------------------------|-----|
| Radio Frequency Identification<br>(RFID)..... | 185 |
| Radio remote control .....                    | 19  |
| Reading lights .....                          | 89  |
| Rear air conditioning system .....            | 96  |
| Rear doors .....                              | 26  |
| Rear fog light .....                          | 80  |
| Rear fog lights .....                         | 88  |
| Rear heating system .....                     | 95  |
| Rear seats .....                              | 42  |
| Rear view camera .....                        | 122 |
| Rear windows .....                            | 33  |

|                                         |          |
|-----------------------------------------|----------|
| Recommended fluids and lubricants ..... | 163, 167 |
| Refuelling .....                        | 124      |
| Remote control .....                    | 19       |
| Reversing lights .....                  | 88       |
| Roof rack .....                         | 64       |

## S

|                                |          |
|--------------------------------|----------|
| Safety belts .....             | 44       |
| Safety net .....               | 63       |
| Seat adjustment .....          | 7, 38    |
| Seat belt .....                | 8        |
| Seat belt reminder .....       | 76       |
| Seat belts .....               | 44       |
| Seat heating .....             | 41       |
| Seat position .....            | 37       |
| Selector lever .....           | 111      |
| Service .....                  | 102, 162 |
| Service display .....          | 73       |
| Service information .....      | 162      |
| Service vehicle soon .....     | 77       |
| Side airbag system .....       | 47       |
| Side turn signal lights .....  | 140      |
| Sliding door .....             | 24       |
| Spare wheel .....              | 154      |
| Speedometer .....              | 71       |
| Speed regulator .....          | 71       |
| Starting off .....             | 17       |
| Starting the engine .....      | 104, 111 |
| Steering column controls ..... | 67       |

|                                 |         |
|---------------------------------|---------|
| Steering wheel adjustment ..... | 9, 66   |
| Steering wheel controls .....   | 66      |
| Stop engine .....               | 77      |
| Stop-start system .....         | 79, 105 |
| Storage compartments .....      | 58      |
| Sunglasses storage .....        | 59      |
| Sun visors .....                | 34      |
| Suspension seat .....           | 38      |
| Symbols .....                   | 4       |

## T

|                                 |         |
|---------------------------------|---------|
| Tachograph .....                | 80, 84  |
| Tachometer .....                | 71      |
| Tail lights .....               | 139     |
| Technical data .....            | 168     |
| Three-point seat belt .....     | 45      |
| Tools .....                     | 146     |
| Top-tether fastening eyes ..... | 57      |
| Towing another vehicle .....    | 159     |
| Towing a trailer .....          | 125     |
| Towing equipment .....          | 126     |
| Towing eye .....                | 158     |
| Towing the vehicle .....        | 158     |
| Traction Control system .....   | 116     |
| Trailer towing .....            | 125     |
| Transmission .....              | 16      |
| Transmission display .....      | 73, 111 |
| Tread depth .....               | 148     |
| Trip computer .....             | 82      |
| Triple-Info-Display .....       | 81      |

|                                      |     |
|--------------------------------------|-----|
| Turn and lane-change signals .....   | 87  |
| Turn signal .....                    | 76  |
| Tyre chains .....                    | 149 |
| Tyre changing .....                  | 152 |
| Tyre designations .....              | 147 |
| Tyre pressure .....                  | 147 |
| Tyre pressures .....                 | 183 |
| Tyre repair kit .....                | 149 |
| Tyres .....                          | 147 |
| Tyres and wheel size, changing ..... | 148 |

## U

|                                 |     |
|---------------------------------|-----|
| Ultrasonic parking assist ..... | 121 |
| Underseat storage .....         | 60  |
| Upholstery, cleaning .....      | 161 |
| Upshift .....                   | 78  |
| Using this manual .....         | 3   |

## V

|                                          |     |
|------------------------------------------|-----|
| Vehicle data .....                       | 167 |
| Vehicle data recording and privacy ..... | 184 |
| Vehicle dimensions .....                 | 174 |
| Vehicle Identification Number .....      | 165 |
| Vehicle messages .....                   | 81  |
| Vehicle specific data .....              | 3   |
| Vehicle storage .....                    | 128 |
| Vehicle unlocking .....                  | 6   |
| Vehicle weight .....                     | 169 |
| Ventilation .....                        | 92  |

**W**

|                                |     |
|--------------------------------|-----|
| Warning chimes .....           | 82  |
| Warning triangle .....         | 63  |
| Washer and wiper systems ..... | 15  |
| Washer fluid .....             | 132 |
| Washing the vehicle.....       | 159 |
| Wheel changing .....           | 152 |
| Wheel covers .....             | 148 |
| Wheels and tyres .....         | 147 |
| Windows.....                   | 32  |
| Windscreen wiper/washer .....  | 67  |
| Winter tyres .....             | 147 |
| Wiper blade replacement .....  | 135 |

Copyright by ADAM OPEL AG, Rüsselsheim, Germany.

The information contained in this publication is effective as of the date indicated below. Adam Opel AG reserves the right to make changes to the technical specifications, features and design of the vehicles relative to the information in this publication as well as changes to the publication itself.

Edition: January 2013, ADAM OPEL AG, Rüsselsheim.

Printed on chlorine-free bleached paper.

**KTA-2683/5-en**

**01/2013**

