


6. Master Cylinder

A: REMOVAL

1) Thoroughly drain the brake fluid from the reservoir tank.

2) Remove the snap pin and clevis pin, and then separate the push rod of the master cylinder from clutch pedal.



- (A) Clevis pin
- (B) Snap pin
- (C) Push rod
- (D) Lock nut


3) Remove the air intake chamber. <Ref. to IN(H4SO)-7, REMOVAL, Air Intake Chamber.>

4) Remove the clutch pipe from the master cylinder.

5) Remove the master cylinder and reservoir tank as a unit.

CAUTION:

Be careful not to spill the brake fluid. Brake fluid spilled on the vehicle body will harm the paint surface; wash it off with water and wipe clean quickly if spilled.



- (A) Master cylinder
- (B) Clutch pipe

B: INSTALLATION

1) Install the master cylinder to the vehicle body, and connect the clutch pipe to the master cylinder.


NOTE:

Check that the pipe is routed properly.

Tightening torque:

T1: 15 N·m (1.5 kgf-m, 11.1 ft-lb)


T2: 18 N·m (1.8 kgf-m, 13.3 ft-lb)



2) Connect the push rod of the master cylinder to the clutch pedal, and install the clevis pin and snap pin.

NOTE:

Apply grease to the clevis pin.



- (A) Clevis pin
- (B) Snap pin
- (C) Push rod

3) After bleeding air from the clutch system, ensure that the clutch operates properly.

<Ref. to CL-21, Clutch Fluid Air Bleeding.>


4) Install the air intake chamber. <Ref. to IN(H4SO)-7, INSTALLATION, Air Intake Chamber.>

Master Cylinder

CLUTCH SYSTEM


C: DISASSEMBLY

- 1) Remove the straight pin and reservoir tank.




- (A) Reservoir tank
(B) Straight pin

- 2) Remove the oil seal.



- (A) Oil seal
(B) Master cylinder

- 3) Move the seat towards the rear.



- (A) Seat
(B) Master cylinder

- 4) Remove the piston stop ring.

CAUTION:

When removing the piston stop ring, be careful to prevent the rod, washer, piston and return spring from coming out.


D: ASSEMBLY

- 1) Apply a coat of grease to the contact surfaces of the push rod and piston before installation.

Grease:

SILICONE GREASE G-40M

(Part No. 004404003)




- 2) Assemble in the reverse order of disassembly.

Tightening torque:

10 N·m (1.0 kgf-m, 7.4 ft-lb)

E: INSPECTION

If any damage, deformation, wear, swelling, rust or other faults are found on the cylinder, piston, push rod, reservoir tank, return spring, seat or hose, replace the faulty part.



- (A) Master cylinder body
(B) Return spring
(C) Piston
(D) Piston stop ring
(E) Push rod ASSY
(F) Seat