



5. Intake Duct

A: REMOVAL

- 1) Remove the collector cover.
- 2) Disconnect the ground cable from the battery.



- 3) Remove the intake manifold. <Ref. to FU(H4DOTC)-14, REMOVAL, Intake Manifold.>
- 4) Remove the sensor, engine harness and fuel pipe attached to the intake manifold. <Ref. to FU(H4DOTC)-22, DISASSEMBLY, Intake Manifold.>
- 5) Remove the intake duct from intake manifold.



B: INSTALLATION

Install in the reverse order of removal.

Tightening torque:

17 N·m (1.7 kgf-m, 12.5 ft-lb)

