

WIPER AND WASHER SYSTEM

6605E-06

PRECAUTION

1. PRECAUTION FOR WASHER NOZZLE (4WAY TYPE) HANDLING

- (a) Do not adjust the washer nozzle with a safety pin, etc. as the washer nozzle tip is made of resin and could be damaged. Be sure to use SST for adjustment.
SST 95060-10010
- (b) When the washer nozzle is clogged with wax, etc., do not use metal objects such as a safety pin to clean the washer nozzle hole. Be sure to use a soft resin brush, etc.

NOTICE FOR INITIALIZATION:


When disconnecting the negative (-) battery terminal, initialize the following systems after the terminal is reconnected.

System Name	See page
Power Window Control System	01-29


NOTICES FOR HYBRID SYSTEM ACTIVATION:

- When the warning lamp is illuminated or the battery has been disconnected and reconnected, pressing the power switch may not start the system on the first try. If so, press the power switch again.
- With the power switch's power mode changed to ON (IG), disconnect the battery. If the key is not in the key slot during reconnection, DTC B2799 may be output.

LOCATION




LHD:




Australia:
Windshield Wiper Switch Assy

Europe:
Windshield Wiper Switch Assy




RHD:




SYSTEM DIAGRAM

Front Wiper:



Rear Wiper:



SYSTEM DESCRIPTION

1. WASHER LINKED OPERATION


- (a) This system operates the front wipers at low speed immediately after a jet of washer fluid when the front washer switch is on for 0.3 second or more. The system operates the front wipers at low speed for approximately 2.2 seconds and then stops operation when the washer switch is on for 1.5 seconds or more.

2. INTERMITTENT OPERATION

- (a) The system operates the front wipers once in approximately 1.6 to 10.7 seconds when the front wiper switch is turned to the INT position. The intermittent time can be adjusted from 1.6 to 10.7 seconds by using the intermittent time adjust dial.
- (b) If the wiper control switch is turned to the INT position, current flows from the already charged capacitor C1 through terminals INT1 and INT2 of the wiper control switch, to Tr1 (transistor). When Tr1 turns on, current flows from terminal +S of the wiper control switch to terminal +1 of the wiper control switch, to terminal +1 of the wiper motor, to the wiper motor and finally to ground, causing the wiper motor to operate. At the same time, current flows from capacitor C1 to terminal INT1 of the wiper control switch and then INT2. When the current flow from capacitor C1 ends, Tr1 turns off to stop the relay contact point and halt the wiper motor.

When the relay contact point turns off, capacitor C1 begins to charge again and Tr1 remains off until charging has been completed. This period corresponds to the intermittent time. When capacitor C1 is fully charged, Tr1 turns on and then the relay contact point turns on, causing the motor to operate again. This cycle is the intermittent operation.

The intermittent time can be adjusted by using the intermittent time adjust dial (variable resistor) to change the charge time of capacitor C1.



I40344

3. REAR WIPER INTERMITTENT OPERATION

- (a) When the rear wiper control switch is turned to the INT position, current flows from the capacitor of the intermittent operation control circuit to turn on Tr. Current flows from terminal +B of the rear wiper relay, to relay coil, to Tr, to terminal C1 of the rear wiper relay, to terminal C1R of the rear wiper control switch and finally to ground, causing the relay contact point to turn on.


When the relay contact point turns on, current flows from terminal +B of the rear wiper relay to the relay contact point, to terminal LM of the rear wiper relay, to terminal +1 of the rear wiper motor, to the rear wiper motor and finally to ground, causing the rear wiper motor to operate.

Tr turns off immediately after the rear wiper motor operation as the current flow from capacitor ends, causing the relay contact point to turn off.

Even when the relay contact point turns off, current flows from terminal +B of the rear wiper motor, to the relay contact point in the rear wiper motor, to terminal S of the rear wiper motor, to terminal SM of the rear wiper relay, to the contact point of the rear wiper relay, to terminal LM of the rear wiper motor, to terminal +1 of the rear wiper motor and finally to ground until the rear wiper motor stops at the automatic stop position, causing the rear wiper motor to operate. Then the rear wiper motor stops at the automatic stop position as the relay contact point in the rear wiper motor turns off.

The capacitor in the intermittent operation control circuit is charged in approximately 12 seconds after the current flow ends. After the charge is completed, current starts flowing again to turn on Tr, causing the relay contact point to turn on.

This cycle (of current flow and charging) as described above is the intermittent operation.



PROBLEM SYMPTOMS TABLE


1. FRONT WIPER AND WASHER SYSTEM

Symptom	Suspected Area	See page
Both front wipers and washer systems do not operate.	1. Windshield Wiper Switch Assy 2. Wire Harness or connector	66-10 -
Front wipers do not operate when the windshield washer is normal.	1. WIP fuse 2. Windshield wiper switch assy 3. Windshield wiper motor assy 4. Wire harness or connector	- 66-10 66-10 -
Front wipers do not operate in LO or HI.	1. Windshield Wiper Switch Assy 2. Windshield Wiper Motor Assy 3. Wire Harness or connector	66-10 66-10 -
Front wipers do not operate in INT.	1. Windshield wiper switch assy 2. Windshield wiper motor assy 3. Wire harness or connector	66-10 66-10 -
Windshield washer motor does not operate.	1. WSH fuse 2. Windshield wiper switch assy 3. Windshield washer motor and pump assy 4. Wire harness or connector	- 66-10 66-8 -
Front wipers do not operate when a jet of washer fluid is emitted with the washer switch on.	1. Windshield wiper switch assy 2. Windshield wiper motor assy 3. Wire harness or connector	66-10 66-10 -
A jet of washer fluid is not emitted when windshield washer motor is normal.	1. Washer hose and nozzle	-
Wiper blade does not return or the return position is wrong when the windshield wiper switch is off.	1. Windshield wiper arm installation position 2. Windshield wiper motor assy 3. Wire harness or connector	66-16 66-10 -

2. REAR WIPER AND WASHER SYSTEM

Symptom	Suspected Area	See page
Both rear wiper and washer systems do not operate.	1. Windshield wiper switch assy 2. Wire harness or connector	66-10 -
Rear wiper does not operate in INT or ON.	1. Windshield wiper switch assy 2. Rear wiper motor assy 3. Wire harness or connector	66-10 66-10 -
Rear washer motor does not operate.	1. WSH fuse 2. Windshield wiper switch assy 3. Windshield washer motor and pump assy 4. Wire harness or connector	- 66-10 66-8 -
A jet of washer fluid is not emitted when rear washer motor is normal.	1. Washer hose and nozzle	-
Wiper blade does not return or the return position is wrong when the rear wiper switch is off.	1. Rear wiper arm installation position 2. Rear wiper motor assy 3. Wire harness or connector	66-22 66-10 -

ON-VEHICLE INSPECTION

**1. WINDSHIELD WASHER MOTOR AND PUMP ASSY****(a) Operation Check**


- (1) Fill the washer jar with washer fluid.

HINT:

Operation should be performed with the windshield washer motor and pump assy installed to the washer jar assy.

- (2) Connect the positive battery (+) lead to terminal 1 of the windshield washer motor and pump assy, and the negative battery (-) lead to terminal 2. Check that washer fluid flows from the washer jar.

Standard: Washer fluid flows from the washer jar.

**2. REAR WASHER MOTOR ASSY (w/ Rear Wiper)****(a) Operation Check**


- (1) Fill the washer jar with washer fluid.

HINT:


Operation should be performed with the windshield washer motor and pump assy installed to the washer jar assy.

- (2) Connect the positive battery (+) lead to terminal 1 of the windshield washer motor and pump assy, and the negative battery (-) lead to terminal 2. Check that washer fluid flows from the washer jar.

Standard: Washer fluid flows from the washer jar.

Europe:

This illustration is for LHD.
RHD and LHD are symmetrical.

Australia:


E71127

I39840


3. WINDSHIELD WIPER MOTOR ASSY(DRIVER SIDE POSITION)

- (a) Automatic Stop Position Inspection
- (1) Operate the windshield wiper motor assy, and then stop the operation.
 - (2) Check the automatic stop position when stopping the windshield wiper motor assy operation.

Standard: Front wiper arm stops at the position shown in the illustration.

Europe:

This illustration is for LHD.
RHD and LHD are symmetrical.

Australia:P I39798
I39841

I41174

4. WINDSHIELD WIPER MOTOR ASSY(FRONT PASSENGER SIDE POSITION)


- (a) Automatic Stop Position Inspection
- (1) Operate the windshield wiper motor assy, and then stop the operation.
 - (2) Check the automatic stop position when stopping the windshield wiper motor assy operation.

Standard: Front wiper arm stops at the position shown in the illustration.

5. REAR WIPER MOTOR ASSY

- (a) Automatic Stop Position Inspection
- (1) Operate the rear wiper motor assy, and then stop the operation.
 - (2) Check the automatic stop position when stopping the rear wiper motor assy operation.


Standard: Rear wiper arm stops at the position shown in the illustration.



P E71131

I39800

INSPECTION



1. WINDSHIELD WIPER SWITCH ASSY (LH POSITION) (AUSTRALIA)

- (a) Measure the resistance according to the value(s) in the table below.

Standard:

Front Wiper Switch


Switch position	Tester connection	Specified resistance
MIST	C10-2 (+1) – C10-3 (+B)	Below 1 Ω
OFF	C10-2 (+1) – C10-4 (+S)	Below 1 Ω
INT	C10-2 (+1) – C10-4 (+S)	Below 1 Ω
LO	C10-2 (+1) – C10-3 (+B)	Below 1 Ω
HI	C10-1 (+2) – C10-3 (+B)	Below 1 Ω

Rear Wiper Switch (w/ Rear Wiper)

Switch position	Tester connection	Specified resistance
OFF	C9-2 (EW) – C9-5 (C1R), C9-2 (EW) – C9-4 (+1R)	10 k Ω or higher
INT	C9-2 (EW) – C9-5 (C1R)	Below 1 Ω
ON	C9-2 (EW) – C9-4 (+1R)	Below 1 Ω

Front Washer Switch

Switch position	Tester connection	Specified resistance
OFF	C9-1 (WF) – C9-2 (EW)	10 k Ω or higher
ON	C9-1 (WF) – C9-2 (EW)	Below 1 Ω



Rear Washer Switch (w/ Rear Wiper)



Switch position	Tester connection	Specified resistance
OFF	C10-10 (WR) – C9-2 (EW), C9-2 (EW) – C9-4 (+1R)	10 k Ω or higher
ON (WASH1)	C10-10 (WR) – C9-2 (EW)	Below 1 Ω
ON (WASH2)	C10-10 (WR) – C9-2 (EW), C9-2 (EW) – C9-4 (+1R)	Below 1 Ω

(b) Intermittent Operation Check

- (1) Connect the voltmeter (+) terminal to terminal C10-2 (+1) of the connector and the voltmeter (-) terminal to terminal C9-2 (EW).
- (2) Connect the positive battery (+) lead to terminal C10-3 (+B) of the connector and the negative battery (-) lead to terminals C9-2 (EW) and C10-4 (+S).
- (3) Turn the wiper switch to the INT position.
- (4) Connect the positive battery (+) lead to terminal C10-4 (+S) of the connector for 5 seconds.

- (5) Connect the negative battery (-) lead to terminal C10-4 (+S) of the connector. Operate the intermittent wiper relay and measure the voltage between terminals C10-2 (+1) and C9-2 (EW)


Standard: Refer to the illustration below.



(c) Front Washer Operation Check

- (1) Turn the wiper switch to the OFF position.
- (2) Connect the positive battery (+) lead to terminal C10-3 (+B) of the connector and the negative battery (-) lead to terminals C10-4 (+S) and C9-2 (EW).
- (3) Connect the voltmeter (+) terminal to terminal C10-2 (+1) of the connector and the voltmeter (-) terminal to terminal C9-2 (EW). Turn the washer switch to the ON and OFF positions, and measure the voltage between terminals C10-2 (+1) and C9-2 (EW).

Standard: Refer to the illustration on the left.

**Windshield Wiper Switch Assy
Connector Front View:**


H

C10

C9

E68144

**2. WINDSHIELD WIPER SWITCH ASSY (RH POSITION)
(EUROPE)**

- (a) Measure the resistance according to the value(s) in the table below.

Standard:
Front Wiper Switch

Switch position	Tester connection	Specified resistance
MIST	C10-2 (+B) – C10-3 (+1)	Below 1 Ω
OFF	C10-1 (+S) – C10-3 (+1)	Below 1 Ω
INT	C10-1 (+S) – C10-3 (+1)	Below 1 Ω
LO	C10-2 (+B) – C10-3 (+1)	Below 1 Ω
HI	C10-2 (+B) – C10-4 (+2)	Below 1 Ω

Rear Wiper Switch (w/ Rear Wiper)


Switch position	Tester connection	Specified resistance
OFF	C9-2(EW) – C9-6 (C1R), C9-2 (EW) – C9-7 (+1R)	10 k Ω or higher
INT	C9-2 (EW) – C9-6 (C1R)	Below 1 Ω
ON	C9-2 (EW) – C9-7 (+1R)	Below 1 Ω

Front Washer Switch

Switch position	Tester connection	Specified resistance
OFF	C9-2 (EW) – C9-3 (WF)	10 k Ω or higher
ON	C9-2 (EW) – C9-3 (WF)	Below 1 Ω

Rear Washer Switch (w/ Rear Wiper)

Switch position	Tester connection	Specified resistance
OFF	C10-5 (WR) – C9-2 (EW), C9-2 (EW) – C9-7 (+1R)	10 k Ω or higher
ON (WASH1)	C10-5 (WR) – C9-2 (EW)	Below 1 Ω
ON (WASH2)	C10-5 (WR) – C9-2 (EW), C9-2 (EW) – C9-7 (+1R)	Below 1 Ω





(b) Intermittent Operation Check

- (1) Connect the voltmeter (+) terminal to terminal C10-3 (+1) of the connector and the voltmeter (-) terminal to terminal C9-2 (EW).
- (2) Connect the positive battery (+) lead to terminal C10-2 (+B) of the connector and the negative battery (-) lead to terminals C9-2 (EW) and C10-4 (+S).
- (3) Turn the wiper switch to the INT position.
- (4) Connect the positive battery (+) lead to terminal C10-1 (+S) of the connector for 5 seconds.

- (5) Connect the negative battery (-) lead to terminal C10-1 (+S) of the connector. Operate the intermittent wiper relay and measure the voltage between terminals C10-3 (+1) and C9-2 (EW)

Standard: Refer to the illustration below.




(c) Front Washer Operation Check

- (1) Turn the wiper switch to the OFF position.
- (2) Connect the positive battery (+) lead to terminal C10-2 (+B) of the connector, the negative battery (-) lead to terminals C10-1 (+S) and C9-2 (EW).
- (3) Connect the voltmeter (+) terminal to terminal C10-3 (+1) of the connector and the voltmeter (-) terminal to terminal C9-2 (EW).
- (4) Turn the washer switch to the ON and OFF positions, and measure the voltage between terminals C10-3 (+1) and C9-2 (EW).

Standard: Refer to the illustration on the left.

Windshield Wiper Motor Assy
Connector Front View:



P

E34081

3. WINDSHIELD WIPER MOTOR ASSY (LHD STEERING POSITION TYPE)

(a) LO Operation Check

- (1) Connect the positive battery (+) lead to terminal 1 (+1) of the connector, and the negative battery (-) lead to terminal 5 (E), and check that the windshield wiper motor assy operates at low speed (LO).


Standard: The motor operates at low speed (LO).

(b) HI Operation Check

- (1) Connect the positive battery (+) lead to terminal 4 (+2) of the connector, and the negative battery (-) lead to terminal 5 (E), and check that the windshield wiper motor assy operates at high speed (HI).

Standard: The motor operates at high speed (HI).

Windshield Wiper Motor Assy
Connector Front View:



P

E34081

4. WINDSHIELD WIPER MOTOR ASSY (RHD STEERING POSITION TYPE)

(a) LO Operation Check

- (1) Connect the positive battery (+) lead to terminal 5 (+1) of the connector, and the negative battery (-) lead to terminal 4 (E), and check that the windshield wiper motor assy operates at low speed (LO).


Standard: The motor operates at low speed (LO).

(b) HI Operation Check

- (1) Connect the positive battery (+) lead to terminal 3 (+2) of the connector, and the negative battery (-) lead to terminal 4 (E), and check that the windshield wiper motor assy operates at high speed (HI).

Standard: The motor operates at high speed (HI).

Rear Wiper Motor Assy
Connector Front View:



H

E59554


5. REAR WIPER MOTOR ASSY

(a) Operation Check

- (1) Connect the positive battery (+) lead to terminal 3 (+1), and the negative battery (-) lead to terminal 2 (-), and check that the rear wiper motor operates.

Standard: The rear wiper motor operates.

Windshield Wiper Relay Assy Connector Front View:



E65930

6. WINDSHIELD WIPER RELAY ASSY

(a) Operation Check


- (1) Using a voltmeter, connect the voltmeter (+) terminal to terminal 4 (LM) of the connector, and the voltmeter (-) terminal to terminal 6 (LS).
- (2) Connect the positive battery (+) lead to terminal 3 (+B) of the connector, and the negative battery (-) lead to terminal 6 (LS). Measure the voltage between terminals 4 (LM) and 6 (LS).

Standard: 10 to 14 V

(b) Intermittent Operation Check

- (1) Using a voltmeter, connect the voltmeter (+) terminal to terminal 4 (LM) of the connector, and the voltmeter (-) terminal to terminal 2 (C1).
- (2) Connect the positive battery (+) lead to terminal 3 (+B) of the connector, and the negative battery (-) lead to terminal 2 (C1). (Wiper switch is in the INT position.)
- (3) Connect the positive battery (+) lead to terminal 5 (SM) of the connector for approximately 5 seconds.
- (4) Connect the negative battery (-) lead to terminal 5 (SM) of the connector. Measure the voltage between terminals 4 (LM) and 2 (C1) when operating the intermittent wiper relay.

Standard: Refer to the illustration below.




E74254

WINDSHIELD WIPER MOTOR ASSY REPLACEMENT


660H6-01

1. REMOVE FRONT WIPER ARM HEAD CAP
2. REMOVE FRONT WIPER ARM (DRIVER SIDE POSITION)
 - (a) Remove the nut and the FR wiper arm (driver side).
3. REMOVE FRONT WIPER ARM (PASSENGER SIDE POSITION)
 - (a) European specifications:
 - (1) Remove the nut and the FR wiper arm (passenger side).
 - (b) Australian specifications:
 - (1) Remove the 2 nuts and the front wiper arm (passenger side).




4. REMOVE HOOD TO COWL TOP SEAL

- (a) Disengage the 8 clips and remove the hood to cowl top seal.




5. REMOVE COWL TOP VENTILATOR LOUVER LH

- (a) Disengage the 8 claws and clip, and remove the cowl top ventilator louver LH.




6. REMOVE COWL TOP VENTILATOR LOUVER RH

- (a) Disengage the 8 claws and clip, and remove the cowl top ventilator louver RH.




7. REMOVE WINDSHIELD WIPER MOTOR & LINK ASSY

- (a) Disconnect the connector.
- (b) European specifications:
 - (1) Remove the 2 bolts.
 - (2) Move the windshield wiper motor & link assy to the left. Disconnect the rubber pin and remove it.



- (c) Australian specifications:
 - (1) Remove the 5 bolts and the windshield wiper motor & link assy.




8. REMOVE WINDSHIELD WIPER MOTOR ASSY

- (a) European specifications:
 - (1) Using a flat-head screwdriver, disengage the windshield wiper link arm from the crank arm pivot of the windshield wiper motor assy.

HINT:


Tape up the screwdriver tip before use.




- (2) Using a flat-head screwdriver, disengage the windshield wiper link arm from the crank arm pivot of the windshield wiper motor assy.

HINT:

Tape up the screwdriver tip before use.



- (3) Using a torx socket wrench (T30), remove the 2 bolts. Remove the windshield wiper motor assy from the windshield wiper link assy.




(b) Australian specifications:


- (1) Using a flat-head screwdriver, disengage the windshield wiper link arm from the crank arm pivot of the windshield wiper motor assy.

HINT:

Tape up the screwdriver tip before use.



- (2) Remove the 3 bolts and the windshield wiper motor assy.




9. INSTALL WINDSHIELD WIPER MOTOR ASSY

(a) European specifications:

- (1) Using a torx socket wrench (T30), install the windshield wiper motor assy to the windshield wiper link assy with the 2 bolts.

Torque: 7.5 N·m (76 kgf·cm, 66 in·lbf)




(b) Australian specifications:

- (1) Install the windshield wiper motor assy to the windshield wiper link assy with the 3 bolts.

Torque: 5.4 N·m (55 kgf·cm, 48 in·lbf)

- (c) Apply MP grease to the crank arm pivot of the windshield wiper motor assy and install the windshield wiper link arm.




10. INSTALL WINDSHIELD WIPER MOTOR & LINK ASSY


(a) European specifications:

- (1) Clip the windshield motor & link assy to the pins.
- (2) Install the windshield wiper motor & link assy with the 2 bolts.

Torque: 5.5 N·m (56 kgf·cm, 49 in·lbf)




- (b) Australian specifications:
 (1) Install the windshield wiper link assy with the 5 bolts.
Torque: 5.5 N·m (56 kgf·cm, 49 in.·lbf)
 (c) Connect the connector.




11. INSTALL FRONT WIPER ARM (DRIVER SIDE POSITION)

- (a) Clean the wiper arm serration with a round file or equivalent (when reinstalling).
 (b) Clean the wiper pivot serration with a wire brush.

European specifications:



Australian specifications:




- (c) Install the FR wiper arm (driver side) with the nut so that the front wiper blade comes to the position shown in the illustration.

Torque: 21 N·m (214 kgf·cm, 15 ft·lbf)

HINT:

Hold down the arm hinge by hand in order to fasten the nut.




12. INSTALL FRONT WIPER ARM (PASSENGER SIDE POSITION)

- Clean the wiper pivot serration with a wire brush.
- Clean the wiper arm serration with a round file or equivalent (when reinstalling).
- European specifications:
 - Install the FR wiper arm (passenger side) with the nut so that the front wiper blade comes to the position shown in the illustration.

Torque: 21 N·m (214 kgf·cm, 15 ft·lbf)

HINT:

Hold down the arm hinge by hand in order to fasten the nut.



- Australian specifications:
 - Install the FR wiper arm (passenger side) with the 2 nuts so that the front wiper blade comes to the position shown in the illustration.

Torque: 21 N·m (214 kgf·cm, 15 ft·lbf)

- Operate the front wipers while spraying water or washer fluid on the windshield glass. Ensure that the wipers function properly and there is no interference with the body.

WIPER RUBBER REPLACEMENT

660HB-01

1. REMOVE FRONT WIPER BLADE


- (a) Remove the front wiper blade from the front wiper arm.

NOTICE:

Do not fold down the front wiper arm with the front wiper blade removed from it.

2. REMOVE WIPER RUBBER

- (a) Remove the wiper rubber from the front wiper blade.



3. INSTALL WIPER RUBBER

- (a) Install the wiper rubber so that the head part (larger side) of the wiper rubber faces the arm axle side.


NOTICE:

Push the front wiper blade into the grooves of the wiper rubber to engage them completely.

REAR WIPER MOTOR ASSY REPLACEMENT

660HA-01

1. REMOVE REAR WIPER ARM COVER
2. REMOVE REAR WIPER ARM ASSY
 - (a) Remove the nut and the rear wiper arm assy.
3. REMOVE BACK DOOR TRIM BOARD ASSY (SEE PAGE 75-33)
4. REMOVE BACK DOOR TRIM BOARD (SEE PAGE 75-33)




5. REMOVE REAR WIPER MOTOR ASSY
 - (a) Disconnect the connector.
 - (b) Remove the 3 bolts and the rear wiper motor assy.



6. INSTALL REAR WIPER MOTOR ASSY
 - (a) Install the rear wiper motor assy with the 3 bolts.
Torque: 5.5 N·m (56 kgf·cm, 49 in·lbf)
 - (b) Connect the connector.

European specifications:

Wiper Arm Serration

**Australian specifications:**

Wiper Arm Serration



Wiper Pivot Serration


Wire brush

P

I38901


7. INSTALL REAR WIPER ARM ASSY

- (a) Clean the rear wiper arm serration with a round file or equivalent (when reinstalling).
- (b) Clean the rear wiper pivot serration with a wire brush.

European specifications:

Installation Position Mark

P

Australian specifications:

Installation Position Mark

P

I39800
I38902

I40980

- (c) Stop the rear wiper motor assy at the automatic stop position. Install the rear wiper arm assy with the nut in the position shown in the illustration.

Torque: 5.5 N·m (56 kgf·cm, 49 in.·lbf)**HINT:**

Hold down the arm hinge by hand in order to fasten the nut.

- (d) Operate the rear wiper while spraying water or washer fluid on the glass. Ensure that the wiper functions properly and that there is no interference with the body.

REAR WIPER RUBBER REPLACEMENT

660HB-01


1. REMOVE RR WIPER BLADE

(a) European specifications:

- (1) Remove the front wiper blade from the rear wiper arm.

NOTICE:

Do not fold down the rear wiper arm with the rear wiper blade removed from it.




(b) Australian specifications:

- (1) Raise the rear wiper blade to the position as shown in the illustration where the meshing of the claw disengages with a clicking sound. [*1]

NOTICE:


Be careful not to break the claw.



- (2) Pull the rear wiper blade straight away from the rear wiper arm towards the left side of the vehicle at condition [*1].

NOTICE:

Do not fold down the rear wiper arm with the rear wiper blade removed from it.



2. REMOVE REAR WIPER RUBBER


- (a) Pull the end of the wiper rubber protruding from the blade stopper as shown in the illustration.

NOTICE:

Do not pull out the wiper rubber forcibly. If you do, the backing plates will be deformed or the blade claws will be damaged.

HINT:

Lightly pushing the rubber from the ends towards the middle will allow it to be removed more easily.




3. INSTALL REAR WIPER RUBBER


- (a) Install rear wiper rubber backing plate No.1 and No.2 as shown in the illustration.

NOTICE:

Install the backing plates in the correct direction.



- (b) Insert the rear wiper rubber from the front end of the rear wiper blade to the rear end through the second claw.
 (c) After pushing the rear wiper rubber through the rear end side claw, allow it to stick out from the rear end stopper.




- (d) Slide the rear wiper rubber through the front end claw.

WINDSHIELD WIPER SWITCH ASSY

REPLACEMENT

660HC-01

1. DISCONNECT BATTERY NEGATIVE TERMINAL (SEE PAGE 60-1)
2. REMOVE STEERING WHEEL COVER LOWER NO.2 (SEE PAGE 60-20)
3. REMOVE STEERING WHEEL COVER LOWER NO.3 (SEE PAGE 60-20)
4. REMOVE HORN BUTTON ASSY (SEE PAGE 60-20)
5. REMOVE STEERING WHEEL ASSY (SEE PAGE 50-8)
SST 09950-50013 (09951-05010, 09952-05010, 09953-05020, 09954-05021)
6. REMOVE TILT LEVER BRACKET (SEE PAGE 50-8)
7. REMOVE STEERING COLUMN COVER (SEE PAGE 50-8)




8. REMOVE WINDSHIELD WIPER SWITCH ASSY

- (a) Disconnect the connector.
- (b) Push and disengage the claw shown in the illustration and remove the windshield wiper switch assy.

NOTICE:

The claw will be broken if pressed too hard.



9. CENTER SPIRAL CABLE (SEE PAGE 60-29)
10. INSTALL STEERING WHEEL ASSY (SEE PAGE 50-8)
11. INSTALL HORN BUTTON ASSY (SEE PAGE 60-20)
12. CONNECT BATTERY NEGATIVE TERMINAL (SEE PAGE 21-56)
13. INSPECT HORN BUTTON ASSY (SEE PAGE 60-14)
14. INSPECT SRS WARNING LIGHT (SEE PAGE 05-1151)
15. PERFORM INITIALIZATION (SEE PAGE 01-29)

WASHER NOZZLE ADJUSTMENT

660HD-01


1. INSPECT WASHER NOZZLE

- (a) With the power switch on (IG), check the position that the washer fluid hits the windshield.

Standard: Washer fluid hits the windshield in the areas indicated in the illustration.

Front:


European specifications:



This illustration is for LHD.
RHD and LHD are symmetrical.

- A: 820 mm (32.28 in.)
- B: 735 mm (28.94 in.)
- C: 112 mm (4.41 in.)
- D: 90 mm (3.54 in.)
- E: 380 mm (14.96 in.)
- F: 375 mm (14.76 in.)
- G: 555 mm (21.85 in.)
- H: 435 mm (17.13 in.)


Australian specifications:



138405
138406

139803

Rear:



A: 157 mm (6.18 in.)	E: 76 mm (2.99 in.)
B: 110 mm (4.33 in.)	F: 52 mm (2.05 in.)
C: 261 mm (10.28 in.)	G: 163.6 mm (6.44 in.)
D: 301 mm (11.85 in.)	H: 143.6 mm (5.65 in.)

I38900


I39839

2. ADJUST WASHER NOZZLE

- (a) Using a TOYOTA 4 Way Nozzle Adjustment Tool (part number: 95060-10010), insert the bumpy portions of the adjustment tool into the bumpy portions of the nozzle jet and make the adjustment.

NOTICE:

- Clarify which type of washer nozzle is being adjusted, as two types (4 mm and 5 mm diameter types) exist.
- Do not use a metal pin or other such tool as it may damage the nozzle jet.



P

I40986