


DTC	C1336/39	Zero Point Calibration of Deceleration Sensor Undone
-----	----------	--

CIRCUIT DESCRIPTION

DTC No.	DTC Detecting Condition	Trouble Area
C1336/39	After battery terminal was connected, when the shift lever was moved other than to P position within 15 sec. soon after ECU terminal IG1 become ON for the first time.	- Deceleration sensor - Deceleration sensor circuit - P position switch circuit

WIRING DIAGRAM



INSPECTION PROCEDURE


1	Check if zero point calibration of deceleration sensor has done or not.
---	---

Obtains the zero point calibration of the deceleration sensor (See page DI-53).

CHECK:

Check that the VSC indicator light comes on and the both indicators go off after 15 seconds.

YES	No problem.
-----	-------------



2 Check for open and short circuit in harness and connector between P position switch and skid control ECU and ECM (See page IN-30).

NG

Repair or replace harness or connector.

OK

3 Check for open and short circuit in harness and connector between deceleration sensor and skid control ECU (See page IN-30).

NG

Repair or replace harness or connector.

OK

4 Check deceleration sensor (See page DI-113).

NG

Replace deceleration sensor assembly.

OK

Check and replace skid control ECU.