

REMOVAL




1. TABLE OF BOLT, SCREW AND NUT

HINT:

All bolts, screws and nuts relevant to installing and removing the instrument panel are shown along with their alphabet codes in the table below.

IP

mm (in.) (L=Length)

Code	Shape	Code	Shape	Code	Shape
A	 φ=5 (0.20) L=14 (0.55)	B	 φ=8 (0.31) L=15 (0.59)	C	 φ=6 (0.24) L=16 (0.63)

G

B129998E05

2. DISCONNECT CABLE FROM NEGATIVE BATTERY TERMINAL

CAUTION:


Wait at least 90 seconds after disconnecting the cable from the negative (-) battery terminal to prevent airbag and seat belt pretensioner activation.


3. REMOVE INSTRUMENT CLUSTER FINISH PANEL SUB-ASSEMBLY

- (a) Using a screwdriver, detach the 4 clips, 6 claws and remove the instrument cluster finish panel.


HINT:

Tape the screwdriver tip before use.



**4. REMOVE COMBINATION METER ASSEMBLY**


- (a) Remove the 2 screws.
- (b) Pull the combination meter as indicated by the arrow in the illustration to detach the 2 clips.
- (c) Disconnect the connector and remove the combination meter.

**5. REMOVE NO. 2 INSTRUMENT CLUSTER FINISH PANEL CENTER**

- (a) Using a screwdriver, detach the 3 clips, 3claws and remove the cluster finish panel, then disconnect the connector.

HINT:


Tape the screwdriver tip before use.

**6. REMOVE NO. 1 INSTRUMENT CLUSTER FINISH PANEL CENTER**


- (a) Using a screwdriver, detach the 3 clips, 3claws and remove the cluster finish panel, then disconnect the connector.

HINT:

Tape the screwdriver tip before use.

**7. REMOVE RADIO RECEIVER**

- (a) Remove the 4 bolts.
- (b) Detach the 4 clips, remove the radio receiver and then disconnect the connectors.



8. REMOVE INSTRUMENT PANEL REGISTER ASSEMBLY CENTER

- (a) Using a screwdriver, detach the 5 clips and remove the instrument panel register.

HINT:

Tape the screwdriver tip before use.



9. REMOVE GLOVE COMPARTMENT DOOR ASSEMBLY (See page [IP-20](#))


10. REMOVE FRONT PILLAR GARNISH LH (See page [IR-27](#))

11. REMOVE FRONT PILLAR GARNISH RH (See page [IR-28](#))

12. REMOVE UPPER INSTRUMENT PANEL

- (a) Remove the 2 bolts from the passenger airbag.
 (b) Disconnect the passenger airbag connector.
 (c) Remove the 2 bolts and 2 screws.
 (d) Disconnect the connectors and clamps.
 (e) Detach the 6 clips and 5 claws and remove the instrument panel.






DISASSEMBLY


1. REMOVE NO. 1 SIDE DEFROSTER NOZZLE DUCT

- (a) Remove the 3 screws and duct.




2. REMOVE NO. 2 SIDE DEFROSTER NOZZLE DUCT

- (a) Remove the 3 screws and duct.




3. REMOVE NO. 1 HEATER TO REGISTER DUCT

- (a) Remove the screw and duct.



4. REMOVE NO. 2 HEATER TO REGISTER DUCT

- (a) Remove the screw and duct.



5. REMOVE NO. 3 HEATER TO REGISTER DUCT

- (a) Remove the 2 screws and duct.

6. REMOVE NO. 1 INSTRUMENT PANEL REGISTER ASSEMBLY

7. REMOVE NO. 2 INSTRUMENT PANEL REGISTER ASSEMBLY


8. REMOVE FRONT PASSENGER AIRBAG ASSEMBLY (See page [RS-350](#))

9. REMOVE AUTOMATIC LIGHT CONTROL SENSOR
(for Automatic Light Control System)
10. REMOVE COOLER (SOLAR SENSOR) THERMISTOR
(for Automatic Air Conditioning System)


REASSEMBLY

1. **INSTALL COOLER (SOLAR SENSOR) THERMISTOR**
(for Automatic Air Conditioning System)
2. **INSTALL AUTOMATIC LIGHT CONTROL SENSOR**
(for Automatic Light Control System)
3. **INSTALL FRONT PASSENGER AIRBAG ASSEMBLY**
(See page [RS-351](#))
4. **INSTALL NO. 2 INSTRUMENT PANEL REGISTER ASSEMBLY**
5. **INSTALL NO. 1 INSTRUMENT PANEL REGISTER ASSEMBLY**
6. **INSTALL NO. 3 HEATER TO REGISTER DUCT**
(a) Install the duct with the 2 screws.


IP




7. **INSTALL NO. 2 HEATER TO REGISTER DUCT**
(a) Install the duct with the screw.




8. **INSTALL NO. 1 HEATER TO REGISTER DUCT**
(a) Install the duct with the screw.



**9. INSTALL NO. 2 SIDE DEFROSTER NOZZLE DUCT**

(a) Install the duct with the 3 screws.



**10. INSTALL NO. 1 SIDE DEFROSTER NOZZLE DUCT**

(a) Install the duct with the 3 screws.

INSTALLATION

1. INSTALL UPPER INSTRUMENT PANEL


- (a) Attach the 6 clips and 5 claws to install the instrument panel.
- (b) Connect the connectors and clamps.
- (c) Install the 2 bolts and 2 screws.



- (d) Connect the passenger airbag connector.

- (e) Install the 2 bolts to the passenger airbag.
Torque: 20 N*m (204 kgf*cm, 15 ft.*lbf)


2. INSTALL FRONT PILLAR GARNISH LH (See page [IR-57](#))
3. INSTALL FRONT PILLAR GARNISH RH (See page [IR-58](#))
4. INSTALL GLOVE COMPARTMENT DOOR ASSEMBLY (See page [IP-25](#))




5. INSTALL INSTRUMENT PANEL REGISTER ASSEMBLY CENTER

- (a) Attach the 5 clips to install the instrument panel register.


IP

**6. INSTALL RADIO RECEIVER**


- (a) Connect the connectors.
- (b) Attach the 4 clips to install the radio receiver.
- (c) Install the 4 bolts.

**7. INSTALL NO. 1 INSTRUMENT CLUSTER FINISH PANEL CENTER**


- (a) Connect the connector.
- (b) Attach the 3 clips and 3 claws to install the cluster finish panel.

**8. INSTALL NO. 2 INSTRUMENT CLUSTER FINISH PANEL CENTER**

- (a) Connect the connector.
- (b) Attach the 3 clips and 3 claws to install the cluster finish panel.

**9. INSTALL COMBINATION METER ASSEMBLY**

- (a) Connect the connector.
- (b) Attach the 2 clips to install the combination meter.
- (c) Install the 2 screws.

**10. INSTALL INSTRUMENT CLUSTER FINISH PANEL SUB-ASSEMBLY**

- (a) Attach the 4 clips and 6 claws to install the instrument cluster finish panel.

11. CONNECT CABLE TO NEGATIVE BATTERY TERMINAL**12. CHECK SRS WARNING LIGHT**







- (a) Check the SRS warning light (see page [RS-37](#)).

REMOVAL

1. TABLE OF BOLT, SCREW AND NUT

HINT:

All bolts, screws and nuts relevant to installing and removing the instrument panel are shown along with their alphabet codes in the table below.

mm (in.) (L=Length)					
Code	Shape	Code	Shape	Code	Shape
(A)	 $\varphi=5$ (0.20) L=14 (0.55)	(B)	 $\varphi=6$ (0.24) L=14 (0.55)	(C)	 $\varphi=5$ (0.20) L=16 (0.63)
(D)	 $\varphi=6$ (0.24) L=20 (0.79)	(E)	 $\varphi=7$ (0.28) L=20 (0.79)	(F)	 $\varphi=6$ (0.24) L=22 (0.87)

G

B129999E01


2. DISCONNECT CABLE FROM NEGATIVE BATTERY TERMINAL

CAUTION:

Wait at least 90 seconds after disconnecting the cable from the negative (-) battery terminal to prevent airbag and seat belt pretensioner activation.

- REMOVE INSTRUMENT PANEL SUB-ASSEMBLY
 - Remove the instrument panel (see page [IP-4](#)).
- REMOVE STEERING PAD ASSEMBLY (See page [RS-336](#))
- REMOVE STEERING WHEEL ASSEMBLY (See page [SR-12](#))
- REMOVE STEERING COLUMN COVER (See page [SR-12](#))
- REMOVE SPIRAL CABLE SUB-ASSEMBLY (See page [RS-346](#))
- REMOVE HEADLIGHT DIMMER SWITCH ASSEMBLY
- REMOVE WINDSHIELD WIPER SWITCH ASSEMBLY
- REMOVE HEATER CONTROL SUB-ASSEMBLY (for Automatic Air Conditioning System) (See page [AC-241](#))
- REMOVE HEATER CONTROL SUB-ASSEMBLY (for Manual Air Conditioning System) (See page [AC-243](#))


IP

**12. REMOVE NO. 1 CONSOLE UPPER PANEL GARNISH**

- (a) Using a screwdriver, detach the 4 clips and upper panel garnish.

HINT:


Tape the screwdriver tip before use.

**13. REMOVE NO. 2 CONSOLE UPPER PANEL GARNISH**

- (a) Using a screwdriver, detach the 4 clips and upper panel garnish.

HINT:


Tape the screwdriver tip before use.

**14. REMOVE UPPER CONSOLE PANEL SUB-ASSEMBLY**


- (a) Remove the shift lever knob.
 (b) Using a screwdriver, detach the 2 clips, 4 claws and remove the upper console panel then disconnect the connector.

HINT:


Tape the screwdriver tip before use.

**15. REMOVE SWITCH BASE**


- (a) Detach the 2 clips and 2 claws.
- (b) Disconnect the connectors and remove the switch base.

**16. REMOVE CONSOLE CUP HOLDER BOX**


- (a) Remove the 2 screws.
- (b) Detach the 2 clips and remove the cup holder box.

**17. REMOVE UPPER REAR CONSOLE PANEL SUB-ASSEMBLY**


- (a) Using a screwdriver, detach the 4 claws and 2 clips.
HINT:
Tape the screwdriver tip before use.
- (b) Disconnect the connector and remove the upper rear console panel.

**18. REMOVE CONSOLE REAR END PANEL**

- (a) Using a screwdriver, detach the 6 claws and remove the console rear end panel.
HINT:
Tape the screwdriver tip before use.


**19. REMOVE CONSOLE REAR END PANEL (RSE Type)**

- (a) Using a screwdriver, detach the 4 claws, 2 clips and remove the console rear end panel then disconnect the connectors.
HINT:
Tape the screwdriver tip before use.




20. REMOVE NO. 1 INSTRUMENT PANEL BRACKET COVER INNER LH

- (a) Detach the 2 claws and remove the instrument panel bracket cover.




21. REMOVE NO. 1 INSTRUMENT PANEL BRACKET COVER INNER RH

- (a) Detach the 2 claws and remove the instrument panel bracket cover.



22. REMOVE REAR CONSOLE BOX SUB-ASSEMBLY

- (a) Remove the console box carpet.
- (b) Remove the 2 bolts and 2 screws.
- (c) Disconnect the connector and remove the rear console box.




23. REMOVE LOWER INSTRUMENT PANEL FINISH PANEL


- (a) Remove the 2 screws.
- (b) Using a screwdriver detach the 8 claws and remove the lower instrument panel finish panel.

HINT:


Tape the screwdriver tip before use.

**24. REMOVE NO. 2 INSTRUMENT PANEL UNDER COVER SUB-ASSEMBLY**


- (a) Detach the 2 claws and remove the instrument panel under cover.

**25. REMOVE GLOVE COMPARTMENT DOOR ASSEMBLY**

- (a) Open the glove compartment door.
(b) Detach the claw from the glove compartment door stopper.
(c) While pushing in the sides of the glove compartment door as indicated by the arrows in the illustration, open the door to release it from the 2 stoppers.




- (d) Open the door until it is horizontal.




- (e) Pull the glove compartment door toward the rear of the vehicle to detach the 2 hinges and remove the glove compartment door.

IP

**26. REMOVE NO. 1 SWITCH HOLE BASE**


- (a) Using a screwdriver, detach the 4 clips.
- (b) Disconnect the connectors and remove the switch hole base.

**27. REMOVE INSTRUMENT PANEL SAFETY PAD COVER**

- (a) Using a screwdriver, detach the 4 claws and remove the instrument panel safety pad cover.

HINT:


Tape the screwdriver tip before use.

**28. REMOVE INSTRUMENT PANEL BOX**

- (a) Remove the screw.
- (b) Using a screwdriver, detach the 6 clips and remove the instrument panel box.

HINT:


Tape the screwdriver tip before use.

**29. REMOVE POWER STEERING ECU ASSEMBLY**

- (a) Disconnect the connectors.
- (b) Remove the 3 nuts and ECU.


30. REMOVE LOWER INSTRUMENT PANEL

- (a) Remove the 2 bolts, 3 screws and 2 clips.
- (b) Disconnect the connectors and clamps and remove the lower instrument panel.




DISASSEMBLY

1. REMOVE GLOVE COMPARTMENT DOOR STOPPER SUB-ASSEMBLY
2. REMOVE STEREO JACK ADAPTER ASSEMBLY
 - (a) Detach the 2 claws and remove the stereo jack adapter.



REASSEMBLY


1. INSTALL STEREO JACK ADAPTER ASSEMBLY
 - (a) Attach the 2 claws to install the stereo jack adapter.
2. INSTALL GLOVE COMPARTMENT DOOR STOPPER SUB-ASSEMBLY



INSTALLATION

1. INSTALL LOWER INSTRUMENT PANEL

- Connect the connectors and clamps and install the lower instrument panel.
- Install the 2 bolts, 3 screws and 2 clips.




IP

B129871


2. INSTALL POWER STEERING ECU ASSEMBLY

- Install the ECU with the 3 nuts.
- Connect the connectors.




C128905E01


IP

**3. INSTALL INSTRUMENT PANEL BOX**


- (a) Attach the 6 clips to install the instrument panel box.
- (b) Install the screw.

**4. INSTALL INSTRUMENT PANEL SAFETY PAD COVER**


- (a) Attach the 4 claws to install the instrument panel safety pad cover.

**5. INSTALL NO. 1 SWITCH HOLE BASE**


- (a) Connect the connectors.
- (b) Attach the 4 clips to install the switch hole base.

**6. INSTALL GLOVE COMPARTMENT DOOR ASSEMBLY**

- (a) Attach the 2 hinges to install the door.




- (b) Attach the claw to the glove compartment door stopper.
- (c) While pushing in the sides of the glove compartment door as indicated by the arrows in the illustration, close the door to engage it to the 2 stoppers.




7. INSTALL NO. 2 INSTRUMENT PANEL UNDER COVER SUB-ASSEMBLY

- (a) Attach the 2 claws to install the instrument panel under cover.




8. INSTALL LOWER INSTRUMENT PANEL FINISH PANEL

- (a) Attach the 8 claws to install the lower instrument panel finish panel.
- (b) Install the 2 screws.




9. INSTALL REAR CONSOLE BOX SUB-ASSEMBLY

- (a) Connect the connector.
- (b) Install the rear console box with the 2 bolts and 2 screws.
- (c) Install the console box carpet.




10. INSTALL NO. 1 INSTRUMENT PANEL BRACKET COVER INNER LH

- (a) Attach the 2 claws to install the instrument panel bracket cover.




11. INSTALL NO. 1 INSTRUMENT PANEL BRACKET COVER INNER RH

- (a) Attach the 2 claws to install the instrument panel bracket cover.




12. INSTALL CONSOLE REAR END PANEL

- (a) Attach the 6 claws to install the console rear end panel.




13. INSTALL CONSOLE REAR END PANEL (RSE Type)

- (a) Attach the 2 clips and 4 claws to install the console rear end panel.




14. INSTALL UPPER REAR CONSOLE PANEL SUB-ASSEMBLY


- (a) Connect the connector.
(b) Attach the 4 clips to install the upper rear console panel.

**15. INSTALL CONSOLE CUP HOLDER BOX**


- (a) Attach the 2 clips to install the cup holder box.
- (b) Install the 2 screws.

**16. INSTALL SWITCH BASE**


- (a) Connect the connectors.
- (b) Attach the 2 clips and 2 claws to install the switch base.

**17. INSTALL UPPER CONSOLE PANEL SUB-ASSEMBLY**

- (a) Connect the connector.
- (b) Attach the 2 clips and 4 claws to install the upper console panel.
- (c) Install the shift lever knob.

**18. INSTALL NO. 2 CONSOLE UPPER PANEL GARNISH**

- (a) Attach the 4 clips to install the upper panel garnish.

**19. INSTALL NO. 1 CONSOLE UPPER PANEL GARNISH**

- (a) Attach the 4 clips to install the upper panel garnish.

20. INSTALL HEATER CONTROL SUB-ASSEMBLY (for Automatic Air Conditioning System) (See page AC-241)**21. INSTALL HEATER CONTROL SUB-ASSEMBLY (for Manual Air Conditioning System) (See page AC-244)****22. INSTALL WINDSHIELD WIPER SWITCH ASSEMBLY****23. INSTALL HEADLIGHT DIMMER SWITCH ASSEMBLY**

24. **INSTALL SPIRAL CABLE SUB-ASSEMBLY** (See page [RS-347](#))
25. **INSTALL STEERING COLUMN COVER** (See page [SR-20](#))
26. **INSTALL STEERING WHEEL ASSEMBLY** (See page [SR-21](#))
27. **INSTALL STEERING PAD ASSEMBLY** (See page [RS-336](#))
28. **INSTALL INSTRUMENT PANEL SUB-ASSEMBLY**
 - (a) Install the instrument panel (see page [IP-9](#)).
29. **CONNECT CABLE TO NEGATIVE BATTERY TERMINAL**
30. **CHECK SRS WARNING LIGHT**
 - (a) Check the SRS warning light (see page [RS-37](#)).


UPPER INSTRUMENT PANEL

PRECAUTION


1. **PRECAUTION FOR VEHICLE WITH SRS AIRBAG AND SEAT BELT PRETENSIONER**
 - (a) Some operations in this section may affect the SRS airbags and seat belt pretensioner. Prior to performing the corresponding operations, read the SRS airbag NOTICE (see page [RS-1](#)).

COMPONENTS

IP



N*m (kgf*cm, ft.*lbf) : Specified torque




LOWER INSTRUMENT PANEL

PRECAUTION

1. PRECAUTION FOR VEHICLE WITH SRS AIRBAG AND SEAT BELT PRETENSIONER



- (a) Some operations in this section may affect the SRS airbags and seat belt pretensioner. Prior to performing the corresponding operations, read the SRS airbag NOTICE (see page [RS-1](#)).

COMPONENTS





N*m (kgf*cm, ft.*lbf) : Specified torque

IP



N*m (kgf*cm, ft.*lbf) : Specified torque

NO. 1 INSTRUMENT PANEL
BRACKET COVER INNER RHNO. 1 INSTRUMENT PANEL
BRACKET COVER INNER LH

SHIFT LEVER KNOB

UPPER CONSOLE PANEL
SUB-ASSEMBLY




SWITCH BASE

UPPER REAR CONSOLE
PANEL SUB-ASSEMBLY


NO. 2 CONSOLE UPPER PANEL GARNISH




CONSOLE BOX CARPET

NO. 1 CONSOLE UPPER PANEL
GARNISH

CONSOLE CUP HOLDER BOX



REAR CONSOLE BOX SUB-ASSEMBLY


CONSOLE REAR END PANEL
(RSE Type)

CONSOLE REAR END PANEL



IP

STEREO JACK ADAPTER ASSEMBLY



B136011E01