


Oldsmobile Alero 1999 fuse box diagram

Instrument panel fuse box

Driver's Side




Oldsmobile Alero – fuse box – instrument panel

(driver's side)

Fuse	Usage
RADIO SW	Steering Wheel Radio Switches
RADIO ACC	Radio
WIPER	Windshield Wiper Motor, Washer Pump
TRUNK REL/RFA/RADIO AMP	Trunk Release Relay/Motor, RKE, Audio Amplifier
TURN LPS	Turn Signal Lamps
PWR MIRROR	Power Mirrors
AIR BAG	Air Bags
BFC BATT	Body Computer (BFC)
PCM ACC	PCM
DR LOCK	Door Lock Motors
IPC/BFC ACC	Cluster, Body Computer (BFC)
STOP LPS	Stop Lamps
HAZARD LPS	Hazard Lamps
IPC/HVAC BATT	HVAC Head, Cluster, Data Link Connector

Circuit Breaker	Usage
PWR SEAT	Power Seats

Passenger's Side




Oldsmobile Alero – fuse box – instrument panel

(passenger's side)

Fuse	Usage
INST LPS	Interior Lamp Dimming
CRUISE SW LPS	Steering Wheel Cruise Control Switch Lamps
CRUISE SW	Steering Wheel Cruise Control Switches
HVAC BLOWER	HVAC Blower Motor
CRUISE	Cruise Control
FOG LPS	Fog Lamps
INT LPS	Interior Courtesy Lamps
RADIO BATT	Radio
SUNROOF	Power Sunroof
Circuit Breaker	Usage
PWR WNDW	Power Windows

Engine compartment fuse block



Oldsmobile Alero – fuse box – engine

compartment

Fuse	Usage
Maxi-Fuses	
1	Ignition Switch
2	Left-Hand Electrical Center-Power Seats, Power Mirrors, Door Locks, Trunk Release, Audio Amplifier, Remote Lock Control
3	Left-Hand Electrical Center-Stop Lamps, Hazard Lamps, Body Function Control Module, Cluster, Climate Control System
4	Right-Hand Electrical Center-Fog Lamps, Radio, Body Function Control Module, Interior Lamps
5	Ignition Switch
6	Not Used
7	Anti-Lock Brakes
8	Cooling Fan #1
Mini-Relays	
9	Rear Defog
10	Not Used
11	Anti-Lock Brakes
12	Cooling Fan #1
13	HVAC Blower (Climate Control)
14	Cooling Fan #2
15	Cooling Fan #2
Micro-Relays	
16	Air Conditioning Compressor
17	Not Used
18	Fuel Pump
19	Automatic Light Control
20	Automatic Light Control
21	Horn
22	Daytime Running Lamps
Mini-Fuses	
23	Spare Fuse Holder
24	Spare Fuse Holder
25	Spare Fuse Holder
26	Spare Fuse Holder
27	Spare Fuse Holder
28	Spare Fuse Holder
29	Spare Fuse Holder
30	Spare Fuse Holder
31	Spare Fuse Holder
32	Spare Fuse Holder

33	Rear Defog
34	Accessory Power Outlets, Cigarette Lighter
35	Anti-Lock Brakes
36	Anti-Lock Brakes, Variable Effort Steering
37	Air Conditioning Compressor, Body Function Control Module
38	Automatic Transaxle
39	Powertrain Control Module
40	Anti-Lock Brakes
41	Ignition System
42	Back-Up Lamps, Brake Transaxle Shift Interlock
43	Horn
44	Powertrain Control Module
45	Parking Lamps
46	Rear Defog, Daytime Running Lamps, Climate Control System
47	Canister Vent Valve, Exhaust Oxygen Sensors
48	Fuel Pump, Injectors
49	Generator
50	Right-Hand Headlamp
51	Left-Hand Headlamp
52	Cooling Fan
53	HVAC Blower (Climate Control)
54	Not Used
55	Not Used
56	Fuse Puller for Mini Fuses
57	Not Used