

Follow the Severe Conditions Maintenance Schedule if the vehicle is driven in Canada or MAINLY under one or more of the Severe Driving Conditions (page 3-11):

Service at the indicated distance or time whichever comes first.	miles x 1,000	15	30	45	60	75	90	105	120	NOTE	SECTION and PAGE
	km x 1,000	24	48	72	96	120	144	168	192		
	months	12	24	36	48	60	72	84	96		
Replace engine oil and oil filter	Every 3,750 miles (6,000 km) or 6 months									Capacity for change with filter: 4.6 ℓ (4.9 US qt, 4.0 Imp qt)	8-4,8-5
Check engine oil and coolant	Check oil and coolant at each fuel stop									Check levels and check for leaks.	8-4, 10-5
Clean (○) or replace (●) air cleaner element Use normal schedule except in dusty conditions	○	●	○	●	○	●	○	●			11-153
Replace spark plugs								●		NGK: PFR5L-11 DENSO: PK 16PR-L11 Standard gap: 1.0 – 1.1 mm (0.039 – 0.043 in) Service limit: 1.3 mm (0.051 in)*1	4-22
Replace timing belt*2, balancer belt*2, and inspect water pump								●		Check water pump for signs of seal leakage.	6-8 to 6-13, 10-10
Inspect and adjust drive belts		●		●		●		●		Check for cracks and damage. Check deflection and tension at center of alternator belt pressing with 98 N (10 kgf, 22 lbf) tension: Alternator drive belt: 9.5 – 11.5 mm (0.37 – 0.45 in) P/S pump belt: 10.5 – 12.5 mm (0.41 – 0.49 in) A/C Compressor belt: 8.0 – 11 mm (0.31 – 0.43 in)	4-33, 17-15, 22-85
Inspect idle speed								●		650 ± 50 rpm (in N or P position)	11-124
Replace engine coolant			●		●		●			Capacity for change: 6.1 ℓ (6.4 US qt, 5.4 Imp qt) Check specific gravity for freezing point.	10-5
Replace transmission fluid		●		●		●		●		3.0 ℓ (3.2 US qt, 2.6 Imp qt) for change with Genuine Honda Premium Formula ATF	14-108
Replace front differential fluid		●	●	●	●	●	●	●	●	Capacity for change; 1.05 ℓ (1.11 US qt, 0.92 Imp qt)	15-4
Inspect front and rear brakes	Every 7,500 miles (12,000 km) or 6 months									• Check the brake pad and disc thickness. Check for damage and cracks. • Check the calipers for damage, leaks, and tightness.	19-10, 19-11, 12, 17, 18, 19,23
Replace brake fluid (Including ABS)			●			●				Use Genuine Honda DOT3 brake fluid. Check that brake fluid level is between the upper and lower marks on the reservoir.	19-8
Check parking brake adjustment	●	●	●	●	●	●	●	●	●	Check the parking brake operation. Fully engaged 6 to 8 notches.	19-6
Replace air conditioning filter*3		●		●		●		●			22-68
Rotate tires (Check the inflation and condition at least once per month)	Rotate tires every 7,500 miles (12,000 km)									The suggested rotation method is shown in the diagram in the Owner's Manual.	—
Lubricate all hinges, locks, and latches	●	●	●	●	●	●	●	●	●	Lubricate all hinges, latches, and locks.	3-2, 3-3

*1: Do not adjust the gap, replace the spark plug if it is out of service limit.

*2: Replace the timing belt and timing balancer belt at 60,000 miles (U.S.) 100,000 km (Canada) if the vehicle regularly is driven in one or more of these conditions:

- In very high temperatures (over 110°F, 43°C).
- In very low temperatures (under -20°F, -29°C).

*3: Replace every 15,000 miles (24,000 km) if the vehicle is driven primarily in urban areas that have high concentrations of soot in the air from industry and diesel-powered vehicles. Replace the air conditioning filter more often if air flow from the climate control system becomes less than usual.

Service at the indicated distance or time whichever comes first.	miles x 1,000	15	30	45	60	75	90	105	120	NOTE	SECTION and PAGE
	km x 1,000	24	48	72	96	120	144	168	192		
	months	12	24	36	48	60	72	84	96		
Visually inspect the following items:										• Check for correct installation and position, check for cracks, deterioration, rust, and leaks. • Check tightness of screws, nuts, and joints. If necessary, retighten.	_____
Tie-rod ends, steering gear box, and boots	Every 7,500 miles (12,000 km) or 6 months									• Check rack grease and steering linkage. • Check the boots for damage and leaking grease. • Check the fluid line for damage and leaks.	17-14, 17-23
Suspension components										Check the bolts for tightness. Check all boots for deterioration and damage.	18-3, 21, 22
Driveshaft boots										Check boots and boot bands for cracks. Check rack grease.	16-3
Brake hoses and lines [including ABS]	●	●	●	●	●	●	●	●	Check the master cylinder, proportioning control valve, and ABS modulator for damage and leakage.	19-28	
All fluid levels and condition of fluids									Check levels and check for leaks. If necessary, add transmission fluid, engine coolant, brake fluid, wind-shield washer fluid.	8-4, 10-5, 14-108, 15-4, 17-16, 19-8	
Cooling system hoses and connections									Check all hoses for damage, leaks, and deterioration. Check all hose clamps. Retighten if necessary.	10-2	
Exhaust system*									Check the catalytic converter heat shield, exhaust pipe, and muffler for damage, leaks, and tightness.	9-5	
Fuel lines, and connections*									Check fuel lines for loose connections, cracks, and deterioration. Retighten loose connections and replace any damaged parts.	11-126	
Lights and controls									Check all light functions and headlight position.	23-123	
Vehicle underbody									Check the paint for damages, scratches, stone chipping, and dents.	_____	

According to state and federal regulations, failure to perform maintenance on the items marked with an asterisk (*) will not void customer's emission warranties. However, Acura recommends that all maintenance services be performed at the recommended time or mileage period to ensure long-term reliability.

Severe Driving Conditions:

- Driving less than 5 miles (8 km) per trip or, in freezing temperatures, driving less than 10 miles (16 km) per trip.
- Driving in hot [over 90°F (32°C)] conditions.
- Extensive idling or long periods of stop-and-go driving.
- Trailer towing, driving with a roof-top carrier, or driving in mountainous conditions.
- Driving on muddy, dusty, or de-iced roads.

NOTE: If the vehicle is driven OCCASIONALLY under a "severe" condition, you should follow the Normal Conditions Maintenance Schedule on pages 3-8 and 3-9.

