

A

B

C

D

E

F

STC

H

I

J

K

L

M

N

O

P

SECTION **STC**

STEERING CONTROL SYSTEM

CONTENTS

BASIC INSPECTION	3	C1608 CONTROL UNIT	13
DIAGNOSIS AND REPAIR WORKFLOW	3	Description	13
Work Flow	3	DTC Logic	13
FUNCTION DIAGNOSIS	4	Diagnosis Procedure	13
EPS SYSTEM	4	Special Repair Requirement	14
System Diagram	4	U1200 VEHICLE SPEED SIGNAL (ABS)	15
System Description	4	Description	15
Component Parts Location	4	DTC Logic	15
Component Description	6	Diagnosis Procedure	15
DIAGNOSIS SYSTEM (EPS CONTROL UNIT)	7	Special Repair Requirement	15
CONSULT-III Function (EPS)	7	U14FF VEHICLE SPEED SIGNAL (METER) ...	16
COMPONENT DIAGNOSIS	8	Description	16
C1601 BATTERY POWER SUPPLY	8	DTC Logic	16
Description	8	Diagnosis Procedure	16
DTC Logic	8	Special Repair Requirement	16
Diagnosis Procedure	8	U1000 CAN COMM CIRCUIT	17
Special Repair Requirement	9	Description	17
C1604 TORQUE SENSOR	10	DTC Logic	17
Description	10	Diagnosis Procedure	17
DTC Logic	10	Special Repair Requirement	17
Diagnosis Procedure	10	ECU DIAGNOSIS	18
Special Repair Requirement	10	EPS CONTROL UNIT	18
C1606 EPS MOTOR	11	Reference Value	18
Description	11	Wiring Diagram - ELECTRONICALLY CON-	
DTC Logic	11	TROLLED POWER STEERING SYSTEM -	19
Diagnosis Procedure	11	Fail-Safe	22
Special Repair Requirement	11	DTC No. Index	22
C1607 EEPROM	12	SYMPTOM DIAGNOSIS	24
Description	12	EPS WARNING LAMP DOES NOT TURN ON...24	
DTC Logic	12	Diagnosis Procedure	24
Diagnosis Procedure	12	EPS WARNING LAMP DOES NOT TURN	
Special Repair Requirement	12	OFF	25
		Diagnosis Procedure	25

STEERING WHEEL TURNING FORCE IS HEAVY OR LIGHT	27
Diagnosis Procedure	27
UNBALANCE STEERING WHEEL TURNING FORCE AND RETURN BETWEEN RIGHT AND LEFT	28
Diagnosis Procedure	28
UNBALANCE STEERING WHEEL TURNING FORCE (TORQUE VARIATION)	29
Diagnosis Procedure	29

PRECAUTION	30
PRECAUTIONS	30
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER"	30
Precaution Necessary for Steering Wheel Rota- tion After Battery Disconnect	30
Service Notice or Precautions for EPS System	30
ON-VEHICLE REPAIR	32
EPS CONTROL UNIT	32
Removal and Installation	32

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000000943735

DETAILED FLOW

1. COLLECT THE INFORMATION FROM THE CUSTOMER

Get the detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred) using the diagnosis worksheet.

>> GO TO 2.

2. PERFORM THE SELF-DIAGNOSIS

Check the DTC display with the self-diagnosis function. Refer to [STC-7, "CONSULT-III Function \(EPS\)"](#).

Is there any DTC displayed?

YES >> GO TO 3.

NO >> GO TO 4.

3. PERFORM THE SYSTEM DIAGNOSIS

Perform the diagnosis applicable to the displayed DTC. Refer to [STC-22, "DTC No. Index"](#).

>> GO TO 6.

4. CHECK THE WARNING LAMP FOR ILLUMINATION

Check that the warning lamp illuminate.

Is ON/OFF timing normal?

YES >> GO TO 5.

NO >> GO TO 2.

5. PERFORM THE DIAGNOSIS BY SYMPTOM

Perform the diagnosis applicable to the symptom.

>> GO TO 6.

6. REPAIR OR REPLACE THE MALFUNCTIONING PARTS

Repair or replace the specified malfunctioning parts.

>> GO TO 7.

7. FINAL CHECK

Perform the self-diagnosis again, and check that the malfunction is repaired completely. After checking, erase the self-diagnosis memory. Refer to [STC-7, "CONSULT-III Function \(EPS\)"](#).

Is no other DTC present and the repair completed?


YES >> INSPECTION END

NO >> GO TO 3.

FUNCTION DIAGNOSIS

EPS SYSTEM

System Diagram



System Description

INFOID:0000000000940471

- EPS control unit performs an arithmetical operation on data, such as steering wheel turning force (sensor signal) from the torque sensor, vehicle speed signal, etc. Then it generates an optimum assist torque to the EPS motor according to the driving condition.
- EPS control unit decreases the output to EPS motor while extremely using the power steering function (e.g., full steering) for protecting EPS motor and EPS control unit (Protect overload status). While activating protect overload status, the assist torque gradually decreases, and the steering wheel turning force becomes heavy. The normal assist torque reactivates by not steering.
- In case of an error in the electrical system, the fail-safe function stops output signals to the EPS motor. Then the previous state is changed to the manual steering state.
- Self-diagnosis can be done with CONSULT-III.
- EPS control unit will decrease assistance under 2 conditions.
 - Extensive steering at low speed will cause the ECU and MOTOR to heat up, once temperature reaches critical point ECU will reduce current to reduce heat up. System will recover as temperature lowers (reduced or no assistance).
 - Holding steering on rack-end (full lock) for 1 second will cause the system to engage rack-end protection. This reduces assistance down to 40% in order to prevent heat up. Assistance is immediately returned to 100% when steering released or turned away from rack-end.


Component Parts Location

INFOID:0000000000940472

EPS SYSTEM

< FUNCTION DIAGNOSIS >

LHD models



- 1. EPS warning lamp
- 4. Torque sensor
- A. Combination meter


- 2. EPS control unit
- 5. Reduction gear
- B. Steering column assembly

- 3. EPS motor

EPS SYSTEM

< FUNCTION DIAGNOSIS >

RHD models



- 1. EPS warning lamp
- 2. EPS control unit
- 3. EPS motor
- 4. Torque sensor
- 5. Reduction gear
- A. Combination meter
- B. Steering column assembly

Component Description

INFOID:000000000940473

Components parts	Reference
EPS control unit	STC-13, "Description"
EPS motor	STC-11, "Description"
Torque sensor	STC-10, "Description"
Reduction gear	Reduction gear increases the assist torque provided from EPS motor with worm gears, and outputs to the column shaft.
EPS warning lamp	Turn on when a malfunction occurs in the EPS system, and tells the driver the malfunction.

DIAGNOSIS SYSTEM (EPS CONTROL UNIT)

< FUNCTION DIAGNOSIS >

DIAGNOSIS SYSTEM (EPS CONTROL UNIT)

CONSULT-III Function (EPS)

INFOID:000000000949820

FUNCTION

CONSULT-III can display each diagnostic item using the diagnostic test modes shown following.

Diagnostic test mode	Function
Self-diagnostic results	Self-diagnostic results can be read and erased quickly.
Data monitor	Input/Output data in the EPS control unit can be read.
ECU part number	EPS control unit part number can be read.
CAN diagnostic support monitor	The results of transmit/receive diagnosis of CAN communication can be read.

SELF-DIAG RESULTS MODE

Display Item List

Refer to [STC-22, "DTC No. Index"](#).

DATA MONITOR MODE

Display Item List

Monitor item (Unit)	Remarks
BATTERY VOLT (V)	Displays the power supply voltage for EPS control unit.
TORQUE SENSOR (Nm)	Displays steering wheel turning force detected by torque sensor.
MOTOR SIG (A)	Displays the current commanded value to EPS motor.
MOTOR CURRENT (A)	Displays the current value consumed by EPS motor.
ASSIST TORQUE (Nm)	Displays assist torque being output by the electric power steering.
C/U TEMP (°C)	Displays the temperature of the EPS control unit.
ASSIST LEVEL (%)	Normally displays 100%. In case of an excessive stationary steering, the assist curvature gradually falls. However, it return to 100% when left standing.
VEHICLE SPEED (km/h) or (MPH)	Vehicle speed is displayed from vehicle speed signal with CAN communication.
WARNING LAMP (On/Off)	EPS warning lamp control status is displayed.
ENGINE STATUS (STOP/RUN)	Engine speed is displayed from engine status signal with CAN communication.
MOTOR TEMP (°C)	Displays the temperature of EPS motor.
VHCL SPD CALC (km/h) or (MPH)	Displays vehicle speeds used for controlling EPS.

C1601 BATTERY POWER SUPPLY

< COMPONENT DIAGNOSIS >

COMPONENT DIAGNOSIS

C1601 BATTERY POWER SUPPLY

Description

INFOID:000000000940491

Power is supplied from the battery to EPS control unit.

DTC Logic

INFOID:000000000940492

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1601	BATTERY VOLT	When the power supply malfunction supplied to EPS control unit is detected.	• Harness or connector • EPS control unit

DTC CONFIRMATION PROCEDURE

1.CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

Self-diagnosis results
BATTERY VOLT

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [STC-8. "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000000940494

1.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect EPS control unit harness connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connector and then perform self-diagnosis. Refer to [STC-7. "CONSULT-III Function \(EPS\)"](#).

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 2.
NO >> Poor connection of connector terminal. Repair or replace connector.

2.CHECK EPS CONTROL UNIT POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect EPS control unit harness connector.
3. Turn ignition switch ON. (Do not start engine.)
4. Check voltage between EPS control unit harness connector terminals and ground.

EPS control unit		—	Voltage
Connector	Terminal		
M38	1	Ground	Battery voltage
M37	10		

5. Turn ignition switch OFF.
6. Check voltage between EPS control unit harness connector terminals and ground.

C1601 BATTERY POWER SUPPLY

< COMPONENT DIAGNOSIS >

EPS control unit		—	Voltage
Connector	Terminal		
M38	1	Ground	Battery voltage
M37	10		Approx. 0 V

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace malfunctioning components.

3.CHECK EPS CONTROL UNIT GROUND CIRCUIT

1. Check continuity between EPS control unit harness connector terminal and ground.

EPS control unit		—	Continuity
Connector	Terminal		
M38	2	Ground	Existed

2. Connect EPS control unit harness connector.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

4.CHECK DTC

Start engine.

Does EPS warning lamp turn OFF?

YES >> EPS control unit is malfunction. Replace steering column assembly.

NO >> Perform self-diagnosis, repair or replace damaged parts.

Special Repair Requirement

INFOID:000000000956134

1.AJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the EPS control unit. Refer to [BRC-78, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#). (With ESP models)

>> END

C1604 TORQUE SENSOR

< COMPONENT DIAGNOSIS >

C1604 TORQUE SENSOR

Description

INFOID:000000000940497

Torque sensor detects the steering torque, and transmit the signal to EPS control unit.

DTC Logic

INFOID:000000000940498

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1604	TORQUE SENSOR	Malfunction of the torque sensor in steering column assembly is detected.	• Harness or connector • Torque sensor • EPS control unit

DTC CONFIRMATION PROCEDURE

1.CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

Self-diagnosis results
TORQUE SENSOR

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [STC-10, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000000940499

1.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect EPS control unit harness connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connectors and then perform the self-diagnosis. Refer to [STC-7, "CONSULT-III Function \(EPS\)"](#).

Is the "TORQUE SENSOR" [C1604] displayed?

- YES >> Torque sensor is malfunction. Replace steering column assembly.
NO >> Poor connection of connector terminal. Repair or replace connector.

Special Repair Requirement

INFOID:000000000956143

1.AJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the EPS control unit. Refer to [BRC-78, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#). (With ESP models)

>> END

C1606 EPS MOTOR

< COMPONENT DIAGNOSIS >

C1606 EPS MOTOR

Description

INFOID:000000000940502

EPS motor provides the assist torque by control signal from EPS control unit.

DTC Logic

INFOID:000000000940503

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1606	EPS MOTOR	When the motor driver malfunction of EPS control unit or EPS motor malfunction is detected.	• Harness or connector • EPS motor • EPS control unit

DTC CONFIRMATION PROCEDURE

1.CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

Self-diagnosis results
EPS MOTOR

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [STC-11. "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000000940504

1.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect EPS control unit harness connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connectors and then perform the self-diagnosis.

Is the "EPS MOTOR" [C1606] displayed?

- YES >> EPS motor malfunctions. Replace steering column assembly.
NO >> Poor connection of connector terminal. Repair or replace connector.

Special Repair Requirement

INFOID:000000000956144

1.AJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the EPS control unit. Refer to [BRC-78, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#). (With ESP models)

>> END

C1607 EEPROM

< COMPONENT DIAGNOSIS >

C1607 EEPROM

Description

INFOID:000000000940507

EPS control unit incorporates a memory function.

DTC Logic

INFOID:000000000940508

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1607	EEPROM	When the memory (EEPROM) system malfunction is detected in EPS control unit.	• Harness or connector • EPS control unit

DTC CONFIRMATION PROCEDURE

1.CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

Self-diagnosis results
EEPROM

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [STC-12. "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000000940509

1.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect EPS control unit harness connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connectors and then perform the self-diagnosis.

Is the "EEPROM" [C1607] displayed?

- YES >> EEPROM malfunctions. Replace steering column assembly. Refer to [ST-10. "Exploded View"](#).
NO >> Poor connection of connector terminal. Repair or replace connector.

Special Repair Requirement

INFOID:000000000956145

1.ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the EPS control unit. Refer to [BRC-78. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#). (With ESP models)

>> END

C1608 CONTROL UNIT

< COMPONENT DIAGNOSIS >

C1608 CONTROL UNIT

Description

INFOID:000000000940512

EPS control unit performs an arithmetical operation on data, such as steering wheel turning force (sensor signal) from the torque sensor, vehicle speed signal, etc. Then it generates an optimum assist torque to the EPS motor according to the driving condition.

DTC Logic

INFOID:000000000940513

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1608	CONTROL UNIT	When the internal malfunction is detected in EPS control unit.	• Harness or connector • EPS control unit

DTC CONFIRMATION PROCEDURE

1.CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

Self-diagnosis results
CONTROL UNIT

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [STC-13, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000000940514

1.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect EPS control unit harness connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connectors and then perform self-diagnosis.

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 2.
NO >> Poor connection of connector terminal. Repair or replace connector.

2.EPS CONTROL UNIT POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect EPS control unit harness connector.
3. Turn ignition switch ON. (Do not start engine.)
4. Check voltage between EPS control unit harness connector terminals and ground.

EPS control unit		—	Voltage
Connector	Terminal		
E38	1	Ground	Battery voltage
E37	10		

5. Turn ignition switch OFF.
6. Check voltage between EPS control unit harness connector terminals and ground.

C1608 CONTROL UNIT

< COMPONENT DIAGNOSIS >

EPS control unit		—	Voltage
Connector	Terminal		
E38	1	Ground	Battery voltage
E37	10		Approx. 0 V

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace malfunctioning components.

3.CHECK EPS CONTROL UNIT GROUND CIRCUIT

1. Check continuity between EPS control unit harness connector terminal and ground.

EPS control unit		—	Continuity
Connector	Terminal		
E38	2	Ground	Existed

2. Connect EPS control unit harness connector.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair open circuit or short to ground or short to power in harness or connectors.

4.CHECK DTC

Start engine.

Does EPS warning lamp turn OFF?

YES >> EPS control unit is malfunction. Replace steering column assembly.

NO >> Perform self-diagnosis, repair or replace damaged parts.

Special Repair Requirement

INFOID:000000000956146

1.AJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the EPS control unit. Refer to [BRC-78, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#). (With ESP models)

>> END

U1200 VEHICLE SPEED SIGNAL (ABS)

< COMPONENT DIAGNOSIS >

U1200 VEHICLE SPEED SIGNAL (ABS)

Description

INFOID:000000000940517

EPS control unit receives the vehicle speed signal from ABS actuator and electric unit (control unit) with CAN communication line.

DTC Logic

INFOID:000000000940518

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
U1200	CAN VHCL SPEED (ABS)	Abnormal vehicle speed signals received with CAN communication are detected.	• Harness or connector • CAN communication line • EPS control unit

DTC CONFIRMATION PROCEDURE

1.CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

Self-diagnosis results
CAN VHCL SPEED (ABS)

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [STC-15, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000000940519

1.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SYSTEM

Perform ABS actuator and electric unit (control unit) self-diagnosis. Repair or replace items indicated, then perform ABS actuator and electric unit (control unit) self-diagnosis again. Refer to [BRC-17, "CONSULT-III Function \(ABS\)"](#) (With ABS models), [BRC-96, "CONSULT-III Function \(ABS\)"](#) (With ESP models).

Is any item indicated on the self-diagnosis display?

- YES >> Repair or replace malfunctioning components.
NO >> GO TO 2.

2.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect EPS control unit harness connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connectors and then perform the self-diagnosis.

Is any item indicated on the self-diagnosis display?

- YES >> EPS control unit malfunctions. Replace steering column assembly. Refer to [ST-10, "Exploded View"](#).
NO >> Poor connection of connector terminal. Repair or replace connector.

Special Repair Requirement

INFOID:000000000956147

1.ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the EPS control unit. Refer to [BRC-78, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#). (With ESP models)

>> END

U14FF VEHICLE SPEED SIGNAL (METER)

< COMPONENT DIAGNOSIS >

U14FF VEHICLE SPEED SIGNAL (METER)

Description

INFOID:000000000940522

EPS control unit receives the vehicle speed signal from combination meter with CAN communication line.

DTC Logic

INFOID:000000000940523

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
U14FF	CAN VHCL SPEED (METER)	Abnormal vehicle speed signals received with CAN communication are detected.	• Harness or connector • CAN communication line • EPS control unit

DTC CONFIRMATION PROCEDURE

1.CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

Self-diagnosis results
CAN VHCL SPEED (METER)

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [STC-16, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000000940524

1.CHECK COMBINATION METER SYSTEM

Perform combination meter self-diagnosis. Repair or replace items indicated, then perform combination meter self-diagnosis again. Refer to [MWI-23, "CONSULT-III Function \(METER/M&A\)"](#).

Is any item indicated on the self-diagnosis display?

- YES >> Repair or replace malfunctioning components.
NO >> GO TO 2.

2.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect EPS control unit harness connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connectors and then perform the self-diagnosis. Refer to [STC-7, "CONSULT-III Function \(EPS\)"](#).

Is any item indicated on the self-diagnosis display?

- YES >> EPS control unit malfunctions. Replace steering column assembly. Refer to [ST-10, "Exploded View"](#).
NO >> Poor connection of connector terminal. Repair or replace connector.

Special Repair Requirement

INFOID:000000000956148

1.ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the EPS control unit. Refer to [BRC-78, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#). (With ESP models)

>> END

U1000 CAN COMM CIRCUIT

< COMPONENT DIAGNOSIS >

U1000 CAN COMM CIRCUIT

Description

INFOID:000000000940527

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

DTC Logic

INFOID:000000000940528

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
U1000	CAN COMM CIRCUIT	When EPS control unit is not transmitting or receiving CAN communication signal for 2 seconds or more.	• Harness or connector • CAN communication line • EPS control unit

DTC CONFIRMATION PROCEDURE

1.CHECK SELF-DIAGNOSIS RESULTS

Check the self-diagnosis results.

Self-diagnosis results
CAN COMM CIRCUIT

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [STC-17. "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000000940529

1.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect EPS control unit harness connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connector and perform self-diagnosis. Refer to [STC-7. "CONSULT-III Function \(EPS\)"](#).

Is above displayed on the self-diagnosis display?

- YES >> Go to [LAN-46. "Trouble Diagnosis Flow Chart"](#).
NO >> INSPECTION END

Special Repair Requirement

INFOID:000000000956149

1.ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the EPS control unit. Refer to [BRC-78. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#). (With ESP models)

>> END

EPS CONTROL UNIT

< ECU DIAGNOSIS >

ECU DIAGNOSIS

EPS CONTROL UNIT

Reference Value

INFOID:000000000940480

VALUES ON THE DIAGNOSIS TOOL

CAUTION:

The output signal indicates the EPS control unit calculation data. The normal values will be displayed even in the event that the output circuit (harness) is open.

Monitor item (Unit)	Content	Condition		Display value
BATTERY VOLT (V)	Power supply voltage for EPS control unit	Ignition switch: ON		Battery voltage
TORQUE SENSOR (Nm)	Steering wheel turning force	Engine running	Steering wheel: Not steering (There is no steering force)	0.0 Nm
			Steering wheel: Right turn	Positive value (Nm)
			Steering wheel: Left turn	Negative value (Nm)
MOTOR SIG (A)	Command current to EPS motor	Engine running	Steering wheel: Not steering (There is no steering force)	0.0 A
			Steering wheel: Right turn	Negative value (A)
			Steering wheel: Left turn	Positive value (A)
MOTOR CURRENT (A)	Consumption current of EPS motor	Engine running	Steering wheel: Not steering (There is no steering force)	0.0 A
			Steering wheel: Steering	0 – 105.0 A ^{*1} (The value is changed according to steering left or right)
ASSIST TORQUE (Nm)	Displays assist torque being output by the EPS.	Engine running	Steering wheel: Not steering (There is no steering force)	0.0 Nm
			Steering wheel: Right turn	Negative value (Nm)
			Steering wheel: Left turn	Positive value (Nm)
ASSIST LEVEL (%)	Assist available level	Engine running		100 % ^{*2}
VEHICLE SPEED (km/h) or (mph)	Vehicle speed	Vehicle stopped		0 km/h (0 mph)
		While driving		Approximately equal to the indication on speedometer (inside of $\pm 10\%$) ^{*3}
WARNING LAMP (On/Off)	EPS warning lamp condition	EPS warning lamp: ON		On
		EPS warning lamp: OFF		Off
ENGINE STATUS (RUN/STOP)	Engine status	Engine stopped (Engine speed: Less than 400 rpm)		STOP
		Engine running (Engine speed: 400 rpm or more)		RUN

*1: Almost in accordance with the value of MOTOR SIG. It is not a malfunction though these values are not accorded when steering quickly.


*2: Normally displays 100%. In case of an excessive stationary steering, the assist curvature gradually falls. However, it returns to 100% when left standing.

*3: It is not a malfunction, though it might not be corresponding just after ignition switch in turned ON.

EPS CONTROL UNIT

< ECU DIAGNOSIS >

TERMINAL LAYOUT



PHYSICAL VALUES

Terminal No. (Wire Color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/Output		
1 (W)	Ground	Battery power supply	Input	Always	Battery voltage
2 (B)	Ground	Ground	Output	Always	0 V
6 (P)	Ground	CAN-L	Input/Output	—	—
8 (L)	Ground	CAN-H	Input/Output	—	—
10 (O)	Ground	Ignition power supply	Input	Ignition switch: ON	Battery voltage
				Ignition switch: OFF	0 V


Wiring Diagram - ELECTRONICALLY CONTROLLED POWER STEERING SYSTEM -

INFOID:0000000000940481

EPS CONTROL UNIT

< ECU DIAGNOSIS >

ELECTRONICALLY CONTROLLED POWER STEERING SYSTEM




2006/12/08

JCGWA0027GE

ELECTRONICALLY CONTROLLED POWER STEERING SYSTEM

Connector No.	E16
Connector Name	ECM
Connector Type	MAA2FB-MEA8-LH



Terminal No.	Color of Wire	Signal Name [Specification]
83	P	CAN-L
84	L	CAN-H

Connector No.	E34
Connector Name	ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)
Connector Type	BAA2ZFB-AH24-LH




Terminal No.	Color of Wire	Signal Name [Specification]
15	P	CAN-L
26	L	CAN-H

Connector No.	E36
Connector Name	ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)
Connector Type	BAA2ZFB-AH24-LH



Terminal No.	Color of Wire	Signal Name [Specification]
15	P	CAN-L
28	L	CAN-H

Connector No.	E60
Connector Name	ECM
Connector Type	MAA24FB-MEA8-LH



Terminal No.	Color of Wire	Signal Name [Specification]
99	P	MAIN CAN-L (BODY)
100	L	MAIN CAN-H (BODY)

Connector No.	E105
Connector Name	WIRE TO WIRE
Connector Type	THROMW-HS16-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
51	P	-
52	L	-

Connector No.	E106
Connector Name	WIRE TO WIRE
Connector Type	U02MB-MC



Terminal No.	Color of Wire	Signal Name [Specification]
2	W	-

Connector No.	M4
Connector Name	DATA LINK CONNECTOR
Connector Type	BD16FW



Terminal No.	Color of Wire	Signal Name [Specification]
6	L	-
14	P	-

Connector No.	M34
Connector Name	COMBINATION METER
Connector Type	SAB40FW



Terminal No.	Color of Wire	Signal Name [Specification]
21	L	CAN-H
22	P	CAN-L

CONNECTOR NO.

M37

CONNECTOR NAME

EPS CONTROL UNIT

CONNECTOR TYPE

Molex 98545-0001



Terminal No.

6

Color of Wire

P

Signal Name [Specification]

-



Terminal No.

8

Color of Wire

L

Signal Name [Specification]

-



Terminal No.

10

Color of Wire

O

Signal Name [Specification]

-

CONNECTOR NO.

M38

CONNECTOR NAME

EPS CONTROL UNIT

CONNECTOR TYPE

TYCO 0-1644567-1



Terminal No.

1

Color of Wire

W

Signal Name [Specification]

-



Terminal No.

2

Color of Wire

B

Signal Name [Specification]

-

CONNECTOR NO.


M77

CONNECTOR NAME

WIRE TO WIRE

CONNECTOR TYPE

TH60FW-MS16-TM4



Terminal No.


51

Color of Wire

P

Signal Name [Specification]

-



Terminal No.

52

Color of Wire

L

Signal Name [Specification]

-

CONNECTOR NO.

M78

CONNECTOR NAME

WIRE TO WIRE

CONNECTOR TYPE

LOGFB-MC



Terminal No.

2

Color of Wire

W

Signal Name [Specification]

-



Terminal No.

2

Color of Wire

W

Signal Name [Specification]

-

JCGWA0029GE

Fail-Safe

INFOID:000000000940482

- If any malfunction occurs in the system, and control unit detects the malfunction, EPS warning lamp on combination meter turns ON to indicate system malfunction.
- When EPS warning lamp is ON, enters a manual steering state. (Control turning force steering wheel becomes heavy.)

DTC No. Index

INFOID:0000000000940483

EPS CONTROL UNIT

< ECU DIAGNOSIS >

DTC	Items (CONSULT screen terms)	Reference
C1601	BATTERY VOLT	STC-8, "Description"
C1604	TORQUE SENSOR	STC-10, "Description"
C1606	EPS MOTOR	STC-11, "Description"
C1607	EEPROM	STC-12, "Description"
C1608	CONTROL UNIT	STC-13, "Description"
U1200	CAN VHCL SPEED (ABS)	STC-15, "Description"
U14FF	CAN VHCL SPEED (METER)	STC-16, "Description"
U1000	CAN COMM CIRCUIT	STC-17, "Description"

A

B

C

D

E

F

STC

H

I

J

K

L

M

N

O

P

EPS WARNING LAMP DOES NOT TURN ON

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

EPS WARNING LAMP DOES NOT TURN ON

Diagnosis Procedure

INFOID:000000000940534

1.CHECK SYSTEM FOR CAN COMMUNICATION LINE

Perform self-diagnosis. Refer to [STC-7, "CONSULT-III Function \(EPS\)"](#).

Is the "CAN COMM CIRCUIT [U1000]" displayed?

- YES >> Perform trouble diagnosis for CAN communication line.
- NO >> GO TO 2.

2.CHECK EPS CONTROL UNIT

Check EPS control unit input/output signal. Refer to [STC-18, "Reference Value"](#).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Check EPS control unit pin terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace damaged parts.

3.CHECK COMBINATION METER SELF-DIAGNOSIS RESULTS

Perform combination meter self-diagnosis. Refer to [MWI-23, "CONSULT-III Function \(METER/M&A\)"](#).

Is self-diagnosis results indicated?

- YES >> Repair or replace malfunctioning components.
- NO >> GO TO 4.

4.SYMPTOM CHECK

Check again.

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> Replace combination meter.

EPS WARNING LAMP DOES NOT TURN OFF

< SYMPTOM DIAGNOSIS >

EPS WARNING LAMP DOES NOT TURN OFF

Diagnosis Procedure

INFOID:000000000940536

1.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis. Refer to [STC-7, "CONSULT-III Function \(EPS\)"](#).

Is any malfunction detected by self-diagnosis?

- YES >> Check the malfunctioning system.
NO >> GO TO 2.

2.CHECK EPS CONTROL UNIT POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect EPS control unit harness connector.
3. Turn ignition switch ON. (Do not start engine.)
4. Check voltage between EPS control unit harness connector terminals and ground.

EPS control unit		—	Voltage
Connector	Terminal		
M38	1	Ground	Battery voltage
M37	10		

5. Turn ignition switch OFF.
6. Check voltage between EPS control unit harness connector terminals and ground.

EPS control unit		—	Voltage
Connector	Terminal		
M38	1	Ground	Battery voltage
M37	10		Approx. 0 V

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace malfunctioning components.

3.CHECK EPS CONTROL UNIT GROUND CIRCUIT

1. Check continuity between EPS control unit harness connector terminal and ground.

EPS control unit		—	Continuity
Connector	Terminal		
M38	2	Ground	Existed

2. Connect EPS control unit harness connector.

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair open circuit or short to ground or short to power in harness or connectors.

4.CHECK EPS CONTROL UNIT PIN TERMINAL

Check EPS control unit pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Repair or replace damaged parts.

5.CHECK COMBINATION METER SELF-DIAGNOSIS RESULTS

Perform combination meter self-diagnosis. Refer to [MWI-23, "CONSULT-III Function \(METER/M&A\)"](#).

is self-diagnosis results indicated?

- YES >> Repair or replace malfunctioning components.

EPS WARNING LAMP DOES NOT TURN OFF

< SYMPTOM DIAGNOSIS >

NO >> GO TO 6.

6. CHECK VEHICLE SPEED SIGNAL FROM ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Perform self-diagnosis with ABS actuator and electric unit (control unit).

- Without ESP models: [BRC-17, "CONSULT-III Function \(ABS\)"](#)
- With ESP models: [BRC-96, "CONSULT-III Function \(ABS\)"](#)

Is any malfunction detected by self-diagnosis?

YES >> Check the malfunctioning system.

NO >> GO TO 7.

7. CHECK ENGINE STATUS SIGNAL

Perform self-diagnosis with ECM.

- HR16DE (with EURO-OBD): [EC-100, "CONSULT-III Function"](#).
- HR16DE (Without EURO-OBD): [EC-430, "CONSULT-III Function"](#).
- MR20DE (with EURO-OBD): [EC-719, "CONSULT-III Function"](#).
- MR20DE (without EURO-OBD): [EC-1054, "CONSULT-III Function"](#).
- K9K: [EC-1315, "Diagnosis Description"](#)

Is the malfunction detected by self-diagnosis?

YES >> Check the malfunctioning system.

NO >> GO TO 8.

8. SYMPTOM CHECK

Check again.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace combination meter. Refer to [MWI-72, "Exploded View"](#).

STEERING WHEEL TURNING FORCE IS HEAVY OR LIGHT

< SYMPTOM DIAGNOSIS >

STEERING WHEEL TURNING FORCE IS HEAVY OR LIGHT

Diagnosis Procedure

INFOID:000000000940537

1.CHECK SYSTEM FOR CAN COMMUNICATION LINE

Perform self-diagnosis. Refer to [STC-7, "CONSULT-III Function \(EPS\)"](#).

Is the "CAN COMM CIRCUIT [U1000]" displayed.

- YES >> Perform trouble diagnosis for CAN communication line. Refer to [STC-17, "Description"](#).
NO >> GO TO 2.

2.CHECK VEHICLE SPEED SIGNAL FROM ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Perform self-diagnosis with ABS actuator and electric unit (control unit).

- Without ESP models: [BRC-17, "CONSULT-III Function \(ABS\)"](#)
- With ESP models: [BRC-96, "CONSULT-III Function \(ABS\)"](#)

Is any malfunction detected by self-diagnosis?

- YES >> Check the malfunctioning system.
NO >> GO TO 3.

3.CHECK COMBINATION METER SIGNAL

Perform self-diagnosis with combination meter. Refer to [MWI-23, "CONSULT-III Function \(METER/M&A\)"](#).

Is the malfunction detected by self-diagnosis?

- YES >> Check the malfunctioning system.
NO >> GO TO 4.

4.CHECK ENGINE STATUS SIGNAL

Perform self-diagnosis with ECM.

- HR16DE (with EURO-OBD): [EC-100, "CONSULT-III Function"](#).
- HR16DE (Without EURO-OBD): [EC-430, "CONSULT-III Function"](#).
- MR20DE (with EURO-OBD): [EC-719, "CONSULT-III Function"](#).
- MR20DE (without EURO-OBD): [EC-1054, "CONSULT-III Function"](#).
- K9K: [EC-1315, "Diagnosis Description"](#)

Is the malfunction detected by self-diagnosis?

- YES >> Check the malfunctioning system.
NO >> GO TO 5.

5.CHECK EPS CONTROL UNIT

Check EPS control unit input/output signal. Refer to [STC-18, "Reference Value"](#).

Is the inspection result normal?

- YES >> GO TO 6.
NO >> Check EPS control unit pin terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace damaged parts.

6.CHECK STEERING WHEEL TURNING FORCE

Check steering wheel turning force. Refer to [ST-7, "Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 7.
NO >> Repair or replace malfunctioning components.

7.SYMPTOM CHECK

Check again.

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Check the steering wheel turning force for mechanical malfunction. Refer to [ST-7, "Inspection"](#).

UNBALANCE STEERING WHEEL TURNING FORCE AND RETURN BETWEEN RIGHT AND LEFT

< SYMPTOM DIAGNOSIS >

UNBALANCE STEERING WHEEL TURNING FORCE AND RETURN BETWEEN RIGHT AND LEFT

Diagnosis Procedure

INFOID:000000000940538

1.CHECK EPS WARNING LAMP

Confirm EPS warning lamp during engine running.

Does EPS warning lamp turn OFF?

YES >> GO TO 2.

NO >> Go to [STC-25, "Diagnosis Procedure"](#).

2.CHECK WHEEL ALIGNMENT

Check wheel alignment. Refer to [FSU-7, "Wheel Alignment Inspection"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Adjust wheel alignment. Refer to [FSU-7, "Wheel Alignment Inspection"](#).

3.CHECK EPS CONTROL UNIT

Check EPS control unit input/output signal. Refer to [STC-18, "Reference Value"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Check EPS control unit pin terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace damaged parts.

4.CHECK STEERING WHEEL TURNING FORCE

Check steering wheel turning force. Refer to [ST-7, "Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace malfunctioning components.

5.SYMPTOM CHECK

Check again.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Check the steering wheel turning force for mechanical malfunction. Refer to [ST-7, "Inspection"](#).

UNBALANCE STEERING WHEEL TURNING FORCE (TORQUE VARIATION)

< SYMPTOM DIAGNOSIS >

UNBALANCE STEERING WHEEL TURNING FORCE (TORQUE VARIATION)

Diagnosis Procedure

INFOID:000000000940540

1.CHECK EPS WARNING LAMP

Confirm EPS warning lamp during engine running.

Does EPS warning lamp turn OFF?

YES >> GO TO 2.

NO >> Go to [STC-25, "Diagnosis Procedure"](#).

2.CHECK STEERING COLUMN INTERMEDIATE SHAFT

Check the connection between intermediate shaft and the mounting part of steering column assembly and steering gear assembly. Refer to [ST-10, "Exploded View"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace damaged parts.

3.CHECK EPS CONTROL UNIT

Check EPS control unit input/output signal. Refer to [STC-18, "Reference Value"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Check EPS control unit pin terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace damaged parts.

4.SYMPTOM CHECK

Check again.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Check the steering wheel turning force for mechanical malfunction. Refer to [ST-7, "Inspection"](#).

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000001115248

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRC and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRC section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Precaution Necessary for Steering Wheel Rotation After Battery Disconnect

INFOID:0000000001115249

NOTE:

- This Procedure is applied only to models with Intelligent Key system and NATS (NISSAN ANTI-THEFT SYSTEM).
- Remove and install all control units after disconnecting both battery cables with the ignition knob in the "LOCK" position.
- Always use CONSULT-III to perform self-diagnosis as a part of each function inspection after finishing work. If DTC is detected, perform trouble diagnosis according to self-diagnostic results.

For models equipped with the Intelligent Key system and NATS, an electrically controlled steering lock mechanism is adopted on the key cylinder.

For this reason, if the battery is disconnected or if the battery is discharged, the steering wheel will lock and steering wheel rotation will become impossible.

If steering wheel rotation is required when battery power is interrupted, follow the procedure below before starting the repair operation.

OPERATION PROCEDURE

1. Connect both battery cables.

NOTE:

Supply power using jumper cables if battery is discharged.

2. Use the Intelligent Key or mechanical key to turn the ignition switch to the "ACC" position. At this time, the steering lock will be released.
3. Disconnect both battery cables. The steering lock will remain released and the steering wheel can be rotated.
4. Perform the necessary repair operation.
5. When the repair work is completed, return the ignition switch to the "LOCK" position before connecting the battery cables. (At this time, the steering lock mechanism will engage.)
6. Perform a self-diagnosis check of all control units using CONSULT-III.

Service Notice or Precautions for EPS System

INFOID:0000000000940487


CAUTION:

Check the following item when performing the trouble diagnosis.


PRECAUTIONS

< PRECAUTION >


- Check any possible causes by interviewing the symptom and it's condition from the customer if any malfunction, such as EPS warning lamp is turned ON, occurs.
- Check if air pressure and size of tires are proper, the specified part is used for the steering wheel, and control unit is genuine part.
- Check if the connection of steering column assembly and steering gear assembly is proper (there is not looseness of mounting bolts, damage of rods, boots or sealants, and leakage of grease, etc).
- Check if the wheel alignment is adjusted properly.
- Check if there is any damage or modification to suspension or body resulting in increased weight or altered ground clearance.
- Check if installation conditions of each link and suspension are proper.
- Check if the battery voltage is proper.
- Check connection conditions of each connector are proper.
- Before connecting or disconnecting the EPS control unit harness connector, turn ignition switch "OFF" and disconnect battery ground cable. Because battery voltage is applied to EPS control unit even if ignition switch is turned "OFF".



- When connecting or disconnecting pin connectors into or from EPS control unit, take care not to damage pin terminals (bend or break).
When connecting pin connectors, make sure that there are no bends or breaks on EPS control unit pin terminal.



- Before replacing EPS control unit, perform EPS control unit input/output signal inspection and make sure whether EPS control unit functions properly or not. Refer to [STC-18, "Reference Value"](#).



EPS CONTROL UNIT

< ON-VEHICLE REPAIR >

ON-VEHICLE REPAIR

EPS CONTROL UNIT

Removal and Installation

INFOID:000000000945621

CAUTION:

When replacing EPS control unit, replace steering column assembly. Refer to [ST-10, "Removal and Installation"](#).