

ELECTRICAL SYSTEM

SECTION EL

CONTENTS

PRECAUTIONS	3	INTERIOR ROOM LAMP	47
Supplemental Restraint System (SRS) "AIR		System Description	47
BAG"	3	Wiring Diagram - ROOM/L -	49
Wiring Diagrams and Trouble Diagnosis	3	Trouble Diagnoses for Interior Lamp Timer	50
HARNESS CONNECTOR	4	SPOT AND TRUNK ROOM LAMPS	57
Description	4	Wiring Diagram - INT/L -	57
STANDARDIZED RELAY	5	METERS AND GAUGES	58
Description	5	Component Parts and Harness Connector	
POWER SUPPLY ROUTING	7	Location	58
Schematic	7	System Description	58
Wiring Diagram - POWER -	8	Combination Meter	60
Inspection	14	Schematic	62
GROUND	15	Wiring Diagram - METER -	63
Ground Distribution	15	Meter/Gauge Operation and Odo/Trip Meter	
COMBINATION SWITCH	26	Segment Check in Diagnosis Mode	64
Check	26	Trouble Diagnoses	65
Replacement	27	Electrical Components Inspection	71
HEADLAMP	28	WARNING LAMPS	73
Component Parts and Harness Connector		Schematic	73
Location	28	Wiring Diagram - WARN -	74
System Description	28	Electrical Components Inspection	77
Wiring Diagram - H/LAMP -	29	A/T INDICATOR	78
Trouble Diagnoses	31	Wiring Diagram - AT/IND -	78
Bulb Replacement	32	WARNING BUZZER	79
Aiming Adjustment	34	Component Parts and Harness Connector	
PARKING, LICENSE AND TAIL LAMPS	35	Location	79
Wiring Diagram - TAIL/L -	35	System Description	79
STOP LAMP	37	Wiring Diagram - BUZZER -	81
Wiring Diagram - STOP/L -	37	Trouble Diagnoses	82
BACK-UP LAMP	38	FRONT WIPER AND WASHER	87
Wiring Diagram - BACK/L -	38	System Description	87
TURN SIGNAL AND HAZARD WARNING LAMPS	39	Wiring Diagram - WIPER -	89
Wiring Diagram - TURN -	39	Removal and Installation	90
Trouble Diagnoses	41	Washer Nozzle Adjustment	91
Blub Replacement	41	Washer Tube Layout	92
Electrical Components Inspection	42	HORN	93
ILLUMINATION	43	Wiring Diagram - HORN -	93
Schematic	43	CIGARETTE LIGHTER	94
Wiring Diagram - ILL -	44	Wiring Diagram - CIGAR -	94

CONTENTS (Cont'd)

CLOCK	95	Description	131
Wiring Diagram - CLOCK -	95	Schematic	132
REAR WINDOW DEFOGGER	96	Time Control System Inspection Table	133
Component Parts and Harness Connector		NATS (NISSAN ANTI-THEFT SYSTEM)	134
Location	96	Component Parts and Harness Connector	
System Description.....	96	Location	134
Wiring Diagram - DEF -	97	System Description.....	135
Trouble Diagnoses.....	98	System Composition.....	135
Electrical Components Inspection	100	Wiring Diagram - NATS -	136
Filament Check.....	101	CONSULT-II	137
Filament Repair	102	Trouble Diagnoses.....	139
AUDIO	103	How to Replace NATS IMMU	153
Wiring Diagram - AUDIO -	103	ELECTRICAL UNITS LOCATION	154
AUDIO ANTENNA	104	Engine Compartment.....	154
Location of Antenna.....	104	Passenger Compartment.....	156
Window Antenna Repair	104	HARNES LAYOUT	158
POWER SUNROOF	106	How to Read Harness Layout	158
System Description.....	106	Outline.....	159
Wiring Diagram - SROOF -	107	Main Harness.....	160
Trouble Diagnoses.....	109	Engine Room Harness	162
DOOR MIRROR	110	Engine Control Harness	166
Wiring Diagram - MIRROR -	110	Engine Sub Harness.....	168
POWER WINDOW	111	Engine Harness	169
System Description.....	111	Body Harness	170
Schematic	113	Tail Harness	172
Wiring Diagram - WINDOW -	114	Room Lamp Harness.....	173
Trouble Diagnoses.....	117	Door Harness.....	174
POWER DOOR LOCK	120	BULB SPECIFICATIONS	175
Component Parts and Harness Connector		Headlamp.....	175
Location	120	Exterior Lamp	175
System Description.....	120	Interior Lamp.....	175
Wiring Diagram - D/LOCK -	121	WIRING DIAGRAM CODES (CELL CODES)	176
Trouble Diagnoses.....	123		
UNIFIED METER CONTROL UNIT (TIME			
CONTROL SYSTEM)	131		

PRECAUTIONS

Supplemental Restraint System (SRS) "AIR BAG"

Supplemental Restraint System (SRS) "AIR BAG"

NMEL0001

The Supplemental Restraint System such as "AIR BAG" used along with a seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. The SRS system composition which is available to NISSAN MODEL S15 is as follows:

The Supplemental Restraint System consists of driver air bag module (located in the center of the steering wheel), front passenger air bag module (located on the instrument panel on passenger side), a diagnosis sensor unit, warning lamp, wiring harness and spiral cable.

Information necessary to service the system safely is included in the **RS section** of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance should be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the RS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified with yellow harness connector.

Wiring Diagrams and Trouble Diagnosis

NMEL0002

When you read wiring diagrams, refer to the following:

- Refer to GI-11, "HOW TO READ WIRING DIAGRAMS"
- Refer to EL-7, "POWER SUPPLY ROUTING" for power distribution circuit

When you perform trouble diagnosis, refer to the following:

- Refer to GI-31, "HOW TO FOLLOW TEST GROUPS IN TROUBLE DIAGNOSES"
- Refer to GI-20, "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT"

Check for any Service bulletins before servicing the vehicle.

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

HARNESS CONNECTOR

Description

Description

NMEL0003

NMEL0003S01

HARNESS CONNECTOR (TAB-LOCKING TYPE)


- The tab-locking type connectors help prevent accidental looseness or disconnection.
- The tab-locking type connectors are disconnected by pushing or lifting the locking tab(s). Refer to the illustration below.

Refer to the next page for description of the slide-locking type connector.

CAUTION:

Do not pull the harness or wires when disconnecting the connector.

[Example]



SEL769DA

Description

NORMAL OPEN, NORMAL CLOSED AND MIXED TYPE RELAYS

Relays can mainly be divided into three types: normal open, normal closed and mixed type relays.

NMEL0004

NMEL0004S01

GI

MA

EM

LC

EC


FE

CL

MT

SEL881H

AT



TYPE OF STANDARDIZED RELAYS

NMEL0004S02

1M	1 Make	2M	2 Make
1T	1 Transfer	1M·1B	1 Make 1 Break

PD

AX

SU

BR

ST

RS

BT


HA

SEL882H

SC















EL

IDX



STANDARDIZED RELAY

Description (Cont'd)

Type	Outer view	Circuit	Connector symbol and connection	Case color
1T				BLACK
2M				BROWN
1M•1B				GRAY
1M				BLUE
				

The arrangement of terminal numbers on the actual relays may differ from those shown above.

SEL188W

Schematic

NMEL0005

GI



EM

LC

EC

FE

CL

MT

AT

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

EL-POWER-02

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

AX

SU

BR

ST

RS




BT

HA

SC

EL

IDX



FRONT

REFER TO THE FOLLOWING.

M6, M7, E103, E105

B4, B5 - FUSE BLOCK

JUNCTION BOX (J/B)

1	6	11	16	21	25
2	7	12	17	22	26
3	8	13	18	23	27
4	9	14	19	24	
5	10	15	20		28

UP

TEL782B



POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

ACCESSORY POWER SUPPLY — IGNITION SW. IN “ACC” OR “ON”

NMEL0006S02

EL-POWER-03



REFER TO THE FOLLOWING.

(M6), (M7), (E103), (E104)
-FUSE BLOCK-JUNCTION
BOX (J/B)

1	6	11	16	21	25
2	7	12	17	22	26
3	8	13	18	23	27
4	9	14	19	24	
5	10	15	20		28

UP

TEL783B



POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

IGNITION POWER SUPPLY — IGNITION SW. IN “ON” AND/OR “START”

NMEL0006S03

EL-POWER-04



REFER TO THE FOLLOWING.

(M6), (M7), (E103), (E104),
(E105), (B5) - FUSE BLOCK
JUNCTION BOX (J/B)

1	6	11	16	21	25
2	7	12	17	22	26
3	8	13	18	23	27
4	9	14	19	24	
5	10	15	20		28

UP



TEL784B

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

EL-POWER-05



REFER TO THE FOLLOWING.

(M6), (M7), (E105), (B4)
-FUSE BLOCK-JUNCTION
BOX (J/B)

1	6	11	16	21	25
2	7	12	17	22	26
3	8	13	18	23	27
4	9	14	19	24	
5	10	15	20		28



UP

TEL785B

POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

EL-POWER-06



REFER TO THE FOLLOWING.

M6, M7, E104, E105
-FUSE BLOCK-JUNCTION
BOX (J/B)

1	6	11	16	21	25
2	7	12	17	22	26
3	8	13	18	23	27
4	9	14	19	24	
5	10	15	20		28

UP

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

AX

SU

BR

ST

RS

BT

HA

SC


EL

IDX

TEL786B

POWER SUPPLY ROUTING

Inspection



Inspection

NMEL0007

FUSE

NMEL0007S01

- If fuse is blown, be sure to eliminate cause of problem before installing new fuse.
- Use fuse of specified rating. Never use fuse of more than specified rating.
- Do not partially install fuse; always insert it into fuse holder properly.
- Remove fuse for "ELECTRICAL PARTS (BAT)" if vehicle is not used for a long period of time.



FUSIBLE LINK

NMEL0007S02

A melted fusible link can be detected either by visual inspection or by feeling with finger tip. If its condition is questionable, use circuit tester or test lamp.

CAUTION:

- If fusible link should melt, it is possible that critical circuit (power supply or large current carrying circuit) is shorted. In such a case, carefully check and eliminate cause of problem.
- Never wrap outside of fusible link with vinyl tape. Important: Never let fusible link touch any other wiring harness, vinyl or rubber parts.



CIRCUIT BREAKER

NMEL0007S03

For example, when current is 30A, the circuit is broken within 8 to 20 seconds.

Ground Distribution

MAIN HARNESS

NMEL0008
NMEL0008S01

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

AX

SU

BR

ST

RS

BT


HA

SC

EL

IDX

CEL300A




CON-NECTOR NUMBER	CONNECT TO
M2	Door lock relay
M4	Power window relay
M6	Fuse block (J/B) • Accessory relay • Ignition relay • Blower relay-1
M18	Combination meter (Terminal No. 9) • Unified meter control unit • Air bag warning lamp • Fuel gauge • Water temperature gauge
M19	Combination meter (Terminal No. 28) • Turn signal and hazard warning lamp • Clock • Fuel warning lamp
M19	Combination meter (Terminal No. 29) • High beam indicator
M20	Combination meter (Terminal No. 60) • A/T indicator lamp
M21	Combination flasher unit
M36	Hazard switch
M37	Rear window defogger switch (Terminal No. 2)
M37	Rear window defogger switch (Illumination)(Terminal No. 6)
M37	Rear window defogger switch (Indicator)(Terminal No. 4)
M41	A/T mode switch
R3	Spot lamp
D6	Door mirror remote control switch
D7	Power window main switch
D8	Door unlock sensor

Next page

GROUND

Ground Distribution (Cont'd)



CEL301A

ENGINE ROOM HARNESS

NMEL0008S02

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

AX

SU

BR

ST

RS


BT

HA

SC


EL

IDX




GROUND

Ground Distribution (Cont'd)



ENGINE CONTROL HARNESS

NMEL0008S03



GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

AX

SU

BR

ST

RS

BT

HA

SC



EL

IDX

GROUND



Ground Distribution (Cont'd)

D Preceding page



CON-NECTOR NUMBER	CONNECT TO
F1	ECM (Terminal No. 107)
F1	ECM (Terminal No. 108)
F1	ECM (Terminal No. 116)
F23	Power steering oil pressure switch
F29	IACV-FICD solenoid valve
F35	Condenser

B To main harness




CON-NECTOR NUMBER	CONNECT TO
F8	ABS control unit (Terminal No. 26)
F8	ABS control unit (Terminal No. 28)
F8	ABS control unit (Terminal No. 30)
F8	ABS control unit (Terminal No. 32)

CEL305A

ENGINE HARNESS

NMEL0008S07



GI

MA

EM

LC

EC

FE

CL

MT

AT

CEL306A PD

AX

SU

BR

ST

RS

BT

HA



SC

EL

IDX

ENGINE SUB HARNESS


NMEL0008S08



CEL307A

BODY HARNESS

NMEL0008S04



GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX


TAIL HARNESS

NMEL0008S06



REAR WINDOW DEFOGGER HARNESS

NMEL0008S09



GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL



IDX

COMBINATION SWITCH

Check

Check

NMEL0009



TURN SIGNAL
LAMP SWITCH

	L	N	R
1	○		○
2		○	
3	○		

LIGHTING SWITCH

	OFF			1ST			2ND		
	A	B	C	A	B	C	A	B	C
5			○			○	○	○	○
6			○			○	○	○	○
7								○	
8		○			○	○	○	○	○
9		○			○	○	○	○	○
10								○	
11				○	○	○	○	○	○
12				○	○	○	○	○	○




FRONT WIPER AND
WASHER SWITCH

	OFF	INT	LO	HI	WASH
13					○
14	○	○	○		
15	○	○			○
16			○	○	
17		○		○	○
18					○

WIPER AMPLIFIER
(In combination switch)

VARIABLE
INTERMITTENT
WIPER VOLUME

CEL311A



Replacement

NMEL0010

For removal and installation of spiral cable, refer to RS section ["Installation — Air Bag Module and Spiral Cable", "SUPPLEMENTAL RESTRAINT SYSTEM (SRS)"].

- Each switch can be replaced without removing combination switch base.
- To remove combination switch base, remove base attaching screw.
- Before installing the steering wheel, align the steering wheel guide pins with the screws which secure the combination switch as shown in the left figure.

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

AX

SU

BR

ST

RS

BT

HA

SC


EL

IDX

HEADLAMP

Component Parts and Harness Connector Location

Component Parts and Harness Connector Location



System Description

NMEL0198

The headlamp operation is controlled by the lighting switch which is built into the combination switch. Power is supplied at all times

- to lighting switch terminal 8
- to headlamp relay terminal 6
- through 15A fuse (No. 42, located in the fuse and fusible link box), and
- to lighting switch terminal 5
- to headlamp relay terminal 3
- through 15A fuse (No. 41, located in the fuse and fusible link box).

HEADLAMP SWITCH OPERATION

NMEL0198S09

Low Beam Operation

NMEL0198S0901

When the lighting switch is turned to the 2ND position and placed in LOW ("B") position, power is supplied

- from lighting switch terminal 10
- to terminal 1 of the headlamp LH, and
- from lighting switch terminal 7
- to terminal 1 of the headlamp RH.

Terminal 2 of each headlamp supplies ground through body grounds E43 and E57. With power and ground supplied, the low beams will illuminate.

High Beam Operation/Flash-to-Pass Operation

NMEL0198S0902

When the lighting switch is turned to the 2ND position and placed in HIGH ("A") position or PASS ("C") position, power is supplied

- from lighting switch terminal 6
- to terminal 3 of the headlamp RH, and
- from lighting switch terminal 9
- to terminal 3 of the headlamp LH,
- to headlamp relay terminal 1
- to combination meter terminal 40 for the high beam indicator.

Ground is supplied

- to terminal 29 of the combination meter through body grounds M1 and M67, and
- to headlamp relay terminal 2 through body grounds E43 and E57.

Then headlamp relay is energized and power is supplied to terminal 1 of each headlamp.

Terminals 2 and 4 of each headlamp supply ground through body grounds E43 and E57.

With power and ground supplied, the high beams, the low beams and the high beam indicator illuminate.




HEADLAMP

Wiring Diagram — H/LAMP —

Wiring Diagram — H/LAMP —

NMEL0013

EL-H/LAMP-01



EL


IDX

TEL787B

HEADLAMP

Wiring Diagram — H/LAMP — (Cont'd)


EL-H/LAMP-02



21	22	23	24	25			26	27	28	29
30	31	32	33	34	35	36	37	38	39	40

M19

BR



REFER TO THE FOLLOWING.
(E101) -SUPER MULTIPLE
JUNCTION (SMJ)

TEL788B

HEADLAMP

Trouble Diagnoses

Trouble Diagnoses

NMEL0202

Symptom	Possible cause	Repair order	
Neither headlamp operates.	1. Lighting switch	1. Check Lighting switch.	GI
LH headlamp (low and high beam) does not operate, but RH headlamp (low and high beam) does operate.	1. 15A fuse 2. Lighting switch	1. Check 15A fuse (No. 42, located in fusible link and fuse box). Verify battery positive voltage is present at lighting switch terminal 8. 2. Check lighting switch.	MA EM
RH headlamp (low and high beam) does not operate, but LH headlamp (low and high beam) does operate.	1. 15A fuse 2. Lighting switch	1. Check 15A fuse (No. 41, located in fusible link and fuse box). Verify battery positive voltage is present at lighting switch terminal 5. 2. Check lighting switch.	LC
LH high beam does not operate, but LH low beam does operate.	1. Bulb 2. Open in LH high beam circuit 3. LH high beam ground circuit 4. Lighting switch	1. Check bulb. 2. Check the harness between lighting switch and LH headlamp for an open circuit. 3. Check the harness between LH headlamp and ground. 4. Check lighting switch.	EC FE
LH low beam does not operate, but LH high beam does operate.	1. Bulb 2. Open in LH low beam circuit 3. LH low beam ground circuit 4. Lighting switch	1. Check bulb. 2. Check the harness between lighting switch and LH headlamp for an open circuit. 3. Check the harness between LH headlamp and ground. 4. Check lighting switch.	CL MT
RH high beam does not operate, but RH low beam does operate.	1. Bulb 2. Open in RH high beam circuit 3. RH high beam ground circuit 4. Lighting switch	1. Check bulb. 2. Check the harness between lighting switch and RH headlamp for an open circuit. 3. Check the harness between RH headlamp and ground. 4. Check lighting switch.	AT PD
RH low beam does not operate, but RH high beam does operate.	1. Bulb 2. Open in RH low beam circuit 3. RH low beam ground circuit 4. Lighting switch	1. Check bulb. 2. Check the harness between lighting switch and RH headlamp for an open circuit. 3. Check the harness between RH headlamp and ground. 4. Check lighting switch.	AX SU
High beam indicator does not work.	1. Bulb 2. Ground circuit 3. Open in high beam circuit	1. Check bulb in combination meter. 2. Check harness between high beam indicator and ground. 3. Check the harness between lighting switch and combination meter for an open circuit.	BR ST
When the lighting switch is turned to the 2ND position and placed in HIGH ("A") position, low beam does not operate, but high beam does operate.	1. Headlamp relay circuit 2. Headlamp relay ground circuit 3. Headlamp relay	1. Check the following. a. Harness between headlamp relay and fuse. b. Harness between headlamp relay and lighting switch. 2. Check harness between headlamp relay and ground. 3. Check headlamp relay.	RS BT HA

SC


EL

IDX

HEADLAMP

Bulb Replacement

NMEL0015



The headlamp is a semi-sealed beam type which uses a replaceable halogen bulb. The bulb can be replaced from the engine compartment side without removing the headlamp body.

- Grasp only the plastic base when handling the bulb. Never touch the glass envelope.

RH HEADLAMP

Headlamp Bulb (Low beam)

1. Disconnect the battery cable.
2. Pull off the rubber cap.
3. Push and turn the bulb retaining pin.
4. Remove the headlamp bulb carefully. Do not shake or rotate bulb when removing it.
5. Install in reverse order of removal.

NMEL0015S01

NMEL0015S0101

Headlamp Bulb (High beam)

1. Disconnect the harness connector from rear end of the bulb.
2. Turn bulb cover counterclockwise, then remove it.
3. Remove the headlamp bulb carefully. Do not shake or rotate the bulb when removing it.
4. Install in reverse order of removal.

NMEL0015S0102

Turn Signal Lamp Bulb

1. Remove front fender protector.
2. Turn bulb cover counterclockwise, then remove it.
3. Remove the turn signal lamp bulb carefully. Do not shake or rotate the bulb when removing it.
4. Install in reverse order of removal.

NMEL0015S0103

LH HEADLAMP**Headlamp Bulb (Low beam)**

=NMEL0015S02

NMEL0015S0201

1. Disconnect the battery cable.
2. Remove air duct and air cleaner case.
3. Pull off the rubber cap.
4. Push and turn the bulb retaining pin.
5. Remove the headlamp bulb carefully. Do not shake or rotate the bulb when removing it.
6. Install in reverse order of removal.

GI

MA

EM

Headlamp Bulb (High beam)

NMEL0015S0202

1. Disconnect the harness connector from rear end of the bulb.
2. Turn bulb cover counterclockwise, then remove it.
3. Remove the headlamp bulb carefully. Do not shake or rotate the bulb when removing it.
4. Install in reverse order of removal.

LC

EC

Turn Signal Lamp Bulb

NMEL0015S0203

1. Remove front fender protector.
2. Remove air guide to inter cooler.
3. Turn bulb cover counterclockwise, then remove it.
4. Remove the turn signal lamp bulb carefully. Do not shake or rotate the bulb when removing it.
5. Install in reverse order of removal.

FE

CL

MT

CAUTION:

Do not leave headlamp reflector without bulb for a long period of time. Dust, moisture, smoke, etc. entering headlamp body may affect the performance of the headlamp. Remove headlamp bulb from the headlamp reflector just before a replacement bulb is installed.

AT

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

HEADLAMP

Aiming Adjustment


Aiming Adjustment

=NMEL0016

For details, refer to the regulations in your own country.

Before performing aiming adjustment, check the following.


- 1) Keep all tires inflated to correct pressures.
- 2) Place vehicle and tester on one and same flat surface.
- 3) See that there is no-load in vehicle (coolant, engine oil filled up to correct level and full fuel tank) other than the driver (or equivalent weight placed in driver's position).



LOW/HIGH BEAM

NMEL0016S02

1. Turn headlamp low beam on.
 2. Use adjusting screws to perform aiming adjustment.
- First tighten the adjusting screw all the way and then make adjustment by loosening the screw.



- Adjust headlamps so that main axis of light is parallel to center line of body and is aligned with point P shown in illustration.
- Figure to the left shows headlamp aiming pattern for driving on right side of road; for driving on left side of road, aiming pattern is reversed.
- Dotted lines in illustration show center of headlamp.
 - “H”: Horizontal center line of headlamps
 - “W_L”: Distance between each headlamp center
 - “L”: 3,000 mm (118.1 in)
 - “C”: 30 mm (1.18 in)

PARKING, LICENSE AND TAIL LAMPS

Wiring Diagram — TAIL/L —

Wiring Diagram — TAIL/L —

NMEL0024

EL-TAIL/L-01

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

AX

SU

BR

ST

RS



BT

HA

SC

EL

IDX




REFER TO THE FOLLOWING.
 (E101) -SUPER MULTIPLE
 JUNCTION (SMJ)

PARKING, LICENSE AND TAIL LAMPS

Wiring Diagram — TAIL/L — (Cont'd)

EL-TAIL/L-02



1	2	3	4	5			6	7	8	9
10	11	12	13	14	15	16	17	18	19	20

B1
W

1	2	3		4	5	
6	7	8	9	10	11	12

B24
W

1		2	
3	4	5	6

T6
W

T8
W

1
2

T7
BR



TEL790B

Wiring Diagram — STOP/L —

Wiring Diagram — STOP/L —

NMEL0025

EL-STOP/L-01



REFER TO THE FOLLOWING.
(M6) -FUSE BLOCK-JUNCTION
BOX (J/B)



BACK-UP LAMP

Wiring Diagram — BACK/L —

Wiring Diagram — BACK/L —

NMEL0026

EL-BACK/L-01



REFER TO THE FOLLOWING.

(E101) -SUPER MULTIPLE JUNCTION (SMJ)
(E105) -FUSE BLOCK-JUNCTION BOX (J/B)


TURN SIGNAL AND HAZARD WARNING LAMPS

Wiring Diagram — TURN —

Wiring Diagram — TURN —

NMEL0032

EL-TURN-01



21	22	23	24	25	26	27	28	29
30	31	32	33	34	35	36	37	38
39	40							

(M19)
BR

1	2
3	

(M21)
B

4	5	6
8	7	2
1	3	

(M36)
W

REFER TO THE FOLLOWING.
(M7) - FUSE BLOCK-JUNCTION BOX (J/B)

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

TEL793B


TURN SIGNAL AND HAZARD WARNING LAMPS

Wiring Diagram — TURN — (Cont'd)

EL-TURN-02



REFER TO THE FOLLOWING.
(E101), (F4) -SUPER MULTIPLE
JUNCTION (SMJ)



TURN SIGNAL AND HAZARD WARNING LAMPS

Trouble Diagnoses

Trouble Diagnoses

NMEL0033

Symptom	Possible cause	Repair order
Turn signal and hazard warning lamps do not operate.	1. Hazard switch 2. Combination flasher unit 3. Open in combination flasher unit circuit	1. Check hazard switch. 2. Refer to combination flasher unit check. 3. Check wiring to combination flasher unit for open circuit.
Turn signal lamps do not operate but hazard warning lamps operate.	1. 10A fuse 2. Hazard switch 3. Turn signal switch 4. Open in turn signal switch circuit	1. Check 10A fuse [No. 2, located in fuse block (J/B)]. Turn ignition switch ON and verify battery positive voltage is present at terminal 2 of hazard switch. 2. Check hazard switch. 3. Check turn signal switch. 4. Check the wire between combination flasher unit terminal 3 and turn signal switch terminal 1 for open circuit.
Hazard warning lamps do not operate but turn signal lamps operate.	1. 15A fuse 2. Hazard switch 3. Open in hazard switch circuit	1. Check 15A fuse [No. 17, located in fuse block (J/B)]. Verify battery positive voltage is present at terminal 3 of hazard switch. 2. Check hazard switch. 3. Check the wire between combination flasher unit terminal 3 and hazard switch terminal 4 for open circuit.
Headlamp assembly LH or RH does not operate.	1. Bulb 2. Grounds E43 and E57 3. Open in headlamp assembly circuit	1. Check bulb. 2. Check grounds E43 and E57. 3. Check the wire between headlamp assembly and turn signal switch.
Rear combination lamp LH or RH does not operate.	1. Bulb 2. Grounds B2, B18 and T19 3. Open in rear combination lamp circuit	1. Check bulb. 2. Check grounds B2, B18 and T19. 3. Check the wire between rear combination lamp and turn signal switch.
Side turn signal lamp LH does not operate.	1. Bulb 2. Grounds M1 and M67 3. Open in side turn signal lamp LH circuit	1. Check bulb. 2. Check grounds M1 and M67. 3. Check harness between side turn signal lamp LH and turn signal switch.
Side turn signal lamp RH does not operate.	1. Bulb 2. Grounds E43 and E57 3. Open in side turn signal lamp RH circuit	1. Check bulb. 2. Check grounds E43 and E57. 3. Check harness between side turn signal lamp RH and turn signal switch.
LH and RH turn indicators do not operate.	1. Ground	1. Check grounds M1 and M67.
LH or RH turn indicator does not operate.	1. Bulb 2. Open combination meter circuit	1. Check bulb in combination meter. 2. Check the wire between hazard switch and combination meter.


Blub Replacement

Refer to "Bulb Replacement" in "HEADLAMP", EL-32.

NMEL0322

TURN SIGNAL AND HAZARD WARNING LAMPS

Electrical Components Inspection



Electrical Components Inspection

COMBINATION FLASHER UNIT CHECK

NMEL0034

NMEL0034S01


- Before checking, ensure that bulbs meet specifications.
- Connect a battery and test lamp to the combination flasher unit, as shown. Combination flasher unit is properly functioning if it blinks when power is supplied to the circuit.

ILLUMINATION

Schematic

Schematic

NMEL0036



GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX

TEL795B



EL-ILL-01



Wiring Diagram — ILL — (Cont'd)

Wiring Diagram — ILL — (Cont'd)



EL-ILL-02



ILLUMINATION

Wiring Diagram — ILL — (Cont'd)

EL-ILL-03



TEL798B

System Description

NMEL0165

NMEL0165S01

POWER SUPPLY AND GROUND

Power is supplied at all times:

- through 10A fuse [No. 28, located in the fuse block (J/B)]
- to key switch terminal 1
- through 10A fuse [No. 26, located in the fuse block (J/B)]
- to interior room lamp terminal 1.

When the key is withdrawn from ignition key cylinder, power is interrupted:

- through key switch terminal 2
- to combination meter terminal 33.

With the ignition key switch in the ON or START position, power is supplied:

- through 10A fuse [No. 11, located in the fuse block (J/B)]
- to combination meter terminal 12.

When the driver side door is opened, ground is supplied:

- through case ground of door switch (driver side) and
- to door switch (driver side) terminal 1
- through body grounds B2 and B18
- to door switch (driver side) terminal 3
- from door switch (driver side) terminal 2
- to combination meter terminal 24.

When the passenger side door is opened, ground is supplied:

- through case ground of door switch (passenger side)
- to door switch (passenger side) terminal 1
- to combination meter terminal 5.

When the driver side door is unlocked, unified meter control unit (time control system) receives a ground signal:

- through body grounds terminals M1 and M67
- to door unlock sensor terminal 1
- from door unlock sensor terminal 2
- to combination meter terminal 22.

When a signal, or combination of signals is received by the unified meter control unit (time control system), ground is supplied:

- through combination meter terminal 38
- to interior room lamp terminal 2.

With power and ground supplied, the interior room lamp illuminates.

SWITCH OPERATION

When interior room lamp switch is ON, ground is supplied:

- through case grounds of interior room lamp
- to interior room lamp.

INTERIOR ROOM LAMP TIMER OPERATION

When interior room lamp switch is in the "DOOR" position, the unified meter control unit (time control system) keeps the interior room lamp illuminated for about 20 seconds when:

- unlock signal is supplied from door unlock sensor while all doors are closed and key is out of ignition key cylinder
- key is withdrawn from ignition key cylinder while all doors are closed
- driver's door is opened and then closed while key is out of the ignition key cylinder. (However, if the driver's door is closed with the key inserted in the ignition key cylinder after the driver's door is opened with the key withdrawn, the timer is operated.)

The timer is canceled when:

- driver's door is locked,
- driver's door is opened, or

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

AX

SU

BR

ST

NMEL0165S02

RS

BT

NMEL0165S03

HA

SC

EL

IDX

INTERIOR ROOM LAMP

System Description (Cont'd)

- ignition switch is turned ON.

When driver's door is locked, interior room lamp timer is canceled as described before.

ON-OFF CONTROL

When the driver side door or passenger door is opened, the interior room lamp turns on while the interior room lamp switch is in the "DOOR" position.

NMEL0165S04

INTERIOR ROOM LAMP

Wiring Diagram — ROOM/L —






Wiring Diagram — ROOM/L —

NMEL0163

EL-ROOM/L-01

REFER TO EL-POWER.

SR : WITH SUNROOF
OS : WITHOUT SUNROOF



REFER TO THE FOLLOWING.

E101 -SUPER MULTIPLE JUNCTION (SMJ)
M6 , M7 , E105 -FUSE BLOCK-JUNCTION BOX (J/B)

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

TEL799B

INTERIOR ROOM LAMP

Trouble Diagnoses for Interior Lamp Timer


Trouble Diagnoses for Interior Lamp Timer


=NMEL0215

DIAGNOSTIC PROCEDURE 1

NMEL0215S01



SYMPTOM: Interior lamp timer does not operate.


1	CHECK IGNITION ON SIGNAL																
1. Disconnect combination meter harness connector. 2. Check voltage between combination meter harness connector M18 terminal 12 (G/Y) and ground.																	
 <table border="1" data-bbox="787 472 1388 598"> <thead> <tr> <th colspan="2">Terminal No.</th> <th colspan="3">Ignition switch position</th> </tr> <tr> <th>(+)</th> <th>(-)</th> <th>OFF</th> <th>ACC</th> <th>ON</th> </tr> </thead> <tbody> <tr> <td>12</td> <td>Ground</td> <td>0V</td> <td>0V</td> <td>Battery voltage</td> </tr> </tbody> </table>			Terminal No.		Ignition switch position			(+)	(-)	OFF	ACC	ON	12	Ground	0V	0V	Battery voltage
Terminal No.		Ignition switch position															
(+)	(-)	OFF	ACC	ON													
12	Ground	0V	0V	Battery voltage													
SEL216Y																	
OK or NG																	
OK	▶	GO TO 2.															
NG	▶	Check the following. 10A fuse [No. 11, located in fuse block (J/B)] - Harness for open or short between combination meter and fuse															

2	CHECK DOOR SWITCH INPUT SIGNAL																			
1. Connect combination meter harness connector. 2. Check the following. - Voltage between combination meter harness connector M19 terminal 24 (BR/W) and ground (Driver side) - Voltage between combination meter harness connector M18 terminal 5 (P) and ground (Passenger side)																				
 <table border="1" data-bbox="868 1186 1429 1375"> <thead> <tr> <th colspan="2">Terminals No.</th> <th rowspan="2">Condition (Door)</th> <th rowspan="2">Voltage [V]</th> </tr> <tr> <th>(+)</th> <th>(-)</th> </tr> </thead> <tbody> <tr> <td rowspan="2">24</td> <td rowspan="2">Ground</td> <td>Open</td> <td>0</td> </tr> <tr> <td>Closed</td> <td>Approx. 5</td> </tr> <tr> <td rowspan="2">5</td> <td rowspan="2">Ground</td> <td>Open</td> <td>0</td> </tr> <tr> <td>Closed</td> <td>Approx. 5</td> </tr> </tbody> </table>			Terminals No.		Condition (Door)	Voltage [V]	(+)	(-)	24	Ground	Open	0	Closed	Approx. 5	5	Ground	Open	0	Closed	Approx. 5
Terminals No.		Condition (Door)	Voltage [V]																	
(+)	(-)																			
24	Ground	Open	0																	
		Closed	Approx. 5																	
5	Ground	Open	0																	
		Closed	Approx. 5																	
SEL217Y																				
OK or NG																				
OK	▶	GO TO 4.																		
NG	▶	GO TO 3.																		

INTERIOR ROOM LAMP

Trouble Diagnoses for Interior Lamp Timer (Cont'd)


3	CHECK DOOR SWITCH														
1. Disconnect door switch harness connector. 2. Check the following. ● Continuity between door switch harness connector B14 terminals 2 and 3, and terminal 1 and ground (Driver side). ● Continuity between door switch harness connector B12 terminal 1 and ground (Passenger side).															
 Door switch connector  Door switch connector <table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <thead> <tr> <th style="padding: 5px;">Terminal No.</th> <th style="padding: 5px;">Condition (Door switch)</th> <th style="padding: 5px;">Continuity</th> </tr> </thead> <tbody> <tr> <td rowspan="2" style="padding: 5px;">2-3</td> <td style="padding: 5px;">Pushed</td> <td style="padding: 5px;">No</td> </tr> <tr> <td style="padding: 5px;">Released</td> <td style="padding: 5px;">Yes</td> </tr> <tr> <td rowspan="2" style="padding: 5px;">1-Ground</td> <td style="padding: 5px;">Pushed</td> <td style="padding: 5px;">No</td> </tr> <tr> <td style="padding: 5px;">Released</td> <td style="padding: 5px;">Yes</td> </tr> </tbody> </table>			Terminal No.	Condition (Door switch)	Continuity	2-3	Pushed	No	Released	Yes	1-Ground	Pushed	No	Released	Yes
Terminal No.	Condition (Door switch)	Continuity													
2-3	Pushed	No													
	Released	Yes													
1-Ground	Pushed	No													
	Released	Yes													
SEL218Y															
OK or NG															
OK	▶	Check the following. ● Door switch ground circuit and condition ● Harness for open or short between combination meter and door switch													
NG	▶	Replace door switch.													


4	CHECK DOOR UNLOCK SENSOR CIRCUIT									
1. Disconnect combination meter harness connector. 2. Check continuity between combination meter harness connector M19 terminal 22 (W/G) and ground.										
 Combination meter connector <table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <thead> <tr> <th style="padding: 5px;">Terminal No.</th> <th style="padding: 5px;">Condition (Driver's door)</th> <th style="padding: 5px;">Continuity</th> </tr> </thead> <tbody> <tr> <td rowspan="2" style="padding: 5px;">22-Ground</td> <td style="padding: 5px;">Locked</td> <td style="padding: 5px;">No</td> </tr> <tr> <td style="padding: 5px;">Unlocked</td> <td style="padding: 5px;">Yes</td> </tr> </tbody> </table>			Terminal No.	Condition (Driver's door)	Continuity	22-Ground	Locked	No	Unlocked	Yes
Terminal No.	Condition (Driver's door)	Continuity								
22-Ground	Locked	No								
	Unlocked	Yes								
SEL219Y										
OK or NG										
OK	▶	GO TO 7.								
NG	▶	GO TO 5.								

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

INTERIOR ROOM LAMP


Trouble Diagnoses for Interior Lamp Timer (Cont'd)



5	CHECK DOOR UNLOCK SENSOR									
1. Disconnect door unlock sensor harness connector. 2. Check continuity between door unlock sensor harness connector D8 terminals 1 and 2.										
 Door unlock sensor connector  <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th>Terminal No.</th> <th>Condition (Driver's Door)</th> <th>Continuity</th> </tr> </thead> <tbody> <tr> <td rowspan="2" style="text-align: center;">1-2</td> <td style="text-align: center;">Locked</td> <td style="text-align: center;">No</td> </tr> <tr> <td style="text-align: center;">Unlocked</td> <td style="text-align: center;">Yes</td> </tr> </tbody> </table>			Terminal No.	Condition (Driver's Door)	Continuity	1-2	Locked	No	Unlocked	Yes
Terminal No.	Condition (Driver's Door)	Continuity								
1-2	Locked	No								
	Unlocked	Yes								
SEL220Y										
OK or NG										
OK	▶	GO TO 6.								
NG	▶	Replace door unlock sensor.								

6	CHECK DOOR UNLOCK SENSOR INPUT SIGNAL													
1. Connect door unlock sensor harness connector and combination meter harness connector. 2. Check voltage combination meter harness connector M19 terminal 22 (W/G) and ground.														
 Combination meter connector  <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th colspan="2">Terminal No.</th> <th rowspan="2">Condition (Driver's Door)</th> <th rowspan="2">Voltage [V]</th> </tr> <tr> <th>(+)</th> <th>(-)</th> </tr> </thead> <tbody> <tr> <td rowspan="2" style="text-align: center;">22</td> <td rowspan="2" style="text-align: center;">Ground</td> <td style="text-align: center;">Locked</td> <td style="text-align: center;">Approx. 5</td> </tr> <tr> <td style="text-align: center;">Unlocked</td> <td style="text-align: center;">0</td> </tr> </tbody> </table>			Terminal No.		Condition (Driver's Door)	Voltage [V]	(+)	(-)	22	Ground	Locked	Approx. 5	Unlocked	0
Terminal No.		Condition (Driver's Door)	Voltage [V]											
(+)	(-)													
22	Ground	Locked	Approx. 5											
		Unlocked	0											
SEL221Y														
OK or NG														
OK	▶	Check the following. ● Door unlock sensor ground circuit ● Harness for open or short between combination meter and door unlock sensor												
NG	▶	Replace combination meter.												

INTERIOR ROOM LAMP

Trouble Diagnoses for Interior Lamp Timer (Cont'd)

7	CHECK KEY SWITCH INPUT SIGNAL	
Check voltage between combination meter harness connector M19 terminal 33 (B/P) and ground.		
 CONNECT   : Approx. 12V  : 0V Combination meter connector  Voltage [V]: Condition of key switch: key is inserted. Approx. 12 Condition of key switch: key is withdrawn. 0		
SEL222Y		
OK or NG		
OK	▶	Replace unified meter control unit.
NG	▶	GO TO 8.

8	CHECK KEY SWITCH (INSERT)	
1. Disconnect key switch harness connector. 2. Check continuity between key switch harness connector E108 terminals 1 and 2.		
   Key switch connector  Continuity: Condition of key switch: key is inserted. Yes Condition of key switch: key is withdrawn. No		
SEL223Y		
OK or NG		
OK	▶	Check the following. ● 10A fuse [No. 28, located in fuse block (J/B)] ● Harness for open or short between key switch and fuse ● Harness for open or short between combination meter and key switch
NG	▶	Replace key switch.


INTERIOR ROOM LAMP


Trouble Diagnoses for Interior Lamp Timer (Cont'd)

DIAGNOSTIC PROCEDURE 2

=NMEL0215S02


SYMPTOM: Interior lamp timer does not cancel properly.


1	CHECK IGNITION ON SIGNAL															
1. Disconnect combination meter harness connector. 2. Check voltage between combination meter harness connector M18 terminal 12 (G/Y) and ground.																
 Combination meter connector  <table border="1" style="border-collapse: collapse; text-align: center;"> <thead> <tr> <th colspan="2" style="text-align: left;">Terminal No.</th> <th colspan="3" style="text-align: left;">Ignition switch position</th> </tr> <tr> <th style="text-align: left;">(+)</th> <th style="text-align: left;">(-)</th> <th style="text-align: left;">OFF</th> <th style="text-align: left;">ACC</th> <th style="text-align: left;">ON</th> </tr> </thead> <tbody> <tr> <td>12</td> <td>Ground</td> <td>0V</td> <td>0V</td> <td>Battery voltage</td> </tr> </tbody> </table>		Terminal No.		Ignition switch position			(+)	(-)	OFF	ACC	ON	12	Ground	0V	0V	Battery voltage
Terminal No.		Ignition switch position														
(+)	(-)	OFF	ACC	ON												
12	Ground	0V	0V	Battery voltage												
SEL216Y																
OK or NG																
OK	▶ GO TO 2.															
NG	Check the following. 10A fuse [No. 11, located in fuse block (J/B)] - Harness for open or short between combination meter and fuse															

2	CHECK DOOR SWITCH INPUT SIGNAL																		
1. Connect combination meter harness connector. 2. Check the following. - Voltage between combination meter harness connector M19 terminal 24 (BR/W) and ground (Driver side) - Voltage between combination meter harness connector M18 terminal 5 (P) and ground (Passenger side)																			
 Combination meter connector Combination meter connector  <table border="1" style="border-collapse: collapse; text-align: center;"> <thead> <tr> <th colspan="2" style="text-align: left;">Terminals No.</th> <th rowspan="2" style="text-align: left;">Condition (Door)</th> <th rowspan="2" style="text-align: left;">Voltage [V]</th> </tr> <tr> <th style="text-align: left;">(+)</th> <th style="text-align: left;">(-)</th> </tr> </thead> <tbody> <tr> <td rowspan="2">24</td> <td rowspan="2">Ground</td> <td>Open</td> <td>0</td> </tr> <tr> <td>Closed</td> <td>Approx. 5</td> </tr> <tr> <td rowspan="2">5</td> <td rowspan="2">Ground</td> <td>Open</td> <td>0</td> </tr> <tr> <td>Closed</td> <td>Approx. 5</td> </tr> </tbody> </table>		Terminals No.		Condition (Door)	Voltage [V]	(+)	(-)	24	Ground	Open	0	Closed	Approx. 5	5	Ground	Open	0	Closed	Approx. 5
Terminals No.		Condition (Door)	Voltage [V]																
(+)	(-)																		
24	Ground	Open	0																
		Closed	Approx. 5																
5	Ground	Open	0																
		Closed	Approx. 5																
SEL217Y																			
OK or NG																			
OK	▶ GO TO 4.																		
NG	▶ GO TO 3.																		

INTERIOR ROOM LAMP


Trouble Diagnoses for Interior Lamp Timer (Cont'd)


3	CHECK DOOR SWITCH														
1. Disconnect door switch harness connector. 2. Check the following. • Continuity between harness connector B14 terminals 2 and 3, and terminal 1 and ground (Driver side) • Continuity between door switch harness connector B12 terminal 1 and ground (Passenger side)															
 <table border="1" style="margin-left: 20px;"> <thead> <tr> <th>Terminal No.</th> <th>Condition (Door switch)</th> <th>Continuity</th> </tr> </thead> <tbody> <tr> <td rowspan="2">2-3</td> <td>Pushed</td> <td>No</td> </tr> <tr> <td>Released</td> <td>Yes</td> </tr> <tr> <td rowspan="2">1-Ground</td> <td>Pushed</td> <td>No</td> </tr> <tr> <td>Released</td> <td>Yes</td> </tr> </tbody> </table>			Terminal No.	Condition (Door switch)	Continuity	2-3	Pushed	No	Released	Yes	1-Ground	Pushed	No	Released	Yes
Terminal No.	Condition (Door switch)	Continuity													
2-3	Pushed	No													
	Released	Yes													
1-Ground	Pushed	No													
	Released	Yes													
SEL218Y															
OK or NG															
OK	▶	Check the following. • Door switch ground circuit and condition • Harness for open or short between combination meter and door switch													
NG	▶	Replace door switch.													

4	CHECK DOOR UNLOCK SENSOR INPUT SIGNAL									
1. Disconnect combination meter harness connector. 2. Check continuity between combination meter harness connector M19 terminal 22 (W/G) and ground.										
 <table border="1" style="margin-left: 20px;"> <thead> <tr> <th>Terminal No.</th> <th>Condition (Driver's door)</th> <th>Continuity</th> </tr> </thead> <tbody> <tr> <td rowspan="2">22-Ground</td> <td>Locked</td> <td>No</td> </tr> <tr> <td>Unlocked</td> <td>Yes</td> </tr> </tbody> </table>			Terminal No.	Condition (Driver's door)	Continuity	22-Ground	Locked	No	Unlocked	Yes
Terminal No.	Condition (Driver's door)	Continuity								
22-Ground	Locked	No								
	Unlocked	Yes								
SEL219Y										
OK or NG										
OK	▶	Replace unified meter control unit.								
NG	▶	GO TO 5.								

INTERIOR ROOM LAMP

Trouble Diagnoses for Interior Lamp Timer (Cont'd)

5	CHECK DOOR UNLOCK SENSOR									
1. Disconnect door unlock sensor harness connector. 2. Check continuity between door unlock sensor harness connector D8 terminals 1 and 2.										
 Door unlock sensor connector  <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th>Terminal No.</th> <th>Condition (Driver's Door)</th> <th>Continuity</th> </tr> </thead> <tbody> <tr> <td rowspan="2" style="text-align: center;">1-2</td> <td style="text-align: center;">Locked</td> <td style="text-align: center;">No</td> </tr> <tr> <td style="text-align: center;">Unlocked</td> <td style="text-align: center;">Yes</td> </tr> </tbody> </table>			Terminal No.	Condition (Driver's Door)	Continuity	1-2	Locked	No	Unlocked	Yes
Terminal No.	Condition (Driver's Door)	Continuity								
1-2	Locked	No								
	Unlocked	Yes								
SEL220Y										
OK or NG										
OK	▶	GO TO 6.								
NG	▶	Replace door unlock sensor.								

6	CHECK DOOR UNLOCK SENSOR INPUT SIGNAL													
1. Connect door unlock sensor harness connector and combination meter harness connector. 2. Check voltage combination meter harness connector M19 terminal 22 (W/G) and ground.														
 Combination meter connector  <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th colspan="2">Terminal No.</th> <th rowspan="2">Condition (Driver's Door)</th> <th rowspan="2">Voltage [V]</th> </tr> <tr> <th>(+)</th> <th>(-)</th> </tr> </thead> <tbody> <tr> <td rowspan="2" style="text-align: center;">22</td> <td rowspan="2" style="text-align: center;">Ground</td> <td style="text-align: center;">Locked</td> <td style="text-align: center;">Approx. 5</td> </tr> <tr> <td style="text-align: center;">Unlocked</td> <td style="text-align: center;">0</td> </tr> </tbody> </table>			Terminal No.		Condition (Driver's Door)	Voltage [V]	(+)	(-)	22	Ground	Locked	Approx. 5	Unlocked	0
Terminal No.		Condition (Driver's Door)	Voltage [V]											
(+)	(-)													
22	Ground	Locked	Approx. 5											
		Unlocked	0											
SEL221Y														
OK or NG														
OK	▶	Check the following. - Door unlock sensor ground circuit - Harness for open or short between combination meter and door unlock sensor												
NG	▶	Replace unified meter control unit.												



SPOT AND TRUNK ROOM LAMPS

Wiring Diagram — INT/L —

Wiring Diagram — INT/L —

NMEL0323

EL-INT/L-01



REFER TO THE FOLLOWING.
M6, B4 - FUSE BLOCK-
JUNCTION BOX (J/B)

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


TEL800B

METERS AND GAUGES

Component Parts and Harness Connector Location

Component Parts and Harness Connector Location

NMEL0041



SEL255Y

System Description

NMEL0042

UNIFIED CONTROL METER

NMEL0042S06

- Speedometer, odo/trip meter, tachometer, fuel gauge and water temperature gauge are controlled totally by unified meter control unit built-in combination meter.
- Digital meter is adopted for odo/trip meter.*
*The record of the odo meter is kept even if the battery cable is disconnected. The record of the trip meter is erased when the battery cable is disconnected.
- Odo/trip meter segment can be checked in diagnosis mode.
- Meter/gauge can be checked in diagnosis mode.

POWER SUPPLY AND GROUND CIRCUIT

NMEL0042S08

Power is supplied at all times

- through 10A fuse [No. 28, located in the fuse block (J/B)]
- to combination meter terminal 13.

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 11, located in the fuse block (J/B)]
- to combination meter terminal 12.

Ground is supplied

- to combination meter terminal 9
- through body grounds M1 and M67.

WATER TEMPERATURE GAUGE

NMEL0042S01

The water temperature gauge indicates the engine coolant temperature. The reading on the gauge is based on the resistance of the thermal transmitter.

As the temperature of the coolant increases, the resistance of the thermal transmitter decreases. A variable ground is supplied to terminal 18 of the combination meter for the water temperature gauge. The needle on the gauge moves from "C" to "H".

TACHOMETER

NMEL0042S02

The tachometer indicates engine speed in revolutions per minute (rpm).

The tachometer is regulated by a signal

- from terminal 2 of the ECM
- to combination meter terminal 15 for the tachometer.

FUEL GAUGE

The fuel gauge indicates the approximate fuel level in the fuel tank.
The fuel gauge is regulated by a variable ground signal supplied

- to combination meter terminal 17 for the fuel gauge
- from terminal 2 of the fuel level sensor unit
- through terminal 4 of the fuel level sensor unit and
- through body grounds B2, B18 and T19.

SPEEDOMETER

The combination meter provides a voltage signal to the ABS control unit for the speedometer.
The voltage is supplied

- from combination meter terminal 14 for the speedometer
- to terminal 11 of ABS control unit.

The speedometer converts the voltage into the vehicle speed displayed.

TIME CONTROL SYSTEM

For time control system operation, refer to “UNIFIED METER CONTROL UNIT (TIME CONTROL SYSTEM)”, EL-131.

NMEL0042S03

GI

MA

EM

NMEL0042S04

LC

EC

NMEL0042S09

FE

CL

MT

AT

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL



IDX

Combination Meter

NMEL0043

NMEL0043S01

CHECK



Bulb socket color	Bulb wattage
Brown	1.4W
Blue	2.0W
Black	3.0W



(): Bulb socket color

CONSTRUCTION

NMEL0043S02

SEC. 248

() : Numbers of holding screw



FEL263Y

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

METERS AND GAUGES

Schematic

Schematic

NMEL0324

		SPEEDOMETER (	7
			8
			9
		TACHOMETER (	14
			15
			17
		WATER TEMP. GAUGE (	18
			20
		FUEL GAUGE (	22
		UNIFIED METER CONTROL UNIT (WITH ODO/TRIP METER)	24
			31
			33
12			35
			36
13			37
			38

		AIR BAG	
			26
		WARNING BUZZER	
		CLOCK	
		DOOR (1. 4W)	5
		O/D OFF (1. 4W) (A)	64
		OIL (1. 4W)	62
		BELT (1. 4W)	6
		CHARGE (3W)	61
		MALFUNCTION INDICATOR (1. 4W)	63
		FUEL (1. 4W)	
		ABS (1. 4W)	44
		BRAKE (1. 4W)	45
27		TURN RH (1. 4W)	28
21		TURN LH (1. 4W)	29
40		HIGH BEAM (1. 4W)	
		CLOCK ILLUMINATION (2W)	
		ODO/TRIP METER ILLUMINATION (2W)	
32		METER ILLUMINATION (3Wx3, 1. 4Wx2)	11
		A/T INDICATOR (1. 4Wx6) (A)	
46		P	60
47		R	
48		N	
49		D	
50		2	
51		1	

TEL801B

Wiring Diagram — METER —

NMEL0045

EL-METER-01

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

AX

SU

BR

ST

RS






BT

HA

SC

EL

IDX



REFER TO THE FOLLOWING.

(F4) -SUPER MULTIPLE JUNCTION (SMJ)
(M6, M7) -FUSE BLOCK-JUNCTION BOX (J/B)

METERS AND GAUGES

Meter/Gauge Operation and Odo/Trip Meter Segment Check in Diagnosis Mode

Meter/Gauge Operation and Odo/Trip Meter Segment Check in Diagnosis Mode

NMEL0151

DIAGNOSIS FUNCTION


NMEL0151S01

- Odo/trip meter segment can be checked in diagnosis mode.
- Meters/gauges can be checked in diagnosis mode.

HOW TO ALTERNATE DIAGNOSIS MODE

NMEL0151S02

1. Turn ignition switch to ON and change odo/trip meter to "TRIP A" or "TRIP B".
2. Turn ignition switch to OFF.
3. Turn ignition switch to ON when pushing odo/trip meter switch.
4. Confirm that trip meter indicates "0000.0".
5. Push odo/trip meter switch more than three times within 5 seconds.




6. All odo/trip meter segments should be turned on.

NOTE:

If some segments are not turned on, unified meter control unit with odo/trip meter should be replaced.

At this point, the unified control meter is turned to diagnosis mode.



7. Push odo/trip meter switch. Indication of each meter/gauge should be as shown left during pushing odo/trip meter switch if it is no malfunctioning.

NOTE:

It takes about a few seconds for indication of fuel gauge and water temperature gauge to become stable.

Trouble Diagnoses PRELIMINARY CHECK

NMEL0046

NMEL0046S04

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

AX

SU

BR

ST

RS


BT

HA

SC

EL

IDX



SEL361W

*1: Meter/Gauge Operation and Odo/
Trip Meter Segment Check in
Diagnosis Mode (EL-64)

*2: METER/GAUGE RESISTANCE
CHECK (EL-71)

*3: POWER SUPPLY AND GROUND
CIRCUIT CHECK (EL-67)

*4: Symptom Chart 1 (EL-66)

*5: Symptom Chart 2 (EL-66)

METERS AND GAUGES

Trouble Diagnoses (Cont'd)

SYMPTOM CHART

NMEL0046S10

Symptom Chart 1 (Malfunction is Indicated in Diagnosis Mode)

NMEL0046S1001


Symptom	Possible causes	Repair order
Odo/trip meter indicate(s) malfunction in Diagnosis mode.	Unified meter control unit	Replace unified meter control unit.
Multiple meter/gauge indicate malfunction in Diagnosis mode.		
One of speedometer/tachometer/fuel gauge/water temp. gauge indicates malfunction in Diagnosis mode.	1. Meter/Gauge 2. Unified meter control unit	1. Check resistance of meter/gauge indicating malfunction. If the resistance is NG, replace the meter/gauge. Refer to "METER/GAUGE RESISTANCE CHECK", EL-71. 2. If the resistance of meter/gauge is OK, replace unified meter control unit.

Symptom Chart 2 (No Malfunction is Indicated in Diagnosis Mode)

NMEL0046S1002

Symptom	Possible causes	Repair order
One of speedometer/tachometer/fuel gauge/water temp. gauge is malfunctioning.	1. Sensor signal - Vehicle speed signal - Engine revolution signal - Fuel gauge - Water temp. gauge 2. Unified meter control unit	1. Check the sensor for malfunctioning meter/gauge. INSPECTION/VEHICLE SPEED SIGNAL (Refer to EL-68.) INSPECTION/ENGINE REVOLUTION SIGNAL (Refer to EL-68.) INSPECTION/FUEL LEVEL SENSOR UNIT (Refer to EL-69.) INSPECTION/THERMAL TRANSMITTER (Refer to EL-70.) 2. Replace unified meter control unit.
Multiple meter/gauge are malfunctioning. (except odo/trip meter)		

Before starting trouble diagnoses below, perform PRELIMINARY CHECK, EL-65.



POWER SUPPLY AND GROUND CIRCUIT CHECK

=NMEL0046S07


Power Supply Circuit Check

NMEL0046S0701

Terminals		Ignition switch position			
(+) (−)		OFF	ACC	ON	
Connector	Terminal (Wire color)				
M18	13 (R/W)	Ground	Battery voltage	Battery voltage	Battery voltage
	12 (G/Y)	Ground	0V	0V	Battery voltage

If NG, check the following.

- 10A fuse [No. 28, located in fuse block (J/B)]
- 10A fuse [No. 11, located in fuse block (J/B)]
- Harness for open or short between fuse and combination meter



Ground Circuit Check

NMEL0046S0702

Terminals			Continuity
(+)		(−)	
Connector	Terminal (Wire color)		
M18	9 (B)	Ground	Yes


GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

METERS AND GAUGES

Trouble Diagnoses (Cont'd)

INSPECTION/VEHICLE SPEED SIGNAL


=NMEL0046S03

1	CHECK ABS CONTROL UNIT OUTPUT
- Lift up drive wheel. - Turn ignition switch "ON". - Check voltage between combination meter harness connector M18 terminal 14 (LG) and ground when rotating wheel by hand.	
 Combination meter connector Voltage: Approx. 0 - 5V	
OK or NG	
OK	▶ ABS control unit output signal is OK.
NG	▶ Check the following. • Harness for open or short between ABS control unit and combination meter. • ABS control unit. Refer to BR-72, "Control Unit".

SEL226Y

INSPECTION/ENGINE REVOLUTION SIGNAL

NMEL0046S02

1	CHECK ECM OUTPUT
- Start engine. - Check voltage between combination meter harness connector M18 terminals 15 (L/OR) and ground at idle and 2,000 rpm.	
 Combination meter connector Higher rpm = Higher voltage Lower rpm = Lower voltage Voltage should change with rpm.	
OK or NG	
OK	▶ Engine revolution signal is OK.
NG	▶ Harness for open or short between ECM and combination meter


SEL227Y

INSPECTION/FUEL LEVEL SENSOR UNIT

=NMEL0046S08

1	CHECK GROUND CIRCUIT FOR FUEL LEVEL SENSOR UNIT	
1. Disconnect fuel level sensor unit harness connector. 2. Check harness continuity between fuel level sensor unit harness connector T9 terminal 4 (B) and ground.		
 Fuel level sensor unit connector Continuity should exist.		
SEL228Y		
OK or NG		
OK	▶	GO TO 2.
NG	▶	Repair harness or connector.

2	CHECK FUEL LEVEL SENSOR UNIT	
Refer to “FUEL LEVEL SENSOR UNIT CHECK” (EL-71).		
OK or NG		
OK	▶	GO TO 3.
NG	▶	Replace fuel level sensor unit.

3	CHECK HARNESS FOR OPEN OR SHORT	
1. Disconnect combination meter connector and fuel level sensor unit connector. 2. Check continuity between combination meter harness connector M18 terminal 17 (W/B) and fuel level sensor unit harness connector T9 terminal 2 (W/B). Continuity should exist. 3. Check continuity between combination meter harness connector M18 terminal 17 (W/B) and ground. Continuity should not exist.		
Combination meter connector  OK or NG		
OK	▶	Fuel level sensor unit is OK.
NG	▶	Repair harness or connector.


METERS AND GAUGES



Trouble Diagnoses (Cont'd)

INSPECTION/THERMAL TRANSMITTER

=NMEL0046S09

1	CHECK THERMAL TRANSMITTER	
Refer to "THERMAL TRANSMITTER CHECK" (EL-72).		
OK or NG		
OK	▶	GO TO 2.
NG	▶	Replace.

2	CHECK HARNESS FOR OPEN OR SHORT	
1. Disconnect combination meter connector and thermal transmitter connector. 2. Check continuity between combination meter harness connector M18 terminal 18 (L/W) and thermal transmitter harness connector F117 terminal 1 (L/W). Continuity should exist. 3. Check continuity between combination meter harness connector M18 terminal 18 (L/W) and ground. Continuity should not exist.		
Combination meter connector  Thermal transmitter connector   		
SEL230Y		
OK or NG		
OK	▶	Thermal transmitter is OK.
NG	▶	Repair harness or connector.



Electrical Components Inspection

=NMEL0047

METER/GAUGE RESISTANCE CHECK

NMEL0047S04

Check resistance between installation screws of meter/gauge.

Screws		Resistance Ω
Tacho/Speedometer	Fuel/Temp. gauge	
A - C	A - C	Approx. 190 - Approx. 260
B - D	B - C	Approx. 230 - Approx. 310

FUEL LEVEL SENSOR UNIT CHECK

NMEL0047S01

- For removal, refer to FE-8, "FUEL SYSTEM".

Sending Unit

NMEL0047S0101

Check the resistance between terminals 2 and 4.

Ohmmeter		Float position mm (in)			Resistance value Ω
(+)	(-)				
2	4	*1	Full	361 (14.21)	Approx. 4 - 6
		*2	1/2	249 (9.80)	30 - 36
		*3	Empty	46 (1.81)	80 - 93


*1 and *3: When float is in contact with stopper.

METERS AND GAUGES

Electrical Components Inspection (Cont'd)

Lead Switch

=NMEL0047S0102




CEL314A

Lead switch is built into the fuel tank.

Check the continuity between terminals 5 and 6 or 5 and 7.

Terminals	Lead switch condition		Fuel level line	Fuel capacity (Approximate values) ℓ (Imp qt)
	SW1	SW2		
5-6 and 5-7	ON	ON	Above a	More than 6.8 (6)
5-6	OFF	ON	a - b	2.5 - 6.8 (2-1/4-6)
No continuity	OFF	OFF	Below b	Less than 2.5 (2-1/4)



MEL424F

THERMAL TRANSMITTER CHECK

NMEL0047S02

Check the resistance between the terminals of thermal transmitter and body ground.


Water temperature	Resistance
60°C (140°F)	Approx. 170 - 210Ω
100°C (212°F)	Approx. 47 - 53Ω

WARNING LAMPS

Schematic

Schematic

NMEL0049



GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL



IDX

TEL803B

WARNING LAMPS

Wiring Diagram — WARN — (Cont'd)

EL-WARN-02



REFER TO THE FOLLOWING.
(E101), (F4) -SUPER
MULTIPLE JUNCTION (SMJ)



TEL805B

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

WARNING LAMPS




Wiring Diagram — WARN — (Cont'd)

EL-WARN-03



REFER TO THE FOLLOWING.
(E101) -SUPER MULTIPLE JUNCTION (SMJ)

TEL806B



Electrical Components Inspection

FUEL WARNING LAMP OPERATION CHECK

NMEL0051

NMEL0051S01

1. Turn ignition switch "OFF".
2. Disconnect fuel level sensor unit harness connector T9.
3. Connect a resistor (80Ω) between fuel level sensor unit harness connector terminals 2 and 4.
4. Turn ignition switch "ON".

The fuel warning lamp should come on.

OIL PRESSURE SWITCH CHECK

NMEL0051S02

	Oil pressure kPa (bar, kg/cm ² , psi)	Continuity
Engine running	More than 10 - 20 (0.10 - 0.20, 0.1 - 0.2, 1 - 3)	No
Engine not running	Less than 10 - 20 (0.10 - 0.20, 0.1 - 0.2, 1 - 3)	Yes

Check the continuity between the terminals of oil pressure switch and body ground.

DIODE CHECK

NMEL0051S03

- Check continuity using an ohmmeter.
- Diode is functioning properly if test results are as shown in the figure at left.
- Check diodes at the combination meter harness connector instead of on the combination meter assembly. Refer to EL-74, "WARNING LAMP" wiring diagrams.

NOTE:

Specification may vary depending on the type of tester. Before performing this inspection, be sure to refer to the instruction manual for the tester to be used.




A/T INDICATOR

Wiring Diagram — AT/IND —

Wiring Diagram — AT/IND —

NMEL0159

EL-AT/IND-01



REFER TO THE FOLLOWING.

(E101) -SUPER MULTIPLE JUNCTION (SMJ)

(E105) -FUSE BLOCK-JUNCTION BOX (J/B)

TEL807B

WARNING BUZZER

Component Parts and Harness Connector Location

Component Parts and Harness Connector Location

NMEL0052

GI

MA

EM

LC


EC

FE

CL

SEL254Y

MT



System Description

NMEL0053

AT

The warning buzzer is controlled by unified meter control unit (time control system).

The warning buzzer is located in the combination meter.

Power is supplied at all times

- through 10A fuse [No. 28, located in the fuse block (J/B)]
- to key switch terminal 1,
- to combination meter terminal 13, and
- through 10A fuse (No. 39, located in the fuse and fusible link box)
- to lighting switch terminal 11.

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 11, located in the fuse block (J/B)]
- to combination meter terminal 12.

Ground is supplied to combination meter terminal 9 through body grounds M1 and M67.

When a signal, or combination of signals, is received by the unified meter control unit (time control system), the warning buzzer will sound.

IGNITION KEY WARNING BUZZER

NMEL0053S01

RS

With the key in the ignition key cylinder, the ignition switch in the OFF position, and the driver's door open, the warning buzzer will sound.

Power is supplied

- from key switch terminal 2
- to combination meter terminal 33.

Ground is supplied

- from door switch (driver side) terminal 2
- to combination meter terminal 24.

Door switch (driver side) terminal 3 is grounded through body grounds B2 and B18.

LIGHT WARNING BUZZER

NMEL0053S02

EL

With ignition switch OFF, driver's door open, and lighting switch in 1ST or 2ND position, warning buzzer will sound.

Power is supplied

- from lighting switch terminal 12
- to combination meter terminal 32.

IDX

WARNING BUZZER

System Description (Cont'd)

Ground is supplied

- from door switch (driver side) terminal 2
- to combination meter terminal 24.

Door switch (driver side) terminal 3 is grounded through body grounds B2 and B18.

WARNING BUZZER

Wiring Diagram — BUZZER —

Wiring Diagram — BUZZER —

NMEL0054

EL-BUZZER-01

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

AX

SU

BR

ST

RS



BT

HA

SC

EL

IDX



REFER TO THE FOLLOWING.

(E101) -SUPER MULTIPLE JUNCTION (SMJ)
 (M6, M7, E105) -FUSE BLOCK-JUNCTION BOX (J/B)

WARNING BUZZER


Trouble Diagnoses

Trouble Diagnoses SYMPTOM CHART

NMEL0055

NMEL0055S01

REFERENCE PAGE (EL-)	82	83	84	85
SYMPTOM	POWER SUPPLY AND GROUND CIRCUIT CHECK	DIAGNOSTIC PROCEDURE 1 (LIGHTING SWITCH INPUT SIGNAL CHECK)	DIAGNOSTIC PROCEDURE 2 (KEY SWITCH INSERT SIGNAL CHECK)	DIAGNOSTIC PROCEDURE 3
Light warning buzzer does not activate.	X	X		X
Ignition key warning buzzer does not activate.	X		X	X
All warning buzzers do not activate.	X			X



POWER SUPPLY AND GROUND CIRCUIT CHECK

NMEL0055S02


Power Supply Circuit Check

NMEL0055S0201

Terminals		Ignition switch position			
(+) (Terminal Wire color)		(-)	OFF	AAC	ON
M18	13 (R/W)	Ground	Battery voltage	Battery voltage	Battery voltage
	12 (G/Y)	Ground	0V	0V	Battery voltage

If NG, check the following:

- 10A fuse [No. 28, located in fuse block (J/B)]
- 10A fuse [No. 11, located in fuse block (J/B)]
- Harness for open or short between fuse and combination meter




Ground Circuit Check

NMEL0055S0202

Terminals			Continuity
(+) (Terminal Wire color)		(-)	
Connector	Terminal (Wire color)		
M18	9 (B)	Ground	Yes

DIAGNOSTIC PROCEDURE 1 (LIGHTING SWITCH
INPUT SIGNAL CHECK)

=NMEL0055S03

1	CHECK LIGHTING SWITCH INPUT SIGNAL	
Check voltage between combination meter harness connector M19 terminal 32 (R/L) and ground.		
 CONNECT  	Combination meter connector 	Voltage [V]: Condition of lighting switch: 1ST or 2ND Approx. 12 Condition of lighting switch: OFF 0
SEL231Y		
OK or NG		
OK	▶	Lighting switch is OK.
NG	▶	Check the following. ● 10A fuse (No. 39, located in the fuse and fusible link box) ● Lighting switch ● Harness for open or short between combination meter and fuse ● Harness for open or short between combination meter and lighting switch

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX



WARNING BUZZER

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 2 (KEY SWITCH INSERT SIGNAL CHECK)


=NMEL0055S04


1 CHECK KEY SWITCH INPUT SIGNAL	
Check voltage between combination meter harness connector M19 terminal 33 (B/P) and ground.  CONNECT Key switch connector Approx. 12V 0V  Combination meter connector  Voltage [V]: Condition of key switch: key is inserted. Approx. 12 Condition of key switch: key is withdrawn. 0 SEL222Y	
OK or NG	
OK	▶ Key switch is OK.
NG	▶ GO TO 2.

2 CHECK KEY SWITCH (INSERT)	
1. Disconnect key switch harness connector. 2. Check continuity between key switch harness connector E108 terminals 1 and 2.  DISCONNECT Key switch connector   Continuity: Condition of key switch: key is inserted. Yes Condition of key switch: key is withdrawn. No SEL223Y	
OK or NG	
OK	▶ Check the following. • 10A fuse [No. 28, located in fuse block (J/B)] • Harness for open or short between key switch and fuse • Harness for open or short between combination meter and key switch
NG	▶ Replace key switch.

DIAGNOSTIC PROCEDURE 3

=NMEL0055S06

1	CHECK IGNITION ON SIGNAL																
1. Disconnect combination meter harness connector. 2. Check voltage between combination meter harness connector M18 terminal 12 (G/Y) and ground.																	
 Combination meter connector  <table border="1" style="margin-left: 20px;"> <thead> <tr> <th colspan="2">Terminal No.</th> <th colspan="3">Ignition switch position</th> </tr> <tr> <th>(+)</th> <th>(-)</th> <th>OFF</th> <th>ACC</th> <th>ON</th> </tr> </thead> <tbody> <tr> <td>12</td> <td>Ground</td> <td>0V</td> <td>0V</td> <td>Battery voltage</td> </tr> </tbody> </table>			Terminal No.		Ignition switch position			(+)	(-)	OFF	ACC	ON	12	Ground	0V	0V	Battery voltage
Terminal No.		Ignition switch position															
(+)	(-)	OFF	ACC	ON													
12	Ground	0V	0V	Battery voltage													
SEL216Y																	
OK or NG																	
OK	▶	GO TO 2.															
NG	▶	Check the following. 10A fuse [No. 11, located in fuse block (J/B)] - Harness for open or short between combination meter and fuse															

2	CHECK DOOR SWITCH INPUT SIGNAL													
1. Connect combination meter harness connector. 2. Check voltage between combination meter harness connector M19 terminal 24 (BR/W) and ground.														
 Combination meter connector  <table border="1" style="margin-left: 20px;"> <thead> <tr> <th colspan="2">Terminals No.</th> <th rowspan="2">Condition (Driver's door)</th> <th rowspan="2">Voltage [V]</th> </tr> <tr> <th>(+)</th> <th>(-)</th> </tr> </thead> <tbody> <tr> <td rowspan="2">24</td> <td rowspan="2">Ground</td> <td>Open</td> <td>0</td> </tr> <tr> <td>Closed</td> <td>Approx. 5</td> </tr> </tbody> </table>			Terminals No.		Condition (Driver's door)	Voltage [V]	(+)	(-)	24	Ground	Open	0	Closed	Approx. 5
Terminals No.		Condition (Driver's door)	Voltage [V]											
(+)	(-)													
24	Ground	Open	0											
		Closed	Approx. 5											
SEL232Y														
OK or NG														
OK	▶	Driver side door switch is OK.												
NG	▶	GO TO 3.												

WARNING BUZZER

Trouble Diagnoses (Cont'd)


3

CHECK DRIVER SIDE DOOR SWITCH

1. Disconnect door switch harness connector.
2. Check continuity between door switch harness connector B14 terminals 2 and 3, and terminal and ground.



Door switch connector



Terminal No.	Condition (Driver's door switch)	Continuity
2-3	Pushed	No
	Released	Yes
1-Ground	Pushed	No
	Released	Yes

SEL233Y

OK or NG

OK	▶	Check the following. ● Driver side door switch ground circuit and condition ● Harness for open or short between combination meter and driver side door switch
NG	▶	Replace driver side door switch.

System Description

WIPER OPERATION

The wiper switch is controlled by a lever built into the combination switch. There are three wiper switch positions:

- LO speed
- HI speed
- INT (Intermittent)

With the ignition switch in the ON or START position, power is supplied

- through 20A fuse [No. 6, located in the fuse block (J/B)]
- to wiper motor terminal 4.

Low and High Speed Wiper Operation

Ground is supplied to wiper switch terminal 17 through body grounds E43 and E57.

When the wiper switch is placed in the LO position, ground is supplied

- through terminal 14 of the wiper switch
- to wiper motor terminal 2.

With power and ground supplied, the wiper motor operates at low speed.

When the wiper switch is placed in the HI position, ground is supplied

- through terminal 16 of the wiper switch
- to wiper motor terminal 3.

With power and ground supplied, the wiper motor operates at high speed.

Auto Stop Operation

With wiper switch turned OFF, wiper motor will continue to operate until wiper arms reach windshield base.

When wiper arms are not located at base of windshield with wiper switch OFF, ground is provided

- from terminal 14 of the wiper switch
- to wiper motor terminal 2, in order to continue wiper motor operation at low speed.

Ground is also supplied

- through terminal 13 of the wiper switch
- to wiper motor terminal 5
- through terminal 6 of the wiper motor, and
- through body grounds M67 and M1.

When wiper arms reach base of windshield, wiper motor terminals 4 and 5 are connected instead of terminals 5 and 6. Wiper motor will then stop wiper arms at the STOP position.

Intermittent Operation

The wiper motor operates the wiper arms one time at low speed at a set interval of approximately 2 to 13 seconds. This feature is controlled by the wiper amplifier (INT SW) combined with wiper switch.

When the wiper switch is placed in the INT position, ground is supplied to wiper amplifier.

The desired interval time is input to wiper amplifier (INT VR) from wiper volume switch combined with wiper switch.

Then intermittent ground is supplied

- to wiper motor terminal 2
- from terminal 14 of wiper switch
- through wiper amplifier (OUTPUT).

The wiper motor operates at low speed at the desired interval.

WASHER OPERATION

With the ignition switch in the ON or START position, power is supplied

- through 20A fuse [No. 6, located in the fuse block (J/B)]
- to washer motor terminal 1.

When the lever is pulled to the WASH position, ground is supplied

- to washer motor terminal 2
- from terminal 18 of the wiper switch
- through terminal 17 of the wiper switch, and

NMEL0057

NMEL0057S01

GI

MA

EM

LC

NMEL0057S0101

EC

FE

CL

MT

NMEL0057S0102

AT

PD

AX

SU

BR

NMEL0057S0103

ST

RS

BT

HA

NMEL0057S02

SC

EL

IDX

FRONT WIPER AND WASHER

System Description (Cont'd)

- through body grounds E43 and E57.

With power and ground supplied, the washer motor operates.

When the lever is pulled to the WASH position for one second or more, the wiper motor operates at low speed for approximately 3 seconds to clean windshield. This feature is controlled by the wiper amplifier in the same manner as the intermittent operation.

FRONT WIPER AND WASHER

Wiring Diagram — WIPER —

Wiring Diagram — WIPER —

NMEL0058

EL-WIPER-01

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

AX

SU

BR

ST

RS



BT

HA

SC

EL


IDX



REFER TO THE FOLLOWING.
(E101), (F4) -SUPER
MULTIPLE JUNCTION (SMJ)
(M7), (E105) -FUSE BLOCK-
JUNCTION BOX (J/B)

FRONT WIPER AND WASHER

Removal and Installation



Removal and Installation

WIPER ARMS

NMEL0060

NMEL0060S01


1. Prior to wiper arm installation, turn on wiper switch to operate wiper motor and then turn it "OFF" (Auto Stop).
2. Lift the blade up and then set it down onto glass surface to set the blade center to clearance "L₁" & "L₂" immediately before tightening nut.
3. Eject washer fluid. Turn on wiper switch to operate wiper motor and then turn it "OFF".
4. Ensure that wiper blades stop within clearance "L₁" & "L₂".

Clearance "L₁": 17.5 - 32.5 mm (1.161 - 1.752 in)

Clearance "L₂": 29.5 - 44.5 mm (0.689 - 1.280 in)

- Tighten wiper arm nuts to specified torque.


Front wiper: 21 - 26 N·m (2.1 - 2.7 kg·m, 16 - 19 ft·lb)



- Before reinstalling wiper arm, clean up the pivot area as illustrated. This will reduce possibility of wiper arm looseness.

WIPER LINKAGE

NMEL0060S02




Removal

- 1. Remove cowl top seal rubber and cowl top cover.
- 2. Remove wiper motor connector.
- 3. Remove nuts that secure wiper pivot.
- 4. Remove 4 screws that secure wiper motor.
- 5. Detach wiper motor from wiper linkage at ball joint.
- 6. Remove wiper linkage.

Be careful not to break ball joint rubber boot.

Installation


- Grease ball joint portion before installation.
- 1. Installation is the reverse order of removal.



Washer Nozzle Adjustment

- Adjust washer nozzle with suitable tool as shown in the figure at left.

Adjustable range: ±10°



Unit: mm (in)			
*1	358 (14.09)	*5	70 (2.76)
*2	245 (9.65)	*6	245 (9.65)
*3	300 (11.81)	*7	378 (14.88)
*4	203 (7.99)	*8	503 (19.80)


*: The diameters of these circles are less than 80 mm (3.15 in).

FRONT WIPER AND WASHER

Washer Tube Layout

Washer Tube Layout

NMEL0062



CEL317A

Wiring Diagram — HORN —

NMEL0071

EL-HORN-01

GI

MA

EM

LG

EC

FE

CL

MT

AT

PD

AX

SU

BR

ST

RS





BT

HA

SC

EL

IDX



REFER TO THE FOLLOWING.
E101 -SUPER MULTIPLE
JUNCTION (SMJ)

★: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT".



CIGARETTE LIGHTER

Wiring Diagram — CIGAR —

Wiring Diagram — CIGAR —

NMEL0156

EL-CIGAR-01




REFER TO THE FOLLOWING.
M6 -FUSE BLOCK-JUNCTION
BOX (J/B)

Wiring Diagram — CLOCK —

NMEL0166

EL-CLOCK-01



1	2	3	4	5	6	7	8	9	M18	21	22	23	24	25	26	27	28	29	M19		
10	11	12	13	14	15	16	17	18		19	20	30	31	32	33	34	35	36		37	38
W										BR											

	O	4	E106
3	1	5	W

REFER TO THE FOLLOWING.

E101 -SUPER MULTIPLE JUNCTION (SMJ)
M6 , M7 -FUSE BLOCK-JUNCTION BOX (J/B)

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

REAR WINDOW DEFOGGER

Component Parts and Harness Connector Location

Component Parts and Harness Connector Location

NMEL0072



SEL252Y

System Description

NMEL0073

The rear window defogger system is controlled by the unified meter control unit (time control system). The rear window defogger operates only for approximately 15 minutes.

Power is supplied at all times

- to rear window defogger relay terminal 3
- through 15A fuse [No. 25, located in the fuse block (J/B)] and
- to rear window defogger relay terminal 6
- through 15A fuse [No. 21, located in the fuse block (J/B)].

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 5, located in the fuse block (J/B)]
- to the rear window defogger relay terminal 1 and
- through 10A fuse [No. 11, located in the fuse block (J/B)]
- to combination meter terminal 12.

Ground is supplied to terminal 2 of the rear window defogger switch through body grounds M1 and M67.

When the rear window defogger switch is turned ON, ground is supplied

- through terminal 1 of the rear window defogger switch
- to combination meter terminal 20.

Terminal 37 of the combination meter then supplies ground to the rear window defogger relay terminal 2.

With power and ground supplied, the rear window defogger relay is energized.

Power is supplied

- through terminals 5 and 7 of the rear window defogger relay
- to the rear window defogger terminal 1.

Terminal 2 of the rear window defogger is grounded through body ground B103.

With power and ground supplied, the rear window defogger filaments heat and defog the rear window.

When the system is activated, the rear window defogger indicator illuminates in the rear window defogger switch.

Power is supplied

- to terminal 3 of the rear window defogger switch
- from terminals 5 and 7 of the rear window defogger relay.

Terminal 4 of the rear window defogger switch is grounded through body grounds M1 and M67.

REAR WINDOW DEFOGGER





Wiring Diagram — DEF —

Wiring Diagram — DEF —

=NMEL0074

EL-DEF-01

REFER TO EL-POWER.



*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT".

REFER TO THE FOLLOWING.
(M7), (B4), (B5) - FUSE
BLOCK-JUNCTION BOX (J/B)

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

TEL813B


REAR WINDOW DEFOGGER


Trouble Diagnoses

Trouble Diagnoses DIAGNOSTIC PROCEDURE SYMPTOM: Rear window defogger does not activate, or does not go off after activating.

NMEL0075


NMEL0075S01


1 CHECK REAR WINDOW DEFOGGER OUTPUT SIGNAL		
1. Turn ignition switch to ON position. 2. Check voltage between combination meter harness connector M19 terminal 37 (L/W) and ground.  Combination meter connector  Voltage [V]: Rear window defogger switch is "OFF". Approx. 12 Rear window defogger switch is "ON". 0 SEL234Y OK or NG		
OK	▶	Check the following. • Rear window defogger relay (Refer to EL-100.) • Rear window defogger circuit • Rear window defogger filament (Refer to EL-101.)
NG	▶	GO TO 2.

2 CHECK DEFOGGER RELAY COIL SIDE CIRCUIT		
1. Disconnect combination meter harness connector. 2. Turn ignition switch to ON position. 3. Check voltage between combination meter harness connector M19 terminal 37 (L/W) and ground.  Combination meter connector  Battery voltage should exist. SEL235Y OK or NG		
OK	▶	GO TO 3.
NG	▶	Check the following. • 10A fuse [No. 5, located in the fuse block (J/B)] • Rear window defogger relay • Harness for open or short between fuse and rear window defogger relay • Harness for open or short between rear window defogger relay and combination meter

REAR WINDOW DEFOGGER

Trouble Diagnoses (Cont'd)


3	CHECK REAR WINDOW DEFOGGER SWITCH INPUT SIGNAL	
Check continuity between combination meter harness connector M18 terminal 20 (LG/R) and ground.		
 Combination meter connector  Continuity: Rear window defogger switch is pushed. Continuity should exist. Rear window defogger switch is released. Continuity should not exist. SEL236Y		
OK or NG		
OK	▶	GO TO 4.
NG	▶	Check the following. • Rear window defogger switch (Refer to EL-100.) • Harness for open or short between combination meter and rear window defogger switch • Rear window defogger switch ground circuit


4	CHECK IGNITION INPUT SIGNAL																
Check voltage between combination meter harness connector M18 terminal 12 (G/Y) and ground.																	
 Combination meter connector  <table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <thead> <tr> <th colspan="2" data-bbox="787 1081 1031 1113">Terminal No.</th> <th colspan="3" data-bbox="1031 1081 1388 1113">Ignition switch position</th> </tr> <tr> <th data-bbox="787 1113 909 1144">(+) (12)</th> <th data-bbox="909 1113 1031 1144">(-) (Ground)</th> <th data-bbox="1031 1113 1144 1144">OFF</th> <th data-bbox="1144 1113 1266 1144">ACC</th> <th data-bbox="1266 1113 1388 1144">ON</th> </tr> </thead> <tbody> <tr> <td data-bbox="787 1144 909 1197">12</td> <td data-bbox="909 1144 1031 1197">Ground</td> <td data-bbox="1031 1144 1144 1197">0V</td> <td data-bbox="1144 1144 1266 1197">0V</td> <td data-bbox="1266 1144 1388 1197">Battery voltage</td> </tr> </tbody> </table> SEL216Y			Terminal No.		Ignition switch position			(+) (12)	(-) (Ground)	OFF	ACC	ON	12	Ground	0V	0V	Battery voltage
Terminal No.		Ignition switch position															
(+) (12)	(-) (Ground)	OFF	ACC	ON													
12	Ground	0V	0V	Battery voltage													
OK or NG																	
OK	▶	GO TO 5.															
NG	▶	Check the following. • 10A fuse [No. 11, located in the fuse block (J/B)] • Harness for open or short between combination meter and fuse															

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

REAR WINDOW DEFOGGER

Trouble Diagnoses (Cont'd)

5		CHECK COMBINATION METER GROUND CIRCUIT	
Check continuity between combination meter harness connector M18 terminal 9 (B) and ground.			
  Continuity should exist.			
SEL237Y			
OK or NG			
OK	▶	Replace unified meter control unit.	
NG	▶	Repair harness or connector.	



Electrical Components Inspection


NMEL0076

REAR WINDOW DEFOGGER RELAY

NMEL0076S01

Check continuity between terminals 3 and 5, 6 and 7.

Condition	Continuity
12V direct current supply between terminals 1 and 2	Yes
No current supply	No



REAR WINDOW DEFOGGER SWITCH





NMEL0076S02

Check continuity between terminals when rear window defogger switch is pushed and released.

Terminals	Condition	Continuity
1 - 2	Rear window defogger switch is pushed.	Yes
	Rear window defogger switch is released.	No

REAR WINDOW DEFOGGER

Filament Check



Filament Check

=NMEL0077

1. Attach probe circuit tester (in volt range) to middle portion of each filament.

- When measuring voltage, wrap tin foil around the top of the negative probe. Then press the foil against the wire with your finger.

2. If a filament is burned out, circuit tester registers 0 or 12 volts.

3. To locate burned out point, move probe to left and right along filament. Test needle will swing abruptly when probe passes the point.

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

REAR WINDOW DEFOGGER

Filament Repair

REPAIR EQUIPMENT

NMEL0078

NMEL0078S01

- 1) Conductive silver composition (Dupont No. 4817 or equivalent)
- 2) Ruler 30 cm (11.8 in) long
- 3) Drawing pen
- 4) Heat gun
- 5) Alcohol
- 6) Cloth

REPAIRING PROCEDURE




NMEL0078S02

1. Wipe broken heat wire and its surrounding area clean with a cloth dampened in alcohol.
2. Apply a small amount of conductive silver composition to tip of drawing pen.

Shake silver composition container before use.

3. Place ruler on glass along broken line. Deposit conductive silver composition on break with drawing pen. Slightly overlap existing heat wire on both sides [preferably 5 mm (0.20 in)] of the break.
4. After repair has been completed, check repaired wire for continuity. This check should be conducted 10 minutes after silver composition is deposited.

Do not touch repaired area while test is being conducted.












5. Apply a constant stream of hot air directly to the repaired area for approximately 20 minutes with a heat gun. A minimum distance of 3 cm (1.2 in) should be kept between repaired area and hot air outlet. If a heat gun is not available, let the repaired area dry for 24 hours.

Wiring Diagram — AUDIO —

NMEL0081

EL-AUDIO-01



REFER TO THE FOLLOWING.

(E101) -SUPER MULTIPLE JUNCTION (SMJ)

(M7) -FUSE BLOCK-JUNCTION BOX (J/B)

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX



TEL814B

AUDIO ANTENNA

Location of Antenna

Location of Antenna

NMEL0087



Window Antenna Repair

NMEL0250


ELEMENT CHECK

NMEL0250S01



1. Attach probe circuit tester (in ohm range) to antenna terminal on each side.
If an element is OK, continuity should exist.
If an element is broken, no continuity should exist. Go to step 2.

AUDIO ANTENNA

Window Antenna Repair (Cont'd)



- When measuring continuity, wrap tin foil around the top of probe. Then press the foil against the wire with your finger.



- To locate broken point, move probe along element. Tester needle will swing abruptly when probe passes the point.

ELEMENT REPAIR

Refer to "Filament Repair", "REAR WINDOW DEFOGGER" (EL-102).

NMEL0250S02

POWER SUNROOF

System Description

System Description

NMEL0222

OUTLINE

Electric sunroof system consists of

NMEL0222S01

- Sunroof switch
- Sunroof motor

OPERATION

The sunroof can be opened or closed and tilted up or down with the sunroof switch.





NMEL0222S03

Wiring Diagram — SROOF —

Wiring Diagram — SROOF —

NMEL0089

EL-SROOF-01



REFER TO THE FOLLOWING.

(E101) -SUPER MULTIPLE JUNCTION (SMJ)

(M6) -FUSE BLOCK-JUNCTION
BOX (J/B)

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

AX

SU

BR

ST

RS

BT

HA

SC



EL

INDEX

POWER SUNROOF

Wiring Diagram — SROOF — (Cont'd)

EL-SROOF-02



*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT".

TEL816B

POWER SUNROOF

Trouble Diagnoses

Trouble Diagnoses

NMEL0225

Symptom	Possible cause	Repair order
Power sunroof cannot be operated using any switch.	10A fuse, 30A fusible link and M13 circuit breaker - Sunroof motor ground circuit - Sunroof switch - Sunroof switch circuit - Sunroof motor	- Check 10A fuse [No. 5, located in fuse block (J/B)], 30A fusible link (letter I, located in fuse and fusible link box) and M13 circuit breaker. Turn ignition switch "ON" and verify battery positive voltage is present at terminals 1 of sunroof motor. - Check sunroof motor ground circuit. - Check sunroof switch. - Check harness between sunroof switch and sunroof motor. - Check sunroof motor.
Power sunroof cannot be operated using one of the sunroof switches.	- Sunroof switch - Sunroof switch circuit	- Check sunroof switch. - Check the harness between sunroof motor and sunroof switch.

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX


DOOR MIRROR

Wiring Diagram — MIRROR —

Wiring Diagram — MIRROR —

NMEL0090

EL-MIRROR-01



TEL817B

System Description

NMEL0191

Power is supplied at all times

- from 30A fusible link (letter I, located in the fuse and fusible link box)
- to circuit breaker terminal 1
- through circuit breaker terminal 2
- to power window relay terminal 3 and
- to power window main switch terminal 10.

With ignition switch in ON or START position, power is supplied

- through 10A fuse [No. 5, located in the fuse block (J/B)]
- to power window relay terminal 1 and

Ground is supplied to power window relay terminal 2

- through body grounds M1 and M67.

The power window relay is energized and power is supplied

- through power window relay terminal 5
- to power window main switch terminal 13,
- to power window switch (passenger side) terminal 5.

MANUAL OPERATION

Driver Side Door

Ground is supplied

- to power window main switch terminal 5
- through body grounds M1 and M67.

WINDOW UP

When the driver's window switch in the power window main switch is pressed in the up position, power is supplied

- to driver side power window regulator terminal 1
- through power window main switch terminal 6.

Ground is supplied

- to driver side power window regulator terminal 3
- through power window main switch terminal 7.

Then, the motor raises the window until the switch is released.

WINDOW DOWN

When the driver's window switch in the power window main switch is pressed in the down position, power is supplied

- to driver side power window regulator terminal 3
- through power window main switch terminal 7.

Ground is supplied

- to driver side power window regulator terminal 1
- through power window main switch terminal 6.

Then, the motor lowers the window until the switch is released.

Passenger Side Door

Ground is supplied

- to power window main switch terminal 5
- through body grounds M1 and M67.

NOTE:

Numbers in parentheses are terminal numbers, when power window switch is pressed in the UP and DOWN positions respectively.

POWER WINDOW MAIN SWITCH OPERATION

Power is supplied

- through power window main switch terminals (12, 14)
- to power window sub-switch (passenger side) terminals (3, 4).

GI

MA

EM

LC

EC

FE

CL

NMEL0191S01

NMEL0191S0101

MT

AT

PD

AX

SU

BR

ST

RS

BT

NMEL0191S0102

HA

SC

EL

IDX

POWER WINDOW

System Description (Cont'd)

The subsequent operation is the same as the power window switch operation.

POWER WINDOW SUB-SWITCH OPERATION

Power is supplied

- through power window sub-switch terminals 1 and 2
- to power window regulator terminals 1 and 2.

Ground is supplied

- to power window regulator terminals 1 and 2
- through power window sub-switch terminals 1 and 2
- to power window sub-switch terminals 3 and 4
- through power window main switch terminals 12 and 14.

Then, the motor raises or lowers the window until the switch is released.

AUTO OPERATION

The power window AUTO feature enables the driver to open or close the driver's window without holding the window switch in the down or up position.

The AUTO feature operates on the driver's window.

NMEL0191S02

POWER WINDOW LOCK

The power window lock is designed to lock operation of passenger's door window.

When the lock switch is pressed to lock position, ground of the sub-switches in the power window main switch is disconnected. This prevents the power window motors from operating.

NMEL0191S03

INTERRUPTION DETECTION FUNCTION

Power window main switch monitors the power window regulator motor operation and the power window position (full closed or other) for driver's power window by the signals from encoder and limit switch in power window regulator.

When power window main switch detects interruption during the following close operation in the driver's side door,


- automatic close operation when ignition switch is in the "ON" position
- automatic close operation during retained power operation

Power window main switch controls driver's power window regulator motor for open and the power window will be lowered about 150 mm (5.91 in).

NMEL0191S05

Schematic

NMEL0103



GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

AX

SU

BR

ST

RS

BT

HA

SC



EL

INDEX

Wiring Diagram — WINDOW — (Cont'd)

Wiring Diagram — WINDOW — (Cont'd)


EL-WINDOW-02



POWER WINDOW

Wiring Diagram — WINDOW — (Cont'd)

EL-WINDOW-03



1	2	3	4
5	6	7	8

(D2)
W

7	6	5	4	3	2	1
16	15	14	13	12	11	10

(D7)
W

1	2
3	4

(D32)
W

1	2
---	---

(D34)
B

4	1	3	2	5
---	---	---	---	---

(D36)
W

TEL821B

Trouble Diagnoses

NMEL0105

Symptom	Possible cause	Repair order	
None of the power windows can be operated using any switch.	1. 10A fuse 2. 30A fusible link, M13 circuit breaker 3. Power window relay 4. Open/short in power window main switch circuit 5. Ground circuit 6. Power window main switch	1. Check 10A fuse [No. 5, located in fuse block (J/B)] Turn ignition switch "ON" and verify battery positive voltage is present at terminal 1 of power window relay. 2. Check 30A fusible link (letter I, located in fuse and fusible link box) and M13 circuit breaker. Verify battery positive voltage is present at terminal 3 of power window relay. 3. Check power window relay. 4. Check W/B wire between power window relay and power window main switch for open/short circuit. 5. Check the following: a. Check ground circuit of power window main switch. b. Check power window relay ground circuit. 6. Check power window main switch.	GI MA EM LC EC FE
Driver side power window cannot be operated but other windows can be operated.	1. Driver side power window regulator circuit 2. Driver side power window regulator 3. Open/short in power window main switch circuit 4. Power window main switch	1. Check harness between power window main switch and driver side power window regulator for open or short circuit. 2. Check driver side power window regulator. 3. Check W/B wire between power window relay and power window main switch for open/short circuit. 4. Check power window main switch.	CL MT
One or more power windows except driver's side window cannot be operated.	1. Power window sub-switches 2. Power window regulators 3. Power window main switch 4. Power window circuit	1. Check power window sub-switch. 2. Check power window regulator. 3. Check power window main switch. 4. Check the following. a. Check harness between the power window relay terminal 5 and power window sub-switch terminal 5. b. Check harnesses between power window main switch and power window sub-switch for open/short circuit. c. Check harnesses between power window sub-switch and power window regulator for open/short circuit.	AT PD AX SU
Power windows except driver's side window cannot be operated using power window main switch but can be operated by power window sub-switch.	1. Power window main switch	1. Check power window main switch.	BR
Driver side power window automatic operation does not function properly.	1. Power window main switch	1. Check power window main switch.	ST RS

EL

IDX



POWER WINDOW

Trouble Diagnoses (Cont'd)

ENCODER AND LIMIT SWITCH CHECK

=NMEL0105S01

1	CHECK DOOR WINDOW SLIDE MECHANISM
Check the following. ● Obstacles in window, glass molding, etc. ● Worn or deformed glass molding ● Door sash tilted too far inward or outward ● Door window regulator OK or NG	
OK	▶ GO TO 2.
NG	▶ Remove obstacles or repair door window slide mechanism.

2	CHECK POWER SUPPLY TO LIMIT SWITCH
Check voltage between power window main switch harness connector D7 terminal 15 (OR) and ground.  CONNECT   Power window main switch connector   Voltage: 5V NOTE: Check voltage when power window regulator harness connector is disconnected. SEL238Y OK or NG	
OK	▶ GO TO 3.
NG	▶ Replace power window main switch.

3


CHECK LIMIT SWITCH OPERATION

Check voltage between power window main switch harness connector D7 terminal 15 (OR) and ground during power window closing operation.


CONNECT



Power window main switch connector



Terminal No.	Condition	Voltage (DCV)
Power window main switch: 15	Approx. 15 mm (0.59 in) below the full closed position to full closed position	Approx. 5
	Other positions	Approx. 0

SEL239Y

OK or NG

OK

▶

GO TO 5.


NG

▶

GO TO 4.

4 RESET LIMIT SWITCH

Reset limit switch. Refer to BT-19, "Door Limit Switch Reset". Then check voltage between power window main switch harness connector D7 terminal 15 (OR) and ground during power window closing operation at least ten times.



Terminal No.	Condition	Voltage (DCV)
Power window main switch: 15	Approx. 15 mm (0.59 in) below the full closed position to full closed position	Approx. 5
	Other positions	Approx. 0

SEL239Y



OK or NG

OK ► GO TO 5.

NG ► Replace power window regulator motor (driver side).

5 CHECK ENCODER

Measure voltage between power window main switch harness connector D7 terminal 8 (R) and ground with oscilloscope when power window is in automatic closing operation.



HI: Approx. 5V
LO: Approx. 0V

SEL240Y

OK or NG

OK ► Replace power window main switch.


NG ► Replace power window regulator motor (driver side).

POWER DOOR LOCK

Component Parts and Harness Connector Location

Component Parts and Harness Connector Location

NMEL0106



SEL253Y

System Description

NMEL0107

NMEL0107S04

OPERATION

- The lock/unlock switch on the driver's door trim can lock and unlock the passenger's door.
- The lock knob on the driver's door can lock and unlock all doors. (Signals from door unlock sensor)
- With the key inserted in the driver's door key cylinder, the doors can be locked by turning the key to the "LOCK" position, and unlocked by turning to the "UNLOCK" position. (Signals from door unlock sensor)

POWER DOOR LOCK

Wiring Diagram — D/LOCK —

Wiring Diagram — D/LOCK —

NMEL0109

EL-D/LOCK-01

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

AX

SU

BR

ST

RS







BT

HA

SC

EL

IDX



REFER TO THE FOLLOWING.
(M6) - FUSE BLOCK-JUNCTION BOX (J/B)

Wiring Diagram — D/LOCK — (Cont'd)

EL-D/LOCK

BATTERY

30A

7A

CIRCUIT BREAKER

DOOR LOCK RELAY

DOOR LOCK ACTUATOR (PASSENGER SIDE)

COMBINATION METER

UNIFIED METER CONTROL UNIT (WITH ODO/TRIP METER)

REFER TO EL-POWER.

W/B

E101

M10

M13

W/R

B

R/G

L

W/L

R/B

W/L

L

W/L

L

W/L

B

B

B

M1

M6

D32

M57

D37

M19

35

36

1

2

3

4

5

6

1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

19

20

21

22

23

24

25

26

27

28

29

30

31

32

33

34

35

36

37

38

39

40

41

42

43

44

45

46

47

48

49

50

51

52

53

54

55

56

57

58

59

60

61

62

63

64

65

66

67

68

69

70

71

72

73

74

75

76

77

78

79

80

81

82

83

84

85

86

87

88

89

90

91

92

93

94

95


96

97

98

99

100




**(E101) -SUPER MULTIPLE
JUNCTION (SMJ)**

Trouble Diagnoses SYMPTOM CHART

NMEL0193

NMEL0193S01

REFERENCE PAGE (EL-)	123	125	127	129
SYMPTOM	POWER SUPPLY AND GROUND CIRCUIT CHECK	DOOR LOCK/UNLOCK SWITCH CHECK	DOOR UNLOCK SENSOR CHECK	DOOR LOCK ACTUATOR CHECK
Power door lock does not operate with driver's door lock knob/key cylinder and door lock/unlock switch on door trim.	X			X
Power door lock does not operate with door lock/unlock switch on door trim.		X		
Power door lock does not operate with driver's door lock knob/key cylinder.			X	



POWER SUPPLY AND GROUND CIRCUIT CHECK

NMEL0193S12

Power Supply Circuit Check

NMEL0193S1201

Terminal No.		Ignition switch position			
(+)		(-)	OFF	ACC	ON
Connector	Terminal (Wire color)				
M18	13 (R/W)	Ground	Battery voltage	Battery voltage	Battery voltage
M2	3 (W/R)	Ground	Battery voltage	Battery voltage	Battery voltage


If NG, check the following.

- 10A fuse [No. 28, located in fuse block (J/B)]
- 30A fusible link [letter I, located in fuse and fusible link box]
- Circuit breaker
- Harness for open or short between fuse and combination meter
- Harness for open or short between fusible link and circuit breaker

POWER DOOR LOCK

Trouble Diagnoses (Cont'd)

- Harness for open or short between circuit breaker and door lock relay



Ground Circuit Check

NMEL0193S1202

Terminal No.			Continuity
(+) Terminal (Wire color)		(-) Ground	
Connector			
M18	9 (B)	Ground	Yes
M2	2 (B)	Ground	Yes

DOOR LOCK/UNLOCK SWITCH CHECK


=NMEL0193S05

1 CHECK DOOR LOCK/UNLOCK SWITCH CIRCUIT

1. Disconnect combination meter harness connector.
2. Check continuity between combination meter harness connector M18 terminal 7 (LG/B) or 8 (BR/R) and ground.



Combination meter connector



Terminal No.	Condition (Door lock/unlock switch)	Continuity
7-Ground	Lock	Yes
	Neutral/Unlock	No
8-Ground	Unlock	Yes
	Neutral/Lock	No

SEL243Y

OK or NG


OK	▶	Door lock/unlock switch is OK; go to unified meter control unit (time control system) check. Refer to EL-133.
NG	▶	GO TO 2.

2 CHECK DOOR LOCK/UNLOCK SWITCH

1. Disconnect door lock/unlock switch harness connector.
2. Check continuity between door lock/unlock switch terminals.
 - Power window main switch (Door lock/unlock switch)



Power window main switch connector



Condition	Terminal No.		
	2	3	5
Lock		○	○
N	No continuity		
Unlock	○		○

SEL244Y

OK or NG

OK	▶	GO TO 3.
NG	▶	Replace door lock/unlock switch.

POWER DOOR LOCK

Trouble Diagnoses (Cont'd)

3

CHECK DOOR LOCK/UNLOCK SWITCH INPUT SIGNAL

</

DOOR UNLOCK SENSOR CHECK


=NMEL0193S11

1 CHECK DOOR UNLOCK SENSOR CIRCUIT

1. Disconnect combination meter harness connector.
2. Check continuity between combination meter harness connector M19 terminal 22 (W/G) and ground.



Combination meter connector



Terminal No.	Condition (Driver's door)	Continuity
22-Ground	Locked	No
	Unlocked	Yes

SEL219Y

OK or NG


OK	▶	Door unlock sensor is OK; go to unified meter control unit (time control system) check. Refer to EL-133.
NG	▶	GO TO 2.

2 CHECK DOOR UNLOCK SENSOR

1. Disconnect door unlock sensor harness connector.
2. Check continuity between door unlock sensor harness connector D8 terminals 1 and 2.



Door unlock sensor connector



Terminal No.	Condition (Driver's Door)	Continuity
1-2	Locked	No
	Unlocked	Yes


SEL220Y

OK or NG

OK	▶	GO TO 3.
NG	▶	Replace door unlock sensor.


POWER DOOR LOCK


Trouble Diagnoses (Cont'd)

3	CHECK DOOR UNLOCK SENSOR INPUT SIGNAL														
1. Connect door unlock sensor harness connector and combination meter harness connector. 2. Check voltage combination meter harness connector M19 terminal 22 (W/G) and ground.															
 CONNECT   Combination meter connector  <table><tr><th colspan="2">Terminal No.</th><th rowspan="2">Condition (Driver's Door)</th><th rowspan="2">Voltage [V]</th></tr><tr><th>(+)</th><th>(-)</th></tr><tr><td rowspan="2">22</td><td rowspan="2">Ground</td><td>Locked</td><td>Approx. 5</td></tr><tr><td>Unlocked</td><td>0</td></tr></table>				Terminal No.		Condition (Driver's Door)	Voltage [V]	(+)	(-)	22	Ground	Locked	Approx. 5	Unlocked	0
Terminal No.		Condition (Driver's Door)	Voltage [V]												
(+)	(-)														
22	Ground	Locked	Approx. 5												
		Unlocked	0												
SEL221Y															
OK or NG															
OK	▶	Check the following. • Door unlock sensor ground circuit • Harness for open or short between combination meter and door unlock sensor													
NG	▶	Replace unified meter control unit (time control system).													

DOOR LOCK ACTUATOR CHECK

=NMEL0193S08


1	CHECK DOOR LOCK ACTUATOR CIRCUIT														
1. Disconnect combination meter harness connector. 2. Check voltage between combination meter harness connector M19 terminal 35 (R/G) or 36 (R/B) and ground.															
 Combination meter connector  <table border="1"> <thead> <tr> <th colspan="2">Terminal No.</th> <th rowspan="2">Condition (Door lock/unlock switch)</th> <th rowspan="2">Voltage [V]</th> </tr> <tr> <th>(+)</th> <th>(-)</th> </tr> </thead> <tbody> <tr> <td>35</td> <td>Ground</td> <td>Lock</td> <td rowspan="2">Approx. 12</td> </tr> <tr> <td>36</td> <td>Ground</td> <td>Unlock</td> </tr> </tbody> </table> SEL246Y			Terminal No.		Condition (Door lock/unlock switch)	Voltage [V]	(+)	(-)	35	Ground	Lock	Approx. 12	36	Ground	Unlock
Terminal No.		Condition (Door lock/unlock switch)	Voltage [V]												
(+)	(-)														
35	Ground	Lock	Approx. 12												
36	Ground	Unlock													
OK or NG															
OK	▶	GO TO 2.													
NG	▶	Check the following. • Door lock relay • Harness for open or short between combination meter and door lock relay													

2	CHECK DOOR LOCK INPUT SIGNAL														
1. Connect combination meter harness connector. 2. Check voltage between combination meter harness connector M19 terminal 35 (R/G) or 36 (R/B) and ground.															
 Combination meter connector  <table border="1"> <thead> <tr> <th colspan="2">Terminal No.</th> <th rowspan="2">Condition (Door lock/unlock switch)</th> <th rowspan="2">Voltage [V]</th> </tr> <tr> <th>(+)</th> <th>(-)</th> </tr> </thead> <tbody> <tr> <td>35</td> <td>Ground</td> <td>Lock</td> <td rowspan="2">Approx. 12 → 0 → 12</td> </tr> <tr> <td>36</td> <td>Ground</td> <td>Unlock</td> </tr> </tbody> </table> SEL247Y			Terminal No.		Condition (Door lock/unlock switch)	Voltage [V]	(+)	(-)	35	Ground	Lock	Approx. 12 → 0 → 12	36	Ground	Unlock
Terminal No.		Condition (Door lock/unlock switch)	Voltage [V]												
(+)	(-)														
35	Ground	Lock	Approx. 12 → 0 → 12												
36	Ground	Unlock													
OK or NG															
OK	▶	GO TO 3.													
NG	▶	Replace unified meter control unit (time control system).													

3	CHECK DOOR LOCK RELAY	
Check door lock relay.		
OK or NG		
OK	▶	GO TO 4.
NG	▶	Replace door lock relay.

POWER DOOR LOCK

Trouble Diagnoses (Cont'd)

4	CHECK DOOR LOCK ACTUATOR	
	1. Disconnect door lock actuator harness connector. 2. Apply 12V direct current to door lock actuator harness connector D37 and check operation.  Door lock actuator operation: Terminals between (+): 1 and (-): 3 Unlocked → Locked Terminals between (+): 3 and (-): 1 Locked → Unlocked SEL222WD	
	OK or NG	
OK	▶	Check harness for open or short between door lock relay and door lock actuator.
NG	▶	Replace door lock actuator.

UNIFIED METER CONTROL UNIT (TIME CONTROL SYSTEM)

Description

Description

NMEL0308

OUTLINE

Unified meter control unit (time control system) totally controls the following body electrical system operations.

- Warning buzzer
- Rear window defogger
- Power door lock
- Interior room lamp

INPUT/OUTPUT

NMEL0308S02

System	Input	Output
Power door lock	Door lock/unlock switch Door unlock sensor	Door lock actuator
Warning buzzer	Key switch (Insert) Ignition switch (ON) Lighting switch (1st or 2nd) Door switch driver side	Warning buzzer (located in combination meter)
Rear window defogger	Ignition switch (ON) Rear window defogger switch	Rear window defogger relay
Interior room lamp	Door switches Door unlock sensor Ignition switch (ON) Key switch (Insert)	Interior room lamp

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

UNIFIED METER CONTROL UNIT (TIME CONTROL SYSTEM)

Schematic

Schematic

NMEL0309



TEL824B

UNIFIED METER CONTROL UNIT (TIME CONTROL SYSTEM)

Time Control System Inspection Table

Time Control System Inspection Table

NMEL0310

Terminal No.	Wire color	Connections	Operated condition	Voltage (Approximate values)
5	P	Door switch (Driver/Passenger)	OFF (Closed) → ON (Open)	5V → 0V
7	LG/B	Door lock/unlock switch	Neutral → Locked	5V → 0V
8	BR/R	Door lock/unlock switch	Neutral → Unlocked	5V → 0V
9	B	Ground	—	—
12	G/Y	Ignition switch	ON or START → OFF or ACC	12V → 0V
13	R/W	Battery	Battery voltage	12V
20	LG/R	Rear window defogger switch	OFF → ON (Ignition key is in "OFF" position)	5V → 0V
22	W/G	Driver door unlock sensor	Driver door: OFF (Locked) → ON (Unlocked)	5V → 0V
24	BR/W	Driver door switch	Driver door: OFF (Closed) → ON (Open)	5V → 0V
32	R/L	Combination switch (Lighting switch)	1ST, 2ND Position: ON → OFF	12V → 0V
33	B/P	Key switch	Key inserted → Key withdrawn from IGN key cylinder	12V → 0V
35	R/G	Door lock relay	Door lock/unlock switch: Neutral → Locked	12V → 0V → 12V
36	R/B	Door lock relay	Door lock/unlock switch: Neutral → Unlocked	12V → 0V → 12V
37	L/W	Rear window defogger relay	Rear window defogger switch: OFF → ON (Ignition key is in "ON" position)	12V → 0V*1
38	R/W	Interior room lamp	Driver/Passenger door: OFF (Closed) → ON (Open) (Lamp switch in "Door" position)	12V → 0V
			Ignition key is in "ON" position (Lamp switch in "Door" position)	12V
			Key withdrawn from IGN key cylinder (Lamp switch in "Door" position)	0V*2

*1: Rear defogger ON (For approximately 15 minutes)


*2: Will increase to 12 volts approximately 20 seconds after the key is withdrawn from IGN key cylinder.

NATS (NISSAN ANTI-THEFT SYSTEM)

Component Parts and Harness Connector Location

Component Parts and Harness Connector Location

NMEL0325



SEL251Y

NOTE:

If customer reports a "No Start" condition, request ALL KEYS to be brought to the Dealer in case of an NATS malfunction.

System Description

=NMEL0326

NATS (Nissan Anti-Theft System) has the following immobilizer functions:


- Since only NATS ignition keys, whose ID nos. have been registered into the ECM and IMMU of NATS, allow the engine to run, operation of a stolen vehicle without a NATS registered key is prevented by NATS. That is to say, NATS will immobilize the engine if someone tries to start it without the registered key of NATS.
- All of the originally supplied ignition key IDs (except for card plate key) have been NATS registered. If requested by the vehicle owner, a maximum of five key IDs can be registered into the NATS components.
- The security indicator blinks when the ignition switch is in "OFF" or "ACC" position. Therefore, NATS warns outsiders that the vehicle is equipped with the anti-theft system.
- When NATS detects trouble, the security indicator lamp lights up while ignition key is in the "ON" position.
- NATS trouble diagnoses, system initialization and additional registration of other NATS ignition key IDs must be carried out using CONSULT-II hardware and CONSULT-II NATS software. When NATS initialization has been completed, the ID of the inserted ignition key is automatically NATS registered. Then, if necessary, additional registration of other NATS ignition key IDs can be carried out. Regarding the procedures of NATS initialization and NATS ignition key ID registration, refer to CONSULT-II operation manual, IVIS/NVIS.
- **When servicing a malfunction of the NATS (indicated by lighting up of Security Indicator Lamp) or registering another NATS ignition key ID no., it may be necessary to re-register original key identification. Therefore, be sure to receive all keys from vehicle owner.**

System Composition

NMEL0327

The immobilizer function of the NATS consists of the following:

- NATS ignition key
- NATS immobilizer control unit (NATS IMMU) located in the ignition key cylinder
- Engine control module (ECM)
- Security indicator







NATS (NISSAN ANTI-THEFT SYSTEM)

Wiring Diagram — NATS —

Wiring Diagram — NATS —


NMEL0328

EL-NATS-01



REFER TO THE FOLLOWING.
 (E101), (F4) -SUPER
 MULTIPLE JUNCTION (SMJ)
 (M6), (M7) -FUSE BLOCK-
 JUNCTION BOX (J/B)

TEL825B



CONSULT-II

CONSULT-II INSPECTION PROCEDURE

1. Turn ignition switch OFF.
2. Insert NATS program card into CONSULT-II.



Program card NATS (AEN00A)

3. Connect CONSULT-II to data link connector.

4. Turn ignition switch ON.
5. Touch "START".

6. Perform each diagnostic test mode according to each service procedure.

For further information, see the CONSULT-II Operation Manual, NATS.



CONSULT-II DIAGNOSTIC TEST MODE FUNCTION


CONSULT-II DIAGNOSTIC TEST MODE	Description
C/U INITIALIZATION	When replacing any of the following three components, C/U initialization and re-registration of all NATS ignition keys are necessary. (NATS ignition key/IMMU/ECM)
SELF-FUNCTION CHECK	ECM checks its own NATS communication interface by itself.
SELF-DIAG RESULTS	Detected items (screen terms) are as shown in the chart EL-138.

NATS (NISSAN ANTI-THEFT SYSTEM)

CONSULT-II (Cont'd)

HOW TO READ SELF-DIAGNOSTIC RESULTS

NMEL0329S03



SELF-DIAGNOSTIC RESULTS ITEM CHART

NMEL0329S04

Detected items (Screen terms)	Description	Reference page
IMMU	ECM received the signal from IMMU that IMMU is malfunctioning.	EL-141
ECM	ECM is malfunctioning.	EL-141
CHAIN OF ECM-IMMU	Communication impossible between ECM and IMMU.	EL-142
DIFFERENCE OF KEY	IMMU can receive the key ID signal but the result of ID verification between key ID and IMMU is NG.	EL-146
CHAIN OF IMMU-KEY	IMMU cannot receive the key ID signal.	EL-147
ID DISCORD, IMM-ECM	The result of ID verification between IMMU and ECM is NG. System initialization is required.	EL-148
ELECTRONIC NOISE	Noise (interference) interfered into NATS communication lines during communicating.	EL-149
DON'T ERASE BEFORE CHECKING ENG DIAG	Engine trouble data and NATS trouble data have been detected in ECM.	EL-139
LOCK MODE	When the starting operation is carried out 5 or more times consecutively under the following conditions, NATS will shift the mode to one which prevents the engine from being started. - Unregistered ignition key is used - IMMU or ECM malfunctioning	EL-152

Trouble Diagnoses WORK FLOW

NMEL0330

NMEL0330S01

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

AX

SU

BR

ST

RS


BT

HA

SC

EL

IDX



NATS (NISSAN ANTI-THEFT SYSTEM)

Trouble Diagnoses (Cont'd)

SYMPTOM MATRIX CHART 1 (Self-diagnosis related item)

NMEL0330S02

SYMPTOM	Displayed "SELF-DIAG RESULTS" on CONSULT screen.	DIAGNOSTIC PROCEDURE (Reference page)	SYSTEM (Malfunctioning part or mode)	REFERENCE PART NO. OF ILLUSTRATION ON NEXT PAGE
- Security indicator lighting up* - Engine will start.	IMMU	PROCEDURE 1 (EL-141)	IMMU	A
	ECM	PROCEDURE 2 (EL-141)	ECM	B
- Security indicator lighting up* - Engine hard to start	CHAIN OF ECM-IMMU	PROCEDURE 3 (EL-142)	Open circuit in battery voltage line of IMMU circuit	C1
			Open circuit in ignition line of IMMU circuit	C2
			Open circuit in ground line of IMMU circuit	C3
			Open circuit in communication line between IMMU and ECM	C4
			Short circuit between IMMU and ECM communication line and battery voltage line	C4
			Short circuit between IMMU and ECM communication line and ground line	C4
			ECM	B
			IMMU	A
	DIFFERENCE OF KEY	PROCEDURE 4 (EL-146)	Unregistered key	D
			IMMU	A
	CHAIN OF IMMU-KEY	PROCEDURE 5 (EL-147)	Malfunction of key ID chip	E
			IMMU	A
	ID DISCORD, IMM-ECM	PROCEDURE 6 (EL-148)	System initialisation has not yet been completed.	F
			ECM	F
	ELECTRONIC NOISE	PROCEDURE 7 (EL-149)	Noise interference in communication line	—
	LOCK MODE	PROCEDURE 9 (EL-152)	LOCK MODE	D
- MIL staying ON - Security indicator lighting up*	DON'T ERASE BEFORE CHECKING ENG DIAG	WORK FLOW (EL-139)	Engine trouble data and NATS trouble data have been detected in ECM	—

*: When NATS detects trouble, the security indicator lights up while ignition key is in the "ON" position.

NATS (NISSAN ANTI-THEFT SYSTEM)

Trouble Diagnoses (Cont'd)


SYMPTOM MATRIX CHART 2 (Non self-diagnosis related item)

NMEL0330S03

SYMPTOM	DIAGNOSTIC PROCEDURE (Reference page)	SYSTEM (Malfunctioning part or mode)
Security ind. does not light up.	PROCEDURE 8 (EL-150)	Security ind.
		Open circuit between Fuse and IMMU
		Continuation of initialization mode
		IMMU

DIAGNOSTIC SYSTEM DIAGRAM

NMEL0330S04



SELF-DIAG RESULTS	
DTC RESULTS	TIME
IMMU	0

SEL951W

DIAGNOSTIC PROCEDURE 1

NMEL0330S05

Self-diagnostic results:
"IMMU" displayed on CONSULT-II screen

1. Confirm SELF-DIAGNOSTIC RESULTS "ECM" displayed on CONSULT-II screen. Ref. part No. B.
2. Replace IMMU.
3. Perform initialization with CONSULT-II.
For initialization, refer to "CONSULT-II operation manual NATS".

SELF-DIAG RESULTS	
DTC RESULTS	TIME
ECM	0

SEL952W

DIAGNOSTIC PROCEDURE 2

NMEL0330S06

Self-diagnostic results:
"ECM" displayed on CONSULT-II screen

1. Confirm SELF-DIAGNOSTIC RESULTS "ECM" displayed on CONSULT-II screen. Ref. part No. B.
2. Replace ECM.
3. Perform initialization with CONSULT-II.
For initialization, refer to "CONSULT-II operation manual NATS".

NATS (NISSAN ANTI-THEFT SYSTEM)

Trouble Diagnoses (Cont'd)


DIAGNOSTIC PROCEDURE 3

=NMEL0330S07

Self-diagnostic results:

"CHAIN OF ECM-IMMU" displayed on CONSULT-II screen

1	CONFIRM SELF-DIAGNOSTIC RESULTS											
Confirm SELF-DIAGNOSTIC RESULTS "CHAIN OF ECM-IMMU" displayed on CONSULT-II screen.												
<table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th colspan="2">SELF DIAG RESULTS</th> </tr> <tr> <th>DTC RESULTS</th> <th>TIME</th> </tr> </thead> <tbody> <tr> <td>CHAIN OF ECM-IMMU</td> <td>0</td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> </tbody> </table>			SELF DIAG RESULTS		DTC RESULTS	TIME	CHAIN OF ECM-IMMU	0				
SELF DIAG RESULTS												
DTC RESULTS	TIME											
CHAIN OF ECM-IMMU	0											
SEL366X												
Is CONSULT-II screen displayed as above?												
Yes	▶	GO TO 2.										
No	▶	GO TO SYMPTOM MATRIX CHART 1.										

2	CHECK POWER SUPPLY CIRCUIT FOR IMMU	
1. Disconnect IMMU connector. 2. Check voltage between IMMU harness connector E114 terminal 8 (W) and ground with CONSULT-II or tester.		
 Battery voltage should exist.		
SEL302WG		
OK or NG		
OK	▶	GO TO 3.
NG	▶	Check the following • 10A fuse (No. 34, located in the fuse and fusible link box) • Harness for open or short between fuse and IMMU connector Ref. Part No. C1

NATS (NISSAN ANTI-THEFT SYSTEM)


Trouble Diagnoses (Cont'd)

3	CHECK IGN SW. ON SIGNAL	
	1. Turn ignition switch ON. 2. Check voltage between IMMU harness connector E114 terminal 7 (BR) and ground with CONSULT-II or tester. Battery voltage should exist. SEL303WI OK or NG	
OK	▶	GO TO 4.
NG	▶	Check the following • 10A fuse [No. 14, located in the fuse block (J/B)] • Harness for open or short between fuse and IMMU connector Ref. part No. C2

4	CHECK GROUND CIRCUIT FOR IMMU	
	1. Turn ignition OFF. 2. Check continuity between IMMU harness connector E114 terminal 4 (B) and ground. Continuity should exist. SEL304WG OK or NG	
OK	▶	GO TO 5.
NG	▶	Repair harness. Ref. part No. C3

NATS (NISSAN ANTI-THEFT SYSTEM)

Trouble Diagnoses (Cont'd)

7	CHECK COMMUNICATION LINE GROUND SHORT CIRCUIT	
1. Turn ignition switch OFF. 2. Check continuity between ECM harness connector F1 terminal 8 (OR) or IMMU harness connector E114 terminal 1 (PU/R) and ground.		
 DISCONNECT  ECM CONNECTOR 8 IMMU connector 1  Continuity should not exist.		
OK or NG		
OK	▶	GO TO 8.
NG	▶	Communication line is short-circuited with ground line. Repair harness or connectors. Ref. part No. C4

8	SELF-FUNCTION CHECK	
1. Connect ECM connector and disconnect IMMU connector. 2. Turn ignition switch ON. 3. Touch "SELF-FUNCTION CHECK" on CONSULT-II "SELECT DIAG MODE" screen. 4. Touch "START". ECM will then check its communication interface by itself. SELF-FUNCTION CHECK TOUCH START, THE ECM WILL CHECK THE IMMU COMMUNICATION INTERFACE. START SELF-FUNCTION CHECK result: OK or NG		
OK	▶	IMMU is malfunctioning. Replace IMMU. Ref. part No. A Perform initialization with CONSULT-II. For the operation of initialization, refer to "CONSULT-II operation manual NATS".
NG	▶	ECM is malfunctioning. Replace ECM. Ref. part No. B Perform initialization with CONSULT-II. For the operation of initialization, refer to "CONSULT-II operation manual NATS".

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

NATS (NISSAN ANTI-THEFT SYSTEM)

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 4

=NMEL0330S08

Self-diagnostic results:

"DIFFERENCE OF KEY" displayed on CONSULT-II screen

1	CONFIRM SELF-DIAGNOSTIC RESULTS											
Confirm SELF-DIAGNOSTIC RESULTS “DIFFERENCE OF KEY” displayed on CONSULT-II screen.												
<table><tr><th colspan="2">SELF DIAG RESULTS</th></tr><tr><th>DTC RESULTS</th><th>TIME</th></tr><tr><td>DIFFERENCE OF KEY</td><td>0</td></tr><tr><td></td><td></td></tr><tr><td></td><td></td></tr></table>			SELF DIAG RESULTS		DTC RESULTS	TIME	DIFFERENCE OF KEY	0				
SELF DIAG RESULTS												
DTC RESULTS	TIME											
DIFFERENCE OF KEY	0											
SEL367X												
Is CONSULT-II screen displayed as above?												
Yes	▶	GO TO 2.										
No	▶	GO TO SYMPTOM MATRIX CHART 1.										

SEL367X

2	PERFORM INITIALIZATION WITH CONSULT-II				
Perform initialization with CONSULT-II. Re-register all NATS ignition key IDs. For initialization and registration of NATS ignition key IDs, refer to “CONSULT-II operation manual NATS”.					
<table><tr><td>IMMU INITIALIZATION</td></tr><tr><td>INITIALIZATION FAIL</td></tr><tr><td>THEN IGN KEY SW ‘OFF’ AND ‘ON’, AFTER CONFIRMING SELF-DIAG AND PASSWORD, PERFORM C/U INITIALIZATION AGAIN.</td></tr></table>			IMMU INITIALIZATION	INITIALIZATION FAIL	THEN IGN KEY SW ‘OFF’ AND ‘ON’, AFTER CONFIRMING SELF-DIAG AND PASSWORD, PERFORM C/U INITIALIZATION AGAIN.
IMMU INITIALIZATION					
INITIALIZATION FAIL					
THEN IGN KEY SW ‘OFF’ AND ‘ON’, AFTER CONFIRMING SELF-DIAG AND PASSWORD, PERFORM C/U INITIALIZATION AGAIN.					
NOTE:					
If the initialization is not completed or fails, CONSULT-II shows above message on the screen.					
Can the system be initialized and can the engine be started with re-registered NATS ignition key?					
Yes	▶	Ignition key ID was unregistered. Ref. part No. D			
No	▶	IMMU is malfunctioning. Replace IMMU. Ref. part No. A Perform initialization with CONSULT-II. For initialization, refer to “CONSULT-II operation manual NATS”.			

SEL297W

NATS (NISSAN ANTI-THEFT SYSTEM)

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 5

=NMEL0330S09

Self-diagnostic results:

"CHAIN OF IMMU-KEY" displayed on CONSULT-II screen

1	CONFIRM SELF-DIAGNOSTIC RESULTS											
Confirm SELF-DIAGNOSTIC RESULTS “CHAIN OF IMMU-KEY” displayed on CONSULT-II screen.												
<table><tr><th colspan="2">SELF DIAG RESULTS</th></tr><tr><th>DTC RESULTS</th><th>TIME</th></tr><tr><td>CHAIN OF IMMU-KEY</td><td>0</td></tr><tr><td></td><td></td></tr><tr><td></td><td></td></tr></table>			SELF DIAG RESULTS		DTC RESULTS	TIME	CHAIN OF IMMU-KEY	0				
SELF DIAG RESULTS												
DTC RESULTS	TIME											
CHAIN OF IMMU-KEY	0											
SEL368X												
Is CONSULT-II screen displayed as above?												
Yes	▶	GO TO 2.										
No	▶	GO TO SYMPTOM MATRIX CHART 1.										

2	CHECK NATS IGNITION KEY ID CHIP	
Start engine with another registered NATS ignition key.		
Does the engine start?		
Yes	▶	Ignition key ID chip is malfunctioning. Replace the ignition key. Ref. part No. E Perform initialization with CONSULT-II. For initialization, refer to “CONSULT-II Operation Manual NATS”.
No	▶	GO TO 3.

3	CHECK IMMU INSTALLATION	
Check IMMU installation. Refer to “How to Replace IMMU” in EL-153.		
OK or NG		
OK	▶	IMMU is malfunctioning. Replace IMMU. Ref. part No. A Perform initialization with CONSULT-II. For initialization, refer to “CONSULT-II Operation Manual NATS”.
NG	▶	Reinstall IMMU correctly.

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

NATS (NISSAN ANTI-THEFT SYSTEM)

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 6

=NMEL0330S10

Self-diagnostic results:

"ID DISCORD, IMM-ECM" displayed on CONSULT-II screen

1	CONFIRM SELF-DIAGNOSTIC RESULTS											
Confirm SELF-DIAGNOSTIC RESULTS "ID DISCORD, IMM-ECM" displayed on CONSULT-II screen.												
<table border="1"> <thead> <tr> <th colspan="2">SELF DIAG RESULTS</th> </tr> <tr> <th>DTC RESULTS</th> <th>TIME</th> </tr> </thead> <tbody> <tr> <td>ID DISCORD, IMM-ECM</td> <td>0</td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> </tbody> </table>			SELF DIAG RESULTS		DTC RESULTS	TIME	ID DISCORD, IMM-ECM	0				
SELF DIAG RESULTS												
DTC RESULTS	TIME											
ID DISCORD, IMM-ECM	0											
NOTE: "ID DISCORD IMM-ECM": Registered ID of IMMU is in discord with that of ECM.												
Is CONSULT-II screen displayed as above?												
Yes	▶	GO TO 2.										
No	▶	GO TO SYMPTOM MATRIX CHART 1.										

SEL369X

2	PERFORM INITIALIZATION WITH CONSULT-II				
Perform initialization with CONSULT-II. Re-register all NATS ignition key IDs. For initialization, refer to "CONSULT-II operation manual NATS".					
<table border="1"> <thead> <tr> <th>IMMU INITIALIZATION</th> </tr> </thead> <tbody> <tr> <td>INITIALIZATION FAIL</td> </tr> <tr> <td>THEN IGN KEY SW 'OFF' AND 'ON', AFTER CONFIRMING SELF-DIAG AND PASSWORD, PERFORM C/U INITIALIZATION AGAIN.</td> </tr> </tbody> </table>			IMMU INITIALIZATION	INITIALIZATION FAIL	THEN IGN KEY SW 'OFF' AND 'ON', AFTER CONFIRMING SELF-DIAG AND PASSWORD, PERFORM C/U INITIALIZATION AGAIN.
IMMU INITIALIZATION					
INITIALIZATION FAIL					
THEN IGN KEY SW 'OFF' AND 'ON', AFTER CONFIRMING SELF-DIAG AND PASSWORD, PERFORM C/U INITIALIZATION AGAIN.					
NOTE: If the initialization is not completed or fails, CONSULT-II shows above message on the screen.					
Can the system be initialized?					
Yes	▶	Start engine. (END) (System initialization had not been completed. Ref. part No. F)			
No	▶	ECM is malfunctioning. Replace ECM. Ref. part No. F Perform initialization with CONSULT-II. For initialization, refer to "CONSULT-II operation manual NATS".			

SEL297W

NATS (NISSAN ANTI-THEFT SYSTEM)

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 7

=NMEL0330S11

Self-diagnostic results:

"ELECTRONIC NOISE/MINGLE NOISE" displayed on CONSULT screen

1	CONFIRM SELF-DIAGNOSTIC RESULTS											
Confirm SELF-DIAGNOSTIC RESULTS "ELECTRONIC NOISE/MINGLE NOISE" displayed on CONSULT-II screen.												
<table border="1"> <tr> <th colspan="2">SELF DIAG RESULTS</th> </tr> <tr> <th>DTC RESULTS</th> <th>TIME</th> </tr> <tr> <td>ELECTRONIC/MINGLE NOISE</td> <td>0</td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> </table>			SELF DIAG RESULTS		DTC RESULTS	TIME	ELECTRONIC/MINGLE NOISE	0				
SELF DIAG RESULTS												
DTC RESULTS	TIME											
ELECTRONIC/MINGLE NOISE	0											
SEL937X												
Is CONSULT-II screen displayed as above?												
Yes	▶	GO TO 2.										
No	▶	GO TO SYMPTOM MATRIX CHART 1.										

2	TURN OFF AND REMOVE NOISE	
1. Turn off or remove any possible noise sources. 2. Touch "ERASE" on CONSULT-II SELF-DIAGNOSTIC RESULTS screen. 3. Start engine.		
Does engine start?		
Yes	▶	INSPECTION END
No	▶	GO TO 1.

NATS (NISSAN ANTI-THEFT SYSTEM)

Trouble Diagnoses (Cont'd)


DIAGNOSTIC PROCEDURE 8

"SECURITY INDICATOR LAMP DOES NOT LIGHT UP"


=NMEL0330S12

1	CHECK FUSE
Check 10A fuse [No. 28, located in the fuse block (J/B)].	
Is 10A fuse OK?	
Yes	▶ GO TO 2.
No	▶ Replace fuse.

2	CHECK SECURITY INDICATOR LAMP
1. Install 10A fuse. 2. Perform initialization with CONSULT-II. For initialization, refer to "CONSULT-II Operation Manual NATS". 3. Turn ignition switch OFF. 4. Start engine and turn ignition switch OFF. 5. Check the security indicator lamp lighting. Security indicator lamp should be blinking.	
OK or NG	
OK	▶ INSPECTION END
NG	▶ GO TO 3.

3	CHECK SECURITY INDICATOR LAMP POWER SUPPLY CIRCUIT
1. Disconnect security indicator lamp connector. 2. Check voltage between security indicator lamp harness connector M50 terminal 1 (R/W) and ground.	
Security indicator lamp connector   Battery voltage should exist. SEL250Y	
OK or NG	
OK	▶ GO TO 4.
NG	▶ Check harness for open or short between fuse and security indicator lamp.

4	CHECK SECURITY INDICATOR LAMP
Check security Indicator Lamp.	
Is security indicator lamp OK?	
Yes	▶ GO TO 5.
No	▶ Replace security indicator lamp.

5	CHECK IMMU FUNCTION	
1. Connect IMMU connector. 2. Disconnect security indicator lamp connector. 3. Check continuity between IMMU harness connector E114 terminal 5 (G/OR) and ground. IMMU connector     Cotinuity should exist intermittently. SEL300WG OK or NG		
OK	▶	Check harness for open or short between security indicator lamp and IMMU.
NG	▶	IMMU is malfunctioning. Replace IMMU. Perform initialization with CONSULT-II. For initialization, refer to “CONSULT-II operation manual NATS”.

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

NATS (NISSAN ANTI-THEFT SYSTEM)

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 9

=NMEL0330S13

Self-diagnostic results:

"LOCK MODE" displayed on CONSULT-II screen


1	CONFIRM SELF-DIAGNOSTIC RESULTS											
Confirm SELF-DIAGNOSTIC RESULTS "LOCK MODE" is displayed on CONSULT-II screen.												
<table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th colspan="2">SELF DIAG RESULTS</th> </tr> <tr> <th>DTC RESULTS</th> <th>TIME</th> </tr> </thead> <tbody> <tr> <td>LOCK MODE</td> <td>0</td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> </tbody> </table>			SELF DIAG RESULTS		DTC RESULTS	TIME	LOCK MODE	0				
SELF DIAG RESULTS												
DTC RESULTS	TIME											
LOCK MODE	0											
SEL371X												
Is CONSULT-II screen displayed as above?												
Yes	▶	GO TO 2.										
No	▶	GO TO SYMPTOM MATRIX CHART 1.										

2	ESCAPE FROM LOCK MODE	
- Turn ignition switch OFF. - Turn ignition switch ON with registered key. (Do not start engine.) Wait 5 seconds. - Return the key to OFF position. - Repeat steps 2 and 3 twice (total of three cycles). - Start the engine.		
Does engine start?		
Yes	▶	System is OK. (Now system is escaped from "LOCK MODE".)
No	▶	GO TO 3.

3	CHECK IMMU ILLUSTRATION	
Check IMMU installation. Refer to "How to Replace IMMU" in EL-153.		
OK or NG		
OK	▶	GO TO 4.
NG	▶	Reinstall IMMU correctly.

4	PERFORM INITIALIZATION WITH CONSULT-II				
Perform initialization with CONSULT-II. For initialization, refer to “CONSULT-II operation manual NATS”.					
<table><tr><td>IMMU INITIALIZATION</td></tr><tr><td>INITIALIZATION FAIL</td></tr><tr><td>THEN IGN KEY SW ‘OFF’ AND ‘ON’, AFTER CONFIRMING SELF-DIAG AND PASSWORD, PERFORM C/U INITIALIZATION AGAIN.</td></tr></table>			IMMU INITIALIZATION	INITIALIZATION FAIL	THEN IGN KEY SW ‘OFF’ AND ‘ON’, AFTER CONFIRMING SELF-DIAG AND PASSWORD, PERFORM C/U INITIALIZATION AGAIN.
IMMU INITIALIZATION					
INITIALIZATION FAIL					
THEN IGN KEY SW ‘OFF’ AND ‘ON’, AFTER CONFIRMING SELF-DIAG AND PASSWORD, PERFORM C/U INITIALIZATION AGAIN.					
NOTE: If the initialization is not completed or fails, CONSULT-II shows the above message on the screen. Can the system be initialized?					
Yes	▶	System is OK.			
No	▶	GO TO DIAGNOSTIC PROCEDURE 4 to check “CHAIN OF IMMU-KEY”, refer to EL-147.			

SEL297W



How to Replace NATS IMMU

NMEL0331

NOTE:

- If NATS IMMU is not installed correctly, NATS system will not operate properly and SELF-DIAG RESULTS on CONSULT-II screen will show "LOCK MODE" or "CHAIN OF IMMU-KEY".

SEL096W


GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

ELECTRICAL UNITS LOCATION


Engine Compartment

Engine Compartment

NMEL0129



Relay box



CEL319A

ELECTRICAL UNITS LOCATION

Engine Compartment (Cont'd)

NOTE:

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL



IDX

ELECTRICAL UNITS LOCATION

Passenger Compartment

Passenger Compartment



NMEL0130



CEL320A

ELECTRICAL UNITS LOCATION

Passenger Compartment (Cont'd)




GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

HARNESS LAYOUT

How to Read Harness Layout

How to Read Harness Layout

NMEL0131



The following Harness Layouts use a map style grid to help locate connectors on the drawings:

- Main Harness
- Engine Room Harness (Engine Compartment)
- Engine Control Harness
- Body Harness

TO USE THE GRID REFERENCE

NMEL0131S01

1. Find the desired connector number on the connector list.
2. Find the grid reference.
3. On the drawing, find the crossing of the grid reference letter column and number row.
4. Find the connector number in the crossing zone.
5. Follow the line (if used) to the connector.

CONNECTOR SYMBOL


NMEL0131S02

Main symbols of connector (in Harness Layout) are indicated in the below.

Connector type	Water proof type		Standard type	
	Male	Female	Male	Female
• Cavity: Less than 4 • Relay connector				
• Cavity: From 5 to 8				
• Cavity: More than 9				
• Ground terminal etc.	—			

Outline

NMEL0132



CEL322A

NOTE:

For detailed ground distribution information, refer to "Ground Distribution", "GROUND", EL-15.


GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

HARNESS LAYOUT

Main Harness

Main Harness

NMEL0133



CEL323A

F5	(M1)	-	: Body ground
F4	(M2)	W/6	: Door lock relay
G4	(M3)	SB/6	: Joint connector-1 (With A/T)
F4	(M4)	L/4	: Power window relay
F4	(M6)	W/10	: Fuse block (J/B)
F4★	(M7)	W/16	: Fuse block (J/B)
G4	(M8)	W/20	: To (B1)
G3	(M9)	W/6	: To (B3)
G3★	(M10)	SMJ	: To (E101)
G3	(M13)	W/2	: Circuit breaker
G3	(M14)	W/12	: To (D1)
G3	(M15)	W/10	: To (D2)
G2	(M16)	W/8	: To (R1)
E2	(M17)	SB/6	: Joint connector-2 (With A/T)
D2	(M18)	W/20	: Combination meter
E2	(M19)	BR/20	: Combination meter
E2	(M20)	BR/24	: Combination meter
E3	(M21)	B/3	: Combination flasher unit
F4	(M22)	GY/14	: Data link connector
E3	(M23)	B/2	: Stop lamp switch
F3	(M24)	BR/2	: Shift lock brake switch (With A/T)
E2★	(M25)	W/24	: TCM (Transmission control module) (With A/T)
D2★	(M26)	GY/24	: TCM (Transmission control module) (With A/T)
D3	(M27)	B/6	: Air mix door motor
D3	(M28)	BR/10	: Mode door motor
D3	(M29)	B/6	: Bi-level door motor
E3	(M30)	Y/7	: Spiral cable
B3	(M31)	B/12	: Push control unit
C2	(M32)	B/16	: Push control unit
D3	(M33)	W/6	: Fan switch
C3	(M34)	W/3	: A/C switch
B3	(M35)	BR/6	: PTC
C4	(M36)	W/8	: Hazard switch
C4	(M37)	W/6	: Rear window defogger
C4	(M38)	B/1	: Cigarette lighter illumination
B3	(M39)	B/2	: Cigarette lighter socket
A3	(M40)	W/2	: Ashtray illumination
A4	(M41)	W/8	: A/T mode switch
A4	(M42)	Y/20	: Air bag diagnosis sensor unit

C2	(M43)	W/4	: Option connector (Deck)
C2	(M44)	W/10	: Option connector (Audio unit)
D3	(M45)	W/6	: Option connector (Audio unit)
C2	(M46)	W/2	: Antenna amp.
C2	(M47)	Y/2	: Front passenger air bag module
C1	(M48)	W/8	: Intake door motor
B2	(M49)	W/3	: Thermo control amplifier
C1	(M50)	BR/2	: Security indicator lamp
B2	(M52)	BR/4	: Fan resistor
B2	(M53)	W/2	: Blower motor
B2	(M56)	W/8	: To (D31)
A2	(M57)	W/6	: To (D32)
B3	(M58)	L/4	: Blower relay-2
B3★	(M60)	W/48	: To (F4)
B3★	(M62)	W/4	: To (F5) (With A/T)
B3	(M67)	-	: Body ground


★ : Be sure to connect and lock the connectors securely after repair work.
 Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

HARNESS LAYOUT

Engine Room Harness


Engine Room Harness

NMEL0134



CEL325A


(E2)	BR/6	: Headlamp relay
(E3)	L/4	: Cooling fan relay-1
(E4)	L/4	: Starter relay (With A/T)
(E5)	L/4	: A/C relay
(E6)	GY/3	: Horn relay
(E8)	-	: Fuse block
(E9)	-	: Fusible link block
(E10)	-	: Relay box (Fusible link and fuse block)
(E11)	GY/2	: Brake fluid level switch
(E12)	GY/2	: Front wheel sensor RH
(E13)	BR/2	: Side turn signal lamp RH
(E22)	GY/2	: Park/neutral position switch (With A/T)
(E23)	GY/8	: Park/neutral position switch (With A/T)
(E24)	GY/3	: Revolution sensor (With A/T)
(E25)	BR/8	: To terminal cord assembly (With A/T)
(E26)	SB/8	: To (E201)
(E27)	B/2	: To (E202)
(E29)	B/2	: Fusible link
(E33)	GY/2	: Front washer motor
(E37)	GY/3	: Front combination lamp RH
(E38)	GY/2	: Headlamp RH (Low)
(E39)	B/2	: Headlamp RH (High)
(E43)	-	: Body ground
(E44)	GY/4	: Cooling fan motor
(E47)	B/1	: Horn high
(E48)	B/1	: Horn low
(E52)	B/2	: Headlamp LH (High)
(E53)	GY/2	: Headlamp LH (Low)
(E54)	GY/3	: Front combination lamp LH
(E55)	B/4	: Triple-pressure switch
(E56)	GY/3	: To (F20)
(E57)	-	: Body ground



★ : Be sure to connect and lock the connectors securely after repair work.
 Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

HARNESS LAYOUT

Engine Room Harness (Cont'd)



★	(E101)	SMJ	:	To (MT10)
	(E103)	B/2	:	Fuse block (J/B)
	(E104)	W/4	:	Fuse block (J/B)
	(E105)	W/12	:	Fuse block (J/B)
	(E106)	W/6	:	Illumination control switch
	(E107)	B/5	:	Ignition switch
	(E108)	BR/2	:	Key switch
	(E109)	BR/8	:	Combination switch (Lighting switch/Turn signal lamp switch)
	(E110)	BR/4	:	Combination switch (Lighting switch)
	(E112)	GY/8	:	Combination switch (Front wiper switch)
	(E114)	W/8	:	NATS IMMU

★: Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes. **Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.**

CEL327A

HARNESS LAYOUT

Engine Room Harness (Cont'd)

NOTE:

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

HARNESS LAYOUT


Engine Control Harness

Engine Control Harness

NMEL0135



CEL328A



For detailed ground distribution information, refer to "GROUND DISTRIBUTION".

★ : Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes. Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.


HARNESS LAYOUT

Engine Sub Harness


Engine Sub Harness

NMEL0332

- ★ (F101) GY/6 : To (F24)
- ★ (F102) — : Engine ground
- ★ (F103) GY/3 : Ignition coil No. 4 (With power transistor)
- ★ (F104) GY/3 : Ignition coil No. 3 (With power transistor)
- ★ (F105) GY/3 : Ignition coil No. 2 (With power transistor)
- ★ (F106) GY/3 : Ignition coil No. 1 (With power transistor)



Engine ground



For detailed ground distribution information, refer to "GROUND DISTRIBUTION".

- ★ : Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes. Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.



- ★ (F111) SB/8 : To (F27)
- (F112) B/2 : Injector No. 4
- (F113) B/2 : Injector No. 3
- (F114) B/2 : Injector No. 2
- (F115) B/2 : Injector No. 1
- ★ (F116) GY/2 : Engine coolant temperature sensor
- (F117) B/1 : Thermal transmitter
- ★ (F121) GY/2 : To (F28)
- ★ (F122) B/2 : Knock sensor

CEL330A

Engine Harness

NMEL0333

For detailed ground distribution information, refer to "GROUND DISTRIBUTION".



E201	SB/8	:	To E26
E202	B/2	:	To E27
E204	–	:	Battery
E205	–	:	Fusible link block
E206	–	:	Body ground
E207	–	:	Alternator (B)
E208	–	:	Alternator (E)
E209	GY/2	:	Alternator (S, L)
E210	GY/1	:	Oil pressure switch
E211	B/1	:	Starter motor
E212	GY/2	:	Back-up lamp switch (With M/T)
E213	B/2	:	Park/neutral position switch (With M/T)
E214	–	:	Starter motor

CEL331A


GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

HARNESS LAYOUT

Body Harness

Body Harness

NMEL0136



CEL332A

Rear window defogger harness
B1 (B102) B/1 : Rear window defogger (-)
B1 (B103) - : Body ground

G2	(B1)	W/20	:	To	(M8)
F2	(B2)	-	:	Body ground	
G2	(B3)	W/6	:	To	(M9)
G2	(B4)	W/10	:	Fuse block (J/B)	
G2	(B5)	W/3	:	Fuse block (J/B)	
G2	(B6)	L/4	:	Fuel pump relay	
F2	(B7)	BR/6	:	Rear window defogger relay	
E2	(B8)	W/6	:	A/T device (With A/T)	
F3	(B9)	W/3	:	Seat belt buckle switch (Driver side)	
E3	(B10)	W/1	:	Parking brake switch	
C2	(B12)	W/3	:	Door switch (Passenger side)	
F3	(B14)	W/3	:	Door switch (Driver side)	
E2	(B18)	-	:	Body ground	
D2	(B19)	W/1	:	Rear window defogger coil	
C2	(B20)	BR/2	:	Rear speaker RH	
C2	(B21)	W/2	:	Trunk room lamp	
B2	(B22)	W/2	:	High-mounted stop lamp	
B2	(B23)	BR/2	:	Rear speaker LH	
D3	(B24)	W/12	:	To	(T1)

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
AX
SU
BR
ST
RS
BT
HA
SC


EL

HARNESS LAYOUT

Tail Harness

Tail Harness


NMEL0138



CEL334A

Room Lamp Harness

NMEL0334



R1	W/8	:	To	(M16)
R2	W/1	:	Sunroof motor assembly	
R3	W/2	:	Spot lamp	
R4	W/2	:	Interior room lamp (Without sunroof)	
R5	W/2	:	Interior room lamp (With sunroof)	

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

HARNESS LAYOUT


Door Harness

Door Harness

NMEL0142

RH SIDE


- (D1) W/12 : To (M14)
- (D2) W/10 : To (M15)
- (D3) W/2 : Door speaker
- (D4) SB/8 : Power window regulator
- (D5) W/8 : Door mirror actuator
- (D6) W/10 : Door mirror remote control switch
- (D7) W/16 : Power window main switch
- (D8) GY/2 : Door unlock sensor



CEL336A

LH SIDE

- (D31) W/8 : To (M56)
- (D32) W/6 : To (M57)
- (D33) W/2 : Door speaker
- (D34) B/2 : Power window regulator
- (D35) W/8 : Door mirror actuator
- (D36) W/8 : Power window sub-switch
- (D37) SB/4 : Door lock actuator (Passenger side)



CEL337A

BULB SPECIFICATIONS

Headlamp

Headlamp		NMEL0144S03
Item	Wattage (W)	
High (Semi-sealed beam)	60	
Low (Semi-sealed beam)	55 (H1LL)	

Exterior Lamp			NMEL0144S01
Item		Wattage (W)	
Parking lamp		5	LC
Front turn signal lamp		21	
Side turn signal lamp		5	EC
Rear combination lamp	Turn signal	21	CL
	Stop/Tail	21/5	
	Back-up	18	
License plate lamp		5	CL
High-mounted stop lamp		18	

Interior Lamp			NMEL0144S02
Item		Wattage (W)	
Interior room lamp		10	
Spot lamp	With sunroof	10	
	Without sunroof	8	
Trunk room lamp		3.4	

EL

MA

EM

LC

EC

FE

CL

MT

AT

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

WIRING DIAGRAM CODES (CELL CODES)

Use the chart below to find out what each wiring diagram code stands for.

Refer to the wiring diagram code in the alphabetical index to find the location (page number) of each wiring diagram.

Code	Section	Wiring Diagram Name
AAC/V	EC	IACV-AAC Valve
ABS	BR	Anti-lock Brake System
A/C	HA	Air Conditioner
AT/C	EC	A/T Control
AT/IND	EL	A/T Indicator Lamp
AUDIO	EL	Audio
BACK/L	EL	Back-up Lamp
BA/FTS	AT	A/T Fluid Temperature Sensor and TCM Power Supply
BUZZER	EL	Warning Buzzer
CHARGE	SC	Charging System
CIGAR	EL	Cigarette Lighter
CLOCK	EL	Clock
CMPS	EC	Camshaft Position Sensor
COOL/F	EC	Cooling Fan Control
DEF	EL	Rear Window Defogger
D/LOCK	EL	Power Door Lock
ECTS	EC	Engine Coolant Temperature Sensor
ENGSS	AT	Engine Speed Signal
FICD	EC	IACV-FICD Solenoid Valve
F/PUMP	EC	Fuel Pump Control
H/LAMP	EL	Headlamp
HORN	EL	Horn
HO2S	EC	Heated Oxygen Sensor
HO2SH	EC	Heated Oxygen Sensor Heater
IGN/SG	EC	Ignition Signal
ILL	EL	Illumination
INJECT	EC	Injector
INT/L	EL	Spot and Trunk Room Lamps
IVC	EC	Intake Valve Timing Control Solenoid Valve
KS	EC	Knock Sensor
LOAD	EC	Load Signal
LPSV	AT	Line Pressure Solenoid Valve
MAFS	EC	Mass Air Flow Sensor

Code	Section	Wiring Diagram Name
MAIN	AT	Main Power Supply and Ground Circuit
MAIN	EC	Main Power Supply and Ground Circuit
METER	EL	Speedometer, Tachometer, Temp., and Fuel Gauges
MIL/DL	EC	MIL and Data Link Connector
MIRROR	EL	Door Mirror
NATS	EL	NISSAN ANTI-THEFT SYSTEM
NONDTC	AT	Non-detectable Items
OVRCSV	AT	Overrun Clutch Solenoid Valve
PNP/SW	EC	Park/Neutral Position Switch
POWER	EL	Power Supply Routing
PST/SW	EC	Power Steering Oil Pressure Switch
ROOM/L	EL	Interior Room Lamp
S/SIG	EC	Start Signal
SHIFT	AT	A/T Shift Lock System
SROOF	EL	Electric Sunroof
SRS	RS	Supplemental Restraint System
SSV/A	AT	Shift Solenoid Valve A
SSV/B	AT	Shift Solenoid Valve B
START	SC	Starting System
STOP/L	EL	Stop Lamp
TAIL/L	EL	Parking, License and Tail Lamps
TCV	AT	Torque Converter Clutch Solenoid Valve
TPS	AT	Throttle Position Sensor
TPS	EC	Throttle Position Sensor
TURN	EL	Turn Signal and Hazard Warning Lamps
VSS	EC	Vehicle Speed Sensor
VSSA/T	AT	Vehicle Speed Sensor A/T (Revolution Sensor)
VSSMTR	AT	Vehicle Speed Sensor MTR
WARN	EL	Warning Lamps
WG/V	EC	Wastegate valve control
WINDOW	EL	Power Window
WIPER	EL	Front Wiper and Washer