

F I A T P A N D A



O W N E R H A N D B O O K

This Owner Handbook is intended to show the vehicle's operating conditions.

For the enthusiast user who wants to have insights, curiosities and detailed information about the characteristics and functions of the vehicle, Fiat gives the opportunity to consult a dedicated section which is available in electronic format.

ONLINE VEHICLE OWNER HANDBOOK

The following symbol  is reported within the text of the Owner Handbook, next to the subjects for which details are provided.

Go to the www.mopar.eu/owner website and access your personal area.

The “Maintenance and care” page includes all the information about your vehicle and the link to access *eLUM*, where you will find all the details of the Owner Handbook.

The *eLUM* website is free and will allow you, among many other things, to easily consult the on-board documents of all the other vehicles of the Group.

Have a nice reading and happy motoring!

Dear Customer,

We would like to congratulate and thank you for choosing a Fiat Panda.

We have written this handbook to help you get to know all the features of your vehicle and use it in the best possible way.

Here you will find information, advice and important warnings regarding use of your vehicle and how to achieve the best performance from the technical features of your Fiat Panda.

You are advised to read it right through before taking to the road for the first time, to become familiar with the controls and above all with those concerning brakes, steering and gearbox; at the same time, you can understand the vehicle behaviour on different road surfaces.

This document also provides a description of special features and tips, as well as essential information for the safe driving, care and maintenance of your Fiat Panda over time.

After reading it, you are advised to keep the handbook inside the vehicle, for an easy reference and for making sure it remains on board the vehicle should it be sold.

In the attached Warranty Booklet you will also find a description of the Services that Fiat offers to its customers, the Warranty Certificate and the detail of the terms and conditions for maintaining its validity.

We are sure that these will help you to get in touch with and appreciate your new vehicle and the service provided by the people at Fiat.

Enjoy reading. Happy motoring!

IMPORTANT

This Owner Handbook describes all versions of the Fiat Panda; please consider only the information relevant to your vehicle's trim level, engine and version. All data contained in this publication are purely indicative. FCA Italy S.p.A. can modify the content of this publication at any time, for technical or commercial purposes. For further information, contact a Fiat Dealership.

READ THIS CAREFULLY

REFUELLING



Petrol engines: only refuel with unleaded petrol with octane rating (RON) not less than 95 in compliance with the European specification EN228. Using these mixtures may cause misfiring and driving issues, as well as damage fundamental components of the supply system.
Diesel engines: refuel only with Diesel fuel motor vehicles conforming to the European specification EN590. The use of other products or mixtures may damage the engine beyond repair and consequently invalidate the warranty, due to the damage caused.
LPG engines: refuel only with LPG for motor vehicles conforming to the European specification EN589. The use of other products or mixtures may damage the engine beyond repair and consequently invalidate the warranty, due to the damage caused.
For further details on the use of the correct fuel see the "Refuelling the vehicle" paragraph in the "Starting and driving" chapter.

STARTING THE ENGINE



Make sure that the handbrake is engaged and place the gear lever in neutral. Fully depress the clutch pedal, without pressing the accelerator, then turn the ignition key to MAR and wait for the  warning light to switch off (and the  warning light for Diesel versions); turn the ignition key to AVV and release it as soon as the engine starts.

Versions with Dualogic gearbox: make sure that the handbrake is engaged and that the gear lever is in P (Parking) or N (Neutral), fully depress the brake pedal, then turn the ignition key to AVV and release it as soon as the engine is started. .

PARKING ON FLAMMABLE MATERIAL



The catalytic converter develops high temperatures during operation. Do not park the car on grass, dry leaves, pine needles or other flammable material: fire hazard.

RESPECTING THE ENVIRONMENT



The vehicle is fitted with a system that carries out a continuous diagnosis of the emission-related components in order to help protect the environment.

ELECTRICAL ACCESSORIES



If, after buying the vehicle, you decide to add electrical accessories (with the risk of gradually draining the battery), contact a Fiat Dealership. They can calculate the overall electrical requirement and check that the vehicle's electric system can support the required load.

SCHEDULED SERVICING



Correct maintenance of the car is essential for ensuring that it maintains its performance and its safety features, its environmental friendliness and low running costs for a long time to come.

USE OF THE OWNER HANDBOOK

OPERATING INSTRUCTIONS

Each time direction instructions (left/right or forwards/backwards) about the vehicle are given, these must be intended as regarding an occupant in the driver's seat. Special cases not complying with this rule will be specified as appropriate in the text. The figures in the Owner Handbook are provided by way of example only: this might imply that some details of the image do not correspond to the actual arrangement of your vehicle. In addition, the Handbook has been conceived considering vehicles with steering wheel on the left side; it is therefore possible that on vehicles with steering wheel on the right side, the position or construction of some controls is not exactly mirror-like with respect to the figure.

To identify the chapter with the information needed you can consult the index at the end of this Owner Handbook.

Chapters can be rapidly identified with dedicated graphic tabs, at the side of each odd page. A few pages further there is a key for getting to know the chapter order and the relevant symbols in the tabs. There is in any case a textual indication of the current chapter at the side of each even page.

WARNINGS AND PRECAUTIONS

While reading this Owner Handbook you will find a series of **WARNINGS** to prevent procedures that could damage your vehicle.

There are also **PRECAUTIONS** that must be carefully followed to prevent incorrect use of the components of the vehicle, which could cause accidents or injuries.

Therefore all **WARNINGS** and **PRECAUTIONS** must always be carefully followed.

WARNINGS and **PRECAUTIONS** are recalled in the text with the following symbols:



personal safety;



vehicle safety;



environmental protection.

NOTE These symbols, when necessary, are indicated besides the title or at the end of the line and are followed by a number. That number recalls the corresponding warning at the end of the relevant section.

SYMBOLS

Some vehicle components have coloured labels whose symbols indicate precautions to be observed when using this component.

A plate summarising these symbols can also be found under the bonnet.

VEHICLE CHANGES/ALTERATIONS

IMPORTANT Any change or alteration of the vehicle might seriously affect its safety and road holding, thus causing accidents, in which the occupants could even be fatally injured.

KNOWING YOUR CAR	
KNOWING THE INSTRUMENT PANEL	
SAFETY	
STARTING AND DRIVING	
IN AN EMERGENCY	
SERVICING AND CARE	
TECHNICAL DATA	
MULTIMEDIA	
INDEX	

KNOWING YOUR CAR

In-depth knowledge of your new vehicle starts here.

The handbook that you are reading simply and directly explains how it is made and how it works.


That's why we advise you to read it seated comfortably on board, so that you can see immediately what is described here for yourself.

DASHBOARD	8
THE KEYS.....	9
IGNITION DEVICE	10
THE FIAT CODE SYSTEM	11
DOORS.....	11
SEATS	12
HEAD RESTRAINTS.....	14
STEERING WHEEL	15
REAR VIEW MIRRORS.....	16
EXTERNAL LIGHTS.....	17
INTERIOR LIGHTS	19
WINDOW CLEANING.....	20
CLIMATE CONTROL SYSTEM	22
ELECTRIC WINDOWS	26
BONNET	26
LUGGAGE COMPARTMENT	28
USB PORTS AND AUX INPUT	29
SMARTPHONE DOCKING	30
VERSION WITH LPG SYSTEM.....	31
VERSION WITH METHANE SYSTEM (NATURAL POWER)	33



DASHBOARD

The presence and position of controls, instruments and gauges may vary depending on the versions.



1

F1D0131

1. Adjustable air vents 2. Exterior light control stalk 3. Driver front airbag 4. Windscreen wiper/rear window wiper/trip computer control lever 5. Adjustable and directable central air vents 6. Passenger front airbag 7. Glove compartment (for versions/markets, where provided) 8. Radio (for versions/markets, where applicable) 9. Control buttons 10. Gear lever 11. Heating/ventilation/climate control system controls 12. Ignition device 13. Instrument panel 14. Front electric windows 15. ECO/ASR OFF buttons (for versions/markets, where provided)

THE KEYS



KEY WITHOUT REMOTE CONTROL

The metal insert of the key activates: the ignition device, the driver's side and passenger's side door locks (for versions/markets where provided) and the luggage compartment lock.


KEY WITH REMOTE CONTROL

(for versions/markets, where provided)



Metal insert A fig. 2 of the key operates:

- ☐ the ignition device;
 - ☐ the driver side door and, for versions/markets where provided, the passenger side door.
- Press button B fig. 2 to open/close the metal insert.



Briefly press button  : unlocking of doors and luggage compartment, timed switching-on of internal lights and double flashing of direction indicators (for versions/markets, where provided). Briefly press the  button: lock of doors and luggage compartment with roof lights off and single flash of direction indicators (for versions/markets, where provided).

Press the  button: remote opening of the luggage compartment and double flashing of the direction indicators. The direction indicators will flash twice to indicate that the luggage compartment has been opened.

REQUEST FOR ADDITIONAL KEYS

Should a new mechanical key or a new key with remote control be necessary, go to a FIAT Dealership, taking an ID document and the vehicle ownership documents. The system can recognise up to 8 keys with incorporated remote control.



WARNING

1) Press button B only with the key away from your body, especially your eyes and from objects which could get damaged (e.g. your clothes). Do not leave the key unattended, to prevent people, especially children, from inadvertently pressing the button.



WARNING

1) The electronic components inside the key may be damaged if the key is subjected to strong shocks. In order to ensure complete efficiency of the electronic devices inside the key, it should never be exposed to direct sunlight.




WARNING

1) Used batteries must be disposed of, as specified by law, in the special containers. Otherwise take them to a Fiat Dealership, which will deal with their disposal.




IGNITION DEVICE



2) 3) 4) 5)

The key can be turned to 3 different positions fig. 3:

- ☐ STOP: engine off, key can be removed, steering column locked. Some electrical devices (e.g. audio system, central door locking system, etc.) can operate;
- ☐ MAR: driving position. All electrical devices are enabled;
- ☐ AVV: engine starting.



3

F1D0006

The ignition switch is fitted with a safety system that requires the ignition key to be turned back to STOP if the engine does not start, before the starting operation can be repeated.

STEERING LOCK

Engagement

When the key is at STOP, remove the key and turn the steering wheel until it locks.

Disengagement

Move the steering wheel slightly and turn the key to MAR.



WARNING

2) If the ignition device is tampered with (e.g.: attempted theft), have it checked over by a Fiat Dealership as soon as possible.

3) When getting out of the vehicle, always remove the key to prevent any occupants from accidentally activating the controls. Remember to engage the handbrake. Engage first gear if the vehicle is parked uphill or reverse if the vehicle is parked downhill. Never leave children unattended in the vehicle.

4) It is absolutely forbidden to carry out any after-market operation involving steering system or steering column modifications (e.g. installation of anti-theft device) that could adversely affect performance and safety, invalidate the warranty and also result in non-compliance of the vehicle with type-approval requirements.

5) Never extract the key while the vehicle is moving. The steering wheel will automatically lock as soon as it is turned. This also applies to cases in which the vehicle is towed.

THE FIAT CODE SYSTEM

This is an electronic engine locking system which increases protection against attempted thefts of the vehicle. It is automatically activated when the ignition key is removed.

OPERATION

Each time the vehicle is started by turning the ignition key to MAR, the Fiat CODE system control unit sends a recognition code to the Powertrain Control Module to deactivate the immobiliser.

The code is sent only if the Fiat CODE system control unit has acknowledged the code received from the key.

Each time the ignition key is turned to STOP, the Fiat CODE system deactivates the functions of the Powertrain Control Module. If, during starting, the code is not correctly recognised, the  warning light switches on in the instrument panel. In this case, turn the key to STOP and then to MAR; if it is still locked, try again with the other keys that come with the vehicle. Contact a Fiat Dealership if you still cannot start the engine.

If the  warning light switches on, this means that the system is running a self-diagnosis (for example due to a voltage drop). Should the fault persist, contact a Fiat Dealership.


DOORS



LOCKING/UNLOCKING DOORS FROM THE INSIDE

Push the control lever A fig. 4 towards the door to lock the doors or pull it to unlock them. With central door locking system (for versions/markets, where provided), operating the lever A on the driver's side will lock/unlock all the doors. Operating lever A on the other doors locks/unlocks only the door concerned. With mechanical lock, locking/unlocking takes place operating the single control levers.

IMPORTANT The locked door condition is indicated by the red printing B fig. 4.



4

F1D0029



LOCKING/UNLOCKING DOORS FROM THE OUTSIDE

Mechanical key: insert the metal insert in the lock and turn it.

Key with remote control (for versions/markets where provided): press the  button to lock the doors, or the  button to unlock the doors.

IMPORTANT Before opening a door, ensure that you can do it in conditions of safety. Open the doors only when the vehicle is stationary.

CHILD SAFETY DEVICE




This system prevents the rear doors from being opened from the inside. The device B fig. 5 can be engaged only with the doors open.

☐ position 1 - device engaged (door locked);

☐ position 2 - device not engaged (door may be opened from the inside).

The device remains engaged even if the doors are electrically unlocked.

IMPORTANT The rear doors cannot be opened from the inside when the child safety device is engaged.



5

F1D0030




WARNING

6) Always use this device when carrying children. After engaging the child lock on both rear doors, check for effective engagement by trying to open a door with the internal handle.

SEATS



FRONT SEATS



Longitudinal adjustment


Lift lever A fig. 6 and push the seat forwards or backwards: in the driving position, you should be able to rest your arms on the rim of the steering wheel.

Height adjustment

(for versions/markets, where provided)

Adjust lever B fig. 6 upwards or downwards to obtain the required height.

IMPORTANT Carry out the adjustment whilst seated in the driver's seat.




6

F1D0007

Backrest angle adjustment

Operate lever C fig. 7 until the desired position is reached, then release the lever.



7


F1D0008

FRONT SEAT ELECTRIC HEATING

(for versions/markets, where provided)

With the ignition key turned to MAR, press button A or B fig. 8 respectively to switch the function on.

To deactivate the function press the button again.



8

F1D0145


REAR SEATS

Extending the boot



Proceed as follows:

- ☐ remove the rear shelf;
- ☐ move the seat belts to the side, making sure that they are correctly extended and not twisted;
- ☐ if there is a third rear seat (for versions/markets, where provided), release the central belt, winding the buckle into its housing on the roof panel;
- ☐ operate the levers at the sides of the rear seats fig. 9 pushing them towards the inside of the vehicle, fold the backrest and then bring the backrest onto the cushion.



9

F1D0034

Repositioning the backrests

Move the seat belts to the side, making sure that they are correctly extended and not twisted. Lift up the backrest folded previously until a click is heard for the engagement mechanism.



WARNING

7) All adjustments must be made with the car stationary.

8) If a side bag is fitted, it is dangerous to use seat covers not available from Lineaccessori MOPAR®.

9) Once you have released the adjustment lever, always check that the seat is locked on the guides by trying to move it back and forth. If the seat is not locked into place, it may unexpectedly slide and cause the driver to lose control of the car.

10) If passengers are seating in the rear seats, remove all potentially dangerous objects which may cause injuries in the event of an accident.





WARNING

2) The fabric upholstery of the seats has been designed to withstand long-term wear deriving from normal use of the car. Some precautions are however required. Avoid prolonged and/or excessive rubbing against clothing accessories such as metal buckles and Velcro strips which, by applying a high pressure on the fabric in a small area, could cause it to break, thereby damaging the upholstery.

3) Before tilting the backrest, remove any objects on the seat cushion.


HEAD RESTRAINTS



FRONT HEAD RESTRAINTS

Upwards adjustment: raise the head restraint until it clicks into place.

Downwards adjustment: press button A fig. 10 and lower the head restraint.



10

F1D0011

"Anti-Whiplash" device


The head restraints are equipped with an "Anti-Whiplash" device, which reduces the distance between head and head restraint in the event of a rear impact, thus mitigating the "whiplash" effect.

The head restraint may move when the backrest is pressed by the occupant's torso or hand: this behaviour is caused by the system and should not be considered a malfunction.

REAR HEAD RESTRAINTS

Upwards adjustment: raise the head restraint until it clicks into place.

Downwards adjustment: press button A fig. 11 and lower the head restraint.



11

F1D0012

IMPORTANT If the rear seats are used, always set the head restraints in the "completely raised" position.

Removal

Proceed as follows to remove the head restraints:

- ☐ raise the head restraints to their maximum height;
- ☐ press buttons A and B fig. 11 at the side of the two supports, then remove the head restraints by pulling them upwards.



WARNING

11) All adjustments must be made with the vehicle stationary. Head restraints must be adjusted so that the head, rather than the neck, rests on them. Only in this case can they protect your head correctly.

12) To make the best use of the head restraint's protective action, adjust the backrest so that your torso is upright and keep your head as close as possible to the head restraint.

STEERING WHEEL




13) 14)

ADJUSTMENTS

The steering wheel can be adjusted vertically.

To adjust, move lever A fig. 12 downwards to position 1, then adjust the steering wheel to the most suitable position and lock it in position by moving lever A to position 2.



12

F1D0013



WARNING

13) Adjustments must be made only with the vehicle stationary and engine off.

14) It is absolutely forbidden to carry out any after-market operation involving steering system or steering column modifications (e.g. installation of anti-theft device) that could adversely affect performance and safety, invalidate the warranty and also result in non-compliance of the vehicle with type-approval requirements.




REAR VIEW MIRRORS



INTERIOR MIRROR

The mirror is fitted with a safety device that causes its release in the event of a violent impact with the passenger. Operate lever A fig. 13 to adjust the mirror into two different positions: normal or anti-glare.




13

F1D0014

DOOR MIRRORS 15)

Manual adjustment

From the inside of the vehicle, operate lever A fig. 14 to adjust the mirror.



14

F1D0015

Electric adjustment


(for versions/markets, where provided)

The mirrors can only be adjusted with the ignition key at MAR. To carry out the adjustment, proceed as follows:

- ☐ select the desired mirror (left or right) using selector A fig. 15;
- ☐ move selector A to position B and manipulate it to adjust the left door mirror;
- ☐ move selector A to position D and manipulate it to adjust the right door mirror.

Once you have finished the adjustment, return selector A to intermediate locking position C.

IMPORTANT When the heated rear window is activated, door mirror defrosting is activated (for versions/markets, where provided).



15

F1D0016

Manual folding

When required, fold the mirrors toward the vehicle interior.

IMPORTANT When driving, the mirrors must always be open.



WARNING

15) As the driver's door mirror is curved, it may slightly alter the perception of distance.

EXTERNAL LIGHTS

The left stalk fig. 16 controls the operation of the headlights, side lights, dipped beam headlights, parking lights, main beam headlights, direction indicators, and "Follow me home" device.



16

F1D0019

The exterior lights can only be switched on when the ignition key is at MAR. The instrument panel and the various dashboard controls will come on with the external lights.

SIDE LIGHTS / DAYTIME RUNNING LIGHTS (DRL) "Daytime Running Lights"

(for versions/markets, where provided)



With the ignition key in MAR position and the ring nut A fig. 16 turned to **O** position, the daytime lights switch on automatically; the other lights and the internal lighting remain off.

SIDE LIGHTS / DIPPED BEAM HEADLIGHTS

With the ignition key turned to MAR, turn ring nut A fig. 16 to . If dipped beam headlights are activated, the daytime running lights switch off and the side lights and dipped headlights switch on. The  warning light switches on in the instrument panel.

PARKING LIGHTS

These lights can only be turned on with ignition key in STOP position or removed, by moving the ring nut A fig. 16 first to position **O** and then to position . The  warning light switches on in the instrument panel.

MAIN BEAM HEADLIGHTS

To activate the main beam headlights, with ring nut A fig. 16 at , pull the stalk towards the steering wheel beyond the end of travel position. The  warning light switches on in the instrument panel.

When the stalk is pulled towards the steering wheel again, beyond the end of travel position, the main beam headlights deactivate, the dipped headlights reactivate and the  warning light switches off.

FLASHING

To do this, pull the stalk towards the steering wheel (unstable position), regardless of the position of ring nut A fig. 16. The  warning light switches on in the instrument panel.

DIRECTION INDICATORS

Bring the stalk to the (stable) position:

upwards: activates the right direction indicator;

downwards: activates the left direction indicator.

The  or  warning light will blink on the instrument panel. The direction indicators switch off automatically when the steering wheel is straightened.

"Lane Change" function

If you wish to signal a lane change, place the left stalk in the unstable position for less than half a second. The direction indicator on the side selected will flash five times and then switch off automatically.

"FOLLOW ME HOME" DEVICE

This allows the space in front of the vehicle to be lit for a set time.



Activation: with the ignition key on STOP or removed, pull the stalk towards the steering wheel within 2 minutes from when the engine is turned off.

Each time the stalk is moved, the lights stay on for an extra 30 seconds up to a maximum of 210 seconds; then the lights are switched off automatically. Each time the stalk is operated, the  warning light on the instrument panel switches on and the display also shows a message and how long the function will remain active.

The  warning light comes on when the stalk is first moved and stays on until the function is automatically deactivated. Each time the stalk is activated it increases the time that the lights remain on.

Deactivation: keep the stalk pulled towards the steering wheel for more than two seconds.

REAR FOG LIGHTS

Press the  button, on the dashboard, to switch on the rear fog lights. With rear fog lights on, the  warning light on the instrument panel will come on at the same time.

FRONT FOG LIGHTS/REAR FOG LIGHTS

(for versions/markets, where provided)


The fog lights can be activated only when the dipped beam headlights are on.

To turn on the front/rear fog lights, press button A fig. 17 as follows:

- ☐ **First pressing:** front fog lights on;
- ☐ **second press:** rear fog lights on;
- ☐ **third pressing:** front/rear fog lights off

With front fog lights on, the  warning light on the instrument panel will come on at the same time.

With rear fog lights on, the  warning light on the instrument panel will come on at the same time.



17

F1D0024



WARNING

16) The daytime running lights are an alternative to the dipped beam headlights for driving during the daytime in countries where it is compulsory to have lights on during the day, and they are also permitted in those countries where this is not obligatory.

17) Daytime running lights cannot replace dipped beam headlights when driving at night or through tunnels. The use of daytime running lights is governed by the highway code of the country in which you are driving. Comply with legal requirements.

INTERIOR LIGHTS




FRONT ROOF LIGHT

Singe-bulb roof light

The lens of roof light A fig. 18 can be set to three positions:

- ☐ right side pressed: light always on
- ☐ left side pressed: light always off
- ☐ central position: the light switches on/off when the doors are opened/closed.



18

F1D0021

Multi-bulb roof light

(for versions/markets, where provided)


Switch A fig. 19 is used to switch on/off the roof light bulbs.

Switch A positions:

- ☐ central position (position 1): lights C and D switch on/off when the doors are opened/closed;

- ☐ pressed to the left (position 0): lights C and D are always switched off;
- ☐ pressed to the right (position 2): lights C and D are always switched on. The lights switch on/off gradually. Switch B positions fig. 19:

- ☐ central position (position 1): lights C and D are always switched off;
- ☐ pressed to the left (position 0): light C switches on;
- ☐ pressed to the right (position 2): light D switches on.



19

F1D0022

IMPORTANT Before getting out of the vehicle, make sure that both switches are in the central position: when the doors are closed the lights will switch off to avoid draining the battery. In any case, if the switch is left in the on position, the roof light switches off automatically about 15 minutes after the engine has been switched off.

ROOF LIGHT TIMING

On certain versions, to facilitate getting in/out of the vehicle at night or in poorly-lit areas, two timed modes have been provided.

- ☐ when getting into the vehicle;
- ☐ when getting out of the vehicle.



WINDOW CLEANING


WINDSCREEN WIPER/WASHER



This operates only with the ignition key turned to MAR.

Ring nut A fig. 20 has four different positions:

- ☐ windscreen wiper off.
- 00** intermittent operation.
- ☐ continuous slow operation.
- ☐ continuous fast operation.



20

F1D0020

Move the stalk upwards (unstable position) to limit operation to the time for which the stalk is held in this position. When released, the stalk will return to its default position and the windscreen wiper will be automatically stopped.

With ring nut A fig. 20 in **00** position, the windscreen wiper will automatically adapt its operating speed to the speed of the vehicle.

With the windscreen wipers operational, if reverse gear is engaged, the rear window wiper is automatically activated.

“Smart washing” function

Pull the stalk towards the steering wheel (unstable position) to operate the windscreen washer.

Keeping the stalk pulled for more than half a second, with just one movement it is possible to operate the washer jet and the wiper at the same time. The windscreen wiper stops working three strokes after the stalk is released. A further stroke after approximately 6 seconds completes the cycle.

REAR WINDOW WIPER/WASHER



This operates only with the ignition key turned to MAR.

Turn ring nut B fig. 20 from position ☐ to position ☐ to operate the rear window wiper as follows:

- ☐ in intermittent mode when the windscreen wiper is not operating;

☐ in synchronous mode (at half the speed of the windscreen wiper) when the windscreen wiper is operating;

☐ in continuous mode with reverse gear engaged and the control active. With the windscreen wiper on and reverse gear engaged, rear window wiping will be continuous.

Pushing the stalk towards the dashboard (unstable position) will activate the rear window washer jet. Keep the stalk pushed for more than half a second to activate the rear window wiper as well. Releasing the stalk will activate the smart washing function, as described for the windscreen wiper.

The function stops when the stalk is released.



WARNING

4) Do not use the windscreen wiper to remove layers of snow or ice from the windscreen. In such conditions, the windscreen wiper may be subjected to excessive stress and the motor cut-out switch, which prevents operation for a few seconds, may intervene. If operation is not restored (even after turning the key and restarting the engine), contact a Fiat Dealership.

5) Do not operate the windscreen wiper with the blades lifted from the windscreen.

6) Make sure the device is switched off whenever the windscreen must be cleaned.

7) Do not use the rear window wiper to remove layers of snow or ice. In such conditions, the wiper may be subjected to excessive stress and the motor cut-out switch, which prevents operation for a few seconds, may intervene. If operation is not subsequently restored, contact a Fiat Dealership.





(for versions/markets, where provided)

Controls



F1D0132

A - Air temperature adjustment knob (red-hot / blue-cold).

B - Air recirculation knob:

 internal air recirculation.

  air intake from outside.

IMPORTANT It is advisable to switch the air recirculation on whilst queuing or in tunnels, or whilst driving on dusty roads, to prevent the introduction of polluted air. However, it is better not to use the function for long periods, particularly if there are many people on board, to prevent the windows from misting.

C - Air distribution knob:

-  air flow to central and side dashboard vents to ventilate the chest and the face during the hot season.
-  distribution between foot area diffusers (warmest air) and dashboard diffusers (coolest air).
-  towards the footwell diffusers. Due to the natural tendency of heat to spread upwards, this type of distribution warms the passenger compartment up as quickly as possible, providing an immediate feeling of warmth.
-  distribution between footwell diffusers and windscreen/front side window vents. This type of distribution achieves effective heating of the passenger compartment and prevents the windows from misting up.
-  air flow to the windscreen and front side window diffusers to demist or defrost them.

D - Heated rear window, folding mirror/heated windscreen (for versions/markets, where available) activation/deactivation button. The LED on the button switches on to indicate activation. To maintain battery efficiency, the function is automatically deactivated after about 20 minutes

E - Fan speed and climate control system activation/deactivation knob (for versions/markets, where available).

IMPORTANT In warm-humid weather conditions, using cold air on the windscreen may cause external condensation, which could limit visibility.

Note To stop the air flow from the vents, position the knob at 0 and put knob B to internal air recirculation.

ADDITIONAL HEATER

(for versions/markets, where provided)

This device speeds up passenger compartment warming when it is very cold. The heater switches on automatically according to the environmental conditions, with engine started and when the temperature of the engine coolant is low. The additional heater turns off automatically after the required comfort conditions are achieved.


The heater only operates if the outside temperature and engine coolant temperature are low. The heater will not activate if the battery voltage is too low.



AUTOMATIC CLIMATE CONTROL SYSTEM

(for versions/markets, where provided)

Controls



22

F1D0708

A - Turns on the AUTO function (climate control system automatic operation).

B - Increases the air temperature.

C - Decreases the air temperature.

D - Selects manual air distribution.

By pressing the buttons, one of the five possible air flow distribution patterns can be selected:

 air flow to the windscreen and front side window diffusers to demist or defrost them.

 air flow to central and side dashboard vents to ventilate the chest and the face during the hot season.

 towards the footwell diffusers. Due to the natural tendency of heat to spread upwards, this type of distribution warms the passenger compartment up as quickly as possible, providing an immediate feeling of warmth.

 divided between the footwell diffusers (warmest air) and the dashboard vents (coolest air).



distribution between footwell diffusers and windscreen/front side window vents. This type of distribution achieves effective heating of the passenger compartment and prevents the windows from misting up.

IMPORTANT In warm-humid weather conditions, using cold air on the windscreen may cause external condensation, which could limit visibility.

E - Turns on/off the MAX-DEF function (fast front window defrosting/demisting).

F - Turns on/off the air conditioning compressor.

G - Turns on/off the internal air recirculation.

H - Turns on/off the air conditioning.

F - Turns on/off the heated rear window and (for versions/markets, where available) the heated mirrors/heated windscreen.

L/M - Adjusts the fan speed.

The automatic climate control manages the Start&Stop function (engine off when the car speed is zero) to guarantee a suitable comfort inside the passenger compartment.

NOTE In particularly severe climate conditions it is recommended to limit the use of the Start&Stop function to prevent the compressor from continuously switching on and off, with consequent rapid misting of the windows and accumulation of humidity with unpleasant smells in the passenger compartment.



WARNING

18) *It is advisable not to use the internal air recirculation function when the outside temperature is low, because the windows could mist rapidly.*



WARNING

2) *The system uses a coolant that is compatible with the laws in force in countries where the vehicle is sold, R134a or R1234yf. In case of a recharge operation, only use the gas indicated on the label placed in the engine compartment. The use of other coolants affects the efficiency and condition of the system. The lubricant used for the compressor is also strictly linked to the type of cooling gas, please refer to a Fiat Dealership.*



ELECTRIC WINDOWS

ELECTRIC FRONT WINDOWS




19) 20)

These operate when the ignition key is turned to MAR and for about three minutes after turning the ignition key to STOP or removing it.

The electric window control buttons are located beside the gear lever fig. 23 and activate:

- A Opening/closing of the left window.
- B Opening/closing of the right window.

With the ignition key at MAR, a long press activates the automatic operation of the window: raising/lowering on the driver's side and lowering only on the passenger side.



23

F1D0031

MANUAL REAR WINDOW WINDERS

To open/close the window operate the handle on the door panel.



WARNING

19) *Improper use of the electric windows can be dangerous. Before and during operation, always check that nobody is exposed to the risk of being injured either directly by the moving window or through objects getting caught or hit by it.*


20) *When leaving the vehicle, always remove the ignition key to avoid the risk of injury for people still on board due to accidental operation of the electric windows.*

BONNET

OPENING

Proceed as follows:


- ☐ pull lever A fig. 24 in the direction indicated by the arrow;



24

F1D0035


- ☐ move lever B fig. 25 to the left;



25

F1D0036

❑ lift the bonnet and, at the same time, release the supporting rod C fig. 26 from its catch D, then insert the end of the rod into housing E in the bonnet (large hole) and push to safety position (small hole).



26

F1D0037

⚠ 21) 22)

CLOSING


Proceed as follows:

- ❑ keep the bonnet raised with one hand and remove rod C fig. 26 from housing E with the other, inverting the opening motion, then fit it back into its catch D;
- ❑ lower the bonnet to approximately 20 centimetres from the engine compartment and let it drop. Make sure that the bonnet is completely closed and not only fastened by the locking device by trying to open it. If it is not perfectly closed, do not try to press the bonnet lid down but open it and repeat the procedure.

⚠ 23) 24)

IMPORTANT Always check that the bonnet is closed correctly to prevent it from opening while the vehicle is travelling.

The following plate fig. 27 is applied inside the engine compartment:



27

F1D1000



WARNING

21) *Incorrect positioning of the supporting rod may cause the bonnet to drop suddenly.*

22) *Use both hands to lift the bonnet. Before lifting, check that the windscreen wiper arms are not raised from the windscreen, that the vehicle is stationary and that the handbrake is engaged.*

23) *Perform these operations only with vehicle stationary.*

24) *For safety reasons, the bonnet must always be properly closed while driving. Therefore, make sure that the bonnet is properly closed and that the lock is engaged. If you discover that the bonnet is not perfectly closed during travel, stop immediately and close the bonnet in the correct manner.*



LUGGAGE COMPARTMENT



The luggage compartment unlocking is electrically operated and is deactivated when the vehicle is in motion.

OPENING



25)

By mechanical key

On versions with mechanical key, the luggage compartment can be opened from outside the vehicle, inserting the metal insert of the key in the latch on the tailgate handle and rotating.


With remote control

(for versions/markets, where provided)

The luggage compartment is unlocked by pressing the  button on the remote control. The direction indicators will blink twice.

With electric handle (soft touch) (for versions/markets, where provided)

For versions with soft touch electrical handle, the tailgate (when unlocked) can only be opened from outside the vehicle using the electric opening handle A fig. 28 located under the handle until a click is heard, which indicates unlocking. The tailgate can be opened at any time, if the doors are unlocked. To open it, enable the handle, opening one of the front doors or unlocking the doors with the remote control or using the key without remote control.




28

F1D0032

Emergency opening from the inside

Proceed as follows:

- ☐ remove the rear head restraints and fully fold the seats;
- ☐ remove the protective cap and release the lock using a screwdriver or the metal insert of the key fig. 29.



29

F1D0033

CLOSING



26)

Pull the grab handle located inside the tailgate.

IMPORTANT Before closing the luggage compartment make sure that you have the keys since the luggage compartment is automatically locked.

LUGGAGE COMPARTMENT INITIALISATION

IMPORTANT If the battery is disconnected or the protection fuse blows, the luggage compartment opening/closing mechanism must be reinitialised as follows: close all the doors and the tailgate, press the  button on the remote control, then press the .

 27) 28) 29)



WARNING

25) Take care not to knock objects on the roof rack when opening the tailgate.

26) With the engine on, always make sure that the tailgate is closed: exhaust gases could be drawn inside the load compartment.

27) Every attachment has a maximum load capacity of 100 kg.


28) A heavy load that has not been secured may cause serious injuries in the event of an accident.

29) If you are travelling in an area with limited opportunities for vehicle refuelling and you wish to bring petrol with you in a petrol can, you must do so in compliance with current regulations and using an approved can, appropriately secured to the load securing attachments. Anyway, by doing so, you increase the risk of fire in the event of an accident with your vehicle.

USB PORTS AND AUX INPUT

(for versions/markets, where provided)


Depending on the trim level, the vehicle may be equipped with:



30

F1D0698

 a USB port/main AUX input fig. 30. The AUX input for connection of external devices (iPod, music players, etc.) and the USB port for the transfer of data from a USB Pen Drive or other source (smartphone etc.) and slow recharging;



31

F1D0697

 an accessory USB port on the dashboard fig. 31 with the sole function of recharging external devices (smartphone etc.).




SMARTPHONE DOCKING

(for versions/markets, where provided)

Depending on the trim level, the vehicle may be equipped with a smartphone docking station to be installed on the dashboard.

Installing/uninstalling the station

Install the smartphone docking station by inserting it in the specific seat on the dashboard, illustrated in fig. 32 (click fit).




32

F1D0702

To remove the docking station, press both side buttons fig. 33 simultaneously.

Note When the smartphone docking station is not in use, it is recommended to remove it from its seat to avoid noise and/or vibrations.




33

F1D0700

Inserting/removing the smartphone

To insert the smartphone in the docking station:




34

F1D0703

□ ensure that the ring nut A fig. 34 is turned to position ;

□ insert the smartphone horizontally in its seat, placing it on the base of the docking station, and press to open the gripping hand fig. 35;




35

F1D0699

□ lay the smartphone on the front base and release it. The load on the spring inside the docking station will allow the gripping hand to close;

□ block the smartphone by turning the ring nut A fig. 34 so that it clicks into position .



36

F1D0701

□ The rear knob B fig. 36 allows possible adjustments depending on the weight and geometry of the smartphone.

To remove the smartphone from the docking station:

- ❑ turn the ring nut A fig. 34 so that it clicks into position  ,
- ❑ take out the smartphone by pressing it down to open the gripping hand;
- ❑ remove the smartphone from the docking station and release it. The load on the spring inside the docking station will allow the gripping hand to close after the phone has been removed.

 8) 9) 10)

WARNING

8) When the vehicle is moving, the smartphone must be used in the docking station only in a horizontal position and without any inclination (see fig. 35). Any other position of the docking station is allowed only with the vehicle stopped, with the sole purpose of facilitating the insertion of the smartphone in the station.

9) The maximum dimensions of the usable smartphones are: 67 mm (width) and 11 mm (depth).

10) The maximum weight of smartphone that can be installed is 180 g.

VERSION WITH LPG SYSTEM




 30) 31) 15)  11) 12) 13) 14)

INTRODUCTION

The LPG version features two fuel supply systems: one for petrol and one for LPG.


Although the LPG system has numerous safety features, it is advisable to proceed as follows every time the vehicle is not in use for a long period or moved in an emergency as a result of a breakdown or accident:

- ❑ unscrew the fixing devices A fig. 37, then remove the cover B;
- ❑ close the LPG cock by turning the ring nut C fig. 38 clockwise;
- ❑ refit the cover and retighten the fastening devices.



37

F1D0111




38

F1D0112

LPG TANK

 15)

The car has a (pressurised) tank A fig. 39 for storing LPG in a liquid state. It is toroidal and is located in the spare wheel compartment with suitable protection.



39

F1D0113



LPG tank certification


The LPG tank is certified in accordance with the regulations in force.

In Italy, the tank has a life of 10 years starting from the car registration date. If the vehicle has been registered in a country other than Italy, the duration and the testing/inspection procedures of the LPG tank can vary depending on the national laws of that country. In all case, when the time limit for your country has expired, go to a Fiat Dealer to have the tank replaced.

SELECTION OF PETROL/LPG SUPPLY TYPE

 32)  16) 17) 18)

The button A fig. 40 (petrol/LPG switch) allows you to select running on petrol or LPG.



40

F1D0109

To guarantee switching in full safety, the actual change to the chosen fuel system takes place depending on the car usage conditions; it may not therefore be immediate.

Switching is confirmed by the green warning light  on the instrument panel turning on/off.

If the LPG runs out, switching to petrol takes place automatically. In this case the display shows the  icon just above the wording LPG and the four bars of the digital gauge turn off.

REFUELLING

 19) 20)

LPG

Maximum refuelling capacity (including reserve): 30.5 litres. The figure already takes into account the 80% tank filling limit and the residual fluid required for priming; this figure represents the maximum permitted capacity. In addition, this figure may vary from one refuelling to another due to differences between the network pump supply pressures, pumps having different supply/locking features, tank not completely run out of fuel.



WARNING

30) Note that in some countries (including Italy) there are legal restrictions in force for parking/garaging motor vehicles fuelled by gas that is denser than air; LPG comes under this category.

31) Modifications or repairs to the supply system that are not carried out correctly or do not take the system technical specifications into account can cause malfunctions leading to the risk of fire.

32) Do not switch between the two operating modes whilst starting the engine.



WARNING

11) The system operates at temperatures ranging between -20°C and 100°C.

12) If the fuel runs out while running on LPG, the car switches to petrol automatically and all the bars of the digital indicator on the display turn off. The display remains in this state until the next LPG refuelling.

13) The car is equipped with a gaseous LPG injection system designed specifically for it: it is therefore absolutely forbidden to alter the configuration of the system or its components. The use of other components or materials could cause malfunctions and lead to a reduction in safety; therefore, in the case of problems, contact a Fiat Dealership. To prevent damage to the gas system parts when towing or raising the vehicle, follow the instructions in the "Towing the vehicle" paragraph of the Owner Handbook.

14) When painting in an oven, the LPG tank must be removed from the car and later refitted by a Fiat Dealership. Although the LPG system has numerous safety features, it is advisable to proceed as follows every time the vehicle is not in use for a long period or moved in an emergency as a result of a breakdown or accident: unscrew the fastening devices A fig. 37, then remove the cover B. Close the LPG cock rotating the ring nut C clockwise fig. 39. Refit the cover and retighten the fastening devices.

15) Periodically (at least once every six months), it is advisable to let the LPG in the tank run out and, at the next refuelling, check that it does not exceed the maximum capacity of 30.5 litres (reserve included) (with a tolerance of 2 litres excess) (see instructions in the "Capacities" paragraph of this Supplement). If the level is above 30.5 litres (reserve included) contact a Fiat Dealership immediately.

16) Regardless of the last fuel system used, at the following engine starting, after the initial petrol stage, the system will automatically switch to LPG.

17) When switching from petrol to LPG is requested, a metal noise from the valves which pressurise the circuit can be heard. As a result of the switching logic described above, a delay between the valve ticking and the the green warning light  on the instrument panel turning off is completely normal.

18) In particular usage conditions, such as starting and operation at low ambient temperature or LPG supply with low propane content, the system may switch temporarily to petrol operation, without indicating the performed switching. In the event of low LPG levels in the tank or request for high performance (e.g. overtaking, fully laden vehicle, steep hills) the system may automatically switch to petrol operation to guarantee the engine power requested. The green warning light  on the instrument panel turns on to indicate this. When the above conditions are no longer present, the system automatically restores LPG operation; the green warning light  switches off. To achieve the automatic switching described above, make sure that there is always enough fuel in the petrol tank.

19) Only use LPG for motor vehicles.

20) It is strictly forbidden to use any additive in the LPG.

VERSION WITH METHANE SYSTEM (Natural Power)




 33) 34) 35)  21)

INTRODUCTION

The "Natural Power" version features two fuel systems, one for petrol and one for natural gas (methane).

METHANE CYLINDERS

The vehicle is equipped with two cylinders (total capacity about 72 litres) fig. 41 - fig. 42 located under the vehicle's floor and protected by two special guards.



41

F1D0137





42

F1D0138

The methane, stored in the cylinders at high pressure, flows through a dedicated pipe to reach the pressure regulator/reduction unit which supplies the two methane injectors at low pressure (about 9 bar).

Cylinder certification

The methane cylinders are certified in accordance with ECE Regulation no. 110.

The cylinders must be inspected, in accordance with ECE Regulation Procedure no. 110, every 4 years from the car registration date or in accordance with specific regulations in individual countries.

The plates provided by the Dealership with the on board documentation contain the date for the first inspection of the cylinders. Methane refuelling stations are not authorised to refill the cylinders when the inspection date has expired.


IMPORTANT If the vehicle has been registered in a country other than Italy, the certification data, identification and inspection procedures for the methane cylinders should conform to the legislation in that country. In any case, remember that the life of the cylinders is 20 years from the production date as set out in ECE Regulation no. 110.

SELECTION OF PETROL/METHANE SUPPLY TYPE

⚠ 36) ⚠ 22) 23) 24)

This engine normally runs on methane except during starting, when it runs on petrol.

The button A fig. 43 (petrol/methane switch) allows you to select running on petrol or methane.



43

F1D0109

To guarantee switching in full safety, the actual change to the chosen fuel system takes place depending on the car usage conditions; it may not therefore be immediate.

Switching is confirmed by the green warning light  on the instrument panel turning on/off.

In addition, when starting at outside temperatures below approximately -10°C , the switching times from petrol to methane increase to allow the pressure regulator/reduction unit to heat up.

If the methane has run out, switching to petrol takes place automatically. In this case, the four bars of the digital gauge turns off and the green warning light  on the instrument panel turns on.

REFUELLING

Methane

Capacity: about 12 kg. The total volume of cylinders is about 72 litres.



WARNING

33) The Fiat Panda Natural Power is equipped with a high pressure methane fuel supply system, designed to operate at a rated pressure of 200 bar. It is dangerous to stretch the system with higher pressures. To prevent damage to the gas system parts when towing or lifting the vehicle, follow the instructions in the Owner Handbook, in the paragraph: "Towing the vehicle". If there is a fault in the methane system, only contact a Fiat Dealership. Do not alter the methane system configuration or components. They are designed exclusively for the Fiat Panda Natural Power. The use of other components or materials could cause malfunctions and prejudice safety.

34) When oven painting, the cylinders must be removed from the vehicle and subsequently refitted by a Fiat Dealership. Although the methane system has numerous safety features, it is advisable to close the manual cocks for the cylinders every time the vehicle is not in use for a long period, transported on other vehicles or moved in an emergency as a result of a breakdown or accident.

35) Modifications or repairs to the supply system that are not carried out correctly or do not take the system technical specifications into account can cause malfunctions leading to the risk of fire.

36) Do not switch between the two operating modes whilst starting the engine.



WARNING

21) If the fuel runs out while running on methane, the car switches to petrol automatically and all the bars of the digital indicator on the display turn off. The display remains in this state until the next methane refuelling.

22) Regardless of the last fuel system used, at the following engine starting, after the initial petrol stage, the system will automatically switch to methane.

23) When switching from petrol to methane is requested, a metal noise from the valves which pressurise the circuit can be heard, as it happens while starting the car. As a result of the switching logic described above, a delay between the valve ticking and the the green warning light  on the instrument panel turning off is completely normal.

24) In particular usage conditions, such as starting and operation at low ambient temperature, the system may switch temporarily to petrol operation, without indicating the performed switching. In the event of low methane levels in the tank or a request for high performance (e.g. overtaking, fully laden vehicle, steep hills) the system may automatically switch to petrol operation to guarantee the engine power requested. The green warning light  on the instrument panel turns on to indicate this. When the above conditions are no longer present, the system automatically restores methane operation. The green warning light  turns off. To achieve the automatic switching described above, make sure that there is always enough fuel in the petrol tank.



KNOWING THE INSTRUMENT PANEL

This section of the handbook gives you all the information you need to understand, interpret and use the instrument panel correctly.

CONTROL PANEL AND ON-BOARD INSTRUMENTS	37
DISPLAY	38
WARNING LIGHTS AND MESSAGES	40
- Red warning lights	40
- Amber warning lights	47
- Green warning lights	55
- Blue warning lights	56
- Symbols and messages on the display	56

CONTROL PANEL AND ON-BOARD INSTRUMENTS

The instrument background colour and type may vary according to the versions.

The warning lights on the instrument panel may change according to the version/trim level (e.g. LPG, Cross etc.) of the vehicle. Warning lights  and  are available on diesel versions only. On diesel versions, the maximum engine speed (red range on the rev counter) corresponds to 6000 rpm.



44

A. Speedometer (speed indicator) – B. Multifunction display – C. Rev counter


F1D0690



DISPLAY



The display fig. 45 will show the following information:



45

F1D0002

- A** Date
- B** Dualdrive electric power steering engagement indication (CITY text)
- C** Headlight alignment position (only with dipped beam headlights on)
- D** Start&Stop function indication (for versions/markets where provided)
- E** Time
- F** Milometer (display of distance travelled in kilometres/miles)
- G** Seat belt indicators
- H** Outside temperature (for versions/markets, where provided)
- I** Gear engaged indication (Duallogic versions only)

- L** Gear Shift Indicator (for versions/markets, where provided)
- M** Engine coolant temperature indicator.
- N** Fuel level indicator.


GEAR SHIFT INDICATOR

The GSI (Gear Shift Indicator) system advises the driver to change gear through a specific indication on the control panel. Through the GSI, the driver is notified that changing gear will allow a reduction in fuel consumption. When the SHIFT UP icon (▲ SHIFT) is shown on the display, the GSI advises the driver to engage a higher gear, while when the SHIFT DOWN icon (▼ SHIFT) is shown, the GSI advises the driver to engage a lower gear. The indication remains displayed until a gear is shifted or the driving conditions go back to a situation where gearshifting is not required to improve consumption.

CONTROL BUTTONS

They are located on the dashboard fig. 46.

Note The symbol on the buttons depends on the version: ▲ and ▼ or ▲ and ▼.



46

F1D0003

- ▲ / ▼ : press and release the buttons to scroll the menu items upwards or downwards, or to increase/decrease the displayed value.
- SET : press briefly to access the menu and/or go to next screen or confirm the desired selection. Hold pressed to go back to the standard screen.

SETUP MENU

The menu includes the following items:

- MENU
- LIGHTING
- SPEED WARNING
- HEADLIGHT SENSOR (for versions/markets where provided)
- TRIP B ACTIVATION/DATA
- SET TIME
- SET DATE
- SEE RADIO (for markets/versions, where provided)

- ☐ AUTOCLOSE (for versions/markets, where provided)
- ☐ MEASUREMENT UNIT
- ☐ LANGUAGE
- ☐ WARNINGS VOLUME
- ☐ SEAT BELT BUZZER (for versions/markets, where provided)
- ☐ SERVICE
- ☐ AIRBAG/PASSENGER BAG (for versions/markets, where provided)
- ☐ DAYTIME RUNNING LIGHTS (for versions/markets, where provided)
- ☐ TYRE RESET (for versions/markets, where provided)
- ☐ CITY BRAKE C./ COLLISION MITIGATION (for versions/markets, where provided)
- ☐ EXIT MENU

Deactivating front passenger airbag and side bag

This function is used to activate/deactivate the front passenger's airbag. Proceed as follows:

- ☐ press the  button and, after the display shows the message "Passenger Bag: Off to deactivate) or the message ("Passenger Bag: On" to activate) by pressing  and , press  once again;
- ☐ a confirmation request message will appear on the display;

- ☐ by pressing the  or  buttons, select "Yes" (to confirm activation/deactivation) or "No" (to cancel);

- ☐ press the  button briefly; a message confirming the selection is displayed and you return to the menu screen. Hold down the button to return to the standard screen without storing.

TRIP COMPUTER

The Trip computer is used to display information on car operation when the key is turned to MAR. Two separate trips, called "Trip A" and "Trip B", are provided to monitor the entire mission (journey) in a reciprocally independent manner.

"Trip A" can be used to display the values relating to: "Outside temperature (for versions/markets, where provided)", "Range", "Distance travelled", "Average consumption", "Instantaneous consumption", "Average speed", "Trip time (driving time)"

"Trip B" may be used to display the figures relating to: "Distance travelled B", "Average fuel consumption B", "Average speed B", "Journey time B (driving time)". The "Trip B" function may be excluded.

Both functions can be reset (reset means start of a new journey).

To reset, hold the TRIP button on the right steering wheel stalk pressed.
NOTE "Range" and "Instantaneous fuel consumption" parameters cannot be reset.



WARNING LIGHTS AND MESSAGES

IMPORTANT NOTES

IMPORTANT Warning lights are accompanied by a specific message and/or sound when applicable. These indications are indicative and precautionary and as such must not be considered as exhaustive and/or alternative to the information contained in the Owner Handbook, which you are advised to read carefully in all cases. Always refer to the information in this section in the event of a failure indication.

IMPORTANT Failure indications displayed are divided into two categories: very serious and less serious failures. Serious faults are indicated by a repeated and prolonged warning "cycle". Less serious faults are indicated by a warning "cycle" with a shorter duration. The display cycle of both categories can be interrupted by pressing the **SET** button. The instrument panel warning light will stay on until the cause of the malfunction is eliminated.

WARNING LIGHTS ON INSTRUMENT PANEL

Red warning lights


Warning light	What it means
	SEAT BELTS NOT FASTENED (for versions/markets, where provided) The warning light switches on constantly with the vehicle stationary and the driver's side or passenger side seat belt (when the passenger is present) not fastened. The warning light will flash and a buzzer will sound if the car is in motion and the front seat belts are not correctly fastened. For permanent deactivation of the acoustic signal (buzzer) of the S.B.R. (Seat Belt Reminder) system contact a Fiat Dealership. The system can be reactivated using the Setup Menu.

Warning light	What it means
  	EBD FAILURE The simultaneous switching on of the  (red),  (amber) and  (amber) warning lights with the engine on indicates either an anomaly of the EBD system or that the system is not available. In this case, the rear wheels may suddenly lock and the vehicle may swerve when braking sharply. On certain versions a dedicated message is displayed. Drive very carefully to the nearest Fiat Dealership to have the system inspected immediately.
	AIRBAG FAILURE When the ignition key is turned to MAR, the warning light switches on but should switch off after a few seconds. If the warning light switches on constantly, this indicates a fault in the airbag system. On certain versions a dedicated message is displayed.  37) 38)


WARNING

37) If, when turning the key to MAR, the  warning light does not switch on or if it stays on when travelling, there could be a fault in the restraint systems; in this event airbags or pretensioners may not be deployed in the event of impact or, in a lower number of cases, they may deploy accidentally. Contact a Fiat Dealership immediately to have the system checked.

38) A failure of the  warning light is indicated by the  warning light flashing. In this case, any faults of the airbag system might be not signalled. Before continuing, contact a Fiat Dealership immediately to have the system checked.



Warning light	What it means
	LOW BRAKE FLUID/HANDBRAKE ENGAGED When the ignition key is turned to MAR, the warning light switches on but should switch off after a few seconds. Low brake fluid level The warning light turns on when the level of the brake fluid in the reservoir falls below the minimum level, possibly due to a leak in the circuit. On certain versions a dedicated message is displayed.  39) Handbrake engaged The warning light switches on when the handbrake is engaged. If the vehicle is moving a buzzer will also sound. IMPORTANT If the warning light turns on when travelling, check that the handbrake is not engaged.
	LOW BATTERY CHARGE (for versions/markets, where provided) The warning light comes on when the ignition key is turned to MAR, but it should go out as soon as the engine has started (with the engine running at idle speed a brief delay before going out is acceptable). If the warning light stays on constantly or flashing, on some versions along with a dedicated message on the display, contact a Fiat Dealership.
	DOORS/BONNET/LUGGAGE COMPARTMENT OPEN The warning light switches on, on some versions along with a message and a symbol in the display, when one or more doors, the bonnet or the tailgate are not properly closed. An acoustic signal is activated with the doors open and the car moving.



WARNING

39) If the (⚠) warning light switches on when travelling, stop the car immediately and contact a Fiat Dealership.

Warning light	What it means
	INSUFFICIENT ENGINE OIL/PRESSURE When the ignition key is turned to MAR the warning light switches on, but should switch off as soon as the engine is started. Low engine oil pressure The warning light turns on constantly, on some versions along with a dedicated message on the display, when the system detects that engine oil pressure is insufficient.  40)


WARNING

40) If the  warning light switches on when travelling (on certain versions together with the message on the display), stop the engine immediately and contact a Fiat Dealership.



Warning light	What it means
	Engine oil degraded (diesel versions with DPF) The warning light comes on flashing, on some versions along with a dedicated message on the display. The warning light flashes for 3 minute cycles with the warning light off for intervals of 5 seconds until oil is changed. After the initial warning, each time the engine is started up, the warning light will continue to flash in the same mode, until the oil is changed. On certain versions a dedicated message is displayed. The flashing of the warning light should not be considered as a fault, it simply informs the customer that the oil needs to be changed following normal car use. Remember that the deterioration of the engine oil is accelerated by: ☐ mainly town use of the vehicle which makes the DPF regeneration process more frequent; ☐ use of the vehicle for short drives, in which the engine does not have time to reach its regular operating temperature; ☐ repeated interruptions to the regeneration process signalled by the DPF warning light coming on.  41)



WARNING

41) *If the warning light switches on, the deteriorated engine oil must be changed as soon as possible, and never more than 500 km from the first time that the warning light switches on. Failure to observe the above may result in severe damage to the engine and invalidate the warranty. Remember that the operation of this warning light is not related to the amount of oil in the engine. Therefore, never top up with oil when the light starts flashing.*

Warning light	What it means
	ENGINE COOLANT TEMPERATURE TOO HIGH The warning light switches on when the ignition key is turned to MAR, but it should switch off after a few seconds. The warning light comes on, on some versions along with a message on the display, when the engine is overheated. In normal driving conditions: stop the car, switch off the engine and check that the water level in the reservoir is not below the MIN mark. In this case, wait for the engine to cool down, then slowly and carefully open the cap, top up with coolant and check that the level is between the MIN and MAX marks on the reservoir itself. Also check visually for any fluid leaks. If, when restarting, the warning light switches on again, contact a Fiat Dealership. If the car is used under demanding conditions (e.g. towing trailers uphill or fully loaded): slow down and, if the warning light stays on, stop the car. Wait for 2 or 3 minutes with the engine running and slightly accelerated to further favour the coolant circulation. Then stop the engine. Check that the coolant level is correct as described above. IMPORTANT Over demanding routes, it is advisable to keep the engine on and slightly accelerated for a few minutes before switching it off.
	“DUALDRIVE” ELECTRIC POWER STEERING FAILURE When the key is turned to MAR, the warning light switches on but it should switch off after a few seconds. If the warning light stays on, on some versions along with a dedicated message on the display, you may not have steering assistance and the effort required to operate the steering wheel could be notably increased; steering is, however, possible. In this case, contact a Fiat Dealership. IMPORTANT In some circumstances, factors independent of the electric power steering could cause the warning light on the instrument panel to switch on. In this case, stop the car immediately (should it be in motion), stop the engine for about 20 seconds and then restart the engine. If the warning light, on some versions along with a dedicated message on the display, remains on, contact a Fiat Dealership. IMPORTANT After the battery is disconnected, the steering must be initialised. The warning light switches on to indicate this. To carry out this procedure, simply turn the steering wheel all the way from one end to the other or drive in a straight line for about a hundred metres.



Warning light	What it means
	"DUALOGIC" GEARBOX FAILURE When the ignition key is turned to MAR, the warning light switches on but should switch off after a few seconds. The warning light comes on flashing, along with a dedicated message on the display and an acoustic signal, to indicate gearbox failure.  25)

	WARNING
25) <i>If the gearbox is faulty, contact a Fiat Dealership as soon as possible to have the system checked.</i>	

Warning light	What it means
	ABS FAILURE The warning light switches on when the ignition key is turned to MAR, but it should switch off after a few seconds. The warning light comes on, on some versions along with a message on the display, when the system is inefficient. In this case the braking system maintains its efficiency unaltered but without the advantage of the ABS system. Drive carefully and contact a Fiat Dealership as soon as possible.
	PASSENGER AIRBAG/SIDE BAGS DEACTIVATED The warning light is located on the dashboard in central position and switches on deactivating the front passenger airbag and the side airbag. With front passenger airbag on, when the ignition key is turned to MAR, the warning light switches on constantly for several seconds and then it should switch off.  42)



WARNING

42) A failure of the  warning light is indicated by the  warning light switching on. In addition, the airbag system automatically disables the airbags on the passenger's side (front and side bags where provided). Before continuing, contact a Fiat Dealership immediately to have the system checked.



Warning light	What it means
	City Brake Control - "Collision Mitigation" SYSTEM DEACTIVATED (for versions/markets, where provided) The warning light switches on when the City Brake Control - "Collision Mitigation" system is deactivated through the Setup Menu.
	INJECTION/EOBD SYSTEM FAILURE In normal conditions, when the ignition key is turned to MAR the warning light switches on, but it should switch off as soon as the engine is started. If the warning light remains on or switches on whilst driving, the injection system is not working properly; in particular, if the warning light switches on steadily, this indicates a malfunction in the supply/ignition system that could cause excessive exhaust emissions, a possible loss of performance, poor driveability and high fuel consumption. Under these conditions, the vehicle can continue travelling at moderate speed without demanding excessive effort from the engine. Prolonged use of the vehicle with the warning light on constantly may cause damage: contact a Fiat Dealership as soon as possible. The warning light switches off if the malfunction disappears, but is still stored by the system. NOTE For petrol engines, if the warning light flashes, the catalytic converter may be damaged. In this case, it is necessary to release the accelerator pedal to lower the speed of the engine until the warning light stops flashing; continue the journey at moderate speed, trying to avoid driving conditions that may cause further flashing and contact a Fiat Dealership as soon as possible.  26)



WARNING

26) Go to a Fiat Dealership as soon as possible if the  warning light either does not light up when the key is turned to MAR or if, while travelling, the warning light switches on or flashes (along with a message and a symbol on the display on some versions). The operation of the  warning light may be checked by the traffic police using specific devices. Comply with the laws and regulations of the country where you are driving.

Warning light	What it means
	ESC SYSTEM (for versions/markets, where provided) The warning light switches on when the ignition key is turned to MAR, but it should switch off after a few seconds. If the warning light does not switch off or stays on while driving, on some versions along with a message on the display, contact a Fiat Dealership. Flashing of the warning light while driving indicates the intervention of the ESC system.
	Hill Holder failure This warning light switches on, on some versions along with a dedicated message on the display, in the case of a Hill Holder system fault. In this case, contact a Fiat Dealership.
	ELD system failure (For versions/markets, where provided) This warning light switches on, on some versions along with a dedicated message on the display, in the case of an ELD system failure. In this case, contact a Fiat Dealership as soon as possible.
	FIAT CODE SYSTEM FAILURE The warning light (or the symbol on the display) switches on, on some versions along with a dedicated message on the display, to signal the Fiat CODE system failure. In this case, contact a Fiat Dealership as soon as possible.



Warning light	What it means
	GLOW PLUG HEATING/GLOW PLUG HEATING FAILURE (diesel versions) Plug preheating This warning light switches on when the key is turned to MAR. It should switch off as soon as the heater plugs have reached a preset temperature. The engine can be started as soon as the warning light switches off. IMPORTANT At moderate or high ambient temperatures the warning light may stay on for an extremely short time. Heater plug preheating failure The warning light will flash, on some versions along with a dedicated message on the display, to indicate a fault in the plug preheating system. Contact a Fiat Dealership as soon as possible to have the fault fixed.
	FUEL RESERVE - LIMITED RANGE This warning light switches on when 5 to 7 litres of fuel are left in the tank. When the remaining range is lower than approx. 50 km (or equivalent value in miles), on some versions, the display will show a dedicated message. IMPORTANT The warning light will flash to indicate a system fault. If this is the case, go to a Fiat Dealership to have the system checked.
	REAR FOG LIGHT The warning light switches on when the rear fog light is activated.

Warning light	What it means
	DPF (PARTICULATE FILTER) CLEANING IN PROGRESS (Diesel versions with DPF) When the ignition key is turned to MAR, the warning light switches on but should switch off after a few seconds. The warning light switches on constantly, on some versions along with a dedicated message on the display, to notify the driver that the DPF system needs to eliminate captured pollutants (particulate) through the regeneration process. The warning light does not come on every time the DPF is being regenerated, rather only when the driving conditions are such that the driver needs to know it. To switch the warning light off, the vehicle must be kept moving until the regeneration process is completed. On average, the process lasts 15 minutes. Optimal conditions for completing the process are achieved by travelling at 60 km/h with engine speed above 2000 rpm. If this light switches on, it does not mean that the vehicle is defective, so there is no need to take it to a workshop.  43)


WARNING

43) *The driving speed must always be suitable for traffic and weather conditions and the driver must always comply with the Highway Code. The engine can also be switched off if the DPF warning light is on; nevertheless, repeated interruptions of the regeneration process could cause an early deterioration of engine oil. For this reason, always wait until the warning light switches off before stopping the engine as described above. Do not complete the DPF regeneration process when the vehicle is stopped.*



Warning light	What it means
	GENERAL FAILURE INDICATION (for versions/markets, where provided) The warning light turns on in the following circumstances.
	Speed limit exceeded (for versions/markets, where provided) The warning light switches on when the speed limit set in the Setup Menu is exceeded. When the vehicle exceeds this value, on some versions a dedicated message is shown in the display and an acoustic signal is emitted.
	Fuel cut-off system intervention/failure This warning light switches on, on some versions along with a dedicated message on the display, in the case of fuel cut-off system activation/failure.
	Start&Stop system failure (for versions/markets, where provided) The warning light comes on when a fault is detected in the Start&Stop system. In the event of a Start&Stop system failure, contact a Fiat Dealership.
	Temporary or permanent City Brake Control - "Collision Mitigation" system failure (for versions/markets, where provided) The warning light switches on, on some versions along with a message on the display, when a temporary or permanent City Brake Control - "Collision Mitigation" system fault is detected. If the fault is permanent: contact a Fiat Dealership to have the system checked.
	Airbag fault When this warning light starts flashing, for versions/markets where provided, this indicates an airbag warning light fault. In this case, the airbag may not indicate possible airbag system malfunctions. Contact a Fiat Dealership immediately.

Warning light	What it means
	Parking sensor failure (for versions/markets, where provided) The warning light switches on, on some versions along with a dedicated message on the display, when a fault is detected in the parking sensors.
	Exterior lights failure (for versions/markets, where provided) The warning light switches on when a fault is detected in one of the following lights: side lights, number plate lights, rear fog lights, direction indicators, daytime running lights (DRL).
	Engine oil pressure sensor failure (for versions/markets, where provided) The engine oil pressure sensor failure is indicated by the activation of the warning light on the instrument panel.
	ELD system fault (Panda Cross and Panda 4x4 versions) The warning light switches on, on some versions along with a dedicated message on the display, when a fault is detected in the 4x4 drive. Contact a Fiat Dealership as soon as possible.
	Water in diesel filter (diesel versions) (for versions/markets, where provided) The warning light switches on when the ignition key is turned to MAR, but it should switch off after a few seconds. The warning light switches on when water is detected in the diesel filter. On certain versions a dedicated message is displayed.  27)



WARNING

27) If the  warning light switches on (on some versions together with the dedicated message on the display), contact a Fiat Dealership as soon as possible to have the system bled. If the above indication occurs immediately after refuelling, water may have entered the tank: turn the engine off immediately and contact a Fiat Dealership.



Warning light	What it means
	iTPMS (for versions/markets, where provided) Tyre pressure low The warning light switches on constantly to indicate that the tyre pressure is lower than the recommended value, in order to guarantee long tyre life and low fuel consumption, or to indicate a slow loss of pressure. In this way the iTPMS warns the driver that one or more tyres may be flat and probably punctured. In this case it is advisable to restore the correct pressure value. Once the normal operating conditions of the vehicle are restored, carry out the Tyre reset procedure. IMPORTANT Do not continue driving with one or more flat tyres as handling may be compromised. Stop the vehicle, avoiding sharp braking and steering. iTPMS failure/iTPMS temporarily deactivated The warning light flashes for about 75 seconds and then stays on constantly (along with a dedicated message on the display) to indicate that the system is temporarily deactivated or faulty. The system goes back to normal operation when the operating conditions allow it. If this is not the case, carry out the Tyre reset procedure after restoring the normal operating conditions. If the malfunction warning persists, contact a Fiat Dealership as soon as possible.
	LPG FUEL RESERVE (for versions/markets, where provided) The warning light switches on when the residual quantity of LPG drops below 1/5 of the tank capacity. On certain versions a dedicated message is displayed.
	METHANE RESERVE (Natural Power versions) The warning light switches on when the residual quantity of Methane drops below 1/5 of the tank capacity. On certain versions a dedicated message is displayed.

Warning light	What it means
	ELD SYSTEM (Panda Cross and Panda 4x4 versions) The warning light on flashing indicates activation of the electronic locking differential (ELD) function.
	HDC SYSTEM (Panda Cross versions) The warning light on constantly, along with a dedicated message on the display, indicates activation of the HDC function. Deactivation of the function is signalled by flashing of the warning light, by an acoustic warning and by a dedicated message on the display.
	PETROL/LPG SWITCHING (for versions/markets, where provided) <i>Warning light on constantly:</i> petrol operation. <i>Warning light off:</i> LPG operation.
	PETROL/METHANE SWITCHING (for versions/markets, where provided) <i>Warning light on constantly:</i> petrol operation. <i>Warning light off:</i> Methane operation.
	FRONT FOG LIGHTS The warning light comes on when the front fog lights are turned on.
	SIDE LIGHTS AND DIPPED BEAM HEADLIGHTS/FOLLOW ME HOME Side lights and dipped beam headlights The warning light switches on when the side lights or dipped headlights are turned on. Follow Me Home The warning light comes on, on some versions along with a dedicated message on the display, when the "Follow me home" device is used.



Warning light	What it means
	LEFT DIRECTION INDICATOR The warning light turns on when the direction indicator control lever is moved downwards or, together with the right indicator, when the hazard warning light button is pressed.
	RIGHT DIRECTION INDICATOR The warning light turns on when the direction indicator control lever is moved upwards or, together with the left indicator, when the hazard warning light button is pressed.

Blue warning lights

Warning light	What it means
	MAIN BEAM HEADLIGHTS The warning light switches on when the main beam headlights are turned on.

Symbols and messages on the display

Symbol or message	What it means
	The symbol is displayed, along with a dedicated message, in the event of an LPG system failure. In this case, contact a Fiat Dealership as soon as possible, running on petrol.
	The symbol is displayed, along with a dedicated message, in the event of a methane supply system failure. In this case, contact a Fiat Dealership as soon as possible, running on petrol.

Symbol or message	What it means
	FUEL LEVEL SENSOR FAILURE The symbol appears and all the notches disappear in the event of fuel gauge sensor failure. Contact a Fiat Dealership as soon as possible.
START&STOP (For versions/markets, where provided)	The message is displayed when the Start&Stop system is activated/deactivated by pressing the  button in the central part of the dashboard. With the Start&Stop system on, the LED on the button is off; if the system is deactivated the LED comes on.
HDC (Panda Cross versions)	With the "HDC" on, the following messages can be displayed. ☐ HDC on ☐ HDC off ☐ HDC cannot be activated ☐ HDC off, wait for the brakes to cool down
SERVICE	When the next scheduled service is approaching, the word "Service" appears on the display, followed by the number of kilometres or miles left. This is displayed automatically, with ignition key at MAR-ON, 2000 km (or equivalent value in miles) before servicing or, where provided, 30 days before servicing. It is also displayed each time the key is turned to MAR-ON or, for versions/markets, where provided, every 200 km (or equivalent value in miles). Go to a Fiat Dealership, where the "Scheduled Servicing Plan" operations will be performed and the message will be reset.



Symbol or message	What it means
DUALOGIC GEARBOX	For versions equipped with "Dualogic" gearbox, the following messages can be displayed: ☐ Reduce gear changes ☐ Manual mode unavailable ☐ Automatic mode not available ☐ Clutch overheating ☐ Press the brake pedal ☐ Press the brake pedal - delayed start-up ☐ Gear not available ☐ Manoeuvre not allowed ☐ Press brake pedal and repeat manoeuvre ☐ Positioning of the gear lever at N (neutral).  28) 29)



WARNING

28) If the messages continue to be shown in the display, contact a Fiat Dealership.

29) In order to safeguard the efficiency of the clutch, do not use the accelerator to keep the car stationary (e.g. when stopped on an incline); if the clutch overheats it could damage it; use the brake pedal instead and only use the accelerator pedal when you decide to set off.

SAFETY

The chapter that you are about to read is very important: it describes the safety systems with which the vehicle is equipped and provides instructions on how to use them correctly.

ACTIVE SAFETY SYSTEMS	60
DRIVING ASSISTANCE SYSTEMS ..	65
OCCUPANT PROTECTION SYSTEMS	69
SEAT BELTS	69
SBR (SEAT BELT REMINDER) SYSTEM	71
PRE-TENSIONERS	72
CHILD PROTECTION SYSTEMS.....	74
SUPPLEMENTARY RESTRAINT SYSTEM (SRS) - AIRBAG.....	84



ACTIVE SAFETY SYSTEMS



ABS (Anti-lock Braking System)

This system, which is an integral part of the braking system, prevents one or more wheels from locking and slipping in all road surface conditions, irrespective of the intensity of the braking action, ensuring that the vehicle can be controlled even during emergency braking.

IMPORTANT To obtain the maximum efficiency of the braking system, a bedding-in period of about 500 km is needed: during this period it is better to avoid sharp, repeated and prolonged braking.

The ABS also includes the following systems: EBD (Electronic Braking Force Distribution), MSR (Motor Schleppmoment Regelung) and MBA (Mechanical Brake Assist) (for versions/markets, where provided).

System intervention

The driver can feel that the ABS system has come into action because the brake pedal pulsates slightly and the system gets noisier: this is entirely normal with the system operating.



44) 45) 46) 47) 48) 49) 50) 51) 52)

ESC SYSTEM (Electronic Stability Control)

(for versions/markets, where provided)

This is an electronic system that controls vehicle stability in the event of tyre grip loss, helping maintain directional control. The system is capable of recognising potentially dangerous situations in terms of the stability and intervenes automatically on the brakes in a differentiated manner for the four wheels in order to provide a stabilising torque.

The ESC system switches on automatically when the engine is started and cannot be switched off.

System intervention

The intervention of the system is indicated by the flashing of the **ESC** warning light on the instrument panel, to inform the driver that the vehicle is in critical stability and grip conditions.



53) 54) 55) 56) 57) 58)

HH (Hill Holder) SYSTEM

This system is an integral part of the ESC system and facilitates starting on slopes.

It is automatically activated in the following conditions:

☐ *uphill*: vehicle stationary on a road with a gradient higher than 5%, engine running, brake pressed and transmission in neutral or gear other than reverse engaged;

☐ *downhill*: vehicle stationary on a road with a gradient higher than 5%, engine running, brake pressed and reverse gear engaged.

When setting off, the ESC system control unit maintains the braking pressure on the wheels until the torque necessary for starting is reached, or in any case for a maximum of 2 seconds, allowing your right foot to be moved easily from the brake pedal to the accelerator.

When two seconds have elapsed, without starting, the system is automatically deactivated, gradually releasing the braking pressure. During this release stage, the typical mechanical brake release noise can be heard, indicating that the vehicle is about to move.

NOTE: the Hill Holder system is not active with parking brake engaged.

IMPORTANT The Hill Holder system is not a parking brake, therefore do not leave the vehicle without activating the handbrake, switching off the engine, and engaging first gear, with the vehicle parked in safe conditions.

ASR (AntiSlip Regulation) SYSTEM


It is an integral part of the ESC system. It is automatically activated in the case of drive wheels slipping, loss of grip on wet roads (aquaplaning) and acceleration on slippery, snowy or icy roads, etc. Depending on the slipping conditions, two different control systems are activated:

- ❑ if the slipping involves both drive wheels, the ASR intervenes reducing the power transmitted by the engine;
- ❑ if the slipping only involves one of the drive wheels, it intervenes automatically braking the wheel that is slipping.

Engagement/disengagement of the ASR system

The ASR system switches on automatically each time the engine is started.

Whilst driving, the ASR can be switched off and subsequently switched on again by pressing the ASR OFF button fig. 47.



47

F1D0038

On some versions, the intervention of the system is indicated by a dedicated message shown on the display. When the system is not active, the LED on the button ASR OFF turns on and, on some versions, a message appears on the display.

When the ASR is deactivated whilst driving, the next time the vehicle is started the ASR is automatically activated.

When travelling on snowy roads with snow chains, it may be helpful to turn the ASR off: in fact, in these conditions, the driving wheels skidding when setting off gives you better traction.

⚠ 59) 60) 61) 62) 63)

HBA (Hydraulic Brake Assist) SYSTEM

The HBA system is designed to improve the vehicle's braking capacity during emergency braking. The system detects an emergency braking by monitoring the speed and strength with which the brake pedal is pressed, thereby applying the optimal brake pressure.

This can reduce the braking distance: the HBA system therefore completes the ABS.

Maximum assistance from the HBA system is obtained by pressing the brake pedal very quickly. In addition, the brake pedal must be pressed continuously during braking, avoiding intermittent presses, to benefit from the system.

Do not reduce pressure on the brake pedal until braking is not necessary anymore.

The HBA system is deactivated when the brake pedal is released.

⚠ 64) 65) 66)



ELD (Electronic Locking Differential) SYSTEM

(Panda Cross and Panda 4x4 versions)


The ELD system allows the drive force to be evenly distributed over the same axle when one or both wheels are slipping. The ELD acts by braking the wheels with poor grip (or those slipping more than the others), thereby transferring the drive force to those which have greater grip on the ground. The system operates at speeds below 50 km/h. Above this speed, it is automatically deactivated and it is reactivated when the speed falls below 50 km/h.

The activation of the ELD system involves the following functions being switched on:

- ☐ inhibition of the ASR function, in order to fully exploit the engine torque;
- ☐ differential lock effect on the front and rear axles, via the braking system, to improve drive on uneven surfaces.


Enabling the system

To arrange operation of the ELD system press button A fig. 48 (4x4 versions) or turn the ring nut fig. 49 to the right (Cross versions) and keep it in this position until LED 2 on the selector lights up.



48

F1D0122



49

F1D0116

System intervention

The  warning light on the instrument panel flashes to signal that the system has intervened.

If the space-saver wheel is used

If the space-saver wheel is used, the control unit for 4x4 drive detects its presence (via the wheel speed signals) and reduces the intervention of the four-wheel drive mode to a minimum, while guaranteeing the agility of the vehicle. No fault/alarm signal is displayed on the instrument panel or on the display.

Disabling the system

To disable the system, press button A fig. 48 (4x4 versions) or turn the ring nut fig. 49 to the left (Cross versions) and keep it in this position until LED 1 on the selector lights up.

HDC (Hill Descent Control) SYSTEM

(Panda Cross versions)


It is an integral part of the ESC system and is aimed at keeping the vehicle at a constant speed during a descent, operating autonomously on the brakes in various ways at the same time. In this way the HDC function helps the driver when facing steep gradient roads in low-grip and/or rough ground conditions.

Noise and vibrations coming from the wheel sides (brakes) when the HDC system is activated are normal.

IMPORTANT The system does not relieve the driver of the responsibility of controlling the vehicle and does not replace attention while driving. The driver of the vehicle takes the complete responsibility for the consequences of their actions and of an incorrect and not responsible use of the vehicle.

Enabling the system

To arrange operation of the HDC system, turn ring nut fig. 50, with LED 2 on, to the right, and keep it in this position until LED 3 on the selector lights up. The  warning light comes on in the instrument panel and the dedicated message is displayed.



50

F1D0116

IMPORTANT System intervention set-up can be engaged only with "Off Road" mode activated.

System intervention

To activate the system reach a speed slower than 25 km/h. After reaching the desired speed, release the accelerator and brake pedals completely. If you want to increase/decrease the speed, press the accelerator/brake pedals again.

IMPORTANT The system is also available for very low speeds between 5 km/h and 9 km/h, but in this interval the gearbox must be set to neutral to prevent engine stalling.

IMPORTANT For speeds above 9 km/h, the HDC system must be used with a gear that is suitable for the set speed, in order to prevent possible engine stalling. While the HDC system is operating it is also possible to take control of the vehicle again by pressing the brake and accelerator pedals. If the HDC is not available when system intervention set-up is engaged, this could be due to brake overheating. In this case, wait for a few minutes.

IMPORTANT The system is available for speeds between 5 km/h and 25 km/h. It is advisable to use the system with low gears (first, second and third).

IMPORTANT On level ground in urban areas it is advisable to deactivate the HDC system intervention set-up, since for speeds below 25 km/h in some usage conditions, such as when setting off, gearshifting and driving over road humps without using the accelerator pedal, the system might activate.

Disabling the system

To deactivate the system, turn the ring nut fig. 50 to the left, keeping it in this position until LED 3 on the selector switches off.

IMPORTANT If the braking system overheats the system will deactivate through a gradual release of the braking pressure, leaving vehicle control to the driver. Deactivation of the HDC system is accompanied by flashing of the , by a dedicated message on the display and an acoustic warning. To reactivate the system intervention set-up wait for the system to cool down and turn the ring nut again.



IMPORTANT If the speed exceeds 25 km/h and is below 50 km/h, the HDC system intervention set-up is deactivated but is ready for being reactivated when the speed drops back below 25 km/h. In this case the indication on the instrument panel turns off and the LED on the ring nut stays on. If vehicle speed exceeds 50 km/h, the HDC system completely deactivates and each individual action made by the system on the brakes is blocked. To reactivate it, turn the ring nut again when the speed is again below 25 km/h.



WARNING

44) *The ABS exploits the grip available to the full, but it cannot improve it. Therefore, you should take great care when driving on slippery surfaces, without taking unnecessary risks.*

45) *When the ABS cuts in and you feel the brake pedal pulsating, do not raise your foot, but keep it pressed; in doing so you will stop in the shortest amount of space possible depending on the current road conditions.*

46) *If the ABS intervenes, this indicates that the grip of the tyres on the road is nearing its limit. You must slow down to a speed compatible with the available grip.*

47) *For maximum efficiency of the braking system, a bedding-in period of about 500 km is required: during this period it is advisable to avoid sharp, repeated and prolonged braking.*

48) *The ABS cannot alter the natural laws of physics, and cannot increase grip which depends on the condition of the road.*

49) *The ABS cannot prevent accidents, including those due to excessive speed on corners, driving on low-grip surfaces or aquaplaning.*

50) *The capability of the ABS must never be tested irresponsibly and dangerously, in such a way as to compromise personal safety and the safety of others.*

51) *For the correct operation of the ABS, the tyres must of necessity be the same make and type on all wheels, in perfect condition and, above all, of the prescribed type and dimensions.*

52) *When the Mechanical Brake Assist intervenes, noises may be heard from the system. This is normal. In any case, keep the brake pedal firmly depressed while braking.*

53) *For the correct operation of the ESC system, the tyres must of necessity be the same make and type on all wheels, in perfect condition and, above all, of the prescribed type and size.*

54) *The ESC functions even when the space-saver wheel is being used. Always remember that the space-saver wheel, being smaller than the original wheel, provides less grip.*

55) *Do not take unnecessary risks, even if your vehicle is fitted with an ESC system. Your driving style must always be suited to the road conditions, visibility and traffic. The driver is always responsible for road safety.*

56) *The ESC system cannot alter the natural laws of physics, and cannot increase grip which depends on the condition of the road.*

57) *The ESC system cannot prevent accidents, including those due to excessive speed on corners, driving on low-grip surfaces or aquaplaning.*

58) *The capability of the ESC system must never be tested irresponsibly and dangerously, in such a way as to compromise personal safety and the safety of others.*

59) *For the correct operation of the ASR system, the tyres must of necessity be the same make and type on all wheels, in perfect condition and, above all, of the prescribed type and size.*

60) *Do not take unnecessary risks, even if your vehicle is fitted with an ASR system. Your driving style must always be suited to the road conditions, visibility and traffic. The driver is ultimately responsible for road safety.*

61) *The ASR system cannot alter the natural laws of physics, and cannot increase grip which depends on the condition of the road.*

62) *The ASR system cannot prevent accidents, including those due to excessive speed on corners, driving on low-grip surfaces or aquaplaning.*

63) The capability of the ASR system must never be tested irresponsibly and dangerously, in such a way as to compromise personal safety and the safety of others.

64) The HBA system cannot increase tyre grip on the road over the limits imposed by laws of physics: always drive carefully according to the conditions of the road surface.

65) The HBA system cannot prevent accidents, including those due to excessive speed on bends, travelling on low-grip surfaces or aquaplaning.

66) The HBA system is an aid for the driver, who must always pay full attention while driving. The responsibility always rests with the driver. The features of the HBA system must never be tested in imprudent or dangerous ways, with the possibility of putting the safety of the driver, occupants or other road users at risk.

DRIVING ASSISTANCE SYSTEMS

CBC (City Brake Control) SYSTEM - "Collision Mitigation"

(for versions/markets, where provided)



67) 68) 69) 70) 71)



30) 31) 32) 33) 34) 35) 36)

This is a driving assistance system, which includes a laser sensor, located in the upper part of the windscreen fig. 51, that can detect the presence of nearby cars in front of the vehicle and, in the case of an imminent collision, intervenes automatically, braking the vehicle to prevent the impact or mitigate its effects.



51

F1D0041

The system only works if:

- ☐ the ignition key is at MAR;
- ☐ the vehicle speed is between 5 and 30 km/h;

☐ the front seat belts are fastened. Anyway, the system can be deactivated (then reactivated) through the Setup Menu on the display.

The system intervenes if there is risk of imminent collision and the driver does not press the brake pedal promptly. If the system detects that the vehicle ahead could be hit, it may prepare the vehicle to a possible emergency braking.

If the driver does not carry out any action to prevent the collision, the system may automatically slow down the vehicle, in order to prepare it to a possible impact.

When there is risk of impact, if the action on the brake pedal by the driver is not sufficient, the system may intervene in order to improve the reaction of the braking system, therefore reducing vehicle speed further.

When driving uphill on a steep slope, the system may intervene, activating the braking system.

Versions equipped with Start&Stop

system: at the end of the automatic braking, the Start&Stop system will activate as described in the "Start&Stop system" paragraph of the "Starting and driving" chapter.



Versions equipped with manual gearbox:

at the end of the automatic braking the engine may stall and turn off, unless the driver presses the clutch pedal.

Versions equipped with "Dualogic" gearbox

(for versions/markets, where provided): at the end of braking the last gear stored remains engaged.

IMPORTANT Both on versions equipped with manual gearbox and on those with "Dualogic" gearbox (for versions/markets, where provided), after the vehicle is stopped the brake calipers may be stuck for about 2 seconds for safety reasons. Make sure you press the brake pedal if the vehicle moves slightly forwards.

IMPORTANT The system does **NOT** activate when reverse is engaged. The system does **NOT** activate if the front seat belts are not fastened.

Engagement/disengagement


The system can be deactivated (then reactivated) through the Setup Menu on the display.

Driving in special conditions

In certain driving conditions, such as, for example:

- ❑ driving close to a bend (see fig. 52);
- ❑ vehicles with small dimensions and/or not aligned in the driving lane (see fig. 53);
- ❑ lane change by other vehicles (see fig. 54);


system intervention can be unexpected or delayed. The driver must therefore be very careful, keeping control of the vehicle to drive in complete safety.



52


F1D0042

IMPORTANT If you are driving on roads close to trees with protruding branches it is advisable to deactivate the system to prevent the branches at the height of the bonnet or the windscreen from interfering with the system.



53

F1D0043



54

F1D0044

iTPMS System (indirect Tyre Pressure Monitoring System)

(for versions/markets, where provided)

 72) 73) 74) 75) 76) 77)

The vehicle can be equipped with the iTPMS (indirect Tyre Pressure Monitoring System) which monitors the tyre inflation status thanks to wheel speed sensors.

The system warns the driver if one or more tyres are flat by the (!) warning light continuously lit on the instrument panel and a dedicated warning message on the display.

If one tyre only is flat, the system can indicate its position: it is in any case recommended to check the pressure on all four tyres.

This indication is displayed also when turning the engine off and on again until the RESET procedure is carried out.

Reset procedure

The iTPMS needs an initial "self-learning" phase (with length depending on the driving style and road conditions: optimal conditions being driving on a straight road at 80 km/h for at least 20 minutes) which starts when the Reset procedure is carried out.

The Reset procedure must be carried out:

- ❑ each time tyre pressure is modified;
- ❑ when even only one tyre is changed;
- ❑ when tyres are rotated/inverted;
- ❑ when the space-saver wheel is fitted.

Before carrying out the Reset procedure, inflate the tyres to the rated pressure values specified in the inflation pressure table (see "Wheels" paragraph in the "Technical specifications" chapter).

If the Reset procedure is not carried out, in all above cases, the (!) warning light may give false indications on one or more tyres.

To carry out the RESET procedure, with the vehicle stopped and the ignition device at MAR, use the Main Menu as follows:

- ❑ briefly press the  button: the display will show Reset;
- ❑ press the  button or the  button to select ("Yes" or "No");
- ❑ briefly press the  button: the display will show "Confirm";
- ❑ press  button or  to select ("Yes" to Reset or "No" to exit the video page);
- ❑ press the  button again to return to the standard screen or to the main menu according to where you are in the menu.

At the end of the Reset procedure the display will show the "Reset saved" message, indicating that the self-learning has been started.

Operating conditions

The system is active for speeds above 15 km/h.

In a few situations such as sporty driving, particular conditions of the road surface (e.g. icy, snowy, unsurfaced roads...) the signalling may be delayed or partial in detecting the contemporary deflation of more than one tyre.

Under special conditions (e.g. vehicle loaded asymmetrically on one side, towing a trailer, damaged or worn tyre, fitting the space-saver wheel, use of the "Fix&Go Airflat" kit, fitting snow chains, fitting different tyres on the axles) the system may give false indications or be temporarily deactivated.

If the system is temporarily deactivated, the warning light (!) flashes for about 75 seconds and then is continuously on; at the same time, the display shows a dedicated message.

This indication is displayed also after the engine has been switched off and then on again if the correct operating conditions are not restored.





WARNING

67) The system is an aid for the driver, who must always pay full attention while driving. The responsibility always rests with the driver, who must take into account the traffic conditions in order to drive in complete safety. The driver must always maintain a safe distance from the vehicle in front.

68) If the driver depresses the brake pedal fully or carries out a fast steering during system operation, the automatic braking function may stop (e.g. to allow a possible manoeuvre to avoid the obstacle).

69) The laser beam is not visible at the naked eye. Do not look directly, or with optical instruments (e.g. lenses), at the laser beam from a distance lower than 10 cm: this may cause damage to the sight. The laser beam is also present when the key is at MAR but its operation is off, not available or manually deactivated with the display Setup Menu.

70) The system intervenes on vehicles travelling in the same lane. Small sized vehicles (e.g. bicycles or motorbikes) or people, animals and things (e.g. pushchairs) and more in general all those obstacles with a low reflection of the light emitted by the laser (e.g. vehicles soiled with mud) are not taken into consideration.

71) If the car must be placed on a roller bench (at a speed within 5 and 30 km/h) for maintenance interventions or if it is washed in an automatic roller washing tunnel with an obstacle in the front part (e.g. another car, a wall or another obstacle), the system may detect its presence and activate. In this case the system must be deactivated through the display Setup Menu.

72) If the system signals a pressure decrease on a specific tyre, it is recommended to check the pressure on all four tyres.

73) The iTPMS does not relieve the driver from the obligation to check the tyre pressure every month; it is not to be considered a system to replace maintenance or a safety system.

74) Tyre pressure must be checked with tyres cold. Should it become necessary for whatever reason to check pressure with warm tyres, do not reduce pressure even though it is higher than the prescribed value, but repeat the check when tyres are cold.

75) The iTPMS cannot indicate sudden tyre pressure drops (for example when a tyre bursts). In this case, stop the vehicle, braking with caution and avoiding abrupt steering.

76) The system only warns that the tyre pressure is low: it is not able to inflate them.

77) Insufficient tyre inflation increases fuel consumption, reduces the tread duration and may affect the capacity to drive safely.



WARNING

30) The laser sensor may have limited or absent operation due to weather conditions such as: heavy rain, hail, thick fog, heavy snow, formation of ice layers on the windscreen.

31) Sensor operation may also be compromised by the presence of dust, condensation, dirt or ice on the windscreen, by traffic conditions (e.g. vehicles that are driving not aligned with you car, vehicle driving in a transverse or opposite way on the same lane, bend with a small radius of curvature), by road surface conditions and by driving conditions (e.g. off-road driving). Make sure the windscreen is always clean. Use specific detergents and clean cloths to avoid scratching the windscreen. The sensor operation may also be limited or absent in some driving, traffic and road surface conditions.

32) Projecting loads on the roof of the car may interfere with the correct operation of the sensor. Before starting make sure the load is correctly positioned, in order not to cover the sensor operating range.

33) If the windscreen must be replaced due to scratches, chipping or breakage, contact exclusively a Fiat Dealership. Do not replace the windscreen on your own, risk of malfunction! It is advisable to replace the windscreen if it is damaged in the laser sensor area.

34) Do not tamper nor operate on the laser sensor. Do not close the openings in the aesthetic cover located under the interior rear view mirror. In the event of a sensor failure, contact a Fiat Dealership.

35) Do not cover the operating range of the sensor with stickers or other objects. Also pay attention to other objects on the bonnet (e.g. a layer of snow) and make sure they do not interfere with the light emitted by the laser.

36) If a trailer or a vehicle is towed the system must be deactivated with the display Setup Menu.

OCCUPANT PROTECTION SYSTEMS

The most important safety equipment of the vehicle comprises the following protection systems:

- ☐ seat belts;
- ☐ SBR (Seat Belt Reminder) system;
- ☐ head restraints;
- ☐ child restraint systems;
- ☐ front airbags and side bags.

Read the information given the following pages with the utmost care. It is of fundamental importance that the protection systems are used in the correct way to guarantee the maximum possible safety level for the driver and the passengers.

For the description of the headrest adjustment see the "Headrests" paragraph in the "Knowing your vehicle" chapter.

SEAT BELTS

USING THE SEAT BELTS

All vehicle seats are equipped with seat belts with three anchor points and a retractor. The retractor mechanism operates locking the belt in the event of sharp braking or strong deceleration due to an impact. This allows the belt strap to slide freely and to adapt to the body of the occupant. In the event of an accident, the belt will lock reducing the risk of impact inside the passenger compartment and of being projected outside the vehicle.

The driver is responsible for respecting, and ensuring that all the other occupants of the vehicle also respect, the local laws in force in relation to the use of the seat belts.

Always fasten the seat belts before setting off.

The belt should be worn keeping the torso straight and rested against the backrest.


To fasten the seat belts, hold tongue A fig. 55 and insert it into buckle B, until it clicks into place. On removal, if the belt jams, let it rewind for a short stretch, then pull it out again without jerking.



To unfasten the seat belts, press button C. Guide the seat belt with your hand while it is rewinding, to prevent it from twisting. Through the retractor, the belt automatically adapts to the body of the passenger wearing it, allowing freedom of movement.



78)
The retractor may lock when the vehicle is parked on a steep slope: this is perfectly normal. Furthermore, the retractor mechanism locks the belt if it is pulled sharply or in the event of sudden braking, collisions and high-speed bends.




55

F1D0050

The rear seat is fitted with inertia seat belts with three anchor points and a retractor. Wear the rear seat belts as shown in fig. 56 (4-seater versions) or fig. 57 (5-seater versions).




79) 80) 81)



56

F1D0051



57

F1D0052


IMPORTANT When putting the back seat to its normal position, make sure the seat belts are positioned so they are ready to use.

ADJUSTING THE SEAT BELT HEIGHT

(for versions/markets, where provided)



82) 83)
Four different adjustments in height are provided. To adjust, press button A fig. 58 and raise or lower handle B. Always adjust the height of the seat belt to fit the person wearing it: this precaution could greatly reduce the risk of injury in the case of collision. Correct adjustment is obtained when the belt passes approximately half way between the shoulder and the neck.



58

F1D0053

For some versions, front seat belts have just one fixed anchor point located on the door pillar.



WARNING

78) Never press button C fig. 55 when travelling.

79) Remember that in the event of an accident, the rear seat passengers not wearing seat belts are exposed to a very serious risk and also represent a serious danger for the front seat occupants.

80) The rear central seat belt (for versions/markets where provided) is provided with a service buckle. Do not use the seat belt with the service buckle not fastened. In this case there is a high risk of injury or death in the event of an accident. Before using the belt, always make sure that the service buckle is correctly fastened.

81) The rear left and right side belts are provided with an adjustment device for the metal tongue position (metal hook). Adjust the tongue position with respect to the seat belt to improve comfort and reduce noise inside the passenger compartment.

82) Make height adjustment of the seat belts when the car is stationary.

83) After height adjustment, always check that the cursor to which the ring is fastened is locked in one of the preset positions. To do this, with button A fig. 58 released, exert further pressure downwards to allow the locking device to click if the grip has not been released in one of the possible positions.

SBR (Seat Belt Reminder) SYSTEM


The SBR system warns the passengers of the front and rear (for versions/markets, where provided) seats if their seat belt is not fastened.

The system signals unfastened seat belts with visual warnings (warning lights on in the instrument panel and icons on the display) and an acoustic signal (see the following paragraphs). Contact a Fiat Dealership to deactivate this acoustic warning permanently. The acoustic warning can be reactivated at any time through the display Setup Menu.

Seat belts warning light operation

The icons shown on the display fig. 59 indicate:

- ☐ **1:** front left seat belt;
- ☐ **2:** rear left seat belt;
- ☐ **3:** rear central seat belt;
- ☐ **4:** rear right seat belt;
- ☐ **5:** front right seat belt;
- ☐ **A:** seat belt not fastened;
- ☐ **B:** seat belt fastened;



59

F1D0054



With driver and/or passenger side (with passenger present) seat belts unfastened, when 20 km/h are exceeded or when travelling at a speed between 10 and 20 km/h for longer than 5 seconds, an acoustic signal cycle will be started for the front seats (continuous acoustic signal for 6 seconds followed by a 90 second beep) and the warning light will flash.

Once the cycle is complete, the warning lights stay on with a fixed light until the vehicle is turned off or the seat belt fastened.

If the seat belt is unfastened again while travelling, the acoustic warning restarts as described previously and the  icon is displayed.

For the rear seats, the reminder cycle is only activated when any seat belt is unfastened together with an acoustic warning (three beeps). If the condition of any (front or rear) seat belt changes, also the condition of the other (front/rear) seat belts is reported.

The visual indication (display of the  icon) will start and stop independently for each warning light if several seat belts are unfastened.

The visual indication will change condition (display of the  icon) after the corresponding seat belt has been fastened again.

IMPORTANT When the ignition key is turned to MAR, if all the front and rear belts are already fastened the  warning lights will be displayed for 30 seconds.

PRE-TENSIONERS



84) 85) 86) 87)



37)

The vehicle is equipped with front seat belt pretensioners, which draw back the seat belts by several centimetres in the event of a strong frontal impact. This guarantees the perfect adherence of the seat belts to the occupant's bodies before the retention action begins.

It is evident that the pretensioners have operated when the belt withdraws towards the retractor. This vehicle is also equipped with a second pretensioner (in the kick plate area). Its activation is signalled by the shortening of the metal cable.

A slight discharge of smoke may be produced during the activation of the pretensioner which is not harmful and does not involve any fire hazard.

The pretensioner does not require any maintenance or lubrication. Anything that modifies its original conditions invalidates its efficiency.

If, due to unusual natural events (floods, sea storms, etc.), the device has been affected by water and/or mud, contact a Fiat Dealership to have it replaced.

IMPORTANT To obtain the highest degree of protection from the action of the pretensioner, wear the seat belt tight to the chest and pelvis.

LOAD LIMITERS

To increase occupant safety, the retractors contain a load limiter to dose the force acting on the chest and shoulders during the belt restraining action in the case of frontal collisions.

GENERAL INSTRUCTIONS FOR USING THE SEAT BELTS


Seat belts are also to be worn by pregnant women: the risk of injury in the case of impact is greatly reduced for them and the unborn child if they are wearing a seat belt. Pregnant women must position the lower part of the belt very low down so that it passes over the pelvis and under the abdomen (see fig. 60). While pregnancy increases, the driver must adjust both seat and steering wheel to have full control over the vehicle (pedals and steering wheel should be easily accessed). The maximum clearance should be kept between the abdomen and the steering wheel.



60

F1D0123

The seat belt must not be twisted. The upper part must pass over the shoulder and cross the chest diagonally. The lower part must adhere to the pelvis (as shown in fig. 61) rather than the abdomen of the occupant. Do not use devices (clips, etc.) to hold the seat belt away from your body.



61

F1D0124

Each seat belt must be used by only one person. Never travel with a child sitting on the passenger's lap and a single belt to protect them both fig. 62. In general, do not place any objects between the person and the belt.



62

F1D0125

SEAT BELTS MAINTENANCE

For keeping the seat belts in efficient conditions, carefully observe the following warnings:

- ☐ always use the seat belt with the strap well stretched and not twisted; make sure that it is free to run without obstructions;
- ☐ check seat belt operation as follows: attach the seat belt and pull it hard;
- ☐ replace the belt after an accident of a certain severity even if it does not appear to be damaged. Always replace the seat belt if the pretensioners were deployed;



- ❑ prevent the retractors from getting wet: their correct operation is only guaranteed if water does not get inside;
- ❑ replace the seat belt when it shows wear or cuts;
- ❑ to clean the belt, wash by hand with water and neutral soap, rinse and leave to dry in the shade. Do not use strong detergents, bleach, paints or any other chemical substance which could damage the belt fibres.



WARNING

84) *The pretensioner may be used only once. Contact a Fiat Dealership to have it replaced after it has been deployed.*

85) *For maximum safety, keep the backrest upright, lean back into it and make sure the seat belt fits closely across your chest and pelvis. Always fasten the seat belts on both the front and the rear seats! Travelling without wearing seat belts will increase the risk of serious injury and even death in the event of an accident.*

86) *Removing or tampering with seat belt and pretensioner components is strictly prohibited. Any intervention on these components must be performed by qualified and authorised technicians. Always go to a Fiat Dealership.*

87) *If the belt has been sharply pulled, for example as the result of an accident, the seat belt, together with the anchoring devices, the anchoring device fixing screws and the pretensioner must be completely replaced. Even if the belt does not present any exterior signs of wear or damage, it may have lost its restraining properties.*



WARNING

37) *Operations which lead to impacts, vibrations or localised heating (over 100°C for a maximum of six hours) in the area around the pretensioner may cause damage or make it deploy. Contact a Fiat Dealership should intervention be necessary on these components.*

CHILD PROTECTION SYSTEMS

CARRYING CHILDREN SAFELY

88) 89) 90) 91)

For optimal protection in the event of an impact, all occupants must be seated and wearing adequate restraint systems, including newborn and other children! This prescription is compulsory in all EC countries according to EC Directive 2003/20/EC. Children below the height of 1.50 metres and up to 12 years must be protected with suitable restraint systems and be seated on the rear seats.

Statistics on accidents indicate that the rear seats offer greater safety for children.

Compared with an adult, a child's head is larger and heavier in proportion to their body and the child's muscular and bone structures are not fully developed. Therefore, correct restraint systems other than adult seat belts are necessary to reduce as much as possible the risk of injuries in the event of an accident, braking or sudden manoeuvre.

Children must be seated safely and comfortably. Depending on the characteristics of the child restraint systems used, you are advised to keep children in rearward facing child restraint systems for as long as possible (at least until 3-4 years old), since this is the most protected position in the event of an impact. The choice of the most suitable child restraint system depends on the weight and size of the child. There are various types of child restraint systems, which can be secured to the vehicle by means of the seat belts or with the ISOFIX anchorages.

It is recommended to always choose the restraint system most suitable for the child; for this reason always refer to the Owner Handbook provided with the child restraint system, to be sure that it is of the right type for the children it is intended for.


In Europe the characteristics of child restraint systems are ruled by the regulation ECE-R44, dividing them into five weight groups:

Group	Weight groups
Group 0	up to 10 kg in weight
Group 0+	up to 13 kg in weight
Group 1	9 - 18 kg
Group 2	15 - 25 kg
Group 3	22 - 36 kg

All restraint devices must bear the certification data, together with the control mark, on a label solidly fixed to the child restraint system which must never be removed.

Lineaccessori MOPAR® includes child restraint systems for each weight group. These devices are recommended having been specifically designed for Fiat vehicles.

**FITTING A CHILD
RESTRAINT SYSTEM
WITH SEAT BELTS**



The Universal child restraint systems installed with the seat belts only are type-approved on the basis of the ECE R44 standard and are divided into various weight groups.

IMPORTANT The figures are indicative and provided for assembly purposes only. Fit the child restraint system according to the instructions, which must be included.

IMPORTANT Following an accident of a certain importance, it is recommended to replace both the child restraint system and the seat belt to which it was bound.

Group 0 and 0+

Babies up to 13 kg must be carried with a rear facing child restraint system of a type as shown in fig. 63 which, supporting the head, does not induce stress on the neck in the event of sudden decelerations.

The child restraint system is secured by the vehicle seat belts, as shown in fig. 63 and it must restrain the child in turn with its own belts.

0-13 kg




63

F1D0055



Group 1

Children weighing from 9 to 18 kg may be transported in forward facing child restraint systems fig. 64.

9-18 kg

64


F1D0056

Group 2

Children from 15 to 25 kg may use the vehicle seat belts directly fig. 65. In this case, the child restraint system is used to position the child correctly with respect to the seat belts so that the diagonal belt section crosses the child's chest and not the neck, and the lower part is snug on the pelvis not the abdomen.


Group 3

For children between 22 kg and 36 kg, there are boosters which allow the seat belt to be worn correctly. The fig. 66 shows the correct child positioning on the rear seat.

15-25 kg

65

F1D0057

22-36 kg

66

F1D0058

Children over 1.50m in height can wear seat belts like adults.

PASSENGER SEAT COMPLIANCE WITH REGULATIONS ON UNIVERSAL CHILD RESTRAINT SYSTEM USE

The car complies with the new European Directive 2000/3/EC which governs the arrangement possibilities for child restraints on the various seats of the car as shown in the following table:

Group	Weight groups	Front passenger's seat(*)		Rear central passenger (for versions/markets, where provided)	Rear side passengers
		Airbag enabled	Airbag disabled		
Group 0	up to 10 kg	X	U	X	U
Group 0+	up to 13 kg	X	U	X	U
Group 1	9-18 kg	X	U	X	U
Group 2	15-25 kg	U	U	X	U
Group 3	22-36 kg	U	U	X	U

X= Seat not suitable for children in this weight category

U= Suitable for child restraint systems in the "Universal" category, according to European Regulation EEC-R44 for the specified "Groups".

(*) IMPORTANT: NEVER fit a rearward-facing child seat in the front passenger seat if the airbag is active. If you wish to fit a rearward-facing child seat in the front passenger seat, first deactivate the relative airbag (see instructions in the paragraph (Supplementary protection system (SRS) – Airbag))



INSTALLING AN ISOFIX CHILD CARSEAT




95) 96) 97) 98)

The outer rear seats of the vehicle are equipped with ISOFIX anchorages, a European standard which makes fitting a child restraint system quick, simple and safe.

The ISOFIX system lets you install the ISOFIX child restraining system without using the car seat belts but connecting them directly to the carseat with three anchors in the car. Traditional child restraint systems can be fitted alongside ISOFIX child restraint systems on different seats in the same vehicle. To install an ISOFIX child restraint system, attach it to the two metal anchorages A fig. 67 located where the rear seat cushion meets the backrest, then fix the upper strap (available together with the restraint system) to the dedicated anchorage B fig. 68 located at the bottom behind the backrest.


As an example, fig. 69 shows an example of a Universal ISOFIX child restraint system for weight group 1.

IMPORTANT The fig. 69 is indicative and for assembly purposes only. Fit the child restraint system according to the instructions, which must be included.



67


F1D0060



68

F1D0061

IMPORTANT Following an accident of a certain importance, it is recommended to replace both the child restraint system and the Isofix anchoring devices.



69

F1D0059

SUITABILITY OF PASSENGER SEATS FOR ISOFIX CHILD RESTRAINT SYSTEM USE

The table below shows the various installation possibilities for ISOFIX child restraint systems on seats fitted with the specific anchorages in accordance with European standard ECE 16.

Weight group	Child restraint system position	Isofix size class	Rear side Isofix positions
Group 0 up to 10 kg	Rear facing	E	IL (*)
	Rear facing	E	IL (*)
Group 0+ up to 13 kg	Rear facing	D	IL (*)
	Rear facing	C	X
	Rear facing	D	IL (*)
	Rear facing	C	X
Group 1 from 9 up to 18 kg	Forward facing	B	IUF-IL
	Forward facing	B1	IUF-IL
	Forward facing	A	IUF-IL

IL: suitable for ISOFIX child restraint systems specific and approved for this type of vehicle.

(*): the Isofix child restraint system can be installed by adjusting the front seat.

X: ISOFIX position not suitable for ISOFIX child restraint systems in this group of weight and/or size class.

IUF-IL: Suitable for Isofix child restraint systems to be positioned in forward facing position, universal class (fitted with third upper mounting), type-approved for the relevant weight group.

NOTE When a Universal ISOFIX child restraint system is used, only ECE R44 "ISOFIX Universal" (R44/03 or further upgrades) type-approved child restraint systems can be used.

The other weight groups are covered by specific ISOFIX child restraint systems, which can be used only if specifically tested for this vehicle (see list of vehicles provided with the child restraint system).

IMPORTANT The rear central seat (for versions/markets where provided) and the passenger front seat are not approved for any type of Isofix child restraint system.



CHILD RESTRAINT SYSTEMS RECOMMENDED BY FCA FOR YOUR PANDA

Lineaccessori MOPAR® includes a complete range of child restraint systems to be fixed using the seat belt with three anchorage points or the ISOFIX anchorages.

Weight group	Child restraint system	Type of child restraint system	Child restraint system installation
Group 0+: from birth to 13 kg		Britax Baby Safe plus Type-approval number: E1 04301146 Fiat order code: 71806415	Universal/ISOFIX child restraint system. It must be installed facing rearwards, using the vehicle seat belts only, or the dedicated ISOFIX base (which can be purchased separately) and the vehicle ISOFIX anchorages. It must be fitted on the rear outer seats.
		Britax Baby Safe ISOFIX base Fiat order code: 71806416	

Weight group

Child restraint system

Type of child restraint system

Child restraint system installation



Fair G0/1S

Type-approval number: E4

04443718

Fiat order code: 71807388

+

+



or



Fair ISOFIX RWF platform, "A" type for G 0/1S

Fiat order code: 71805368

or

Fair ISOFIX FWF platform, "M" type for G 0/1S

Fiat order code: 71806374

+

+



FAIR head restraint

Fiat order code: 71807387

Group 1: from 9 up
to 18 kg

Universal/ISOFIX child restraint system. It can be fitted forward facing/rearward facing using only the vehicle seat belts or the Isofix anchorages.

FCA recommends fitting it using the rear facing ISOFIX platform (RWF specific "A" type - to be purchased separately) or the forward facing ISOFIX platform (FWF specific "M" type - to be purchased separately), the rigid head restraint (to be purchased separately) and the ISOFIX anchorages for the vehicle.

It must be fitted on the rear outer seats.



Weight group	Child restraint system	Type of child restraint system	Child restraint system installation
Group 1: from 9 up to 18 kg		Britax Safefix TT Type-approval number: E1 04301199 Fiat order code: 71805956	It must be fitted facing forwards only, using the ISOFIX attachments and the upper strap, provided with the child restraint system. It must be fitted on the rear outer seats.
		Britax Roemer Duo Plus Type-approval number: E1 04301133 Fiat order code: 71803161	It must be fitted facing forwards only, using the ISOFIX attachments and the upper strap, provided with the child restraint system. It must be fitted on the rear outer seats.
Group 2: from 15 kg to 36 kg		Fair Junior Fix Type-approval number: E4 04443721 Fiat order code: 71806570	It can only be fitted facing forwards, using the three-point seat belt and the ISOFIX attachments of the vehicle, if present in the selected position.

IMPORTANT FCA recommends fitting the child restraint system according to the instructions, which must be included.

Main recommendations to carry children safely

- ❑ Install the child restraint systems on the rear seat, which is the most protected position in the event of an impact.
- ❑ Keep children in rearward facing child restraint systems for as long as possible, until 3–4 years old if possible.
- ❑ Should a rearward facing child restraint system be installed on the rear seats, it is advisable to position it as far forward as the position of the front seat allows.
- ❑ If the passenger's front airbag is deactivated, always check that the  warning light is on constantly in the central dashboard, to make sure that it has actually been deactivated.
- ❑ Carefully follow the instructions supplied with the child restraint system. Keep the instructions in the vehicle along with the other documents and this handbook. Do not use second-hand child restraint systems without instructions.
- ❑ Only one child is to be strapped into each restraint system; never carry two children using one child restraint system.
- ❑ Always check that the seat belts do not rest on the child's neck.

- ❑ Always check that the seat belt is well fastened by pulling on it.
- ❑ While travelling, do not let the child sit incorrectly or unfasten the belts.
- ❑ Never allow a child to put the belt's diagonal section under an arm or behind their back.
- ❑ Never carry children on your lap, even newborns. No one can hold a child in the case of an accident.
- ❑ If the car has been involved in a medium-high severity road accident, replace the child restraint system with a new one. In addition, and depending on the type of child restraint system installed, replace the isofix anchorages or the seat belt with which the child restraint system was connected.
- ❑ Before installing a child restraint system of any kind on the rear seat facing in the direction of movement of the vehicle, it is necessary to remove the head restraint from the rear seat position in which the child restraint system is to be installed. On the other hand, before installing a child restraint system composed of only the seat cushion (without backrest) on the rear seat, it is necessary to ensure that the head restraint of the rear seat position in which the child restraint system is to be installed is correctly fitted.



WARNING

88) SEVERE DANGER When a front passenger airbag is fitted, do not install rearward facing child restraint systems on the front passenger seat. Deployment of the airbag in an accident could cause fatal injuries to the child regardless of the severity of the collision. It is advisable to always carry children in a child restraint system on the rear seat, which is the most protected position in the event of a collision.

89) On the sun visor there is a label with suitable symbols reminding the user that it is compulsory to deactivate the airbag if a rearward facing child restraint system is fitted. Always comply with the instructions on the passenger side sun visor (see the "Supplementary Restraint System (SRS) - Airbag" paragraph).

90) Should it be necessary to carry a child on the passenger side front seat in a rear facing child restraint system, the passenger side front and side airbags must be deactivated through the display main menu, verifying deactivation by checking that the warning light  located in the central part of the dashboard has switched on. Move the passenger's seat as far back as possible to avoid contact between the child seat and the dashboard.

91) Do not move the front or rear seat if a child is seated on it or on the dedicated child restraint system.



92) *Incorrect fitting of the child restraint system may result in an inefficient protection system. In the event of an accident the child restraint system may become loose and the child may be injured, even fatally. When fitting a restraint system for newborns or children, strictly comply with the instructions provided by the Manufacturer.*

93) *When the child restraint system is not used, secure it with the seat belt or with the ISOFIX anchorages, or remove it from the vehicle. Do not leave it unsecured inside the passenger compartment. In this way, in the case of sudden braking or an accident, it will not cause injuries to the occupants.*

94) *After installing a child restraint system, do not move the seat: always remove the child restraint system before making any adjustment.*

95) *Always make sure that the chest section of the seat belt does not pass under the arms or behind the back of the child. In the event of an accident the seat belt will not be able to secure the child, with the risk of injury, including fatal injury. Therefore the child must always wear the seat belt correctly.*

96) *Do not use the same lower anchorage to install more than one child restraint system.*

97) *If a Universal ISOFIX child restraint system is not fixed to all three anchorages, it will not be able to protect the child correctly. In a crash, the child could be seriously or fatally injured.*

98) *Fit the child restraint system when the car is stationary. The child restraint system is correctly fixed to the brackets when you hear the click. Follow the instructions for assembly, disassembly and positioning that the Manufacturer must supply with the child restraint system.*

SUPPLEMENTARY RESTRAINT SYSTEM (SRS) - AIRBAG

The vehicle is equipped with:

- ☐ front driver airbag;
- ☐ front passenger airbag;
- ☐ front side bags for pelvis, chest and shoulder protection of driver and passenger (for versions/markets, where provided);
- ☐ side bags for head protection of front seat passengers and rear side seat passengers (window bag).

FRONT AIRBAGS



99) The front (driver and passenger) airbags protect the front seat occupants in the event of head-on crashes of medium-high severity, by placing the cushion between the occupant and the steering wheel or dashboard.

Therefore non-activation of airbags in other types of collisions (side impacts, rear shunts, roll-overs, etc.) does not indicate a system malfunction. Driver and passenger front airbags are not a replacement of but complementary to the seat belts, which should always be worn, as specified by law in Europe and most non-European countries.


In the event of an impact, those not wearing a seat belt are projected forwards, and may come into contact with the bag which is still inflating. The protection offered by the bag is compromised in these circumstances. The front airbags may not activate in the case of a frontal impact against highly deformable objects not involving the front surface of the vehicle (e.g. wing collision against guard rail) or in the case of the vehicle wedging under other vehicles or protective barriers (e.g. under trucks or guard rails). Failure to activate in the conditions described above is due to the fact that they may not provide any additional protection compared with seat belts, so their activation would be inappropriate. In these cases, non-deployment does not indicate a system malfunction. The driver's and passenger's front airbags have been designed and calibrated to protect front seat occupants wearing seat belts. At their maximum inflation, their volume fills most of the space between the steering wheel and the driver and between the dashboard and the passenger.

The airbags are not deployed in the event of minor frontal impacts (for which the restraining action of the seat belts is sufficient). It is therefore always necessary to wear seat belts.

Front airbag driver's side



This consists of an instantly inflating bag contained in a special compartment in the centre of the steering wheel fig. 70.




70

F1D0063

Passenger side front airbag

This consists of an instantly inflating bag contained in a special recess in the dashboard fig. 71 which has a larger volume than that of the driver.



71

F1D0064

Passenger side front airbag and child restraint systems



Rearward facing child restraint systems must **NEVER** be fitted on the front seat with an active passenger side airbag since in the event of an impact the airbag activation may cause fatal injuries to the transported child.

ALWAYS comply with the instructions on the label on the passenger side sun visor fig. 72.



72

F1D0126




Deactivating the passenger side airbags: front airbag and side bag

If a child must be carried on the front seat in a rearward facing child restraint system, deactivate the passenger front airbag and the side bags. With airbags deactivated, the  (A-fig. 73 warning light turns on in the dashboard, in central position). Use the display Setup Menu to deactivate.



115)



73

F0W0689

Passenger side front airbag and child restraint systems: IMPORTANT

I	RISCHIO DI FERITE GRAVI O MORTALI. I seggiolini bambino che si montano nel verso opposto a quello di marcia non vanno installati sui sedili anteriori in presenza di air bag passeggero attivo.
GB	DEATH OR SERIOUS INJURY CAN OCCUR. NEVER use a rearward facing child restraint on a seat protected by an ACTIVE AIRBAG in front of it, DEATH or SERIOUS INJURY to the CHILD can occur
F	RISQUE DE MORT OU DE BLESSURES GRAVES. NE PAS positionner le siège pour enfant tourné vers l'arrière, en cas d'air bag passager actif.
D	Nichtbeachtung kann TOD oder SCHWERE VERLETZUNGEN zur Folge haben. Rückwärts gerichtete Kinderrückhaltesysteme (Babyschale) dürfen nicht in Verbindung mit aktiviertem Beifahrerairbag auf dem Beifahrersitz verwendet werden
NL	DIT KAN DODELIJK ZIJN OF ERNSTIGE ONGELUKKEN VEROORZAKEN. Plaats het kinderstoeltje niet ruggelings op de voorstoel wanneer er een airbag aanwezig is.
E	PUEDO OCACIONAR MUERTE O HERIDAS GRAVES. NO ubicar el asiento para niños en sentido inverso al de marcha en el asiento delantero si hubiese airbag activo lado pasajero.
PL	MOŻE GROZIĆ ŚMIERCIĄ LUB CIEŻKIMI OBRAŻENIAMI. NIE WOLNO umieszczać fotelika dziecięcego tyłem do kierunku jazdy na przednim siedzeniu w przypadku zainstalowanej aktywnej poduszki powietrznej pasażera.
TR	ÖLÜM VEYA AĞIR ŞEKİLDE YARALANMAYA SEBEP OLABİLİR. Yolcu airbağı aktif halde iken çocuk koltuğunu araç gidis yönüne ters biçimde yerleştirmeyin.
DK	FARE FOR DØDELIGE KVÆLTELSER OG LIVSTRUENDE SKADOR. Placer aldrig en bagudvendt barnstol på passagerersædet, hvis passager-airbaggen er indstillet til at være aktiv (on).
EST	TAGAJÄRJEKS VÕIVAD OLLA TÕSISED KEHAVIGASTUSED VÕI SURM. Turvapäida olemasolu korral ärge asetage lapse turvaistet sõidusuuna vastassuunas.
FIN	KUOLEMANVAARA TAI VAKAVIEN VAMMOJEN UHKA. Älä aseta lasten turvaistuinta niin, että lapsi on selkää menosuuntaan, kun matkustajan airbag on käytössä.
P	RISCO DE MORTE OU FERIMENTOS GRAVES. Não posicionar o banco para crianças numa posição contrária ao sentido de marcha quando o airbag de passageiro estiver activo.
LT	GALI ĮSTIKTI MIRTIS ARBA GALITE RIMTAI SUSIŽEISTI. Nedekite vaiko sėdynės atgręžtos nugarą į priekinį automobilio stiklą ten, kur yra veikiant keleivio oro pagalvė.
S	KAN VARA LIVSHOTANDE ELLER LEDA TILL ALLVARLIGA SKADOR. Placera aldrig en bakåtvänd barnstol i framsätet då passagerarsidans krockkudde är aktiv.
H	HALÁLOS VAGY SÜLYÖS BALESET KÖVETKEZHET BE. Ne helyezzük a gyermekülést a menetiránnyal szembe, ha az utas oldalán légzsák működik.
LV	VAR IZRAISĪT NĀVI VAI NOPIETNAS TRAUMAS. Nenovietot mazulja sēdekli pretēji braukšanas virzienam, ja pasažiera pusē ir uzstādīts gaisa spilvens.
CZ	HROZÍ NEBEZPEČÍ VÁŽNÉHO UBLÍŽENÍ NA ZDRAVÍ NEBO DOKONCE SMRTI. Neumísťujte detskou sedačku do opačnej polohy vŕči smeru jazdy v prípade aktívneho airbagu spolujazdce.
SLO	LAHKO PRIDE DO SMRTI ALI HUDIH POŠKODB. Otroškega avtomobilskega sedeža ne nameščajte v obratni smeri vožnje, če ima vozilo vgrajene zračne blazine za potnike.
RO	SE POATE PRODUCERECESUL SAU LEZIUNI GRAVE. Nu aşezaţi scaunul de maşină pentru bebeluşi în poziţie contrară direcţiei de mers atunci când airbag-ul pasagerului este activat.
GR	ΜΠΟΡΕΙ ΝΑ ΠΡΟΚΑΛΗΘΟΥΝ ΘΑΝΑΤΟΣ Ή ΣΟΒΑΡΑ ΤΡΑΥΜΑΤΑ. Μην τοποθετείτε το καρεκλάκι αυτοκινήτου για παιδιά σε αντίθετη προς την φορά πορείας θέση σε περίπτωση που υπάρχει αερόσακος εν ενεργεία στη θέση συνεπιβάτη.
BG	ИМА ОПАСНОСТ ОТ СМЪРТ И СЕРИОЗНИ НАРАНЯВАНИЯ. Не поставяйте столчето за пренасяне на бебета в положение обратно на посоката на движение, при положение активно на въздушната възглавница за пътуване.
SK	MOŽE NASTAŤ SMŤ ALEBO VÁŽNE ZRANENIA. Nedávajte autosedačku pre deti do polohy proti chodu vozidla, keď je aktívny airbag spolujazdca.
RUS	ТРАВМЫ И ЛЕТАЛЬНЫЙ ИСХОД. Детское кресло, устанавливающееся против направления движения, нельзя монтировать на месте переднего пассажира, если последнее оборудовано активной подушкой безопасности.
HR	OPASNOST OD TEŠKIH ILI SMRTONOSNIH OZLEJEDA. Sjedala za djecu koja se montiraju u smjeru suprotnom od vožnje ne smiju se instalirati na prednja sjedala ako postoji aktivni zračni jastuk suvozača.
AS	قد تحدث حالات وفاة أو إصابات بالغة. لا تستخدم مقاعد الأمان الخاصة بالأطفال على مقعد مزود "بوسادة هوائية"، حيث إن الطفل قد يتعرض للوفاة أو لإصابة بالغة.



SIDE BAGS (Side bag - Window bag)

To help increase occupants protection in the event of a side impact, the vehicle is equipped with front side bags (for versions/markets, where provided) and window bag (for versions/markets, where provided).

Side bags protect occupants from side-on crashes of medium/high severity by placing the bag between the occupant and the internal parts of the side structure of the vehicle.

Non-activation of side bags in other types of collisions (front collisions, rear shunts, roll-overs, etc.) is not a system malfunction.


Side bag

(for versions/markets, where provided)

These comprise two types of bags located in the front seat backrests fig. 75 which protect the pelvic, chest and shoulder area of the occupants in the event of a side impact of medium-high severity.

Window bag

This comprises two "curtain" bags located behind the side roof cover and covered by special trim fig. 76. They are designed to protect the head of front and rear passengers in the event of side impacts.



75

F1D0066



76

F1D0067

The deployment of side bags in the event of side impacts of low severity is not required.

In the event of a side impact, the system provides best protection if the passenger sits on the seat in a correct position, thus allowing correct window bag deployment.

The window bag is not available for the VAN version.

 102) 103) 104) 105) 106) 107) 108) 109) 110) 111) 112) 113) 114)

Important notes

Do not wash the seats with water or pressurised steam (wash by hand or at automatic seat washing stations). The front and/or side airbags may activate in the event of sharp impacts to the underbody of the vehicle (e.g. impact with steps, pavements, potholes or road bumps etc.).

When the airbag deploys it emits a small amount of dust: the dust is harmless and does not indicate the beginning of a fire. The dust may irritate the skin and eyes however: in this case, wash with neutral soap and water.

Airbag checking, repair and replacement must be carried out at a Fiat Dealership.

If the vehicle is scrapped, have the airbag system deactivated at a Fiat Dealership.

Pretensioners and airbags are deployed in different ways on the basis of the type of collision. Failure to activate one or more of the devices does not indicate a system malfunction.



WARNING

99) Do not apply stickers or other objects on the steering wheel, on the dashboard in the passenger side airbag area, on the side upholstery on the roof and on the seats. Never put objects (e.g. mobile phones) on the passenger's side dashboard since they could interfere with correct inflation of the airbag and also cause serious injury to the passengers.

100) Always drive with your hands on the rim of the steering wheel so that the airbag can inflate freely if required. Do not drive with your body bent forward. Keep your back straight against the backrest.

101) When there is an active passenger airbag, DO NOT install rearward facing child restraint systems on the front seat. Deployment of the airbag in an accident could cause fatal injuries to the child regardless of the severity of the impact. Therefore, always deactivate the passenger side airbag when a rearward facing child restraint system is installed on the front passenger seat. The front passenger seat must also be positioned back as far as possible in order to prevent the child restraint system from coming into contact with the dashboard. Immediately reactivate the passenger airbag as soon as the child restraint system has been removed.

102) Do not affix rigid objects to the garment hooks or support handles.

103) Do not rest your head, arms or elbows on the door, windows or the area in which the window bag is located to avoid possible injury during airbag inflation.

104) Never lean your head, arms or elbows out of the window.

105) If, when the ignition device is turned to MAR, the  warning light does not switch on or stays on whilst driving, a fault may have occurred in the restraint systems. In this case the airbags or pretensioners may not be deployed in an impact or, in a lower number of cases, they may be deployed accidentally. Contact a Fiat Dealership immediately to have the system checked.

106) In the event of "yellow"  warning light failure, the "red"  warning light switches on and, for versions/markets where provided, the explosive charges of the passenger airbag and the side bags are deactivated. When the "red" warning light is on, before proceeding contact a Fiat Dealership to have the system immediately checked (see previous warning).

107) On vehicles with side bags, do not cover the front seat backrests with extra covers.

108) Do not travel carrying objects in your lap, in front of your chest or between your lips (pipe, pencils, etc.): they could cause severe injury if the airbag is deployed.

109) If the car has been stolen or in the case of attempt to steal it, if it has been subjected to vandalism or floods, have the airbag system checked by a Fiat Dealership.



110) The airbags may also be deployed when the car is not moving, if the key is in the ignition and turned to MAR-ON or when the engine is off, if the car is hit by another moving vehicle. Therefore, even if the vehicle is stationary, when an active front passenger airbag is fitted, DO NOT install rearward facing child restraint systems on the front passenger seat. Deployment of the airbag following an impact could cause fatal injuries to the child. Therefore, always deactivate the passenger side airbag when a rearward facing child restraint system is installed on the front passenger seat. The front passenger seat must also be positioned back as far as possible in order to prevent the child restraint system from coming into contact with the dashboard. Immediately reactivate the passenger airbag as soon as the child restraint system has been removed. Also remember that, if the key is turned to STOP, none of the safety devices (airbags or pretensioners) will be deployed in the event of collision. Non-deployment in such cases does not indicate a system malfunction.

111) The airbag warning light  indicates the passenger protection status. If the warning light is off, the passenger side protection is activated. It can be deactivated from the menu, in this case the warning light comes on. When the vehicle is started (ignition key in MAR position), the warning light comes on for approx. 8 seconds, provided that at least 5 seconds have elapsed from the previous switching off. If this does not happen please contact a Fiat Dealership. If the vehicle is switched off/on again in less than 5 seconds the warning light may remain off. In this case, to check correct warning light operation, switch the vehicle off, wait at least 5 seconds and switch on again. During the first 8 seconds, the activation of the warning light does not actually show the passenger protection status, but only checks its correct operation. The warning light may light up with various intensity levels depending on the vehicle conditions. The intensity may also vary during the same key cycle. (The warning light is tested also for markets where the passenger protection deactivation function is not provided, and the warning light switches on for less than one second when the key is turned to MAR, then switches off again.)

112) The airbag deployment threshold is higher than that of the pretensioners. For collisions in the range between the two thresholds, it is normal for only the pretensioners to be activated.

113) The airbag does not replace seat belts but increases their efficiency. Because front airbags are not deployed for low-speed crashes, side collisions, rear-end shunts or rollovers, occupants are protected, in addition to any side bags, only by their seat belts, which must therefore always be fastened.

114) If the "red"  warning light does not switch on for a few seconds when the key is turned to MAR, there may be a fault with the "red" warning light. In this case, after a few seconds, the  warning light starts flashing. Contact a Fiat Dealership immediately to have the system checked.

115) To deactivate the airbags using the instrument panel menu, see the description in the "Knowing the instrument panel" chapter, "Setup Menu" paragraph.

STARTING AND DRIVING

*Let's get to the "heart" of the vehicle:
seeing how you can exploit all of its
potential to the full.*

*We'll look at how to drive it safely in any
situation, so that it can be a welcome
companion, with our comfort and
our wallets in mind.*

STARTING THE ENGINE	92
PARKING THE VEHICLE	93
MANUAL GEARBOX	94
DUALOGIC GEARBOX.....	95
MODE SELECTOR.....	96
DUALDRIVE ELECTRIC POWER STEERING	97
ECO FUNCTION	98
STOP/START SYSTEM	99
PARKING SENSORS.....	100
REFUELLING THE VEHICLE	101
TOWING TRAILERS	103



STARTING THE ENGINE



 116) 117)

 38) 39) 40) 41)

Before starting the engine, adjust the seat, the interior rear view mirrors, the door mirrors and fasten the seat belt correctly.

Never press the accelerator pedal for starting the engine.

VERSIONS WITH MANUAL GEARBOX

Petrol versions

Proceed as follows:

 engage the handbrake and place the gear lever in neutral. **For 0.9 TwinAir and 0.9 TwinAir Turbo versions** engage the handbrake and place the gear lever in neutral or fully press the clutch pedal if a gear other than neutral is engaged;

 **for all versions (except 0.9 TwinAir Turbo)** fully depress the clutch pedal, without pressing the accelerator;

 turn the ignition key to AVV and release it as soon as the engine starts.

Diesel versions

Proceed as follows:

 engage the handbrake, put the gear lever into neutral and turn the ignition key to MAR: the warning lights  and  on the instrument panel will turn on;

 wait for the warning lights  and  to turn off and then fully depress the clutch pedal without pressing the accelerator;

 turn the ignition key to AVV as soon as warning light  switches off. Release the ignition key as soon as the engine starts.

IMPORTANT If the engine does not start at the first attempt, return the ignition key to STOP before repeating the procedure. If, with the ignition key at MAR, the warning lights  and  (only for petrol versions) stay on in the instrument panel, the ignition key must be brought back to STOP and then to MAR again. If the  warning light stays on, retry with the other keys provided. Contact a Fiat Dealership if you still cannot start the engine.

VERSIONS WITH DUALOGIC GEARBOX



Engine starting is allowed both with a gear engaged and with the gearbox in neutral (N).

However, the brake pedal must always be pressed first if neutral is not engaged. It is therefore advisable to place the gear lever in neutral (N) before starting the engine.

LPG AND NATURAL POWER VERSIONS

The engine always starts up on petrol independently of the mode previously selected.



STOPPING THE ENGINE



Turn the ignition key to STOP while the engine is idling.

IMPORTANT After a demanding drive, before turning the engine off you should allow it to idle to allow the temperature in the engine compartment to decrease.



WARNING

116) It is dangerous to run the engine in enclosed areas. The engine takes in oxygen and releases carbon dioxide, carbon monoxide and other toxic gases.

117) Remember that the brake servo and power steering are not operational until the engine has been started, therefore you need to apply much more force than usual to the brake pedal and steering wheel.

118) If the engine fails to start with a gear engaged, the potentially dangerous situation due to the fact that the gearbox is automatically placed in neutral will be signalled by an acoustic signal.



WARNING

38) If the warning light  flashes for 60 seconds after starting or during an extended towing period, this indicates a problem in the glow plug pre-heating system. You can use the vehicle as usual if the engine starts but you should contact a Fiat Dealership as soon as possible.

39) It is advisable not to demand maximum performance from your vehicle (e.g. excessive acceleration, long distances at maximum rpm, excessively intense braking, etc.) when it is first used.

40) When the engine is off, do not leave the key turned to MAR to prevent unnecessary electrical consumption from draining the battery.

41) Never bump start the engine by pushing, towing or coasting downhill. This could cause fuel to flow into the catalytic converter and damage it beyond repair.

42) There must therefore always be some petrol in the tank to protect the petrol pump and to guarantee temporary switching from LPG or Methane to petrol operation, if high performance is required.

43) A quick burst on the accelerator before stopping the engine serves no practical purpose; it wastes fuel and is especially damaging to turbocharged engines.

PARKING THE VEHICLE

When parking and leaving the car, proceed as follows:

 engage a gear (1st gear if facing uphill or reverse if facing downhill) and leave the wheels turned;

 stop the engine and engage the handbrake;

 always remove the ignition key. Block the wheels with a wedge or a stone if the car is parked on a steep slope.

On versions equipped with Dualogic transmission, wait for the letter P to be displayed before releasing the brake pedal.

WARNING Never leave the car with the gearbox in neutral (or, on versions equipped with Dualogic transmission, before putting the gear lever in the P position).

Handbrake




194) 195) 196)

The handbrake lever is located between the two front seats.

Handbrake engagement: pull lever A fig. 77 upwards until the vehicle is braked.





77

F1D0146

Handbrake disengagement: slightly raise lever A and hold button B pressed, checking that the (C) warning light switches off in the instrument panel.

**WARNING**

119) Never leave children unattended in the car. Always remove the key from the ignition when leaving the car and take it with you.


120) The car should be braked after a few clicks of the lever, if it is not, contact a Fiat Dealership to have it adjusted.

121) In the case of parking manoeuvres on roads on a gradient, the front wheels must be steered towards the pavement (when parking downhill), or in the opposite direction if the vehicle is parked uphill. Block the wheels with a wedge or a stone if the car is parked on a steep slope.

MANUAL GEARBOX

⚠ 122) ⚠ 44)

To engage the gears, press the clutch pedal fully and put the gear lever into the required position (the diagram for gear engagement is shown on the knob fig. 78).



78

F1D0069

For 0.9 TwinAir, 0.9 TwinAir Turbo and 1.2 8v 69 HP versions: to engage reverse R from neutral, raise ring A fig. 78 underneath the knob and, at the same time, shift the lever to the right and then backwards.

For version 1.3 16v MultiJet : to engage reverse R from neutral position, shift the lever to the right and then back.

IMPORTANT Reverse can only be engaged when the vehicle is completely stationary. With the engine running, wait for at least 2 seconds with the clutch pedal fully pressed before engaging reverse to prevent damage to the gears and grating.

IMPORTANT The clutch pedal should be used only for gear changes. Do not drive with your foot resting on the clutch pedal, however lightly. For versions/markets where provided, the electronic clutch pedal control could cut in, interpreting the incorrect driving style as a fault.

**WARNING**

122) Depress the clutch pedal fully to change gear correctly. It is therefore essential that there is nothing under the pedals: make sure the mats are lying flat and do not get in the way of the pedals.

**WARNING**

44) Do not drive with your hand resting on the gear lever as the force exerted, even if slight, could lead over time to premature wear of the internal gearbox components.

DUALOGIC GEARBOX


(for versions/markets, where provided)



The vehicle can be equipped with an electronically controlled manual gearbox known as Dualogic which allows two operating modes: MANUAL and AUTO.

GEAR LEVER

The gear lever A fig. 79, located on the dashboard, is floating multistable type, i.e. it has three stable positions and three unstable positions.



79

F1D0107

The three stable positions correspond to neutral (N), reverse (R) and the central position located between the unstable positions (+) and (-).

The unstable positions, in other words those that are abandoned as soon as the lever is released, are the positions for requesting a higher gear (+), requesting a lower gear (-) and requesting automatic operating mode (A/M).

IMPORTANT With the engine started, any error between the lever position and the gear actually engaged is signalled by a buzzer until consistency is restored.

MANUAL MODE

Proceed as follows:

- ☐ press the brake pedal and start the engine;
- ☐ if AUTO appears on the display, move the lever A fig. 79 to A/M to select MANUAL mode;
- ☐ push gear lever A towards (+) to engage first gear (if starting from N or R, simply place the lever in the middle position) or R to engage reverse;
- ☐ release the brake pedal and press the accelerator pedal;
- ☐ in driving conditions, push lever A of the gearbox towards (+) to engage the next gear up or towards (-) to engage the next gear down.


AUTOMATIC MODE

Proceed as follows:

- ☐ press the brake pedal;
- ☐ start the engine;
- ☐ if AUTO does not appear on the display, move the gear lever A fig. 79 to A/M to select AUTOMATIC mode;
- ☐ push the gear lever towards (+) to engage 1st gear (if starting from N or R, simply place the lever in the middle position) or R to engage reverse;
- ☐ release the brake pedal and press the accelerator pedal: the gear most suited to the vehicle speed will be engaged.

AUTO-ECO OPERATION

To activate the function press the ECO button fig. 80 on the central tunnel. The ECO function can be only activated only with automatic mode active.



80

F1D0108



With the ECO function active, the system will select the most suitable gear depending on the vehicle speed, engine rpm and intensity with which the accelerator pedal is pressed, with the aim of limiting fuel consumption.

"Kick Down" FUNCTION (for versions/markets, where provided)

If necessary (e.g. when overtaking), the system downshifts one or more gears when the accelerator pedal is depressed beyond the point where it becomes stiff (and if the rpm allow it) in order to provide suitable power and torque for the acceleration requested by the driver.

IMPORTANT The use of the "Kick Down" function is recommended only when overtaking or accelerating quickly, in order not to increase fuel consumption.



WARNING


45) Avoid keeping your hand on this lever except during gear change or AUTO/MANUAL mode requests.

MODE SELECTOR

(Panda Cross versions)



This device allows, using the ring nut of the knob fig. 81 (on the central tunnel), three vehicle response modes to be selected according to driving style and road conditions:



- ☐ 1 = AUTO mode;
- ☐ 2 = OFF ROAD mode;
- ☐ 3 = HDC function.

The ring nut is monostable type. In other words, it always remains in a central position. The selected driving mode is indicated by the corresponding LED switching on the knob and by an indication on the display.

"AUTO" MODE

It is a driving mode aimed at comfort and safety in normal grip and driving conditions.

"OFF ROAD" MODE

It is a driving mode aimed at setting off in poor grip conditions on low-grip road surfaces (e.g. snow, ice, mid, etc.).

Engagement

Rotate the ring nut fig. 81 to the right and hold in this position for half a second, until the corresponding LED lights up and "Off Road" mode activation indicator appears on the display with a dedicated message. When the "Off Road" mode is activated, the presetting for ELD system intervention activates automatically.

IMPORTANT When the "Off Road" mode is activated, the Stop/Start system is temporarily disabled. Temporary deactivation of the system switches on the corresponding LED on the trim (located on the central dashboard). To activate the Stop/Start function, with "Off Road" mode on, press the  button on the dashboard trim. However, when the "Off Road" mode is deactivated, the Stop/Start system is enabled again.

IMPORTANT When the "Off Road" mode is activated, the City Brake Control system is temporarily deactivated. Temporarily deactivation of the system results in the switching on of the  warning light on the instrument panel. When the "Off Road" mode is deactivated, the City Brake Control system is enabled again.

Disengagement

To deactivate the "Off Road" mode and return to the "Auto" mode, rotate the ring nut to the left and hold in this position for half a second. In this case, the LED corresponding to "Auto" mode will light up and the "Off Road" mode deactivation indication will appear on the display.

IMPORTANT If "Off Road" or "Auto" mode was active when the engine was stopped, the next time it is started the mode that was selected is reactivated.

"HDC" FUNCTION

This driving function permits a constant vehicle speed to be maintained downhill.

Engagement/Disengagement

For engaging/disengaging the HDC function refer to the "Active safety systems" paragraph in the "Safety" chapter.

FAILURE OF THE MODE SELECTOR SYSTEM

IMPORTANT In the event of system failure or a fault with knob, no driving modes can be selected. The display will show a dedicated message.

IMPORTANT In this case it is not advisable trying to drive down roads with a steep gradient, the system cannot help the driver in any way.

DUALDRIVE ELECTRIC POWER STEERING

 123) 124)


This only operates with the key turned to MAR and the engine started. The steering allows the force required at the steering wheel to be adjusted to suit driving conditions.

IMPORTANT When turning the ignition key quickly, full power steering functionality can be achieved after a few seconds.

CITY FUNCTION ACTIVATION/ DEACTIVATION

Press the CITY fig. 82 button to activate/deactivate the function. The activation of the function is signalled by the word CITY on the display (in some versions it is signalled by the word CITY appearing on the instrument panel). When the CITY function is on, the steering wheel effort is lighter, making parking easier: therefore, this function is particularly useful for driving in city centres.





82

F1D0025

IMPORTANT During parking manoeuvres requiring a lot of steering, the steering may become harder; this is normal and is due to the intervention of the system to protect the electric steering motor from overheating so no intervention is required. When the vehicle is used again later on, the power steering will work normally.



WARNING


123) It is absolutely forbidden to carry out any after-market operation involving steering system or steering column modifications (e.g. installation of anti-theft device) that could adversely affect performance and safety, invalidate the warranty and also result in non-compliance of the vehicle with type-approval requirements.

124) Before servicing the vehicle, switch off the engine and remove the key from the ignition switch to activate the steering lock. This is especially important when the vehicle wheels are not touching the ground. If this is not possible (for example if the key needs to be turned to MAR or the engine must be running), remove the main fuse that protects the electric power steering.

ECO FUNCTION

(for versions/markets, where provided)

To activate the function press the ECO button fig. 83.



83

F1D0140

When the ECO function is active, the car is set for driving characterised by reduced fuel consumption. When the function is active, the corresponding LED on the button switches on.

This function stays in the memory and, when the vehicle is started again, the system keeps the setting it had before the engine was stopped. Press the ECO button again to deactivate the function and restore the normal driving setting.

STOP/START SYSTEM



125) 126) 46)

The Stop/Start system automatically stops the engine when the vehicle is stationary and starts it again when the driver wants to move off. This reduces consumption, the emission of harmful gases and noise pollution.

OPERATING MODE

Engine stopping mode: with the vehicle stopped, the engine stops with gearbox in neutral and clutch pedal released.

Note The engine can only be stopped automatically after exceeding a speed of about 10 km/h, to prevent the engine from being repeatedly stopped when driving at walking pace.


Restarting the engine: press the clutch pedal to restart the engine.

MANUAL SYSTEM ACTIVATION/DEACTIVATION

To activate/deactivate the system manually, press the  fig. 84 button on the dashboard control trim.

LED off: system deactivated.

LED on: system deactivated.



84

F1D0040



WARNING

125) If the battery needs to be replaced, always contact a Fiat Dealership. The replacement battery should be of the same type (HEAVY DUTY) and should have the same characteristics.

126) Before opening the bonnet, make sure that the engine is off and that the ignition key is in the STOP position. Please follow the instructions on the decal near the front crossmember. We recommend that you remove the key from the ignition if other people remain in the vehicle. Exit from the vehicle only after having removed the ignition key or having rotated it to the STOP position. During refuelling, make sure that the engine is off and that the ignition key is in the STOP position.



WARNING

46) If climate comfort is to be favoured, the Stop/Start system can be disabled, for a continuous operation of the climate control system.




PARKING SENSORS



SENSORS

The sensors are located in the rear bumper fig. 85 and their function is to detect the presence of any obstacles near the rear part of the vehicle and inform the driver, through an intermittent acoustic signal.



85

F1D0045

ACTIVATION/ DEACTIVATION

The sensors are automatically activated when reverse is engaged. As the obstacle behind the vehicle gets closer, the acoustic signal becomes more frequent.

OPERATION WITH A TRAILER

Sensor operation is automatically deactivated when the trailer's electric cable plug is fitted in the vehicle's tow hook socket. The sensors are automatically reactivated when the trailer's cable plug is removed.

IMPORTANT INFORMATION

When parking, take the utmost care over obstacles that may be above or under the sensor.

Objects close to the vehicle are not detected under certain circumstances and could therefore cause damage to the vehicle or be damaged.

The following conditions may influence the performance of the parking assistance system:

- ❑ the presence of ice, snow, mud or multiple layers of paint on the surface of the sensor may reduce its sensitivity and the system performance;
- ❑ mechanical interference (e.g. washing the vehicle, rain, strong wind, hail) may cause the sensor to detect a non-existent obstacle ("echo interference");

- ❑ the presence of ultrasonic systems (e.g. pneumatic brake systems of trucks or pneumatic drills) near the vehicle could alter the signals sent to the sensor;
- ❑ the variation in sensor position, caused by variation in ride (due to suspension or shock absorber wear), changing tyres, overloaded vehicle, or tuning that lowers the vehicle, for example, may affect parking sensor system performance;
- ❑ the presence of a tow hook without trailer interferes with the correct operation of the parking sensors. If a fixed tow hook is installed, the sensors cannot be used. If the customer installs a removable tow hook, this must always be disconnected from the crossmember whenever the trailer is not attached to prevent the activation of the sensors.



WARNING

127) The responsibility for parking and other dangerous manoeuvres always and in every case lies with the driver. While carrying out these manoeuvres, always make sure that no people (especially children) or animals are in the area concerned. The parking sensors are used to assist the driver, who must never allow his attention to lapse during potentially dangerous manoeuvres, even those executed at low speeds.



WARNING

47) The sensors must be clean of mud, dirt, snow or ice in order for the system to operate correctly. Be careful not to scratch or damage the sensors while cleaning them. Avoid using dry, rough or hard cloths. The sensors must be washed using clean water, with the addition of vehicle shampoo if necessary. When using special washing equipment such as high pressure jets or steam cleaning, clean the sensors very quickly keeping the jet more than 10 cm away.

REFUELLING THE VEHICLE



128) 129) 130)

Always stop the engine before refuelling.

PETROL ENGINES

Only use unleaded petrol, with an octane number (R.O.N.) not lower than 95. In order to prevent damage to the catalytic converter never introduce even the smallest amount of leaded petrol, even in the event of an emergency.

DIESEL ENGINES

Only use Diesel for motor vehicles (EN590 specification). When using or parking the car for a long time in the mountains or cold areas, it is advisable to refuel using locally available diesel. In this case, it is also advisable to keep the tank over 50% full.

REFUELLING PROCEDURE






48)

Diesel and petrol versions

The refuelling procedure described below is illustrated on the label B fig. 86 located inside the fuel flap. The label also indicates the fuel type (UNLEADED FUEL=petrol, DIESEL=diesel fuel).

To refuel proceed as follows:

- ☐ open flap A fig. 86, pulling it outwards;
- ☐ introduce the dispenser in the filler and refuel;
- ☐ after refuelling, before removing the dispenser, wait for at least 10 seconds in order for the fuel to flow inside the tank;
- ☐ then remove the dispenser from the filler and close flap A.



86

F1D0047




Flap A fig. 86 is provided with a dust cover gaiter C which prevents deposits of impurities and dust at the end of the filler when the flap is closed.

Emergency refuelling

Proceed as follows:

- ❑ open the luggage compartment and take the adapter B fig. 87 located in the tool box (versions equipped with space-saver wheel - for versions/markets, where provided) or in the Fix&Go Airflat container (versions equipped with Fix&Go Airflat);




87

F1D0048

- ❑ open flap A, pulling it outwards;
- ❑ introduce the adapter B in the filler and refuel;
- ❑ after refuelling, remove the adapter and close the flap, then reintroduce the adapter in its casing and put it back in the luggage compartment.

LPG versions

To access the LPG filler, open the access flap A fig. 88 and undo the cap B.





88

F1D0114

Observe the following precautions during the refuelling operation:

- ❑ switch off the engine;
- ❑ apply the handbrake;
- ❑ turn the ignition key to STOP;
- ❑ do not smoke;
- ❑ hand the special adapter A fig. 89 over to the qualified LPG refuelling personnel.



89

F1D0115

IMPORTANT Depending on the country, there are various types of adapters for LPG refuelling pumps. Filler adapter, supplied with the vehicle and located in a special case, is specifically designed for the country in which the vehicle is sold. If you are in a different country, find out what type of adaptor is used there.


Natural Power versions



49)

To access filler B fig. 90, open the flap and undo cap A turning it counterclockwise.

The profile of filler B for refilling is the universal type, compatible with Italian and NGV1 standards. In some European countries adapters are considered ILLEGAL (e.g. in Germany).



90

F1D0110



WARNING

128) Do not apply any object/plug to the end of the filler which is not provided for the car. The use of non-compliant objects/caps could cause a pressure increase inside the tank, resulting in dangerous situations.

129) Do not bring naked flames or lit cigarettes near to the fuel filler: fire risk. Keep your face away from the fuel filler to prevent breathing in harmful vapours.

130) Do not use a mobile phone near the refuelling pump: risk of fire.



WARNING

48) For diesel engines, only use diesel fuel for motor vehicles in accordance with EN 590 European specifications. The use of other products or mixtures may damage the engine beyond repair and consequently invalidate the warranty, due to the damage caused. If you accidentally introduce other types of fuel into the tank, do not start the engine. Empty the tank. If the engine has been run for even an extremely limited amount of time, you must not only drain the fuel tank, but the rest of the supply circuit as well.

49) The other plates (provided with the vehicle documents) show the date when the first cylinder inspection/test is due. Methane refuelling stations are not authorised to refill the cylinders when the inspection date has expired.

TOWING TRAILERS



131) 132)

IMPORTANT

For towing motorhomes or trailers the vehicle must be fitted with an approved tow hook and an adequate electrical system. Installation must be carried out by a specialist.

Install any specific and/or additional door mirrors as specified by the Highway Code.

Remember that when towing a trailer, steep hills are harder to climb, braking distances increase and overtaking takes longer depending on the overall weight of the trailer.

Engage a low gear when driving downhill, rather than constantly using the brake.

The weight the trailer exerts on the vehicle tow hook reduces the vehicle's loading capacity by the same amount. To make sure that the maximum towable weight is not exceeded (given in the vehicle registration document) account should be taken of the fully laden trailer, including accessories and luggage.

Do not exceed the speed limits specific to each country you are driving in, in the case of vehicles towing trailers. In any case, the top speed must not exceed 100 km/h.



An electric brake (or electric winch) should be supplied directly by the battery through a cable with a cross section of no less than 2.5 mm².

In addition to the electrical branches, the vehicle electrical system can only be connected to the supply cable for an electric brake and to the cable for an internal light for the trailer, not exceeding 15 W. For connections, use the preset control unit with a battery cable with section not less than 2.5 mm².

On Panda Cross and Panda 4x4 versions, in the event of prolonged vehicle use at maximum tow capacity on slopes, replacing engine oil more frequently (every 10,000 km) is advisable.

IMPORTANT The use of auxiliary loads other than external lights (electric brake, winch, etc.) must be used with engine running.

IMPORTANT To install a tow hook contact a Fiat Dealership.



WARNING

131) *The ABS with which the vehicle is equipped will not control the braking system of the trailer. Particular caution is required on slippery roads.*

132) *Never modify the braking system of the vehicle to control the trailer brake. The trailer braking system must be fully independent of the vehicle's hydraulic system.*

IN AN EMERGENCY

A punctured tyre or a burnt-out bulb?

At times, a problem may interfere with our journey.

The pages on emergencies can help you to deal with critical situations independently and with calm.

In an emergency we recommend that you call the freephone number found in the Warranty Booklet.

It is also possible to call the national or international universal freephone number to search for the nearest Dealership.


HAZARD WARNING LIGHTS.....	106
REPLACING A BULB	106
REPLACING FUSES.....	112
CHANGING A WHEEL	115
“FIX&GO AIRFLAT” KIT	118
JUMP STARTING	121
FUEL CUT-OFF SYSTEM	122
TOWING THE VEHICLE	123



HAZARD WARNING LIGHTS

Press button A fig. 91 to switch the lights on/off. Warning lights  and  in the instrument panel are lit up when the lights are ON.

IMPORTANT The use of hazard warning lights is governed by the highway code of the country you are driving in: comply with legal requirements.



Emergency braking

In the event of emergency braking the hazard warning lights switch on automatically as well as the  and  warning lights in the instrument panel. The lights switch off automatically when emergency braking ceases.

REPLACING A BULB



 133) 134)  50) 51)

GENERAL INSTRUCTIONS

- ☐ Before changing a bulb check the contacts for oxidation;
- ☐ burnt bulbs must be replaced by others of the same type and power;
- ☐ after replacing a headlight bulb, always check its alignment;
- ☐ when a light is not working, check that the corresponding fuse is intact before changing a bulb. For the location of fuses, refer to the paragraph "If a fuse blows" in this section;

IMPORTANT When the weather is cold or damp or after heavy rain or washing, the surface of headlights or rear lights, may steam up and/or form drops of condensation on the inside. This is a natural phenomenon due to the difference in temperature and humidity between the inside and the outside of the glass which does not indicate a fault and does not compromise the normal operation of lighting devices. The mist disappears quickly when the lights are turned on, starting from the centre of the diffuser, extending progressively towards the edges.

Bulbs	Type	Power
Dipped/main beam headlights	H4	55 W
Front side lights/Day lights (DRL)	P21/5W	21 W
Rear side lights	P21/5W	5 W
Front direction indicators	PY21W	21 W
Side direction indicators	W5W	5 W
Rear direction indicators	PY21W	21 W
Brake lights	P21/5W	21 W
Third brake light	LED	-
Fog lights	H11	55 W
Reverse	W16W	16 W
Rear fog light	W16W	16 W
Number plate	C5W	5 W




FRONT LIGHT CLUSTERS

(except Panda Cross versions)

The bulbs are arranged inside the front light cluster fig. 92 as follows:

- A - Dipped beam/main beam headlights/direction indicators;
- B - Daytime running lights (DRL);
- C - Fog lights.



92


F1D0134

FRONT LIGHT CLUSTERS

(Panda Cross versions)

On the Panda Cross versions, the bulbs are arranged inside the front light cluster fig. 93 as follows:

- A - Dipped beam/main beam headlights/direction indicators;
- B - Fog lights;
- C - Daytime Running Lights (DRL).




93

F1D0117

DIPPED/MAIN BEAM HEADLIGHTS

To replace the bulb, proceed as follows:


- remove cover A fig. 94;



94

F1D0079

- push the connector + bulb holder unit B fig. 95 downwards;
- remove the bulb C from connector D and replace it;



95

F1D0080

- refit the new bulb on the connector making sure that it is locked correctly, then reinsert the connector unit and the bulb holder B in its housing;
- then refit the cover A.

DIRECTION INDICATORS

Front

To replace the bulb, proceed as follows:


- remove cover B fig. 94;
- turn the bulb holder anticlockwise, extract the bulb and replace it;
- refit the new bulb on the connector making sure that it is locked correctly, then reinsert the connector in its housing rotating it clockwise;

Side

To replace the bulb, proceed as follows:

- adjust the lens A fig. 96 to compress in the clip B, then pull the cluster outwards;

- ❑ turn the bulb holder C anticlockwise, extract the bulb and replace it;
- ❑ refit the bulb holder C in the lens and turn it clockwise;
- ❑ refit the unit making sure that the internal clip B clicks into position.



96


F1D0081

FOG LIGHTS

(for versions/markets, where provided - except Panda Cross versions)


To replace the bulb, proceed as follows:

- ❑ steer the wheel completely inwards, adjust the screws A fig. 97 and remove the flap B;
- ❑ adjust the clip C fig. 98 and disconnect the electrical connector D;
- ❑ rotate and remove the bulb holder E, release and replace the bulb;
- ❑ refit the new lamp and carry out the procedure described previously in reverse.



97

F1D0082



98


F1D0083

FOG LIGHTS

(Panda Cross versions)

To change the fog light bulb, proceed as follows:


- ❑ steer both the wheels completely, loosen the screws A fig. 99 and remove the guard flap B;
- ❑ locate the fog light unit, rotate it anticlockwise by a quarter of a turn and remove it;



99

F1D0118

- ❑ lift the lever A fig. 100 and disconnect the connector B from the bulb-bulb holder assembly C;



100

F1D0119

- ❑ replace the bulb-bulb holder assembly C;
- ❑ reconnect the assembly to connector B, reposition assembly C in its housing by rotating it clockwise by a quarter of a turn, until it clicks into the correct position;




□ reposition the guard door B fig. 99, taking care that the tabs are positioned in their housings and tighten the fixing screws A.

SIDE LIGHTS/DAYTIME RUNNING LIGHTS (DRL)

(for versions/markets, where provided - except Panda Cross versions)

To replace the bulb, proceed as follows:

- steer the wheel completely, adjust the screws A fig. 97 and remove the flap B;
- adjust the clip C fig. 101 and disconnect the electrical connector D;



101

F1D0084

- rotate and remove the bulb holder E, release and replace the bulb;
- refit the new lamp and carry out the procedure described previously in reverse.

DAYTIME RUNNING LIGHTS (DRL)

(Panda Cross versions)


IMPORTANT To change LED DRLs contact a Fiat Dealership.

REAR LIGHT CLUSTERS

These contain the bulbs for the side lights, brake lights and direction indicators.

To replace the bulb proceed as follows:


- undo the two screws A fig. 102 from their seats, pull gently outwards until releasing the whole headlight from the two clips (press-fitted D fig. 103) and release the connector;



103

F1D0086

- undo the five screws B from their seats and remove the bulb holder C;
- remove the bulbs, pushing them slightly and turning them anti-clockwise;



102

F1D0085

- refit the new lamp and carry out the procedure described previously in reverse.

REVERSING LIGHT/REAR FOG LIGHT




135)

The reversing lights and rear fog lights are located in the rear bumper.

To replace the bulb, proceed as follows:


- adjust the tabs A and remove the flap B fig. 104



104

F1D0087

- adjust the clip C fig. 105 and disconnect the electrical connector D;



105

F1D0088

- turn the bulb holder E and remove it, extract the bulb and replace it;
- refit the new lamp and carry out the procedure described previously in reverse.


THIRD BRAKE LIGHTS

These are located in the tailgate and are LED lights. For replacement, contact a Fiat Dealership.

NUMBER PLATE LIGHTS

To replace the bulbs proceed as follows:


- remove lens A fig. 106;



106

F1D0089

- replace the bulb A fig. 107, releasing it from the side contacts;



107

F1D0090

- Insert the new bulb and make sure that it is correctly clamped between the contacts, then refit the lens A fig. 107.



WARNING

133) Modifications or repairs to the electric system that are not carried out properly or do not take the system technical specifications into account can cause malfunctions leading to the risk of fire.

134) Halogen bulbs contain pressurised gas; in the case of breakage they may burst.

135) Before replacing the bulb, wait for the catalytic converter to cool down: RISK OF BURNS.



WARNING

50) Halogen bulbs must be handled by holding the metallic part only. Touching the transparent part of the bulb with your fingers may reduce the intensity of the emitted light and even reduce the lifespan of the bulb. In the event of accidental contact, wipe the bulb with a cloth moistened with alcohol and let the bulb dry.

51) If possible, we recommend to have bulbs replaced by a Fiat Dealership. The correct operation and alignment of the external lights are absolutely essential for the safety of the vehicle and of compliance with the law.



REPLACING FUSES



136) 137) 138) 139) 140) 141)




52)

GENERAL INFORMATION

To facilitate fuse replacement, use the pliers hooked inside the fuse box lid on the dashboard left-hand side.

ENGINE COMPARTMENT JUNCTION BOX

The fuse box is located next to the battery: to access the fuses, undo screw A fig. 108, and lift cover B upwards.




108

F1D0091

The number identifying the electrical component corresponding to each fuse is shown on the cover. After replacing the fuse, make sure you close cover B on the junction unit.

DASHBOARD FUSE BOX

The fuse box fig. 109 is located near the left side of the steering column and the fuses can be accessed easily from the lower part of the dashboard.



109

F1D0093

ENGINE COMPARTMENT JUNCTION BOX

fig. 108

USERS	FUSE	AMPERE
Body Computer node	F01	60
Passenger compartment fan	F08	40
Front fog lights	F09	15
Horns	F10	15
Main beam headlights	F14	15
Heated windscreen	F15	70
Air conditioning compressor	F19	7.5
Front power socket (with or without cigar lighter)	F20	15
Fuel pump	F21	15
Blow-by	F30	5
+15 (*) reversing lights	F87	5
Mirror demisting	F88	7.5
Heated rear window	F89	30
Battery charge status sensor	F90	5

(*)+15 = ignition-operated positive pole



DASHBOARD FUSE BOX

fig. 109

USERS	FUSE	AMPERE
+15 (*) headlight alignment corrector	F13	5
+15 (*) Ignition-operated control with inhibition during engine starting	F31	5
+30 (**)	F36	10
+15 (*) brake pedal switch (NO)	F37	7.5
Central door locking	F38	20
Two-way windscreen washer pump	F43	20
Front electric window (driver side)	F47	20
Front electric window (passenger side)	F48	20
+15 (*)	F49	7.5
+15 (*)	F50	7.5
+15 (*)	F51	5
+30 (**)	F53	7.5

(*)+15 = ignition-operated positive pole

(**)+30 = battery direct positive pole (not ignition-operated)



WARNING

136) If the replaced fuse blows again, contact a Fiat Dealership.

137) Never replace a fuse with metal wires or anything else.

138) Never replace a fuse with another with a higher amp rating; DANGER OF FIRE.

139) If a general fuse (MEGA-FUSE, MIDI-FUSE, MAXI-FUSE) blows contact a Fiat Dealership.

140) Before replacing a fuse, make sure that the ignition key has been removed and that all the other services are switched off and/or disengaged.

141) Contact Fiat Dealership if a safety system (airbags, brakes), engine system (engine, gearbox) or steering system general protection fuse blows.



WARNING

52) If you need to wash the engine compartment, take care not to directly hit the fuse box and the window wiper motors with the water jet.

CHANGING A WHEEL



142) 143) 144) 145) 146)

JACK

Important notes:

- ☐ the jack weight is 1.76 kg;
- ☐ the jack requires no adjustment;
- ☐ the jack cannot be repaired and in the event of a fault it must be replaced by another original one;
- ☐ no tool other than its cranking device may be fitted on the jack.

Jack maintenance

- ☐ prevent any dirt from depositing on the "worm screw";
- ☐ keep the "worm screw" lubricated;
- ☐ never modify the jack.


Conditions in which not to use the jack

- ☐ temperature below -40°C
- ☐ on sandy or muddy ground
- ☐ on uneven ground
- ☐ on steep roads
- ☐ in extreme weather conditions: thunderstorms, typhoons, hurricanes, blizzards, storms, etc.
- ☐ in direct contact with the engine or to carry out repairs under the vehicle
- ☐ on boats.

CHANGING PROCEDURE

Proceed as follows:

- ☐ stop the car in a position that is not dangerous for oncoming traffic where you can change the wheel safely. The ground must be flat and sufficiently compact;
- ☐ switch off the engine, pull up the handbrake and engage the 1st gear or reverse. Wear the reflective safety jacket (compulsory by law) before getting out of the vehicle;
- ☐ open the luggage compartment, pull tab A fig. 110 and lift up the mat;




110

F1D0072




❑ using the wrench A fig. 111 located in the tool box, loosen the locking device, take the tool box B and place it close to the wheel to be replaced. Then take the space-saver wheel C. For the Panda VAN and Panda 4x4 versions, the jack and the tools can be located under the passenger side front seat;



111

F1D0073

❑ take the wrench A fig. 112 and loosen the fixing bolts by about one turn;




112

F1D0074


❑ position the jack under the vehicle, near the wheel to be changed;

❑ operate the device A fig. 113 to extend the jack until the top of the jack B fig. 114 fits correctly into the side member C (next to the mark ∇ on the side member);



113

F1D0075



114

F1D0076

❑ alert any bystander that the vehicle is about to be raised; all persons should be kept away from the vehicle and nobody must touch it until it has been lowered;

❑ fit handle D fig. 113 into the housing in device A, operate the jack and raise the vehicle until the wheel is a few centimetres from the ground;

❑ remove the wheel cap after loosening the 3 fixing bolts and finally loosen the fourth bolt and extract the wheel (only for versions with wheel caps fixed by bolts);

❑ make sure the contact surfaces between space-saver wheel and hub are clean so that the fastening bolts will not come loose;

❑ fit the space-saver wheel by inserting the first bolt for two threads into the hole closest to the valve;

❑ take the wrench A fig. 112 and fully tighten the fixing bolts;

❑ operate the jack handle D fig. 113 to lower the car. Then extract the jack;



❑ use the wrench A fig. 112 to fully tighten the bolts, passing alternately from one bolt to the opposite one;

❑ when replacing an alloy wheel rim it is advisable to place it upside down, with the aesthetic part facing upwards.

REFITTING THE STANDARD WHEEL



54)

Following the procedure described previously, raise the vehicle and remove the space-saver wheel.

Versions with steel wheels

Proceed as follows:

- make sure the contact surfaces between standard wheel and hub are clean so that the fastening bolts will not come loose;

- fit the standard wheel by inserting the first bolt by 2 threads into the hole closest to the inflation valve;

- fit the hub cap, aligning the crescent hole with the bolt already fitted, then fit the other bolts;

- using the wrench provided, tighten the fastening bolts;

- lower the vehicle and remove the jack;

- use the wrench provided to fully tighten the bolts, passing alternately from one bolt to the opposite one.

Versions with alloy wheels

Proceed as follows:

- insert the wheel on the hub and using the wrench provided tighten the bolts;

- lower the vehicle and remove the jack;

- use the wrench provided to fully tighten the bolts, passing alternately from one bolt to the opposite one.

- reinsert the press-fitted hub cap, making sure that the reference hole on the wheel is aligned with the reference pin on the cap.

IMPORTANT If it is not fitted properly, the hub cap may detach itself when the vehicle is running.

At the end of operation

- stow the space-saver wheel in the compartment provided in the luggage compartment;

- insert the jack and the other tools in the container;

- arrange the container and tools on the space-saver wheel;

- correctly reposition the boot mat.



WARNING

142) The space-saver wheel (for versions/markets where provided) is specific to your car, do not use it on other models, or use the space-saver wheel of other models on your car. The space-saver wheel must only be used in the event of an emergency. Never use it for more than strictly necessary and never exceed 80 km/h. On the space-saver wheel there is an orange label, summarising the main warnings regarding space-saver wheel usage restrictions. Never remove or cover the label. The label contains the following indications in four languages: "Warning! For temporary use only! 80 km/h max! Replace with standard wheel as soon as possible. Never cover this indication." Never apply a wheel cap on a space-saver wheel.

143) Alert other drivers that the car is stationary in compliance with local regulations: hazard warning lights, warning triangle, etc. Any passengers on board should leave the car, especially if it is heavily laden. Passengers should stay away from on-coming traffic while the wheel is being changed. On hills or uneven roads, use chocks or appropriate objects to block the wheels of the vehicle.



144) The vehicle's driving characteristics will be modified with the space-saver wheel fitted. Avoid violent acceleration and braking, abrupt steering and fast cornering. The overall duration of the space-saver wheel is about 3000 km, after which the relevant tyre must be replaced with another one of the same type. Never install a traditional tyre on a rim designed to be used as a space-saver wheel. Have the wheel repaired and refitted as soon as possible. Using two or more space-saver wheels at the same time is forbidden. Do not apply grease to the bolt threads before fitting: they could come unscrewed.

145) The jack is a tool developed and designed only for changing a wheel, if a tyre gets punctured or damaged, on the vehicle with which it is supplied or on other vehicles of the same model. Any other use, e.g. to jack up other vehicle models or different things, is strictly prohibited. Never use for maintenance or repair activities under the car or to exchange the summer/winter wheels and vice versa. Never go under the raised vehicle. If any work under the vehicle is necessary, contact the Fiat Service Network. Incorrect positioning of the jack may cause the raised vehicle to fall: use only in the positions indicated. Do not use the jack for loads higher than the one shown on its label. Never start the engine with vehicle raised. If the vehicle is raised more than necessary, everything can become more unstable, with the risk of the vehicle dropping violently. Thus, lift the vehicle only as needed in order to access the spare wheel.

146) If the hub cap is not fitted correctly, it may come off when the car is travelling. Never tamper with the inflation valve. Never introduce tools of any kind between rim and tyre. Check tyre and space-saver wheel pressures regularly, complying with the values given in the "Technical specifications" chapter.



WARNING

53) When turning the jack handle make sure that it can turn freely without scraping your hand against the ground. The moving components of the jack ("worm screw" and joints) can also cause injuries: avoid touching them. If you come into contact with lubricating grease, clean yourself thoroughly.

54) Contact a Fiat Dealership as soon as possible to have the correct tightening of the wheel bolts checked.


"Fix&Go Airflat" kit



The kit is located in the luggage compartment under the load platform cover.

The kit is composed of:

- ❑ a spray bottle A fig. 115 with the sealant, equipped with filling pipe B, separated by the compressor C;
- ❑ compressor C with pressure gauge, fitting valve to couple the bottle A, cable with supply socket D and pipe E to restore pressure (this is inside the body as shown);
- ❑ adhesive label on the spray bottle A, with the message "max. 80 km/h" to be placed where the driver can easily see it (for example on the dashboard) after repairing the tyre;
- ❑ instruction booklet, explaining the quick and correct use of the Fix&Go;
- ❑ a pair of protective gloves.



115

F1D0147

TYRE REPAIRING AND PRESSURE RESTORING PROCEDURE


55) 56)

147)

Proceed as follows:


□ Position the vehicle in a safe and suitable area and engage the handbrake. Take the kit. Open the cover D (fig. 116) of the compressor B and insert the sealant cartridge A in its compartment, pressing firmly downwards. Remove the adhesive speed label and apply it in a visible position. Wear the protective gloves provided. Remove the valve cap E from the punctured tyre and connect and firmly tighten the transparent sealing fluid tube C.

□ Ensure that the on-off button A (fig. 117) is in the off 0 position. Insert the electrical connector D fig. 115 in the car's 12V socket.



116

F1D0148



117

F1D0149

□ Move the on-off button A fig. 117 to the on I position to switch on the compressor. When the pressure gauge F fig. 116 indicates the right pressure for the car, switch off the compressor by moving the on-off button A to the 0 position. If the pressure gauge F indicates a pressure lower than 1.8 bar / 26 psi 5 minutes after starting the compressor, switch off the compressor, disconnect the sealing fluid tube C (fig. 116) from the tyre valve, retighten the valve cap and move the car about 10 metres to distribute the sealing fluid in the tyre. Stop the car safely and repeat the operation above until the required pressure is reached. If after other 5 min. from the compressor ignition, the pressure gauge F still indicates a pressure lower than 1.8 bar / 26 psi, the TYRE IS TOO DAMAGED AND CANNOT BE REPAIRED. Disconnect, put the kit back in its compartment and call roadside assistance.



❑ If the required pressure is reached, continue driving. Do not exceed 80 km/h. Avoid sudden acceleration or braking. After driving for about 8 km / 5 miles, position the vehicle in a safe and suitable area and engage the handbrake. Take the kit, ensure that the on-off button A (fig. 117) is in the **0** position and insert the electrical connector in the car's 12V socket. Remove the repaired tyre's valve cap, take out the black inflation tube and screw it firmly onto the valve. Inspect the pressure gauge F to check the tyre pressure.

❑ If the pressure is lower than 1.8 bar / 26 psi, the TYRE IS TOO DAMAGED AND CANNOT BE REPAIRED. Disconnect, put the kit back in its compartment and call roadside assistance.


❑ If the pressure is equal to or higher than 1.8 bar / 26 psi, switch on the compressor to reach the required pressure. Disconnect and replace the kit in the specific compartment. Drive carefully to a specialist or the manufacturer's dealership as soon as possible.

PRESSURE RESTORING

Take out the black inflation tube and screw it firmly onto the tyre valve. Press the button B fig. 118 to adjust any tyre overpressure.

CARTRIDGE REPLACEMENT

Only use Fix&Go original cartridges which can be purchased at Fiat Dealership. Press the release button C and lift it to remove the cartridge A fig. 118. Insert the new cartridge and press it firmly downwards.



118

F1D0150



WARNING

147) The information required by the applicable regulation is indicated on the Fix&Go kit package label. Compliance with the indications on the label is an essential condition to ensure the safety and the effectiveness of the Fix&Go kit. Carefully read the label before use, avoid improper use. Fix&Go is subject to expiration and must be replaced periodically. The kit should be used by adults and cannot be used by children.



WARNING

55) Show the package and the label to the personnel charged with handling the tyre treated with the tyre repair kit.

56) Fix&Go provides a temporary repair, therefore the tyre must be examined and repaired by a specialist as soon as possible. The sealing fluid is effective at temperatures between -40°C and +50°C. It is possible to repair tyres which have been damaged on tread up to a diameter of 4mm; however, tyres damaged on their side cannot be repaired. Before using Fix&Go kit, ensure that the tyre isn't excessively damaged and that the rim is in good condition, otherwise do not use it and call roadside assistance. Do not remove foreign bodies from the tyre. Do not let the compressor turned on for more than 20 consecutive minutes - overheating hazard.

JUMP STARTING



If the battery is flat, a jump starting can be performed using the battery and the cables of another vehicle, or using a booster battery.

IMPORTANT

When a booster battery is used, comply with the utilisation and precaution instructions specified by the producer. Do not use the booster battery or any other source of external supply with a voltage above 12 V: the battery, the starter, the alternator and the electrical system of the vehicle could be damaged.

Do not attempt jump starting if the battery is frozen. The battery could break and explode!

PREPARATION TO JUMP STARTING



148) 149)



57) 58)

IMPORTANT The positive terminal (+) of the battery is shielded by a protective cover. Lift the cover to access the positive terminal.
Proceed as follows:

❑ engage the handbrake, move the Dualogic gear lever to P (Park) or, for versions with manual gearbox, to neutral and bring the ignition key to STOP;

❑ switch off all the other electrical devices in the vehicle;

❑ if another vehicle is ready for jump starting, park the vehicle within the reach of the cables to be used for starting, operate the handbrake and make sure that the ignition is deactivated.

IMPORTANT Avoid contact between the two vehicles since this could cause a connection to earth and may result in serious injury to any people nearby.

PROCEDURE FOR JUMP STARTING

IMPORTANT If the procedure below is carried out incorrectly, it can cause severe injury to people or damage the recharging system of one or both vehicles. Carefully follow the instructions given below.

Cable connection

Proceed as follows to carry out a jump starting:

❑ connect one end of the cable used for positive (+) to the positive terminal (+) of the vehicle with flat battery;

❑ connect the other end of the cable used for positive (+) to the positive terminal (+) of the auxiliary battery;

❑ connect one end of the cable used for negative (-) to the negative terminal (-) of the auxiliary battery;

❑ Connect the other end of the cable used for negative (-) to an engine earth (the visible metal part of the vehicle engine with flat battery) away from the battery and the fuel injection system;

❑ start the vehicle engine with the auxiliary battery, let it run for a few minutes at idling. Start the engine of the vehicle with flat battery.

Cable disconnection.

Once the engine has been started, remove the cables proceeding as follows:

❑ disconnect the end of the cable used for negative (-) from the engine earth of the vehicle with flat battery;

❑ disconnect the other end of the cable used for negative (-) from the negative terminal (-) of the auxiliary battery;

❑ disconnect the end of the cable used for positive (+) from the positive terminal (+) of the auxiliary battery;



❑ disconnect one end of the cable used for positive (+) from the positive terminal (+) of the vehicle with flat battery;

If it is often necessary to perform a jump starting, have the vehicle battery and the recharging system checked by a Fiat Dealership.

IMPORTANT Any accessories (e.g. mobile phones, etc.) connected to the vehicle power sockets draw current even if they are not used. These devices, if left connected too much time with engine off, may cause the battery to drain with following reduction of its life and/or failure to start the engine.



WARNING

148) *This procedure must be performed by qualified personnel as incorrect actions may cause high-intensity electrical discharge. Furthermore, battery fluid is poisonous and corrosive: avoid contact with skin and eyes. Keep naked flames and lighted cigarettes away from the battery and do not cause sparks.*

149) *Remove any metal objects (e.g. rings, watches, bracelets), that might cause an accidental electrical contact and cause serious injury.*



WARNING

57) *Do not connect the cable to the negative terminal (–) of the flat battery. The following spark could lead to battery explosion and cause serious harm. Only use the specific earth point; do not use any other exposed metallic part.*

58) *Never use a fast battery-charger to start the engine as this could damage the electronic systems of your vehicle, particularly the ignition and engine fuel supply control units.*

FUEL CUT-OFF SYSTEM



150)

This intervenes in the case of an impact causing:

- ❑ the interruption of the fuel supply with the engine consequently cutting out;
- ❑ the automatic unlocking of the doors;
- ❑ the automatic switching on of the interior lights
- ❑ the switching on of the hazard warning lights.

IMPORTANT Carefully check the car for fuel leaks, for instance in the engine compartment, under the car or near the tank area. After an impact, turn the ignition key to STOP to prevent the battery from running down.

To restore the correct operation of the car, proceed as follows:

- ❑ turn the ignition key to the MAR position;
- ❑ activate the right direction indicator;
- ❑ deactivate the right direction indicator;
- ❑ activate the left direction indicator;
- ❑ deactivate the left direction indicator;
- ❑ activate the right direction indicator;

- ☐ deactivate the right direction indicator;
- ☐ activate the left direction indicator;
- ☐ deactivate the left direction indicator;
- ☐ turn the ignition key to STOP and then to MAR.

LPG versions: in the event of an impact, petrol supply is immediately cut-off, the LPG safety valves are closed and the injection is interrupted, switching off the engine.

Natural Power versions: in the event of an impact, the power supply is immediately cut off, causing engine switching off.



WARNING

150) If, after an impact, you smell fuel or notice leaks from the fuel system, do not reactivate the system to avoid the risk of fire.

TOWING THE VEHICLE




151) 152) 153) 154) 155)

The tow hook, which is supplied with the vehicle, is housed in the tool box, under the carpet in the luggage compartment.


ATTACHING THE TOW HOOK

Manually remove cap A fig. 119 (front bumper) or A fig. 120 (rear bumper), pressing the lower part, take the tow hook B from its housing in the tool box and tighten it completely on the front or rear threaded pin.



119

F1D0094



120

F1D0095

Versions with Duallogic gearbox

Make sure that the gearbox is in neutral (N) (checking that the vehicle moves when pushed) and proceed in the same way as for towing a normal vehicle with a manual gearbox. If the gearbox cannot be put in neutral, do not tow the vehicle and contact a Fiat Dealership.

Panda Cross and Panda 4x4 versions


The vehicle can only be towed in one of the following ways (and always with the engine off, gear set to neutral and handbrake released):

- ☐ with all the wheels on the road surface;
- ☐ with the front (or rear) wheels raised or resting on an emergency vehicle and the rear (or front) wheels resting on a specific trolley;



❑ loaded on the flatbed of the rescue vehicle with all the wheels on the flatbed.

IMPORTANT For Panda Cross versions, the tow hooks A fig. 121 the vehicle is equipped with can only be used for towing it in an emergency.



121

F1D0120



WARNING

151) Before starting towing operations, turn the ignition key to MAR and then to STOP, without extracting it. The steering column will automatically lock when the key is removed and the wheels cannot be steered.

152) Before tightening the ring clean the threaded housing thoroughly. Make sure that the ring is fully fastened in the housing before towing the vehicle.

153) Whilst towing, remember that as the assistance of the brake servo and the electric power steering is not available, greater force needs to be exerted on the brake pedal and more effort is required on the steering wheel. Do not use flexible cables when towing and avoid jerky movements. While towing, make sure that the trailer hitch does not damage any components it is touching. When towing the vehicle, you must comply with all specific traffic regulations, both in terms of the towing device and behaviour on the road. Do not start the engine while towing the vehicle.

154) The front and rear tow hooks should be used only for emergencies on the road. You are allowed to tow the vehicle for short distances using an appropriate device in accordance with the highway code (a rigid bar), to move the vehicle on the road in readiness for towing or transporting via a breakdown vehicle. Tow rings **MUST NOT** be used to tow vehicles off the road or where there are obstacles and/or for towing operations using cables or other non-rigid devices. In compliance with the above conditions, towing must take place with the two vehicles (one towing, the other towed) aligned as much as possible along the same centre line.

155) Do not use tow hooks for securing the vehicle on ships.

SERVICING AND CARE

Correct maintenance permits the performance of the vehicle to be maintained over time, as well as limited running costs and safeguarding the efficiency of the safety systems.

This chapter explains how.

SCHEDULED SERVICING	126
BATTERY RECHARGING	135
ENGINE COMPARTMENT	137
WINDSCREEN / REAR WINDOW WIPERS	142
LIFTING THE VEHICLE.....	143
WHEELS AND TYRES.....	143
BODYWORK.....	144
INTERIOR	144



SCHEDULED SERVICING

Correct servicing is crucial for guaranteeing a long life for the vehicle under the best conditions. For this reason, Fiat has planned a series of checks and services at fixed distance intervals and, where provided, at fixed time intervals, as described in the Scheduled Servicing Plan.

Before each service, it is always necessary to carefully follow the instructions in the Scheduled Servicing Plan (e.g. periodically check level of fluids, tyre pressure, etc.).

Scheduled Servicing is offered by all Fiat Dealerships according to a set time schedule. If, during each operation, in addition to the ones scheduled, the need arises for further replacements or repairs, these may be carried out with the owner's explicit agreement only. If your vehicle is used frequently for towing, the interval between one service operation and the next should be reduced.

IMPORTANT Scheduled Servicing interventions are set out by the Manufacturer. Failure to have them carried out may invalidate the warranty. It is advisable to inform a Fiat Dealership of any small operating irregularities without waiting for the next service.

PERIODIC CHECKS

Every **1,000** km or before long journeys, check and if necessary, top up: engine coolant level; brake fluid level; screen washer fluid level; tyre inflation pressure and condition; lighting system operation (headlights, direction indicators, hazard warning lights, etc.); screen washer/wiper system operation and positioning/wear of windscreen/ rear window wiper blades.

Every **3,000** km, check and top up if required: engine oil level.

DEMANDING USE OF THE CAR

If the vehicle is used under one of the following conditions: towing a trailer or motorhome; dusty roads; short (less than 7-8 km) and repeated journeys with sub-zero outside temperatures; engine often idling or driving long distances at low speed or long periods of inactivity, the following checks must be carried out more often than indicated in the Scheduled Servicing Plan:

- ☐ check front disc brake pad condition and wear;
- ☐ check cleanliness of bonnet and luggage compartment locks, cleanliness and lubrication of linkage;
- ☐ visually inspect conditions of: engine, gearbox, transmission, pipes and hoses (exhaust/fuel system/brakes) and rubber elements (gaiters/sleeves/ bushes, etc.);
- ☐ check battery charge and battery fluid level (electrolyte);
- ☐ visually inspect conditions of the accessory drive belts;
- ☐ check and, if necessary, change engine oil and replace oil filter / pollen filter / air cleaner.

SCHEDULED SERVICING PLAN (petrol versions)

The checks listed in the Scheduled Servicing Plan, after reaching 150,000 km/10 years, must be cyclically repeated starting from the first interval, thus following the same intervals as before.

Thousands of kilometres	15	30	45	60	75	90	105	120	135	150
Years	1	2	3	4	5	6	7	8	9	10
Check tyre condition/wear and adjust pressure, if necessary; check the expiry date of the "Fix&Go Airflat" repair kit (for versions/markets, where provided)	•	•	•	•	•	•	•	•	•	•
Check operation of lighting system (headlights, direction indicators, hazard warning lights, boot, passenger compartment, glove compartment, instrument panel warning lights, etc.)	•	•	•	•	•	•	•	•	•	•
Check and, if necessary, top up fluid levels (1)	•	•	•	•	•	•	•	•	•	•
Check exhaust emissions/smokiness	•	•	•	•	•	•	•	•	•	•
Use the diagnosis socket to check supply/engine management systems operation, emissions and, for versions/markets, where provided, engine oil degradation	•	•	•	•	•	•	•	•	•	•
Visually inspect conditions of: exterior bodywork, underbody protection, pipes and hoses (exhaust, fuel system, brakes), rubber elements (gaiters, sleeves, bushes, etc.)	•		•		•		•		•	
Check windscreen/rear window wiper blade position/wear	•		•		•		•		•	

(1) Always only use the liquids shown in the handbook for topping up after having checked that the system is not damaged.



Thousands of kilometres	15	30	45	60	75	90	105	120	135	150
Years	1	2	3	4	5	6	7	8	9	10
Check operation of the windscreen wiper/washer system and adjust jets, if necessary	●		●		●		●		●	
Check cleanliness of bonnet and luggage compartment locks, cleanliness and lubrication of linkage		●		●		●		●		●
Check handbrake lever travel and adjust, if necessary		●		●		●		●		●
Check and adjust clutch pedal travel (0.9 TwinAir 60HPV/ 65HP and 1.2 8V 69 HP versions only)		●		●		●		●		●
Visually inspect conditions and wear of front disc brake pads and integrity of pad wear indicator	●	●	●	●	●	●	●	●	●	●
Visually inspect condition and wear of rear disc brake pads and integrity of pad wear indicator (Panda Cross and Panda 4x4 versions only)	●	●	●	●	●	●	●	●	●	●
Visually check condition and wear of rear drum brake linings (Panda Cross and Panda 4x4 versions excluded)	●	●	●	●	●	●	●	●	●	●
Visually check conditions of accessory drive belt and control and (for versions without automatic tensioner) check tension			●						●	
Visually inspect conditions of toothed timing drive belt (all 0.9 TwinAir versions excluded)			●						●	
Check tappet clearance and adjust if necessary (1.2 8V 69 HP versions)				●				●		

Thousands of kilometres	15	30	45	60	75	90	105	120	135	150
Years	1	2	3	4	5	6	7	8	9	10
Check and, if necessary, top-up the Dualogic gearbox oil level (2)		•		•		•		•		•
Check manual gearbox with drive transmission idler unit (PTU) oil level (Panda Cross and Panda 4x4 versions only)				•				•		
Check rear differential oil level (Panda Cross and Panda 4x4 versions only)				•				•		
Visually inspect condition of: LPG pipes and connectors, LPG tank fixing (LPG versions only)		•		•		•		•		•
Check fuel system operation and parameters using the diagnosis socket (LPG versions only)		•		•		•		•		•
Visually inspect condition of: methane pipes and connectors and methane cylinder fastening, restore if necessary (Natural Power versions only) (3)		•		•		•		•		•
Check pressure regulator and replace internal filter, if necessary (Natural Power versions only) (3)		•		•		•		•		•
Check fuel system operation and parameters using self-diagnosis socket (Natural Power versions only)		•		•		•		•		•
Check torque tightening of cylinder fastening bands (Natural Power versions only)				•				•		
Check pressure regulator heating pipes sealing (Natural Power versions only)		•		•		•		•		•

(2) Check to be carried out every year for cars on the road in countries with particularly severe climates (cold countries).

(3) Or every year.



Thousands of kilometres	15	30	45	60	75	90	105	120	135	150
Years	1	2	3	4	5	6	7	8	9	10
Check correct fitting of injectors (positioning, clip retention) (Natural Power versions only)		●		●		●		●		●
Change engine oil and replace oil filter (4) (O) (●)	○	●	○	●	○	●	○	●	○	●
Replace spark plugs (1.2 8V 69 HP and 0.9 TwinAir Turbo 80 HP/85 HP versions) (5)		●		●		●		●		●
Replace spark plugs (0.9 TwinAir 60 HP/65 HP) (5)				●				●		
Replace accessory drive belt/s	(6)									

(4) If the vehicle is used mainly on urban routes or the annual distance travelled is less than 10,000 km, the engine oil and engine oil filter must be changed every year.

(O) Recommended operations

(●) Mandatory operations

(5) For 0.9 Twin Air versions, to guarantee correct operation and prevent serious damage to the engine, it is essential to proceed as follows: only use spark plugs specifically certified for these engines; all spark plugs should be of the same type and brand (see the "Engine" paragraph in the "Technical specifications" chapter); strictly comply with the spark plugs replacement intervals in the Scheduled Servicing Plan. It is advisable to contact a FIAT Dealership for plug replacement.

(6) Areas that are not dusty: recommended maximum mileage 120,000 km. The belt must be replaced every 6 years, regardless of distance travelled. Dusty areas and/or demanding use of the vehicle (cold climates, town use, long periods of idling): advised maximum mileage 60,000 km. The belt must be replaced every 4 years, regardless of distance travelled.

Thousands of kilometres	15	30	45	60	75	90	105	120	135	150
Years	1	2	3	4	5	6	7	8	9	10
Replace toothed timing drive belt (all 0.9 TwinAir versions excluded)	(6)									
Replace air cleaner cartridge (7)		●		●		●		●		●
Change the brake fluid	(8)									
Replace filter inside the pressure regulator (LPG versions only)						●				
Replace paper filter (LPG in gaseous state) (LPG versions only)		●		●		●		●		●
Replace the passenger compartment cleaner (7) (O) (●)	○	●	○	●	○	●	○	●	○	●

(6) Areas that are not dusty: recommended maximum mileage 120,000 km. The belt must be replaced every 6 years, regardless of distance travelled. Dusty areas and/or demanding use of the vehicle (cold climates, town use, long periods of idling): advised maximum mileage 60,000 km. The belt must be replaced every 4 years, regardless of distance travelled.

(7) If the vehicle is used in dusty areas, this cleaner must be replaced every 15,000 km

(8) The brake fluid replacement has to be done every two years, irrespective of the mileage

(O) Recommended operations

(●) Mandatory operations



DIESEL VERSIONS

The checks listed in the Scheduled Servicing Plan, after reaching 200,000 km/10 years, must be cyclically repeated starting from the first interval, thus following the same intervals as before.

Thousands of kilometres	20	40	60	80	100	120	140	160	180	200
Years	1	2	3	4	5	6	7	8	9	10
Check tyre condition/wear and adjust pressure, if necessary; check the expiry date of the "Fix&Go Airflat" repair kit (for versions/markets, where provided)	•	•	•	•	•	•	•	•	•	•
Check operation of lighting system (headlights, direction indicators, hazard warning lights, boot, passenger compartment, glove compartment, instrument panel warning lights, etc.)	•	•	•	•	•	•	•	•	•	•
Check and, if necessary, top up fluid levels (1)	•	•	•	•	•	•	•	•	•	•
Check exhaust emissions/smokiness	•	•	•	•	•	•	•	•	•	•
Use the diagnosis socket to check supply/engine management systems operation, emissions and, for versions/markets, where provided, engine oil degradation	•	•	•	•	•	•	•	•	•	•
Visually inspect conditions of: exterior bodywork, underbody protection, pipes and hoses (exhaust, fuel system, brakes), rubber elements (gaiters, sleeves, bushes, etc.)	•		•		•		•		•	
Check windscreen/rear window wiper blade position/wear	•		•		•		•		•	

(1) Always only use the liquids shown in the handbook for topping up after having checked that the system is not damaged.

Thousands of kilometres	20	40	60	80	100	120	140	160	180	200
Years	1	2	3	4	5	6	7	8	9	10
Check operation of the windscreen wiper/washer system and adjust jets, if necessary	●		●		●		●		●	
Check cleanliness of bonnet and luggage compartment locks, cleanliness and lubrication of linkage		●		●		●		●		●
Check handbrake lever travel and adjust, if necessary		●		●		●		●		●
Visually inspect conditions and wear of front disc brake pads and integrity of pad wear indicator	●	●	●	●	●	●	●	●	●	●
Visually inspect condition and wear of rear disc brake pads and integrity of pad wear indicator (Panda Cross and Panda 4x4 versions only)	●	●	●	●	●	●	●	●	●	●
Visually check condition and wear of rear drum brake linings (Panda Cross and Panda 4x4 versions excluded)	●	●	●	●	●	●	●	●	●	●
Visually inspect condition of the accessory drive belt(s)			●						●	
Check drive transmission idler unit (PTU) oil level (Panda Cross and Panda 4x4 versions only)			●			●			●	
Check rear differential oil level (Panda Cross and Panda 4x4 versions only)			●			●			●	
Change engine oil and replace oil filter	(2)									

(2) The actual interval for changing engine oil and replacing the engine oil filter depends on the vehicle usage conditions and is signalled by the warning light or message in the instrument panel. In any case, it must never exceed 2 years. If the vehicle is mainly used in towns and cities, change the engine oil and filter every year.



Thousands of kilometres	20	40	60	80	100	120	140	160	180	200
Years	1	2	3	4	5	6	7	8	9	10
Replace accessory drive belt/s	(3)									
Replace fuel filter cartridge (4)			●			●			●	
Replace air cleaner cartridge (5)		●		●		●		●		●
Change the brake fluid	(6)									
Replace the passenger compartment cleaner (5) (O) (●)	○	●	○	●	○	●	○	●	○	●

(3) Areas that are not dusty: recommended maximum mileage 120,000 km. The belt must be replaced every 6 years, regardless of distance travelled. Dusty areas and/or demanding use of the car (cold climates, town use, long periods of idling): advised maximum mileage 60,000 km. The belt must be replaced every 4 years, regardless of distance travelled.

(4) If the vehicle runs on fuel with quality below the relevant European specification, this filter must be replaced every 20,000 km

(5) If the vehicle is used in dusty areas, this cleaner must be replaced every 20,000 km

(6) The brake fluid replacement has to be done every two years, irrespective of the mileage

(O) Recommended operations

(●) Mandatory operations

BATTERY RECHARGING



156) 157)

IMPORTANT After turning the ignition key to STOP and having closed the driver's side door, wait at least one minute before disconnecting and then reconnecting the battery electrical supply.

IMPORTANT Charging should be slow at a low ampere rating for approximately 24 hours. Charging for a longer time may damage the battery.

IMPORTANT The cables of the electrical system must be correctly reconnected to the battery, i.e. the positive cable (+) to the positive terminal and the negative cable (–) to the negative terminal. The battery terminals are marked with the positive (+) and negative (–) symbols, and are shown on the battery cover. The battery terminals must also be corrosion-free.

IMPORTANT If a "quick-type" battery charger is used with the battery fitted on the vehicle, before connecting it disconnect both cables of the battery itself. Do not use a "quick-type" battery charger to provide the starting voltage.

IMPORTANT The battery recharging procedure is given as information only. You are advised to contact a Fiat Dealership to have this operation performed.

VERSIONS WITHOUT Start&Stop SYSTEM (for versions/markets, where provided)

Charge the battery as follows:


- ☐ disconnect the negative battery terminal;
- ☐ connect the charger cables to the battery terminals, observing the polarity;
- ☐ turn on the charger;
- ☐ when it is recharged, turn the charger off before disconnecting it from the battery;
- ☐ reconnect the negative battery terminal.

VERSIONS WITH Stop/Start SYSTEM (for versions/markets, where provided)

To recharge, proceed as follows:

- ☐ disconnect the connector A fig. 122 (pressing the button B) from the sensor C monitoring the battery conditions, on the negative pole D of the battery;
- ☐ connect the positive cable of the battery charger to the positive battery pole E and the negative cable to the terminal of sensor D;

- ☐ turn on the battery charger. At the end of the charging process, switch the battery charger off;
- ☐ after having disconnected the charging device, reconnect the connector A to the sensor C.



122

F1D0136



**WARNING**

156) *Battery fluid is poisonous and corrosive: avoid contact with your skin and eyes. The battery should be charged in a well ventilated place, away from naked flames or possible sources of sparks: danger of explosion and fire.*

157) *Do not attempt to charge a frozen battery: it must be thawed first, otherwise it may explode. If freezing has occurred, the battery should be checked by skilled personnel to make sure that the internal elements are not damaged and that the body is not cracked, with the risk of leaking poisonous and corrosive acid.*


ENGINE COMPARTMENT



CHECKING LEVELS

⚠ 158) 159) ⚠ 59)

0.9 TwinAir/0.9 TwinAir Turbo versions




123

F1D0097

A. Engine oil plug / filler -- B. Engine oil dipstick -- C. Engine coolant -- D. Washer fluid for windscreen/rear window -- E. Brake fluid -- F. Battery




1.2 8V 69 HP versions

124

F1D0098

A. Engine oil plug / filler -- B. Engine oil dipstick -- C. Engine coolant -- D. Washer fluid for windscreen/rear window -- E. Brake fluid -- F. Battery

1.3 16V MultiJet versions




125

F1D0141

A. Engine oil plug / filler -- B. Engine oil dipstick -- C. Engine coolant -- D. Washer fluid for windscreen/rear window -- E. Brake fluid -- F. Battery



ENGINE OIL

Check the oil level a few minutes (about five) after the engine has stopped, with the vehicle parked on level ground. Check that the oil level is between the MIN and MAX references on the dipstick B. If the oil level is near or even under the MIN mark, add oil using the filler A to reach the MAX mark.

NOTE For the 0.9 TwinAir and 0.9 TwinAir Turbo versions, engine oil dipstick B is integral with the cap A. Take out the engine oil dipstick A, clean it with a lint-free cloth and reinsert it. Extract it again and check that the level is between the MIN and MAX marks on the dipstick.

Engine oil consumption

The maximum engine oil consumption is usually 400 grams every 1000 km. During the initial period of use the engine oil consumption conditions should be considered as having stabilised after the first 5000 - 6000 km.

IMPORTANT After adding or changing the oil, let the engine run for a few seconds and wait a few minutes after switching it off before checking the level.

ENGINE COOLANT FLUID

The coolant level must be checked when the engine is cold and must range between the MIN and MAX marks on the reservoir.

If the level is too low, unscrew reservoir cap C and add the fluid described in the "Technical Specifications" section.

WINDSCREEN/REAR WINDOW WASHING FLUID


If the level is too low, raise reservoir cap D (see previous pages) and add the fluid described in the chapter "Technical Specifications".

BRAKE FLUID

Check that the fluid is at the maximum level (the fluid level in the reservoir must not exceed the MAX mark). If the fluid level in the reservoir is too low, undo reservoir cap E and add the fluid described in the "Technical Specifications" chapter.

DUALOGIC GEARBOX HYDRAULIC ACTIVATION SYSTEM OIL

The fluid level should only be checked at a Fiat Dealership.

BATTERY

Battery F does not require topping up the electrolyte with distilled water. A periodic check carried out at a Fiat Dealership is, however, necessary to check efficiency.

IMPORTANT After the battery is disconnected, the steering must be initialised. The warning light on the instrument panel switches on to indicate this. To carry out this procedure turn the steering wheel all the way from one end to the other or drive in a straight line for about a hundred metres.

IMPORTANT If the charge level remains under 50% for a long time, the battery is damaged by sulphation, reducing its capacity and efficiency at start-up.

CLIMATE CONTROL SYSTEM MAINTENANCE

In winter, the climate control system must be turned on at least once a month for about 10 minutes. Before summer, have the system checked at a Fiat Dealership.



WARNING

158) Never smoke while working in the engine compartment: gas and inflammable vapours may be present, with the risk of fire.

159) Be very careful when working in the engine compartment when the engine is hot: you may get burned.

160) The cooling system is pressurised. If necessary, only replace the plug with another original or the operation of the system may be adversely affected. Do not remove the reservoir plug when the engine is hot: you risk scalding yourself.

161) Do not travel with the windscreen washer fluid reservoir empty: the windscreen washer is essential for improving visibility. Some commercial windscreen washer additives are flammable. The engine compartment contains hot components which may set it on fire.

162) Brake fluid is poisonous and highly corrosive. In the event of accidental contact, immediately wash the affected parts with water and mild soap. Then rinse thoroughly. Call a doctor immediately if swallowed.

163) The symbol , on the brake fluid container indicates if a brake fluid is synthetic or mineral-based. Use of mineral type fluids will damage the special rubber seals of the braking system beyond repair.

164) Battery fluid is poisonous and corrosive. Avoid contact with the skin and eyes. Keep naked flames and sources of sparks away from the battery: risk of explosion and fire.

165) Using the battery with insufficient fluid irreparably damages the battery and may cause an explosion.

166) If the car will be unused for an extended period of time in extremely cold weather conditions, remove the battery and store it in a heated area to avoid it freezing.

167) Always wear appropriate goggles when working on or near the battery.



WARNING

59) Be careful not to confuse the various types of fluids while topping up: they are not compatible with each other! Topping up with an unsuitable fluid could severely damage your vehicle.

60) The oil level must never exceed the MAX reference.

61) Do not add oil with specifications other than those of the oil already existing in the engine.

62) PARAFLU ^{UP} antifreeze is used in the engine cooling system. Use the same fluid as in the cooling system when topping up. PARAFLU ^{UP} cannot be mixed with any other type of fluid. If this occurs, do not start the engine and contact your Fiat Dealership immediately.

63) Prevent brake fluid, which is highly corrosive, from coming into contact with painted parts. Should it happen, immediately wash with water.

64) Incorrect installation of electric and electronic devices may cause severe damage to your car. After purchasing your vehicle, if you wish to install any accessories (anti-theft, phone, etc.), contact a Fiat Dealership, which will suggest the most appropriate devices for your vehicle, and will, most importantly, advise you if a higher capacity battery needs to be installed.



WARNING

3) Used engine oil and oil filters contain substances which are harmful to the environment. To change the oil and filters, we advise you to contact a Fiat Dealership.

4) Used transmission fluid contains substances that are harmful to the environment. It is advisable to have the oil changed by a Fiat Dealership where it will be disposed of respecting the environment and according to legal requirements.

5) Batteries contain substances which are very dangerous for the environment. For battery replacement, contact a Fiat Dealership.




WINDSCREEN / REAR WINDOW WIPERS



168) 65)

REPLACING THE WINDSCREEN WIPER BLADES

- raise the wiper arm, press tab A fig. 126 of the attachment spring and remove the blade from the arm;
- fit the new blade, inserting the tab into the special slot in the arm, making sure that it is locked;
- lower the wiper arm onto the windscreen.




126

F1D0100

REPLACING THE REAR WINDOW WIPER BLADE

Proceed as follows:

- raise the cover A fig. 127, undo the nut B and remove the arm C;
- correctly position the new arm, fully tighten the nut B then lower the cover A.



127

F1D0101

NOZZLES

Windscreen washer

The windscreen washer jets can be adjusted rotating the side notch with a screwdriver. If there is no jet of fluid, firstly check that there is fluid in the reservoir (see "Checking fluid levels" in this chapter). Then check that the nozzle holes are not clogged; use a needle to unblock them if necessary.

Rear window washer

The rear window washer jets are fixed. The nozzle holder is located above the rear window.



WARNING

168) Driving with worn windscreen/rear window wiper blades is a serious hazard, because visibility is reduced in bad weather.



WARNING


65) Do not operate the windscreen wiper with the blades lifted from the windscreen.

LIFTING THE VEHICLE



169)

If the vehicle needs to be raised, go to a Fiat Dealership which is equipped with arm lifts and workshop lifts fig. 128.



128

F1D0135



WARNING

169) Lift the vehicle exclusively by positioning the jack arms or the workshop jack in the points illustrated.

WHEELS AND TYRES



LUM



170) 171)



66) 67) 68) 69)

SUGGESTIONS ABOUT THE ROTATION OF THE TYRES

The front and rear tyres are subject to different loads and stress due to steering, manoeuvres and braking. For this reason they are subject to uneven wear.

To resolve this problem, tyres should be rotated at the appropriate time. This operation is recommended for tyres with a deep tread pattern, suitable both for on-road and off-road driving. Tyre rotation contributes to the preservation of the grip and traction performance on wet, muddy or snowy roads, guaranteeing optimal driveability of the vehicle. In the case of irregular wear of the tyres, the reason must be identified and corrected before rotating them.



WARNING

170) Do not cross switch the tyres if they are "unidirectional" type. In this case, always take care not to fit the tyres with a direction of rotation that is opposite to that indicated: you would risk losing grip and control of the vehicle.

171) Travelling with partially or completely deflated tyres can cause safety problems and damage the concerned tyre beyond repair.



WARNING

66) The road holding qualities of the car also depend on the correct inflation pressure of the tyres.

67) If tyre pressure is too low, the tyre may overheat and be severely damaged as a result.

68) Do not switch tyres from the right-hand side of the vehicle to the left-hand side, and vice versa.

69) Never submit alloy rims to repainting treatments requiring the use of temperatures exceeding 150°C. The mechanical properties of the wheels could be impaired.



BODYWORK

PRESERVING THE BODYWORK

Paint



70)



6)

To correctly wash the car, proceed as follows:

- ☐ remove the aerial from the roof to prevent damage to it if the car is washed in an automatic system;
 - ☐ if high pressure jets or cleaners are used to wash the vehicle, keep a distance of at least 40 cm from the bodywork to avoid damage or alteration. It should be remembered that the build up of water can damage the car over a period of time;
 - ☐ wash the bodywork using a low pressure jet of water;
 - ☐ wipe a sponge with a slightly soapy solution over the bodywork, frequently rinsing the sponge;
 - ☐ rinse well with water and dry with a jet of air or a chamois.
- Dry the less visible parts (e.g. door frames, bonnet, headlight frames etc.) with special care, as water may stagnate more easily in these areas. The car should not be taken to a closed area immediately, but left outside so that residual water can evaporate.

Do not wash the car after it has been left in the sun or with the bonnet hot: this may alter the shine of the paintwork.

Exterior plastic parts must be cleaned in the same way as the rest of the vehicle.

Avoid parking under trees; the resin dropped by trees makes the paintwork go opaque and increases the possibility of corrosion.

IMPORTANT Bird droppings should be washed off immediately and thoroughly as the acid they contain is particularly aggressive.



WARNING

70) *In order to preserve the aesthetic appearance of the paint, abrasive products and/or polishes should not be used for cleaning the vehicle.*



WARNING

6) *Detergents pollute the environment. Only wash your vehicle in areas equipped to collect and treat wastewater from this type of activity.*

INTERIOR

SEATS AND FABRIC PARTS

Remove dust with a soft brush or a vacuum cleaner.

Rub the seats with a sponge moistened with a solution of water and neutral detergent.

WARNING To avoid ruining the upholstery, do not use acetone, acetic alcohol, denatured ethyl alcohol or any highly aggressive solvents or detergents to clean the fabric parts. Use spotting agents such as isopropyl alcohol or dry stain removers.

TECHNICAL DATA



Everything you may find useful for understanding how your vehicle is made and works is contained in this chapter and illustrated with data, tables and graphics. For the enthusiasts and the technician, but also just for those who want to know every detail of their vehicle.

IDENTIFICATION DATA.....	146
ENGINE	147
WHEELS	151
DIMENSIONS.....	158
WEIGHTS.....	161
REFUELLING	166
FLUIDS AND LUBRICANTS	168
PERFORMANCE	172
FUEL CONSUMPTION	173
CO ₂ EMISSIONS	175
PRESCRIPTIONS FOR HANDLING THE VEHICLE AT THE END OF ITS LIFE	176



IDENTIFICATION DATA

VEHICLE IDENTIFICATION NUMBER (VIN) PLATE

Depending on the version, the plate fig. 129 may be located to the right or at the centre of the luggage compartment (lift the carpet covering to access it). It contains the following data:



129

F1D0142

- A** Name of Manufacturer
- B** Type-approval number.
- C** Vehicle type identification code.
- D** Chassis serial number.
- E** Maximum permitted weight of vehicle fully laden.
- F** Maximum permitted weight of vehicle fully laden plus trailer.
- G** Maximum permitted weight on first axle (front).

H Maximum permitted weight on second axle (rear).

I Engine type.

L Bodywork version code.

M Spare part number.

N Correct value of smoke coefficient (for diesel engines).

BODYWORK PAINT IDENTIFICATION PLATE


This is applied inside the bonnet (left side) and bears the following data fig. 130:

A Paint manufacturer.

B Colour name.

C Fiat colour code.

D Respray and touch up code.



130

F1D0128

CHASSIS MARKING

This is located on the right side of the luggage compartment rear floor and gives the following identification data:

☐ type of vehicle;

☐ chassis serial number.

ENGINE MARKING

It is stamped on the cylinder block and includes the type and the engine serial number.

ENGINE

Versions	1.2 8V 69 HP	1.2 8V 69 HP LPG	
Engine code	169A4000	169A4000	
Cycle	Otto	Otto	
Number and position of cylinders	4 in line	4 in line	
Piston bore and stroke (mm)	70.8 × 78.86	70.8 × 78.86	
Total displacement (cm³)	1242	1242	
Compression ratio	11.1: 1	11.1: 1	
		LPG	Petrol
Maximum power (EC) (kW)	51	51	51
Maximum power (EEC) (HP)	69	69	69
corresponding engine speed (rpm)	5500	5500	5500
Maximum torque (EC) (Nm)	102	102	102
Maximum torque (EC) (kgm)	10.4	10.4	10.4
corresponding engine speed (rpm)	3000	3000	3000
Spark plugs	NGK ZKR7A-10 or CHAMPION RA8MCX4		NGK ZKR7AI-8
Fuel	Unleaded petrol 95 R.O.N. (EN 228 specifications)	LPG for motor vehicles (EN589 Specification)	Unleaded petrol 95 R.O.N. (EN 228 specifications)



Versions	0.9 TwinAir 60 HP (*)	0.9 TwinAir 65 HP	0.9 TwinAir Turbo 80 HP (*)
Engine code	312A6000	312A4000	312A5000
Cycle	Otto	Otto	Otto
Number and position of cylinders	2 in line	2 in line	2 in line
Piston bore and stroke (mm)	83.5 × 88	83.5 × 88	80.5 × 86
Total displacement (cm³)	964	964	875
Compression ratio	11.1: 1	11.1: 1	10: 1
Maximum power (EC) (kW)	44	48	59
Maximum power (EEC) (HP)	60	65	80
corresponding engine speed (rpm)	6250	6250	5500
Maximum torque (EC) (Nm)	88	88	145
Maximum torque (EC) (kgm)	8.9	8.9	14.8
corresponding engine speed (rpm)	3500	3500	1900
Spark plugs	NGK T20182U	NGK LKR7DI-12	NGK PLKR9C8
Fuel	Unleaded petrol 95 R.O.N. (EN 228 specifications)	Unleaded petrol 95 R.O.N. (EN 228 specifications)	Unleaded petrol 95 R.O.N. (EN 228 specifications)

(*) For versions/markets, where provided

Versions	0.9 TwinAir Turbo 85 HP	0.9 TwinAir Turbo Natural Power	
Engine code	312A2000	312A2000	
Cycle	Otto	Otto	
Number and position of cylinders	2 in line	2 in line	
Piston bore and stroke (mm)	80.5 × 86.0	80.5 × 86.0	
Total displacement (cm³)	875	875	
Compression ratio	10: 1	10: 1	
		Methane	Petrol
Maximum power (EC) (kW)	62.5 / 57 (*)	59	62.5
Maximum power (EEC) (HP)	85 / 77.5(*)	80	85
corresponding engine speed (rpm)	5500	5500	5500
Maximum torque (EC) (Nm)	145 / 100 (*)	140	145
Maximum torque (EC) (kgm)	14.8 / 10.2 (*)	14.3	14.8
corresponding engine speed (rpm)	1900 / 2000 (*)	2500	1900
Spark plugs	NGK ILKR9G8	NGK ILKR9G8	
Fuel	Unleaded petrol 95 R.O.N. (EN 228 specifications)	Methane for motor vehicles	Unleaded petrol 95 R.O.N. (EN 228 specifications)

(*) With ECO button pressed



Versions	0.9 TwinAir Turbo 90 HP (*)	1.3 16V Multijet 95 HP	1.3 16V MultiJet 80 HP
Engine code	312A7000	312B1000 / 330A1000(°)	312B2000 / 225A2000 (°°)
Cycle	Otto	Diesel	Diesel
Number and position of cylinders	2 in line	4 in line	4 in line
Piston bore and stroke (mm)	80.5 × 86.0	69.6 × 82	69.6 × 82
Total displacement (cm³)	875	1248	1248
Compression ratio	10: 1	16.8: 1	16.8: 1
Maximum power (EC) (kW)	66.2 / 57 (**)	70	59
Maximum power (EEC) (HP)	90 / 77.5 (**)	95	80
corresponding engine speed (rpm)	5500	3750	3750
Maximum torque (EC) (Nm)	145 / 100 (**)	200	200
Maximum torque (EC) (kgm)	14.8 / 10.2 (**)	20.4	20.4
corresponding engine speed (rpm)	1900 / 2000 (**)	1500	1500
Spark plugs	NGK ILKR9G8	-	-
Fuel	Unleaded petrol 95 R.O.N. (EN 228 specifications)	Diesel for motor vehicles (EN590 Specification)	Diesel for motor vehicles (EN590 Specification)

(*) For versions/markets, where provided

(°) 4x4 and Cross Versions

(°°) 4x4 versions

(**) With ECO button pressed

WHEELS



172) 173) 174)

Alloy or pressed steel rims. Tubeless radial carcass tyres.

All approved tyres are listed in the Registration Document.

IMPORTANT If there are any discrepancies between the Owner Handbook and the Registration Document, take the information from the latter. For safe driving, the car must be fitted with tyres of the same make and type on all wheels.

IMPORTANT Do not use inner tubes with Tubeless tyres.

RIMS AND TYRES PROVIDED

Panda versions

Versions	Wheels	Tyres provided	Snow tyres	Space saver spare wheel (*)
0.9 TwinAir 60 HP (*)	5,5J x 14H2 - ET35	175/65 R14 82T (**)	175/65 R14 82Q (M+S)	135/80 R14 84M
	5,5J x 14H2 - ET35	175/65 R14 82T (**)	175/65 R14 82Q (M+S)	135/80 R14 84M
0.9 TwinAir 65 HP	5,5J x 14H2 - ET35	175/65 R14 82T Goodyear Duragrip (**) (***)	175/65 R14 82Q (M+S)	135/80 R14 84M
	6J x 15H2 - ET35 (****)	185/55 R15 82T (°)	185/55 R15 82Q (M+S)	135/80 R14 84M

(*) For versions/markets, where provided.

(**) The tyre can be fitted with size 9 mm snow chains.

(***) For versions/markets, where provided. Tyres offering equivalent performance can be used as an alternative.

(****) Alloy wheel rim.

(°) Not suitable for chains.



Versions	Wheels	Tyres provided	Snow tyres	Space saver spare wheel (*)
0.9 TwinAir 80 HP (*)	5,5J x 14H2 - ET35	175/65 R14 82T (**)	175/65 R14 82Q (M+S)	135/80 R14 84M
	5,5J x 14H2 - ET35	175/65 R14 82T (**)	175/65 R14 82Q (M+S)	135/80 R14 84M
0.9 TwinAir Turbo 85 HP	5,5J x 14H2 - ET35	175/65 R14 82T Goodyear Duragrip (**) (***)	175/65 R14 82Q (M+S)	135/80 R14 84M
	6J x 15H2 - ET35 (****)	185/55 R15 82T (°)	185/55 R15 82Q (M+S)	135/80 R14 84M
0.9 TwinAir Turbo Natural Power	6J x 15H2 - ET 35 (****)	175/65 R15 84T (°°°)	175/65 R15 84Q (M+S)	-
	5,5J x 14H2 - ET35	165/65 R14 79T (*)	175/65 R14 79Q (M+S)	135/80 R14 84M
	5,5J x 14H2 - ET35	165/70 R14 81T (*)	175/65 R14 81Q (M+S)	135/80 R14 84M
1.2 8V 69 HP	5,5J x 14H2 - ET35	175/65 R14 82T (**)	175/65 R14 82Q (M+S)	135/80 R14 84M
	6J x 15H2 - ET35 (****)	185/55 R15 82T (°)	185/55 R15 82Q (M+S)	135/80 R14 84M
	5,5J x 14H2 - ET35	175/65 R14 82T	175/65 R14 84Q (M+S)	135/80 R14 84P 135/80 R14 80P reinforced 135/80 R14 84M
1.2 8V 69 HP S&S	6J x 15H2 - ET35	185/55 R15 82T	185/55 R15 82Q (M+S)	
	6,5J x 16H2 - ET35	195/45 R16 84T	195/45 R16 84Q (M+S)	
1.3 16V Multijet	5,5J x 14H2 - ET35	175/65 R14 82T (**)	175/65 R14 82Q (M+S)	135/80 R14 84M
	6J x 15H2 - ET35	185/55 R15 82H	185/55 R15 82Q (M+S)	135/80 R14 84M

(*) For versions/markets, where provided.

(**) The tyre can be fitted with size 9 mm snow chains.

(***) For versions/markets, where provided. Tyres offering equivalent performance can be used as an alternative.

(****) Alloy wheel rim.

(°) Not suitable for chains.

(°°°) Tyre to which chains can be fitted, with reduced size chains: 7 mm.

Panda 4x4 versions

Versions	Wheels	Tyres provided	Snow tyres	Space saver spare wheel (*)
0.9 TwinAir Turbo 85 HP	5,5J x 14H2 - ET35	175/65 R14 82T (**)	175/65 R14 84Q (M+S)	135/80 R14 84M
	5,5J x 14H2 - ET35	175/65 R14 82T Goodyear Duragrip (**) (***)	175/65 R14 84Q (M+S)	135/80 R14 84M
	6J x 15H2 - ET35	175/65 R15 84T (M+S)(°)	175/65 R15 84T (M+S)	125/80 R15 95M
	6J x 15H2 - ET35	175/65 R15 84T (°) (°°)	175/65 R15 84Q (M+S)	125/80 R15 95M
1.3 16V Multijet	6J x 15H2 - ET35	175/65 R15 84T (M+S) (°)	175/65 R15 84T (M+S)	125/80 R15 95M
	6J x 15H2 - ET35	175/65 R15 84T (°)	175/65 R15 84Q (M+S)	125/80 R15 95M

(*) For versions/markets, where provided.

(**) The tyre can be fitted with size 9 mm snow chains.

(***) For versions/markets, where provided. Tyres offering equivalent performance can be used as an alternative.

(°) Tyres to which reduced size snow chains can be fitted: 7 mm.

(°°) Tyres available on request.



Panda Cross versions

Versions	Wheels	Tyres provided	Snow tyres	Space saver spare wheel (*)
0.9 TwinAir Turbo 90 HP	6 J x 15H2 ET35	175/65 R15 84T (M+S) (**)	175/65 R15 84T (M+S)	125/80 R15 95M
	6 J x 15H2 ET35	175/65 R15 84T (**)	175/65 R15 84Q (M+S)	125/80 R15 95M
	6 J x 15H2 ET30	185/65 R15 88H (M+S) (***)	185/65 R15 88Q (M+S)	125/80 R15 95M
	6 J x 15H2 ET30	185/65 R15 88H(***)	185/65 R15 88Q (M+S)	125/80 R15 95M
1.3 16V Multijet	6 J x 15H2 ET35	175/65 R15 84T (M+S) (**)	175/65 R15 84T (M+S)	125/80 R15 95M
	6 J x 15H2 ET35	175/65 R15 84T (**)	175/65 R15 84Q (M+S)	125/80 R15 95M
	6 J x 15H2 ET30	185/65 R15 88H (M+S) (***)	185/65 R15 88H (M+S)	125/80 R15 95M
	6 J x 15H2 ET30	185/65 R15 88H(***)	185/65 R15 88Q (M+S)	125/80 R15 95M

(*) For versions/markets, where provided.

(**) The tyre can be fitted with chains.

(***) Tyre not suitable for fitting snow chains.

Note For Panda Cross and Panda 4x4 versions if the space-saver wheel is used, the control unit for 4x4 drive detects its presence (via the wheel speed signals) and reduces the intervention of the four-wheel drive to a minimum, while guaranteeing the agility of the vehicle. No fault/alarm signal is displayed on the instrument panel or on the display.

COLD TYRE INFLATION PRESSURE (bar)

When the tires are warm, the inflation pressure should be + 0.3 bar in relation to the recommended figure. However, recheck that the value is correct with the tyre cold. With snow tyres, add +0.2 bar to the pressure value prescribed for standard tyres.

Panda versions

Tyres	Unladen/medium load		Full load		Space saver spare wheel (*)
	Front	Rear	Front	Rear	
165/65 R14 79T	2.5	2.2	2.7	2.4	2.8
165/70 R14 81T (*)	2.3	2.0	2.5	2.2	2.8
175/65 R14 82T	2.2 / 2.5 (**)	2.0 / 2.5 (**) / 2.1 (***)	2.5	2.5	2.8
185/55 R15 82T	2.2	2.0	2.5	2.5	2.8
185/55 R15 82H	2.2	2.0	2.5	2.5	2.8

(*) For versions/markets, where provided

(**) 0.9 TwinAir 60 HP/80 HP engines

(***) Natural Power versions



Panda Cross / Panda 4x4 versions

Tyres	Unladen/medium load		Full load		Space saver spare wheel (°)
	Front	Rear	Front	Rear	
175/65 R14 82T M+S (*)	2.2	2.1	2.5	2.5	4.2
175/65 R15 84T (*)	2.2	2.1	2.5	2.5	4.2
175/65 R15 84T (**)	2.4	2.2	2.7	2.7	4.2
185/65 R15 88H (**)	2.4	2.2	2.7	2.7	4.2

(°) For versions/markets, where provided.

(*) For Panda 4x4 versions

(**) For Panda Cross versions

Note For Cross and 4x4 versions, do not drive deliberately for long distances with the tyres flat (not at the prescribed pressure) and/or with greatly varying pressures between front axle and rear axle, in order to avoid any malfunction of the 4x4 drive.

SNOW CHAINS

 175) 176) 177)  71)

Important notes

The use of snow chains should be in compliance with local regulations of each country. In certain countries, tyres marked with code M+S (Mud and Snow) are considered as winter equipment; therefore their use is equivalent to that of the snow chains. The snow chains may be applied only to the front wheel tyres.

Check the tension of the snow chains after the first few metres have been driven.

Using snow chains with tyres with non-original dimensions may damage the vehicle.

Using different size or type (M+S, snow, etc.) tyres between front and rear axle may adversely affect vehicle driveability, with the risk of losing control of the vehicle and resulting accidents.

Snow chains cannot be fitted to the space-saver wheel (for versions/markets, where provided). If a front tyre is punctured, replace a rear wheel with the space-saver wheel and move the rear wheel to the front axle. In this way, with two normal drive wheels at the front, snow chains can be fitted.



WARNING

172) The maximum speed for snow tyres marked "Q" is 160 km/h, while it is 190 km/h for "T" tyres and 210 km/h for "H" tyres. The highway code speed limits must however always be complied with.

173) 185/55 R15 82T tyres cannot be fitted with chains.

174) 175/65 R14 82T tyres can be fitted with reduced size snow chains: 9 mm.

175) 175/65 R15 84T tyres can be fitted with reduced size snow chains: 7 mm.

176) Keep the vehicle's speed down when snow chains are fitted; never exceed 50 km/h. Avoid potholes, do not drive over steps or pavements and do not drive long distances over roads without snow, to avoid damaging both your vehicle and the road surface.

177) DO NOT fit wheel hub caps when using integral hub caps fixed (with springs) to the steel rim and after sale tyres provided with Rim Protector. Use of unsuitable tyres and wheel caps may cause sudden decrease of tyre pressure.



WARNING

71) With snow chains, use the accelerator with extreme care to prevent, or to limit as much as possible, slipping of the drive wheels that could cause chain breakage, resulting in damage to the car body or mechanical components.




DIMENSIONS

Dimensions are expressed in mm and refer to the vehicle equipped with its standard-supplied tyres. Height is measured with vehicle unladen.

LUGGAGE COMPARTMENT CAPACITY Capacity (VDA standards) =225 litres

Panda versions




131

F1D0103

A	B	C	D	E	F	G	H	I
3653	747	2300	606	1551/1605(*)	1407/1408(*)	1643	1409/1414(*)	1882

(*) Natural Power versions.

Panda 4x4 versions



132


F1D0104

A	B	C	D	E	F	G	H	I
3686 / 3653(*)	765 / 747	2300	621 / 606 (*)	1605	1408	1672/1643(*)	1411	1882

(*) VAN versions.



Panda Cross versions



133

F1D0121

A	B	C	D	E	F	G	H	I
3705	772.5	2300	632.5	1656.5	1406	1662	1403	1882

WEIGHTS

Panda versions

Weights (kg)	0.9 TwinAir 60HP / 65HP	0.9 TwinAir Turbo 80HP / 85HP	0.9 TwinAir Turbo Natural Power
Unladen weight (with all fluids, fuel tank 90% full and without optional equipment):	955	975 / 980	1080/1090 (***)
Payload including the driver: (*)	480 (4-seater) / 500 (5-seater)	480 (4-seater) / 500 (5-seater)	460 (4-seater) /450(***) (4-seater) / 470 (5-seater) / 460(***) (5-seater)
Maximum permitted loads (**)			
- front axle:	770	855	875
- rear axle:	760	760	810
- total:	1435 (4-seater) / 1455 (5-seater)	1455 (4-seater) / 1460 (4-seater) (°) / 1475 (5-seater) / 1480 (5-seater) (°)	1540 (4-seater) / 1550 (5-seater)
Towable loads			
- braked trailer:	800	800	(°°)
- non-braked trailer:	400	400	(°°)
Maximum load on roof:	55	55	55
Maximum load on ball joint (braked trailer):	60	60	(°°)

(***) For versions/markets, where foreseen

(*) If special equipment is fitted (trailer towing equipment, etc.) the empty weight will increase and consequently the payload will decrease in relation to the maximum permitted loads.

(**) Loads not to be exceeded. The user is responsible for arranging goods in the luggage compartment and/or load platform within the maximum permitted loads.

(°) Versions equipped with the "Dualogic" gearbox

(°°) **IMPORTANT A trailer cannot be towed so there are no provisions for fitting a tow hook.**



Weights (kg)	1.2 8V 69 HP	1.2 8V 69 HP LPG	1.3 16V Multijet 80HP/95HP
Unladen weight (with all fluids, fuel tank 90% full and without optional equipment):	940/965(****)	980	1045
Payload including the driver: (*)	480 (4-seater) / 455(****) (4-seater) / 500 (5-seater) / 475(****) (5-seater)	470	480 (4-seater)(1) / 470 (4-seater) (2) / 500 (5-seater)(1) / 490 (5-seater) (2)
Maximum permitted loads (**)			
- front axle:	770	770	855
- rear axle:	760	760	760
- total:	1420 (4-seater) / 1440 (5-seater)	1450	1515 (4-seater) / 1535 (5-seater)
Towable loads			
- braked trailer:	800	(***)	900
- non-braked trailer:	400	(***)	400
Maximum load on roof:	55	55	55
Maximum load on ball joint (braked trailer):	60	(***)	60

(****) For versions/markets, where foreseen

(*) If special equipment is fitted (trailer towing equipment, etc.) the empty weight will increase and consequently the payload will decrease in relation to the maximum permitted loads.

(1) 80 HP

(2) 95 HP

(**) Loads not to be exceeded. The user is responsible for arranging goods in the luggage compartment and/or load platform within the maximum permitted loads.

(***) **IMPORTANT A trailer cannot be towed so there are no provisions for fitting a tow hook.**

Panda Cross and Panda 4x4 versions

Weights (kg)	0.9 TwinAir Turbo 85 HP	0.9 TwinAir Turbo 90 HP	1.3 16V Multijet 80HP/95HP
Unladen weight (with all fluids, fuel tank 90% full and without optional equipment):	1050	1090	1125 (°) / 1165 (°°)
Payload including the driver: (*)	480 (4-seater) / 500 (5-seater)	440 (4-seater) / 495 (5-seater)	470 (4-seater) (°) / 430 (4-seater) (°°) / 490 (5-seater) (°) / 460 (5-seater) (°°)
Maximum permitted loads (**)			
- front axle:	875	875	875
- rear axle:	810	810	810
- total:	1530 (4-seater) / 1550 (5-seater)	1530 (4-seater) / 1585 (5-seater)	1595 (4-seater) / 1615 (5-seater) (°) / 1625 (5-seater) (°°)
Towable loads			
- braked trailer:	800	800	900
- non-braked trailer:	400	400	400
Maximum load on roof:	55	60 (***)	60 (***) (°°)
Maximum load on ball joint (braked trailer):	60	60	60

(°) Panda 4x4 versions

(°°) Panda Cross versions

(*) If special equipment is fitted (trailer towing equipment, etc.) the empty weight will increase and consequently the payload will decrease in relation to the maximum permitted loads.

(**) Loads not to be exceeded. The user is responsible for arranging goods in the luggage compartment and/or load platform within the maximum permitted loads.

(***) Load evenly distributed



Panda VAN versions

Weights (kg)	0.9 TwinAir 65 HP	0.9 TwinAir Turbo 85 HP	0.9 TwinAir Turbo 85 HP 4x4	0.9 TwinAir Turbo Natural Power
Unladen weight (with all fluids, fuel tank 90% full and without optional equipment):	950 (2-seater) / 960 (4-seater)	980	1035	1075
Payload including the driver: (*)	505 (2-seater) / 490 (4-seater)	500 (2-seater) / 490 (4-seater)	510	420 (°) / 460
Maximum permitted loads (**)				
- front axle:	770	855	875	875
- rear axle:	770 (2-seater) / 780 (4-seater)	770 (2-seater) / 780 (4-seater)	810	810
- total:	1455 (2-seater) / 1450 (4-seater)	1480 (2-seater) / 1470 (4-seater)	1545	1495 (°) / 1535
Towable loads				
- braked trailer:	800	800	800	(***)
- non-braked trailer:	400	400	400	(***)
Maximum load on roof:	60	60	60	60
Maximum load on ball joint (braked trailer):	60	60	60	(***)

(*) If special equipment is fitted (trailer towing equipment, etc.) the empty weight will increase and consequently the payload will decrease in relation to the maximum permitted loads.

(°) Versions with reduced capacity

(**) Loads not to be exceeded. The user is responsible for arranging goods in the luggage compartment and/or load platform within the maximum permitted loads.

(***) **IMPORTANT A trailer cannot be towed so there are no provisions for fitting a tow hook.**

Weights (kg)	1.2 8V 69 HP	1.2 8V 69 HP LPG	1.3 16V MultiJet 80 HP	1.3 16V MultiJet 4x4 80 HP
Unladen weight (with all fluids, fuel tank 90% full and without optional equipment):	935 (2-seater) / 945 (4-seater)	975	1040 (2-seater) / 1050 (4-seater)	1110
Payload including the driver: (*)	505 (2-seater) / 490 (4-seater)	470	400 (2-seater) ^(°) / 495 (2-seater) / 485 (4-seater)	485
Maximum permitted loads (**)				
- front axle:	770	770	855 (2-seater) / 875 (4-seater)	875
- rear axle:	770 (2-seater) / 780 (4-seater)	770	770 (2-seater) / 780 (4-seater)	810
- total:	1440 (2-seater) / 1435 (4-seater)	1445	1440 (2-seater) ^(°) / 1535 (2-seater) / 1535 (4-seater)	1595
Towable loads				
- braked trailer:	800	(***)	900	900
- non-braked trailer:	400	(***)	400	400
Maximum load on roof:	60	60	60	-
Maximum load on ball joint (braked trailer):	60	(***)	60	60

(*) If special equipment is fitted (trailer towing equipment, etc.) the empty weight will increase and consequently the payload will decrease in relation to the maximum permitted loads.

(°) Versions with reduced capacity

(**) Loads not to be exceeded. The user is responsible for arranging goods in the luggage compartment and/or load platform within the maximum permitted loads.

(***) **IMPORTANT A trailer cannot be towed so there are no provisions for fitting a tow hook.**



REFUELLING

	0.9 TwinAir 60HP/65HP	0.9 TwinAir Turbo	1.2 8V 69 HP	Prescribed fuels and original lubricants
Fuel tank (litres):	37	37	37	Unleaded petrol with R.O.N. no lower than 95 (EN 228 specifications)
including a reserve of (litres):	5 - 7	5 - 7	5 - 7	
Engine cooling system (litres):	4.8	5.2	4.6	Mixture of distilled water and PARAFLU ^{UP} liquid at 50% (**)
Engine sump (litres):	2.8	2.8	2.5	SELENIA DIGITEK P.E (0.9 TwinAir and 0.9 TwinAir Turbo versions) / SELENIA K P.E. (1.2 8V 69 HP versions) / SELENIA MULTIPower GAS 5W-40 (LPG versions)
Engine sump and filter (litres):	3.2	3.2	2.8	
Gearbox casing/differential:	1.65 (litres)	1.65 (litres) / (1.7) kg (***)	1.65 (litres)	TUTELA TRANSMISSION TECHNYX (0.9 TwinAir and 0.9 TwinAir Turbo versions) / TUTELA TRANSMISSION GEARFORCE (1.2 8V 69HP, LPG and Natural Power versions)
Rear differential (kg) (**):	-	0.62	-	TUTELA TRANSMISSION CROSS
Dualogic gearbox hydraulic activation system (litres):	-	0.7	-	TUTELA CS SPEED
Hydraulic brake circuit (litres):	0.55	0.55	0.55	TUTELA TOP 4 or TUTELA TOP 4/S
Windscreen and rear window washer fluid reservoir (litres):	2.7	2.7	2.7	Mixture of water and PETRONAS DURANCE SC35

(**) When the vehicle is used in particularly harsh weather conditions, we recommend using a mixture of 60% PARAFLU^{UP} and 40% demineralised water.

(***) Panda Cross and Panda 4x4 versions

	1.3 16V Multijet	1.3 16V Multijet Cross / 4x4	Prescribed fuels and original lubricants
Fuel tank (litres):	37	35	Diesel for motor vehicles (EN590 Specification)
including a reserve of (litres):	5 - 7	5 - 7	
Engine cooling system (litres):	6.3	6.3	Mixture of distilled water and PARAFLU ^{UP} liquid at 50% (**)
Engine sump (litres):	3.7	3.7	SELENIA WR FORWARD
Engine sump and filter (litres):	3.9	3.9	
Gearbox casing/front differential (kg):	1.8	1.70	TUTELA TRANSMISSION GEARFORCE
Drive transmission idler unit (PTU) (kg):	-	0.39	TUTELA TRANSMISSION MULTIAxLE
Rear differential (kg):	-	0.62	TUTELA TRANSMISSION CROSS
Hydraulic brake circuit (litres):	0.55	0.55	TUTELA TOP 4 or TUTELA TOP 4/S
Windscreen and rear window washer fluid reservoir (litres):	2.7	2.7	Mixture of water and PETRONAS DURANCE SC35

(**) When the vehicle is used in particularly harsh weather conditions, we recommend using a mixture of 60% PARAFLU^{UP} and 40% demineralised water.



FLUIDS AND LUBRICANTS

Your vehicle is equipped with an engine oil that has been thoroughly developed and tested in order to meet the requirements of the Scheduled Servicing Plan. Constant use of the prescribed lubricants guarantees the fuel consumption and emission specifications. Lubricant quality is crucial for engine operation and duration.



Use	Features	Specification	Original fluids and lubricants	Replacement interval
Lubricants for petrol engines and 1.2 8V 69HP	SAE 5W-40 ACEA C3 / API SN.	9.55535-S2	SELENIA K P.E. Contractual Technical Reference No. F603.C07	According to Scheduled Service Plan
Lubricants for petrol engines 0.9 TwinAir and 0.9 TwinAir Turbo	SAE 0W-30 ACEA C2 / API SN.	9.55535-GS1	SELENIA DIGITEK P.E. Contractual Technical Reference No. F020.B12	According to Scheduled Service Plan
Lubricant for petrol/methane engines	SAE 0W-30 ACEA C2 / API SN.	9.55535-GS1	SELENIA DIGITEK P.E. Contractual Technical Reference No. F020.B12	According to Scheduled Service Plan

If lubricants conforming to the required specifications are not available, products that meet the indicated specifications can be used to top up; in this case optimal performance of the engine is not guaranteed.

Use	Features	Specification	Original fluids and lubricants	Replacement interval
Lubricant for petrol/ LPG engines	SAE 5W-40 ACEA C3 / API SN.	9.55535-T2	SELENIA MULTIPOWER GAS 5W-40 Contractual Technical Reference No. F922.E09	According to Scheduled Service Plan
Diesel engine lubricants	SAE 0W-30 ACEA C2.	9.55535-DS1 or MS.90047	SELENIA WR FORWARD Contractual Technical Reference No. F842.F13	According to Scheduled Service Plan



WARNING

72) The use of products with different specifications than those indicated above could cause damage to the engine not covered by the warranty.



Use	Features	Specification	Original fluids and lubricants	Apps
Lubricants and greases for drive transmission	SAE 75W- 85 grade synthetic lubricant. 9.55550-MX3	9.55550-MX3	TUTELA TRANSMISSION TECHNIX Contractual Technical Reference No. F010.B05	Manual gearbox and differential (0.9 TwinAir and 0.9 TwinAir Turbo versions)
	SAE 75W grade synthetic lubricant.	9.55550-MZ6 or MS.90030-M1	TUTELA TRANSMISSION GEARFORCE Contractual Technical Reference No. F002.F10	Manual gearbox and differential (1.3 16V Multijet, LPG, and 1.2 8V 69HP and Natural Power versions)
	Fully synthetic oil with dedicated additive.	9.55550-SA1 or MS.90030-H1	TUTELA CS SPEED Contractual Technical Reference No. F005.F98	Dualogic gearbox hydraulic activation system
	SAE 75W-85 grade synthetic lubricant.	9.55550 - DA4	TUTELA TRANSMISSION CROSS Contractual Technical Reference No. F001.D12	Rear differential (°)
	SAE 75W-85 grade synthetic lubricant, which exceeds API GL5 specifications.	9.55550 - DA3	TUTELA TRANSMISSION MULTIAxLE Contractual Technical Reference No. F426.E06	Drive transmission idler unit (PTU) (°)
	Molybdenum disulphide grease, for use at high temperatures. N.L.G.I. consistency 1-2.	9.55580 - GRASS II	TUTELA ALL STAR Contractual Technical Reference No. F702.G07	Wheel side constant velocity joints
	Low friction coefficient grease for constant velocity joints. N.L.G.I. consistency 0-1.	9.55580 - GRASS II	TUTELA STAR 700 Contractual Technical Reference No. F701.C07	Differential side constant velocity joints

(°) Panda Cross and Panda 4x4 versions.

Use	Features	Specification	Original fluids and lubricants	Apps
Brake fluid	Synthetic fluid for brake and clutch systems. Exceeds specifications: FMVSS no. 116 DOT 4, ISO 4925 SAE J1704.	9.55597 or MS.90039	TUTELA TOP 4 Contractual Technical Reference No. F001.A93 or TUTELA TOP 4/S Contractual Technical Reference No. F005.F15	Hydraulic brakes and hydraulic clutch controls
Protective agent for radiators	Protective agent with antifreeze action with organic formulation. CUNA NC 956-16, ASTM D 3306 Specifications.	9.55523 or MS.90032	PARAFLU^{UP} (*) Contractual Technical Reference No. F101.M01	Cooling circuits proportions of use: 50% water 50% PARAFLU^{UP} (**)
Diesel fuel additive	Additive for Diesel with antifreeze and protective action for Diesel engines	-	TUTELA DIESEL ART Contractual Technical Reference No. F601.L06	To be mixed with diesel (25 cc per 10 litres)
Windscreen/rear window washer fluid	Mixture of spirits and surfactants. Exceeds CUNA NC 956-11 specifications.	9.55522 or MS.90043	PETRONAS DURANCE SC35 Contractual Technical Reference No. F001.D16	To be used diluted or undiluted in windscreen washer/wiper systems

(*) IMPORTANT Do not top up or mix with other fluids which have different specifications from those described.

(**) When the vehicle is used in particularly harsh weather conditions, we recommend using a mixture of 60% **PARAFLU^{UP}** and 40% demineralised water.



PERFORMANCE

Top speeds after the initial period of usage of the vehicle.

Versions	km/h
0.9 TwinAir 60 HP (*)	158 in 4th gear
0.9 TwinAir 65 HP	160
0.9 TwinAir Turbo 80 HP (*)	175
0.9 TwinAir Turbo 80 HP Dualogic (*)	175
0.9 TwinAir Turbo 85 HP	177
0.9 TwinAir Turbo 85 HP Dualogic (*)	177
0.9 TwinAir Turbo 85 HP 4x4	166
0.9 TwinAir Turbo 90 HP Cross	167
0.9 TwinAir Turbo Natural Power	170 (°) / 168(°°)
1.2 8V 69 HP	164
1.2 8V 69 HP LPG	164
1.3 16V MultiJet 80 HP	170
1.3 16V Multijet 80 HP 4x4	160
1.3 16V Multijet 95 HP	182
1.3 16V Multijet 95 HP 4x4	167
1.3 16V Multijet 95 HP Cross	168

(*) For versions/markets, where provided

(°) Running on petrol

(°°) Running on methane

FUEL CONSUMPTION

The fuel consumption figures given in the tables below are determined on the basis of the type-approval tests laid down by specific European Directives.

IMPORTANT The type of route, traffic conditions, weather conditions, driving style, general condition of the car, trim level/equipment/accessories, use of the climate control system, car load, presence of roof racks and other situations that adversely affect the aerodynamics or wind resistance lead to different fuel consumption values than those measured. The fuel consumption will get more regular only after having driven the first 3000 km.

FUEL CONSUMPTION ACCORDING TO THE CURRENT EUROPEAN DIRECTIVE (litres/100 km)

NOTE Consumption of methane-fuelled Natural Power versions is intended in m³/100 km.

Versions	Urban	Extra-urban	Combined
0.9 TwinAir 60 HP (*)	4.5	3.4	3.8
0.9 TwinAir 65 HP	5.0 / 4.8 (*)	3.8 / 3.7 (*)	4.2 / 4.1 (*)
0.9 TwinAir Turbo 80 HP (*)	4.4	3.4	3.8
0.9 TwinAir Turbo 80 HP Dualogic (*)	4.4	3.4	3.8
0.9 TwinAir Turbo 85 HP	5.0 / 4.9 (*)	3.8	4.2
0.9 TwinAir Turbo 85 HP Dualogic	4.8	3.7	4.1
0.9 TwinAir Turbo 85 HP 4x4	5.9	4.3	4.9
0.9 TwinAir Turbo 90 HP	5.9	4.3	4.9
0.9 TwinAir Turbo Natural Power	5.8 (°) / 6.0 (°°)	3.8 (°) / 4.0 (°°)	4.5 (°) / 4.7 (°°)
1.2 8V 69 HP	6.7 / 6.5 (*) / 5.9 (*)	4.3 / 4.2 (*) / 4.0 (*)	5.2 / 5.0 (*) / 4.7 (*)
1.2 8V 69 HP S&S	5.9	4.0	4.7

(*) For versions/markets, where provided.

(°) Running on petrol

(°°) Running on methane



Versions	Urban	Extra-urban	Combined
1.2 8V 69 HP LPG	6.6 (°) / 6.9 (°°°)	4.3 (°) / 6.3 (°°°)	5.1 (°) / 6.5 (°°°)
1.3 16V MultiJet 80 HP	4.3	3.2	3.6
1.3 16V Multijet 80HP 4x4	4.7	4.3	4.4
1.3 16V MultiJet 95 HP	4.3	3.2	3.6
1.3 16V MultiJet 95 HP 4x4	4.7	4.3	4.4
1.3 16V MultiJet 95 HP Cross	4.8	4.4	4.8

(°) Running on petrol

(°°°) Running on LPG

CO₂ EMISSIONS

The CO₂ emission levels given in the following tables refer to combined consumption.

Versions	CO ₂ EMISSIONS ACCORDING TO CURRENT EUROPEAN DIRECTIVE (g/km)
0.9 TwinAir 60 HP (*)	88
0.9 TwinAir 65 HP	99 / 95 (*)
0.9 TwinAir Turbo 80 HP (*)	88
0.9 TwinAir Turbo 80 HP Dualogic (*)	88
0.9 TwinAir Turbo 85 HP	99 / 97 (*)
0.9 TwinAir Turbo 85 HP Dualogic	95
0.9 TwinAir Turbo 85 HP 4x4	114
0.9 TwinAir Turbo 90 HP Cross	114
0.9 TwinAir Turbo Natural Power	106 (°) / 85 (°°)
1.2 8V 69 HP	120 / 117 (*) / 119 (*) / 110 (*)
1.2 8V 69 HP S&S	110
1.2 8V 69 HP LPG	119 (°) / 106 (°°°)
1.3 16V MultiJet 80 HP	94
1.3 16V Multijet 80HP 4x4	117
1.3 16V MultiJet 95 HP	94
1.3 16V MultiJet 95 HP 4x4	117
1.3 16V MultiJet 95 HP Cross	119

(*) For versions/markets, where provided.

(°) Running on petrol.

(°°) Running on methane.

(°°°) Running on LPG.



PRESCRIPTIONS FOR HANDLING THE VEHICLE AT THE END OF ITS LIFE

(Where provided)

FCA has been committed for many years to safeguarding the environment through the constant improvement of its production processes and manufacturing products that are increasingly "eco-compatible". To grant customers the best possible service in terms of respecting environmental laws and in response to European Directive 2000/53/EC governing vehicles at the end of their life, FCA is offering its customers the chance to hand over their vehicle at the end of its life without incurring any additional costs. The European Directive sets out that when the vehicle is handed over, the last keeper or owner should not incur any expenses as a result of it having a zero or negative market value.

To hand your vehicle over at the end of its life without extra cost, contact one of our dealerships if you are purchasing another vehicle or an FCA-authorized collection and scrapping centre. These centres have been carefully chosen to offer high quality service for the collection, treatment and recycling of vehicles at their end of life, respecting the surrounding environment. You can find further information on these collection and scrapping centres either from an FCA dealership or by calling the number in the Warranty Booklet or by consulting the websites of the various FCA brands.

MULTIMEDIA



This chapter describes the main functions of the radio and of the Uconnect Radio that may be fitted on the vehicle.

RADIO.....	178
UCONNECT RADIO	186
DASHBOARD (RIGHT-HAND DRIVE VERSION)	201
CONTROL PANEL AND ON-BOARD INSTRUMENTS	202
REPLACING FUSES.....	203
PARKING	203



RADIO



178) 179) 180) 181) 182) 183)

The radio has been designed according to the specifications of the passenger compartment, with a personalised design matching the style of the dashboard perfectly.

TIPS

Road safety

Please, learn how to use all different radio functions (e.g. save stations) before beginning to drive.

Care and maintenance

Clean the cover with a soft anti-static cloth only. Cleaning and polishing products may damage the surface.

ANTITHEFT PROTECTION

The radio is equipped with an anti-theft protection system based on the exchange of information between the radio and the electronic control unit (Body Computer) present on the vehicle.

This system guarantees maximum safety and prevents the secret code from being entered each time the radio power supply is disconnected.

If the check has a positive outcome, the radio will start to function, whereas if the comparison codes are not the same or if the electronic control unit (Body Computer) is replaced, the device will ask the user to enter the secret code according to the procedure described in the paragraph below.

Entering the secret code

When the radio is switched on, if the password is requested, the display will show "Radio code" for about 2 seconds, followed by four dashes "- - - -".

The secret code is made up of four digits from 1 to 6, each corresponding to one of the dashes.

To enter the first digit of the code, press the button corresponding to the pre-selected stations (from 1 to 6).

Enter the other code digits in the same way.

If the four digits are not entered within 20 seconds, the display shows the text "Enter code - - - -". If this occurs, it is not considered an incorrect code entry.

After entering the fourth digit (within 20 seconds), the car radio will work.

If an incorrect code is entered, the radio will emit a sound and the display shows the text "Radio blocked/wait" to notify the user of the need to enter the correct code.

Each time the user enters an incorrect code, the waiting time will gradually increase (1 min, 2 min, 4 min, 8 min, 16 min, 30 min, 1h, 2h, 4h, 8h, 16h, 24h) up to a maximum of 24 hours.


The waiting time will be shown on the display with the text "Radio blocked/wait". After the text has disappeared it is possible to start the code entering procedure again.

Vehicle radio passport

This document certifies the ownership of the vehicle radio. The radio passport shows the radio model, serial number and secret code.

IMPORTANT Keep the radio passport in a safe place so that you can give the information to the relevant authorities if the radio is stolen.

In the case of loss of the vehicle radio passport, contact the Fiat Dealership, taking an ID document and the vehicle ownership documents.



134

F1D0695



General functions


Button	Functions	Mode
	Ignition	short button press
	Switching off	short button press
	Volume adjustment	LH/RH knob rotation
FM AS	FM1, FM2, FM Autostore radio source selection	short cyclical button press
AM	MW1, MW2 radio source selection	short cyclical button press
MEDIA	CD source selection	short cyclical button press
	Volume activation/deactivation (Mute/Pause)	Short button press
	Audio adjustments: low tones (BASS), high tones (TREBLE), RH/LH balance (BALANCE), front/rear balance (FADER)	Menu activation: short button press Adjustment type selection: press ▲ or ▼ buttons. Value adjustment: press ◀ or ▶ buttons.
MENU	Advanced functions adjustment	Menu activation: short button press Adjustment type selection: press ▲ or ▼ buttons. Value adjustment: press ◀ or ▶ buttons.

Radio functions

Button	Functions	Mode
	Radio station search: ☐ Automatic search ☐ Manual search	Automatic search: press ◀ or ▶ buttons (hold the button down for fast forward) Manual search: press ▲ or ▼ buttons (hold the button down for fast forward)
1 2 3 4 5 6	Store current radio station	Long button press for memory preset from 1 to 6
	Stored station recall	Brief button press for memory preset from 1 to 6

CD functions

Button	Functions	Mode
▲	CD ejection	Short button press
◀	Play previous/next track	Brief press of ◀ or ▶ buttons
▶	Fast forwarding/rewinding CD track	Long press of ◀ or ▶ buttons
▲▼	Playing previous/next folder (for CD-MP3)	Brief press of ▲ or ▼ buttons



GENERAL INFORMATION

The radio offers the following functions:

Radio section

- ☐ PLL tuning with FM/AM/MW frequency bands;
- ☐ RDS (Radio Data System) with TA (traffic alerts) function - TP (traffic programmes) - EON (Enhanced Other Network) - REG (regional programmes);
- ☐ AF: search selection for alternative frequencies in RDS mode;
- ☐ provision for emergency alarm;
- ☐ automatic/manual tuning into stations;
- ☐ FM Multipath detector;
- ☐ manual storing of 30 stations: 18 on FM band (6 on FM1, 6 on FM2, 6 on FMT), 12 on MW band (6 on MW1, 6 on MW2);
- ☐ automatic programming (Autostore function) of 6 stations on dedicated FM band
- ☐ SPEED VOLUME function: automatic volume adjustment according to the vehicle speed;
- ☐ automatic Stereo/Mono selection.

CD section

- ☐ Direct selection of the disc;
- ☐ Track selection (forward/back);
- ☐ Fast advance (forward/back) through tracks;

- ☐ CD Display function: display of disc name and time elapsed since the start of the track

- ☐ Playing of audio CDs, CD-Rs and CD-RWs.

MP3 CD section

- ☐ MP3-Info function (ID3-TAG);
- ☐ Folder selection (previous/next);
- ☐ Track selection (forward/back);
- ☐ Fast advance (forward/back) through tracks;
- ☐ MP3 Display function: display of name of folder, ID3-TAG information, time elapsed since the start of the track, name of the file
- ☐ Playing of audio or data CD, CD-R and CD-RW.

Audio section

- ☐ Mute/Pause function;
- ☐ Soft-Mute function;
- ☐ Loudness function
- ☐ 7-band graphic equaliser;
- ☐ Separate bass/treble adjustment
- ☐ Right/left channel balance.

FUNCTIONS AND ADJUSTMENTS

Turning the car radio on

The car radio comes on when the  (ON/OFF) button/knob is pressed briefly.

When the radio is turned on with the key extracted from the ignition switch, it turns off automatically after about 20 minutes. After the radio has switched itself off automatically it can be turned on for a further 20 minutes by pressing the  (ON/OFF) button/knob.

Turning the car radio off

Briefly press the  (ON/OFF) button/knob.

Volume adjustment

Turn the  (ON/OFF) button/knob to adjust the volume.

If the volume level is changed during the transmission of traffic news, the new setting will only be maintained until the news is finished.

MUTE/Pause function

(setting volume to zero)

Press the  button briefly to activate the Mute function. The volume will gradually decrease and the words "RADIO Mute" will be displayed (in radio mode) or "PAUSE" (in CD mode).

Press the  button again to deactivate the Mute function. The volume will gradually increase until it reaches the level set previously.

Audio settings

The functions that can be selected from the audio menu change depending on the context: AM/FM/CD.

Press the  button briefly to change the Audio functions.

After the  button is first pressed, the display will show the bass level value for the source activated at that time (e.g. in FM mode the display will show the wording "FM Bass +2").

Use the  or  buttons to scroll through the menu functions. To change the setting of the function selected use the  or  buttons. The current status of the selected function appears on the display.

The functions managed by the Menu are:

-  BASS: adjustment of bass tones;
-  TREBLE: adjustment of high tones;
-  BALANCE: right/left balance adjustment;
-  FADER: front/back balance adjustment;
-  LOUDNESS: activation/deactivation of the increase of bass and high tones;

-  EQUALISER: activation and selection of factory-set equaliser levels;
-  USER EQUALISER: customised equaliser setting.

MENU

MENU button function

Press the button MENU briefly to activate the Menu function. The display will show the first menu item that can be adjusted (AF) ("AF Switching On" on the display).

Use the  or  buttons to scroll through the Menu functions. To change the setting of the function selected use the  or  buttons.

The current status of the selected function appears on the display.

The functions managed by the Menu are:

-  AF SWITCHING: automatic activation/deactivation of the selection of the station with the strongest signal that transmits the same programme.
-  TRAFFIC INFORMATION: activation/deactivation of traffic information (only on FM band).
-  REGIONAL MODE: activation/deactivation of regional programmes.
-  MP3 DISPLAY: CD MP3 display setting.
-  SPEED VOLUME: speed-dependent automatic volume control.

-  RADIO ON VOLUME: maximum radio volume limit activation/deactivation.

-  RADIO OFF: off mode selection.

-  SYSTEM RESET: reset of factory settings.

Press the button MENU again to exit the Menu function.

Note The AF SWITCHING, TRAFFIC INFORMATION and REGIONAL MODE adjustments are only possible in FM mode.

RADIO (Tuner)

To select the Radio function when another audio source is being listened to, briefly press the FM, AS or AM buttons, depending on the desired band.

Once the Radio mode has been activated, the display will show the name (only RDS stations) and the frequency of the selected radio station, the frequency band selected (e.g. FM1) and the preselect button number (e.g. P1).

Frequency band selection

With the Radio mode active, press the FM, AS or AM button briefly and repeatedly to select the desired reception band.



Each time the button is pressed, the AM and FM bands are selected cyclically:

Preset buttons

The buttons numbered from 1 to 6 are used to set the following preset stations:

□ 18 in the FM band (6 in FM1, 6 in FM2, 6 in FMT or "FMA" (on some versions);

□ 12 in the MW band (6 in MW1, 6 in MW2).

To listen to a preset station, select the desired frequency band and then press the corresponding preset button briefly (from 1 to 6).

By pressing the preset button for more than 2 seconds, the tuned station will be stored. The storing phase is confirmed by an acoustic signal.

Automatic tuning

Briefly press the ◀ or ▶ button to start the automatic tuning search for the next station that can be received in the selected direction.

Manual tuning

Select the desired frequency band and then press the ▲ or ▼ button briefly and repeatedly to start to the search in the desired direction. If the ▲ or ▼ button is pressed longer, the fast search will start and then stop when the button is released.

CD PLAYER

To activate the CD player built-into the equipment, proceed as follows:

□ insert a CD with the equipment switched on: the first track will start to play;
or

□ if a CD has already been loaded, switch on the radio and then briefly press the CD button to select the "CD" operating mode: the last track listened to will start to play.

It is advisable to use original CDs to ensure optimal playback. If CD-R/RW are used, we recommend using good quality media that are burned at the slowest speed possible.

CD loading/ejection

To load the CD, insert it gently into the slot to activate the motorised loading system, which will position it correctly.

Press the ▲ (EJECT) button with the radio on to activate the motorised ejection of the CD. After ejection, the last audio source listened to before playing the CD will be heard.



Indications on the display

When the CD player is in operation, information appears on the display with the following meanings:

□ "CD Track 5": indicates the number of the CD track;

□ "03:42": indicates the time elapsed since the start of the track (if the respective Menu function is activated).

Track selection (forward/back)

Briefly press the ◀ button to play the previous CD track and the ▶ button to play the next track.

Fast forward/rewind through tracks

Hold down the ◀ button to fast forward the selected track or hold down the ▶ button to fast rewind the track.

The fast forward/rewind will stop once the button is released.

"Pause" function

To pause the CD player, press the  button. The words "CD Pause" will appear on the display.

To resume listening to the track, press the  button again. If another audio source is selected, the pause function is deactivated.

CD MP3 PLAYER

In addition to playing normal audio CDs, the car radio can also play CD-ROMs on which MP3 format compressed audio files are recorded. The radio operates as described in the "CD Player" chapter when an ordinary audio CD is inserted.

Selecting next/previous folder

Press the  button to select one of the next folders or press the  button to select a previous folder.

The display will show the number and the name of the folder (e.g. "DIR 2 XXXXXX").

If no other folder/track is selected during the next 2 seconds, the first track contained in the new folder will be played.

If the last track in the folder at that moment selected is played, the next folder will be played.



WARNING

178) If the volume is too loud this could be dangerous for the driver and for passengers when driving in traffic. Always adjust the volume so that you can still hear background noises.

179) Multimedia CDs include data tracks in addition to the audio tracks. Playing this type of CD can cause hissing at a volume that may jeopardise road safety as well as cause damage to the final stages and the speakers.

180) Using some of the system functions whilst driving can distract attention away from the road, risking an accident or other serious consequences; they should therefore be used only when driving conditions allow it and, if necessary, only with the vehicle stationary.

181) WARNING: Looking at the system when driving can divert attention from the road, with the risk of accidents or other serious consequences. Do not change the system settings or load data while driving. Stop the vehicle in a safe and legal manner before carrying out these operations. Adopting these precautions is important since setting or changing some functions may require the driver to be distracted from the road and remove their hands from the steering wheel.

182) Looking at the display for a long time: while driving, do not use any function that requires looking at the display for a long time. Pull over in a safe and legal manner before attempting to access a function of the system that requires prolonged attention. Even occasional short glances at the display may be hazardous if your attention is diverted from driving at a critical moment.

183) Setting the volume: do not turn the volume up too high. Keep the volume at a level where you can still hear outside traffic and emergency signals while driving. Driving while unable to hear these sounds may cause an accident.



WARNING

73) Do not press the eject button accidentally when inserting a CD.



Uconnect RADIO



(184) (185) (186) (187) (188) (189) (190) (191) (192) (193)

The Uconnect Radio was designed according to the specific characteristics of the passenger compartment, with a customised design that perfectly matches matching the style of the dashboard.

The instructions for use are given below and we recommend you to read them carefully.

TIPS

Familiarise yourself with the various functions of the Uconnect Radio (for example, storing the stations) before starting to drive.

Reception conditions

Reception conditions change constantly while driving. Reception may be interfered with by the presence of mountains, buildings or bridges, especially when you are far away from the broadcaster.

IMPORTANT The volume may be increased when receiving traffic bulletins.

Care and maintenance

Only clean the cover with a soft, anti-static cloth. Cleaning and polishing products may damage the surface.

ANTITHEFT PROTECTION

The Uconnect Radio is equipped with an anti-theft protection system based on the exchange of information between the Uconnect Radio and the electronic control unit (Body Computer) present on the vehicle.

This system guarantees maximum safety and prevents the secret code from being entered each time the Uconnect Radio power supply is disconnected.

If the check has a positive outcome, the Uconnect Radio will start to operate, whereas if the comparison codes are not the same or if the electronic control unit (Body Computer) is replaced, the device will ask the user to enter the secret code according to the procedure described in the paragraph below.

Entering the secret code

When the Uconnect Radio is switched on, if the password is requested, the display will show "Radio code" for about 2 seconds, followed by four dashes "- - - -".

The secret code is made up of four digits from 1 to 6, each corresponding to one of the dashes.

To enter the first digit of the code, press the button corresponding to the pre-selected stations (from 1 to 6). Enter the other code digits in the same way.

If the four digits are not entered within 20 seconds, the display shows the text "Enter code - - - -". If this occurs, it is not considered an incorrect code entry. After entering the fourth digit (within 20 seconds), the Uconnect Radio will start to operate.

If an incorrect code is entered, the Uconnect Radio will emit a sound and the display shows the text "Radio blocked/wait" to notify the user of the need to enter the correct code. Each time the user enters an incorrect code, the waiting time will gradually increase (1 min, 2 min, 4 min, 8 min, 16 min, 30 min, 1h, 2h, 4h, 8h, 16h, 24h) up to a maximum of 24 hours.

The waiting time will be shown on the display with the text "Radio blocked/wait". After the text has disappeared it is possible to start the code entering procedure again.

Vehicle radio passport

This document certifies ownership of the Uconnect Radio. The radio passport shows the Uconnect Radio model, serial number and secret code.

IMPORTANT Keep the radio passport in a safe place so that you can give the information to the relevant authorities if the Uconnect Radio is stolen.

In the case of loss of the vehicle radio passport, contact the Fiat Dealership, taking an ID document and the vehicle ownership documents.



QUICK GUIDE

135

F1D0707

General functions


Button	Functions	Mode
	Switching on	short button press
	Switching off	long button press
	Volume adjustment	turn knob
RADIO	Select the radio source FM, AM, DAB (where present)	short cyclical button press
ABC – 1 2 3 4 5 6	Select preset ranges	short cyclical button press
MEDIA	Select Audio Bluetooth ®, USB/iPod, AUX	short cyclical button press
 (Play/Pause)	Activate Play/Pause for the Media source Activate Mute for the Radio and AUX sources	Short button press
	Audio adjustments: low tones (BASS), high tones (TREBLE), RH/LH balance (BALANCE), front/rear balance (FADER)	Menu activation: short button press Adjustment type selection: press ▲ or ▼ buttons. Value adjustment: press ◀ or ▶ buttons.
MENU	Advanced functions adjustment	Menu activation: short button press Adjustment type selection: press ▲ or ▼ buttons. Value adjustment: press ◀ or ▶ buttons.



Radio functions

Button	Functions	Mode
▲ ▼ ◀ ▶	Radio station search: ☐ Automatic search ☐ Manual search	Automatic search: press ◀ or ▶ buttons (hold the button down for fast forward) Manual search: press ▲ or ▼ buttons (hold the button down for fast forward)
1 2 3 4 5 6	Store current radio station Stored station recall Brief button press for memory preset from 1 to 6	Long button press for memory preset from 1 to 6

STEERING WHEEL CONTROLS



136

F1D0106



Button	Functions	Mode
	☐ Enable/disable Audio Mute ☐ Return to the previous menu mode function	Short button press
+	Increasing volume	Button press
-	Decreasing volume	Button press
SRC	Select sources FM, AM, DAB (where present), Bluetooth® Audio, USB and AUX	Button press
	Radio: automatic search for the next tunable broadcaster - USB/iPod source: selecting the next track	Button press
	Radio: automatic search for the previous tunable broadcaster - USB/iPod source: selecting the previous track	Button press

Multimedia support function

Button	Functions
	☐ Accept an incoming phone call
	☐ End the phone call in progress ☐ Reject an incoming phone call
	Deactivate a voice recognition ☐ Activate/deactivate Audio Mute ☐ Interrupt the reading of an SMS message ☐ Exit from the Main Menu of Bluetooth® ☐ Exit from a submenu and return to previous menu option ☐ Exit from the current menu option without saving ☐ Deactivate/reactivate the microphone during a phone conversation ☐ Mute the volume of the call tone for incoming phone calls

Button	Functions
	☐ Activation of voice recognition ☐ Interruption of the voice message in order to give a new voice command
+/-	☐ Adjust the audio volume of all functions: hands-free, text message reader, multimedia supports, voice messages, Radio, USB, depending on the active source.
▲	☐ Scroll through Menu items on the panel
▼	☐ Select multimedia support tracks ☐ Scroll through SMS messages in the list
	☐ Access to the radio menu displayed on the instrument panel
SRC/OK	☐ Confirm manually selected menu option ☐ Select sources: FM, AM, DAB (where present), Bluetooth® AUDIO, USB and AUX ☐ Select the SMS message on the instrument panel

The functions of the steering wheel controls are activated when the button is released.



GENERAL INFORMATION

The Uconnect Radio is equipped with the following functions:

Radio section

- ☐ PLL tuning with FM/AM/MW frequency bands (where present);
- ☐ RDS (Radio Data System) with TA (traffic alerts) function - TP (traffic programmes) - EON (Enhanced Other Network) - REG (regional programmes);
- ☐ AF: search selection for alternative frequencies in RDS mode;
- ☐ automatic/manual tuning into stations;
- ☐ FM Multipath detector;
- ☐ manual storing of 36 or 54 stations: 18 in the FM band (6 in FM-A, 6 in FM-B and 6 in FM-C) and 18 in AM (6 in AM-A, 6 in AM-B and 6 in AM-C) and 18 in DAB (where present);
- ☐ SPEED VOLUME function: automatic volume adjustment according to the vehicle speed;
- ☐ automatic Stereo/Mono selection.

Audio section

- ☐ Mute function;
- ☐ Soft-Mute function;
- ☐ Loudness function
- ☐ 7-band graphic equaliser;
- ☐ Separate bass/treble adjustment
- ☐ Right/left channel balance.

Bluetooth®

For the **Bluetooth®** function, see the description in the dedicated paragraph.

USB/iPod section

For the USB/iPod function, see the description in the dedicated paragraph.

AUX section

- ☐ AUX source selection;
- ☐ AUX Offset function: alignment of the portable device volume with that of the other sources;
- ☐ Portable player playback.

Note It is not possible to view the AUX source info on the radio display

FUNCTIONS AND ADJUSTMENTS

Switching on

The Uconnect Radio comes on when the  (ON/OFF) button/knob is pressed briefly.

If the Uconnect Radio is switched on when the key is removed from the ignition, it will switch off automatically after about 20 minutes (if this time has been set). After the Uconnect Radio has switched itself off automatically it can be turned on for a further 20 minutes by pressing the  (ON/OFF) button.

Switching off

Long press on button  (ON/OFF).

Volume adjustment

To adjust the volume, turn the twist control .

If the volume level is changed during the transmission of traffic news, the new setting will only be maintained until the news is finished.

Mute Function

(setting volume to zero)

Press the  button on the steering wheel to activate the Mute function. In the Radio source, the word "MUTE" will appear, associated with the active source.

Press the  button on the steering wheel again to deactivate the Mute function.

Audio settings

The functions that can be selected from the audio menu change depending on the context: AM/FM and DAB (where present)/USB/iPod/**Bluetooth®**/AUX. Press the AUDIO button briefly to change the Audio functions. After the AUDIO button is first pressed, the display will show the bass level value for the source activated at that time (e.g. in FM mode the display will show the wording "FM Bass +2").

Use the ▲ or ▼ buttons to scroll through the menu functions. To change the setting of the function selected use the ◀ or ▶ buttons.

The current status of the selected function appears on the display. The functions managed by the Menu are:

- ☐ BASS: adjustment of bass tones;
- ☐ TREBLE: adjustment of high tones;
- ☐ BALANCE: right/left balance adjustment;
- ☐ FADER: front/back balance adjustment;
- ☐ LOUDNESS: activation/deactivation of the increase of bass and high tones;
- ☐ EQUALISER: activation and selection of factory-set equaliser levels;
- ☐ MY EQ: customised equaliser setting.

MENU

MENU button functions

Press the button MENU briefly to activate the Menu function. Use the ▲ or ▼ buttons to scroll through the menu functions. To change the setting of the function selected use the ◀ or ▶ buttons. The functions managed by the Menu are:

☐ AF SWITCHING: automatic activation/deactivation of the selection of the station with the strongest signal that transmits the same programme.

Note FM following in DAB (where provided; the radio switches automatically to FM in case of low DAB signal and back to DAB as soon as the signal is available) is enabled by enabling AF.

☐ TRAFFIC INFORMATION: activation/deactivation of traffic information.

Note Traffic information is enabled only if tuned to the station broadcasting the announcement.

☐ DAB INFO CATEGORIES (only enabled for DAB sources): single category enable/disable (Financial, News flash, Program info, Spec event, Sport report, Warning, Weather).

☐ REGIONAL MODE: activation/deactivation of regional programmes.

☐ MP3 DISPLAY: MP3 display setting.

☐ SPEED VOLUME: speed-dependent automatic volume control.

☐ RADIO ON VOLUME: maximum radio volume limit activation/deactivation.

☐ RADIO OFF: off mode selection.

☐ SYSTEM RESET: reset of factory settings.

Press the button MENU again to exit the Menu function.

Note The AF SWITCHING, TRAFFIC INFORMATION and REGIONAL MODE adjustments are only possible in FM mode.

RADIO (Tuner)

To select the Radio function while listening to another audio source, briefly press the RADIO button several times to select the desired band, FM AM or DAB (where present). Once the Radio mode has been activated, the display will show the name (only RDS stations) and the frequency of the selected radio station, the frequency band selected (e.g. FMA) and the preselect button number (e.g. P1).

Each time the button is pressed, the FM, AM and DAB bands (where present) are selected cyclically.

Preset buttons

The buttons numbered from 1 to 6 are used to set the following preset stations:

☐ 18 in the FM band (6 in FM-A, 6 in FM-B and 6 in FM-C);

☐ 18 in the AM band (6 in AM-A, 6 in AM-B and 6 in AM-C).



To listen to a preset station, select the desired frequency band with the RADIO button, briefly press ABC button to select the preset band (A, B or C), and then briefly press the corresponding preset button (from 1 to 6).

By pressing the preset button for more than 2 seconds, the tuned station will be stored. The storing phase is confirmed by an acoustic signal.

Automatic tuning

Briefly press the ◀ or ▶ button to start the automatic tuning search for the next station that can be received in the selected direction.

Manual tuning

Select the desired frequency band and then press the ▲ or ▼ button briefly and repeatedly to start to the search in the desired direction. If the ▲ or ▼ button is pressed longer, the fast search will start and then stop when the button is released.

USB/iPod MODE

To activate USB/iPod mode, insert the respective device (USB stick or other device) in the USB port located in the glove compartment.

If a USB/iPod device is inserted with the system on, this starts playing the tracks present on the device.

AUX MODE

To activate the AUX source, press the MEDIA button or the SRC control on the steering wheel repeatedly until the corresponding source is displayed.

BLUETOOTH®

Bluetooth® technology allows you to use your mobile phone through the car's hands-free system, without the need for wires.

To use the hands-free function it is necessary to have a mobile phone with **Bluetooth®** technology. To consult the list of compatible phones, see the site: www.mopar.eu/owner.

The hands-free function allows the following operations to be performed:

- Calling a telephone number by voice command: you can dial a telephone number by stating the numbers out loud.
- Calling someone in the phonebook using voice commands: you can call someone in your mobile phonebook using your voice. You can also call someone in your phonebook by selecting from the contacts that appear on the display of the instrument panel. (This function requires your phone directory to have been copied onto the vehicle hands-free system).

□ Accepting a call: you can accept an incoming call by pressing the  button on the steering wheel.

□ Rejecting a call: you can reject a call with a long press of the  button on the steering wheel.

SMS message reader

(available only with mobile phones that support this function)

The SMS message reader makes it possible to:

- Be informed, by means of a message on the instrument panel display, of the reception a new SMS message on your mobile phone with **Bluetooth®** technology; the number/ name of the sender is displayed and the system will also ask whether to read the message to you.
- Manage the list of messages received on your mobile phone only during connection with the active system.

Quick guide to the SMS message reader

(only for mobile phones that support this function)

If your **Bluetooth®** phone supports this function, when you receive a new SMS message, the system alerts you with an acoustic signal and asks you if you want to read it.

❑ Say "Yes" or press the  button or **SRC/OK**. The system will read the last message received;

❑ Say "NO" or press the  /  button. The system will store the message which you can read later, as long as the phone is connected to the system.

To get to know all the functions and ways of using the SMS message reader, refer to the "SMS MESSAGE READER FUNCTIONS" chapter.

MULTIMEDIA FUNCTIONS

The **MEDIA** menu allows you to view and reproduce the tracks stored on a USB/**Bluetooth**® AUDIO or AUX source (connected to the USB port). It is recommended to load only unprotected music files, with supported extensions. If the USB device contains other formats (e.g. .exe, .cab, .inf, etc.), problems might arise during playing of tracks.

To connect your UBS device to the system, proceed as follows:

- ❑ Connect the device to the USB socket in the glove compartment;
- ❑ Turn the ignition key to MAR. The system will automatically start playing your digital tracks, selecting them from a library that is created the moment the USB device is connected.

When the creation of the multimedia library is over, it is possible to use the system to display and select the tracks present and to activate playing.

Managing the multimedia library

With the MEDIA function you can select the digital audio on your USB device, using voice recognition or the steering wheel controls.

Tracks may be selected by folder, artist, musical genre, album and playlist.

Activate the Main Menu from the steering wheel controls on the instrument panel display, select the BROWSE USB option and then press **SRC/OK**.

Select one of the following items:

- ❑ FOLDERS
 - ❑ ARTISTS
 - ❑ GENRES
 - ❑ ALBUMS
 - ❑ PLAYLIST
- and press **SRC/OK**.

❑ select "PLAY ALL" and confirm with **SRC/OK**;

❑ select the item chosen and confirm with **SRC/OK**;

It is also possible to access the same functions with the voice commands:

❑ press the button on the steering wheel  and say "BROWSE USB";

❑ say one of the available options: "FOLDERS", "ARTISTS", "GENRES", "ALBUMS", "PLAYLIST";

❑ select "PLAY ALL" and confirm with **SRC/OK**;

❑ select the item chosen and confirm with **SRC/OK**.

Pause

To pause the track you are listening to: press the  button on the front panel of the Uconnect Radio.

To resume listening to a track that you have paused: press the  button on the front panel of the Uconnect Radio.

Stop

To stop playing a track: say "Stop".
To resume, say "Play".

Note The "Play" command is only available if playback has been stopped using the "Stop" command.

Next track

To skip to the next track, using manual interaction: while listening to a digital track, press  (steering wheel controls) or  (Uconnect Radio controls) (where present).



Previous track

To return to the previous track, using manual interaction: while listening to a digital track, press ▼ (steering wheel controls) or ◀ (Uconnect Radio controls) (where present).

Change audio source

To change the active audio source (Radio, USB/iPod, Tuner, **Bluetooth®** Audio) press the **SRC/OK** or **MEDIA** button on the front panel of the Uconnect Radio, or, with voice interaction: say "Select source USB/iPod, Radio, **Bluetooth®** Audio".

Note While playing **Bluetooth®** audio, there could be some incorrect displays related to the phone. This is not due to the radio, but depends on the information sent by the phone.

BLUETOOTH® DEVICE

IMPORTANT NOTES

- Access to the phonebook copied onto the system is possible only when the mobile phone from which it has been copied is connected.
- The names stored on the SIM card or in your mobile phone memory can be transferred to the system in different ways, depending on the model of mobile phone.

Getting to know the voice commands

When talking to the system, you can always use the voice command "Help" to obtain detailed instructions on the voice commands available for each interactive stage.

Pairing a Bluetooth® device

Note This operation should be carried out only with the vehicle stationary.

To pair your mobile phone with the system, proceed as follows.
Manual procedure:

- Activate the Main Menu by pressing the **MENU** button;
- select the SETTINGS option, then the "Pairing" option.
Voice procedure:
- Press  and say "Settings". Then, at the end of the message, say "Pairing".
- The system will show a PIN number on the display to be used for pairing.
- Using the search function of the **Bluetooth®** devices of your phone, search for the "Radio BT" device.

□ When prompted, enter the PIN code displayed on the instrument panel using your mobile phone keypad. If pairing is successful, the system will say "Connecting" and at the end the display will show, as confirmation, the ID of the paired mobile phone. Once the device has been paired, if the function is supported by the phone, the system automatically asks to download the phonebook onto the Uconnect Radio.

Note After updating the phone software, for proper operation, it is recommended to remove the phone from the list of devices linked to the radio, delete the previous system pairing also from the list of **Bluetooth®** devices on the phone and make a new pairing.

Making a phone call

- Press the steering wheel control  and say "Call" and the name of the contact in the phonebook.
- If the name is recognised, the system will display the information for the contact on the display.
- The system will ask you to confirm your request. To make the call, say "Yes"; otherwise, say "No".

Alternatively, it is possible to call a number that is not in the phonebook by saying the number one figure at a time.

Managing an incoming call

When a call is received, the system will display the caller's ID, where available. The incoming call will be signalled by your mobile phone's personalised ringtones (the availability of this function depends on the specific features of your phone).

Answering a call:

- ☐ To answer the call, press  ;
- ☐ To end the call, press  for more than 1 second.
- ☐ To reject a call: press  .
- ☐ To ignore a call and not hear the ring tone, press  .

Putting a phone call on HOLD

To place a call in progress on HOLD and disable the microphone in order to be able to speak without being heard by the person you are talking to, press  .

VOICE COMMANDS

Global commands

- ☐ SELECT MEDIA SOURCE;
- ☐ SELECT RADIO SOURCE;
- ☐ SELECT PHONE SOURCE;
- ☐ CALL or DIAL;
- ☐ READ MESSAGE;
- ☐ SETTINGS;
- ☐ HELP;
- ☐ CANCEL;
- ☐ REPEAT.

Phone commands

- ☐ DIAL;
- ☐ CALL (followed by name);
- ☐ CALL (followed by number);
- ☐ CALL BACK;
- ☐ READ LAST;


Audio Bluetooth®/USB/iPod Commands

- ☐ PLAY;
- ☐ PAUSE;
- ☐ STOP.

Radio

- ☐ SELECT BAND "FM" "AM" or "DAB".

Note It is advisable not to direct the middle air vents towards the microphone (fig. 137) because the noise generated by the air on the microphone could cause worsen voice control performance.



137

F1D0999

PANDA UCONNECT APP

To use the Panda Uconnect app you must download it from the Apple App Store or from Google Play and pair the smartphone to the radio via **Bluetooth®**, as described in the "**Bluetooth® Device**" chapter. For the list of compatible phones, see Fiat elum site.

The app interface may change depending on how it is used: connected or not connected to the car radio.



When it is connected via Bluetooth®, you can interact with the radio through the screen of your smartphone. You can listen to your favourite music by selecting the source, the track or the radio station desired. You can also view the phonebook, your car handbook and, if necessary, call for assistance.

When it is not connected, you can have all the information about the state of your car with my:Car and indications about your driving style with eco:Drive. You can also find your car easily if you do not remember where you parked it.



WARNING

184) *If the volume is too loud this could be dangerous for the driver and for passengers when driving in traffic. Always adjust the volume so that you can still hear background noises.*

185) *The use of some of the system's features whilst driving can divert attention away from the road, with the risk of causing accidents or other serious consequences; therefore they must only be used when the driving conditions allow and, where necessary, only when the vehicle is stationary.*

186) *Read and follow these instructions: before using your system, read and follow all the safety information and instructions in this manual. Failure to observe the precautions found in this manual may lead to an accident or other serious consequences.*

187) *Keep the manual in the car: if it is kept in the car, the manual will become something quick and easy to consult for those not familiar with the system. Ensure that everyone has access to the manual and reads the instructions and the safety information carefully before using the system for the first time.*

188) *Warning: looking at the system when driving can divert attention from the road, with the risk of accidents or other serious consequences. Do not change system settings or enter data non-verbally (using the manual controls) while driving. Stop the vehicle in a safe and legal manner before carrying out these operations. Adopting these precautions is important since setting or changing some functions might require the driver to be distracted away from the road and remove his or her hands from the steering wheel.*

189) *Voice commands: the system functions can be carried out using only voice commands. The use of voice commands when driving allows you to manage the system without taking your hands off the steering wheel.*

190) *Looking at the display for a long time: while driving, do not use any function that requires looking at the display for a long time. Pull over in a safe and legal manner before attempting to access a function of the system that requires prolonged attention. Even occasional quick glances at the display can be dangerous if the driver's attention is diverted at a critical moment.*


191) *Setting the volume: do not turn the volume up too high. When driving, keep the volume at a level that allows you to hear the traffic outside and emergency sirens. Driving while unable to hear these sounds may cause an accident.*

192) *Using the voice recognition: the voice recognition software is based on a statistical process that is subject to error. It is your responsibility to monitor voice recognition functions included in the system and address any errors.*

193) *Danger of distraction: the functions may require manual settings (not using voice commands). Attempting to perform such setup or insert data while driving can seriously distract your attention and could cause an accident or other serious consequences. Stop the vehicle in a safe and legal manner before carrying out these operations.*

DASHBOARD (RIGHT-HAND DRIVE VERSION)

The presence and position of controls, instruments and gauges may vary depending on the versions.



138

F0W0476

1. Adjustable and directable air diffusers 2. Exterior light control stalk 3. Driver front airbag 4. Windscreen wiper/rear window wiper/trip computer control lever 5. Adjustable and directable centre air vents 6. Passenger front airbag 7. Glove compartment (for versions/markets, where provided) 8. Radio (for versions/markets, where provided) 9. Control buttons 10. Gear lever 11. Heating/ventilation/climate control system controls 12. Ignition device 13. Instrument panel 14. Electric front windows 15. ECO/ASR OFF buttons (for versions/markets, where provided)



CONTROL PANEL AND ON-BOARD INSTRUMENTS

The instrument background colour and type may vary according to the versions.

The warning lights on the instrument panel may change according to the version/trim level (e.g. LPG, Cross etc.) of the vehicle. Warning lights  and  are available on diesel versions only. On diesel versions, the maximum engine speed (red range on the rev counter) corresponds to 6000 rpm.



139

F1D0692


A. Speedometer (speed indicator) – B. Multifunction display – C. Rev counter

REPLACING FUSES

Fuse location


Fuse box on the dashboard

To access the fuses, remove the plastic cover fig. 140. The fuses are in the fuse box shown in fig. 141.



140

F0W0294




141

F0W0295

PARKING

Switch off the engine and engage the parking brake. Engage a gear (first gear if the car is parked facing uphill or reverse if facing downhill) and leave the wheels turned. If the vehicle is parked on a steep slope, block the wheels with a wedge or stone. Always remove the ignition key when leaving the car.

PARKING BRAKE



142

F0W0296

To engage the handbrake, pull the lever A fig. 142 upwards until the car cannot be moved. To disengage the handbrake, slightly raise lever A and hold button B pressed, checking that the (ⓘ) warning light switches off in the instrument panel.

ⓘ 119) 120) 121)



WARNING

194) Never leave children unattended in the car. Always remove the key from the ignition when leaving the car and take it with you.

195) The car should be braked after a few clicks of the lever, if it is not, contact a Fiat Dealership to have it adjusted.

196) In the case of parking manoeuvres on roads on a gradient, the front wheels must be steered towards the pavement (when parking downhill), or in the opposite direction if the vehicle is parked uphill. Block the wheels with a wedge or a stone if the car is parked on a steep slope.





WARNING

INTERIOR FITTINGS

Never travel with the glove compartment open: it could injure the passenger in the event of a crash.

The cigar lighter gets very hot. Handle it carefully and make sure that children do not touch it: risk of fire and/or burns. Always check that the cigar lighter plug has been released.

ROOF RACK/SKI RACK

☐ After travelling for a short distance, check that the fixing screws for the attachments are correctly tightened.

Never exceed the maximum permitted loads (see chapter "Technical specifications").

Evenly distribute the load and take into account, when driving, the increased responsiveness of the vehicle to side wind.

WIRING FOR RADIO SYSTEM

If you wish to have a sound system installed after purchasing the vehicle, first contact a Fiat Dealership whose qualified personnel will give you advice about a sound system that does not damage the battery charge. Excessive non-running consumption damages the battery and may cause your battery warranty to be terminated.

PROTECTING THE ENVIRONMENT

During normal service, the catalytic converter and the diesel particulate filter (DPF) reach high temperatures. Do not therefore park the vehicle over inflammable materials (grass, dry leaves, pine needles, etc.): fire hazard.

INTERIORS

Never use flammable products, such as petrol ether or rectified petrol to clean the inside of the vehicle. The electrostatic charges which are generated by rubbing during the cleaning operation may cause a fire.

Do not keep aerosol cans in the vehicle: they might explode. Aerosol cans must not be exposed to a temperature exceeding 50°C. When the vehicle is exposed to sunlight, the internal temperature can greatly exceed this value.

POWER SUPPLY

Modifications or repairs to the supply system that are not carried out correctly or do not take the system technical specifications into account can cause malfunctions leading to the risk of fire.

LOADING ADVICE (*Panda VAN versions*)

Abrupt braking or occasional impacts may cause sudden movements of the load with consequent situations of hazard for the driver and passengers: before setting off, secure the load tightly using the partition and, where provided, the appropriate hooks. For securing use cables, ropes or belts strong enough to hold the items to be secured.



WARNING

ROOF RACK/SKI RACK

Fully comply with the regulations in force concerning maximum clearance.

WIRING FOR RADIO SYSTEM

For connection to the radio system set-up, contact a Fiat Dealership to prevent any problem that could impair vehicle safety.

BODYWORK

In order to preserve the aesthetic appearance of the paint abrasive products and/or polishes should not be used for cleaning the vehicle.

Avoid washing with rollers and/or brushes in washing stations. Wash the vehicle only by hand using neutral pH detergents; dry it with a wet chamois leather. Abrasive products and/or polishes should not be used for cleaning the vehicle. Bird droppings must be washed off immediately and thoroughly as the acid they contain is particularly aggressive. Avoid (if at all possible) parking the vehicle under trees; remove vegetable resins immediately as, when dried, it may only be possible to remove them with abrasive products and/or polishes, which is highly inadvisable as they could alter the typical opaqueness of the paint. Do not use pure screen washer fluid for cleaning the windscreen and rear window; dilute it min. 50% with water. Only use pure screen washer fluid when strictly necessary due to outside temperature conditions.

INTERIORS

Never use alcohol, petrols and derivatives to clean the dashboard and instrument panel lens.



WARNING

BODYWORK

Detergents pollute the environment. Only wash your vehicle in areas equipped to collect and treat wastewater from this type of activity.



In the heart of your engine.



Always ask your mechanic for **PETRONAS Selenia** MOTOR OIL

Oil change? The experts recommend Petronas Selenia

*The engine of your car is factory filled with **Petronas Selenia**,
This is an engine oil range which satisfies the most advanced
international specifications. Its superior technical characteristics
allow **Petronas Selenia** to guarantee the **highest performance
and protection of your engine.***

The Petronas Selenia range includes a number of technologically advanced products:

SELENIA K PURE ENERGY

Fully synthetic lubricant designed for latest generation, low emission, petrol engines. Its specific formulation warrants the utmost protection also for high performance turbocharged engines with high thermal stress. Its low ash content helps to maintain the total cleanliness of modern catalysts.

SELENIA WR PURE ENERGY

Fully synthetic lubricant that can meet the requirements of the latest diesel engines. Low ash content to protect the particulate filter from the residual products of combustion. High Fuel Economy System that allows considerable fuel saving.
It reduces the danger of dirtying the turbine to ensure the protection of increasingly high performance diesel engines.

SELENIA MULTIPower GAS PURE ENERGY

Fully-synthetic lubricant designed for petrol engines also turbocharged, powered with methane or LPG. Its exclusive formulation improves valve protection against wear, neutralises the acid compounds formed by combustion and keeps engine performance levels unchanged.

SELENIA K POWER

Fully synthetic lubricant developed for American design petrol engines, specially formulated to allow an excellent resistance to oxidation and high level fuel economy. Excellent protection at high temperatures.

SELENIA DIGITEK PURE ENERGY

Fully synthetic lubricant for petrol engines. High fuel economy characteristics. Specific formulation for the TwinAir two-cylinder engines, Selenia Digitech Pure Energy allows maximum protection of the engine even under high mechanical stress caused by severe stop and go conditions of city traffic.

The range also includes Selenia K, Selenia 20K, Selenia Turbo Diesel, Selenia Sport, Selenia Sport Power, Selenia Racing.

For further information on Petronas Selenia products visit the web site www.pli-petronas.eu

**CHOOSING GENUINE PARTS
IS THE MOST NATURAL CHOICE**



PERFORMANCE



GENUINE PARTS

COMFORT



GENUINE PARTS

SAFETY



GENUINE PARTS

AMBIENT



GENUINE PARTS

ACCESSORIES



GENUINE PARTS

VALUES



GENUINE PARTS

HOW TO RECOGNISE GENUINE PARTS

To recognise a **Genuine Part**, check **that the component bears our brands**, always clearly visible on Genuine Parts, from the braking system to windscreen wipers, from shock absorbers to pollen filter.


All Genuine Parts undergo **strict controls**, both during design and manufacturing stages, by specialists using **vanguard materials**, to **test the component reliability**.

This to guarantee **performance** and **safety** for you and your passengers on board, for a long time.


Always ask for and make sure a **Genuine Part** has been used.



Pollen filter



Shock absorber



Brake pads

**MAINTAIN YOUR VEHICLE IN
TIP TOP CONDITIONS WITH**



Mopar Vehicle Protection offers a series of service contracts that are designed to give all our customers the pleasure of driving their vehicle without any hitch's and concerns.

Our product portfolio consists of a wide and flexible range of **extended warranty and maintenance plans** endorsed by FCA. Each with a series of **different coverage tiers, in terms of durability and mileage**, built to accommodate you're driving needs.

Service contracts are made by experts that know every part of your vehicle, and commit themselves to **maintain it in tip top conditions**. Our knowledge and passion is tailored around designing products that promises all our drivers "worry-free driving".

Only with Mopar Vehicle Protection you are ensured that all service operations are performed by **highly qualified and specialized technicians in authorized FCA repair facilities, using the right tools, equipment and only original parts, all over Europe**.

Check which Service Contract plans are available on your market today and choose the Service Contract that suits your driving habits best.

Ask your local dealer for further information.

INDEX

3rd brake light (bulb replacement)

111

ABS (system)

60

Active safety systems

60

Airbag

84

ASR (system)

61

Battery (recharging)

135

Bonnet

26

CBC system

65

Checking levels

137

Child protection systems

74

Climate control system

22

CO2 emissions

175

Control panel and on-board instruments

202

Dashboard

8

Daytime running lights (DRL)

– "Daytime Running Lights"

17

Dimensions

158

Dipped beam headlights

– control

17

Dipped headlights

– control

17

Dipped/main beam headlights (bulb replacement)

108

Direction indicators

– control

17

Direction indicators (changing a bulb)

108

Display

38

Doors

11

– door locking/unlocking

11

Driving assistance systems

65

DRL (daytime running lights)

17

Dualdrive electric power steering

97

Dualogic gearbox

95

ECO function

98

Electric windows

26

Engine

147

Engine compartment

137

ESC (system)

60

External lights

17

Fiat CODE (system)

11

Fix&Go Airflat kit

118

Fluids and lubricants

168

Fog lights (bulb replacement)

109

Follow me home (device)

17

Front airbags

84

Front roof light

19

Front/rear fog lights

18

Fuel consumption

173

Fuel cut-off system

122

Fuses (replacement)

112

Gear Shift Indicator

38

Handbrake

93

Hazard warning lights

106

HBA (system)

61

Head restraints

14

HH (system)

60

Ignition device

10

Important information and recommendations

204

Instrument panel

201

Interior lights

19

iTPMS

66

Jump starting

121

Keys

– key with remote control

9

– key without remote control

9

Lifting the vehicle

143

Luggage compartment

28

Main beam headlights

– control

17

Manual gearbox

94

Mode selector

96

Number plate lights (bulb replacement)

111

Occupant protection systems

69

Parking lights

17

Parking sensors

100

Parking the vehicle

93

Performance (top speed)

172



Pre-tensioners.....	72	– Adjustments	12	The keys	9
Prescriptions for handling the vehicle at the end of its life	176	Side bags.....	88	Towing the vehicle.....	123
R adio.....	178	Side lights/daytime running lights (bulb replacement)	110	Towing trailers	103
Rear fog lights.....	18	Smartphone Docking	30	U connect RADIO	186
Rear light clusters (bulb replacement)	110	Snow chains	156	USB ports and AUX input.....	29
Rear view mirrors	16	Starting the engine	92	V ersion with LPG system	31
Refuelling	166	Steering lock.....	10	Version with methane system (Natural Power)	33
Refuelling the vehicle.....	101	Steering wheel	15	W arning lights on panel	40
Replacing a bulb	106	Steering wheel stalks		Weights.....	161
Reversing light/rear fog light	110	– left stalk.....	17	Wheel (changing).....	115
S BR (Seat Belt Reminder) system	71	– right stalk	20	Wheels.....	151
Scheduled servicing	126	Stop/Start system	99	Wheels and tyres	143
Seat belts.....	69	Supplementary Restraint System (SRS) - Airbag	84	Window cleaning.....	20
Seats	12	Symbols.....	3	Windscreen/rear window wiper	142
		T echnical data.....	146		

WHY CHOOSING GENUINE PARTS

We really know your car because we invented, designed and built it: we really know every single detail.

At **Fiat Service authorised workshops** you can find technicians directly trained by us, offering quality and professionalism for all service operations.

Fiat workshops are always close to you for the regular servicing operations, season checks and practical recommendations by our experts.

With Original Parts distributed by MOPAR®, you maintain the reliability, comfort and performance features that you bought your new car for over time.

Always ask for Genuine Parts for the components used on our cars; we recommend them because they come from our steady commitment in research and development of highly innovative technologies.

For all these reasons: **rely on Genuine Parts, because they are the only ones designed by FCA for your car.**

SAFETY:
BRAKING SYSTEM

**ENVIRONMENT: PARTICULATE FILTERS,
CLIMATE CONTROL MAINTENANCE**

**COMFORT: SUSPENSION
AND WINDSCREEN WIPERS**

**PERFORMANCE: SPARK PLUGS,
INJECTORS AND BATTERIES**

**LINEACCESSORI
ROOF RACK BARS, WHEEL RIMS**

The data contained in this publication is intended merely as a guide. FCA Italy S.p.A. reserves the right to modify the models and versions described in this booklet at any time for technical and commercial reasons.

If you have any further questions please consult your FIAT dealer.

Printed in recycled paper without chlorine.