

STARTING SYSTEM


ST-2

STARTING SYSTEM – Troubleshooting

TROUBLESHOOTING


Problem	Possible cause	Remedy	Page
Engine will not crank	Battery charge low	Check battery specific gravity Check or replace battery Repair or replace cables	CH-2
	Battery cables loose, corroded or worn Clutch start switch faulty (M/T only) Neutral start switch faulty (A/T only) Starter relay faulty (M/T only) Fusible link blown Starter faulty Ignition switch faulty	Adjust or replace clutch start switch Adjust or repair switch Replace starter relay Replace fusible link Repair starter Replace ignition switch	CL-4
			ST-3
Engine cranks slowly	Battery charge low	Check battery specific gravity Charge or replace battery Repair or replace cables	CH-2
	Battery cables loose, corroded or worn Starter faulty	Repair starter	ST-3
Starter keeps running	Starter faulty Ignition switch faulty Short in wiring	Repair starter Replace ignition switch Repair wiring	ST-3
Starter spins – engine will not crank	Pinion gear teeth broken or starter faulty Flywheel teeth broken	Repair starter Replace flywheel	ST-3

STARTER COMPONENTS




ST-4

STARTING SYSTEM – Starter

**REMOVAL OF STARTER (3S-FE)**

1. DISCONNECT CABLE FROM NEGATIVE TERMINAL OF BATTERY
2. DISCONNECT CONNECTOR AND WIRE FROM STARTER
3. REMOVE STARTER

Remove the two bolts and starter.

**REMOVAL OF STARTER (2VZ-FE)**

1. REMOVE BATTERY AND BATTERY TRAY
2. REMOVE IGNITER BRACKET

(a) Disconnect the following connectors and wire:



- Noise filter connector
- Igniter connector
- High-tension cord for ignition coil
- Ground strap

(b) Disconnect the harness clamp, and remove the two bolts and igniter bracket.

3. DISCONNECT CONNECTOR AND WIRE FROM STARTER

4. REMOVE STARTER

Remove the two bolts and starter.

**DISASSEMBLY OF STARTER**


(See page [ST-3](#))

1. REMOVE FIELD FRAME AND ARMATURE


- (a) Remove the nut, and disconnect the lead wire from the magnetic switch terminal.
- (b) Remove the two through bolts, and pull out the field frame together with the armature.
- (c) (1.4 kW Type)
Remove the O-ring.

2. REMOVE STARTER HOUSING, CLUTCH ASSEMBLY AND GEARS

- (a) Remove the two screws.




STARTING SYSTEM – Starter




(b) Remove the following parts from the magnetic switch:

- (1.0 kW Type)
- (1) Starter housing and clutch assembly
 - (2) Return spring
 - (3) Bearing
 - (4) Idler gear




- (1.4 kW Type)
- (1) Starter housing and clutch assembly
 - (2) Return spring
 - (3) Pinion gear
 - (4) Bearing
 - (5) Idler gear



3. REMOVE STEEL BALL

Using a magnetic finger, remove the steel ball from the clutch shaft hole.



4. REMOVE BRUSH HOLDER

(a) (1.0 kW Type)


Remove the two screws and end cover from the field frame.

(1.4 kW Type)

Remove the two screws, 0-rings and end cover from the field frame.

(b) (1.4 kW Type)

Remove the 0-ring.




(c) Using a screwdriver, hold the spring back and disconnect the brush from the brush holder. Disconnect the four brushes, and remove the brush holder.

5. REMOVE ARMATURE FROM FIELD FRAME

ST-6

STARTING SYSTEM – Starter




INSPECTION AND REPAIR OF STARTER

Armature Coil

1. INSPECT COMMUTATOR FOR OPEN CIRCUIT

Using an ohmmeter, check that there is continuity between the segments of the commutator.

If there is no continuity, replace the armature.



2. INSPECT COMMUTATOR FOR GROUND


Using an ohmmeter, check that there is no continuity between the commutator and armature coil core.

If there is continuity, replace the armature.

Commutator

1. INSPECT COMMUTATOR FOR DIRTY AND BURNT SURFACE

If the surface is dirty or burnt, correct with sandpaper (No.400) or on a lathe.




2. INSPECT COMMUTATOR FOR RUNOUT

(a) Place the commutator on V-blocks.

(b) Using a dial indicator, measure the circle runout.

Maximum circle runout: 0.05 mm (0.0020 in.)

If the circle runout is greater than maximum, correct it with on a lathe.




3. INSPECT COMMUTATOR DIAMETER

Using calipers, measure the diameter.

Standard diameter: 30.0 mm (1.181 in.)

Minimum diameter 29.0 mm (1.142 in.)




4. INSPECT UNDERCUT DEPTH

Check that the undercut depth is clean and free of foreign material. Smooth out the edge.

Standard undercut depth: 0.6 mm (0.024 in.)

Minimum undercut depth: 0.2 mm (0.008 in.)

If the undercut depth is less than minimum, correct it with hacksaw blade.




Field Coil (Field Frame)

1. INSPECT FIELD COIL FOR OPEN CIRCUIT

Using an ohmmeter, check that there is continuity between the lead wire and field coil brush lead.


If there is no continuity, replace the field frame.



2. INSPECT FIELD COIL FOR GROUND

Using an ohmmeter, check that there is no continuity between the field coil end and field frame.

If there is continuity, replace the field frame.



Brushes

INSPECT BRUSH LENGTH

Using calipers, measure the brush length.

Standard length:

1.0 kW type 13.5 mm (0.531 in.)


1.4 kW type 15.5 mm (0.610 in.)

Minimum length:

1.0 kW type 8.5 mm (0.335 in.)

1.4 kW type 10.0 mm (0.394 in.)

If the length is less than minimum, replace the brush holder and field frame.



Brush Springs

INSPECT BRUSH SPRING LOAD

Take the pull scale reading the instant the brush spring separates from the brush.


Standard installed load:

1.79–2.41 kg (3.9–5.31 lb, 18–24 N)

If the installed load is not as specified, replace the brush springs.

ST-8

STARTING SYSTEM – Starter



Brush Holder

INSPECT BRUSH HOLDER INSULATION

Using an ohmmeter, check that there is no continuity between the positive (+) and negative (-) brush holders. If there is continuity, repair or replace the brush holder.


Clutch and Gears

1. INSPECT GEAR TEETH

Check the gear teeth on the pinion gear, idler gear and the clutch assembly for wear or damage.

If damaged, replace the gear or clutch assembly.


If damaged, also check the flywheel ring gear for wear or damage.



2. INSPECT CLUTCH PINION GEAR

Rotate the pinion gear counterclockwise and check that it turns freely. Try to rotate the pinion gear clockwise and check that it locks.


If necessary, replace the clutch assembly.



3. IF NECESSARY, REPLACE CLUTCH ASSEMBLY

A. Disassembly starter housing and clutch assembly


(a) Mount a brass bar in a vise, and install the starter housing and clutch assembly to the brass bar.




(b) Push down the pinion gear.

(c) Using a plastic-faced hammer, tap in the stop collar.

STARTING SYSTEM – Starter




(d) Using a screwdriver, pry out the snap ring.




(e) Remove the following parts:

- (1) Stop collar
- (2) Pinion gear
- (3) Compression spring




(f) Push down the starter housing, remove the spring retainer.



(g) Disassemble the following parts:

- (1) Starter housing
- (2) Bearing retainer.
- (3) Starter clutch
- (4) Compression spring
- (5) Clutch shaft




B. Assemble starter housing and clutch assembly

(a) Assemble the following parts:


- (1) Starter housing
- (2) Bearing retainer
- (3) Starter clutch
- (4) Compression spring
- (5) Clutch shaft

ST-10

STARTING SYSTEM – Starter




- (b) Mount a brass bar in a vise, install the starter housing and clutch assembly to the brass bar.




- (c) Push down the starter housing, and install the following parts:
- (1) Spring retainer
 - (2) Compression spring
 - (3) Pinion gear
 - (4) Stop collar




- (d) Push down the pinion gear.
(e) Using snap ring pliers, install a new snap ring.



- (f) Using pliers, compress the snap ring.
(g) Check that the snap ring fits correctly.




- (h) Remove the starter housing and clutch assembly from the brass bar.
(i) Using a plastic-faced hammer, tap the clutch shaft and install the stop collar onto the snap ring.



Bearings

1. INSPECT BEARINGS


Turn each bearing by hand while applying inward force. If resistance is felt or if the bearing sticks, replace the bearing.



2. IF NECESSARY, REPLACE BEARINGS

(a) Using SST, remove the bearing.

SST 09286-46011




(b) Using SST and a press, press in a new front bearing.

SST 1.0 kW Type 09285-76010

1.4 kW Type 09201-41020

(c) Using a press, press in a new rear bearing.



Magnetic Switch

1. PERFORM PULL-11V COIL OPEN CIRCUIT TEST

Using an ohmmeter, check that there is continuity between terminals 50 and C.

If there is no continuity, replace the magnetic switch.


2. PERFORM HOLD-IN COIL OPEN CIRCUIT TEST

Using an ohmmeter, check that there is continuity between terminal 50 and the switch body.

If there is no continuity, replace the magnetic switch.

ST-12

STARTING SYSTEM – Starter


**ASSEMBLY OF STARTER**

(See page ST-3)

HINT: Use high-temperature grease to lubricate the bearings and gears when assembling the starter.


1. PLACE ARMATURE INTO FIELD FRAME

Apply grease to the armature bearings, and insert the armature into the field frame.

**2. INSTALL BRUSH HOLDER**


- (a) Place the brush holder in position on the armature.
- (b) Using a screwdriver, hold the brush spring back, and connect the brush into the brush holder. Connect the four brushes.

HINT: Check that positive H lead wires are not grounded.



- (c) (1.4 kW Type)


Place a new O-ring in position on the field frame.




- (d) 0.4 kW Type

Install a new O-ring to the end cover screw.

- (e) Install the end cover with the two screws.


**3. INSERT STEEL BALL INTO CLUTCH SHAFT HOLE**

- (a) Apply grease to the steel ball.
- (b) Insert the steel ball into the clutch shaft hole.



4. INSTALL CLUTCH ASSEMBLY AND GEARS


- (a) Apply grease to the return spring.
- (b) Insert the return spring into the magnetic switch hole.



- (c) Place the following parts in position on the starter housing:


(1.0 kW Type)

- (1) Starter housing and clutch assembly
- (2) Idler gear
- (3) Bearing




(1.4 kW Type)

- (1) Starter housing and clutch assembly
- (2) Idler gear
- (3) Bearing
- (4) Pinion gear



- (d) Assemble the starter housing and magnetic switch with the two screws.




5. INSTALL FIELD FRAME AND ARMATURE ASSEMBLY

- (a) (1.4 kW Type)



Place a new O-ring in position on the field frame.

ST-14


STARTING SYSTEM – Starter



- (b) Align the protrusion of the field frame with the cutout of the magnetic switch.



- (c) Install the field frame and armature assembly with the two through bolts.
(d) Connect the lead wire to terminal C, and install the nut.



PERFORMANCE TEST OF STARTER


NOTICE: These tests must be performed within 3 to 5 seconds to avoid burning out the coil.


1. PERFORM PULL-IN TEST

- (a) Disconnect the field coil lead wire from terminal C.
(b) Connect battery to the magnetic switch as shown.
Check that the pinion gear moves outward.
If the pinion gear does not move, replace the magnetic switch.

2. PERFORM HOLD-IN TEST

While connected as above with the pinion gear out, disconnect the negative (–) lead from terminal C.
Check that the pinion gear remains out.
If the pinion gear returns inward, replace the magnetic switch.






3. INSPECT PLUNGER RETURN

Disconnect the negative (+) lead from the switch body. Check that the pinion gear returns inward.

If the pinion gear does not return, replace the magnetic switch.




4. PERFORM NO-LOAD PERFORMANCE TEST

(a) Connect the battery and ammeter to the starter as shown.

(b) Check that the starter rotates smoothly and steadily with the pinion gear moving out. Check the reading on the ammeter.

Standard amperage: 90 A or less at 11.5 V



INSTALLATION OF STARTER (3S-FE)

1. INSTALL STARTER

Install the starter with the two bolts.

Torque: 400 kg-cm (29 ft-lb, 39 N)

2. CONNECT CONNECTOR AND WIRE TO STARTER

3. CONNECT CABLE TO NEGATIVE TERMINAL OF BATTERY

4. CHECK THAT ENGINE STARTS

INSTALLATION OF STARTER (2VZ-FE)

1. INSTALL STARTER

Install the starter with the two bolts.

Torque: 400 kg-cm (29 ft-lb, 39 N-m)

2. CONNECT CONNECTOR AND WIRE TO STARTER

3. INSTALL IGNITER BRACKET



(a) Install the igniter bracket with the two bolts, and connect the harness clamp.

(b) Connect the following connectors and wire:

- Noise filter connector
- Igniter connector
- High-tension cord for ignition coil
- Ground strap


4. INSTALL BATTERY TRAY AND BATTERY

5. CHECK THAT ENGINE STARTS



ST-16


STARTING SYSTEM – Starter Relay (M T only)



STARTER RELAY (MT only)

INSPECTION OF STARTER RELAY


LOCATION: In the left cowl side.



1. INSPECT RELAY CONTINUITY

- Using an ohmmeter, check that there is continuity between terminals 1 and 3.
- Check that there is no continuity between terminals 2 and 4.

If continuity is not as specified, replace the relay.



2. INSPECT RELAY OPERATION

- Apply battery voltage across terminals 1 and 3.
- Using an ohmmeter, check that there is continuity between terminals 2 and 4.


If operation is not as specified, replace the relay.

CLUTCH START SWITCH (MT only)

(See page [CL-4](#))

ST-16


STARTING SYSTEM – Clutch Start Switch (M T only)



STARTER RELAY (MT only)

INSPECTION OF STARTER RELAY


LOCATION: In the left cowl side.



1. INSPECT RELAY CONTINUITY

- Using an ohmmeter, check that there is continuity between terminals 1 and 3.
- Check that there is no continuity between terminals 2 and 4.

If continuity is not as specified, replace the relay.



2. INSPECT RELAY OPERATION

- Apply battery voltage across terminals 1 and 3.
- Using an ohmmeter, check that there is continuity between terminals 2 and 4.

If operation is not as specified, replace the relay.

CLUTCH START SWITCH (MT only)

(See page [CL-4](#))