

2002 ACCESSORIES & EQUIPMENT

Ignition Switch & Key Unlock Warning System - RAV4

BODY ELECTRICAL SYSTEM

PRECAUTION

NOTE: Take care to observe the following precautions when performing inspections or removal and replacement of body electrical related parts.

1. Headlight System

Halogen bulbs have pressurized gas inside and require special handling. They can burst if scratched or dropped. Hold a bulb only by its plastic or metal case.

Don't touch the glass part of a bulb with bare hands.

2. SRS (Supplemental Restraint System)

The RAV4 is equipped with an SRS (Supplemental Restraint System) such as the driver airbag and front passenger airbag, failure to carry out service operation in the correct sequence could cause the SRS to unexpectedly deploy during servicing, possibly leading to a serious accident. Before servicing (including removal or installation of parts, inspection or replacement), be sure to read the precautionary notices in **AIR BAG SAFETY PRECAUTIONS** .

3. Audio System

If the negative (-) terminal cable is disconnected from the battery, the preset AM, FM1 and FM2 stations stored in memory are erased, so be sure to note the stations and reset them after the battery terminal is reconnected.

4. Mobile Communication System

If the vehicle is equipped with a mobile communication system, refer to precautions in **IF VEHICLE IS EQUIPPED WITH MOBILE COMMUNICATION SYSTEM** .

TROUBLESHOOTING

PROBLEM SYMPTOMS


IGNITION SWITCH AND KEY UNLOCK WARNING SWITCH

Symptom/Suspected Area	See
Ignition Switch Is Not Set To Each Position	
Ignition Switch	Step 1 under INSPECTION

Key Unlock Warning System Does Not Operate	
GAUGE Fuse	FUSES & CIRCUIT BREAKERS
Key Unlock Warning Switch	Step 2 under INSPECTION
Door Courtesy Switch	INSPECTION
Wire Harness	*****

IGNITION SWITCH AND KEY UNLOCK WARNING SWITCH

LOCATION




P
G01895660

Fig. 1: Locating Ignition Switch & Key Unlock Warning Switch
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

INSPECTION

1. Inspect ignition switch continuity .



P
G01895662

Fig. 2: Inspecting Ignition Switch Continuity
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Switch position	Tester connection	Specified condition
LOCK	—	No continuity
ACC	1 – 3	Continuity
ON	1 – 2 – 3 5 – 6	Continuity
START	1 – 2 4 – 5 – 6	Continuity


G01895661

Fig. 3: Displaying Switch Specifications
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

If continuity is not as specified, replace the switch.

2. **Inspect key unlock warning switch continuity .**

If continuity is not as specified, replace the switch.



e - 2 - 2 - G
G01895664

Fig. 4: Inspecting Key Unlock Switch Continuity
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Switch position	Tester connection	Specified condition
OFF (Key removed)	—	No continuity
ON (Key set)	1 – 2	Continuity

G01895663

Fig. 5: Displaying Key Unlock Switch Specifications
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

3. **Inspect key unlock warning buzzer .**




Fig. 6: Displaying Key Unlock Buzzer Specifications
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Check the buzzer sound when driver's door is opened and key inserted.

If operation is not as specified, replace the combination meter (See **REMOVAL**).