

SECTION

DEF

DEFOGGER

A

B

C

CONTENTS

E

BASIC INSPECTION	3	Diagnosis Procedure	14	F
DIAGNOSIS AND REPAIR WORKFLOW	3	Component Inspection	15	
Work Flow	3	DRIVER SIDE DOOR MIRROR DEFOGGER ...	16	G
FUNCTION DIAGNOSIS	6	Description	16	
REAR WINDOW DEFOGGER SYSTEM	6	Component Function Check	16	
System Diagram	6	Diagnosis Procedure	16	H
System Description	6	Component Inspection	17	
Component Parts Location	7	PASSENGER SIDE DOOR MIRROR DEFOG-		
Component Description	7	GER	18	I
DIAGNOSIS SYSTEM (BCM)	9	Description	18	
COMMON ITEM	9	Component Function Check	18	
COMMON ITEM : CONSULT-III Function (BCM -		Diagnosis Procedure	18	J
COMMON ITEM)	9	Component Inspection	19	
REAR WINDOW DEFOGGER	9	ECU DIAGNOSIS	20	K
REAR WINDOW DEFOGGER : CONSULT-III		BCM (BODY CONTROL MODULE)	20	
Function (BCM - REAR DEFOGGER)	9	Reference Value	20	
CAN COMMUNICATION	10	Wiring Diagram	21	DEF
System Description	10	SYMPTOM DIAGNOSIS	29	
COMPONENT DIAGNOSIS	11	REAR WINDOW DEFOGGER AND DOOR		
REAR WINDOW DEFOGGER SWITCH	11	MIRROR DEFOGGER DO NOT OPERATE.	29	M
Description	11	Diagnosis Procedure	29	
Component Function Check	11	REAR WINDOW DEFOGGER DOES NOT		
Diagnosis Procedure	11	OPERATE BUT BOTH OF DOOR MIRROR		N
REAR WINDOW DEFOGGER RELAY	12	DEFOGGER OPERATE.	30	
Description	12	Diagnosis Procedure	30	O
Component Function Check	12	BOTH DOORS MIRROR DEFOGGER DON'T		
Diagnosis Procedure	12	OPERATE BUT REAR WINDOW DEFOG-		
Component Inspection	13	GER OPERATES	31	P
REAR WINDOW DEFOGGER POWER SUP-		Diagnosis Procedure	31	
PLY AND GROUND CIRCUIT	14	DRIVER SIDE DOOR MIRROR DEFOGGER		
Description	14	DOES NOT OPERATE.	32	
Component Function Check	14	Diagnosis Procedure	32	

PASSENGER SIDE DOOR MIRROR DEFOGGER DOES NOT OPERATE.	33	PRECAUTIONS	35
Diagnosis Procedure	33	Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	35
REAR WINDOW DEFOGGER SWITCH DOES NOT LIGHT, BUT REAR WINDOW DEFOGGER OPERATES	34	ON-VEHICLE REPAIR	36
Diagnosis Procedure	34	FILAMENT	36
PRECAUTION	35	Inspection and Repair	36
		CONDENSER	38
		Exploded View	38
		Removal and Installation	38

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000001697540

OVERALL SEQUENCE



DETAILED FLOW

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

1. GET INFORMATION FOR SYMPTOM

Get the detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred).

>> GO TO 2

2. CHECK DTC

1. Check DTC.
2. Perform the following procedure if DTC is displayed.
 - Record DTC and freeze frame data (Print them out with CONSULT-III.)
 - Erase DTC.
 - Study the relationship between the cause detected by DTC and the symptom described by the customer.
3. Check related service bulletins for information.

Is any symptom described and any DTC detected?

Symptom is described, DTC is displayed>>GO TO 3

Symptom is described, DTC is not displayed>>GO TO 4

Symptom is not described, DTC is displayed>>GO TO 5

3. CONFIRM THE SYMPTOM

Confirm the symptom described by the customer.

Connect CONSULT-III to the vehicle in "DATA MONITOR" mode and check real time diagnosis results.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 5

4. CONFIRM THE SYMPTOM

Confirm the symptom described by the customer.

Connect CONSULT-III to the vehicle in "DATA MONITOR" mode and check real time diagnosis results.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 6

5. PERFORM DTC CONFIRMATION PROCEDURE

Perform DTC Confirmation Procedure for the displayed DTC, and then check that DTC is detected again.

At this time, always connect CONSULT-III to the vehicle, and check diagnostic results in real time.

If two or more DTCs are detected, refer to XX-XX, "*****" and determine trouble diagnosis order.

NOTE:

- Freeze frame data is useful if the DTC is not detected.
- Perform Component Function Check if DTC Confirmation Procedure is not included in Service Manual. This simplified check procedure is an effective alternative though DTC cannot be detected during this check. If the result of Component Function Check is NG, it is the same as the detection of DTC by DTC Confirmation Procedure.

Is DTC detected?

YES >> GO TO 8

NO >> Refer to XX-XX, "*****".

6. PERFORM BASIC INSPECTION

Perform DEF-3, "Work Flow".

Inspection End>>GO TO 7

7. DETECT MALFUNCTIONING SYSTEM BY SYMPTOM TABLE

Detect malfunctioning system according to DEF-6, "System Description" based on the confirmed symptom in step 4, and determine the trouble diagnosis order based on possible causes and symptom.

>> GO TO 8

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

8. DETECT MALFUNCTIONING PART BY DIAGNOSTIC PROCEDURE

Inspect according to Diagnostic Procedure of the system.

NOTE:

The Diagnostic Procedure described based on open circuit inspection. A short circuit inspection is also required for the circuit check in the Diagnostic Procedure.

Is malfunctioning part detected?

YES >> GO TO 9

NO >> Check voltage of related BCM terminals using CONSULT-III.

9. REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnostic Procedure again after repair and replacement.
3. Check DTC. If DTC is displayed, erase it.

>> GO TO 10

10. FINAL CHECK

When DTC was detected in step 2, perform DTC Confirmation Procedure or Component Function Check again, and then check that the malfunction have been repaired securely.

When symptom was described from the customer, refer to confirmed symptom in step 3 or 4, and check that the symptom is not detected.

Does the symptom reappear?

YES (DTC is detected)>>GO TO 8

YES (Symptom remains)>>GO TO 6

NO >> **INSPECTION END**

A
B
C
D
E
F
G
H
I
J
K
DEF
M
N
O
P

REAR WINDOW DEFOGGER SYSTEM


< FUNCTION DIAGNOSIS >

FUNCTION DIAGNOSIS

REAR WINDOW DEFOGGER SYSTEM

System Diagram

INFOID:000000001697541



System Description

INFOID:000000001697542

Operation Description

- Turn rear window defogger switch ON when the ignition switch is turned ON. Then controller (auto amp.) (rear window defogger switch) transmits rear window defogger switch signal to BCM.
- BCM turns rear window defogger relay ON when rear window defogger switch signal is received.
- Rear window defogger and door mirror defogger (with door mirror defogger) are supplied with power and operate when rear window defogger relay turns ON.
- BCM transmits rear window defogger control signal to IPDM E/R via CAN communication when rear window defogger operates.
- Rear window defogger ON is displayed when controller (auto amp.) receives signals.

Timer function

- BCM turns rear window defogger relay ON for approximately 15 minutes when rear window defogger switch is turned ON while ignition switch is ON. It makes rear window defogger and door mirror defogger (with door mirror defogger) operate.
- Timer is canceled after pressing rear window defogger switch again during timer operation. Then BCM turns rear window defogger relay OFF. The same reaction also occurs during timer operation, if the ignition switch is turned OFF.

INPUT/OUTPUT SIGNAL CHART

Switch	Input signal to BCM	BCM function	Acuator
Rear window defogger switch	Defogger switch signal	Rear window defogger and door mirror defogger* control	Rear window defogger
Push button ignition switch	Ignition signal		Door mirror defogger *


*: With door mirror defogger

REAR WINDOW DEFOGGER SYSTEM

< FUNCTION DIAGNOSIS >

Component Parts Location

INFOID:000000001697543



1. BCM M18, M20 (view with glove box removed)

2. Rear window defogger switch (part of front air control)

3. A. Rear window defogger ground connector D413 (Hatchback)
B. Rear window defogger connector D412 (Hatchback)
C. Condenser-1 D409, D411 (Hatchback)
4. A. Rear window defogger connector B140 (Sedan)
B. Rear window defogger ground connector B141 (Sedan)
C. Condenser-1 B130, B131 (Sedan)

5. IPDM E/R E46, E48

6. Door mirror LH D4, RH D107 (with heated mirrors)
7. Heated mirror relay M48 (with heated mirrors)

Component Description

INFOID:000000001697544

BCM	- Operates the rear window defogger with the operation of rear window defogger switch. - Performs the timer control of rear window defogger.
Rear window defogger relay	Operates the rear window defogger and the door mirror defogger with the control signal from BCM.

REAR WINDOW DEFOGGER SYSTEM

< FUNCTION DIAGNOSIS >

Front air control (rear window defogger switch)	• The rear window defogger switch is turned ON. • Turns the indicator lamp ON when detecting the operation of rear window defogger.
Rear window defogger	• Heats the heating wire with the power supply from the rear window defogger relay to prevent the rear window from fogging up.
Door mirror defogger*	• Heats the heating wire with the power supply from the rear window defogger relay to prevent the door mirror from fogging up.

*: With door mirror defogger

DIAGNOSIS SYSTEM (BCM)

< FUNCTION DIAGNOSIS >

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT-III Function (BCM - COMMON ITEM)

INFOID:000000001697545

APPLICATION ITEM

CONSULT-III performs the following functions via CAN communication with BCM.

Diagnosis mode	Function Description
WORK SUPPORT	Changes the setting for each system function.
SELF-DIAG RESULTS	Displays the diagnosis results judged by BCM. Refer to <u>XX-XX, "*****"</u> .
CAN DIAG SUPPORT MNTR	Monitors the reception status of CAN communication viewed from BCM.
DATA MONITOR	The BCM input/output signals are displayed.
ACTIVE TEST	The signals used to activate each device are forcibly supplied from BCM.
ECU IDENTIFICATION	The BCM part number is displayed.
CONFIGURATION	This function is not used even though it is displayed.

SYSTEM APPLICATION

BCM can perform the following functions for each system.

NOTE:

It can perform the diagnosis modes except the following for all subsystem selection items.

System	Sub system selection item	Diagnosis mode		
		WORK SUPPORT	DATA MONITOR	ACTIVE TEST
Rear window defogger	REAR DEFOGGER		×	×
BCM	BCM	×		

REAR WINDOW DEFOGGER

REAR WINDOW DEFOGGER : CONSULT-III Function (BCM - REAR DEFOGGER)

INFOID:000000001697546

Data monitor

Monitor Item	Description
REAR DEF SW	Indicates [ON/OFF] condition of rear defogger switch.
PUSH SW	Indicates [ON/OFF] condition of push switch.

ACTIVE TEST

Test Item	Description
REAR DEFOGGER	This test is able to check rear window defogger operation. Rear window defogger operates when "ON" on CONSULT-III screen is touched.

CAN COMMUNICATION

< FUNCTION DIAGNOSIS >

CAN COMMUNICATION

System Description

INFOID:000000001697547

Refer to XX-XX, "*****".

REAR WINDOW DEFOGGER SWITCH

< COMPONENT DIAGNOSIS >

COMPONENT DIAGNOSIS

REAR WINDOW DEFOGGER SWITCH

Description

INFOID:000000001697548

- The rear window defogger is operated by turning the rear window defogger switch ON.
- Turns the indicator lamp in the rear window defogger switch ON when operating the rear window defogger.

Component Function Check

INFOID:000000001697549

1. CHECK REAR WINDOW DEFOGGER SWITCH FUNCTION

Check that the indicator lamp of rear window defogger illuminates with rear window defogger switch ON.

Is the inspection result normal?

- YES >> Rear window defogger switch function is OK.
NO >> Refer to [DEF-11, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000001697550

1. CHECK CONTROLLER (AUTO AMP.) (REAR WINDOW DEFOGGER SWITCH)

Does controller (auto amp.) operate normally?

Is the inspection result normal?

- YES >> Inspection End.
NO >> GO TO 2


2. CHECK REAR WINDOW DEFOGGER SWITCH INDICATOR CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between controller (auto amp.) connector and ground.

Terminals		(-)	Condition of rear window defogger switch	Voltage (V) (Approx.)
(+)				
Controller (auto amp.) connector	Terminal			
M37	22	Ground	ON	Battery voltage
			OFF	0

Is the inspection result normal?

- YES >> Repair or replace harness.
NO >> Replace controller (auto amp.). Refer to [XX-XX, "*****"](#).



REAR WINDOW DEFOGGER RELAY

< COMPONENT DIAGNOSIS >

REAR WINDOW DEFOGGER RELAY

Description

INFOID:000000001697551

Power is supplied to the rear window defogger with BCM control.

Component Function Check

INFOID:000000001697552

1. CHECK REAR WINDOW DEFOGGER RELAY POWER SUPPLY CIRCUIT

Check that an operation noise of rear window defogger relay [located in fuse block (J/B)] can be heard when turning the rear window defogger switch ON.

Is the inspection result normal?

- YES >> Rear window defogger relay power supply circuit is OK.
NO >> Refer to [DEF-12, "Diagnosis Procedure"](#).


Diagnosis Procedure

INFOID:000000001697553

1. CHECK REAR WINDOW DEFOGGER RELAY GROUND CIRCUIT

- Turn ignition switch ON.
- Check voltage between BCM connector and ground.

Terminals		Condition of rear window defogger switch	Voltage (V) (Approx.)
(+)	(-)		
BCM connector	Terminal		
M18	59	ON	0
		OFF	Battery voltage



ALLIA0175ZZ


Is the inspection result normal?

- YES >> Rear window defogger power supply circuit is OK.
NO >> GO TO 2

2. CHECK HARNESS CONTINUITY

- Turn ignition switch OFF.
- Disconnect BCM and fuse block (J/B).
- Check continuity between BCM connector (A) and fuse block (J/B) connector (B).

BCM connector	Terminal	Fuse block (J/B) connector	Terminal	Continuity
M18 (A)	59	M4 (B)	4Q	Yes



ALLIA0176ZZ

Is the inspection result normal?

- YES >> GO TO 3
NO >> Repair or replace harness.

3. CHECK REAR WINDOW DEFOGGER RELAY

Check rear window defogger relay.

Refer to [DEF-13, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 4
NO >> Replace rear window defogger relay.

4. CHECK INTERMITTENT INCIDENT

Check intermittent incident.

Refer to [XX-XX, "*****"](#)

Is the inspection result normal?

- YES >> Check the following.

REAR WINDOW DEFOGGER RELAY

< COMPONENT DIAGNOSIS >

- Battery power supply circuit.
- Fuse block (J/B).

NO >> Repair or replace the malfunctioning parts.

Component Inspection

INFOID:000000001697554


1. CHECK REAR WINDOW DEFOGGER RELAY

Check rear window defogger relay.

Terminal		Condition	Continuity
Rear window defogger relay			
3	5	12V direct current supply between terminals 1 and 2.	Yes
		No current supply	No

Is the inspection result normal?

- YES >> Inspection End.
- NO >> Replace rear window defogger relay.



DEF

REAR WINDOW DEFOGGER POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

REAR WINDOW DEFOGGER POWER SUPPLY AND GROUND CIRCUIT

Description

INFOID:000000001697555

Heats the heating wire with the power supply from the rear window defogger relay to prevent the rear window from fogging up.

Component Function Check

INFOID:000000001697556

1. CHECK REAR WINDOW DEFOGGER

Check that the heating wire of rear window defogger is heated when turning the rear window defogger switch ON.

Is the inspection result normal?

- YES >> Rear window defogger is OK.
NO >> Refer to [DEF-14, "Diagnosis Procedure"](#).


Diagnosis Procedure

INFOID:000000001697557

1. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between rear window defogger connector and ground.

Terminals			Condition of rear window defogger switch	Voltage (V) (Approx.)
(+) (Rear window defogger connector)		(-) (Terminal)		
B53	1	Ground	ON	Battery voltage
			OFF	0




Is the inspection result normal?

- YES >> GO TO 2
NO >> GO TO 3

2. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect rear window defogger.
3. Check continuity between rear window defogger connector and ground.

Rear window defogger connector	Terminal	Ground	Continuity
B54	2		Yes



Is the inspection result normal?

- YES >> GO TO 5
NO >> Repair or replace harness.

3. CHECK HARNESS CONTINUITY 1

REAR WINDOW DEFOGGER POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect condenser and rear window defogger.
3. Check continuity between condenser connector (A) and rear window defogger connector (B).

Condenser connector	Terminal	Rear window defogger connector	Terminal	Continuity
B52 (A)	1	B53 (B)	1	Yes

Is the inspection result normal?

YES >> GO TO 4

NO >> Replace condenser. Refer to [DEF-38, "Removal and Installation"](#).

4. CHECK HARNESS CONTINUITY 2

1. Disconnect fuse block (J/B).
2. Check continuity between fuse block (J/B) connector (A) and condenser connector (B).

Fuse block (J/B) connector	Terminal	Condenser connector	Terminal	Continuity
B4 (A)	10T	B52 (B)	1	Yes
	11T			

Is the inspection result normal?

YES >> GO TO 6

NO >> Replace or repair harness.

5. CHECK FILAMENT

Check filament.

Refer to [DEF-15, "Component Inspection"](#).

Is the inspection result normal?

YES >> Refer to [XX-XX, "*****"](#).

NO >> Repair filament. Refer to [DEF-36, "Inspection and Repair"](#).

6. CHECK INTERMITTENT INCIDENT

Check intermittent incident.

Refer to [XX-XX, "*****"](#).

Is the inspection result normal?

YES >> Check the following.

- Battery power supply circuit.
- Fuse block (J/B).

NO >> Repair or replace the malfunctioning parts.

Component Inspection

INFOID:000000001697558

1. CHECK FILAMENT



Check the filament for damage or open circuits.

Refer to [DEF-36, "Inspection and Repair"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair filament. Refer to [DEF-36, "Inspection and Repair"](#).



A
B
C
D
E
F
G
H
I
J
K
DEF
M
N
O
P

DRIVER SIDE DOOR MIRROR DEFOGGER

< COMPONENT DIAGNOSIS >

DRIVER SIDE DOOR MIRROR DEFOGGER

Description

INFOID:000000001697559

Heats the heating wire with the power supply from the rear window defogger relay to prevent the door mirror from fogging up.

Component Function Check

INFOID:000000001697560

1. CHECK DOOR MIRROR DEFOGGER LH

Check that heating wire of door mirror defogger LH is heated when turning the rear window defogger switch ON.

Is the inspection result normal?

- YES >> Door mirror defogger is OK.
NO >> Refer to [DEF-16, "Diagnosis Procedure"](#).


Diagnosis Procedure

INFOID:000000001697561

1. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect door mirror LH.
3. Turn ignition switch ON.
4. Check voltage between door mirror LH connector and ground.

Terminals		Condition of rear window defogger switch	Voltage (V) (Approx.)
(+)	(-)		
Door mirror LH connector	Terminal		
D4	1	ON	Battery voltage
		OFF	0




Is the inspection result normal?

- YES >> GO TO 2
NO >> Repair or replace harness.

2. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between door mirror LH connector and ground.

Door mirror LH connector	Terminal	Ground	Continuity
D4	2		Yes



Is the inspection result normal?

- YES >> GO TO 3
NO >> Repair or replace harness.

3. CHECK DOOR MIRROR DEFOGGER LH

Check door mirror defogger LH.
Refer to [DEF-17, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 4
NO >> Replace door mirror. Refer to [XX-XX, "*****"](#).

4. CHECK INTERMITTENT INCIDENT

Check intermittent incident.

DRIVER SIDE DOOR MIRROR DEFOGGER

< COMPONENT DIAGNOSIS >

Refer to XX-XX, "*****".

Is the inspection result normal?

- YES >> Check the following.
- Battery power supply circuit.
 - Fuse block (J/B).
- NO >> Repair or replace the malfunctioning parts.

Component Inspection

INFOID:000000001697562


1. CHECK DOOR MIRROR DEFOGGER LH

1. Turn ignition switch OFF.
2. Disconnect door mirror LH.
3. Check continuity between door mirror terminals.

Terminal		Continuity
1	2	Yes

Is the inspection result normal?

- YES >> Inspection End.
- NO >> Replace door mirror LH. Refer to XX-XX, "*****".



A
B
C
D
E
F
G
H
I
J
K
DEF
M
N
O
P

PASSENGER SIDE DOOR MIRROR DEFOGGER

< COMPONENT DIAGNOSIS >

PASSENGER SIDE DOOR MIRROR DEFOGGER

Description

INFOID:000000001697563

Heats the heating wire with the power supply from the rear window defogger relay to prevent the door mirror from fogging up.

Component Function Check

INFOID:000000001697564

1. CHECK DOOR MIRROR DEFOGGER RH

Check that the heating wire of door mirror defogger RH is heated when turning the rear window defogger switch ON.

Is the inspection result normal?

- YES >> Door mirror defogger RH is OK.
NO >> Refer to [DEF-18. "Diagnosis Procedure"](#).


Diagnosis Procedure

INFOID:000000001697565

1. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect door mirror RH.
3. Turn ignition switch ON.
4. Check voltage between door mirror RH connector and ground.

Terminals			Condition of rear window defogger switch	Voltage (V) (Approx.)
(+)		(-)		
Door mirror RH connector	Terminal			
D107	1	Ground	ON	Battery voltage
			OFF	0




Is the inspection result normal?

- YES >> GO TO 2
NO >> Repair or replace harness.

2. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between door mirror RH connector and ground.

Door mirror RH connector	Terminal	Ground	Continuity
D107	2		Yes



Is the inspection result normal?

- YES >> GO TO 3
NO >> Repair or replace harness.

3. CHECK PASSENGER SIDE DOOR MIRROR DEFOGGER

Check door mirror defogger RH.
Refer to [DEF-19. "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 4
NO >> Replace door mirror RH. Refer to [XX-XX. "*****"](#).

4. CHECK INTERMITTENT INCIDENT

Check intermittent incident.

PASSENGER SIDE DOOR MIRROR DEFOGGER

< COMPONENT DIAGNOSIS >

Refer to XX-XX, "*****".

Is the inspection result normal?

- YES >> Check the following.
 - Battery power supply circuit.
 - Fuse block (J/B).
- NO >> Repair or replace the malfunctioning parts.

Component Inspection

INFOID:000000001697566


1. CHECK DOOR MIRROR DEFOGGER RH

1. Turn ignition switch OFF.
2. Disconnect door mirror RH.
3. Check continuity between door mirror terminals.

Terminal		Continuity
1	2	Yes

Is the inspection result normal?

- YES >> Inspection End.
- NO >> Replace door mirror RH. Refer to XX-XX, "*****".



DEF

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

ECU DIAGNOSIS

BCM (BODY CONTROL MODULE)

Reference Value

INFOID:0000000001697567

VALUES ON THE DIAGNOSIS TOOL

Monitor Item	Condition	Value/Status
REAR DEF SW	NOTE: The item is indicated, but not monitored.	OFF

TERMINAL LAYOUT


Refer to XX-XX, "*****".

PHYSICAL VALUES

Refer to XX-XX, "*****".

INFOID:0000000001697568

Wiring Diagram



ALLWA0121GB

A
B
C
D
E
F
G
H
I
J
K
DE
M
N
O
P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

**NO
DATA**

ALLIA0659GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

NO
DATA

- A
- B
- C
- D
- E
- F
- G
- H
- I
- J
- K
- DEF
- M
- N
- O
- P

ALLIA0660GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

**NO
DATA**

ALLIA0661GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

NO
DATA

- A
- B
- C
- D
- E
- F
- G
- H
- I
- J
- K
- DEF
- M
- N
- O
- P

ALLIA0662GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

**NO
DATA**

ALLIA0663GB

< ECU DIAGNOSIS >

NO
DATA

- A
- B
- C
- D
- E
- F
- G
- H
- I
- J
- K
- DEF
- M
- N
- O
- P

ALLIA0664GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

**NO
DATA**

ALLIA0665GB

REAR WINDOW DEFOGGER AND DOOR MIRROR DEFOGGER DO NOT OPERATE.

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

REAR WINDOW DEFOGGER AND DOOR MIRROR DEFOGGER DO NOT OPERATE.

Diagnosis Procedure

INFOID:0000000001697569

1. CHECK REAR WINDOW DEFOGGER SWITCH

Check rear window defogger switch.
Refer to DEF-14, "Component Function Check".

Is the inspection result normal?

- YES >> GO TO 2
- NO >> Repair or replace the malfunctioning parts.

2. CHECK REAR WINDOW DEFOGGER RELAY

Check rear window defogger relay.
Refer to DEF-12, "Component Function Check".

Is the inspection result normal?

- YES >> Refer to XX-XX, "*****".
- NO >> Repair or replace the malfunctioning parts.

A
B
C
D
E
F
G
H
I
J
K
DEF
M
N
O
P

DEF

REAR WINDOW DEFOGGER DOES NOT OPERATE BUT BOTH OF DOOR MIRROR DEFOGGER OPERATE.

< SYMPTOM DIAGNOSIS >

REAR WINDOW DEFOGGER DOES NOT OPERATE BUT BOTH OF DOOR MIRROR DEFOGGER OPERATE.

Diagnosis Procedure

INFOID:0000000001697570

1. CHECK REAR WINDOW DEFOGGER POWER SUPPLY AND GROUND CIRCUIT

Check rear window defogger power supply and ground circuit.

Refer to [DEF-14, "Component Function Check"](#).

Is the inspection result normal?

YES >> Refer to [XX-XX, "*****"](#).

NO >> Repair or replace the malfunctioning parts.

BOTH DOORS MIRROR DEFOGGER DON'T OPERATE BUT REAR WINDOW DEFOGGER OPERATES

< SYMPTOM DIAGNOSIS >

BOTH DOORS MIRROR DEFOGGER DON'T OPERATE BUT REAR WINDOW DEFOGGER OPERATES

Diagnosis Procedure

INFOID:000000001697571

1. CHECK INTERMITTENT INCIDENT

Check intermittent incident.

Refer to XX-XX, "*****".

Is the inspection result normal?

- YES >> Check the following.
- Battery power supply circuit.
 - Fuse block (J/B).
- NO >> Repair or replace the malfunctioning parts.

A
B
C
D
E
F
G
H
I
J
K
DEF
M
N
O
P

DEF

DRIVER SIDE DOOR MIRROR DEFOGGER DOES NOT OPERATE.

< SYMPTOM DIAGNOSIS >

DRIVER SIDE DOOR MIRROR DEFOGGER DOES NOT OPERATE.

Diagnosis Procedure

INFOID:000000001697572

1. CHECK DOOR MIRROR DEFOGGER LH

Check door mirror defogger LH.

Refer to [DEF-16, "Component Function Check"](#).

Is the inspection result normal?

YES >> Refer to [XX-XX, "*****"](#).

NO >> Repair or replace the malfunctioning parts.

PASSENGER SIDE DOOR MIRROR DEFOGGER DOES NOT OPERATE.

< SYMPTOM DIAGNOSIS >

PASSENGER SIDE DOOR MIRROR DEFOGGER DOES NOT OPERATE.

Diagnosis Procedure

INFOID:000000001697573

1. CHECK DOOR MIRROR DEFOGGER RH

Check door mirror defogger RH.

Refer to [DEF-18, "Component Function Check"](#).

Is the inspection result normal?

YES >> Refer to [XX-XX, "*****"](#).

NO >> Repair or replace the malfunctioning parts.

A

B

C

D

E

F

G

H

I

J

K

DEF

M

N

O

P

REAR WINDOW DEFOGGER SWITCH DOES NOT LIGHT, BUT REAR WINDOW DEFOGGER OPERATES

< SYMPTOM DIAGNOSIS >

REAR WINDOW DEFOGGER SWITCH DOES NOT LIGHT, BUT REAR WINDOW DEFOGGER OPERATES

Diagnosis Procedure

INFOID:000000001697574

1. CHECK CONTROLLER (AUTO AMP.) (REAR WINDOW DEFOGGER SWITCH)

Check that the controller (auto amp.) (rear window defogger switch) is operating normally.

OK or NG

OK >> Refer to [XX-XX, "*****"](#).

NG >> Refer to [DEF-11, "Diagnosis Procedure"](#).

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000001697575

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

A
B
C
D
E
F
G
H
I
J
K
DEF
M
N
O
P

FILAMENT

< ON-VEHICLE REPAIR >

ON-VEHICLE REPAIR


FILAMENT

Inspection and Repair


INFOID:000000001697576

INSPECTION


1. When measuring voltage, wrap tin foil around the top of the negative probe. Then press the foil against the wire with your finger.



2. Attach probe circuit tester (in Volt range) to middle portion of each filament.



3. If a filament is burned out, circuit tester registers 0 or battery voltage.
4. To locate burned out point, move probe to left and right along filament. Test needle will swing abruptly when probe passes the point.



REPAIR

REPAIR EQUIPMENT

- Conductive silver composition (DuPont No. 4817 or equivalent)




FILAMENT

< ON-VEHICLE REPAIR >

- Ruler 30 cm (11.8 in) long
- Drawing pen
- Heat gun
- Alcohol
- Cloth

REPAIRING PROCEDURE

1. Wipe broken heat wire and its surrounding area clean with a cloth dampened in alcohol.
2. Apply a small amount of conductive silver composition to tip of drawing pen.
Shake silver composition container before use.
3. Place ruler on glass along broken line. Deposit conductive silver composition on break with drawing pen. Slightly overlap existing heat wire on both sides [preferably 5 mm (0.20 in)] of the break.
4. After repair has been completed, check repaired wire for continuity. This check should be conducted 10 minutes after silver composition is deposited.
Do not touch repaired area while test is being conducted.
5. Apply a constant stream of hot air directly to the repaired area for approximately 20 minutes with a heat gun. A minimum distance of 3 cm (1.2 in) should be kept between repaired area and hot air outlet.
If a heat gun is not available, let the repaired area dry for 24 hours.



SPECIAL REPAIR REQUIREMENT

CONDENSER

< ON-VEHICLE REPAIR >

CONDENSER

Exploded View

INFOID:000000001697577


Refer to [DEF-38, "Exploded View"](#).

Removal and Installation

INFOID:000000001697578

REMOVAL

1. Remove the rear seat cushion and the rear seat back.
Refer to [XX-XX, "*****"](#).
2. Remove the rear kickplate, rear wheel well garnish and the rear pillar finisher.
Refer to [XX-XX, "*****"](#).
3. Remove bolt (A), and then remove condenser (1) from the vehicle body.



INSTALLATION

Install in the reverse order of removal.