

SECTION

SB

SEAT BELT

A
B
C
D
E
F
G
SB
I
J
K
L
M
N
O
P

CONTENTS

PRECAUTION	2	ON-VEHICLE REPAIR	6
PRECAUTIONS	2	FRONT SEAT BELT	6
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	2	Removal and Installation of Front Seat Belt	6
Precaution for Seat Belt Service	2	REAR SEAT BELT	8
BASIC INSPECTION	3	Removal and Installation of Rear Seat Belt	8
INSPECTION	3	LATCH SYSTEM FOR CHILDREN	11
Seat Belt Inspection	3	Removal and Installation	11
		TOP TETHER STRAP CHILD RESTRAINT	12
		Removal and Installation	12

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000001366680

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Precaution for Seat Belt Service

INFOID:000000001366681

CAUTION:

- Before removing the front seat belt pre-tensioner assembly, turn the ignition switch off, disconnect the both battery cables and wait at least 3 minutes.
- After replacing or reinstalling front seat belt pre-tensioner assembly, or reconnecting front seat belt pre-tensioner connector, check the system function. Refer to [SRC-11, "SRS Operation Check"](#).
- Do not disassemble buckle or seat belt assembly.
- Do not reuse seat belt anchor bolts after removal. Replace with new ones.
- Replace anchor bolts if they are deformed or worn out.
- Never oil tongue and buckle.
- If any component of seat belt assembly is questionable, do not repair. Replace the whole seat belt assembly.
- If webbing is cut, frayed, or damaged, replace seat belt assembly.
- When replacing seat belt assembly, use a genuine NISSAN seat belt assembly.

AFTER A COLLISION

WARNING:

- Inspect all seat belt assemblies including retractors and attaching hardware after any collision.
- NISSAN recommends that all seat belt assemblies in use during a collision be replaced unless the collision was minor and the belts show no damage and continue to operate properly. Failure to do so could result in serious personal injury in an accident. Seat belt assemblies not in use during a collision should also be replaced if either damage or improper operation is noted. Seat belt pre-tensioner should be replaced even if the seat belts are not in use during a frontal collision in which the air bags are deployed.

Replace any seat belt assembly (including anchor bolts) if:

- The seat belt was in use at the time of a collision (except for minor collisions and the belts, retractors and buckles show no damage and continue to operate properly).
- The seat belt was damaged in an accident. (i.e. torn webbing, bent retractor or guide).
- The seat belt attaching point was damaged in an accident. Inspect the seat belt attaching area for damage or distortion and repair as necessary before installing a new seat belt assembly.
- Anchor bolts are deformed or worn out.
- The seat belt pre-tensioner should be replaced even if the seat belts are not in use during the collision in which the air bags are deployed.

BASIC INSPECTION

INSPECTION

Seat Belt Inspection

INFOID:000000001366781

AFTER A COLLISION

WARNING:

Inspect all seat belt assemblies including retractors and attaching hardware after any collision. NISSAN recommends that all seat belt assemblies in use during a collision be replaced unless the collision was minor and the belts show no damage and continue to operate properly. Failure to do so could result in serious personal injury in an accident. Seat belt assemblies not in use during a collision should also be replaced if either damage or improper operation is noted. Seat belt pre-tensioner should be replaced even if the seat belts are not in use during a frontal collision in which the air bags are deployed.

Replace any seat belt assembly (including anchor bolts) if:

- The seat belt was in use at the time of a collision (except for minor collisions and the belts, retractors and buckles show no damage and continue to operate properly).
- The seat belt was damaged in an accident. (i.e. torn webbing, bent retractor or guide, etc.)
- The seat belt attaching point was damaged in an accident. Inspect the seat belt attaching area for damage or distortion and repair as necessary before installing a new seat belt assembly.
- Anchor bolts are deformed or worn out.
- The seat belt pre-tensioner should be replaced even if the seat belts are not in use during a frontal collision in which the air bags are deployed.

PRELIMINARY CHECKS

1. Check the seat belt warning lamp/chime for proper operation as follows:
 - a. Switch ignition ON. The seat belt warning lamp should illuminate. Also, the seat belt warning chime should sound for about seven seconds.
 - b. Fasten driver's seat belt. The seat belt warning lamp should go out and the chime (if sounding) should stop.
2. If the air bag warning lamp is blinking, conduct self-diagnosis using CONSULT-III, and air bag warning lamp. Refer to [SRC-11, "SRS Operation Check"](#).
3. Check that the seat belt retractor, seat belt anchor and buckle bolts are securely attached.
4. Check the shoulder seat belt guide and shoulder belt height adjuster for front seats. Make sure guide swivels freely and that webbing lays flat and does not bind in guide. Make sure height adjuster operates properly and holds securely.
5. Check retractor operation:
 - a. Fully extend the seat belt webbing and check for twists, tears or other damage.
 - b. Allow the seat belt to retract. Make sure that webbing returns smoothly and completely into the retractor. If the seat belt does not return smoothly, wipe the inside of the loops with a clean paper cloth. Dirt build-up in the loops of the upper anchors can cause the seat belts to retract slowly.
 - c. Fasten the seat belt. Check the seat belt returns smoothly and completely to the retractor. If the webbing does not return smoothly, the cause may be an accumulation of dust or dirt. Use the "SEAT BELT TAPE SET" and perform the following steps.

Inspect the front seat belt though-anchor

1. Pull the seat belt out to a length of 500 mm (19.69 in) or more.
2. Use a clip or other device to attach the seat belt at the center pillar webbing opening.
3. Pass a thin wire through the D-ring anchor webbing opening. Hold both ends of the wire and pull taut while moving it up and down several times along the webbing opening surface to remove matter stuck there.
4. Any dirt that cannot be removed with the wire can be removed by cleaning the opening with a clean cloth.
5. Apply tape at the point where the webbing contacts the though-anchor webbing opening.

NOTE:

Apply the tape so that there is no looseness or wrinkling.

6. Remove the clip attaching the seat belt and check that the webbing returns smoothly.

INSPECTION

< BASIC INSPECTION >

6. Repeat steps above as necessary to check the other seat belts.

SEAT BELT RETRACTOR ON-VEHICLE CHECK

Emergency Locking Retractors (ELR) and Automatic Locking Retractors (ALR)

NOTE:

All seat belt retractors are of the Emergency Locking Retractors (ELR) type. In an emergency (sudden stop) the retractor will lock and prevent the webbing from extending any further. All 3-point type seat belt retractors except the driver's seat belt also have an Automatic Locking Retractors (ALR) mode. The ALR mode (also called child restraint mode) is used when installing child seats. The ALR mode is activated when the seat belt is fully extended. When the webbing is then retracted partially, the ALR mode automatically locks the seat belt in a specific position so the webbing cannot be extended any further. To cancel the ALR mode, allow the seat belt to fully wind back into the retractor.

Check the seat belt retractors using the following test(s) to determine if a retractor assembly is operating properly.

ELR Function Stationary Check

Grasp the shoulder webbing and pull it forward quickly. The retractor should lock and prevent the belt from extending further.

ALR Function Stationary Check

1. Pull out entire length of seat belt from retractor until a click is heard.
2. Retract the webbing partially. A clicking noise should be heard as the webbing retracts, indicating that the retractor is in the Automatic Locking Retractors (ALR) mode.
3. Grasp the seat belt and try to pull out the retractor. The webbing must lock and not extend any further. If NG, replace the retractor assembly.
4. Allow the entire length of the webbing to retract to cancel the automatic locking mode.

ELR Function Moving Check

WARNING:

Perform the following test in a safe, open area clear of other vehicles and obstructions (for example, a large, empty parking lot). Road surface must be paved and dry. DO NOT perform the following test on wet or gravel roads or on public streets and highways. This could result in an accident and serious personal injury. The driver and passenger must be prepared to brace themselves in the event the retractor does not lock.

1. Fasten driver's seat belt. Buckle a passenger into the seat for the belt that is to be tested.
2. Proceed to the designated safe area.
3. Drive the vehicle at approximately 16 km/h (10 MPH). Notify any passengers of a pending sudden stop and the driver and passenger must be prepared to brace themselves in the event the retractor does not lock, apply brakes firmly and make a very hard stop.

During the stop, seat belts should lock and not be extended. If the seat belt retractor assembly does not lock, perform the retractor off-vehicle check.


SEAT BELT RETRACTOR OFF-VEHICLE CHECK

1. Remove the seat belt retractor. Refer to [SB-6, "Removal and Installation of Front Seat Belt"](#).

INSPECTION

< BASIC INSPECTION >

2. Slowly pull out seat belt webbing while tilting the retractor assembly forward from the installed position without twisting the retractor assembly as shown in the illustration.



A: Seat belt retractor in vertically installed position.

B: With 15° or less tilt, the webbing can be pulled out.

C: With 35° or more tilt, the webbing can not be pulled out.

D: Seat belt retractor in horizontally installed position.

⇐: Vehicle front.

If the seat belt does not operate properly within the specifications, replace the seat belt retractor assembly.

FRONT SEAT BELT

< ON-VEHICLE REPAIR >


ON-VEHICLE REPAIR

FRONT SEAT BELT

Removal and Installation of Front Seat Belt

INFOID:000000001396419

LHD shown, RHD similar



- | | | |
|--|--|--|
| 1. Outer anchor RH (also LH if equipped) | 2. Anchor cover RH (also LH if equipped) | 3. Seat belt pre-tensioner connector |
| 4. Seat belt retractor RH | 5. Lap seat belt pre-tensioner (driver side) cover lower | 6. Lap seat belt pre-tensioner (driver side) cover upper |
| 7. Lap seat belt pre-tensioner (driver side) | 8. Seat belt retractor LH | 9. D-ring anchor |
| 10. Adjuster cover | 11. Seat belt adjuster | A. Outer anchor bolt RH |
| B. Seat belt retractor anchor bolt | C. Seat belt retractor bolt upper | D. Lap seat belt pre-tensioner (driver side) |
| E. D-ring anchor bolt | F. Adjuster anchor bolt | ⇐ Vehicle front |

CAUTION:

Before servicing the SRS, turn the ignition switch off, disconnect both battery cables and wait at least 3 minutes.

REMOVAL OF SEAT BELT RETRACTOR

1. Disconnect both the negative and positive battery cables, then wait at least 3 minutes.

FRONT SEAT BELT

< ON-VEHICLE REPAIR >

2. Remove the adjuster cover and D-ring anchor bolt.
3. Remove both the center pillar upper and lower garnish. Refer to [INT-20, "Removal and Installation"](#).


WARNING:

Do not reuse center pillar upper garnish if removed.

4. Pull the floor trim away from center pillar.
5. Disconnect seat belt pre-tensioner connector(s). Refer to [SRC-9, "Direct-connect SRS Component Connectors"](#).

NOTE:

Seat belt retractor LH assembly may have double pre-tensioners using 2 separate Direct-connect SRS Component Connectors. If equipped, make sure to disconnect both pre-tensioners.




6. Remove the outer anchor bolt (or lap seat belt pre-tensioner if driver side).
7. Remove the seat belt retractor bolt upper and seat belt retractor anchor bolt, then remove the seat belt retractor.

INSTALLATION OF SEAT BELT RETRACTOR

Installation is in the reverse order of removal.

REMOVAL OF SEAT BELT BUCKLE

1. Remove the front seat, refer to [SE-14, "Removal and Installation"](#).
2. Disconnect the seat belt buckle harness connector (1).
←: Vehicle front
3. Remove the anchor bolt (A), then remove the seat belt buckle (2).



INSTALLATION OF SEAT BELT BUCKLE

Installation is in the reverse order of removal.

REAR SEAT BELT


< ON-VEHICLE REPAIR >

REAR SEAT BELT

Removal and Installation of Rear Seat Belt

INFOID:000000001366761

Hatchback




- | | | |
|-------------------------------|-----------------------------------|------------------------|
| 1. D-ring anchor | 2. Outer seat belt retractor RH | 3. Outer anchor bolt |
| 4. Seat belt buckle center | 5. Seat belt buckle RH | 6. Seat belt buckle LH |
| 7. Center seat belt retractor | A. Outer retractor anchor bolt RH | B. Buckle anchor bolt |
| C. Center anchor bolt | | |

REAR SEAT BELT

< ON-VEHICLE REPAIR >

Sedan

SEC. 869



- 1. Seat belt retractor
- 4. Seat belt buckle
- A. Seat belt retractor bolt
- ← Vehicle front

- 2. Seat belt retractor cup
- 5. Rear seat cushion
- B. Buckle anchor bolt
- C. Seat belt anchor bolt

- 3. Rear seat belt
- 6. Seat belt escutcheon
- C. Seat belt anchor bolt
- Vehicle front

REMOVAL OF OUTER SEAT BELT RETRACTOR - HATCHBACK

1. Remove rear seatback, cushion and seat back side, refer to [SE-18, "Removal and Installation"](#).
2. Remove the outer anchor bolt.
3. Remove the luggage side lower finisher, refer to [INT-20, "Removal and Installation"](#).
4. Remove the D-ring anchor bolt.

A
B
C
D
E
F
G
SB
I
J
K
L
M
N
O
P

REAR SEAT BELT

< ON-VEHICLE REPAIR >

5. Remove the outer retractor anchor bolt, then remove outer seat belt retractor.

INSTALLATION OF OUTER SEAT BELT RETRACTOR - HATCHBACK

Installation is in the reverse order of removal.

REMOVAL OF OUTER SEAT BELT RETRACTOR - SEDAN

1. Remove rear seat cushion, refer to [SE-18, "Removal and Installation"](#).
2. Remove outer seat belt anchor bolt.
3. Release the seat belt escutcheon, then remove from belt.
4. Remove rear parcel shelf finisher, refer to [INT-26, "Removal and Installation"](#).
5. Remove outer seat belt retractor bolt, then remove outer seat belt retractor.

INSTALLATION OF OUTER SEAT BELT RETRACTOR - SEDAN

Installation is in the reverse order of removal.

REMOVAL OF CENTER SEAT BELT RETRACTOR - HATCHBACK


1. Remove and disassemble the rear seat cushion, refer to [SE-18, "Removal and Installation"](#).
2. Remove the center seat belt retractor.

INSTALLATION OF CENTER SEAT BELT RETRACTOR - HATCHBACK

Installation is in the reverse order of removal.

REMOVAL OF CENTER SEAT BELT RETRACTOR - SEDAN

1. Lift front edge of rear seat cushion and slide forward.
2. Remove center seat belt anchor bolt (A), then pull center seat belt through rear seat cushion (1).
← Vehicle front
3. Release the seat belt escutcheon, then remove from belt.
4. Remove rear parcel shelf finisher, refer to [INT-26, "Removal and Installation"](#).
5. Remove the bolt, then remove center seat belt retractor.



INSTALLATION OF CENTER SEAT BELT RETRACTOR - SEDAN

Installation is in the reverse order of removal.

REMOVAL OF SEAT BELT BUCKLE

1. Remove rear seat cushion, refer to [SE-18, "Removal and Installation"](#).
2. Remove buckle anchor bolt, then remove seat belt buckle.

INSTALLATION OF SEAT BELT BUCKLE

Installation is in the reverse order of removal.

LATCH SYSTEM FOR CHILDREN

< ON-VEHICLE REPAIR >

LATCH SYSTEM FOR CHILDREN

Removal and Installation

INFOID:000000001366762

NOTE:

The LATCH (Lower Anchors and Tether for Children) system is not serviceable.

- A
- B
- C
- D
- E
- F
- G
- SB
- I
- J
- K
- L
- M
- N
- O
- P

TOP TETHER STRAP CHILD RESTRAINT

< ON-VEHICLE REPAIR >


TOP TETHER STRAP CHILD RESTRAINT

Removal and Installation

INFOID:000000001366763

REMOVAL

1. Disconnect the negative battery cable.
2. Remove the rear parcel shelf finisher. Refer to [INT-26, "Removal and Installation"](#).
3. Remove the bolt (A), then remove the top tether bracket (1) from the body panel.



INSTALLATION

Installation is in the reverse order of removal.