

TM

SECTION

TRANSAXLE & TRANSMISSION

A

B

C

TM

CONTENTS

E

5MT: RS5F91R

PRECAUTION	7	GEAR OIL	17	F
PRECAUTIONS	7	Inspection	17	
Caution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	7	Draining	17	G
General Precautions	7	Refilling	17	
Caution for Work	7	REMOVAL AND INSTALLATION	18	
Liquid Gasket	8	SIDE OIL SEAL	18	H
PREPARATION	10	Removal and Installation	18	
PREPARATION	10	Inspection	18	I
Special Service Tools	10	POSITION SWITCH	19	
Commercial Service Tools	12	Removal and Installation	19	J
SYSTEM DESCRIPTION	13	Inspection	19	
STRUCTURE AND OPERATION	13	CONTROL LINKAGE	20	K
Sectional View	13	Exploded View	20	
System Description	13	Removal and Installation	20	
DTC/CIRCUIT DIAGNOSIS	15	Inspection	21	
POSITION SWITCH	15	AIR BREATHER HOSE	22	L
BACK-UP LAMP SWITCH	15	Exploded View	22	
BACK-UP LAMP SWITCH : Component Inspection	15	Removal and Installation	22	
PARK/NEUTRAL POSITION (PNP) SWITCH	15	5TH MAIN GEAR ASSEMBLY	23	M
PARK/NEUTRAL POSITION (PNP) SWITCH : Component Inspection	15	Removal and Installation	23	
SYMPTOM DIAGNOSIS	16	Inspection	23	
NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING	16	UNIT REMOVAL AND INSTALLATION	24	N
NVH Troubleshooting Chart	16	TRANSAXLE ASSEMBLY	24	
PERIODIC MAINTENANCE	17	Exploded View	24	O
		Removal and Installation	24	
		Inspection	25	
		UNIT DISASSEMBLY AND ASSEMBLY ...	26	P
		TRANSAXLE ASSEMBLY	26	
		Exploded View	26	
		Disassembly	30	
		Assembly	36	
		Inspection	44	

INPUT SHAFT AND GEAR	45	CVT CONTROL SYSTEM : Primary Speed Sensor	62
Exploded View	45	CVT CONTROL SYSTEM : Secondary Speed Sensor	62
Disassembly	45	CVT CONTROL SYSTEM : Output Speed Sensor...	63
Assembly	45	CVT CONTROL SYSTEM : CVT Fluid Temperature Sensor	63
Inspection	45	CVT CONTROL SYSTEM : Secondary Pressure Sensor	63
MAINSHAFT AND GEAR	47	CVT CONTROL SYSTEM : Primary Pressure Solenoid Valve	64
Exploded View	47	CVT CONTROL SYSTEM : Low Brake Solenoid Valve	64
Disassembly	47	CVT CONTROL SYSTEM : High Clutch & Reverse Brake Solenoid Valve	64
Assembly	49	CVT CONTROL SYSTEM : Torque Converter Clutch Solenoid Valve	64
Inspection	50	CVT CONTROL SYSTEM : Line Pressure Solenoid Valve	65
FINAL DRIVE	52	CVT CONTROL SYSTEM : G Sensor	65
Exploded View	52	CVT CONTROL SYSTEM : Overdrive Control Switch	65
Disassembly	52	CVT CONTROL SYSTEM : OD OFF Indicator Lamp	65
Assembly	52	CVT CONTROL SYSTEM : Shift Position Indicator	66
Inspection	52	CVT CONTROL SYSTEM : Malfunction Indicator Lamp (MIL)	67
SERVICE DATA AND SPECIFICATIONS (SDS)	54	SHIFT LOCK SYSTEM	67
SERVICE DATA AND SPECIFICATIONS (SDS)	54	SHIFT LOCK SYSTEM : Component Parts Location	67
General Specifications	54	STRUCTURE AND OPERATION	68
CVT: RE0F11A		TRANSAXLE	68
PRECAUTION	55	TRANSAXLE : Cross-Sectional View	68
PRECAUTIONS	55	TRANSAXLE : Transaxle Mechanism	68
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	55	TRANSAXLE : Operation Status	70
Precaution for Procedure without Cowl Top Cover..	55	TRANSAXLE : Oil Pressure System	71
Precaution for TCM and Transaxle Assembly Replacement	55	TRANSAXLE : Component Description	71
Precaution for G Sensor Removal/Installation or Replacement	55	FLUID COOLER & FLUID WARMER SYSTEM	72
General Precautions	56	FLUID COOLER & FLUID WARMER SYSTEM : System Description	72
On Board Diagnosis (OBD) System of CVT and Engine	56	SHIFT LOCK SYSTEM	73
Removal and Installation Procedure for CVT Unit Connector	57	SHIFT LOCK SYSTEM : System Description	73
PREPARATION	59	KEY LOCK SYSTEM	73
PREPARATION	59	KEY LOCK SYSTEM : System Description	73
Special Service Tools	59	SYSTEM	74
Commercial Service Tools	59	CVT CONTROL SYSTEM	74
SYSTEM DESCRIPTION	60	CVT CONTROL SYSTEM : System Description ...	74
COMPONENT PARTS	60	CVT CONTROL SYSTEM : Schematic	77
CVT CONTROL SYSTEM	60	CVT CONTROL SYSTEM : Fail-safe	78
CVT CONTROL SYSTEM : Component Parts Location	60	CVT CONTROL SYSTEM : Protection Control	81
CVT CONTROL SYSTEM : TCM	61	LINE PRESSURE CONTROL	
CVT CONTROL SYSTEM : ROM Assembly	61		
CVT CONTROL SYSTEM : Transmission Range Switch	62		

LINE PRESSURE CONTROL : System Description	82	CALIBRATION OF G SENSOR	130	A
SHIFT CONTROL	82	Description	130	
SHIFT CONTROL : System Description	83	Procedure	130	
SELECT CONTROL	84	STALL TEST	131	B
SELECT CONTROL : System Description	85	Work Procedure	131	
LOCK-UP CONTROL	85	LINE PRESSURE TEST	132	C
LOCK-UP CONTROL : System Description	86	Work Procedure	132	
IDLE NEUTRAL CONTROL	86	CVT POSITION	133	TM
IDLE NEUTRAL CONTROL : System Description	87	Inspection	133	
ON BOARD DIAGNOSTIC (OBD) SYSTEM	90	Adjustment	133	
Description	90	DTC/CIRCUIT DIAGNOSIS	134	E
Function of OBD	90	U0073 COMMUNICATION BUS A OFF	134	
DIAGNOSIS SYSTEM (TCM)	91	Description	134	F
DIAGNOSIS DESCRIPTION	91	DTC Logic	134	
DIAGNOSIS DESCRIPTION : 1 Trip Detection Diagnosis	91	Diagnosis Procedure	134	
DIAGNOSIS DESCRIPTION : DTC and DTC of 1st Trip	91	U0100 LOST COMMUNICATION (ECM A)	135	G
DIAGNOSIS DESCRIPTION : Malfunction Indicator Lamp (MIL)	91	Description	135	
DIAGNOSIS DESCRIPTION : Counter System	91	DTC Logic	135	H
CONSULT Function	93	Diagnosis Procedure	135	
ECU DIAGNOSIS INFORMATION	100	U0140 LOST COMMUNICATION (BCM)	136	I
TCM	100	Description	136	
Reference Value	100	DTC Logic	136	J
Fail-safe	108	Diagnosis Procedure	136	
Protection Control	110	U0141 LOST COMMUNICATION (BCM A)	137	K
DTC Inspection Priority Chart	111	Description	137	
DTC Index	112	DTC Logic	137	L
WIRING DIAGRAM	114	Diagnosis Procedure	137	
CVT CONTROL SYSTEM	114	U0155 LOST COMMUNICATION (IPC)	138	M
Wiring Diagram	114	Description	138	
CVT SHIFT LOCK SYSTEM	121	DTC Logic	138	N
Wiring Diagram	121	Diagnosis Procedure	138	
BASIC INSPECTION	124	U0300 CAN COMMUNICATION DATA	139	O
DIAGNOSIS AND REPAIR WORK FLOW	124	Description	139	
Flowchart of Trouble Diagnosis	124	DTC Logic	139	P
Question sheet	125	Diagnosis Procedure	139	
ADDITIONAL SERVICE WHEN REPLACING TCM	127	U1000 CAN COMM CIRCUIT	140	
Description	127	Description	140	
Procedure	127	DTC Logic	140	
ADDITIONAL SERVICE WHEN REPLACING TRANSAXLE ASSEMBLY	128	Diagnosis Procedure	140	
Description	128	U1117 LOST COMMUNICATION (ABS)	141	
Procedure	128	Description	141	
		DTC Logic	141	
		Diagnosis Procedure	141	
		P062F EEPROM	142	
		Description	142	
		DTC Logic	142	
		Diagnosis Procedure	142	
		P0705 TRANSMISSION RANGE SENSOR A .	143	

DTC Logic	143
Diagnosis Procedure	143
Component Inspection (Transmission Range Switch)	147
P0706 TRANSMISSION RANGE SENSOR A	149
DTC Logic	149
Diagnosis Procedure	149
Component Inspection (Transmission Range Switch)	151
P0711 TRANSMISSION FLUID TEMPERATURE SENSOR A	152
DTC Logic	152
Diagnosis Procedure	153
Component Inspection (CVT Fluid Temperature Sensor)	154
P0712 TRANSMISSION FLUID TEMPERATURE SENSOR A	155
DTC Logic	155
Diagnosis Procedure	155
Component Inspection (CVT Fluid Temperature Sensor)	155
P0713 TRANSMISSION FLUID TEMPERATURE SENSOR A	157
DTC Logic	157
Diagnosis Procedure	157
Component Inspection (CVT Fluid Temperature Sensor)	158
P0715 INPUT SPEED SENSOR A	159
DTC Logic	159
Diagnosis Procedure	159
P0720 OUTPUT SPEED SENSOR	162
DTC Logic	162
Diagnosis Procedure	162
P0740 TORQUE CONVERTER	165
DTC Logic	165
Diagnosis Procedure	166
Component Inspection (Torque Converter Clutch Solenoid Valve)	166
P0743 TORQUE CONVERTER	167
DTC Logic	167
Diagnosis Procedure	168
Component Inspection (Torque Converter Clutch Solenoid Valve)	168
P0744 TORQUE CONVERTER	169
DTC Logic	169
Diagnosis Procedure	170
Component Inspection (Torque Converter Clutch Solenoid Valve)	170
P0746 PRESSURE CONTROL SOLENOID A	171
DTC Logic	171
Diagnosis Procedure	172

Component Inspection (Line Pressure Solenoid Valve)	172
P0846 TRANSMISSION FLUID PRESSURE SEN/SW B	173
DTC Logic	173
Diagnosis Procedure	173
P0847 TRANSMISSION FLUID PRESSURE SEN/SW B	175
DTC Logic	175
Diagnosis Procedure	175
P0848 TRANSMISSION FLUID PRESSURE SEN/SW B	177
DTC Logic	177
Diagnosis Procedure	177
P0863 TCM COMMUNICATION	179
DTC Logic	179
Diagnosis Procedure	179
P0890 TCM	180
DTC Logic	180
Diagnosis Procedure	180
P0962 PRESSURE CONTROL SOLENOID A	182
DTC Logic	182
Diagnosis Procedure	182
Component Inspection (Line Pressure Solenoid Valve)	182
P0963 PRESSURE CONTROL SOLENOID A	184
DTC Logic	184
Diagnosis Procedure	184
Component Inspection (Line Pressure Solenoid Valve)	184
P0965 PRESSURE CONTROL SOLENOID B	186
DTC Logic	186
Diagnosis Procedure	186
P0966 PRESSURE CONTROL SOLENOID B	187
DTC Logic	187
Diagnosis Procedure	187
Component Inspection (Primary Pressure Solenoid Valve)	187
P0967 PRESSURE CONTROL SOLENOID B	189
DTC Logic	189
Diagnosis Procedure	189
Component Inspection (Primary Pressure Solenoid Valve)	189
P0998 SHIFT SOLENOID F	191
DTC Logic	191
Diagnosis Procedure	191
Component Inspection (Low Brake Solenoid Valve)	191
P0999 SHIFT SOLENOID F	193

DTC Logic	193	SHIFT LOCK SYSTEM	219	
Diagnosis Procedure	193	Component Function Check	219	A
Component Inspection (Low Brake Solenoid Valve)	193	Diagnosis Procedure	219	
P099B SHIFT SOLENOID G	195	SYMPTOM DIAGNOSIS	221	B
DTC Logic	195	CVT CONTROL SYSTEM	221	
Diagnosis Procedure	195	Symptom Table	221	C
Component Inspection (High Clutch & Reverse Brake Solenoid Valve)	195	PERIODIC MAINTENANCE	226	
P099C SHIFT SOLENOID G	197	CVT FLUID	226	TM
DTC Logic	197	Inspection	226	
Diagnosis Procedure	197	Replacement	226	
Component Inspection (High Clutch & Reverse Brake Solenoid Valve)	197	Adjustment	227	E
P1586 G SENSOR	199	REMOVAL AND INSTALLATION	229	
DTC Logic	199	CVT SHIFT SELECTOR	229	F
Diagnosis Procedure	199	Exploded View	229	
P1588 G SENSOR	202	Removal and Installation	229	
DTC Logic	202	Disassembly and Assembly	230	G
Diagnosis Procedure	202	Inspection	230	
P2765 CLUTCH B SPEED SENSOR	204	CONTROL CABLE	232	H
DTC Logic	204	Exploded View	232	
Diagnosis Procedure	204	Removal and Installation	232	
P2857 CLUTCH A PRESSURE	207	Inspection and Adjustment	234	
DTC Logic	207	KEY INTERLOCK CABLE	235	I
Diagnosis Procedure	207	Exploded View	235	
P2858 CLUTCH B PRESSURE	208	Removal and Installation	235	J
DTC Logic	208	Inspection	236	
Diagnosis Procedure	208	TCM	237	K
P2859 CLUTCH A PRESSURE	209	Exploded View	237	
DTC Logic	209	Removal and Installation	237	
Diagnosis Procedure	210	Adjustment	237	
P285A CLUTCH B PRESSURE	211	AIR BREATHER HOSE	238	L
DTC Logic	211	Removal and Installation	238	
Diagnosis Procedure	212	G SENSOR	239	M
MAIN POWER SUPPLY AND GROUND CIRCUIT	213	Exploded View	239	
Diagnosis Procedure	213	Removal and Installation	239	
OVERDRIVE CONTROL SWITCH	215	Adjustment	239	N
Component Function Check	215	OIL PAN	240	
Diagnosis Procedure	215	Exploded View	240	
Component Inspection (Overdrive Control Switch)	216	Removal and Installation	240	
OD OFF INDICATOR LAMP	217	Inspection and Adjustment	241	O
Component Function Check	217	PRIMARY SPEED SENSOR	242	
Diagnosis Procedure	217	Exploded View	242	P
SHIFT POSITION INDICATOR CIRCUIT	218	Removal and Installation	242	
Component Parts Function Inspection	218	Inspection and Adjustment	242	
Diagnosis Procedure	218	SECONDARY SPEED SENSOR	243	
		Exploded View	243	
		Removal and Installation	243	
		Inspection and Adjustment	243	

OUTPUT SPEED SENSOR	244	Removal and Installation	251
Exploded View	244	Inspection and Adjustment	251
Removal and Installation	244		
Inspection and Adjustment	244		
DIFFERENTIAL SIDE OIL SEAL	245	UNIT REMOVAL AND INSTALLATION ...	252
Exploded View	245	TRANSMISSION ASSEMBLY	252
Removal and Installation	245	Exploded View	252
Inspection and Adjustment	245	Removal and Installation	252
		Inspection and Adjustment	254
WATER HOSE	247	SERVICE DATA AND SPECIFICATIONS	
Exploded View	247	(SDS)	256
Removal and Installation	247		
Inspection	249	SERVICE DATA AND SPECIFICATIONS	
FLUID COOLER HOSE	250	(SDS)	256
Exploded View	250	General Specification	256
Removal and Installation	250	Shift Characteristics	256
Inspection and Adjustment	250	Stall Speed	256
PLUG	251	Line Pressure	257
Description	251	Torque Converter	257
Exploded View	251	Heater Thermostat	257

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000009486763

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

General Precautions

INFOID:000000009417448

CAUTION:

- Do not reuse CSC (Concentric Slave Cylinder). CSC slides back to the original position every time when removing transaxle assembly. At this time, dust on the sliding parts may damage the seal of CSC and may cause clutch fluid leakage. Refer to [CL-16, "Removal and Installation"](#).
- Do not reuse transaxle gear oil, once it has been drained.
- Check oil level or replace gear oil with vehicle on level surface.
- During removal or installation, keep inside of transaxle clear of dust or dirt.
- Check for the correct installation alignment prior to removal or disassembly. If matching marks are required, be certain they do not interfere with the function of the parts marked.
- In principle, tighten bolts or nuts gradually in several steps working diagonally from inside to outside. If tightening sequence is specified, use it.
- Do not damage sliding surfaces and mating surfaces.

Precaution for Work

INFOID:000000009417449

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
 - Water soluble dirt:
 - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
 - Then rub with a soft, dry cloth.

PRECAUTIONS

[5MT: RS5F91R]

< PRECAUTION >

- Oily dirt:
- Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
- Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
- Then rub with a soft, dry cloth.
- Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
- For genuine leather seats, use a genuine leather seat cleaner.

Liquid Gasket

INFOID:000000009486775

REMOVAL OF LIQUID GASKET SEALING

- After removing the bolts and nuts, separate the mating surface and remove the liquid gasket using Tool (A).

Tool Number : KV10111100 (J-37228)


CAUTION:

Be careful not to damage the mating surfaces.

- In areas where the cutter is difficult to use, use a plastic hammer to lightly tap (1) the cutter where the liquid gasket is applied. Use a plastic hammer to slide (2) the cutter by tapping on the side.


CAUTION:

Do not damage the mating surfaces.




LIQUID GASKET APPLICATION PROCEDURE

1. Using suitable tool (A), remove old liquid gasket adhering to the liquid gasket application surface and the mating surface.
 - Remove liquid gasket completely from the groove of the liquid gasket application surface, mounting bolts, and bolt holes.
2. Wipe the liquid gasket application surface and the mating surface with white gasoline (lighting and heating use) to remove adhering moisture, grease and foreign materials.



3. Attach liquid gasket tube to the suitable tool.
 - Use Genuine Silicone RTV Sealant, or equivalent. Refer to [GI-22, "Recommended Chemical Products and Sealants"](#).**
4. Apply liquid gasket without gaps to the specified location according to the specified dimensions.
 - If there is a groove for liquid gasket application, apply liquid gasket to the groove.




- As for bolt holes (B), normally apply liquid gasket inside the holes. Occasionally, it should be applied outside the holes. Check to read the text of this manual.

(A) : Groove

⇐ : Inside

- Within five minutes of liquid gasket application, install the mating component.
- If liquid gasket protrudes, wipe it off immediately.
- Do not retighten mounting bolts or nuts after the installation.



PRECAUTIONS

< PRECAUTION >

[5MT: RS5F91R]

- After 30 minutes or more have passed from the installation, fill engine oil and engine coolant.

CAUTION:

If there are specific instructions in the procedures contained in this manual concerning liquid gas-ket application, observe them.

A

B

C

TM

E

F

G

H

I

J

K

L

M

N

O

P

PREPARATION

< PREPARATION >

[5MT: RS5F91R]






PREPARATION

PREPARATION

Special Service Tools

INFOID:000000009417450







The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
KV32500QAA (—) Drift set	Installing differential side oil seal 1. — Drift a: 54.3 mm (2.138 in) dia. b: 45 mm (1.77 in) dia. c: 26.6 mm (1.047 in) dia. 2. — Drift d: 54 mm (2.13 in) dia. e: 48.6 mm (1.913 in) dia. f: 26.6 mm (1.047 in) dia
 JPDIC0730ZZ	
KV32300QAC (—) Puller	Removing 5th main gear
 SCIA1781J	
KV32300QAD (—) Puller	Removing 5th main gear
 SCIA1782J	
ST35300000 (—) Drift	- Removing and installing input shaft rear bearing - Removing and installing mainshaft rear bearing a: 45 mm (1.77 in) dia. b: 59 mm (2.32 in) dia.
 ZZA0969D	
KV111011S0 (—) Valve seat remover	Removing mainshaft front bearing
 ZZA0872D	

PREPARATION

< PREPARATION >

[5MT: RS5F91R]

Tool number (Kent-Moore No.) Tool name	Description	
ST33400001 (—) Drift	Installing mainshaft front bearing a: 60 mm (2.36 in) dia. b: 47 mm (1.85 in) dia.	A
 ZZA0814D		B
KV40100900 (—) Drift	Installing input shaft front bearing a: 52 mm (2.05 in) dia. b: 39.5 mm (1.555 in) dia.	C
 NT084		TM
KV32300QAE (—) Drift	Installing differential side bearing outer race a: 61.5 mm (2.421 in) dia.	E
 JPDIC0635ZZ		F
ST33052000 (—) Drift	Removing differential side bearing a: 22 mm (0.87 in) dia. b: 28mm (1.10 in) dia.	G
 ZZA0969D		H
KV40104920 (—) Drift	Installing differential side bearing a: 21.7 mm (0.854 in) dia. b: 44.7 mm (1.760 in) dia.	I
 ZZA0969D		J
— (J-46534) Trim tool set	Removing trim components	K
 AWJIA0483ZZ		L
		M
		N
		O
		P





PREPARATION

< PREPARATION >

[5MT: RS5F91R]

Commercial Service Tools

INFOID:000000009417451


Tool name		Description
Socket	 PCIB1776E	Removing and installing drain plug a: 8 mm (0.31 in) b: 5 mm (0.20 in)
Drift	 S-NT063	Removing input shaft front bearing a: 38 mm (1.50 in) dia.
Drift	 S-NT063	Installing bushing a: 14.5 mm (0.571 in) dia.
Puller	 NT077	• Removing 5th-reverse synchronizer hub • Removing differential side bearing
Bearing remover	 S-NT134	Removing bushing
Power tool	 PIIB1407E	Loosening nuts, screws and bolts

SYSTEM DESCRIPTION

STRUCTURE AND OPERATION

Sectional View

INFOID:000000009417452



- | | | |
|-------------------|--|--------------------------------------|
| 1. Clutch housing | 2. 1st-2nd synchronizer hub assembly | 3. 3rd-4th synchronizer hub assembly |
| 4. 5th input gear | 5. 5th-reverse synchronizer hub assembly | 6. 5th-reverse baulk ring |
| 7. 5th main gear | 8. 4th main gear | 9. 3rd main gear |
| 10. 2nd main gear | 11. 2nd double-cone synchronizer | 12. 1st double-cone synchronizer |
| 13. 1st main gear | 14. Differential side bearing | 15. Differential |
| 16. Final gear | 17. Mainshaft | 18. Input shaft |

System Description

INFOID:000000009417453

DOUBLE-CONE SYNCHRONIZER


STRUCTURE AND OPERATION

< SYSTEM DESCRIPTION >

[5MT: RS5F91R]

Double-cone synchronizers are adopted for 1st and 2nd gears to reduce operating force of the shift selector.

- (1) : Outer baulk ring
- (2) : 2nd main gear
- (3) : Synchronizer cone
- (4) : Inner baulk ring
- (5) : 1st main gear
- (6) : 1st-2nd coupling sleeve




REVERSE GEAR NOISE PREVENTION FUNCTION (REVERSE BRAKE)

Description

Soon after the clutch is disengaged, the input shaft is still rotating due to inertia. This may cause a gear noise when the shift selector is moved to reverse position. The reverse gear noise prevention function stops the rotation of the input shaft and enables smooth gear shifting when the reverse gear is selected.

Operation Principle

1. When the shift selector is moved to reverse position, 5th-reverse coupling sleeve (1) slides in the reverse direction. (⇐)
- (5) : 5th input gear
2. Synchronizer levers (2) with support point (A) at 5th-reverse synchronizer hub (3) presses 5th-reverse baulk ring (4). (⇐)
3. Friction that is generated at 5-reverse baulk ring presses synchronizer lever on 5th-reverse coupling sleeve. (⇐)
4. 5th-reverse coupling sleeve that is pressed by synchronizer lever stops the rotation of input shaft.



POSITION SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[5MT: RS5F91R]

DTC/CIRCUIT DIAGNOSIS

POSITION SWITCH

BACK-UP LAMP SWITCH

BACK-UP LAMP SWITCH : Component Inspection

INFOID:000000009417454

1.CHECK BACK-UP LAMP SWITCH


1. Disconnect position switch connector. Refer to [TM-19, "Removal and Installation"](#).
2. Check continuity between position switch terminals.

Terminals		Condition	Continuity
1	2	Reverse gear position	Yes
		Except reverse gear position	No

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace position switch. Refer to [TM-19, "Removal and Installation"](#).



PARK/NEUTRAL POSITION (PNP) SWITCH

PARK/NEUTRAL POSITION (PNP) SWITCH : Component Inspection

INFOID:000000009417455

1.CHECK PARK/NEUTRAL POSITION (PNP) SWITCH


1. Disconnect position switch connector. Refer to [TM-19, "Removal and Installation"](#).
2. Check continuity between position switch terminals.

Terminals		Condition	Continuity
2	3	Neutral gear position	Yes
		Except neutral gear position	No

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace position switch. Refer to [TM-19, "Removal and Installation"](#).



NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

< SYMPTOM DIAGNOSIS >

[5MT: RS5F91R]

SYMPTOM DIAGNOSIS

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

NVH Troubleshooting Chart

INFOID:000000009417456

Use the chart below to find the cause of the symptom. The numbers indicate the order of the inspection. If necessary, repair or replace these parts.

Reference page		TM-17			TM-26			TM-21	TM-26				
SUSPECTED PARTS (Possible cause)		OIL (Oil level is low)	OIL (Wrong oil)	OIL (Oil level is high)	GASKET (Damaged)	OIL SEAL (Worn or damaged)	O-RING (Worn or damaged)	SHIFT CONTROL LINKAGE (Worn)	SHIFT FORK (Worn)	GEAR (Worn or damaged)	BEARING (Worn or damaged)	BAULK RING (Worn or damaged)	INSERT SPRING (Damaged)
Symptoms	Noise	1	2							3	3		
	Oil leakage		3	1	2	2	2						
	Hard to shift or will not shift		1	1				2				3	3
	Jumps out of gear							1	2	2			

PERIODIC MAINTENANCE

GEAR OIL

Inspection


INFOID:000000009417457

GEAR OIL LEAKS

Make sure that gear oil is not leaking from transaxle or around it.

GEAR OIL LEVEL


1. Remove filler plug (1) and gasket from transaxle case.
2. Check the gear oil level from filler plug hole as shown.
CAUTION:
Do not start engine while checking gear oil level.
3. Install a new gasket on filler plug and then install filler plug to transaxle case.
CAUTION:
Do not reuse gasket.
4. Tighten filler plug to the specified torque. Refer to [TM-26, "Exploded View"](#).



Draining

INFOID:000000009417458

1. Start engine and let it run to warm up transaxle.
2. Stop engine. Remove drain plug (1) and gasket, using suitable tool and then drain gear oil.
3. Install a new gasket on drain plug (1) and install drain plug to clutch housing, using suitable tool.
CAUTION:
Do not reuse gasket.
4. Tighten drain plug (1) to the specified torque. Refer to [TM-26, "Exploded View"](#).




Refilling

INFOID:000000009417459

1. Remove filler plug (1) and gasket from transaxle case.
2. Fill with new gear oil until gear oil level reaches the specified limit at filler plug hole as shown.
CAUTION:
Do not start engine while checking gear oil level.

Oil capacity and viscosity : Refer to [MA-11, "Fluids and Lubricants"](#).

3. Install a new gasket on filler plug and then install filler plug to transaxle case.
CAUTION:
Do not reuse gasket.
4. Tighten filler plug to the specified torque. Refer to [TM-26, "Exploded View"](#).



REMOVAL AND INSTALLATION

SIDE OIL SEAL

Removal and Installation


INFOID:000000009417460

REMOVAL

1. Remove front drive shaft from transaxle assembly. Refer to [FAX-19, "Removal and Installation"](#).
2. Remove differential side oil seal (1) using suitable tool.

CAUTION:

Do not damage transaxle case and clutch housing.



INSTALLATION

1. Install differential side oil seal (1) to transaxle case side (B) and clutch housing side (C) using Tool.

Dimension (L1) : 5.7 – 6.3 mm (0.224 – 0.248 in)


Dimension (L2) : 2.4 – 3.0 mm (0.094 – 0.118 in)

Tool number : KV32500QAA (—)

CAUTION:

- Do not reuse differential side oil seal.
- Do not tilt differential side oil seal.
- Do not damage clutch housing and transaxle case.

2. Install the front drive shaft. Refer to [FAX-19, "Removal and Installation"](#).



Inspection

INFOID:000000009417461

INSPECTION AFTER INSTALLATION

Check the gear oil level and for gear oil leaks. Refer to [TM-17, "Inspection"](#).

POSITION SWITCH

< REMOVAL AND INSTALLATION >

[5MT: RS5F91R]


POSITION SWITCH

Removal and Installation

INFOID:000000009417462

REMOVAL

1. Drain gear oil. Refer to [TM-17, "Draining"](#).
2. Disconnect the harness connector (A) from position switch.
3. Remove position switch from transaxle case.



INSTALLATION

1. Apply recommended sealant to threads of position switch.
CAUTION:
 - Use Genuine Silicone RTV or equivalent. Refer to [GI-22, "Recommended Chemical Products and Sealants"](#).
 - Remove old sealant and gear oil adhering to threads.
2. Install position switch to transaxle case.
3. Tighten position switch to the specified torque. Refer to [TM-26, "Exploded View"](#).
4. Refill gear oil. Refer to [TM-17, "Refilling"](#).

Inspection

INFOID:000000009417463

INSPECTION AFTER INSTALLATION

- Check continuity between position switch terminals. Refer to [TM-15, "BACK-UP LAMP SWITCH : Component Inspection"](#) (Back-up lamp switch) and [TM-15, "PARK/NEUTRAL POSITION \(PNP\) SWITCH : Component Inspection"](#) (PNP switch).
- Check the gear oil level and for gear oil leaks. Refer to [TM-17, "Inspection"](#).

CONTROL LINKAGE


< REMOVAL AND INSTALLATION >

[5MT: RS5F91R]

CONTROL LINKAGE

Exploded View

INFOID:000000009417464




- | | | |
|--------------------|---------------------------|----------------------------|
| 1. Shifter lever A | 2. Selector lever | 3. Selector cable |
| 4. Shifter cable | 5. Cable mounting bracket | 6. Tapping bolt |
| 7. Bracket | 8. Grommet | 9. Shift selector assembly |
| 10. Shift selector | 11. Shift selector handle | |

Removal and Installation

INFOID:000000009417465

REMOVAL

1. Move the shift selector to the neutral position.
2. Remove the battery tray. Refer to [PG-68, "Removal and Installation \(Battery Tray\)"](#).
3. Pull out and disconnect cables from shifter lever A and selector lever, using a suitable tool.
4. While pressing the lock of the selector cable in the direction of the arrows shown, remove the selector cable from the cable mounting bracket.
5. While pressing the lock of the shifter cable in the direction of the arrows shown, remove the shifter cable from the cable mounting bracket.
6. Remove cable mounting bracket from clutch housing.
7. Pull the shift selector handle upward to remove.
8. Remove center console assembly. Refer to [IP-18, "Removal and Installation"](#).
9. Pull out and disconnect each cable from the shift selector assembly, using a suitable tool.




CONTROL LINKAGE

< REMOVAL AND INSTALLATION >

[5MT: RS5F91R]

- a. While pressing the lock of the selector cable in the direction of the arrows shown, remove the selector cable from the shift selector assembly.
- b. While pressing the lock of the shifter cable in the direction of the arrows shown, remove the shifter cable from the shift selector assembly.
10. Remove the shift selector assembly.
11. Remove center muffler, exhaust front tube, and heat plate. Refer to [EX-5, "Exploded View"](#).
12. Remove the bracket from the vehicle.
13. Remove the grommet and then remove the shifter cable and selector cable from the vehicle.



INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- **Install each cable without causing interference with other parts. Do not allow cable to bend less than 120 mm (4.72 in), or exceed 180 degree twist.**
- **Install boot of each cable without causing interference with other parts. Do not exceed 90 degree twist.**
- **Fit boot to center console assembly and the groove on shift selector handle.**
- To install the shift selector handle, press it onto the shift selector.

CAUTION:

- **Do not reuse shift selector handle.**
- **Be careful with orientation of shift selector handle.**
- Bolt hole is not threaded on new clutch housing. Self-tapping bolt is used to attach lock plate to clutch housing.

CAUTION:

Do not reuse self-tapping bolt.

- Insert each cable until it reaches the cable mounting bracket and shift selector assembly.
- Insert each cable until it reaches the shifter lever A and the selector lever.
- Move the shift selector to the neutral position.

Inspection

INFOID:0000000009417466

INSPECTION AFTER INSTALLATION

Shift Selector Handle

Check that the shift selector handle is installed in the right position.

Shifter Cable and Selector Cable

- Pull each cable in the removal direction to check that it does not disconnect from the cable mounting bracket.
- Pull each cable in the removal direction to check that it does not disconnect from the shift selector assembly.
- Pull grommet in the removal direction to check that it does not disconnect from the vehicle.

Shift Selector Assembly and Shift Selector

- Check that there is no unusual noise, binding, bending, looseness, and interference when the shift selector is moved to each position. If there is a malfunction, then repair or replace the malfunctioning part.
- Check that the shift selector smoothly returns to the neutral position after moving the shift selector from 1st to 2nd gear and releasing it. If there is a malfunction, then repair or replace the malfunctioning part.
- Check that the shift selector smoothly returns to the neutral position after moving the shift selector from 5th to the reverse gear position and releasing it. If there is a malfunction, then repair or replace the malfunctioning part.

AIR BREATHER HOSE


< REMOVAL AND INSTALLATION >

[5MT: RS5F91R]

AIR BREATHER HOSE

Exploded View

INFOID:000000009417467



1. Cap

2. Air breather hose

3. 2-way connector

Removal and Installation

INFOID:000000009417468

REMOVAL

1. Remove air cleaner case. Refer to [EM-26, "Removal and Installation"](#).
2. Remove air breather hose from the 2-way connector.

CAUTION:

When removing air breather hose, be sure to hold 2-way connector securely.

3. Remove cap from air breather hose.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- Install air breather hose. Do not bend hose tightly, which may result in pinching or clogging.
- Insert the air breather hose to the base of the 2-way connector.

5TH MAIN GEAR ASSEMBLY

< REMOVAL AND INSTALLATION >

[5MT: RS5F91R]


5TH MAIN GEAR ASSEMBLY

Removal and Installation


INFOID:000000009417469

REMOVAL

1. Move the shift selector to the 3rd gear position.
2. Disconnect the shifter cable and the selector cable from shifter lever A and selector lever. Refer to [TM-20, "Removal and Installation"](#).
CAUTION:
Do not move shifter lever A and selector lever to disconnect each cable.
3. Drain gear oil. Refer to [TM-17, "Draining"](#).
4. Remove fender protector (LH). Refer to [EXT-36, "Removal and Installation"](#).
5. Remove the harness clamp (A) from rear housing (1).



6. Remove rear housing and O-ring.
CAUTION:
Remove in direction of input shaft (←) as shown. Rear housing gear oil channel is inserted to input shaft center hole.
7. Remove 5th main gear assembly. Refer to step 5 through 8 of "Disassembly of TRANSAXLE ASSEMBLY". Refer to [TM-30, "Disassembly"](#).



INSTALLATION

Installation is in the reverse order of removal.

- Shift into 3rd with shifter lever to install the 5th main gear assembly, referring to Step 36 to 39 of "Assembly of TRANSAXLE ASSEMBLY" Refer to [TM-36, "Assembly"](#).
- Install O-ring and the rear housing to the transaxle case and tighten the bolts to the specified torque. Refer to [TM-26, "Exploded View"](#).

CAUTION:

- Do not reuse O-ring.
- Do not pinch O-ring when installing rear housing.
- Refill gear oil. Refer to [TM-17, "Refilling"](#).

Inspection

INFOID:000000009417470

INSPECTION AFTER INSTALLATION


- Check the operation of the control linkage. Refer to [TM-21, "Inspection"](#).
- Check the gear oil level and for oil leaks. Refer to [TM-17, "Inspection"](#).

UNIT REMOVAL AND INSTALLATION

TRANSAXLE ASSEMBLY

Exploded View

INFOID:000000009417471



1. Transaxle assembly

△: Refer to "INSTALLATION" in [TM-24, "Removal and Installation"](#) for the locations and tightening torque.

Removal and Installation

INFOID:000000009417472

WARNING:

Do not remove the radiator cap when the engine is hot. Serious burns could occur from high pressure coolant escaping from the radiator. Wrap a thick cloth around the cap. Slowly turn it a quarter turn to allow built-up pressure to escape. Carefully remove the cap by turning it all the way.

CAUTION:

Do not reuse CSC (Concentric Slave Cylinder). The CSC slides back to the original position every time the transaxle assembly is removed. This action may allow dust or contaminants to gather on the sliding parts and damage a seal of CSC causing clutch fluid leakage.

NOTE:

When removing components such as hoses, tubes/lines, etc., cap or plug openings to prevent fluid from spilling.

REMOVAL

1. Remove the engine and transaxle assembly. Refer to [EM-86, "Removal and Installation"](#).
2. Disconnect the reverse lamp switch harness connector.
3. Remove the bolts that fasten the transaxle assembly and engine assembly.
4. Remove transaxle assembly from the engine assembly.
5. Remove engine mounting bracket (LH). Refer to [EM-85, "Exploded View"](#).
6. Remove CSC (Concentric Slave Cylinder). Refer to [CL-16, "Removal and Installation"](#).

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- Secure transaxle assembly to a suitable jack.
- The transaxle assembly must not interfere with the wire harnesses and clutch tube.
- When installing transaxle assembly, do not bring input shaft into contact with clutch cover.
- Bolt hole is not threaded on new clutch housing. Self-tapping bolt is used to attach lock plate to clutch housing.


TRANSAXLE ASSEMBLY

< UNIT REMOVAL AND INSTALLATION >

[5MT: RS5F91R]

- **Do not reuse self-tapping bolt.**
- Tighten transaxle assembly bolts to the specified torque. The illustration is the view from the engine.

Bolt symbol	A	B	C	D
Insertion direction	Transaxle to engine	Engine to transaxle		
Quantity	2	3	2	1
Bolt length (ℓ) mm (in)	55 (2.17)		49 (1.93)	69 (2.72)
Tightening torque N·m (kg-m, ft-lb)	48.0 (4.9, 35)			



Inspection

INFOID:000000009417473

INSPECTION AFTER INSTALLATION

- Check the operation of the control linkage. Refer to [TM-21, "Inspection"](#).
- Before starting engine, check oil/fluid levels including engine coolant and engine oil. If less than required quantity, fill to the specified level. Refer to [MA-11, "Fluids and Lubricants"](#).
- Use procedure below to check for fuel leaks.
- Turn ignition switch ON (with engine stopped). With fuel pressure applied to fuel piping, check for fuel leaks at connection points.
- Start engine. With engine speed increased, check again for fuel leaks at connection points.
- Run engine to check for unusual noise and vibration.

NOTE:

If hydraulic pressure inside timing chain tensioner drops after removal and installation, slack in the guide may generate a pounding noise during and just after engine start. However, this is normal. Noise will stop after hydraulic pressure rises.

- Warm up engine thoroughly to make sure there is no leaks of fuel, exhaust gas, or any oils/fluids including engine oil and engine coolant.
- Bleed air from passages in lines and hoses, such as in cooling system.
- After cooling down engine, again check oil/fluid levels including engine oil and engine coolant. Refill to specified level, if necessary.
- Summary of the inspection items:

Item		Before starting engine	Engine running	After engine stopped
Engine coolant		Level	Leaks	Level
Engine oil		Level	Leaks	Level
Transmission/ transaxle fluid	CVT Models	Leaks	Level/Leaks	Leaks
	M/T Models	Level/Leaks	Leaks	Level/Leaks
Other oils and fluids*		Level	Leaks	Level
Fuel		Leaks	Leaks	Leaks
Exhaust gas		—	Leaks	—

*Power steering fluid, brake fluid, etc.

TRANSAXLE ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[5MT: RS5F91R]


UNIT DISASSEMBLY AND ASSEMBLY

TRANSAXLE ASSEMBLY

Exploded View

INFOID:000000009417474

CASE AND HOUSING



- | | | |
|-------------------------------|-----------------------------|--------------------|
| 1. Differential side oil seal | 2. Clutch housing | 3. Dowel pin |
| 4. Magnet | 5. Drain plug | 6. Gasket |
| 7. Oil channel | 8. Plug | 9. 2-way connector |
| 10. Oil gutter | 11. Air breather inner tube | 12. Filler plug |
| 13. Transaxle case | 14. O-ring | 15. Rear housing |
| 16. Position switch | | |


Apply Genuine Silicone RTV or equivalent. Refer to [GI-22. "Recommended Chemical Products and Sealants"](#).

INPUT SHAFT AND GEAR

TRANSAXLE ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[5MT: RS5F91R]



- | | | |
|----------------------------------|---------------------------------|-----------------------|
| 1. Input shaft front bearing | 2. Input shaft | 3. Snap ring |
| 4. Input shaft rear bearing | 5. Adapter plate | 6. Bushing |
| 7. 5th input gear | 8. 5th-reverse baulk ring | 9. Synchronizer lever |
| 10. 5th-reverse synchronizer hub | 11. 5th-reverse coupling sleeve | 12. Lock washer |
| 13. Retaining pin | 14. Reverse gear | |

: Apply gear oil.

: Replace the parts as a set.


MAINSHAFT AND GEAR

TRANSAXLE ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[5MT: RS5F91R]

SEC. 322



- | | | |
|------------------------------|-----------------------------|----------------------------|
| 1. Mainshaft front bearing | 2. Mainshaft | 3. 1st main gear |
| 4. 1st inner baulk ring | 5. 1st synchronizer cone | 6. 1st outer baulk ring |
| 7. 1st-2nd synchronizer hub | 8. 1st-2nd coupling sleeve | 9. Spring |
| 10. Insert key | 11. 2nd outer baulk ring | 12. 2nd synchronizer cone |
| 13. 2nd inner baulk ring | 14. Snap ring | 15. Thrust washer |
| 16. 2nd main gear | 17. 3rd main gear | 18. 3rd baulk ring |
| 19. 3rd-4th synchronizer hub | 20. 3rd-4th coupling sleeve | 21. 4th baulk ring |
| 22. 4th main gear | 23. Spacer | 24. Mainshaft rear bearing |
| 25. 5th main gear | | |

: Apply gear oil.


: Replace the parts as a set.

SHIFT FORK AND FORK ROD

TRANSAXLE ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[5MT: RS5F91R]



- | | | |
|---------------------------|-----------------------|-------------------------|
| 1. Retaining pin | 2. 1st-2nd shift fork | 3. Bushing |
| 4. 1st-2nd fork rod | 5. Lock pin | 6. 5th-reverse fork rod |
| 7. 5th-reverse shift fork | 8. Check ball | 9. 3rd-4th shift fork |
| 10. 3rd-4th fork rod | 11. Control shaft | 12. O-ring |
| 13. Selector | 14. Check ball plug | 15. Bushing |
| 16. Spring | 17. Gear catch | |

Apply gear oil.

Apply Genuine Silicone RTV or equivalent. Refer to [GI-22, "Recommended Chemical Products and Sealants"](#).


Replace the parts as a set.

FINAL DRIVE

TRANSAXLE ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[5MT: RS5F91R]



1. Differential side bearing outer race 2. Differential side bearing 3. Final drive

■: Replace the parts as a set.


Disassembly

INFOID:000000009417475

1. Remove drain plug and gasket from clutch housing using suitable tool, and drain gear oil.
2. Remove filler plug and gasket from transaxle case.
3. Remove rear housing and O-ring.

CAUTION:


Remove in direction of input shaft (←) as shown. Rear housing oil channel is inserted to input shaft center hole.



4. Move the shifter lever A (1) to the 3rd gear position.

NOTE:

- If it is not moved to the 3rd gear position, transaxle case cannot be removed from clutch housing.
- The 3rd gear position means that shifter lever A is fully rotated clockwise and it is returned approximately 10 degrees.



TRANSAXLE ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[5MT: RS5F91R]

5. Remove 5th-reverse shift fork (1) and 5th-reverse coupling sleeve.
- a. Remove retaining pin from 5th-reverse shift fork, using a suitable tool (A).
- b. Press 5th-reverse shift fork, shift to 5th, and then engage it with 3rd gear.
- c. Remove bolt (B).
- d. Remove nut (C) and lock washer.

CAUTION:



- Do not reuse nut.
- Do not use an impact wrench for removal. Gears may be damaged.

- e. Remove 5th-reverse shift fork and 5th-reverse coupling sleeve from 5th-reverse synchronizer hub.
6. Remove 5th-reverse synchronizer hub from input shaft, using a suitable tool.

CAUTION:

Set claw of suitable tool to the wider side of the hub when setting the suitable tool in 5th-reverse synchronizer hub.


7. Remove synchronizer levers, 5th-reverse baulk ring, 5th input gear, bushing, and adapter plate from input shaft.




8. Remove 5th main gear from mainshaft, using Tools.

Tool number (A): KV32300QAC (—)

(B): KV32300QAD (—)



9. Remove position switch from transaxle case.




TRANSAXLE ASSEMBLY


< UNIT DISASSEMBLY AND ASSEMBLY >

[5MT: RS5F91R]


10. Remove transaxle case bolts (◀).
11. Remove transaxle case from clutch housing.





12. Remove spacer (1) and 4th main gear (2) from mainshaft.



13. Remove 5th-reverse fork rod (1).
 - a. Pull 5th-reverse fork rod up until it contacts claw (◻) of reverse gear (2).
 - b. Press gear portion of reverse gear down, and then remove 5th-reverse fork rod from clutch housing.



14. Remove 3rd-4th fork rod assembly (1), 3rd-4th coupling sleeve (2), and input shaft assembly (3).
 - a. Remove 4th baulk ring, insert keys, and springs from mainshaft.
 - b. Pull gear of reverse gear (4) up.
 - c. Pull 1st-2nd fork rod (5) up, and then maintain the neutral position.
 - d. Remove 3rd-4th fork rod assembly, 3rd-4th coupling sleeve, and input shaft assembly from clutch housing at the same time.
15. Remove retaining pin from 3rd-4th shift fork, using a pin punch.
16. Remove 3rd-4th shift fork from 3rd-4th shift fork rod.
17. Remove lock pins (◀) from clutch housing.




TRANSAXLE ASSEMBLY


< UNIT DISASSEMBLY AND ASSEMBLY >

[5MT: RS5F91R]


18. Remove 1st-2nd fork rod assembly (1) and mainshaft assembly (2) from clutch housing at the same time.
19. Remove retaining pin from 1st-2nd shift fork, using suitable tool.
20. Remove 1st-2nd shift fork from 1st-2nd shift fork rod.



21. Remove retaining pin from reverse gear, using suitable tool.
22. Remove reverse gear from clutch housing.




23. Remove final drive (1) from clutch housing.
24. Remove magnet and dowel pins (2) from clutch housing.



25. Remove plug (1) from clutch housing (2).

- (C): Plug
- (D): 15 mm (0.59 in)
- (E): 45 mm (1.77 in)
- (F): 95 mm (3.74 in) or more
- (G): 4 mm (0.16 in)

- a. Install suitable tool (A) and (B) to the holes of clutch housing as shown.
- b. While pressing the suitable tool (A) and (B) in the direction of the arrows shown, remove plug from clutch housing.




TRANSAXLE ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[5MT: RS5F91R]

26. Remove input shaft front bearing from clutch housing, using suitable tool.



27. Cut oil channel tube at the base.

CAUTION:


Do not reuse oil channel.

NOTE:


Oil channel will be removed with the mainshaft front bearing.

28. Remove mainshaft front bearing and oil channel from clutch housing, using Tool (A).

Tool number : KV111011S0 (—)




29. Remove bushings (1) from clutch housing, using suitable tool.



30. Remove differential side oil seals (1) from clutch housing and transaxle case, using suitable tool.

CAUTION:

Do not damage transaxle case and clutch housing.



TRANSAXLE ASSEMBLY


< UNIT DISASSEMBLY AND ASSEMBLY >

[5MT: RS5F91R]


31. Remove differential side bearing outer races (1) from clutch housing and transaxle case, using suitable tool.

CAUTION:


Do not damage transaxle case and clutch housing.




32. Pull 2-way connector (1) straight out to remove it from air breather inner tube (2).
33. Remove air breather inner tube from transaxle case.




34. Remove bushings (1) from transaxle case, using suitable tool.
35. Remove retaining pin (◀) from selector, using suitable tool.
36. Remove selector from control shaft.
37. Remove oil gutter from transaxle case.



38. Remove bolt (◀), and then remove bushing, spring, and gear catch from transaxle case.
39. Remove check ball plug from transaxle case.



40. Remove bolts (◀), and then remove control shaft (1) from transaxle case.
41. Remove O-ring from control shaft.



TRANSAXLE ASSEMBLY


< UNIT DISASSEMBLY AND ASSEMBLY >

[5MT: RS5F91R]

42. Expand snap rings (1) and remove input shaft rear bearing and mainshaft rear bearing from transaxle case, using Tool (A).

Tool number : ST35300000 (—)

43. Remove snap rings from transaxle case.
44. Remove check balls (2) from transaxle case.




Assembly

INFOID:000000009417476

1. Install snap rings (1) along transaxle case groove so that notch mates with housing as shown.

CAUTION:

- Do not reuse snap rings.
- Check snap ring installation direction.
- Be sure to align notch with housing.




2. Expand snap rings (1) and install input shaft rear bearing and mainshaft rear bearing to transaxle case, using Tool (A).

CAUTION:

Check that snap ring is correctly installed within bearing groove.

Tool number : ST35300000 (—)

3. Install check balls (2) to transaxle case.



4. Install bushings (1) until they reach transaxle case, using suitable tool (A).


CAUTION:

Do not reuse bushings.

5. Apply gear oil to O-ring, and then install it to control shaft.

CAUTION:

Do not reuse O-ring.



TRANSAXLE ASSEMBLY


< UNIT DISASSEMBLY AND ASSEMBLY >

[5MT: RS5F91R]

6. Install control shaft (1) to transaxle case, and tighten bolts (↩) to the specified torque.

CAUTION:


Replace control shaft and selector as a set.



7. Install selector to control shaft, and then install retaining pin (↩) to selector, using suitable tool.

CAUTION:

- Be careful with the orientation of selector.
- Replace control shaft and selector as a set.
- Do not reuse retaining pin.




8. Install gear catch, spring, and bushing to transaxle case, and then tighten bolt (↩) to the specified torque.

CAUTION:

Replace gear catch, spring, and bushing as a set.

9. Install oil gutter to transaxle case.



10. Install air breather inner tube (2) to transaxle case.

CAUTION:

Do not damage air breather inner tube.


NOTE:

It is easier to install when air breather inner tube end is wrapped and narrowed by tape. Remove tape after installation.

11. Insert 2-way connector (1) straight, and then install it to air breather inner tube.

CAUTION:

Check air breather inner tube for twists after installing.



12. Install differential side oil seals (1) to clutch housing and transaxle case, using Tool.


(B) : Transaxle case side

(C) : Clutch housing side

Dimension (L1) : 5.7 – 6.3 mm (0.224 – 0.248 in)

Dimension (L2) : 2.4 – 3.0 mm (0.094 – 0.118 in)

Tool number : KV32500QAA (—)



TRANSAXLE ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[5MT: RS5F91R]

CAUTION:


- Do not reuse differential side oil seal.
- Do not tilt differential side oil seal.
- Do not damage clutch housing and transaxle case.

13. Install differential side bearing outer races until they reach clutch housing and transaxle case, using Tool (A).

CAUTION:

Replace differential side bearing outer race and differential side bearing as a set.

Tool number : KV32300QAE (—)



14. Install bushings (1) until they reach clutch housing, using suitable tool (A).


CAUTION:

Do not reuse bushings.

15. Install oil channel to clutch housing.


CAUTION:

Do not reuse oil channel.



16. Install mainshaft front bearing so that it becomes even with clutch housing surface, using Tool (A).


Tool number : ST33400001 (—)



17. Install input shaft front bearing so that it becomes even with clutch housing surface, using Tool (A).

Tool number : KV40100900 (—)

18. Install pinion gear, pinion shaft, and plug to clutch housing.



TRANSAXLE ASSEMBLY


< UNIT DISASSEMBLY AND ASSEMBLY >

[5MT: RS5F91R]

19. Install final drive (1) to clutch housing.
20. Install dowel pins (2) and magnet to clutch housing.

CAUTION:

Do not reuse dowel pins.



21. Install reverse gear to clutch housing, and then install retaining pin to clutch housing, using suitable tool.


CAUTION:

Do not reuse retaining pin.


22. Install 1st-2nd shift fork to 1st-2nd fork rod, and then install retaining pin to 1st-2nd shift fork.

CAUTION:

- Do not reuse retaining pin.
- Replace 1st-2nd fork rod and 1st-2nd shift fork as a set.




23. Set 1st-2nd fork rod assembly (1) onto mainshaft assembly (2), and then install them to clutch housing.



24. Install lock pins (↔) to clutch housing.
25. Install 3rd-4th shift fork to 3rd-4th fork rod, and then install retaining pin to 3rd-4th shift fork.

CAUTION:

- Do not reuse retaining pin.
- Replace 3rd-4th fork rod and 3rd-4th shift fork as a set.




26. Install 3rd-4th fork rod assembly (1), 3rd-4th coupling sleeve (2), and input shaft assembly (3) to clutch housing.

- a. Pull 1st-2nd fork rod (4) up, and then maintain the neutral position.
- b. Set 3rd-4th fork rod assembly onto 3rd-4th coupling sleeve, and then install them together with input shaft assembly to clutch housing.

CAUTION:

- Set lock pin (3rd-4th fork rod side) onto 1st-2nd fork rod groove and then install 3rd-4th fork rod assembly.



TRANSAXLE ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >


[5MT: RS5F91R]

- Be careful with the orientation of 3rd-4th coupling sleeve.


(A) : 4th main gear side

(B) : 3rd main gear side

- Install 3rd input gear of input shaft assembly so that it is set under reverse main gear of 3rd-4th coupling sleeve.
- Replace 3rd-4th coupling sleeve and 3rd-4th synchronizer hub as a set.



- Install springs and insert keys to 3rd-4th synchronizer hub.
- Apply gear oil to 4th baulk ring.
- Install 4th baulk ring.




27. Install 5th-reverse fork rod (1) to clutch housing.

CAUTION:

Replace 5th-reverse fork rod and 5th-reverse shift fork as a set.


- Pull gear of reverse gear (2) up.
- Temporarily install 5th-reverse fork rod to clutch housing.



- Press gear of reverse gear (1) down and then install 5th-reverse fork rod (2) to clutch housing.

CAUTION:

Set levers of 5th-reverse fork rod so as to align with reverse gear groove (□).




28. Install 4th main gear (2) and spacer (1) to mainshaft.

CAUTION:

Install spacer so that spacer protrusion faces rear side of transaxle.

29. Press 3rd-4th shift fork down and then shift 3rd-4th coupling sleeve to 3rd gear side.



TRANSAXLE ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[5MT: RS5F91R]

30. Move the shifter lever A (1) to the 3rd gear position.


NOTE:

- If it is not moved to the 3rd gear position, transaxle case cannot be installed to clutch housing.
- The 3rd gear position means that shifter lever A is fully rotated clockwise and it is returned approximately 10 degrees.

31. Apply recommended sealant to transaxle case mating surface of clutch housing.

CAUTION:

- Use Genuine Silicone RTV or equivalent. Refer to [GI-22, "Recommended Chemical Products and Sealants"](#).
- Do not allow old Silicone RTV, moisture, oil, or foreign matter to remain on mating surface.
- Check that mating surface is not damaged.
- Apply a continuous bead of Silicone RTV to the mating surface.




32. Install transaxle case to clutch housing. If it is difficult to install, slightly rotate shifter lever A counterclockwise, and then install.

- (1) : Selector
(2) : Shift fork

CAUTION:

- Do not damage Silicone RTV bead with transaxle case or other objects during installation.
- Be careful to align the lever of 5th-reverse fork rod with reverse gear groove.





33. Rotate input shaft so that bearing and shaft fit each other, and then tighten transaxle bolts (↶) to the specified torque.
34. Apply recommended sealant to position switch thread and check ball plug thread. Install to transaxle case and tighten to specified torque.

CAUTION:

- Use Genuine Silicone RTV or equivalent. Refer to [GI-22, "Recommended Chemical Products and Sealants"](#).
- Do not allow old Silicone RTV, moisture, oil, or foreign matter to remain on thread.

35. Apply gear oil to mainshaft spline.

36. Install 5th main gear (1) to mainshaft, using a suitable bolt (A) [M10 x 1.0] and a suitable nut (B).



TRANSAXLE ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >


[5MT: RS5F91R]

37. Install adapter plate (1), bushing (2), and 5th input gear (3) to input shaft.

CAUTION:

Be careful with the orientation of adapter plate.

⇐ : Transaxle case side



38. Install 5th-reverse synchronizer hub, 5th-reverse coupling sleeve, and 5th-reverse shift fork.

- Apply gear oil to 5th-reverse baulk ring.
- Install 5th-reverse baulk ring (1) to 5th input gear.

⇐ : 5th-reverse synchronizer hub side

CAUTION:

Be careful with the orientation of 5th-reverse baulk ring.

- Install synchronizer levers (2) to 5th-reverse synchronizer hub (3).

CAUTION:



- Replace 5th-reverse synchronizer hub and 5th-reverse coupling sleeve as a set.
- Be careful with the orientation of synchronizer lever.

- Install 5th-reverse synchronizer hub assembly and lock washer to input shaft.

CAUTION:


- Be careful with the orientation of 5th-reverse synchronizer hub.

⇐ : 5th input gear side



- Do not allow synchronizer lever (1) to overlap 5th-reverse baulk ring protrusion (A).

- (2) : 5th-reverse baulk ring
- (3) : 5th-reverse synchronizer hub



TRANSAXLE ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >


[5MT: RS5F91R]

- e. Set 5th-reverse shift fork (1) to 5th-reverse coupling sleeve, and then install them to 5th-reverse fork rod and input shaft.

CAUTION:

Do not reuse nut.

- (A) : Suitable tool
(B) : Bolt
(C) : Nut




CAUTION:

- Be careful with the orientation of 5th-reverse coupling sleeve.

← : 5th input gear side

- Replace 5th-reverse synchronizer hub and 5th-reverse coupling sleeve as a set.
- Replace 5th-reverse shift fork and 5th-reverse fork rod as a set.



- f. Check that the shifter lever A is in the 3rd position. Press 5th-reverse shift fork (1) and move shifter lever A to 5th gear.

(A) : Suitable tool

- g. Tighten bolt (B) to the specified torque.
h. Tighten nut (C) to the specified torque.

CAUTION:

Do not reuse nut.

- i. Install retaining pin to 5th-reverse shift fork, using suitable tool.

CAUTION:



Do not reuse retaining pin.

39. Move shifter lever A (1) to the neutral position.

40. Install O-ring to rear housing.

CAUTION:

Do not reuse O-ring.



TRANSAXLE ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[5MT: RS5F91R]

41. Install rear housing to transaxle case, and tighten bolts (↔) to the specified torque.

CAUTION:

- Do not reuse O-ring.
- Do not pinch O-ring when installing rear housing.

42. Install drain plug.

- a. Install gasket to drain plug.

CAUTION:

Do not reuse gasket.

- b. Install drain plug to clutch housing, using suitable tool.
c. Tighten drain plug to the specified torque.

43. Install filler plug.

- a. Install gasket to filler plug, and then install filler plug to transaxle case.


CAUTION:

Do not reuse gasket.

- b. Tighten filler plug to the specified torque.

CAUTION:

Fill with gear oil before tightening filler plug to the specified torque.




Inspection

INFOID:000000009417477

INSPECTION AFTER DISASSEMBLY

Check contact surface and sliding surface of fork rod and shift fork for excessive wear, uneven wear, and damage. Replace if necessary.



INPUT SHAFT AND GEAR


< UNIT DISASSEMBLY AND ASSEMBLY >

[5MT: RS5F91R]

INPUT SHAFT AND GEAR

Exploded View

INFOID:000000009417478



1. Input shaft front bearing

4. Input shaft rear bearing

7. 5th input gear

10. 5th-reverse synchronizer hub

13. Retaining pin

2. Input shaft

5. Adapter plate

8. 5th-reverse baulk ring

11. 5th-reverse coupling sleeve

14. Reverse gear

3. Snap ring

6. Bushing

9. Synchronizer lever

12. Lock washer

: Apply gear oil.

: Replace the parts as a set.

Disassembly

INFOID:000000009417479

Refer to [TM-30, "Disassembly"](#) for disassembly procedure.

Assembly

INFOID:000000009417480

Refer to [TM-36, "Assembly"](#) for assembly procedure.

Inspection

INFOID:000000009417481

INSPECTION AFTER DISASSEMBLY

Input Shaft and Gear


INPUT SHAFT AND GEAR

< UNIT DISASSEMBLY AND ASSEMBLY >

[5MT: RS5F91R]

Check the following items and replace if necessary.


- Damage, peeling, uneven wear, and distortion of shaft.
- Excessive wear, damage, and peeling of gear.




Synchronizer

Check for the following and replace if necessary.

- Contact surface breakage, damage, and unusual wear of coupling sleeve, synchronizer hub, and synchronizer lever.
- Coupling sleeve and synchronizer hub move smoothly.




- Breakage, damage, and excessive wear of baulk ring cam surface and synchronizer lever contact surface.



Bearing

Check bearing for damage and rough rotation. Replace if necessary.



MAINSHAFT AND GEAR


< UNIT DISASSEMBLY AND ASSEMBLY >

[5MT: RS5F91R]

MAINSHAFT AND GEAR

Exploded View

INFOID:000000009417482



- | | | |
|------------------------------|-----------------------------|----------------------------|
| 1. Mainshaft front bearing | 2. Mainshaft | 3. 1st main gear |
| 4. 1st inner baulk ring | 5. 1st synchronizer cone | 6. 1st outer baulk ring |
| 7. 1st-2nd synchronizer hub | 8. 1st-2nd coupling sleeve | 9. Spring |
| 10. Insert key | 11. 2nd outer baulk ring | 12. 2nd synchronizer cone |
| 13. 2nd inner baulk ring | 14. Snap ring | 15. Thrust washer |
| 16. 2nd main gear | 17. 3rd main gear | 18. 3rd baulk ring |
| 19. 3rd-4th synchronizer hub | 20. 3rd-4th coupling sleeve | 21. 4th baulk ring |
| 22. 4th main gear | 23. Spacer | 24. Mainshaft rear bearing |
| 25. 5th main gear | | |



: Apply gear oil.



: Replace the parts as a set.

Disassembly

INFOID:000000009417483

CAUTION:


- Secure mainshaft in a vise using blocks of wood to prevent damage, and then remove gears and snap rings.

MAINSHAFT AND GEAR

< UNIT DISASSEMBLY AND ASSEMBLY >

[5MT: RS5F91R]


- For removal of snap ring, set snap ring pliers and flat pliers at both sides of snap ring. While expanding snap ring with snap ring pliers, remove snap ring with flat pliers.
- Mark gear component direction for assembly without damaging component contact locations.




1. Remove 3rd-4th synchronizer hub and 3rd baulk ring.
2. Remove snap ring (1) and thrust washer (2).

CAUTION:

Do not reuse snap ring.




3. Remove 3rd main gear (1) and thrust washer (2).



4. Remove snap ring (1) and thrust washer (2).

CAUTION:

Do not reuse snap ring.




MAINSHAFT AND GEAR


< UNIT DISASSEMBLY AND ASSEMBLY >

[5MT: RS5F91R]

- Remove 2nd main gear (1) and thrust washer (2).



- Remove snap ring (1), and then remove 2nd inner baulk ring, 2nd synchronizer cone, and 2nd outer baulk ring.
- Remove 1st-2nd coupling sleeve, insert keys, springs, and 1st-2nd synchronizer hub.
- Remove 1st outer baulk ring, 1st synchronizer cone, 1st inner baulk ring, and 1st main gear (2).




INFOID:000000009417484

Assembly

Assembly is in the reverse order of disassembly.

CAUTION:


- Do not reuse snap ring.
- For installation of snap ring, set snap ring pliers and flat pliers at both sides of snap ring. While expanding snap ring with snap ring pliers, remove snap ring with flat pliers.
- Check that snap ring is securely installed to the groove.
- Apply gear oil to 1st outer baulk ring, 1st synchronizer cone, 1st inner baulk ring, 2nd outer baulk ring, 2nd synchronizer cone, 2nd inner baulk ring, and 3rd baulk ring.
- Replace 1st outer baulk ring, 1st synchronizer cone, and 1st inner baulk ring as a set.
- Replace 2nd outer baulk ring, 2nd synchronizer cone, and 2nd inner baulk ring as a set.



- Be careful with the orientation of 1st-2nd synchronizer hub.

- (A) : 1st main gear side
(B) : 2nd main gear side

- Replace 1st-2nd synchronizer hub and 1st-2nd coupling sleeve as a set.




MAINSHAFT AND GEAR

< UNIT DISASSEMBLY AND ASSEMBLY >

[5MT: RS5F91R]

- Be careful with the orientation of 1st-2nd coupling sleeve.


- (A) : 2nd main gear side
(B) : 1st main gear side




- Be careful with the orientation of 3rd-4th synchronizer hub.

- (A) : 4th main gear side
(B) : 3rd main gear side

- Replace 3rd-4th synchronizer hub and 3rd-4th coupling sleeve as a set.



- Be careful with the orientation of insert key (1) and spring (2).



INFOID:000000009417485


Inspection

INSPECTION AFTER DISASSEMBLY

Mainshaft and Gear

Check the following items and replace if necessary.

- Damage, peeling, uneven wear, and distortion of shaft.
- Excessive wear, damage, and peeling of gear.



Synchronizer


Check the following items and replace if necessary.

MAINSHAFT AND GEAR


< UNIT DISASSEMBLY AND ASSEMBLY >

[5MT: RS5F91R]

- Contact surface breakage, damage, and unusual wear of coupling sleeve, synchronizer hub, insert key, and spring.
- Coupling sleeve and synchronizer hub move smoothly.




- Breakage, damage, and excessive wear of baulk ring cam surface and insert contact surface.



Bearing

Check bearing for damage and rough rotation. Replace if necessary.



FINAL DRIVE


< UNIT DISASSEMBLY AND ASSEMBLY >

[5MT: RS5F91R]

FINAL DRIVE

Exploded View

INFOID:000000009417486



1. Differential side bearing outer race 2. Differential side bearing 3. Final drive


■: Replace the parts as a set.

Disassembly

INFOID:000000009417487

- Remove differential side bearings, using Tool (A) and suitable tool.

Tool number : ST33052000 (—)



Assembly


INFOID:000000009417488

- Install differential side bearings, using Tool (A).

CAUTION:

Replace differential side bearing outer race and differential side bearing as a set.

Tool number : KV40104920 (—)



Inspection

INFOID:000000009417489

INSPECTION AFTER DISASSEMBLY

Gear and Final Drive

FINAL DRIVE


< UNIT DISASSEMBLY AND ASSEMBLY >

[5MT: RS5F91R]

Check the sliding surfaces for wear, crack, or damage. Replace if necessary.

Bearing

Check bearing for damage and rough rotation. Replace if necessary.



A

B

C

TM

E

F

G

H

I

J

K

L

M

N

O

P

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[5MT: RS5F91R]

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specifications

INFOID:000000009417490

Transaxle type			RS5F91R		
Engine type			HR16DE		
Model code number			3AM0C		
Number of speed			5		
Synchronesh type			Warner		
Shift pattern			1 3 5 2 4 R 1 3 5 2 4 R 1 3 5 2 4 R SCIA0821E		
Gear ratio	1st		3.7273		
	2nd		2.0476		
	3rd		1.3929		
	4th		1.0294		
	5th		0.8205		
	Reverse		3.5455		
	Final gear		4.0667		
Number of teeth	Input gear	1st	11		
		2nd	21		
		3rd	28		
		4th	34		
		5th	39		
		Reverse	11		
	Main gear	1st	41		
		2nd	43		
		3rd	39		
		4th	35		
		5th	32		
		Reverse	39		
	Reverse idler gear		26		
	Final gear	Final gear/Pinion	61/15		
		Side gear/Pinion mate gear	13/9		
Gear oil capacity (Reference)			ℓ (US pt, Imp pt)		
Gear oil capacity (Reference)			Approx. 2.67 (5-5/8, 4-3/4)		
Remarks	Reverse brake		Installed		
	Double-cone synchronizer		1st and 2nd		
	Speedometer drive gear		Not installed		

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000009578754

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS


WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

Precaution for Procedure without Cowl Top Cover

INFOID:000000009019576

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc to prevent damage to windshield.



Precaution for TCM and Transaxle Assembly Replacement

INFOID:000000009019577

CAUTION:

- To replace TCM, refer to [TM-127, "Description"](#).
- To replace transaxle assembly, refer to [TM-128, "Description"](#).

Precaution for G Sensor Removal/Installation or Replacement

INFOID:000000009019578

CAUTION:

To remove/install or replace G sensor, refer to [TM-130, "Description"](#).

PRECAUTIONS


< PRECAUTION >

[CVT: RE0F11A]


General Precautions

INFOID:000000009019579


- Turn ignition switch OFF and disconnect the battery cable from the negative terminal before connecting or disconnecting the CVT assembly harness connector. Because battery voltage is applied to TCM even if ignition switch is turned OFF.




- When connecting or disconnecting pin connectors into or from TCM, do not damage pin terminals (bend or break). Check that there are not any bends or breaks on TCM pin terminal, when connecting pin connectors.



- Perform TCM input/output signal inspection and check whether TCM functions normally or not before replacing TCM. Refer to [TM-100, "Reference Value"](#).



- Perform "DTC (Diagnostic Trouble Code) CONFIRMATION PROCEDURE". If the repair is completed DTC should not be displayed in the "DTC CONFIRMATION PROCEDURE".



- Always use the specified brand of CVT fluid. Refer to [MA-11, "Fluids and Lubricants"](#).
- Use lint-free paper not cloth rags during work.
- Dispose of the waste oil using the methods prescribed by law, ordinance, etc. after replacing the CVT fluid.

On Board Diagnosis (OBD) System of CVT and Engine

INFOID:000000009019580

The ECM has an on board diagnostic system. It will light up the malfunction indicator lamp (MIL) to warn the driver of a malfunction causing emission deterioration.

PRECAUTIONS

< PRECAUTION >

[CVT: RE0F11A]

CAUTION:


- Be sure to turn the ignition switch OFF and disconnect the battery cable from the negative terminal before any repair or inspection work. The open/short circuit of related switches, sensors, solenoid valves, etc. will cause the MIL to light up.
- Be sure to connect and lock the connectors securely after work. A loose (unlocked) connector will cause the MIL to light up due to an open circuit. (Be sure the connector is free from water, grease, dirt, bent terminals, etc.)
- Be sure to route and secure the harnesses properly after work. Interference of the harness with a bracket, etc. may cause the MIL to light up due to a short circuit.
- Be sure to connect rubber tubes properly after work. A misconnected or disconnected rubber tube may cause the MIL to light up due to a malfunction of the EGR system or fuel injection system, etc.
- Be sure to erase the unnecessary malfunction information (repairs completed) from the TCM and ECM before returning the vehicle to the customer.

Removal and Installation Procedure for CVT Unit Connector

INFOID:000000009019581


REMOVAL

- Rotate bayonet ring (A) counterclockwise. Pull out CVT unit harness connector (B) upward and remove it.




INSTALLATION

1. Align marking (A) on CVT unit harness connector terminal with marking (B) on bayonet ring. Insert CVT unit harness connector.
2. Rotate bayonet ring clockwise.



3. Rotate bayonet ring clockwise until marking (A) on CVT unit harness connector terminal body is aligned with the slit (B) on bayonet ring as shown in the figure (correctly fitting condition).




CAUTION:

PRECAUTIONS

< PRECAUTION >

[CVT: RE0F11A]

- Securely align marking (A) on CVT unit harness connector terminal body with bayonet ring slit (B). Then, be careful not to make a half fit condition as shown in the figure.
- Do not mistake the slit of bayonet ring for other dent portion.



PREPARATION

< PREPARATION >



[CVT: RE0F11A]

PREPARATION

PREPARATION

Special Service Tools



INFOID:000000009019582

Tool number Tool name	Description
1. KV311039S0 Charging pipe set 2. KV31103920* O-ring	CVT fluid changing and adjustment
 JSDIA1844ZZ	
KV38107900 Protector a: ϕ 32 mm	Installing drive shaft
 PDIA1183J	

*: The O-ring as an unit part is set as a SST.

Commercial Service Tools

INFOID:000000009019583

Tool number Tool name	Description
31197EU50A Drive plate location guide a: ϕ 25 mm	Installing transaxle assembly
 JPDIA0676ZZ	
Drift a: ϕ 56 mm b: ϕ 50 mm	Installing differential side oil seal
 NT115	


SYSTEM DESCRIPTION

COMPONENT PARTS

CVT CONTROL SYSTEM

CVT CONTROL SYSTEM : Component Parts Location

INFOID:000000009019584



ALDIA0434ZZ

- | | | |
|--------------------------------|------------------------------|--------------------------------|
| 1. IPDM E/R | 2. TCM | 3. Transmission range switch |
| 4. Primary speed sensor | 5. CVT unit | 6. Output speed sensor |
| 7. Secondary speed sensor | 8. G sensor | 9. Stop lamp switch |
| 10. CVT shift selector | 11. Overdrive control switch | 12. Combination meter (type A) |
| 13. Combination meter (type B) | | |

COMPONENT DESCRIPTION

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[CVT: RE0F11A]

Component		Function
IPDM E/R		The TCM receives the A/C compressor feedback signal via CAN communications from the IPDM E/R.
TCM		TM-61, "CVT CONTROL SYSTEM : TCM"
Transmission range switch		TM-62, "CVT CONTROL SYSTEM : Transmission Range Switch"
Primary speed sensor		TM-62, "CVT CONTROL SYSTEM : Primary Speed Sensor"
CVT unit		—
Control valve	ROM assembly*	TM-61, "CVT CONTROL SYSTEM : ROM Assembly"
	CVT fluid temperature sensor*	TM-63, "CVT CONTROL SYSTEM : CVT Fluid Temperature Sensor"
	Secondary pressure sensor*	TM-63, "CVT CONTROL SYSTEM : Secondary Pressure Sensor"
	Primary pressure solenoid valve*	TM-64, "CVT CONTROL SYSTEM : Primary Pressure Solenoid Valve"
	Low brake solenoid valve*	TM-64, "CVT CONTROL SYSTEM : Low Brake Solenoid Valve"
	High clutch & reverse brake solenoid valve*	TM-64, "CVT CONTROL SYSTEM : High Clutch & Reverse Brake Solenoid Valve"
	Torque converter clutch solenoid valve*	TM-64, "CVT CONTROL SYSTEM : Torque Converter Clutch Solenoid Valve"
	Line pressure solenoid valve*	TM-65, "CVT CONTROL SYSTEM : Line Pressure Solenoid Valve"
Output speed sensor		TM-63, "CVT CONTROL SYSTEM : Output Speed Sensor"
Secondary speed sensor		TM-62, "CVT CONTROL SYSTEM : Secondary Speed Sensor"
G sensor		TM-65, "CVT CONTROL SYSTEM : G Sensor"
Overdrive control switch		TM-65, "CVT CONTROL SYSTEM : Overdrive Control Switch"
Combination meter		The TCM receives the overdrive control switch signal via CAN communications from the combination meter.
ABS actuator and electric unit (control unit)		The TCM receives the following signals via CAN communications from the ABS actuator and electric unit (control unit). • Vehicle speed signal • VDC operation signal • VDC malfunction signal
ECM		• For purposes including improving the feeling when shifting and preventing drops in engine speed, control signals are exchanged between the ECM and TCM, and real-time cooperative control is performed according to the vehicle driving conditions. (Engine and CVT integrated control) - Engine and CVT integrated control signal • The TCM receives the following signals via CAN communications from the ECM. - Engine speed signal - Accelerator pedal position signal - Closed throttle position signal • TCM sends and receives the following signals with ECM through CAN communication to perform D position N idle control. - N idle instruction signal
BCM		The TCM receives the following signals via CAN communications from the BCM. • Stop lamp switch signal • Turn indicator signal

*: These components are included in control valve assembly.

CVT CONTROL SYSTEM : TCM

INFOID:000000009019585

- The vehicle driving status is judged based on the signals from the sensors, switches, and other control units, and the optimal transaxle control is performed.
- For TCM control items, refer to [TM-74, "CVT CONTROL SYSTEM : System Description"](#).

CVT CONTROL SYSTEM : ROM Assembly

INFOID:000000009019586

- The ROM assembly is installed to control valve.

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[CVT: RE0F11A]

- The ROM assembly stores the calibration data (characteristic value) of each solenoid valve. TCM enables accurate hydraulic control by obtaining the calibration data.

CVT CONTROL SYSTEM : Transmission Range Switch


INFOID:000000009019587

- The transmission range switch is installed to upper part of transaxle case.
- The transmission range switch detects the selector lever position.

CVT CONTROL SYSTEM : Primary Speed Sensor

INFOID:000000009019588


- The primary speed sensor is installed to side cover of transaxle.
- The primary speed sensor detects primary pulley speed.
- The primary speed sensor generates the ON-OFF pulse (short waveform) in proportion to the rotating body speed which is "The higher the rotating body speed is, the faster the change cycle is". The TCM judges the rotating speed from the changing cycle of this pulse signal.



CVT CONTROL SYSTEM : Secondary Speed Sensor

INFOID:000000009019589


- The secondary speed sensor is installed to side cover of transaxle.
- The secondary speed sensor detects secondary pulley speed.
- The secondary speed sensor generates the ON-OFF pulse (short waveform) in proportion to the rotating body speed which is "The higher the rotating body speed is, the faster the change cycle is". The TCM judges the rotating speed from the changing cycle of this pulse signal.



CVT CONTROL SYSTEM : Output Speed Sensor

INFOID:000000009019590


- The output speed sensor is installed to the back side of transaxle case.
- The output speed sensor detects final gear speed. TCM evaluates the vehicle speed from the final gear revolution.
- The output speed sensor generates the ON-OFF pulse (short waveform) in proportion to the rotating body speed which is "The higher the rotating body speed is, the faster the change cycle is". The TCM judges the rotating speed from the changing cycle of this pulse signal.



CVT CONTROL SYSTEM : CVT Fluid Temperature Sensor

INFOID:000000009019591

- The CVT fluid temperature sensor is installed to control valve.
- The CVT fluid temperature sensor detects CVT fluid temperature in oil pan.
- The fluid temperature sensor uses a thermistor, and changes the signal voltage by converting changes in the CVT fluid temperature to a resistance value. TCM evaluates the CVT fluid temperature from the signal voltage value.



CVT CONTROL SYSTEM : Secondary Pressure Sensor

INFOID:000000009019592


- The secondary pressure sensor is installed to control valve.
- The secondary pressure sensor detects the pressure applied to the secondary pulley.

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[CVT: RE0F11A]

- When pressure is applied to the ceramic device in the secondary pressure sensor, the ceramic device is deformed, resulting in voltage change. TCM evaluates the secondary pressure from its voltage change. Voltage is increased along with pressure increase.



CVT CONTROL SYSTEM : Primary Pressure Solenoid Valve

INFOID:0000000009019593

- The primary pressure solenoid valve is installed to control valve.
- The primary pressure solenoid valve controls the primary pressure control valve. For information about the primary pressure control valve, refer to [TM-71, "TRANSAXLE : Component Description"](#).
- The primary pressure solenoid valve uses the linear solenoid valve [N/H (normal high) type].

NOTE:

- The principle of the linear solenoid valve utilizes the fact that the force pressing on the valve spool installed inside the coil increases nearly in proportion to the current. This allows it to produce a fluid pressure that is proportional to this pressing force.
- The N/H (normal high) produces hydraulic control when the coil is not energized.

CVT CONTROL SYSTEM : Low Brake Solenoid Valve

INFOID:0000000009019594

- The low brake solenoid valve is installed to control valve.
- The low brake solenoid valve adjusts the tightening pressure of the low brake.
- The low brake solenoid valve uses the linear solenoid valve [N/L (normal low) type].

NOTE:

- The principle of the linear solenoid valve utilizes the fact that the force pressing on the valve spool installed inside the coil increases nearly in proportion to the current. This allows it to produce a fluid pressure that is proportional to this pressing force.
- The N/L (normal low) type does not produce hydraulic control when the coil is not energized.

CVT CONTROL SYSTEM : High Clutch & Reverse Brake Solenoid Valve

INFOID:0000000009019595

- The high clutch & reverse brake solenoid valve is installed to control valve.
- The high clutch & reverse brake solenoid valve adjusts the tightening pressure of the high clutch and reverse brake.
- The high clutch & reverse brake solenoid valve uses the linear solenoid valve [N/H (normal high) type].

NOTE:

- The principle of the linear solenoid valve utilizes the fact that the force pressing on the valve spool installed inside the coil increases nearly in proportion to the current. This allows it to produce a fluid pressure that is proportional to this pressing force.
- The N/H (normal high) produces hydraulic control when the coil is not energized.

CVT CONTROL SYSTEM : Torque Converter Clutch Solenoid Valve

INFOID:0000000009019596

- The torque converter clutch solenoid valve is installed to control valve.
- The torque converter clutch solenoid valve controls the torque converter clutch control valve. For information about the torque converter clutch control valve, refer to [TM-71, "TRANSAXLE : Component Description"](#).
- The torque converter clutch solenoid valve utilizes a linear solenoid valve [N/L (normal low) type].

NOTE:

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[CVT: RE0F11A]

- The principle of the linear solenoid valve utilizes the fact that the force pressing on the valve spool installed inside the coil increases nearly in proportion to the current. This allows it to produce a fluid pressure that is proportional to this pressing force.
- The N/L (normal low) type does not produce hydraulic control when the coil is not energized.

CVT CONTROL SYSTEM : Line Pressure Solenoid Valve

INFOID:0000000009019597

- The line pressure solenoid valve is installed to control valve.
- The line pressure solenoid valve controls the pressure regulator valve. For information about the pressure regulator valve, refer to [TM-71. "TRANSAXLE : Component Description"](#).
- The line pressure solenoid valve uses the linear solenoid valve [N/H (normal high) type].

NOTE:

- The principle of the linear solenoid valve utilizes the fact that the force pressing on the valve spool installed inside the coil increases nearly in proportion to the current. This allows it to produce a fluid pressure that is proportional to this pressing force.
- The N/H (normal high) produces hydraulic control when the coil is not energized.

CVT CONTROL SYSTEM : G Sensor

INFOID:0000000009019598

- G sensor is installed to floor under instrument lower cover.
- G sensor detects front/rear G and inclination applied to the vehicle.
- G sensor converts front/rear G and inclination applied to the vehicle to voltage signal. TCM evaluates front/rear G and inclination angle of the vehicle from the voltage signal.

CVT CONTROL SYSTEM : Overdrive Control Switch

INFOID:0000000009019599


- The overdrive control switch is installed to the selector lever knob.
- When the OD OFF indicator lamp on the combination meter is OFF and the overdrive control switch is pressed, the overdrive is cancelled and the OD OFF indicator lamp is ON.
- When the OD OFF indicator lamp on the combination meter is ON and the overdrive control switch is pressed, the overdrive is active and the OD OFF indicator lamp is OFF.

CVT CONTROL SYSTEM : OD OFF Indicator Lamp

INFOID:0000000009019600

DESIGN/PURPOSE

The O/D OFF indicator notifies the driver that the shift control of transmaxle is in O/D OFF.



BULB CHECK

Approximately 2 seconds after ignition switch ON.

OPERATION AT COMBNATION METER CNA COMMUNICATION CUT-OFF OR UNUSUAL SIGNAL


For actions on CAN communications blackout in the combnation meter, refer to [MWI-20. "Fail-safe"](#).

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[CVT: RE0F11A]

SYSTEM DIAGRAM



SIGNAL PATH

- When a overdrive control switch signal is input to the combination meter, the combination meter transmits the overdrive control switch signal to the TCM via CAN communication.
- When all of the following conditions are satisfied, the TCM transmits a O/D OFF indicator signal to the combination meter via CAN communication. The combination meter turns ON the O/D OFF indicator lamp on the combination meter, according to the signal.
- TCM receives overdrive control switch signal via CAN communication from combination meter.
- Selector lever: D position

LIGHTING CONDITION

When all of the following conditions are satisfied.


- Ignition switch: ON
- Selector lever: D position
- Overdrive control switch is pressed when the O/D OFF indicator lamp is OFF.

SHUTOFF CONDITION

When any of the conditions listed below is satisfied.

- Ignition switch: Other than ON
- Overdrive control switch is pressed when the O/D OFF indicator lamp is ON.
- Selector lever is shifted to other than D position when the O/D OFF indicator lamp is ON.

TIMING CHART



CVT CONTROL SYSTEM : Shift Position Indicator

INFOID:000000009019601

TCM transmits shift position signal to combination meter via CAN communication. The actual shift position is displayed on combination meter according to the signal.

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[CVT: RE0F11A]

CVT CONTROL SYSTEM : Malfunction Indicator Lamp (MIL)


INFOID:000000009019602

The malfunction indicator lamp (MIL) is located on the combination meter.

The MIL will illuminate when the ignition switch is turned ON without the engine running. This is a bulb check.

When the engine is started, the MIL should turn off. If the MIL remains illuminated, the on board diagnostic system has detected an engine system malfunction.


For details, refer to [EC-57, "DIAGNOSIS DESCRIPTION : Malfunction Indicator Lamp \(MIL\)"](#).



SHIFT LOCK SYSTEM

SHIFT LOCK SYSTEM : Component Parts Location

INFOID:000000009019603



1. Stop lamp switch
4. Shift lock solenoid

2. Shift lock release lever

3. Park position switch

COMPONENT DESCRIPTION

Component	Function
Stop lamp switch	Stop lamp switch turns ON when brake pedal is depressed.
Shift lock release lever	Manually releases the shift lock.
Park position switch	Detects that the selector lever is in "P" position.
Shift lock solenoid	Operates according to the signal from the stop lamp switch and moves the lock lever.

STRUCTURE AND OPERATION

< SYSTEM DESCRIPTION >


[CVT: RE0F11A]

STRUCTURE AND OPERATION

TRANSAXLE

TRANSAXLE : Cross-Sectional View

INFOID:000000009019604



JSDIA1777ZZ

- | | | |
|----------------------|---------------------|---------------------------------------|
| 1. Converter housing | 2. Oil pump | 3. Counter drive gear |
| 4. Control valve | 5. Oil pan | 6. Primary pulley |
| 7. Steel belt | 8. Secondary pulley | 9. Planetary gear (auxiliary gearbox) |
| 10. Side cover | 11. Transaxle case | 12. Differential case |
| 13. Final gear | 14. Reduction gear | 15. Counter driven gear |
| 16. Drive sprocket | 17. Oil pump chain | 18. Torque converter |
| 19. Driven sprocket | | |

TRANSAXLE : Transaxle Mechanism

INFOID:000000009019605

BELT & PULLEY

STRUCTURE AND OPERATION

< SYSTEM DESCRIPTION >

[CVT: RE0F11A]

Mechanism


It is composed of a pair of pulleys (the groove width is changed freely in the axial direction) and the steel belt (the steel plates are placed continuously and the belt is guided with the multilayer steel rings on both sides). The groove width changes according to wrapping radius of steel belt and pulley from low status to overdrive status continuously with non-step. It is controlled with the oil pressures of primary pulley and secondary pulley.

Steel belt

It is composed of multiple steel plates (A) and two steel rings (B) stacked to a several number. The feature of this steel belt transmits power with compression of the steel plate in contrast with transmission of power in pulling with a rubber belt. Friction force is required with the pulley slope to transmit power from the steel plate. The force is generated with the following mechanism:


Oil pressure applies to the secondary pulley to nip the plate. ⇒The plate is pushed and extended outward. ⇒The steel ring shows withstands. ⇒Pulling force is generated on the steel ring. ⇒The plate of the primary pulley is nipped between the pulley. ⇒Friction force is generated between the steel belt and the pulley.

Therefore, responsibilities are divided by the steel plate that transmits the power with compression and the steel ring that maintains necessary friction force. In this way, the tension of the steel ring is distributed on the entire surface and stress variation is limited, resulting in good durability.



Pulley

The primary pulley (input shaft side) and the secondary pulley (output shaft side) have the shaft with slope (fixed cone surface), movable sheave (movable cone surface that can move in the axial direction) and oil pressure chamber at the back of the movable sheave.



Pulley gear shifting operation

• Pulley gear shifting operation


The movable sheave slides on the shaft to change the groove width of the pulley. Input signals of engine load (accelerator pedal opening), engine revolution and gear ratio (vehicle speed) change the operation pressures of the primary pulley and the secondary pulley, and controls the pulley groove width. Along with change of the pulley groove width, the belt contact radius is changed. This allows continuous and stepless

STRUCTURE AND OPERATION

< SYSTEM DESCRIPTION >

[CVT: RE0F11A]

gear shifting from low to overdrive. "The contact radius ratio of each pulley in contact with the belt x auxiliary gearbox gear ratio" is the gear ratio.



AUXILIARY GEARBOX MECHANISM

1st, 2nd and reverse gears are changed with the planetary gear mechanism.

TRANSAXLE : Operation Status

INFOID:000000009019606

×: Engaged or applied.

Slector lever position	Parking mechanism	Counter gear set	Low brake	High clutch	Reverse brake	Primary pulley	Secondary pulley	Steel belt	Reduction gear set
P	×	×				×	×	×	
R		×			×	×	×	×	×
N		×				×	×	×	
D		×	× (1GR)	× (2GR)		×	×	×	×
L		×	× (1GR)	× (2GR)		×	×	×	×

[CVT: RE0F11A]

INFOID:0000000009019608

2014 Versa Note

STRUCTURE AND OPERATION

< SYSTEM DESCRIPTION >

[CVT: RE0F11A]

Part name	Function
Manual valve	Distributes the clutch and brake operation pressures (pilot pressure) corresponding to each shift position.
High clutch/reverse brake switching valve	Switches the circuit for the high clutch and the reverse brake.
Torque converter clutch control valve	It is operated with the torque converter clutch solenoid valve and it adjusts the tightening pressure and non-tightening pressure of the torque converter clutch piston of the torque converter.
Primary pressure control valve	It is operated with the primary pressure solenoid valve and adjusts the feed pressure to the primary pulley.
Primary pressure solenoid valve	TM-64, "CVT CONTROL SYSTEM : Primary Pressure Solenoid Valve"
Low brake solenoid valve	TM-64, "CVT CONTROL SYSTEM : Low Brake Solenoid Valve"
High clutch & reverse brake solenoid valve	TM-64, "CVT CONTROL SYSTEM : High Clutch & Reverse Brake Solenoid Valve"
Torque converter clutch solenoid valve	TM-64, "CVT CONTROL SYSTEM : Torque Converter Clutch Solenoid Valve"
Line pressure solenoid valve	TM-65, "CVT CONTROL SYSTEM : Line Pressure Solenoid Valve"


FLUID COOLER & FLUID WARMER SYSTEM

FLUID COOLER & FLUID WARMER SYSTEM : System Description


INFOID:0000000009019609

CVT FLUID COOLER SCHEMATIC

Without CVT fluid cooler (air-cooling)



With CVT fluid cooler (air-cooling)



COMPONENT DESCRIPTION


CVT Oil Warmer

STRUCTURE AND OPERATION

< SYSTEM DESCRIPTION >

[CVT: RE0F11A]

- The CVT oil warmer (1) is installed on the front part of transaxle assembly.
- When engine is started while engine and CVT are cold, engine coolant temperature rises more quickly than CVT fluid temperature. CVT oil warmer is provided with two circuits for CVT and engine coolant respectively so that warmed engine coolant warms CVT quickly. This helps shorten CVT warming up time, improving fuel economy.
- A cooling effect is obtained when CVT fluid temperature is high.



CVT Fluid Cooler (Water-cooling)


- The CVT fluid cooler (water-cooling) is installed in the radiator side tank (right side).
- CVT fluid is cooled by engine coolant.

CVT Fluid Cooler (Air-cooling)

- The CVT fluid cooler (air-cooling) is installed to vehicle front.
- The CVT fluid cooler (air-cooling) prevents CVT fluid temperature from an abnormal increase while driving the vehicle. When flowing into the CVT fluid cooler (air-cooling), CVT fluid is cooled by driving blast while driving the vehicle.

Heater Thermostat

- The heater thermostat (1) is installed on the front part of transaxle assembly.
- The heater thermostat open and close with set temperature.



SHIFT LOCK SYSTEM

SHIFT LOCK SYSTEM : System Description

INFOID:000000009019619

The selector lever cannot be shifted from "P" position to any other position unless the ignition switch is in the ON position and the brake pedal is depressed.

KEY LOCK SYSTEM

KEY LOCK SYSTEM : System Description

INFOID:000000009019620

- The key lock mechanism also operates as a shift lock:
 - With the ignition switch turned to ON, selector lever cannot be shifted from "P" position to any other position unless brake pedal is depressed.
 - With the key removed, selector lever cannot be shifted from "P" position to any other position.
 - The key cannot be removed unless selector lever is placed in "P" position.
- The shift lock and key lock mechanisms are controlled by the ON-OFF operation of the shift lock solenoid and by the operation of the rotator and slider located inside key cylinder, respectively.


SYSTEM

CVT CONTROL SYSTEM

CVT CONTROL SYSTEM : System Description

INFOID:000000009019610

SYSTEM DIAGRAM



INPUT/OUTPUT SIGNAL TABLE

Sensor (or signal)	TCM function	Actuator
- Engine and CVT integrated control signal - Engine speed signal - Accelerator pedal position signal - Closed throttle position signal - Stop lamp switch signal - Secondary pressure sensor - CVT fluid temperature sensor - Primary speed sensor - Secondary speed sensor - Output speed sensor - Transmission range switch signal - Overdrive control switch signal - Vehicle speed signal (ABS) - ABS operation signal - A/C compressor feedback signal - G sensor - N idle instruction signal - Turn indicator signal	- Line pressure control (TM-82, "LINE PRESSURE CONTROL : System Description") - Shift control (TM-83, "SHIFT CONTROL : System Description") - Select control (TM-85, "SELECT CONTROL : System Description") - Lock-up control (TM-86, "LOCK-UP CONTROL : System Description") - Idle neutral control (TM-87, "IDLE NEUTRAL CONTROL : System Description") - Fail-safe mode (TM-108, "Fail-safe") - Self-diagnosis function (TM-93, "CONSULT Function") - Communication function with CONSULT (TM-93, "CONSULT Function") - CAN communication control (TM-140, "Description")	- Line pressure solenoid valve - Primary pressure solenoid valve - Torque converter clutch solenoid valve - High clutch & reverse brake solenoid valve - Low brake solenoid valve - OD OFF indicator lamp - Shift position indicator

SYSTEM DESCRIPTION

- CVT detects the vehicle driving status from switches, sensors and signals, and controls the vehicle so that the optimum shift position and shift timing may always be achieved. It also controls the vehicle to reduce shift and lockup shock, etc.
- Receives input signals from switches and sensors.
- Sends the output signal necessary for operation of solenoid valves, and evaluates the line pressure, shift timing, lockup operation, engine brake performance, etc.
- If a malfunction occurs on the electric system, activate the fail-safe mode only to drive the vehicle.

LIST OF CONTROL ITEMS AND INPUT/OUTPUT

Control Item		Shift control	Line pressure control	Select control	Lock-up control	Fail-safe function *
Input	Engine torque signal (CAN communication)	×	×	×	×	×
	Engine speed signal (CAN communication)	×	×	×	×	×
	Accelerator pedal position signal (CAN communication)	×	×	×	×	×
	Closed throttle position signal (CAN communication)	×	×		×	
	Stop lamp switch signal (CAN communication)	×	×	×	×	
	Secondary pressure sensor	×	×	×		×
	CVT fluid temperature sensor		×	×	×	×
	Primary speed sensor	×	×		×	×
	Secondary speed sensor	×	×	×	×	×
	Output speed sensor	×	×	×	×	×
	Transmission range switch	×	×	×	×	×
	Overdrive control switch (CAN communication)	×				

SYSTEM

< SYSTEM DESCRIPTION >


[CVT: RE0F11A]


Control Item		Shift control	Line pressure control	Select control	Lock-up control	Fail-safe function *
Output	Line pressure solenoid valve	×	×	×		×
	Primary pressure solenoid valve	×				×
	Torque converter clutch solenoid valve				×	×
	High clutch & reverse brake solenoid valve	×		×		×
	Low brake solenoid valve	×		×		×
	Shift position indicator (CAN communication)			×		
	OD OFF indicator lamp (CAN communication)	×				

·*: If these input/output signals show errors, TCM activates the fail-safe function.

CVT CONTROL SYSTEM : Schematic

INFOID:000000009019611





CVT CONTROL SYSTEM : Fail-safe

INFOID:000000009019612

TCM has a fail-safe mode. The mode functions so that operation can be continued even if the signal circuit of the main electronically controlled input/output parts is damaged.

If the vehicle shows following behaviors including “poor acceleration”, a malfunction of the applicable system is detected by TCM and the vehicle may be in a fail-safe mode. At this time, check the DTC code and perform inspection and repair according to the malfunction diagnosis procedures.

Fail-safe function

DTC	Vehicle behavior	Conditions of vehicle
P062F	Not changed from normal driving	—
P0705	- Shift position indicator on combination meter is not displayed. - Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed	—
P0706	- Shift position indicator on combination meter is not displayed. - Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed	—

SYSTEM

< SYSTEM DESCRIPTION >

[CVT: RE0F11A]

DTC	Vehicle behavior	Conditions of vehicle
P0711	Acceleration is slow	Engine coolant temperature when engine start: Temp. $\geq 10^{\circ}\text{C}$ (50°F)
	- Selector shock is large - Start is slow	Engine coolant temperature when engine start: -35°C (-31°F) $\leq$ Temp. $< 10^{\circ}\text{C}$ (50°F)
	- Selector shock is large - Start is slow	Engine coolant temperature when engine start: Temp. $< -35^{\circ}\text{C}$ (-31°F)
P0712	Acceleration is slow	Engine coolant temperature when engine start: Temp. $\geq 10^{\circ}\text{C}$ (50°F)
	- Selector shock is large - Start is slow	Engine coolant temperature when engine start: -35°C (-31°F) $\leq$ Temp. $< 10^{\circ}\text{C}$ (50°F)
	- Selector shock is large - Start is slow	Engine coolant temperature when engine start: Temp. $< -35^{\circ}\text{C}$ (-31°F)
P0713	Acceleration is slow	Engine coolant temperature when engine start: Temp. $\geq 10^{\circ}\text{C}$ (50°F)
	- Selector shock is large - Start is slow	Engine coolant temperature when engine start: -35°C (-31°F) $\leq$ Temp. $< 10^{\circ}\text{C}$ (50°F)
	- Selector shock is large - Start is slow	Engine coolant temperature when engine start: Temp. $< -35^{\circ}\text{C}$ (-31°F)
P0715	- Selector shock is large - Start is slow - Acceleration is slow - Vehicle speed is not increased - Lock-up is not performed	—
P0720	- Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed	—
P0740	Lock-up is not performed	—
P0743	Lock-up is not performed	—
P0744	Lock-up is not performed	—
P0746	- Selector shock is large - Start is slow - Acceleration is slow - Vehicle speed is not increased - Lock-up is not performed	—
P0846	- Start is slow - Acceleration is slow	—
P0847	Acceleration is slow	—
P0848	- Start is slow - Acceleration is slow	—
P0863	Not changed from normal driving	—
P0890	- Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed	—
P0962	- Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed	—
P0963	- Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed	—

A

B

C

TM

E

F

G

H

I

J

K

L

M

N

O

P

SYSTEM

< SYSTEM DESCRIPTION >

[CVT: RE0F11A]

DTC	Vehicle behavior	Conditions of vehicle
P0965	- Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed	—
P0966	- Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed	—
P0967	- Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed	—
P0998	- Start is slow - Lock-up is not performed	—
P0999	- Start is slow - Lock-up is not performed	Wire disconnection
	- Vehicle speed is not increased - Lock-up is not performed	Voltage shorting
P099B	Start is slow	—
P099C	- Start is slow - Lock-up is not performed	Wire disconnection
	- Vehicle speed is not increased - Lock-up is not performed	Voltage shorting
P1586	Idle neutral control is not performed	—
P1588	Idle neutral control is not performed	—
P2765	- Selector shock is large - Start is slow - Acceleration is slow - Vehicle speed is not increased - Lock-up is not performed	—
P2857	- Start is slow - Lock-up is not performed	—
P2858	- Vehicle speed is not increased - Lock-up is not performed	—
P2859	Vehicle speed is not increased	—
P285A	Start is slow	—
U0073	- Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed	—
U0100	- Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed	—
U0140	Not changed from normal driving	—
U0141	Not changed from normal driving	—
U0155	Not changed from normal driving	—
U0300	- Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed	—
U1000	Not changed from normal driving	—
U1114	Not changed from normal driving	—
U1117	Not changed from normal driving	—

SYSTEM

< SYSTEM DESCRIPTION >

[CVT: RE0F11A]

CVT CONTROL SYSTEM : Protection Control

INFOID:000000009019613

The TCM becomes the protection control status temporarily to protect the safety when the safety of TCM and transmission is lost. It automatically returns to the normal status if the safety is secured.
The TCM has the following protection control.

CONTROL FOR WHEEL SPIN

Control	When a wheel spin is detected, the engine output and gear ratio are limited and the line pressure is increased. At the 1GR, the clutch pressure is increased.
Vehicle behavior in control	If the accelerator is kept depressing during wheel spin, the engine revolution and vehicle speed are limited to a certain degree. From the 1GR, upshift to a certain gear ratio is only allowed.
Normal return condition	Wheel spin convergence returns the control to the normal control.

CONTROL WHEN FLUID TEMPERATURE IS HIGH

Control	When the CVT fluid temperature is high, the gear shift permission maximum revolution and the maximum torque are reduced than usual to prevent increase of the oil temperature.
Vehicle behavior in control	Power performance may be lowered, compared to normal control.
Normal return condition	The control returns to the normal control when CVT fluid temperature is lowered.

TORQUE IS REDUCED WHEN DRIVING WITH THE REVERSE GEAR

Control	Engine output is controlled according to a vehicle speed while reversing the vehicle.
Vehicle behavior in control	Power performance may be lowered while reversing the vehicle.
Normal return condition	Torque returns to normal by positioning the selector lever in a range other than "R" position.

REVERSE PROHIBIT CONTROL


Control	The reverse brake is controlled to avoid becoming engaged when the selector lever is set in "R" position while driving in forward direction at more than the specified speed.
Vehicle behavior in control	If the selector lever is put at "R" position when driving with the forward gear, the gear becomes neutral, not reverse.
Normal return condition	The control returns to normal control when the vehicle is driven at low speeds. (The reverse brake becomes engaged.)

LINE PRESSURE CONTROL

LINE PRESSURE CONTROL : System Description

INFOID:000000009019614

SYSTEM DIAGRAM



DESCRIPTION

Highly accurate line pressure control (secondary pressure control) reduces friction for improvement of fuel economy.

Normal Oil Pressure Control

Appropriate line pressure and secondary pressure suitable for driving condition are determined based on the accelerator pedal position, engine speed, primary pulley (input) speed, secondary pulley (output) speed, vehicle speed, input torque, stop lamp switch signal, transmission range switch signal, lock-up signal, power voltage, target shift ratio, oil temperature and oil pressure.

Secondary Pressure Feedback Control


In normal oil pressure control and oil pressure control in shifting, highly accurate secondary pressure is determined by detecting the secondary pressure using a oil pressure sensor and by feedback control.

SHIFT CONTROL

SHIFT CONTROL : System Description

INFOID:000000009019615

SYSTEM DIAGRAM



DESCRIPTION

To select the gear ratio that can give the driving force to meet driver's intent or vehicle situation, the vehicle driving condition such as vehicle speed or accelerator pedal position is detected and the most appropriate gear ratio is selected and the shifting method before reaching the speed is determined. The information is output to the primary pressure solenoid valve to control the line pressure input/output to the primary pulley, to determine the primary pulley (movable pulley) position and to control the gear position.


D Position (Normal)

SYSTEM

< SYSTEM DESCRIPTION >


[CVT: RE0F11A]

Gear shifting is performed in all shifting ranges from the lowest to the highest gear ratio.




D Position (OD OFF)

The gear ratio is generally high by limiting the shifting range on the high side, and this always generates a large driving power.



L Position

By limiting the shifting range only to the lowest of the gear ratio, a large driving force and engine brake are obtained.




Hill Climbing And Descending Control

If a downhill is detected with the accelerator pedal is released, the system performs downshift to increase the engine brake force so that vehicle may not be accelerated more than necessary. If a climbing hill is detected, the system improves the acceleration performance in re-acceleration by limiting the gear shift range on the high side.

NOTE:

For engine brake control on a downhill, the control can be stopped with CONSULT.



Control In Acceleration


From change of the vehicle speed or accelerator pedal position, the acceleration request level of the driver or driving scene is evaluated. In start or acceleration during driving, the gear shift characteristics with linearity of revolution increase and vehicle speed increase are gained to improve the acceleration feel.

SELECT CONTROL

SELECT CONTROL : System Description

INFOID:000000009019616

SYSTEM DIAGRAM



DESCRIPTION


Based on accelerator pedal angle, engine speed, primary pulley speed, and the secondary pulley speed, the optimum operating pressure is set to reduce impact of a selector lever operation while shifting from "N" ("P") to "D" ("R") position.

LOCK-UP CONTROL

LOCK-UP CONTROL : System Description

INFOID:000000009019617

SYSTEM DIAGRAM



DESCRIPTION

- Controls for improvement of the transmission efficiency by engaging the torque converter clutch in the torque converter and eliminating slip of the converter. Achieves comfortable driving with slip control of the torque converter clutch.
- The oil pressure feed circuit for the torque converter clutch piston chamber is connected to the torque converter clutch control valve. The torque converter clutch control valve is switched by the torque converter clutch solenoid valve with the signal from TCM. This controls the oil pressure circuit, which is supplied to the torque converter clutch piston chamber, to the release side or engagement side.
- If the CVT fluid temperature is low or the vehicle is in fail-safe mode due to malfunction, lock-up control is prohibited.

Lock-up engagement


In lock-up engagement, the torque converter clutch solenoid valve makes the torque converter clutch control valve locked up to generate the lock-up apply pressure. This pushes the torque converter clutch piston for engagement.

Lock-up release condition

In lock-up release, the torque converter clutch solenoid valve makes the torque converter clutch control valve non-locked up to drain the lock-up apply pressure. This does not engage the torque converter clutch piston.

IDLE NEUTRAL CONTROL

SYSTEM DIAGRAM




DESCRIPTION

If a driver has no intention of starting the vehicle in D position, TCM operates the low brake solenoid valve and controls the oil pressure of the low brake to be low pressure. Therefore, the low brake is in the release (slip) status and the power transmission route of transaxle is the same status as the N position. In this way, the transaxle is in idling status and load to the engine can be reduced to improve fuel economy.

NOTE:

Provides idle neutral control when stop/start operation is not performed.



Idle Neutral Control Start Condition

Idle neutral control is started when all of the following conditions are fulfilled. However, during idle neutral control, idle neutral control is stopped when any of the following conditions is not met or idle neutral control continues 30 seconds.

Driving environment	: Flat road or road with mild gradient
Selector lever position	: "D" position
Vehicle speed	: 0 km/h (0 MPH)
Accelerator pedal position	: 0.0/8
Brake pedal	: Depressed
Engine speed	: Idle speed
Turn signal lamp/hazard signal lamp	: Not activated

NOTE:

Stops or prohibits the idle neutral control when the TCM and ECM detect that the vehicle is in one of the following conditions.

- Engine coolant temperature and CVT fluid temperature are the specified temperature or more, or the specified temperature or less.
- When a transaxle malfunction occurs.
- When the vehicle detects DTC and is in the fail-safe mode.

Idle Neutral Control Resume Condition

When the idle neutral control finishes, if the vehicle is driven at more than the specified speed and the idle neutral control start conditions are satisfied, the idle neutral control starts again. If the vehicle has a malfunction, the idle neutral control does not start.

- A
- B
- C
- TM
- E
- F
- G
- H
- I
- J
- K
- L
- M
- N
- O
- P

ON BOARD DIAGNOSTIC (OBD) SYSTEM

< SYSTEM DESCRIPTION >

[CVT: RE0F11A]

ON BOARD DIAGNOSTIC (OBD) SYSTEM

Description

INFOID:0000000009019621

This is an on board diagnosis system which records diagnosis information related to the exhaust gases. It detects malfunctions related to sensors and actuators. The malfunctions are indicated by means of the malfunction indicator lamp (MIL) and are stored as DTC in the ECU memory. The diagnosis information can be checked using a diagnosis tool (GST: Generic Scan Tool).

Function of OBD

INFOID:0000000009019622

The GST is connected to the diagnosis connector on the vehicle and communicates with the on-board control units to perform diagnosis. The diagnosis connector is the same as for CONSULT. Refer to [GI-49, "Description"](#).

DIAGNOSIS SYSTEM (TCM)

DIAGNOSIS DESCRIPTION

DIAGNOSIS DESCRIPTION : 1 Trip Detection Diagnosis and 2 Trip Detection Diagnosis

INFOID:000000009019623

NOTE:

"Start the engine and turn OFF the ignition switch after warm-up." This is defined as 1 trip.

1 TRIP DETECTION DIAGNOSIS

When initial malfunction is detected, TCM memorizes DTC. In these diagnoses, some illuminate MIL and some do not. Refer to [TM-112, "DTC Index"](#).

2 TRIP DETECTION DIAGNOSIS

When initial malfunction is detected, TCM memorizes DTC of the 1st trip. MIL does not light at this stage. <1 trip>

If the same malfunction is detected again in next driving, TCM memorizes DTC. When DTC is memorized, MIL lights. <2 trip>

"Trip" of the "2 trip detection diagnosis" indicates the driving mode that executes self-diagnosis during driving.

×: Check possible —: Check not possible

Item	DTC at the 1st trip		DTC		MIL	
	Display at the 1st trip	Display at the 2nd trip	Display at the 1st trip	Display at the 2nd trip	Illumination at the 1st trip	Illumination at the 2nd trip
1 trip detection diagnosis (Refer to TM-112, "DTC Index")	—	—	×	—	×	—
2 trip detection diagnosis (Refer to TM-112, "DTC Index")	×	—	—	×	—	×

DIAGNOSIS DESCRIPTION : DTC and DTC of 1st Trip

INFOID:000000009019624

2 TRIP DETECTION DIAGNOSIS THAT ILLUMINATES MIL

- The DTC number of the 1st trip is the same as the DTC number.
- When a malfunction is detected at the 1st trip, TCM memorizes DTC of the 1st trip. MIL does not light at this stage. If the same malfunction is not detected at the 2nd trip (conforming to necessary driving conditions), DTC at the 1st trip is erased from TCM. If the same malfunction is detected at the 2nd trip, TCM memorizes DTC and MIL lights at the same time.
- The DTC of the 1st trip is specified in Service \$01 of SAE J1979/ISO 15031-5. Since detection of DTC at the 1st trip does not illuminate MIL, warning for a problem is not given to a driver.
- For procedure to delete DTC and 1st trip DTC from TCM, refer to [TM-93, "CONSULT Function"](#).
- If DTC of the 1st trip is detected, it is necessary to check the cause according to the "Diagnosis flow". Refer to [TM-124, "Flowchart of Trouble Diagnosis"](#).

DIAGNOSIS DESCRIPTION : Malfunction Indicator Lamp (MIL)

INFOID:000000009019625

- TCM not only detects DTC, but also sends the MIL signal to ECM through CAN communication. ECM sends the MIL signal to the combination meter through CAN communication according to the signal, and illuminates MIL.
- For malfunction indicator lamp (MIL) description, refer to [EC-57, "DIAGNOSIS DESCRIPTION : Malfunction Indicator Lamp \(MIL\)"](#).

DIAGNOSIS DESCRIPTION : Counter System

INFOID:000000009019626

RELATION BETWEEN DTC AT 1ST TRIP/DTC/MIL AND DRIVING CONDITIONS (FOR 2 TRIP DETECTION DIAGNOSIS THAT ILLUMINATES MIL)

- When initial malfunction is detected, TCM memorizes DTC of the 1st trip. MIL does not light at this stage.
- If the same malfunction is detected at the 2nd trip, TCM memorizes DTC and MIL lights at the same time.
- Then, MIL goes after driving the vehicle for 3 trips under "Driving condition B" without malfunction.
- DTC is displayed until 40 trips of "Driving condition A" are satisfied without detecting the same malfunction. DTC is erased when 40 trips are satisfied.

DIAGNOSIS SYSTEM (TCM)

< SYSTEM DESCRIPTION >

[CVT: RE0F11A]

- When the self-diagnosis result is acceptable at the 2nd trip (conforming to driving condition B), DTC of the 1st trip is erased.

COUNTER SYSTEM LIST

Item	Driving condition	Trip
MIL (OFF)	B	3
DTC (clear)	A	40
DTC at 1st trip (clear)	B	1

DRIVING CONDITION

Driving condition A

Driving condition A is the driving condition that provides warm-up.

In specific, count-up is performed when all of the following conditions are satisfied.

- Engine speed is 400 rpm or more.
- After start of the engine, the water temperature increased by 20 °C (36 °F) or more.
- Water temperature was 70 °C (158 °F) or more.
- The ignition switch was changed from ON to OFF.

NOTE:

- If the same malfunction is detected regardless of the driving condition, reset the A counter.
- When the above is satisfied without detecting the same malfunction, count up the A counter.
- When MIL goes off due to the malfunction and the A counter reaches 40, the DTC is erased.

Driving condition B

Driving condition B is the driving condition that performs all diagnoses once.

In specific, count-up is performed when all of the following conditions are satisfied.

- Engine speed is 400 rpm or more.
- Water temperature was 70 °C (158 °F) or more.
- In closed loop control, vehicle speed of 70 – 120 km/h (43 – 75 MPH) continued for 60 seconds or more.
- In closed loop control, vehicle speed of 30 – 60 km/h (19 – 37 MPH) continued for 10 seconds or more.
- In closed loop control, vehicle speed of 4 km/h (2 MPH) or less and idle determination ON continued for 12 seconds or more.
- After start of the engine, 22 minutes or more have passed.
- The condition that the vehicle speed is 10km/h (6 MPH) or more continued for 10 seconds or more in total.
- The ignition switch was changed from ON to OFF.

NOTE:


- If the same malfunction is detected regardless of the driving condition, reset the B counter.
- When the above is satisfied without detecting the same malfunction, count up the B counter.
- When the B counter reaches 3 without malfunction, MIL goes off.
- When the B counter is counted once without detecting the same malfunction after TCM memorizes DTC of the 1st trip, DTC of the 1st trip is erased.

DIAGNOSIS SYSTEM (TCM)

< SYSTEM DESCRIPTION >

[CVT: RE0F11A]

TIME CHART



CONSULT Function

INFOID:000000009019627

APPLICATION ITEMS

Conditions	Function
Work Support	This mode enables a technician to adjust some devices faster and more accurately.
Self Diagnostic Results	Retrieve DTC from ECU and display diagnostic items.
Data Monitor	Monitor the input/output signal of the control unit in real time.
CAN Diagnosis	This mode displays a network diagnosis result about CAN by a diagram.

DIAGNOSIS SYSTEM (TCM)

< SYSTEM DESCRIPTION >

[CVT: RE0F11A]

Conditions	Function
CAN Diagnosis Support Monitor	It monitors the status of CAN communication.
ECU Identification	Display the ECU identification number (part number etc.) of the selected system.
CALIB DATA	The calibration data status of TCM can be checked.

SELF DIAGNOSTIC RESULTS

Display Item List

Refer to [TM-112, "DTC Index"](#).

DTC at 1st trip and method to read DTC

- DTC (P0705, P0711, P0720, etc.) is specified by SAE J2012/ISO 15031-6.
- DTC and DTC at 1st trip are displayed on "Self Diagnostic results" of CONSULT.
When DTC is currently detected, "CRNT" is displayed. If "PAST" is displayed, it shows a malfunction occurred in the past. The trip number of drive without malfunction of concerned DTC can be confirmed with "IGN counter" inside "FFD".
- When the DTC at the 1st trip is detected, the "timing" is displayed as "1t".

DTC deletion method

NOTE:

- If the battery terminal is disconnected, the TCM memory is erased. (The disconnection time varies from several seconds to several hours.
- If the ignition switch is left ON after repair, turn OFF the ignition switch and wait for 10 seconds or more. Then, turn the ignition ON again. (Engine stop)
 1. Touch "TRANSMISSION" of CONSULT.
 2. Touch "Self Diagnostic Result".
 3. Touch "Erase". (DTC memorized in TCM is erased.)

IGN counter

The ignition counter is displayed in "FFD" and the number of times of satisfied "Driving condition A" is displayed after normal recovery of DTC. Refer to [TM-91, "DIAGNOSIS DESCRIPTION : Counter System"](#).

- If malfunction (DTC) is currently detected, "0" is displayed.
- After normal recovery, every time "Driving condition A" is satisfied, the display value increases from 1 → 2 → 3...38 → 39.
- When MIL turns OFF due to the malfunction and the counter reaches 40, the DTC is erased.

NOTE:

The counter display of "40" cannot be checked.

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

×: Application ▼: Optional selection

Monitored item	(Unit)	Monitor item selection		Remarks
		MAIN SIG- NALS	ECU IN- PUT SIG- NALS	
VSP SENSOR	(km/h or mph)	▼	×	Displays the vehicle speed calculated from the CVT output shaft speed.
ESTM VSP SIG	(km/h or mph)	▼	×	Displays the vehicle speed signal (ABS) received through CAN communication.
PRI SPEED SEN	(rpm)	▼	×	Displays the primary pulley speed calculated from the pulse signal of the primary speed sensor.
SEC REV SENSOR	(rpm)	▼	×	Displays the secondary pulley speed calculated from the pulse signal of the secondary speed sensor.
VHCL/S SE (REV)	(rpm)	▼	×	Displays the CVT output shaft speed calculated from the pulse signal of the output speed sensor.
ENG SPEED SIG	(rpm)	▼	×	Displays the engine speed received through CAN communication.

DIAGNOSIS SYSTEM (TCM)

< SYSTEM DESCRIPTION >

[CVT: RE0F11A]

Monitored item	(Unit)	Monitor item selection		Remarks
		MAIN SIG- NALS	ECU IN- PUT SIG- NALS	
LINE PRESSURE SEN	(V)	▼	×	Displays the signal voltage of the line pressure sensor.
ATF TEMP SEN	(V)	▼	×	Displays the signal voltage of the CVT fluid temperature sensor.
G SENSOR	(V)	▼	×	Displays the signal voltage of the G sensor.
VIGN SEN	(V)	▼	×	Displays the battery voltage applied to TCM.
VEHICLE SPEED	(km/h or mph)	×	▼	Displays the vehicle speed recognized by TCM.
INPUT REV	(rpm)	▼	▼	Displays the input shaft speed of CVT recognized by TCM.
PRI SPEED	(rpm)	×	▼	Displays the primary pulley speed recognized by TCM.
SEC SPEED	(rpm)	▼	▼	Displays the secondary pulley speed recognized by TCM.
OUTPUT REV	(rpm)	▼	▼	Displays the output shaft speed of CVT recognized by TCM.
ENG SPEED	(rpm)	×	▼	Displays the engine speed recognized by TCM.
SLIP REV	(rpm)	×	▼	Displays the speed difference between the input shaft speed of CVT and the engine speed.
TOTAL GEAR RATIO		×	▼	Displays the total CVT gear ratio calculated from input shaft speed/output shaft speed of CVT.
PULLEY GEAR RATIO		×	▼	Displays the pulley gear ratio calculated from primary pulley speed/secondary pulley speed.
AUX GEARBOX		▼	▼	Displays the gear position of the auxiliary gearbox recognized by TCM.
G SPEED	(G)	▼	▼	Displays the acceleration and deceleration speed of the vehicle calculated from vehicle speed change.
ACCEL POSI SEN 1	(deg)	×	×	Displays the estimated throttle position received through CAN communication.
VENG TRQ	(Nm)	×	▼	Display the engine torque recognized by TCM.
PRI TRQ	(Nm)	▼	▼	Display the input shaft torque of CVT.
TRQ RTO		▼	▼	Display the torque ratio of torque converter.
LINE PRESSURE	(MPa)	×	▼	Displays the secondary pressure (line pressure) calculated from the signal voltage of the secondary pressure sensor.
FLUID TEMP	(°C or °F)	×	▼	Displays the CVT fluid temperature calculated from the signal voltage of the CVT fluid temperature sensor.
DSR REV	(rpm)	▼	▼	Displays the target primary pulley speed calculated from processing of gear shift control.
TRGT GEAR RATIO		▼	▼	Displays the target gear ratio from the input shaft to the output shaft of CVT calculated from processing of gear shift control.
TGT PLY GR RATIO		▼	▼	Displays the target gear ratio of the pulley from processing of gear shift control.
TRGT AUX GEARBOX		▼	▼	Displays the target gear of the auxiliary gearbox calculated from processing of gear shift control.
LU PRS	(MPa)	▼	▼	Displays the target oil pressure of the torque converter clutch solenoid valve calculated from oil pressure processing of gear shift control.

DIAGNOSIS SYSTEM (TCM)

< SYSTEM DESCRIPTION >

[CVT: RE0F11A]

Monitored item	(Unit)	Monitor item selection		Remarks
		MAIN SIG- NALS	ECU IN- PUT SIG- NALS	
LINE PRS	(MPa)	▼	▼	Displays the target oil pressure of the line pressure solenoid valve calculated from oil pressure processing of gear shift control.
TRGT PRI PRESSURE	(MPa)	▼	▼	Displays the target oil pressure of the primary pressure solenoid valve calculated from oil pressure processing of gear shift control.
TRGT HC/RB PRESS	(MPa)	▼	▼	Displays the target oil pressure of the high clutch & reverse brake solenoid valve calculated from oil pressure processing of gear shift control.
TRGT LB PRESSURE	(MPa)	▼	▼	Displays the target oil pressure of the low brake solenoid valve calculated from oil pressure processing of gear shift control.
ISOLT1	(A)	×	▼	Displays the command current from TCM to the torque converter clutch solenoid valve.
ISOLT2	(A)	×	▼	Displays the command current from TCM to the line pressure solenoid valve.
PRI SOLENOID	(A)	×	▼	Displays the command current from TCM to the primary pressure solenoid valve.
HC/RB SOLENOID	(A)	×	▼	Displays the command current from TCM to the high clutch& reverse brake solenoid valve.
L/B SOLENOID	(A)	×	▼	Displays the command current from TCM to the low brake solenoid valve.
SOLMON1	(A)	×	×	Monitors the command current from TCM to the torque converter clutch solenoid valve and displays the monitored value.
SOLMON2	(A)	×	×	Monitors the command current from TCM to the line pressure solenoid valve and displays the monitored value.
PRI SOL MON	(A)	×	×	Monitors the command current from TCM to the primary pressure solenoid valve and displays the monitored value.
HC/RB SOL MON	(A)	×	×	Monitors the command current from TCM to the high clutch& reverse brake solenoid valve and displays the monitored value.
L/B SOL MON	(A)	×	×	Monitors the current command from TCM to the low brake solenoid valve and displays the monitored value.
D POSITION SW	(On/Off)	▼	×	Displays the operation status of the transmission range switch (D position).
N POSITION SW	(On/Off)	▼	×	Displays the operation status of the transmission range switch (N position).
R POSITION SW	(On/Off)	▼	×	Displays the operation status of the transmission range switch (R position).
P POSITION SW	(On/Off)	▼	×	Displays the operation status of the transmission range switch (P position).
BRAKESW	(On/Off)	×	×	Displays the reception status of the stop lamp switch signal received through CAN communication.
L POSITION SW	(On/Off)	▼	×	Displays the operation status of the transmission range switch (L position).
IDLE SW	(On/Off)	×	×	Displays the reception status of the closed throttle position signal received through CAN communication.
SPORT MODE SW	(On/Off)	×	×	Displays the reception status of the overdrive control switch signal received through CAN communication.

DIAGNOSIS SYSTEM (TCM)

< SYSTEM DESCRIPTION >

[CVT: RE0F11A]

Monitored item	(Unit)	Monitor item selection		Remarks
		MAIN SIG- NALS	ECU IN- PUT SIG- NALS	
STRDWSW	(On/Off)	▼	×	- Displays the operation status of the paddle shifter (down switch). - It is displayed although not equipped.
STRUPSW	(On/Off)	▼	×	- Displays the operation status of the paddle shifter (up switch). - It is displayed although not equipped.
DOWNLVR	(On/Off)	▼	×	- Displays the operation status of the selector lever (down switch). - It is displayed although not equipped.
UPLVR	(On/Off)	▼	×	- Displays the operation status of the selector lever (up switch). - It is displayed although not equipped.
NONMMODE	(On/Off)	▼	×	- Displays if the selector lever position is not at the manual shift gate. - It is displayed although not equipped.
MMODE	(On/Off)	▼	×	- Displays if the selector lever position is at the manual shift gate. - It is displayed although not equipped.
INDLRNG	(On/Off)	▼	▼	Displays the transmission status of the shift position (L position) signal transmitted through CAN communication.
INDDRNG	(On/Off)	▼	▼	Displays the transmission status of the shift position (D position) signal transmitted through CAN communication.
INGNRNG	(On/Off)	▼	▼	Displays the transmission status of the shift position (N position) signal transmitted through CAN communication.
INGRRNG	(On/Off)	▼	▼	Displays the transmission status of the shift position (R position) signal transmitted through CAN communication.
INGPRNG	(On/Off)	▼	▼	Displays the transmission status of the shift position (P position) signal transmitted through CAN communication.
CVT LAMP	(On/Off)	▼	▼	Displays the transmission status of the OD OFF indicator lamp signal transmitted through CAN communication.
SPORT MODE IND	(On/Off)	▼	▼	Displays the transmission status of the OD OFF indicator lamp signal transmitted through CAN communication.
MMODE IND	(On/Off)	▼	▼	- Displays the transmission status of the manual mode signal transmitted through CAN communication. - It is displayed although not equipped.
VDC ON	(On/Off)	▼	×	- Displays the reception status of the VDC (ESP) operation signal received through CAN communication. - It is displayed although not equipped.
TCS ON	(On/Off)	▼	×	- Displays the reception status of the TCS operation signal received through CAN communication. - It is displayed although not equipped.
ABS FAIL SIGNAL	(On/Off)	▼	×	Displays the reception status of the ABS malfunction signal received through CAN communication.
ABS ON	(On/Off)	▼	×	Displays the reception status of the ABS operation signal received through CAN communication.
4WD FAIL SIGNAL	(On/Off)	▼	×	- Displays the reception status of the 4WD malfunction signal received through CAN communication. - It is displayed although not equipped.

DIAGNOSIS SYSTEM (TCM)

< SYSTEM DESCRIPTION >

[CVT: RE0F11A]

Monitored item	(Unit)	Monitor item selection		Remarks
		MAIN SIG- NALS	ECU IN- PUT SIG- NALS	
4WD OPERATION SIG	(On/Off)	▼	×	- Displays the reception status of the 4WD operation signal received through CAN communication. - It is displayed although not equipped.
4WD-TCS SIGNAL	(On/Off)	▼	×	- Displays the reception status of the engine torque down request signal received through CAN communication. - It is displayed although not equipped.
RANGE		×	▼	Displays the gear position recognized by TCM.
M GEAR POS		×	▼	Display the target gear of manual mode
G SEN SLOPE	(%)	▼	▼	Displays the gradient angle calculated from the G sensor signal voltage.
ENGBRKLVL	(On/Off)	▼	▼	Displays the setting of "ENGINE BRAKE ADJ" in "Work Support".
PVIGN VOLT	(V)	▼	×	Displays the backup voltage of TCM.
TRGT AUX GR RATIO		▼	▼	Displays the target gear ratio of the auxiliary gearbox calculated from processing of gear shift control.
G SEN CALIBRATION	(YET/DONE)	▼	▼	Displays the status of "G SENSOR CALIBRATION" in "Work Support".
N IDLE STATUS	(On/Off)	▼	▼	Displays idle neutral status.
CVT-B		▼	▼	- Displays CVT fluid temperature count. - This monitor item does not use.
CVT-A		▼	▼	- Displays CVT fluid temperature count. - This monitor item does not use.

WORK SUPPORT

Item name	Description
ENGINE BRAKE ADJ.	Although there is no malfunction on the transaxle and the CVT system, if a customer make a complaint like "I do not feel comfortable with automatic operation of the engine brake on downhill", the engine brake may be cancelled with "engine brake adjustment".
CONFORM CVTF DETERIORATION	Check the degradation level of the CVT fluid under severe conditions.
G SENSOR CALIBRATION	Compensate the G sensor.
ERASE CALIBRATION DATA	Erase the calibration data memorized by TCM.
ERASE LEARNING VALUE	Erase the learning value memorized by TCM.
ERASE MEMORY DATA	Perform "erasing of the calibration data" and "erasing of the learned value" at the same time.
CLUTCH POINT LEARNING*	Allow learning of the clutch engagement point of the auxiliary gearbox for TCM.

*: "Clutch point learning" can be selected, but do not use it.

Engine brake adjustment

ENGINE BRAKE LEVEL

ON : Turn ON the engine brake control.

OFF : Turn OFF the engine brake control.

Check the degradation level of the CVT fluid.

CVTF degradation level data

DIAGNOSIS SYSTEM (TCM)

[CVT: RE0F11A]

< SYSTEM DESCRIPTION >

210,000 or more : Replacement of the CVT fluid is required.
Less than 210,000 : Replacement of the CVT fluid is not required.

A

B

C

TM

E

F

G

H

I

J

K

L

M

N

O

P

ECU DIAGNOSIS INFORMATION

TCM

Reference Value

INFOID:000000009019628

CONSULT DATA MONITOR STANDARD VALUE

- In CONSULT, electric shift timing or lock-up timing, i.e. operation timing of each solenoid valve, is displayed. Therefore, if there is an obvious difference between the shift timing estimated from a shift shock (or engine speed variations) and that shown on the CONSULT, the mechanism parts (including the hydraulic circuit) excluding the solenoids and sensors may be malfunctioning. In this case, check the mechanical parts following the appropriate diagnosis procedure.
- Shift point (gear position) displayed on CONSULT slightly differs from shift pattern described in Service Manual. This is due to the following reasons.
 - Actual shift pattern may vary slightly within specified tolerances.
 - While shift pattern described in Service Manual indicates start of each shift, CONSULT shows gear position at end of shift.
 - The solenoid display (ON/OFF) on CONSULT is changed at the start of gear shifting. In contrast, the gear position display is changed at the time when gear shifting calculated in the control unit is completed.

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor item	Condition	Value/Status (Approx.)
VSP SENSOR	While driving	Almost same as the speedometer display.
ESTM VSP SIG	While driving	Almost same as the speedometer display.
PRI SPEED SEN	In driving (lock-up ON)	A value obtained from dividing engine speed by counter gear ratio
SEC REV SENSOR	Auxiliary gearbox: 1GR	Approximately twice the "VHCL/S SE (REV)"
	Auxiliary gearbox: 2GR	Almost same as the "VHCL/S SE (REV)"
VHCL/S SE (REV)	Auxiliary gearbox: 1GR	Approximately half of the "SEC REV SENSOR"
	Auxiliary gearbox: 2GR	Almost same as the "SEC REV SENSOR"
ENG SPEED SIG	Engine running	Almost same reading as tachometer
LINE PRESSURE SEN	• Selector lever: "N" position • At idle	0.88 – 0.92 V
ATF TEMP SEN	CVT fluid: Approx. 20°C (68°F)	2.01 – 2.05 V
	CVT fluid: Approx. 50°C (122°F)	1.45 – 1.50 V
	CVT fluid: Approx. 80°C (176°F)	0.90 – 0.94 V
G SENSOR	Vehicle is level	2.5 V
VIGN SEN	Ignition switch: ON	10 – 16 V
VEHICLE SPEED	While driving	Almost same as the speedometer display.
INPUT REV	In driving (lock-up ON)	Almost same as the engine speed.
PRI SPEED	In driving (lock-up ON)	A value obtained from dividing engine speed by counter gear ratio
SEC SPEED	Auxiliary gearbox: 1GR	Approximately twice the "OUTPUT REV"
	Auxiliary gearbox: 2GR	Almost same as "OUTPUT REV"
OUTPUT REV	Auxiliary gearbox: 1GR	Approximately half of "SEC SPEED"
	Auxiliary gearbox: 2GR	Almost same as "SEC SPEED"
ENG SPEED	Engine running	Almost same reading as tachometer
SLIP REV	While driving	Engine speed – Input speed

TCM

< ECU DIAGNOSIS INFORMATION >

[CVT: RE0F11A]

Monitor item	Condition	Value/Status (Approx.)
TOTAL GEAR RATIO	Auxiliary gearbox: 1GR	Counter gear ratio × Pulley ratio Auxiliary gearbox gear ratio
	Auxiliary gearbox: 2GR	Counter gear ratio × Pulley ratio
PULLEY GEAR RATIO	In driving (forward)	2.20 – 0.55
	In driving (reverse)	2.20
AUX GEARBOX	Vehicle started with selector lever in “L” position	1st
	Release the accelerator pedal after the following conditions are satisfied • Selector lever: “D” position • Accelerator pedal position: 1/8 or less • Vehicle speed: 50 km/h (31 MPH) or more	2nd
	In gear shifting of auxiliary gearbox	1st ↔ 2nd
G SPEED	Vehicle stopped	0.00 G
	During acceleration	The value changes to the positive side along with acceleration.
	During deceleration	The value changes to the positive side along with deceleration.
ACCEL POSI SEN 1	Accelerator pedal released	0.00 deg
	Accelerator pedal fully depressed	80.00 deg
VENG TRQ	While driving	The value changes along with acceleration/ deceleration.
PRI TRQ	While driving	The value changes along with acceleration/ deceleration.
TRQ RTO	While driving	The value changes along with acceleration/ deceleration.
LINE PRESSURE	Selector lever: “P” position	0.575 MPa
FLUID TEMP	Ignition switch ON.	Displays the CVT fluid temperature.
DSR REV	While driving	It varies along with the driving condition.
TRGT GEAR RATIO	While driving	It varies along with the driving condition.
TGT PLY GR RATIO	In driving (forward)	2.20 – 0.55
	In driving (reverse)	2.20
TRGT AUX GEARBOX	Vehicle started with selector lever in “L” position	1st
	Release the accelerator pedal after the following conditions are satisfied • Selector lever: “D” position • Accelerator pedal position: 1/8 or less • Vehicle speed: 50 km/h (31 MPH) or more	2nd
	In gear shifting of auxiliary gearbox	Display gear position after gear shifting
LU PRS	• Engine started • Vehicle is stopped.	–0.500 MPa
	• Selector lever: “D” position • Accelerator pedal position: 1/8 or less • Vehicle speed: 20 km/h (12 MPH) or more	0.450 MPa
LINE PRS	• After engine warm up • Selector lever: “N” position • At idle	0.500 MPa
	• After engine warming up • Selector lever: “N” position • Depress the accelerator pedal fully	4.930 – 5.430 MPa
TRGT PRI PRESSURE	• Selector lever: “L” position • Vehicle speed: 20 km/h (12 MPH)	0.325 MPa

TCM

< ECU DIAGNOSIS INFORMATION >

[CVT: RE0F11A]

Monitor item	Condition	Value/Status (Approx.)
TRGT HC/RB PRESS	- Selector lever: "L" position - Vehicle speed: 20 km/h (12 MPH)	0.000 MPa
	Release the accelerator pedal after the following conditions are satisfied - Selector lever: "D" position - Accelerator pedal position: 1/8 or less - Vehicle speed: 50 km/h (31 MPH) or more	0.400 MPa
TRGT LB PRESSURE	- Selector lever: "L" position - Vehicle speed: 20 km/h (12 MPH)	0.325 MPa
	Release the accelerator pedal after the following conditions are satisfied - Selector lever: "D" position - Accelerator pedal position: 1/8 or less - Vehicle speed: 50 km/h (31 MPH) or more	0.000 MPa
ISOLT1	- Engine started - Vehicle is stopped.	0.000 A
	- Selector lever: "D" position - Accelerator pedal position: 1/8 or less - Vehicle speed: 20 km/h (12 MPH) or more	0.500 A
ISOLT2	- After engine warm up - Selector lever: "N" position - At idle	0.800 – 0.900 A
	- After engine warming up - Selector lever: "N" position - Depress the accelerator pedal fully	0.350 – 0.400 A
PRI SOLENOID	- Selector lever: "L" position - Vehicle speed: 20 km/h (12 MPH)	0.850 – 0.900 A
HC/RB SOLENOID	- Selector lever: "L" position - Vehicle speed: 20 km/h (12 MPH)	1.000 A
	Release the accelerator pedal after the following conditions are satisfied - Selector lever: "D" position - Accelerator pedal position: 1/8 or less - Vehicle speed: 50 km/h (31 MPH) or more	0.800 – 0.850 A
L/B SOLENOID	- Selector lever: "L" position - Vehicle speed: 20 km/h (12 MPH)	0.200 – 0.250 A
	Release the accelerator pedal after the following conditions are satisfied - Selector lever: "D" position - Accelerator pedal position: 1/8 or less - Vehicle speed: 50 km/h (31 MPH) or more	0.000 A
SOLMON1	- Engine started - Vehicle is stopped.	0.000 A
	- Selector lever: "D" position - Accelerator pedal position: 1/8 or less - Vehicle speed: 20 km/h (12 MPH) or more	0.500 A
SOLMON2	- After engine warm up - Selector lever: "N" position - At idle	0.800 – 0.900 A
	- After engine warming up - Selector lever: "N" position - Depress the accelerator pedal fully	0.350 – 0.400 A
PRI SOL MON	- Selector lever: "L" position - Vehicle speed: 20 km/h (12 MPH)	0.850 – 0.900 A

TCM

< ECU DIAGNOSIS INFORMATION >

[CVT: RE0F11A]

Monitor item	Condition	Value/Status (Approx.)
HC/RB SOL MON	- Selector lever: "L" position - Vehicle speed: 20 km/h (12 MPH)	1.000 A
	Release the accelerator pedal after the following conditions are satisfied - Selector lever: "D" position - Accelerator pedal position: 1/8 or less - Vehicle speed: 50 km/h (31 MPH) or more	0.800 – 0.850 A
L/B SOL MON	- Selector lever: "L" position - Vehicle speed: 20 km/h (12 MPH)	0.200 – 0.250 A
	Release the accelerator pedal after the following conditions are satisfied - Selector lever: "D" position - Accelerator pedal position: 1/8 or less - Vehicle speed: 50 km/h (31 MPH) or more	0.000 A
D POSITION SW	Selector lever: "D" position	On
	Other than the above	Off
N POSITION SW	Selector lever: "N" position	On
	Other than the above	Off
R POSITION SW	Selector lever: "R" position	On
	Other than the above	Off
P POSITION SW	Selector lever: "P" position	On
	Other than the above	Off
BRAKESW	Brake pedal is depressed	On
	Brake pedal is released	Off
L POSITION SW	Selector lever: "L" position	On
	Other than the above	Off
IDLE SW	Accelerator pedal is released	On
	Accelerator pedal is fully depressed	Off
SPORT MODE SW	Press the overdrive control switch	On
	Release the overdrive control switch	Off
STRDWNSW	Always	Off
STRUPSW	Always	Off
DOWNLVR	Always	Off
UPLVR	Always	Off
NONMMODE	Always	Off
MMODE	Always	Off
INDLRNG	Selector lever: "L" position	On
	Other than the above	Off
INDDRNG	Selector lever: "D" position	On
	Other than the above	Off
INDNRNG	Selector lever: "N" position	On
	Other than the above	Off
INDRRNG	Selector lever: "R" position	On
	Other than the above	Off
INDPRNG	Selector lever: "P" position	On
	Other than the above	Off
CVT LAMP	In overdrive OFF	On
	Other than the above	Off

A

B

C

TM

E

F

G

H

I

J

K

L

M

N

O

P

TCM


< ECU DIAGNOSIS INFORMATION >

[CVT: RE0F11A]


Monitor item	Condition	Value/Status (Approx.)
SPORT MODE IND	In overdrive OFF	On
	Other than the above	Off
MMODE IND	Always	Off
VDC ON	Always	Off
TCS ON	Always	Off
ABS FAIL SIGNAL	When ABS malfunction signal is received	On
	Other than the above	Off
ABS ON	ABS is activated	On
	Other than the above	Off
4WD FAIL SIGNAL	Always	Off
4WD OPERATION SIG	Always	Off
4WD-TCS SIGNAL	Always	Off
RANGE	Selector lever: "P" and "N" positions	N/P
	Selector lever: "R" position	R
	Selector lever: "D" position (OD OFF indicator lamp OFF)	D
	Selector lever: "D" position (OD OFF indicator lamp ON)	S
	Selector lever: "L" position	L
M GEAR POS	Always	1
G SEN SLOPE	Flat road	0%
	Uphill gradient	The value changes to the positive side along with uphill gradient. (Maximum 40.45%)
	Downhill gradient	The value changes to the negative side along with downhill gradient. (Minimum – 40.45%)
ENGBRKLVL	When the engine brake level of "ENGINE BRAKE ADJ". in "Work Support" is ON	On
	When the engine brake level of "ENGINE BRAKE ADJ". in "Work Support" is OFF	Off
PVIGN VOLT	Ignition switch: ON	10 – 16 V
TRGT AUX GR RATIO	Vehicle started with selector lever in "L" position	1.80
	Release the accelerator pedal after the following conditions are satisfied • Selector lever: "D" position • Accelerator pedal position: 1/8 or less • Vehicle speed: 50 km/h (31 MPH) or more	1.00
G SEN CALIBRATION	When G sensor calibration is completed	DONE
	When G sensor calibration is not completed	YET
N IDLE STATUS	When idle neutral control is operated	On
	When idle neutral control is not operated	Off
CVT-B*	—	—
CVT-A*	—	—

*: These monitor items do not use.

TERMINAL LAYOUT









INPUT/OUTPUT SIGNAL STANDARD

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	–	Signal	Input/ Output			
2 (R/B)	Ground	L range switch	Input	Ignition switch ON	Selector lever: “L” position	10 – 16 V
					Other than the above	0 V
4 (W/B)	Ground	D range switch	Input		Selector lever: “D” position	10 – 16 V
					Other than the above	0 V
5 (L/B)	Ground	N range switch	Input		Selector lever: “N” position	10 – 16 V
					Other than the above	0 V
6 (O)	Ground	R range switch	Input		Selector lever: “R” position	10 – 16 V
					Other than the above	0 V
7 (Y)	Ground	P range switch	Input		Selector lever: “P” position	10 – 16 V
					Other than the above	0 V
11 (LG)	Ground	Sensor ground	Input	Always		0 V
12 (G/W)	Ground	CVT fluid tempera- ture sensor	Output	Ignition switch ON	CVT fluid: Approx. 20°C	2.01 – 2.05 V
					CVT fluid: Approx. 50°C	1.45 – 1.50 V
					CVT fluid: Approx. 80°C	0.90 – 0.94 V
14 (G/R)	Ground	G sensor	Input	Ignition switch ON	When the vehicle stops on a flat road	2.5 V
15* (V)	—	—	—	—		—
16 (L/R)	Ground	Secondary pres- sure sensor	Input	• Selector lever: “N” position • At idle		0.88 – 0.92 V
21 (R/W)	—	ROM ASSY (CHIP SELECT)	—	—		—
22 (V)	—	ROM ASSY (DATA I/O)	—	—		—
23 (P/L)	—	CAN-L	Input/ Output	—		—
24 (BR)	Ground	Output speed sen- sor	Input	• Selector lever: “L” position • Vehicle speed: 20 km/h (12 MPH)		200 Hz 2.5mSec/div  5V/div JSDIA1904GB

TCM

< ECU DIAGNOSIS INFORMATION >






[CVT: RE0F11A]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	—	Signal	Input/ Output		
26 (O/W)	Ground	Sensor power supply	Output	Ignition switch: ON	5.0 V
				Ignition switch: OFF	0 V
30 (BR/B)	Ground	Line pressure solenoid valve	Output	- After engine warming up - Selector lever: "N" position - At idle	 JSDIA1897GB
				- After engine warming up - Selector lever: "N" position - Depress the accelerator pedal fully	 JSDIA1898GB
31 (L/W)	—	ROM ASSY (CLOCK)	—	—	—
33 (L/G)	—	CAN-H	Input/ Output	—	—
34 (W)	Ground	Secondary speed sensor	Input	- Selector lever: "L" position - Vehicle speed: 20 km/h (12 MPH)	 JSDIA1905GB
35 (LG/R)	Ground	Primary speed sensor	Input	- Selector lever: "L" position - Vehicle speed: 20 km/h (12 MPH)	 JSDIA1906GB
37 (BR/W)	Ground	High clutch & reverse brake solenoid valve	Output	In driving at "L" position	 JSDIA1897GB
				Release the accelerator pedal after the following conditions are satisfied - Selector lever: "D" position - Accelerator pedal position: 1/8 or less - Vehicle speed: 50 km/h (31 MPH) or more	 JSDIA3653GB

TCM

< ECU DIAGNOSIS INFORMATION >

[CVT: RE0F11A]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	–	Signal	Input/ Output		
38 (G)	Ground	Torque converter clutch solenoid valve	Output	- Selector lever: "D" position - Accelerator pedal position: 1/8 or less - Vehicle speed: 20 km/h (12 MPH) or more	
				- Engine started - Vehicle is stopped	
39 (G/B)	Ground	Low brake solenoid valve	Output	- Selector lever: "L" position - Vehicle speed: 20 km/h (12 MPH)	
				Release the accelerator pedal after the following conditions are satisfied - Selector lever: "D" position - Accelerator pedal position: 1/8 or less - Vehicle speed: 50 km/h (31 MPH) or more	
40 (Y/B)	Ground	Primary pressure solenoid valve	Output	- Selector lever: "L" position - Vehicle speed: 20 km/h (12 MPH)	
41 (B)	Ground	Ground	Output	Always	0 V
42 (B)	Ground	Ground	Output	Always	0 V
45 (LG)	Ground	Battery power supply (memory back-up)	Input	Always	10 – 16 V
46 (LG)	Ground	Battery power supply (memory back-up)	Input	Always	10 – 16 V
47 (R/W)	Ground	Ignition power supply	Input	Ignition switch: ON	10 – 16 V
				Ignition switch: OFF	0 V

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	–	Signal	Input/ Output		
48 (R)	Ground	Ignition power supply	Input	Ignition switch: ON	10 – 16 V
				Ignition switch: OFF	0 V

*: This harness is not used.

Fail-safe

INFOID:000000009019629

TCM has a fail-safe mode. The mode functions so that operation can be continued even if the signal circuit of the main electronically controlled input/output parts is damaged.

If the vehicle shows following behaviors including “poor acceleration”, a malfunction of the applicable system is detected by TCM and the vehicle may be in a fail-safe mode. At this time, check the DTC code and perform inspection and repair according to the malfunction diagnosis procedures.

Fail-safe function

DTC	Vehicle behavior	Conditions of vehicle
P062F	Not changed from normal driving	—
P0705	- Shift position indicator on combination meter is not displayed. - Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed	—
P0706	- Shift position indicator on combination meter is not displayed. - Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed	—
P0711	Acceleration is slow	Engine coolant temperature when engine start: Temp. $\geq 10^{\circ}\text{C}$ (50°F)
	- Selector shock is large - Start is slow	Engine coolant temperature when engine start: -35°C (-31°F) $\leq$ Temp. $< 10^{\circ}\text{C}$ (50°F)
	- Selector shock is large - Start is slow	Engine coolant temperature when engine start: Temp. $< -35^{\circ}\text{C}$ (-31°F)
P0712	Acceleration is slow	Engine coolant temperature when engine start: Temp. $\geq 10^{\circ}\text{C}$ (50°F)
	- Selector shock is large - Start is slow	Engine coolant temperature when engine start: -35°C (-31°F) $\leq$ Temp. $< 10^{\circ}\text{C}$ (50°F)
	- Selector shock is large - Start is slow	Engine coolant temperature when engine start: Temp. $< -35^{\circ}\text{C}$ (-31°F)
P0713	Acceleration is slow	Engine coolant temperature when engine start: Temp. $\geq 10^{\circ}\text{C}$ (50°F)
	- Selector shock is large - Start is slow	Engine coolant temperature when engine start: -35°C (-31°F) $\leq$ Temp. $< 10^{\circ}\text{C}$ (50°F)
	- Selector shock is large - Start is slow	Engine coolant temperature when engine start: Temp. $< -35^{\circ}\text{C}$ (-31°F)
P0715	- Selector shock is large - Start is slow - Acceleration is slow - Vehicle speed is not increased - Lock-up is not performed	—

DTC	Vehicle behavior	Conditions of vehicle	
P0720	- Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed	—	A
P0740	Lock-up is not performed	—	B
P0743	Lock-up is not performed	—	
P0744	Lock-up is not performed	—	C
P0746	- Selector shock is large - Start is slow - Acceleration is slow - Vehicle speed is not increased - Lock-up is not performed	—	TM
P0846	- Start is slow - Acceleration is slow	—	E
P0847	Acceleration is slow	—	
P0848	- Start is slow - Acceleration is slow	—	F
P0863	Not changed from normal driving	—	
P0890	- Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed	—	G
P0962	- Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed	—	H
P0963	- Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed	—	I
P0965	- Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed	—	J
P0966	- Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed	—	K
P0967	- Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed	—	L
P0998	- Start is slow - Lock-up is not performed	—	M
P0999	- Start is slow - Lock-up is not performed	Wire disconnection	N
	- Vehicle speed is not increased - Lock-up is not performed	Voltage shorting	O
P099B	Start is slow	—	P
P099C	- Start is slow - Lock-up is not performed	Wire disconnection	
	- Vehicle speed is not increased - Lock-up is not performed	Voltage shorting	
P1586	Idle neutral control is not performed	—	
P1588	Idle neutral control is not performed	—	

DTC	Vehicle behavior	Conditions of vehicle
P2765	• Selector shock is large • Start is slow • Acceleration is slow • Vehicle speed is not increased • Lock-up is not performed	—
P2857	• Start is slow • Lock-up is not performed	—
P2858	• Vehicle speed is not increased • Lock-up is not performed	—
P2859	Vehicle speed is not increased	—
P285A	Start is slow	—
U0073	• Selector shock is large • Start is slow • Acceleration is slow • Lock-up is not performed	—
U0100	• Selector shock is large • Start is slow • Acceleration is slow • Lock-up is not performed	—
U0140	Not changed from normal driving	—
U0141	Not changed from normal driving	—
U0155	Not changed from normal driving	—
U0300	• Selector shock is large • Start is slow • Acceleration is slow • Lock-up is not performed	—
U1000	Not changed from normal driving	—
U1114	Not changed from normal driving	—
U1117	Not changed from normal driving	—

Protection Control

INFOID:000000009019630

The TCM becomes the protection control status temporarily to protect the safety when the safety of TCM and transmission is lost. It automatically returns to the normal status if the safety is secured.
The TCM has the following protection control.

CONTROL FOR WHEEL SPIN

Control	When a wheel spin is detected, the engine output and gear ratio are limited and the line pressure is increased. At the 1GR, the clutch pressure is increased.
Vehicle behavior in control	If the accelerator is kept depressing during wheel spin, the engine revolution and vehicle speed are limited to a certain degree. From the 1GR, upshift to a certain gear ratio is only allowed.
Normal return condition	Wheel spin convergence returns the control to the normal control.

CONTROL WHEN FLUID TEMPERATURE IS HIGH

Control	When the CVT fluid temperature is high, the gear shift permission maximum revolution and the maximum torque are reduced than usual to prevent increase of the oil temperature.
Vehicle behavior in control	Power performance may be lowered, compared to normal control.
Normal return condition	The control returns to the normal control when CVT fluid temperature is lowered.

TORQUE IS REDUCED WHEN DRIVING WITH THE REVERSE GEAR

Control	Engine output is controlled according to a vehicle speed while reversing the vehicle.
Vehicle behavior in control	Power performance may be lowered while reversing the vehicle.
Normal return condition	Torque returns to normal by positioning the selector lever in a range other than "R" position.

REVERSE PROHIBIT CONTROL

Control	The reverse brake is controlled to avoid becoming engaged when the selector lever is set in "R" position while driving in forward direction at more than the specified speed.
Vehicle behavior in control	If the selector lever is put at "R" position when driving with the forward gear, the gear becomes neutral, not reverse.
Normal return condition	The control returns to normal control when the vehicle is driven at low speeds. (The reverse brake becomes engaged.)

DTC Inspection Priority Chart

INFOID:000000009019631

If multiple malfunction codes are detected at the same time, check each code according to the DTC check priority list below.

Priority	DTC (Diagnostic Trouble Code)	Reference
1	P0863 CONTROL UNIT (CAN)	TM-179
	U0073 COMM BUS A OFF	TM-134
	U0100 LOST COMM (ECM A)	TM-135
	U0140 LOST COMM (BCM)	TM-136
	U0141 LOST COMM (BCM A)	TM-137
	U0155 LOST COMM (IPC)	TM-138
	U0300 CAN COMM DATA	TM-139
	U1000 CAN COMM CIRC	TM-140
	U1117 LOST COMM (ABS)	TM-141
2	P0740 TORQUE CONVERTER	TM-165
	P0743 TORQUE CONVERTER	TM-167
	P0962 PC SOLENOID A	TM-182
	P0963 PC SOLENOID A	TM-184
	P0966 PC SOLENOID B	TM-187
	P0967 PC SOLENOID B	TM-189
	P0998 SHIFT SOLENOID F	TM-191
	P0999 SHIFT SOLENOID F	TM-193
	P099B SHIFT SOLENOID G	TM-195
	P099C SHIFT SOLENOID G	TM-197
3	P0890 TCM	TM-180

TCM

< ECU DIAGNOSIS INFORMATION >

[CVT: RE0F11A]

Priority	DTC (Diagnostic Trouble Code)	Reference
4	P062F EEPROM	TM-142
	P0705 T/M RANGE SENSOR A	TM-143
	P0706 T/M RANGE SENSOR A	TM-149
	P0711 FLUID TEMP SENSOR A	TM-152
	P0712 FLUID TEMP SENSOR A	TM-155
	P0713 FLUID TEMP SENSOR A	TM-157
	P0715 INPUT SPEED SENSOR A	TM-159
	P0847 FLUID PRESS SEN/SW B	TM-175
	P0848 FLUID PRESS SEN/SW B	TM-177
	P1586 G SENSOR	TM-199
	P1588 G SENSOR	TM-202
	P2765 OUTPUT SPEED SENSOR	TM-204
5	P0720 OUTPUT SPEED SENSOR	TM-162
6	P0746 PC SOLENOID A	TM-171
	P2857 CLUTCH B PRESSURE	TM-207
	P2858 CLUTCH A PRESSURE	TM-208
	P2859 CLUTCH A PRESSURE	TM-209
	P285A CLUTCH B PRESSURE	TM-211
7	P0744 TORQUE CONVERTER	TM-169
	P0846 FLUID PRESS SEN/SW B	TM-173
	P0965 PC SOLENOID B	TM-186

DTC Index

INFOID:000000009019632

NOTE:

- If multiple malfunction codes are detected at the same time, check each code according to the “DTC check priority list”. [TM-111, "DTC Inspection Priority Chart"](#).
- The ignition counter is displayed in “FFD”. Refer to [TM-93, "CONSULT Function"](#).

DTC*1, *2		Items (CONSULT screen terms)	Trip	MIL	Reference
GST	CONSULT (TRANSMISSION)				
P062F	P062F	EEPROM	1	ON	TM-142
P0705	P0705	T/M RANGE SENSOR A	2	ON	TM-143
P0706	P0706	T/M RANGE SENSOR A	2	ON	TM-149
P0711	P0711	FLUID TEMP SENSOR A	2	ON	TM-152
P0712	P0712	FLUID TEMP SENSOR A	2	ON	TM-155
P0713	P0713	FLUID TEMP SENSOR A	2	ON	TM-157
P0715	P0715	INPUT SPEED SENSOR A	2	ON	TM-159
P0720	P0720	OUTPUT SPEED SENSOR	2	ON	TM-162
P0740	P0740	TORQUE CONVERTER	2	ON	TM-165
P0743	P0743	TORQUE CONVERTER	2	ON	TM-167
P0744	P0744	TORQUE CONVERTER	2	ON	TM-169
P0746	P0746	PC SOLENOID A	2	ON	TM-171
P0846	P0846	FLUID PRESS SEN/SW B	2	ON	TM-173
P0847	P0847	FLUID PRESS SEN/SW B	2	ON	TM-175
P0848	P0848	FLUID PRESS SEN/SW B	2	ON	TM-177

TCM

< ECU DIAGNOSIS INFORMATION >

[CVT: RE0F11A]

DTC*1, *2		Items (CONSULT screen terms)	Trip	MIL	Reference
GST	CONSULT (TRANSMISSION)				
P0863	P0863	CONTROL UNIT (CAN)	1	ON	TM-179
P0890	P0890	TCM	1	ON	TM-180
P0962	P0962	PC SOLENOID A	2	ON	TM-182
P0963	P0963	PC SOLENOID A	2	ON	TM-184
P0965	P0965	PC SOLENOID B	2	ON	TM-186
P0966	P0966	PC SOLENOID B	2	ON	TM-187
P0967	P0967	PC SOLENOID B	2	ON	TM-189
P0998	P0998	SHIFT SOLENOID F	2	ON	TM-191
P0999	P0999	SHIFT SOLENOID F	2	ON	TM-193
P099B	P099B	SHIFT SOLENOID G	2	ON	TM-195
P099C	P099C	SHIFT SOLENOID G	2	ON	TM-197
—	P1586	G SENSOR	1	—	TM-199
—	P1588	G SENSOR	1	—	TM-202
P2765	P2765	OUTPUT SPEED SENSOR	2	ON	TM-204
P2857	P2857	CLUTCH A PRESSURE	2	ON	TM-207
P2858	P2858	CLUTCH B PRESSURE	2	ON	TM-208
P2859	P2859	CLUTCH A PRESSURE	2	ON	TM-209
P285A	P285A	CLUTCH B PRESSURE	2	ON	TM-211
U0073	U0073	COMM BUS A OFF	1	ON	TM-134
U0100	U0100	LOST COMM (ECM A)	1	ON	TM-135
—	U0140	LOST COMM (BCM)	1	—	TM-136
—	U0141	LOST COMM (BCM A)	1	—	TM-137
—	U0155	LOST COMM (IPC)	1	—	TM-138
—	U0300	CAN COMM DATA	1	—	TM-139
—	U1000	CAN COMM CIRC	1	—	TM-140
—	U1117	LOST COMM (ABS)	1	—	TM-141

*1: These numbers are specified by SAE J2012/ISO 15031-6.

*2: The DTC number of the 1st trip is the same as the DTC number.


WIRING DIAGRAM

CVT CONTROL SYSTEM

Wiring Diagram

INFOID:000000009019633

CVT CONTROL SYSTEM




ABDWA0681GB

CVT CONTROL SYSTEM

< WIRING DIAGRAM >

[CVT: RE0F11A]

EN : WITHOUT NAVI
NV : WITH NAVI



ABDWA0682GB

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P


CVT CONTROL SYSTEM

< WIRING DIAGRAM >

[CVT: RE0F11A]


CVT CONTROL SYSTEM CONNECTORS

Connector No.	M8
Connector Name	JOINT CONNECTOR-M02
Connector Color	GREEN




Terminal No.	Color of Wire	Signal Name
8	L	-
9	L	-
19	P	-
20	P	-

Connector No.	M10
Connector Name	JOINT CONNECTOR-M01
Connector Color	BLUE




Terminal No.	Color of Wire	Signal Name
4	L	-
8	L	-
13	P	-
17	P	-

Connector No.	M24
Connector Name	COMBINATION METER
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	L	CAN-H
2	P	CAN-L
8	P	O/D OFF
21	B	GND (ILL)
22	B	GND (POWER)
23	B	GND (CIRCUIT)
27	R/W	BAT
28	GR	IGN

Connector No.	M38
Connector Name	CVT SHIFT SELECTOR
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	P	-
2	B/W	-

Connector No.	M51
Connector Name	JOINT CONNECTOR-M04
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
1	LG	-
12	R/W	-

CVT CONTROL SYSTEM

< WIRING DIAGRAM >

[CVT: RE0F11A]



ABDIA1063GB

CVT CONTROL SYSTEM

< WIRING DIAGRAM >

[CVT: RE0F11A]

Connector No.	E55
Connector Name	WIRE TO WIRE
Connector Color	GRAY



1	2	3	4	5
6	7	8	9	10
11	12			

Terminal No.	Color of Wire	Signal Name
1	P	—
7	R	—

Connector No.	E45
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN



21	20	19	18	17
28	27	26	25	24
23	22			

Terminal No.	Color of Wire	Signal Name
21	R	AT ECU (WITH CVT)

Connector No.	E14
Connector Name	JOINT CONNECTOR-E03
Connector Color	BLUE



12	11	10	9	8	7	6	5	4	3	2	1
----	----	----	---	---	---	---	---	---	---	---	---

Terminal No.	Color of Wire	Signal Name
2	P	—
5	P	—
9	L	—
12	L	—

Connector No.	F41
Connector Name	OUTPUT SPEED SENSOR
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	B	—
2	BR	—
3	R/W	—

Connector No.	F8
Connector Name	WIRE TO WIRE
Connector Color	WHITE



12	11	10	9	8	7	6	5	4	3	2	1
24	23	22	21	20	19	18	17	16	15	14	13

Terminal No.	Color of Wire	Signal Name
5	B	—
6	P/L	—
7	L/G	—
16	G/R	—
17	O	—
18	LG	—

ABDIA1064GB

CVT CONTROL SYSTEM


< WIRING DIAGRAM >

[CVT: RE0F11A]

Terminal No.	Color of Wire	Signal Name
33	L/G	CAN-H
34	W	SECONDARY SPEED SENSOR
35	LG/R	PRIMARY SPEED SENSOR
36	—	—
37	BR/W	HIGH CLUTCH & REVERSE BRAKE SOLENOID VALVE
38	G	TORQUE CONVERTER CLUTCH SOLENOID VALVE
39	G/B	LOW BRAKE SOLENOID VALVE
40	Y/B	PRIMARY PRESSURE SOLENOID VALVE
41	B	GROUND
42	B	GROUND
43	—	—
44	—	—
45	LG	POWER SUPPLY (BACKUP)
46	LG	POWER SUPPLY (BACKUP)
47	R	POWER SUPPLY
48	R/W	POWER SUPPLY

Terminal No.	Color of Wire	Signal Name
13	—	—
14	G/R	G SENSOR
15	V	—
16	L/R	SECONDARY PRESSURE SENSOR
17	—	—
18	—	—
19	—	—
20	—	—
21	R/W	ROM ASSY (CHIP SELECT)
22	V	ROM ASSY (DATA I/O)
23	P/L	CAN-L
24	BR	OUTPUT SPEED SENSOR
25	—	—
26	O/W	SENSOR POWER SUPPLY
27	—	—
28	—	—
29	—	—
30	BR/B	LINE PRESSURE SOLENOID VALVE
31	L/W	ROM ASSY (CLOCK)
32	—	—

Connector No.	F44
Connector Name	TCM (TRANSMISSION CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	—	—
2	R/B	L RANGE SWITCH
3	—	—
4	W/B	D RANGE SWITCH
5	L/B	N RANGE SWITCH
6	O	R RANGE SWITCH
7	Y	P RANGE SWITCH
8	—	—
9	—	—
10	—	—
11	LG	SENSOR GROUND
12	G/W	CVT FLUID TEMPERATURE SENSOR


ABDIA1065GB

CVT CONTROL SYSTEM

< WIRING DIAGRAM >

[CVT: RE0F11A]

Connector No.	F46
Connector Name	CVT UNIT
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	-	-
2	-	-
3	-	-
4	-	-
5	-	-
6	-	-


Terminal No.	Color of Wire	Signal Name
7	-	-
8	-	-
9	-	-
10	-	-
11	-	-
12	-	-
13	-	-
14	-	-
15	-	-
16	-	-
17	-	-
18	-	-
19	-	-
20	-	-
21	-	-
22	-	-

Connector No.	F48
Connector Name	SECONDARY SPEED SENSOR
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	B	-
2	W	-
3	R	-

Connector No.	F49
Connector Name	TRANSMISSION RANGE SWITCH
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	-	-
2	W/B	-
3	-	-
4	R/W	-
5	Y	-
6	R/B	-
7	R	-
8	O	-
9	L/B	-
10	BR	-

Connector No.	F50
Connector Name	PRIMARY SPEED SENSOR
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	B	-
2	LG/R	-
3	R	-

Connector No.	F55
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	LG	-
7	R	-

ABDIA1066GB

CVT SHIFT LOCK SYSTEM

< WIRING DIAGRAM >


[CVT: RE0F11A]

CVT SHIFT LOCK SYSTEM

Wiring Diagram

INFOID:000000009019634

CVT SHIFT LOCK SYSTEM



ABDWA0683GB


CVT SHIFT LOCK SYSTEM

< WIRING DIAGRAM >

[CVT: RE0F11A]


CVT SHIFT LOCK SYSTEM CONNECTORS

Connector No.	M5
Connector Name	JOINT CONNECTOR-M03
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
2	O	—
3	L	—

Connector No.	M38
Connector Name	CVT SHIFT SELECTOR
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	LG	—
6	B/W	—

Connector No.	M69
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
42A	LG	—
45A	L	—

ABDIA1067GB

CVT SHIFT LOCK SYSTEM

< WIRING DIAGRAM >

[CVT: RE0F11A]



A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

BASIC INSPECTION

DIAGNOSIS AND REPAIR WORK FLOW

Flowchart of Trouble Diagnosis

INFOID:000000009019635

NOTE:

"DTC" includes DTC at the 1st trip.

1.OBTAIN INFORMATION ABOUT SYMPTOM

Refer to [TM-125, "Question sheet"](#) and interview the customer to obtain the malfunction information (conditions and environment when the malfunction occurred) as much as possible when the customer brings in the vehicle.

>> GO TO 2.

2.CHECK DTC

1. Before checking the malfunction, check whether any DTC exists.
2. If DTC exists, perform the following operations.
 - Records the DTCs. (Print out using CONSULT and affix to the Work Order Sheet.)
 - Erase DTCs.
 - Check the relation between the cause found by DTC and the malfunction information from customer. [TM-221, "Symptom Table"](#) can be used effectively.
3. Check the relevant information including STI, etc.

Do malfunction information and DTC exist?

Malfunction information and DTC exist.>>GO TO 3.

Malfunction information exists but no DTC.>>GO TO 4.

No malfunction information, but DTC exists.>>GO TO 5.

3.REPRODUCE MALFUCTION SYSTEM

Check the malfunction described by the customer on the vehicle.

Check if the behavior is fail safe or normal operation. Refer to [TM-108, "Fail-safe"](#).

Interview sheet can be used effectively when reproduce malfunction conditions. Refer to [TM-125, "Question sheet"](#).

Verify the relationship between the symptom and the conditions in which the malfunction described by the customer occurs.

>> GO TO 5.

4.REPRODUCE MALFUNCTION SYMPTOM

Check the malfunction described by the customer on the vehicle.

Check if the behavior is fail safe or normal operation. Refer to [TM-108, "Fail-safe"](#).

Interview sheet can be used effectively when reproduce malfunction conditions. [TM-125, "Question sheet"](#).

Verify the relationship between the symptom and the conditions in which the malfunction described by the customer occurs.

>> GO TO 6.

5.PERFORM "DTC CONFIRMATION PROCEDURE"

Perform "DTC CONFIRMATION PROCEDURE" of the appropriate DTC to check if DTC is detected again.

Refer to [TM-111, "DTC Inspection Priority Chart"](#) when multiple DTCs are detected, and then determine the order for performing the diagnosis.

Is any DTC detected?

YES >> GO TO 7.

NO >> Follow [GI-41, "Intermittent Incident"](#) to check.

6.IDENTIFY MALFUNCTIONING SYSTEM WITH "DIAGNOSIS CHART BY SYMPTOM"

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[CVT: RE0F11A]

Use [TM-221, "Symptom Table"](#) from the symptom inspection result in step 4. Then identify where to start performing the diagnosis based on possible causes and symptoms.

>> GO TO 8.

7. REPAIR OR REPLACE THE MALFUNCTIONING PARTS

Repair or replace the detected malfunctioning parts.

Reconnect parts or connector after repairing or replacing, and then erase DTC if necessary.

>> GO TO 8.

8. FINAL CHECK

Perform "DTC CONFIRMATION PROCEDURE" again to make sure that the repair is correctly performed. Check that malfunctions are not reproduced when obtaining the malfunction information from the customer, referring to the symptom inspection result in step 3 or 4.

Is DTC or malfunction symptom reproduced?

YES-1 (DTC is reproduced.)>>GO TO 5.

YES-2 (Malfunction is reproduced.)>>GO TO 6.

NO >> Before delivering the vehicle to the customer, make sure that DTC is erased.

Question sheet

INFOID:0000000009019636

DESCRIPTION

There are many operating conditions that may cause a malfunction of the transmission parts. By understanding those conditions properly, a quick and exact diagnosis can be achieved.

In general, perception of a problem varies depending on individuals. Ask the customer about his/her concerns carefully. It is important to understand the phenomenon or status. To systemize all the information for the diagnosis, prepare the question sheet referring to the question points.

In some cases, multiple conditions that appear simultaneously may cause a DTC to be detected.

KEY POINTS

WHAT Vehicle & engine model
WHEN Date, Frequencies
WHERE..... Road conditions
HOW Operating conditions,
Weather conditions,
Symptoms

SEF907L

Worksheet Sample

Question sheet						
Customer's name	MR/MS	Registration number		Initial year registration	Year	Month day
		Vehicle type		Chassis No.		
Storage date	Year	Month day	Engine	Mileage		km
Symptom			☐ Vehicle does not start. (☐ R position ☐ D position ☐ L position ☐ M position)			
			☐ Upshifting does not occur. ☐ Downshifting does not occur.			
			☐ Lock-up malfunction			
			☐ Shift point is too high. ☐ Shift point is too low.			
			☐ Shift shock (☐ N⇒D ☐ Lock-up ☐ R, D, L and M position)			
			☐ Slip (☐ N⇒D ☐ Lock-up ☐ R, D, L and M position)			
			☐ Noise ☐ Vibration			
			When selector lever position is shifted, shift pattern does not change.			
			☐ Other ()			
First occurrence			☐ Recently (as from month of year)			
Frequency of occurrence			☐ Always ☐ Under certain conditions ☐ Sometimes (time(s)/day)			

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[CVT: RE0F11A]

Question sheet						
Customer's name	MR/MS	Registration number		Initial year registration	Year	Month day
		Vehicle type		Chassis No.		
Storage date	Year	Month day	Engine		Mileage	km
Climate conditions		Irrelevant				
Weather		☐ Clear ☐ Cloud ☐ Rain ☐ Snow ☐ Others)				
Temperature		☐ Hot ☐ Warm ☐ Cool ☐ Cold ☐ Temperature (Approx. °C)				
Relative humidity		☐ High ☐ Moderate ☐ Low				
Transaxle condition		☐ In cold-start ☐ During warm-up (approx. °C) ☐ After warm-up ☐ Engine speed: rpm				
Road conditions		☐ Urban area ☐ Suburb area ☐ Highway ☐ Mountainous road (uphill or downhill)				
Operating condition, etc.		Irrelevant ☐ When engine starts ☐ During idling ☐ During driving ☐ During acceleration ☐ At constant speed driving ☐ During deceleration ☐ During cornering (RH curve or LH curve)				
Other conditions						

ADDITIONAL SERVICE WHEN REPLACING TCM

< BASIC INSPECTION >

[CVT: RE0F11A]

ADDITIONAL SERVICE WHEN REPLACING TCM

Description

INFOID:0000000009019637

When replacing the TCM, perform the following work.

CHECK LOADING OF CALIBRATION DATA

- The TCM acquires calibration data (individual characteristic value) of each solenoid that is stored in the ROM assembly (in the control valve). This enables the TCM to perform accurate control. After the TCM is replaced, check that the TCM has correctly loaded the calibration data.

CALIBRATION OF G SENSOR

- TCM stores calibration data (inherent characteristic value) of G sensor to provide accurate control. Therefore, it is required to perform calibration of G sensor after the replacement of TCM.

CAUTION:

When replacing TCM and transaxle assembly as a set, replace transaxle assembly first and then replace TCM.

If the TCM is replaced in advance, perform "ADDITIONAL SERVICE WHEN REPLACING TRANSAXLE ASSEMBLY" after "G sensor calibration".

Procedure

INFOID:0000000009019638

1.CHECK WORK CONTENTS

Replacing only the TCM>>GO TO 2.

Replacing the TCM after the transaxle assembly is replaced>>GO TO 2.

Replacing the transaxle assembly after the TCM is replaced>>GO TO 5.

2.LOADING OF CALIBRATION DATA

1. Shift the selector lever to the "P" position.
2. Turn ignition switch ON.
3. Check that "P" is displayed on shift position indicator on combination meter.

NOTE:

Displayed approximately 4 – 5 seconds after the selector lever is moved to the "P" position.

Does the shift position indicator display "P"?

YES >> GO TO 3.

NO >> GO TO 4.

3.PERFORM G SENSOR CALIBRATION

Refer to [TM-130. "Procedure"](#).

>> WORK END

4.DETECT MALFUNCTIONING ITEM

Check the following items:

- Harness between the TCM and the ROM assembly inside the transaxle assembly is open or shorted.
- Disconnected, loose, bent, collapsed, or otherwise abnormal connector housing terminals

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

5.PERFORM G SENSOR CALIBRATION

Refer to [TM-130. "Procedure"](#).

>> Perform "ADDITIONAL SERVICE WHEN REPLACING TRANSAXLE ASSEMBLY" after "CALIBRATION OF G SENSOR". Refer to [TM-128. "Procedure"](#).

ADDITIONAL SERVICE WHEN REPLACING TRANSAXLE ASSEMBLY

< BASIC INSPECTION >

[CVT: RE0F11A]

ADDITIONAL SERVICE WHEN REPLACING TRANSAXLE ASSEMBLY

Description

INFOID:000000009019639

When replacing the transaxle, perform the following work.

ERASING THE CALIBRATION DATA

- The TCM acquires calibration data (individual characteristic value) of each solenoid that is stored in the ROM assembly (in the control valve). This enables the TCM to perform accurate control. For this reason, after the transaxle assembly is replaced, it is necessary to erase the calibration data that is stored in the TCM and load new calibration data.

ERASING THE LEARNED VALUE DATA

- TCM learns indicated pressure for appropriate control of the transaxle assembly and records the learned values. For this reason, the learned values stored in TCM must be erased after replacing a transaxle assembly.

ERASING CVT FLUID DEGRADATION LEVEL DATA

- TCM records the degradation level of the CVT fluid calculated from the vehicle driving status. Therefore, if the transaxle assembly is replaced, it is necessary to erase the CVT fluid degradation level data recorded by TCM.

Procedure

INFOID:000000009019640

1. INITIALIZE TCM

Ⓐ With CONSULT

1. Set parking brake.
2. Turn ignition switch ON.
3. Select "Work Support" in "TRANSMISSION".
4. Select "ERASE MEMORY DATA".
5. While maintaining the conditions below, touch "Start".
 - Vehicle stop status
 - With engine stopped
 - Selector lever: "R" position
 - Accelerator pedal: Depressed

NOTE:

Select "Start" and complete within approximately 20 seconds.

Is "COMPLETED" displayed?

YES >> GO TO 2.

NO >> Turn the ignition switch OFF and wait for a minimum of 10 seconds then perform the work again.

2. CHECK AFTER TCM IS INITIALIZED

Ⓐ With CONSULT

1. Turn ignition switch OFF with the selector lever in "R" position and wait for 10 seconds or more.
2. Turn ignition switch ON with the selector lever in "R" position.

CAUTION:

Never start the engine.

3. Select "Special function" in "TRANSMISSION".
4. Select "CALIB DATA".
5. Check that indicated value of "CALIB DATA" is equal to the value shown in the following table.

Item name	Display value	Item name	Display value
UNIT CLB ID1	00	MAP NO HC/RB	00
UNIT CLB ID2	00	MAP NO L/B	00
UNIT CLB ID3	00	OFFSET2 LU	0
UNIT CLB ID4	00	OFFSET2 PL	0
UNIT CLB ID5	00	OFFSET2 PRI	0
UNIT CLB ID6	00	OFFSET2 H/R	0

#

CALIBRATION OF G SENSOR

Description

INFOID:000000009019641

TCM stores calibration data (inherent characteristic value) of G sensor to provide accurate control. Therefore, it is required to perform calibration of G sensor after the following work is performed.

- Removal/installation or replacement of G sensor
- Replacement of TCM

Procedure

INFOID:000000009019642

1. PREPARATION BEFORE CALIBRATION PROCEDURE

1. Park the vehicle on a level surface.
2. Adjust air pressure of all tires to the specified pressure. [WT-50. "Tire Air Pressure"](#).

>> GO TO 2.

2. PERFORM CALIBRATION

④ With CONSULT

1. Turn ignition switch ON.
CAUTION:
Never start engine.
2. Select "Work Support" in "TRANSMISSION".
3. Select "G SENSOR CALIBRATION".
4. Touch "Start".
CAUTION:
Never swing the vehicle during "G sensor calibration".

Is "COMPLETED" displayed?

- YES >> GO TO 3.
NO >> Perform steps 1 and 2 again.

3. PERFORM THE SELF-DIAGNOSIS

④ With CONSULT

1. Turn ignition switch OFF and wait for 10 seconds.
2. Turn ignition switch ON.
3. Select "Self Diagnostic Results" in "TRANSMISSION".

Is "P1586" or "P1588" detected?

- YES >> Go to [TM-112. "DTC Index"](#).
NO >> Calibration end

STALL TEST

< BASIC INSPECTION >

[CVT: RE0F11A]

STALL TEST

Work Procedure

INFOID:000000009019645

INSPECTION

1. Check the engine oil level. Replenish if necessary.
2. Check for leak of the CVT fluid. Refer to [TM-226, "Inspection"](#).
3. Drive for about 10 minutes to warm up the vehicle so that the CVT fluid temperature is 50 to 80°C (122 to 176°F).
4. Be sure to apply the parking brake and block the tires.
5. Start the engine, depress the brake pedal and put the selector lever to the D position.
6. While depressing the brake pedal, depress the accelerator pedal gradually.
7. Read the stall speed quickly. Then, release your foot from the accelerator pedal quickly.

CAUTION:

Do not depress the accelerator pedal for 5 seconds or more during the test.

Stall speed : Refer to [TM-256, "Stall Speed"](#).

8. Place the selector lever in the N position.
9. Cool the CVT fluid.
- CAUTION:**
Run the engine with the idle speed for at least 1 minute.
10. Put the selector lever to the R position and perform Step 6 to Step 9 again.

NARROWING-DOWN MALFUNCTIONING PARTS

	Selector lever position		Possible cause
	D	R	
Stall speed	H	O	• Low brake
	O	H	• Reverse brake
	L	L	• Engine • Torque converter one way clutch
	H	H	• Line pressure is low. • Primary pulley • Secondary pulley • Steel belt

O: Within the stall speed standard value

H: Stall speed is higher than the standard value.

L: Stall speed is lower than the standard value.

LINE PRESSURE TEST

< BASIC INSPECTION >

[CVT: RE0F11A]

LINE PRESSURE TEST

Work Procedure

INFOID:000000009019646

INSPECTION

1. Check the engine oil level. Replenish if necessary. Refer to [LU-7, "Inspection"](#).
2. Check for CVT fluid leaks. Refer to [TM-226, "Inspection"](#).
3. Drive for about 10 minutes to warm up the vehicle so that the CVT fluid temperature is 50 to 80°C (122 to 176°F).
4. Stop the vehicle, apply the parking brake and block the tires.
5. Start the engine.
6. Select "Data Monitor" in "TRANSMISSION".
7. Select "LINE PRESSURE".
8. Measure the line pressure at both idle and the stall speed.

CAUTION:

Keep brake pedal pressed all the way down during measurement.

Line pressure : [TM-257, "Line Pressure"](#)

NARROWING-DOWN MALFUNCTIONING PARTS


Judgment		Possible cause
Idle speed	Low for all positions ("P", "R", "N", "D", "L")	Possible causes include malfunctions in the pressure supply system and low oil pump output. For example: • Oil pump wear • Damage of chain and sprocket • Pressure regulator valve or plug sticking or spring fatigue • Oil strainer ⇒ oil pump ⇒ pressure regulator valve passage oil leak • Engine idle speed too low
	Only low for a specific position	Possible causes include an oil pressure leak in a passage or device related to the position after the pressure is distributed by the manual valve.
	High	Possible causes include a sensor malfunction or malfunction in the line pressure adjustment function. For example: • Accelerator pedal position signal malfunction • CVT fluid temperature sensor malfunction • Line pressure solenoid malfunction (sticking in OFF state, filter clog, cut line) • Pressure regulator valve or plug sticking
Stall speed	Line pressure does not rise higher than the line pressure for idle.	Possible causes include a sensor malfunction or malfunction in the pressure adjustment function. For example: • TCM malfunction • Line pressure solenoid malfunction (shorting, sticking in ON state) • Pressure regulator valve or plug sticking
	The pressure rises, but does not enter the standard position.	Possible causes include malfunctions in the pressure supply system and malfunction in the pressure adjustment function. For example: • Oil pump wear • Line pressure solenoid malfunction (sticking, filter clog) • Pressure regulator valve or plug sticking
	Only low for a specific position	Possible causes include an oil pressure leak in a passage or device related to the position after the pressure is distributed by the manual valve.

CVT POSITION

Inspection

INFOID:000000009020085

1. Turn ON the ignition switch with the shift selector in the "P" position.
2. Press the shift selector handle button with the brake pedal depressed, and confirm that the shift selector can be moved from the "P" position. Also confirm that shift selector will not move from the "P" position without depressing the brake pedal.
3. Move the shift selector and check for "excessive effort," "sticking," "noise" or "rattle".
4. Confirm that shift selector stops at each position with the feel of engagement when it is moved through all the positions. Check whether or not the actual position the shift selector is in matches the position shown by the transaxle body.
5. The method of operating the shift selector to individual positions correctly should be as shown.
 - (A): Press shift selector button to operate shift selector, while depressing the brake pedal.
 - (B): Press shift selector button to operate shift selector.
 - (C): Shift selector can be operated without pressing shift selector button.
6. When the shift selector handle button is pressed without applying forward/backward force to the shift selector at "P", "R", "N" and "D" positions, there should be no "sticking" of the button.
7. Confirm the back-up lamps illuminate only when shift selector is placed in the "R" position. Confirm the back-up lamps do not illuminate when the shift selector is pushed toward the "R" position side when shift selector is in the "P" or "N" position.
8. Check that the engine can be started only when the shift selector is in the "P" and "N" positions.
9. Check that the transaxle is locked when the shift selector is in the "P" position.



Adjustment


INFOID:000000009020084

1. Move the shift selector to the "P" position.

CAUTION:
Rotate the wheels at least a quarter turn and be certain the transaxle is locked in the "P" position.
2. Remove nut (A) and set manual lever (B) to the "P" position.

CAUTION:
Do not apply force to the manual lever.
3. Tighten nuts to the specified torque. Refer to [TM-232, "Exploded View"](#).

CAUTION:
Do not move the manual lever when tightening.



DTC/CIRCUIT DIAGNOSIS

U0073 COMMUNICATION BUS A OFF

Description

INFOID:000000009019647

CAN (Controller Area Network) is a serial communication line for real-time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent malfunction detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independently). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

DTC Logic

INFOID:000000009019648

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
U0073	Control Module Communication Bus A Off	TCM communication blockage lasts for 2 seconds or more when turning ON the ignition switch. (Communication not established.)	Harness or connector (CAN communication line is error)

DTC CONFIRMATION PROCEDURE

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

1. Start the engine and wait for at least 5 seconds.
2. Check the DTC.

Is "U0073" detected?

- YES >> Go to [TM-134, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009019649

For the diagnosis procedure, refer to [LAN-15, "Trouble Diagnosis Flow Chart"](#).

U0100 LOST COMMUNICATION (ECM A)

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

U0100 LOST COMMUNICATION (ECM A)

Description

INFOID:0000000009019650

CAN (Controller Area Network) is a serial communication line for real-time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent malfunction detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independently). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

DTC Logic

INFOID:0000000009019651

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
U0100	Lost Communication With ECM/PCM A	When the ignition switch is ON, TCM is unable to receive the CAN communications signal from ECM continuously for 2 seconds or more.	• ECM • Harness or connector (CAN communication line is open or shorted)

DTC CONFIRMATION PROCEDURE

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

1. Start the engine and wait for at least 5 seconds.
2. Check the DTC.

Is "U0100" detected?

YES >> Go to [TM-135, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000009019652

For the diagnosis procedure, refer to [LAN-15, "Trouble Diagnosis Flow Chart"](#).

U0140 LOST COMMUNICATION (BCM)

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

U0140 LOST COMMUNICATION (BCM)

Description

INFOID:000000009019653

CAN (Controller Area Network) is a serial communication line for real-time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent malfunction detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independently). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

DTC Logic

INFOID:000000009019654

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
U0140	Lost Communication With Body Control Module	When the ignition switch is ON, TCM is unable to receive the CAN communications signal from BCM continuously for 2 seconds or more.	• BCM • Harness or connector (CAN communication line is open or shorted)

DTC CONFIRMATION PROCEDURE

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

Ⓔ With CONSULT

1. Start the engine and wait for at least 5 seconds.
2. Check the DTC.

Is "U0140" detected?

YES >> Go to [TM-136, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009019655

For the diagnosis procedure, refer to [LAN-15, "Trouble Diagnosis Flow Chart"](#).

U0141 LOST COMMUNICATION (BCM A)

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

U0141 LOST COMMUNICATION (BCM A)

Description

INFOID:0000000009019656

CAN (Controller Area Network) is a serial communication line for real-time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent malfunction detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independently). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

DTC Logic

INFOID:0000000009019657

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
U0141	Lost Communication With Body Control Module A	When the ignition switch is turned ON, TCM continues no reception of the CAN communication signal from IPDM E/R for 2 seconds or more.	• IPDM E/R • Harness or connector (CAN communication line is open or shorted)

DTC CONFIRMATION PROCEDURE

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

Ⓐ With CONSULT

1. Start the engine and wait for at least 5 seconds.
2. Check the DTC.

Is "U0141" detected?

- YES >> Go to [TM-134, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000009019658

For the diagnosis procedure, refer to [LAN-15, "Trouble Diagnosis Flow Chart"](#).

U0155 LOST COMMUNICATION (IPC)

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

U0155 LOST COMMUNICATION (IPC)

Description

INFOID:0000000009019659

CAN (Controller Area Network) is a serial communication line for real-time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent malfunction detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independently). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

DTC Logic

INFOID:0000000009019660

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
U0155	Lost Communication With Instrument Panel Cluster (IPC) Control Module	When the ignition switch is ON, TCM is unable to receive the CAN communications signal from the combination meter continuously for 2 seconds or more.	• Combination meter • Harness or connector (CAN communication line is open or shorted)

DTC CONFIRMATION PROCEDURE

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

④ With CONSULT

1. Start the engine and wait for at least 5 seconds.
2. Check the DTC.

Is "U0155" detected?

YES >> Go to [TM-138, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000009019661

For the diagnosis procedure, refer to [LAN-15, "Trouble Diagnosis Flow Chart"](#).

U0300 CAN COMMUNICATION DATA

Description

INFOID:0000000009019662

CAN (Controller Area Network) is a serial communication line for real-time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent malfunction detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independently). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

DTC Logic

INFOID:0000000009019663

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
U0300	Internal Control Module Software Incompatibility	When the ignition switch is ON, the data length transmitted from each control unit is shorter than the specified length and the status continues for 2 seconds or more.	Control unit other than TCM

DTC CONFIRMATION PROCEDURE

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

 With CONSULT

1. Start the engine and wait for 5 seconds or more.
2. Check the DTC.

Is "U0300" detected?

- YES >> Go to [TM-139, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000009019664

1. CONTROL UNIT CHECK

Check the number of control units replaced before "U0300" is detected.

Is one control unit replaced?

- YES >> The specification of the control unit replaced may be incorrect. Check the part number and the specification.
 NO >> GO TO 2.

2. CONTROL UNIT CHECK

 With CONSULT

1. Remove one of the control unit replaced.
2. Assemble the old control unit before replacement.
3. Turn ignition switch ON, and wait for 2 seconds or more.
4. Select "Self Diagnostic Results" in "TRANSMISSION".

Is "U0300" detected?

- YES >> Turn OFF the ignition switch and check other control units in the same manner.
 NO >> The specification of the control unit removed may be incorrect. Check the part number and the specification.

U1000 CAN COMM CIRCUIT

Description

INFOID:0000000009019665

CAN (Controller Area Network) is a serial communication line for real-time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent malfunction detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independently). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

DTC Logic

INFOID:0000000009019666

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
U1000	CAN Communication Line	When the ignition switch is ON, TCM cannot send the CAN communication signal continuously for 2 seconds or more.	Harness or connector (CAN communication line is open or shorted)

DTC CONFIRMATION PROCEDURE

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

① With CONSULT

1. Start the engine and wait for at least 5 seconds.
2. Check the DTC.

Is "U1000" detected?

YES >> Go to [TM-140, "Diagnosis Procedure"](#).

NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000009019667

For the diagnosis procedure, refer to [LAN-15, "Trouble Diagnosis Flow Chart"](#).

U1117 LOST COMMUNICATION (ABS)

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

U1117 LOST COMMUNICATION (ABS)

Description

INFOID:0000000009019668

CAN (Controller Area Network) is a serial communication line for real-time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent malfunction detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independently). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

DTC Logic

INFOID:0000000009019669

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
U1117	Lost Communication With ABS	When the ignition switch is ON, TCM is unable to receive the CAN communications signal from ABS actuator and electric unit (control unit) continuously for 2 seconds or more.	• ABS actuator and electric unit (control unit) • Harness or connector (CAN communication line is open or shorted)

DTC CONFIRMATION PROCEDURE

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

Ⓔ With CONSULT

1. Start the engine and wait for 5 seconds or more.
2. Check the DTC.

Is "U1117" detected?

- YES >> Go to [TM-134, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000009019670

For the diagnosis procedure, refer to [LAN-15, "Trouble Diagnosis Flow Chart"](#).

P062F EEPROM**Description**

INFOID:000000009019671

TCM compares the calculated value stored in the flash ROM with the value stored in TCM. If the calculated value does not agree with the stored value, TCM judges this as a malfunction.

DTC Logic

INFOID:000000009019672

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P062F	Internal Control Module EEPROM Error	Flash ROM error is detected when turning ON the ignition switch.	• TCM (flash ROM) • Harness or connector [TCM power supply (back-up) circuit is open or shorted]

DTC CONFIRMATION PROCEDURE**1. PREPARATION BEFORE WORK**

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

1. Start the engine.
2. Check the DTC.

Is "P062F" detected?

- YES >> Go to [TM-142, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009019673

1. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

Is the inspection result normal?

- YES >> Replace the TCM. Refer to [TM-237, "Removal and Installation"](#).
NO >> Repair or replace malfunctioning parts.

P0705 TRANSMISSION RANGE SENSOR A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

P0705 TRANSMISSION RANGE SENSOR A

DTC Logic

INFOID:0000000009019674

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P0705	Transmission Range Sensor A Circuit (PRNDL Input)	Two or more range signals simultaneously stay ON continuously for 5 seconds under the following diagnosis condition 1 and 2: • Diagnosis condition 1 (continued for 5 seconds or more) - TCM power supply voltage: More than 11 V • Diagnosis condition 2 (continued for 2 seconds or more) - Vehicle speed: Less than 3 km/h (2 MPH) - Accelerator pedal position: 0.6/8 or less - Idle switch: ON - Stop lamp switch: ON	• Harness or connector (Short circuit between transmission range switch and TCM) • Transmission range switch

DTC CONFIRMATION PROCEDURE

CAUTION:

Be careful of the driving speed.

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

1. Start the engine.
2. Maintain the following conditions.

Accelerator pedal position	: 0.0/8
Brake pedal	: Depressed
Vehicle speed	: 0 km/h (0 MPH)

3. Shift the selector lever through entire positions from "P" to "L". (Hold the selector lever at each position for 10 seconds or more.)
4. Check the first trip DTC.

Is "P0705" detected?

- YES >> Go to [TM-143. "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000009019675

1. CHECK TCM INPUT SIGNALS

With CONSULT

1. Turn ignition switch ON.
2. Select "Data Monitor" in "TRANSMISSION".
3. Select "D POSITION SW", "N POSITION SW", "R POSITION SW", "P POSITION SW" and "L POSITION SW".
4. Shift the selector lever through entire positions from "P" to "L" and check ON/OFF of each monitor item.

Monitor item	Test condition	Condition
D POSITION SW	Selector lever: "D" position	On
	Other than the above	Off

P0705 TRANSMISSION RANGE SENSOR A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

Monitor item	Test condition	Condition
N POSITION SW	Selector lever: "N" position	On
	Other than the above	Off
R POSITION SW	Selector lever: "R" position	On
	Other than the above	Off
P POSITION SW	Selector lever: "P" position	On
	Other than the above	Off
L POSITION SW	Selector lever: "L" position	On
	Other than the above	Off

⊗ Without CONSULT

1. Turn ignition switch OFF.
2. Disconnect TCM connector.
3. Turn ignition switch ON.
4. Shift the selector lever from "P" to "L" and check voltage between TCM harness connector terminals and ground.

+		−	Condition	Voltage
TCM				
Connector	Terminal			
F44	2	Ground	Selector lever: “L” position	Battery voltage
			Other than the above	Approx. 0 V
	4		Selector lever: “D” position	Battery voltage
			Other than the above	Approx. 0 V
	5		Selector lever: “N” position	Battery voltage
			Other than the above	Approx. 0 V
	6		Selector lever: “R” position	Battery voltage
			Other than the above	Approx. 0 V
	7		Selector lever: “P” position	Battery voltage
			Other than the above	Approx. 0 V

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-41. "Intermittent Incident"](#).

NO-1 ["D POSITION SW" is "ON" when selector is not in "D" position. (Or connector terminal 4 is at power voltage.)]>>GO TO 2.

NO-2 ["N POSITION SW" is "ON" when selector is not in "N" position. (Or connector terminal 5 is at power voltage.)]>>GO TO 4.

NO-3 ["R POSITION SW" is "ON" when selector is not in "R" position. (Or connector terminal 6 is at power voltage.)]>>GO TO 6.

NO-4 ["P POSITION SW" is "ON" when selector is not in "P" position. (Or connector terminal 7 is at power voltage.)]>>GO TO 8.

NO-5 ["L POSITION SW" is "ON" when selector is not in "L" position. (Or connector terminal 2 is at power voltage.)]>>GO TO 10.

2. CHECK D POSITION SW CIRCUIT (PART 1)

1. Turn ignition switch OFF.
2. Disconnect TCM connector.
3. Check continuity between TCM harness connector terminals.

P0705 TRANSMISSION RANGE SENSOR A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

TCM			Continuity
Connector	Terminal		
F44	4	2	Not existed
		5	
		6	
		7	

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace malfunctioning parts.

3.CHECK D POSITION SW CIRCUIT (PART 2)

1. Disconnect transmission position switch connector.
2. Turn ignition switch ON.
3. Check voltage between TCM harness connector terminal and ground.

+		-	Voltage (Approx.)
TCM			
Connector	Terminal		
F44	4	Ground	0 V

Is the inspection result normal?

YES >> GO TO 12.

NO >> Repair or replace malfunctioning parts.

4.CHECK N POSITION SW CIRCUIT (PART 1)

1. Turn ignition switch OFF.
2. Disconnect TCM connector.
3. Check continuity between TCM harness connector terminals.

TCM			Continuity
Connector	Terminal		
F44	5	2	Not existed
		4	
		6	
		7	

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace malfunctioning parts.

5.CHECK N POSITION SW CIRCUIT (PART 2)

1. Disconnect transmission position switch connector.
2. Turn ignition switch ON.
3. Check voltage between TCM harness connector terminal and ground.

+		-	Voltage (Approx.)
TCM			
Connector	Terminal		
F44	5	Ground	0 V

Is the inspection result normal?

YES >> GO TO 12.

NO >> Repair or replace malfunctioning parts.

P0705 TRANSMISSION RANGE SENSOR A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

6. CHECK P POSITION SW CIRCUIT (PART 1)

1. Turn ignition switch OFF.
2. Disconnect TCM connector.
3. Check continuity between TCM harness connector terminals.

TCM			Continuity
Connector	Terminal		
F44	7	2	Not existed
		4	
		5	
		6	

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair or replace malfunctioning parts.

7. CHECK P POSITION SW CIRCUIT (PART 2)

1. Disconnect transmission position switch connector.
2. Turn ignition switch ON.
3. Check voltage between TCM harness connector terminal and ground.

+		-	Voltage (Approx.)
TCM			
Connector	Terminal		
F44	7	Ground	0 V

Is the inspection result normal?

YES >> GO TO 12.

NO >> Repair or replace malfunctioning parts.

8. CHECK R POSITION SW CIRCUIT (PART1)

1. Turn ignition switch OFF.
2. Disconnect TCM connector.
3. Check continuity between TCM harness connector terminals.

TCM			Continuity
Connector	Terminal		
F44	6	2	Not existed
		4	
		5	
		7	

Is the inspection result normal?

YES >> GO TO 9.

NO >> Repair or replace malfunctioning parts.

9. CHECK R POSITION SW CIRCUIT (PART 2)

1. Disconnect transmission position switch connector.
2. Turn ignition switch ON.
3. Check voltage between TCM harness connector terminal and ground.

P0705 TRANSMISSION RANGE SENSOR A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

+		-	Voltage (Approx.)
TCM			
Connector	Terminal		
F44	6	Ground	0 V

Is the inspection result normal?

YES >> GO TO 12.

NO >> Repair or replace malfunctioning parts.

10.CHECK L POSITION SWITCH CIRCUIT (PART 1)

1. Turn ignition switch OFF.
2. Disconnect TCM connector.
3. Check continuity between TCM harness connector terminals.

TCM			Continuity
Connector	Terminal		
F44	2	4	Not existed
		5	
		6	
		7	

Is the inspection result normal?

YES >> GO TO 11.

NO >> Repair or replace malfunctioning parts.

11.CHECK L POSITION SWITCH CIRCUIT (PART 2)

1. Disconnect transmission position switch connector.
2. Turn ignition switch ON.
3. Check voltage between TCM harness connector terminal and ground.

+		–	Voltage (Approx.)
TCM			
Connector	Terminal		
F44	2	Ground	0 V

Is the inspection result normal?

YES >> GO TO 12.

NO >> Repair or replace malfunctioning parts.

12.CHECK TRANSMISSION RANGE SWITCH

Check transmission range switch. Refer to [TM-147, "Component Inspection \(Transmission Range Switch\)"](#).

Is the check result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

NO >> Repair or replace malfunctioning parts.

Component Inspection (Transmission Range Switch)

INFOID:0000000009019676

1.CHECK TRANSMISSION RANGE SWITCH

Check continuity between transmission range switch connector terminals.

Transmission range switch	Condition	Continuity
Terminal		
7 – 10	Manual lever: “P” and “N” positions	Existed
	Other than the above	Not existed

P0705 TRANSMISSION RANGE SENSOR A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

Transmission range switch Terminal	Condition	Continuity
4 – 5	Manual lever: "P" position	Existed
	Other than the above	Not existed
4 – 8	Manual lever: "R" position	Existed
	Other than the above	Not existed
4 – 9	Manual lever: "N" position	Existed
	Other than the above	Not existed
4 – 2	Manual lever: "D" position	Existed
	Other than the above	Not existed
4 – 6	Manual lever: "L" position	Existed
	Other than the above	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> There is a malfunction of transmission range switch. Replace transaxle assembly. Refer to [TM-252. "Removal and Installation"](#).

P0706 TRANSMISSION RANGE SENSOR A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

P0706 TRANSMISSION RANGE SENSOR A

DTC Logic

INFOID:000000009019677

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P0706	Transmission Range Sensor A Circuit Range/Performance	All range signals stay OFF continuously for 30 seconds under the following diagnosis condition 1 and 2: • Diagnosis condition 1 (continued for 30 seconds or more) - TCM power supply voltage: More than 11 V • Diagnosis condition 2 (continued for 2 seconds or more) - Vehicle speed: Less than 3 km/h (2 MPH) - Accelerator pedal position: 0.6/8 or less - Idle switch: ON - Stop lamp switch: ON	• Harness or connector (Open circuit between ignition switch and transmission range switch/open circuit between transmission range switch and TCM) • Transmission range switch • Control cable

DTC CONFIRMATION PROCEDURE

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

1. Start the engine.
2. Maintain the following conditions.

Accelerator pedal position : 0.0/8
Brake pedal : Depressed
Vehicle speed : 0 km/h (0 MPH)

3. Shift the selector lever through entire positions from "P" to "L". (Hold the selector lever at each position for 35 seconds or more.)
4. Check the first trip DTC.

Is "P0706" detected?

YES >> Go to [TM-149, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009019678

1. ADJUSTMENT OF CONTROL CABLE

Adjust control cable. Refer to [TM-230, "Inspection"](#).

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

With CONSULT

1. Turn ignition switch ON.
2. Select "Self Diagnostic Results" in "TRANSMISSION".
3. Touch "Erase".
4. Perform "DTC CONFIRMATION PROCEDURE". Refer to [TM-149, "DTC Logic"](#).

Is "P0706" detected?

YES >> GO TO 3.
NO >> INSPECTION END

P0706 TRANSMISSION RANGE SENSOR A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

3. CHECK POWER CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect transmission range switch connector.
3. Turn ignition switch ON.
4. Check voltage between transmission range switch harness connector terminal and ground.

+		–	Voltage
Transmission range switch			
Connector	Terminal		
F49	4	Ground	10 – 16 V

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 7.

4. CHECK CIRCUIT BETWEEN TRANSMISSION RANGE SWITCH AND TCM (PART 1)

1. Turn ignition switch OFF.
2. Disconnect TCM connector.
3. Check continuity between transmission range switch harness connector terminals and TCM harness connector terminals.

Transmission range switch		TCM		Continuity
Connector	Terminal	Connector	Terminal	
F49	2	F44	4	Existed
	5		7	
	6		6	
	8		6	
	9		5	

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace malfunctioning parts.

5. CHECK CIRCUIT BETWEEN TRANSMISSION RANGE SWITCH AND TCM (PART 2)

Check continuity between transmission range switch harness connector terminals and ground.

Transmission range switch		—	Continuity
Connector	Terminal		
F49	2	Ground	Not existed
	5		
	6		
	8		
	9		

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace malfunctioning parts.

6. CHECK TRANSMISSION RANGE SWITCH

Check transmission range switch. Refer to [TM-151, "Component Inspection \(Transmission Range Switch\)"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

NO >> Repair or replace malfunctioning parts.

P0706 TRANSMISSION RANGE SENSOR A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

7. CHECK CIRCUIT BETWEEN IPDM E/R AND TRANSMISSION RANGE SWITCH

1. Disconnect IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector and transmission range switch.

IPDM E/R		Transmission range switch		Continuity
Connector	Terminal	Connector	Terminal	
E45	21	F49	4	Existed

Is the check result normal?

YES >> GO TO 8.

NO >> Repair or replace malfunctioning parts.

8. DETECT MALFUNCTIONING ITEMS

Check the following items:

- Open circuit or short circuit in harness between ignition switch and IPDM E/R. Refer to [PG-17, "Wiring Diagram — Ignition Power Supply —"](#).
- Short circuit in harness between IPDM E/R harness connector terminal 21 and transmission range switch harness connector terminal 4.
- 10A fuse (No. 49, IPDM E/R). Refer to [PG-60, "IPDM E/R Terminal Arrangement"](#).
- IPDM E/R

Is the check result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

NO >> Repair or replace malfunctioning parts.

Component Inspection (Transmission Range Switch)

INFOID:000000009019679

1. CHECK TRANSMISSION RANGE SWITCH

Check continuity between transmission range switch connector terminals.

Transmission range switch	Condition	Continuity
Terminal		
7 – 10	Manual lever: "P" and "N" positions	Existed
	Other than the above	Not existed
4 – 5	Manual lever: "P" position	Existed
	Other than the above	Not existed
4 – 8	Manual lever: "R" position	Existed
	Other than the above	Not existed
4 – 9	Manual lever: "N" position	Existed
	Other than the above	Not existed
4 – 2	Manual lever: "D" position	Existed
	Other than the above	Not existed
4 – 6	Manual lever: "L" position	Existed
	Other than the above	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> There is a malfunction of transmission range switch. Replace transaxle assembly. Refer to [TM-252, "Removal and Installation"](#).

P0711 TRANSMISSION FLUID TEMPERATURE SENSOR A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

P0711 TRANSMISSION FLUID TEMPERATURE SENSOR A

DTC Logic

INFOID:000000009019680

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P0711	Transmission Fluid Temperature Sensor A Circuit Range/Performance	When any of 1 or 2 is satisfied: - Under the following diagnosis conditions, CVT fluid temperature does not rise to 10°C (50°F) after driving for a certain period of time with the TCM-received fluid temperature sensor value between –40°C (–40°F) and 9°C (48.2°F). - Diagnosis condition - Selector lever: "D" position - Vehicle speed: 10 km/h (7 MPH) or more - Engine speed: 450 rpm or more - Accelerator pedal position: 1.0/8 or more - TCM power supply voltage: More than 11 V - CVT fluid temperature: Less than 10°C - When the condition of the final judgment is satisfied after satisfying that of the provisional judgment: - Provisional judgment: All of the following conditions are satisfied within 2 seconds after the ignition switch is turned ON. - U0073, U0100, P0712 and P0713 are not detected. - CAN communication is normal. - TCM power supply voltage: More than 11 V - The difference between CVT fluid temperature and engine coolant temperature is 37°C (98.6°F) or more, or –27°C (–16°F) or less. - Final judgment: When all of the following conditions are satisfied and this state is maintained for 300 seconds: - ECM is normal. - Provisional judgment is satisfied.	CVT fluid temperature sensor

DTC CONFIRMATION PROCEDURE

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

With CONSULT

- Turn ignition switch OFF and cool the engine.
- Turn ignition switch ON.

CAUTION:

Never start the engine.

- Select "Data Monitor" in "TRANSMISSION".
- Select "FLUID TEMP".
- Record CVT fluid temperature.
- Start the engine and wait for at least 2 minutes.
- Drive the vehicle for the total minutes specified in the Driving time column below with the following conditions satisfied.

P0711 TRANSMISSION FLUID TEMPERATURE SENSOR A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

Selector lever : "D" position
Accelerator pedal position : 1.0/8 or more
Vehicle speed : 10 km/h (7 MPH) or more

CVT fluid temperature before engine start	Driving time
-40°C (-40°F) – -31°C (-23.8°F)	18 minutes or more
-30°C (-22°F) – -21°C (-5.8°F)	16 minutes or more
-20°C (-4°F) – -11°C (-12.2°F)	13 minutes or more
-10°C (14°F) – -1°C (30.2°F)	9 minutes or more
0°C (32°F) – 9°C (48.2°F)	6 minutes or more
Other than the above	— (Go to 3.)

8. Stop the vehicle.

9. Check the first trip DTC.

⊗ With GST

1. Turn ignition switch OFF and cool the engine.
2. Start the engine and wait for at least 2 minutes.
3. Drive the vehicle and maintain the following conditions for 18 minutes or more.

Selector lever : "D" position
Accelerator pedal position : 1.0/8 or more
Vehicle speed : 10 km/h (7 MPH) or more

4. Stop the vehicle.

5. Check the first trip DTC.

Is "P0711" detected?

YES >> Go to [TM-168, "Diagnosis Procedure"](#).

NO >> GO TO 3.

3. CHECK CVT FLUID TEMPERATURE SENSOR

1. Turn ignition switch OFF.
2. Disconnect CVT unit connector.
3. Check resistance between CVT fluid connector terminal.

CVT unit Terminal	Condition	Resistance (Approx.)
12 – 18	CVT fluid temperature: 20°C (68°C)	6.5 kΩ
	CVT fluid temperature: 50°C (122°C)	2.2 kΩ
	CVT fluid temperature: 80°C (176°C)	0.87 kΩ

Is the inspection result normal?

YES >> INSPECTION END

NO >> There is a malfunction of CVT fluid temperature sensor. Replace transaxle assembly. Refer to [TM-252, "Removal and Installation"](#).

Diagnosis Procedure

INFOID:000000009019681

1. CHECK CVT FLUID TEMPERATURE SENSOR

1. Turn ignition switch OFF.
2. Disconnect CVT unit connector.
3. Check CVT fluid temperature sensor. Refer to [TM-154, "Component Inspection \(CVT Fluid Temperature Sensor\)"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

P0711 TRANSMISSION FLUID TEMPERATURE SENSOR A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

NO >> Repair or replace malfunctioning parts.

Component Inspection (CVT Fluid Temperature Sensor)

INFOID:000000009019682

1. CHECK CVT FLUID TEMPERATURE SENSOR

Check resistance between CVT unit connector terminals.

CVT unit Terminal	Condition	Resistance (Approx.)
12 – 18	CVT fluid temperature: 20°C (68°C)	6.5 kΩ
	CVT fluid temperature: 50°C (122°C)	2.2 kΩ
	CVT fluid temperature: 80°C (176°C)	0.87 kΩ

Is the inspection result normal?

YES >> INSPECTION END

NO >> There is a malfunction of CVT fluid temperature sensor. Replace transaxle assembly. Refer to [TM-252, "Removal and Installation"](#).

P0712 TRANSMISSION FLUID TEMPERATURE SENSOR A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

P0712 TRANSMISSION FLUID TEMPERATURE SENSOR A

DTC Logic

INFOID:0000000009019683

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P0712	Transmission Fluid Temperature Sensor A Circuit Low	The CVT fluid temperature identified by the TCM is 180°C (356°F) or more continuously for 5 seconds or more under the following diagnosis conditions: • Diagnosis conditions - Ignition switch: ON - TCM power supply voltage: More than 11 V	• Harness or connector (CVT fluid temperature sensor circuit is shorted to ground) • CVT fluid temperature sensor

DTC CONFIRMATION PROCEDURE

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

1. Start the engine and wait for 10 seconds or more.
2. Check the first trip DTC.

Is "P0712" detected?

YES >> Go to [TM-155, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000009019684

1. CHECK CIRCUIT BETWEEN TCM AND CVT UNIT

1. Turn ignition switch OFF.
2. Disconnect TCM connector and CVT unit connector.
3. Check continuity between TCM harness connector terminal and ground.

TCM		—	Continuity
Connector	Terminal		
F44	12	Ground	Not existed

Is the inspection result normal?

YES >> GO TO 2.
NO >> Repair or replace malfunctioning part.

2. CHECK CVT FLUID TEMPERATURE SENSOR

Check CVT fluid temperature sensor. Refer to [TM-155, "Component Inspection \(CVT Fluid Temperature Sensor\)"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).
NO >> Repair or replace malfunctioning parts.

Component Inspection (CVT Fluid Temperature Sensor)

INFOID:0000000009019685

1. CHECK CVT FLUID TEMPERATURE SENSOR

Check resistance between CVT unit connector terminals.

P0712 TRANSMISSION FLUID TEMPERATURE SENSOR A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

CVT unit	Condition	Resistance (Approx.)
Terminal		
12 – 18	CVT fluid temperature: 20°C (68°C)	6.5 kΩ
	CVT fluid temperature: 50°C (122°C)	2.2 kΩ
	CVT fluid temperature: 80°C (176°C)	0.87 kΩ

Is the inspection result normal?

YES >> INSPECTION END

NO >> There is a malfunction of CVT fluid temperature sensor. Replace transaxle assembly. Refer to [TM-252. "Removal and Installation"](#).

P0713 TRANSMISSION FLUID TEMPERATURE SENSOR A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

P0713 TRANSMISSION FLUID TEMPERATURE SENSOR A

DTC Logic

INFOID:000000009019686

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P0713	Transmission Fluid Temperature Sensor A Circuit High	The CVT fluid temperature identified by the TCM is -40°C (-40°F) or less continuously for 5 seconds or more under the following diagnosis conditions: • Diagnosis conditions - Ignition switch: ON - Vehicle speed: More than 10 km/h (7 MPH) - TCM power supply voltage: More than 11 V	• Harness or connector (CVT fluid temperature sensor circuit is open or shorted to power supply) • CVT fluid temperature sensor

DTC CONFIRMATION PROCEDURE

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

1. Start the engine.
2. Maintain the following condition for 10 seconds or more.

Vehicle speed : 20 km/h (12 MPH) or more

3. Stop the vehicle.
4. Check the first trip DTC.

Is "P0713" detected?

YES >> Go to [TM-155, "Diagnosis Procedure"](#).

NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009019687

1. CHECK CIRCUIT BETWEEN TCM AND CVT UNIT (PART 1)

1. Turn ignition switch OFF.
2. Disconnect TCM connector and CVT unit connector.
3. Check continuity between TCM harness connector terminals and CVT unit harness connector terminals.

TCM		CVT unit		Continuity
Connector	Terminal	Connector	Terminal	
F44	12	F46	12	Existed
	11		18	

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace malfunctioning part.

2. CHECK CIRCUIT BETWEEN TCM AND CVT UNIT (PART 2)

1. Turn ignition switch ON.
2. Check voltage between TCM harness connector terminal and ground.

P0713 TRANSMISSION FLUID TEMPERATURE SENSOR A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

+		-	Voltage (Approx.)
TCM			
Connector	Terminal		
F44	12	Ground	0 V

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace malfunctioning part.

3.CHECK CVT FLUID TEMPERATURE SENSOR

Check CVT fluid temperature sensor. Refer to [TM-158, "Component Inspection \(CVT Fluid Temperature Sensor\)"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

NO >> Repair or replace malfunctioning parts.

Component Inspection (CVT Fluid Temperature Sensor)

INFOID:0000000009019688

1.CHECK CVT FLUID TEMPERATURE SENSOR

Check resistance between CVT unit connector terminals.

CVT unit Terminal	Condition	Resistance (Approx.)
12 – 18	CVT fluid temperature: 20°C (68°C)	6.5 kΩ
	CVT fluid temperature: 50°C (122°C)	2.2 kΩ
	CVT fluid temperature: 80°C (176°C)	0.87 kΩ

Is the inspection result normal?

YES >> INSPECTION END

NO >> There is a malfunction of CVT fluid temperature sensor. Replace transaxle assembly. Refer to [TM-252, "Removal and Installation"](#).

P0715 INPUT SPEED SENSOR A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

P0715 INPUT SPEED SENSOR A

DTC Logic

INFOID:0000000009019689

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P0715	Input/Turbine Speed Sensor A Circuit	The primary speed sensor value is less than 150 rpm continuously for 5 seconds or more under the following diagnosis conditions: • Diagnosis conditions - Secondary pulley speed: 1,000 rpm or more - TCM power supply voltage: More than 11 V The primary speed sensor value is 240 rpm or less continuously for 500 msec or more under the following diagnosis conditions: • Diagnosis conditions - 10-msec-ago primary pulley speed: 1,000 rpm or more - TCM power supply voltage: More than 11 V	• Harness or connector (Primary speed sensor circuit is open or shorted) • Primary speed sensor

DTC CONFIRMATION PROCEDURE

CAUTION:

Be careful of the driving speed.

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

1. Start the engine.
2. Drive the vehicle.
3. Maintain the following conditions for 10 seconds or more.

Selector lever : "L" POSITION

Vehicle speed : 40 km/h (25 MPH) or more

4. Stop the vehicle.
5. Check the first trip DTC.

Is "P0715" detected?

YES >> Go to [TM-159, "Diagnosis Procedure"](#).

NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000009019690

1. CHECK PRIMARY SPEED SENSOR POWER CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect primary speed sensor connector.
3. Turn ignition switch ON.
4. Check voltage between primary speed sensor harness connector terminal and ground.

+		–	Voltage
Primary speed sensor			
Connector	Terminal		
F50	3	Ground	10 – 16 V

Is the inspection result normal?

P0715 INPUT SPEED SENSOR A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

YES >> GO TO 2.
NO >> GO TO 6.

2.CHECK PRIMARY SPEED SENSOR GROUND CIRCUIT

Check continuity between primary speed sensor harness connector terminal and ground.

Primary speed sensor		—	Continuity
Connector	Terminal		
F50	1	Ground	Existed

Is the inspection result normal?

YES >> GO TO 3.
NO >> Repair or replace malfunctioning parts.

3.CHECK CIRCUIT BETWEEN PRIMARY SPEED SENSOR AND TCM (PART 1)

1. Turn ignition switch OFF.
2. Disconnect TCM connector.
3. Check continuity between primary speed sensor harness connector terminal and TCM harness connector terminal.

Primary speed sensor		TCM		Continuity
Connector	Terminal	Connector	Terminal	
F50	2	F44	35	Existed

Is the inspection result normal?

YES >> GO TO 4.
NO >> Repair or replace malfunctioning parts.

4.CHECK CIRCUIT BETWEEN PRIMARY SPEED SENSOR AND TCM (PART 2)

Check continuity between primary speed sensor harness connector terminal and ground.


Primary speed sensor		—	Continuity
Connector	Terminal		
F50	2	Ground	Not existed

Is the inspection result normal?

YES >> GO TO 5.
NO >> Repair or replace malfunctioning parts.

5.CHECK TCM INPUT SIGNALS

1. Connect all of disconnected connectors.
2. Lift the vehicle.
3. Start the engine.
4. Check frequency of primary speed sensor.

+		—	Condition	Frequency (Approx.)
TCM				
Connector	Terminal			
F44	35	Ground	• Selector lever: “L” position • Vehicle speed: 20 km/h (12 MPH)	1,100 Hz 1mSec/div  5V/div JSDIA1906GB

Is the inspection result normal?

P0715 INPUT SPEED SENSOR A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

- YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).
NO >> Replace primary speed sensor. [TM-242, "Removal and Installation"](#).

6. CHECK CIRCUIT BETWEEN IPDM E/R AND PRIMARY SPEED SENSOR

1. Disconnect IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector terminal and primary speed sensor harness connector terminal.

IPDM E/R		Primary speed sensor		Continuity
Connector	Terminal	Connector	Terminal	
E45	21	F50	3	Existed

Is the check result normal?

- YES >> GO TO 7.
NO >> Repair or replace malfunctioning parts.

7. DETECT MALFUNCTIONING ITEMS

Check the following items:

- Open circuit or short circuit in harness between ignition switch and IPDM E/R. Refer to [PG-17, "Wiring Diagram — Ignition Power Supply —"](#).
- Short circuit in harness between IPDM E/R harness connector terminal 21 and primary speed sensor harness connector terminal 3.
- 10A fuse (No.49, IPDM E/R). Refer to [PG-60, "IPDM E/R Terminal Arrangement"](#).
- IPDM E/R

Is the check result normal?

- YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).
NO >> Repair or replace malfunctioning parts.

P0720 OUTPUT SPEED SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

P0720 OUTPUT SPEED SENSOR

DTC Logic

INFOID:0000000009019691

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P0720	Output Speed Sensor Circuit	The output speed sensor value is less than 150 rpm continuously for 10 seconds or more under the following diagnosis conditions: • Diagnosis conditions - Selector lever: "D", "L" or "R" position - Auxiliary gearbox shifting is not in progress. - When the "D" position switch, "L" position switch or "R" position switch is ON, the output speed has not experienced 250 rpm or more. - After shifting the selector lever, the input speed has experienced less than 300 rpm. - Secondary pulley speed: 1,500 rpm or more - TCM power supply voltage: More than 11 V	• Harness or connector (Output speed sensor circuit is open or shorted) • Output speed sensor
		The output speed sensor value is 90 rpm or less continuously for 500 msec or more under the following diagnosis conditions: • Diagnosis conditions - 10-msec-ago output speed: 730 rpm or more - TCM power supply voltage: More than 11 V	

DTC CONFIRMATION PROCEDURE

CAUTION:

Be careful of the driving speed.

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

1. Start the engine.
2. Drive the vehicle.
3. Maintain the following conditions for 10 seconds or more.

Selector lever : "D" position

Vehicle speed : 55 km/h (34 MPH) or more

4. Stop the vehicle.
5. Check the first trip DTC.

Is "P0720" detected?

YES >> Go to [TM-162, "Diagnosis Procedure"](#).

NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000009019692

1. CHECK OUTPUT SPEED SENSOR POWER CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect output speed sensor connector.
3. Turn ignition switch ON.
4. Check voltage between output speed sensor harness connector terminal and ground.

P0720 OUTPUT SPEED SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

+		–	Voltage
Output speed sensor			
Connector	Terminal		
F41	3	Ground	10 – 16 V

Is the inspection result normal?

YES >> GO TO 2.

NO >> GO TO 6.

2.CHECK OUTPUT SPEED SENSOR GROUND CIRCUIT

Check continuity between output speed sensor harness connector terminal and ground.

Output speed sensor		—	Continuity
Connector	Terminal		
F41	1		
		Ground	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace malfunctioning parts.

3.CHECK CIRCUIT BETWEEN OUTPUT SPEED SENSOR AND TCM (PART 1)

1. Turn ignition switch OFF.
2. Disconnect TCM connector.
3. Check continuity between output speed sensor harness connector terminal and TCM harness connector terminal.

Output speed sensor		TCM		Continuity
Connector	Terminal	Connector	Terminal	
F41	2	F44	24	
				Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace malfunctioning parts.

4.CHECK CIRCUIT BETWEEN OUTPUT SPEED SENSOR AND TCM (PART 2)

Check continuity between output speed sensor harness connector terminal and ground.

Output speed sensor		—	Continuity
Connector	Terminal		
F41	2		
		Ground	Not existed

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace malfunctioning parts.


5.CHECK TCM INPUT SIGNALS

1. Connect all of disconnected connectors.
2. Lift the vehicle.
3. Start the engine.
4. Check frequency of output speed sensor.

P0720 OUTPUT SPEED SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

+		-	Condition	Frequency (Approx.)
TCM				
Connector	Terminal			
F44	24	Ground	• Selector lever: “L” position • Vehicle speed: 20 km/h (12 MPH)	200 Hz 2.5mSec/div  5V/div JSDIA1904GB

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

NO >> Replace output speed sensor. Refer to [TM-244, "Removal and Installation"](#).

6. CHECK CIRCUIT BETWEEN IPDM E/R AND OUTPUT SPEED SENSOR

1. Disconnect IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector terminal and output speed sensor harness connector terminal.

IPDM E/R		Output speed sensor		Continuity
Connector	Terminal	Connector	Terminal	
E45	21	F41	3	Existed

Is the check result normal?

YES >> GO TO 7.

NO >> Repair or replace malfunctioning parts.

7. DETECT MALFUNCTIONING ITEMS

Check the following items:

- Open circuit or short circuit in harness between ignition switch and IPDM E/R. Refer to [PG-17, "Wiring Diagram — Ignition Power Supply —"](#).
- Short circuit in harness between IPDM E/R harness connector terminal 21 and output speed sensor harness connector terminal 3.
- 10A fuse (No.49, IPDM E/R). Refer to [PG-60, "IPDM E/R Terminal Arrangement"](#).
- IPDM E/R

Is the check result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

NO >> Repair or replace malfunctioning parts.

P0740 TORQUE CONVERTER

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

P0740 TORQUE CONVERTER

DTC Logic

INFOID:000000009019693

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P0740	Torque Converter Clutch Circuit/Open	The TCM torque converter clutch solenoid valve current monitor reading is 200 mA or less continuously for 5 seconds or more under the following diagnosis conditions: • Diagnosis conditions - Solenoid valve output current: 750 mA or more - GND short diagnosis of the solenoid valve circuit is not satisfied. - TCM power supply voltage: More than 11 V	• Harness or connector (Torque converter clutch solenoid valve circuit is open or shorted to power supply) • Torque converter clutch solenoid valve

DTC CONFIRMATION PROCEDURE

CAUTION:

Be careful of the driving speed.

1. PREPARATION BEFORE OPERATION (PART 1)

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. PREPARATION BEFORE OPERATION (PART 2)

With CONSULT

1. Start the engine.
2. Select "Data Monitor" in "TRANSMISSION".
3. Select "FLUID TEMP".
4. Confirm that the CVT fluid temperature is in the following range.

FLUID TEMP : 10°C (50°F) or more

With GST

1. Start the engine.
2. Set the CVT fluid to 10°C (50°F) or more.

NOTE:

When the ambient temperature is 20°C (68°F), the CVT fluid usually increases to 50 to 80°C (122 to 176°F) with driving in an urban area for approximately 10 minutes.

Is the CVT fluid 10°C (50°F) or more?

YES >> GO TO 3.

NO >> 1. Warm the transaxle.
2. GO TO 3.

3. CHECK DTC DETECTION

1. Drive the vehicle.
2. Maintain the following conditions for 10 seconds or more.

Selector lever : "D" position
Vehicle speed : 40 km/h (25 MPH) or more

3. Stop the vehicle.
4. Check the first trip DTC.

Is "P0740" detected?

YES >> Go to [TM-166, "Diagnosis Procedure"](#).
NO >> INSPECTION END

P0740 TORQUE CONVERTER

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

Diagnosis Procedure

INFOID:000000009019694

1.CHECK CIRCUIT BETWEEN TCM AND CVT UNIT

1. Turn ignition switch OFF.
2. Disconnect TCM connector and CVT unit connector.
3. Check continuity between TCM harness connector terminal and CVT unit harness connector terminal.

TCM		CVT unit		Continuity
Connector	Terminal	Connector	Terminal	
F44	38	F46	8	Existed

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace malfunctioning parts.

2.CHECK TORQUE CONVERTER CLUTCH SOLENOID VALVE

Check torque converter clutch solenoid valve. Refer to [TM-166, "Component Inspection \(Torque Converter Clutch Solenoid Valve\)"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

NO >> Repair or replace malfunctioning parts.

Component Inspection (Torque Converter Clutch Solenoid Valve)

INFOID:000000009019695

1.CHECK TORQUE CONVERTER CLUTCH SOLENOID VALVE

Check resistance between CVT unit connector terminal and ground.

CVT unit Terminal	—	Condition	Resistance (Approx.)
8	Ground	CVT fluid temperature: 20°C (68°F)	6.1 Ω
		CVT fluid temperature: 50°C (122°F)	6.9 Ω
		CVT fluid temperature: 80°C (176°F)	7.7 Ω

Is the inspection result normal?

YES >> INSPECTION END

NO >> There is a malfunction of torque converter clutch solenoid valve. Replace transaxle assembly.
Refer to [TM-252, "Removal and Installation"](#).

P0743 TORQUE CONVERTER

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

P0743 TORQUE CONVERTER

DTC Logic

INFOID:000000009019696

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P0743	Torque Converter Clutch Circuit Electrical	The TCM torque converter clutch solenoid valve current monitor reading is 200 mA or less continuously for 480 msec or more under the following diagnosis conditions: • Diagnosis conditions - Solenoid valve output current: 750 mA or more - GND short circuit diagnosis occurs in the solenoid valve drive circuit. - TCM power supply voltage: More than 11 V	• Harness or connector (Torque converter clutch solenoid valve circuit is shorted to ground) • Torque converter clutch solenoid valve

DTC CONFIRMATION PROCEDURE

CAUTION:

Be careful of the driving speed.

1. PREPARATION BEFORE OPERATION (PART 1)

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. PREPARATION BEFORE OPERATION (PART 2)

With CONSULT

1. Start the engine.
2. Select "Data Monitor" in "TRANSMISSION".
3. Select "FLUID TEMP".
4. Confirm that the CVT fluid temperature is in the following range.

FLUID TEMP : 10°C (50°F) or more

With GST

1. Start the engine.
2. Set the CVT fluid to 10°C (58°F) or more.

NOTE:

When the ambient temperature is 20°C (68°F), the CVT fluid usually increases to 50 to 80°C (122 to 176°F) with driving in an urban area for approximately 10 minutes.

Is the CVT fluid 10°C (58°F) or more?

YES >> GO TO 3.

- NO >> 1. Warm the transaxle.
2. GO TO 3.

3. CHECK DTC DETECTION

1. Drive the vehicle.
2. Maintain the following conditions for 5 seconds or more.

Selector lever : "D" position
Vehicle speed : 40 km/h (25 MPH) or more

3. Stop the vehicle.
4. Check the first trip DTC.

Is "P0743" detected?

- YES >> Go to [TM-168, "Diagnosis Procedure"](#).
NO >> INSPECTION END

P0743 TORQUE CONVERTER

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

Diagnosis Procedure

INFOID:000000009019697

1.CHECK CIRCUIT BETWEEN TCM AND CVT UNIT

1. Turn ignition switch OFF.
2. Disconnect TCM connector and CVT unit connector.
3. Check continuity between TCM harness connector terminal and ground.

TCM		—	Continuity
Connector	Terminal		
F44	38	Ground	Not existed

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace malfunctioning parts.

2.CHECK TORQUE CONVERTER CLUTCH SOLENOID VALVE

Check torque converter clutch solenoid valve. Refer to [TM-168, "Component Inspection \(Torque Converter Clutch Solenoid Valve\)"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

NO >> Repair or replace malfunctioning parts.

Component Inspection (Torque Converter Clutch Solenoid Valve)

INFOID:000000009019698

1.CHECK TORQUE CONVERTER CLUTCH SOLENOID VALVE

Check resistance between CVT unit connector terminal and ground.

CVT unit Terminal	—	Condition	Resistance (Approx.)
8	Ground	CVT fluid temperature: 20°C (68°F)	6.1 Ω
		CVT fluid temperature: 50°C (122°F)	6.9 Ω
		CVT fluid temperature: 80°C (176°F)	7.7 Ω

Is the inspection result normal?

YES >> INSPECTION END

NO >> There is a malfunction of torque converter clutch solenoid valve. Replace transaxle assembly.
Refer to [TM-252, "Removal and Installation"](#).

P0744 TORQUE CONVERTER

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

P0744 TORQUE CONVERTER

DTC Logic

INFOID:000000009019699

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P0744	Torque converter clutch circuit intermittent	The torque converter slip speed is at or above a set value (40 rpm + (Vehicle speed / 2) continuously for 30 seconds or more under the following diagnosis conditions: • Diagnosis conditions - Selector lever: "D" position - Accelerator pedal position: 1.0/8 or more - Vehicle speed: 10 km/h (6 MPH) or more - Engine speed: 450 rpm or more - CVT fluid temperature: 20°C (68°F) ≤ CVT fluid temperature ≤ 180°C (356°F) - Lockup command is being given (except for slip lockup). - LU PRS: More than 0.2 MPa - TCM power supply voltage: More than 11 V	• Torque converter clutch solenoid valve • Control valve assembly • Torque converter

DTC CONFIRMATION PROCEDURE

CAUTION:

Be careful of the driving speed.

1. PREPARATION BEFORE OPERATION 1

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. PREPARATION BEFORE OPERATION 2

With CONSULT

1. Start the engine.
2. Select "Data Monitor" in "TRANSMISSION".
3. Select "FLUID TEMP".
4. Confirm that the CVT fluid temperature is in the range below.

FLUID TEMP : 20°C (68°F) or more

With GST

1. Start the engine.
2. Set the CVT fluid to 20°C (68°F) or more.

NOTE:

When the ambient temperature is 20°C (68°F), the CVT fluid usually increases to 50 to 80°C (122 to 176°F) with driving in an urban area for approximately 10 minutes.

Is the CVT fluid 20°C (68°F) or more?

YES >> GO TO 3.

NO >> 1. Warm the transaxle.

2. GO TO 3.

3. CHECK DTC DETECTION

1. Drive the vehicle.
2. Maintain the following conditions for 40 seconds or more.

Selector lever : "D" position
Accelerator pedal position : 1.0/8 or more
Vehicle speed : 40 km/h (25 MPH) or more

P0744 TORQUE CONVERTER

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

3. Stop the vehicle.
4. Check the first trip DTC.

Is "P0744" detected?

- YES >> Go to [TM-170, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009019700

1.CHECK LINE PRESSURE

Perform line pressure test. Refer to [TM-132, "Work Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace the malfunction items.

2.CHECK TORQUE CONVERTER CLUTCH SOLENOID VALVE

1. Turn ignition switch OFF.
2. Disconnect CVT unit connector.
3. Check torque converter clutch solenoid valve. Refer to [TM-170, "Component Inspection \(Torque Converter Clutch Solenoid Valve\)"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace the malfunction items.

3.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

Is the inspection result normal?

- YES >> Replace the transaxle assembly. Refer to [TM-252, "Removal and Installation"](#).
NO >> Repair or replace the malfunction items.

Component Inspection (Torque Converter Clutch Solenoid Valve)

INFOID:000000009019701

1.CHECK TORQUE CONVERTER CLUTCH SOLENOID VALVE

Check resistance between CVT unit connector terminal and ground.

CVT unit Terminal	—	Condition	Resistance (Approx.)
8	Ground	CVT fluid temperature: 20°C (68°F)	6.1 Ω
		CVT fluid temperature: 50°C (122°F)	6.9 Ω
		CVT fluid temperature: 80°C (176°F)	7.7 Ω

Is the inspection result normal?

- YES >> INSPECTION END
NO >> There is a malfunction of torque converter clutch solenoid valve. Replace transaxle assembly.
Refer to [TM-252, "Removal and Installation"](#).

P0746 PRESSURE CONTROL SOLENOID A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

P0746 PRESSURE CONTROL SOLENOID A

DTC Logic

INFOID:000000009019702

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P0746	Pressure Control Solenoid A Performance/Stuck Off	The detecting condition A or detection condition B is detected twice or more (1 second or more later after detection of the first) in the same DC under the following diagnosis conditions: • Diagnosis conditions - After the ignition switch is ON, 500 msec or more have passed. - Selector lever: Other than "P" and "N" positions - Idle is not being detected. - Engine speed: 600 rpm or more - Primary pulley speed: 500 rpm or more - Auxiliary gearbox shifting is not in progress. - Acceleration/deceleration speed: -0.05 G or more - The primary pulley speed experienced 306 rpm or more and the secondary pulley speed experienced 230 rpm or more at least once. - The output speed is 107 rpm or less or the secondary pulley speed exceeds 61 rpm. • Detection condition A - Status with the shifting ratio of the primary pulley speed/secondary pulley ratio exceeding 2.55 is 200 msec or more continuously. • Detection condition B - Status with the shifting ratio of the primary pulley speed/secondary pulley ratio exceeding 3.35 is 100 msec or more continuously.	• Line pressure solenoid valve • Control valve assembly

NOTE:

DC stands for "DRIVING CYCLE" and indicates a series of driving cycle of "Ignition switch OFF → ON → driving → OFF".

DTC CONFIRMATION PROCEDURE

CAUTION:

Be careful of the driving speed.

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

1. Start the engine.
2. Drive the vehicle.
3. Maintain the following conditions for 10 seconds or more.

Selector lever	: "D" position
Accelerator pedal position	: 0.1/8 or more
Vehicle speed	: 40 km/h (25 MPH) or more

P0746 PRESSURE CONTROL SOLENOID A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

4. Stop the vehicle.
5. Check the first trip DTC.

Is "P0746" detected?

- YES >> Go to [TM-172, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000009019703

1. CHECK LINE PRESSURE SOLENOID VALVE

1. Turn ignition switch OFF.
2. Disconnect CVT unit connector.
3. Check line pressure solenoid valve. Refer to [TM-172, "Component Inspection \(Line Pressure Solenoid Valve\)"](#)

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace malfunctioning parts.

2. CHECK LINE PRESSURE

Perform line pressure test. Refer to [TM-132, "Work Procedure"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).
NO >> Repair or replace malfunctioning parts.

Component Inspection (Line Pressure Solenoid Valve)

INFOID:0000000009019704

1. CHECK LINE PRESSURE SOLENOID VALVE

Check resistance between CVT unit connector terminal and ground.

CVT unit Terminal	—	Condition	Resistance (Approx.)
1	Ground	CVT fluid temperature: 20°C (68°F)	5.3 Ω
		CVT fluid temperature: 50°C (122°F)	6.0 Ω
		CVT fluid temperature: 80°C (176°F)	6.7 Ω

Is the inspection result normal?

- YES >> INSPECTION END
NO >> There is a malfunction of line pressure solenoid valve. Replace transaxle assembly. Refer to [TM-252, "Removal and Installation"](#).

P0846 TRANSMISSION FLUID PRESSURE SEN/SW B

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

P0846 TRANSMISSION FLUID PRESSURE SEN/SW B

DTC Logic

INFOID:000000009019705

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P0846	Transmission Fluid Pressure Sensor/Switch B Circuit Range/Performance	The detection conditions continuously for 5 seconds or more under the following diagnosis conditions: • Diagnosis conditions - Selector lever: "D" position - The primary pulley speed experienced 306 rpm or more and the secondary pulley speed experienced 230 rpm or more at least once. - Wheel spin is not being detected. - The rate of change in pulley ratio: Between -0.09 and +0.09 inclusive - Solenoid valve output current: 750 mA or more - GND short diagnosis of the solenoid valve circuit is not satisfied. - TCM power supply voltage: More than 11 V • Detection conditions - After the value of "Actual secondary pressure – Target secondary pressure" exceeds 0.675 MPa: • The rate of change in vehicle speed [km/h (MPH)]: Between -49 (-30) and +49 (+30) inclusive • The rate of change in accelerator pedal angle: Between -1.3/8 and +1.3/8 inclusive	• Secondary pressure sensor • Control valve assembly

DTC CONFIRMATION PROCEDURE

CAUTION:

Be careful of the driving speed.

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

1. Start the engine.
2. Shift the selector lever to "D" position.
3. Drive the vehicle at a constant velocity of 40 km/h (25 MPH) at least for 10 seconds.

CAUTION:

At the same time, the accelerator pedal angle must be maintained constant.

4. Stop the vehicle.
5. Check the first trip DTC.

Is "P0846" detected?

- YES >> Go to [TM-173. "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009019706

1. CHECK TCM INPUT SIGNAL

1. Start the engine.
2. Check voltage between TCM connector terminal and ground.

P0846 TRANSMISSION FLUID PRESSURE SEN/SW B

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

+		–	Condition	Voltage
TCM				
Connector	Terminal			
F44	16	Ground	• Selector lever: “N” position • At idle	0.88 – 0.92 V

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

NO >> There is a malfunction of secondary pressure sensor value. Replace transaxle assembly. Refer to [TM-252, "Removal and Installation"](#).

P0847 TRANSMISSION FLUID PRESSURE SEN/SW B

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

P0847 TRANSMISSION FLUID PRESSURE SEN/SW B

DTC Logic

INFOID:000000009019707

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P0847	Transmission Fluid Pressure Sensor/Switch B Circuit Low	The secondary pressure sensor voltage is 0.09 V or less continuously for 5 seconds or more under the following diagnosis conditions: • Diagnosis conditions - CVT fluid temperature: -20°C (-4°F) or more - TCM power supply voltage: More than 11 V	• Harness or connector (Secondary pressure sensor circuit is open or shorted to ground) • Secondary pressure sensor • Control valve assembly

DTC CONFIRMATION PROCEDURE

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

With CONSULT

1. Start the engine.
2. Select "Data Monitor" in "TRANSMISSION".
3. Select "FLUID TEMP".
4. Maintain the following conditions for 10 seconds or more.

FLUID TEMP : -19°C (-2.2°F) or more

5. Check the first trip DTC.

With GST

1. Start the engine and wait for at least 10 seconds.

CAUTION:

When the ambient temperature is -20°C (-4°F) or less and the engine is cold, warm up the engine for approximately 5 minutes.

2. Check the first trip DTC.

Is "P0847" detected?

YES >> Go to [TM-175, "Diagnosis Procedure"](#).

NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009019708

1. CHECK CIRCUIT BETWEEN TCM AND CVT UNIT (PART 1)

1. Turn ignition switch OFF.
2. Disconnect TCM connector and CVT unit connector.
3. Check continuity between TCM harness connector terminals and CVT unit harness connector terminals.

TCM		CVT unit		Continuity
Connector	Terminal	Connector	Terminal	
F44	11	F46	18	Existed
	16		14	
	26		22	

Is the inspection result normal?

P0847 TRANSMISSION FLUID PRESSURE SEN/SW B

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

YES >> GO TO 2.

NO >> Repair or replace malfunctioning parts.

2.CHECK CIRCUIT BETWEEN TCM AND CVT UNIT (PART 2)

Check continuity between TCM harness connector terminals and ground.

TCM		—	Continuity
Connector	Terminal		
F44	16	Ground	Not existed
	26		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace malfunctioning parts.

3.CHECK TCM INPUT SIGNALS

1. Connect all connectors removed.
2. Start the engine.
3. Check voltage between TCM harness connector terminal and ground.

+		–	Condition	Voltage
TCM				
Connector	Terminal			
F44	16	Ground	• Selector lever: “N” position • At idle	0.88 – 0.92 V

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

NO >> There is malfunction of secondary pressure sensor. Replace transaxle assembly. Refer to [TM-252, "Removal and Installation"](#).

P0848 TRANSMISSION FLUID PRESSURE SEN/SW B

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

P0848 TRANSMISSION FLUID PRESSURE SEN/SW B

DTC Logic

INFOID:0000000009019709

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P0848	Transmission Fluid Pressure Sensor/Switch B Circuit Low	The secondary pressure sensor voltage is 4.7 V or more continuously for 5 seconds or more under the following diagnosis conditions: • Diagnosis conditions - CVT fluid temperature: -20°C (-4°F) or more - Secondary pressure target value: 5.7 MPa or less - TCM power supply voltage: More than 11 V	• Harness or connector (Secondary pressure sensor circuit is shorted to power supply) • Secondary pressure sensor • Control valve assembly

DTC CONFIRMATION PROCEDURE

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, the ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

With CONSULT

1. Start the engine.
2. Select "Data Monitor" in "TRANSMISSION".
3. Select "FLUID TEMP".
4. Maintain the following conditions for 10 seconds or more.

FLUID TEMP : -19°C (-2.2°F) or more

5. Check the first trip DTC.

With GST

1. Start the engine and wait for at least 10 seconds.

CAUTION:

When the ambient temperature is -20°C (-4°F) or less and the engine is cold, warm up the engine for approximately 5 minutes.

2. Check the first trip DTC.

Is "P0848" detected?

YES >> Go to [TM-177, "Diagnosis Procedure"](#).

NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000009019710

1. CHECK SECONDARY PRESSURE SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect CVT unit connector.
3. Turn ignition switch ON.
4. Check voltage between CVT unit harness connector terminal and ground.

+		-	Voltage (Approx.)
CVT unit			
Connector	Terminal		
F46	22	Ground	5.0 V

Is the inspection result normal?

P0848 TRANSMISSION FLUID PRESSURE SEN/SW B

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

- YES >> GO TO 2.
NO >> Repair or replace malfunctioning parts.

2.CHECK SECONDARY PRESSURE SENSOR SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect TCM connector.
3. Check continuity between TCM harness connector terminals.

TCM			Continuity
Connector	Terminal		
F46	22	Other than 22	Not existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace malfunctioning parts.

3.CHECK TCM INPUT SIGNALS

1. Connect all connectors removed.
2. Start the engine.
3. Check voltage between TCM harness connector terminal and ground.

+		–	Condition	Voltage
TCM				
Connector	Terminal			
F46	22	Ground	• Selector lever: “N” position • At idle	0.88 – 0.92 V

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).
NO >> There is a malfunction of secondary pressure sensor. Replace transaxle assembly. Refer to [TM-252, "Removal and Installation"](#).

P0863 TCM COMMUNICATION

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

P0863 TCM COMMUNICATION

DTC Logic

INFOID:0000000009019711

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P0863	TCM Communication Circuit	An error is detected at the initial CAN diagnosis of TCM.	TCM

DTC CONFIRMATION PROCEDURE

1.PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2.CHECK DTC DETECTION

1. Turn ignition switch ON.
2. Check the DTC.

Is "P0863" detected?

YES >> Go to [TM-179, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000009019712

1.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

Is the inspection result normal?

YES >> Replace TCM. Refer to [TM-237, "Removal and Installation"](#).
NO >> Repair or replace malfunctioning parts.

P0890 TCM

DTC Logic

INFOID:000000009019713

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P0890	Transmission control module power relay sense circuit low	The battery voltage supplied to the TCM is less than 8.4 V continuously for 200 msec or more under the following diagnosis condition: • Diagnosis condition - TCM power supply voltage: More than 11 V	• Harness or connector (TCM power supply (back-up) circuit is open or shorted.) • TCM

DTC CONFIRMATION PROCEDURE

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

1. Start the engine and wait for 5 seconds or more.
2. Check the DTC.

Is "P0890" detected?

- YES >> Go to [TM-180, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009019714

1. CHECK TCM POWER SUPPLY (BACK-UP) CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect TCM connector.
3. Check voltage between TCM harness connector terminals and ground.

+		–	Voltage
TCM			
Connector	Terminal		
F44	45	Ground	10 – 16 V
	46		

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> GO TO 3.

2. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

Is the inspection result normal?

- YES >> Replace TCM. Refer to [TM-237, "Removal and Installation"](#).
 NO >> Repair or replace malfunctioning parts.

3. DETECT MALFUNCTIONING ITEMS

Check the following items:

- Open circuit or short circuit in harness between battery positive terminal and TCM connectors terminals 45, and 46.
- 10A fuse (No.25, fuse and fusible link block). Refer to [PG-59, "Terminal Arrangement"](#).

Is the inspection result normal?

P0890 TCM

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

YES >> Check intermittent incident. Refer to [GI-41. "Intermittent Incident"](#).
NO >> Repair or replace malfunctioning parts.

A

B

C

TM

E

F

G

H

I

J

K

L

M

N

O

P

P0962 PRESSURE CONTROL SOLENOID A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

P0962 PRESSURE CONTROL SOLENOID A

DTC Logic

INFOID:000000009019715

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P0962	Pressure Control Solenoid A Control Circuit Low	The line pressure solenoid valve current is 200 mA or less continuously for 200 msec or more under the following diagnosis conditions: • Diagnosis conditions - Solenoid output current: 750 mA or more - GND short diagnosis of the solenoid drive circuit is satisfied. - TCM power supply voltage: More than 11 V	• Harness or connector (Line pressure solenoid valve circuit is shorted to ground) • Line pressure solenoid valve

DTC CONFIRMATION PROCEDURE

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

1. Start the engine and wait for 5 seconds or more.
2. Check the first trip DTC.

Is "P0962" detected?

YES >> Go to [TM-182, "Diagnosis Procedure"](#).

NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009019716

1. CHECK CIRCUIT BETWEEN TCM AND CVT UNIT

1. Turn ignition switch OFF.
2. Disconnect TCM connector and CVT unit connector.
3. Check continuity between TCM harness connector terminal and ground.

TCM		—	Continuity
Connector	Terminal		
F44	30	Ground	Not existed

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace malfunctioning parts.

2. CHECK LINE PRESSURE SOLENOID VALVE

Check line pressure solenoid valve. Refer to [TM-182, "Component Inspection \(Line Pressure Solenoid Valve\)"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

NO >> Repair or replace malfunctioning parts.

Component Inspection (Line Pressure Solenoid Valve)

INFOID:000000009019717

1. CHECK LINE PRESSURE SOLENOID VALVE

Check resistance between CVT unit connector terminal and ground.

P0962 PRESSURE CONTROL SOLENOID A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

CVT unit Terminal	—	Condition	Resistance (Approx.)
1	Ground	CVT fluid temperature: 20°C (68°F)	5.3 Ω
		CVT fluid temperature: 50°C (122°F)	6.0 Ω
		CVT fluid temperature: 80°C (176°F)	6.7 Ω

Is the inspection result normal?

YES >> INSPECTION END

NO >> There is a malfunction of line pressure solenoid valve. Replace transaxle assembly. Refer to [TM-252. "Removal and Installation"](#).

P0963 PRESSURE CONTROL SOLENOID A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

P0963 PRESSURE CONTROL SOLENOID A

DTC Logic

INFOID:000000009019718

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P0963	Pressure Control Solenoid A Control Circuit High	The line pressure solenoid valve current is 200 mA or less continuously for 200 msec or more under the following diagnosis conditions: • Diagnosis conditions - Solenoid output current: 750 mA or more - GND short diagnosis of the solenoid drive circuit is not satisfied. - TCM power supply voltage: More than 11 V	• Harness or connector (Line pressure solenoid valve circuit is open or shorted to power supply) • Line pressure solenoid valve

DTC CONFIRMATION PROCEDURE

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

1. Start the engine and wait for 5 seconds or more.
2. Check the first trip DTC.

Is "P0963" detected?

YES >> Go to [TM-184, "Diagnosis Procedure"](#).

NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009019719

1. CHECK CIRCUIT BETWEEN TCM AND CVT UNIT

1. Turn ignition switch OFF.
2. Disconnect TCM connector and CVT unit connector.
3. Check continuity between TCM harness connector terminal and CVT unit harness connector terminal.

TCM		CVT unit		Continuity
Connector	Terminal	Connector	Terminal	
F44	30	F46	1	Existed

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace malfunctioning parts.

2. CHECK LINE PRESSURE SOLENOID VALVE

Check line pressure solenoid valve. Refer to [TM-184, "Component Inspection \(Line Pressure Solenoid Valve\)"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

NO >> Repair or replace malfunctioning parts.

Component Inspection (Line Pressure Solenoid Valve)

INFOID:000000009019720

1. CHECK LINE PRESSURE SOLENOID VALVE

Check resistance between CVT unit connector terminal and ground.

P0963 PRESSURE CONTROL SOLENOID A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

CVT unit Terminal	—	Condition	Resistance (Approx.)
1	Ground	CVT fluid temperature: 20°C (68°F)	5.3 Ω
		CVT fluid temperature: 50°C (122°F)	6.0 Ω
		CVT fluid temperature: 80°C (176°F)	6.7 Ω

Is the inspection result normal?

YES >> INSPECTION END

NO >> There is a malfunction of line pressure solenoid valve. Replace transaxle assembly. Refer to [TM-252. "Removal and Installation"](#).

P0965 PRESSURE CONTROL SOLENOID B

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

P0965 PRESSURE CONTROL SOLENOID B

DTC Logic

INFOID:000000009019721

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P0965	Pressure control solenoid B control circuit range performance	The detection conditions continuously for 5 seconds or more under the following diagnosis conditions: • Diagnosis conditions - Selector lever: Other than "P" and "N" positions - Auxiliary gearbox shifting is not in progress. - Engine speed: More than 500 rpm • Detection condition A - Actual primary pulley ratio: 2.0 – 2.4 - Target primary pulley ratio: Less than 1.2 • Detection condition B - Actual primary pulley ratio: 0.35 – 0.75 - Target primary pulley ratio: More than 1.55	Primary pressure solenoid valve

DTC CONFIRMATION PROCEDURE

CAUTION:

- Be sure to perform "[TM-186, "Diagnosis Procedure"](#)" and then perform "DTC CONFIRMATION PROCEDURE".
- Never perform "DTC CONFIRMATION PROCEDURE" before the repairs. Doing so may result in a secondary malfunction.
- Be careful of the driving speed.

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

1. Start the engine.
2. Drive the vehicle.
3. Maintain the following conditions for 20 seconds or more.

Vehicle speed : 20 km/h (13 MPH) or more

4. Stop the vehicle.
5. Check the first trip DTC.

Is "P0965" detected?

YES >> Go to [TM-186, "Diagnosis Procedure"](#).

NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009019722

1. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

Is the inspection result normal?

YES >> Replace transaxle assembly. Refer to [TM-252, "Removal and Installation"](#).

NO >> Repair or replace malfunctioning parts.

P0966 PRESSURE CONTROL SOLENOID B

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

P0966 PRESSURE CONTROL SOLENOID B

DTC Logic

INFOID:000000009019723

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P0966	Pressure control solenoid B control circuit low	The primary pressure solenoid valve current is 200 mA or less continuously for 480 msec or more under the following diagnosis conditions: • Diagnosis conditions - Solenoid valve output current: 750 mA or more - GND short circuit diagnosis occurs in the solenoid valve drive circuit. - TCM power supply voltage: More than 11 V	• Harness or connector (Primary pressure solenoid valve circuit shorted to ground) • Primary pressure solenoid valve

DTC CONFIRMATION PROCEDURE

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

1. Start the engine and wait for 5 seconds or more.
2. Check the first trip DTC.

Is "P0966" detected?

YES >> Go to [TM-187, "Diagnosis Procedure"](#).

NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009019724

1. CHECK CIRCUIT BETWEEN TCM AND CVT UNIT

1. Turn ignition switch OFF.
2. Disconnect TCM connector and CVT unit connector.
3. Check continuity between TCM harness connector terminal and ground.

TCM		—	Continuity
Connector	Terminal		
F44	40	Ground	Not existed

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace malfunctioning parts.

2. CHECK PRIMARY PRESSURE SOLENOID VALVE

Check primary pressure solenoid valve. Refer to [TM-187, "Component Inspection \(Primary Pressure Solenoid Valve\)"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

NO >> Repair or replace malfunctioning parts.

Component Inspection (Primary Pressure Solenoid Valve)

INFOID:000000009019725

1. CHECK PRIMARY PRESSURE SOLENOID VALVE

Check resistance between CVT unit connector terminal and ground.

P0966 PRESSURE CONTROL SOLENOID B

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

CVT unit Terminal	—	Condition	Resistance (Approx.)
2	Ground	CVT fluid temperature: 20°C (68°F)	5.3 Ω
		CVT fluid temperature: 50°C (122°F)	6.0 Ω
		CVT fluid temperature: 80°C (176°F)	6.7 Ω

Is the inspection result normal?

YES >> INSPECTION END

NO >> There is a malfunction of primary pressure solenoid valve. Replace transaxle assembly. Refer to [TM-252. "Removal and Installation"](#).

P0967 PRESSURE CONTROL SOLENOID B

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

P0967 PRESSURE CONTROL SOLENOID B

DTC Logic

INFOID:0000000009019726

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P0967	Pressure control solenoid B control circuit high	The primary pressure solenoid valve current is 200 mA or less continuously for 200 msec or more under the following diagnosis conditions: • Diagnosis conditions - Solenoid valve output current: 750 mA or more - GND short diagnosis of the solenoid valve circuit is not satisfied. - TCM power supply voltage: More than 11 V	• Harness or connector (Primary pressure solenoid valve circuit open or shorted to power supply) • Primary pressure solenoid valve

DTC CONFIRMATION PROCEDURE

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

1. Start the engine and wait for 5 seconds or more.
2. Check the first trip DTC.

Is "P0967" detected?

YES >> Go to [TM-189, "Diagnosis Procedure"](#).

NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000009019727

1. CHECK CIRCUIT BETWEEN TCM AND CVT UNIT

1. Turn ignition switch OFF.
2. Disconnect TCM connector and CVT unit connector.
3. Check continuity between TCM harness connector terminal and CVT unit harness connector terminal.

TCM		CVT unit		Continuity
Connector	Terminal	Connector	Terminal	
F44	40	F46	2	Existed

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace malfunctioning parts.

2. CHECK PRIMARY PRESSURE SOLENOID VALVE

Check primary pressure solenoid valve. Refer to [TM-189, "Component Inspection \(Primary Pressure Solenoid Valve\)"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

NO >> Repair or replace malfunctioning parts.

Component Inspection (Primary Pressure Solenoid Valve)

INFOID:0000000009019728

1. CHECK PRIMARY PRESSURE SOLENOID VALVE

Check resistance between CVT unit connector terminal and ground.

P0967 PRESSURE CONTROL SOLENOID B

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

CVT unit Terminal	—	Condition	Resistance (Approx.)
2	Ground	CVT fluid temperature: 20°C (68°F)	5.3 Ω
		CVT fluid temperature: 50°C (122°F)	6.0 Ω
		CVT fluid temperature: 80°C (176°F)	6.7 Ω

Is the inspection result normal?

YES >> INSPECTION END

NO >> There is a malfunction of primary pressure solenoid valve. Replace transaxle assembly. Refer to [TM-252. "Removal and Installation"](#).

P0998 SHIFT SOLENOID F

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

P0998 SHIFT SOLENOID F

DTC Logic

INFOID:0000000009019729

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P0998	Shift solenoid F control circuit low	The TCM low brake solenoid valve current monitor reading is 200 mA or less continuously for 480 msec or more under the following diagnosis conditions: • Diagnosis conditions - Solenoid valve output current: 750 mA or more - GND short circuit diagnosis occurs in the solenoid valve drive circuit. - TCM power supply voltage: More than 11 V	• Harness or connector (Low brake solenoid valve circuit shorted to ground) • Low brake solenoid valve

DTC CONFIRMATION PROCEDURE

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

1. Start the engine.
2. Shift the selector lever to "D" position and wait for 5 seconds or more.
3. Check the first trip DTC.

Is "P0998" detected?

YES >> Go to [TM-191, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000009019730

1. CHECK CIRCUIT BETWEEN TCM AND CVT UNIT

1. Turn ignition switch OFF.
2. Disconnect TCM connector and CVT unit connector.
3. Check continuity between TCM harness connector terminal and ground.

TCM		Ground	Continuity
Connector	Terminal		
F44	39	Ground	Not existed

Is the inspection result normal?

YES >> GO TO 2.
NO >> Repair or replace malfunctioning parts.

2. CHECK LOW BRAKE SOLENOID VALVE

Check low brake solenoid valve. Refer to [TM-191, "Component Inspection \(Low Brake Solenoid Valve\)"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).
NO >> Repair or replace malfunctioning parts.

Component Inspection (Low Brake Solenoid Valve)

INFOID:0000000009019731

1. CHECK LOW BRAKE SOLENOID VALVE

P0998 SHIFT SOLENOID F

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

Check resistance between CVT unit connector terminal and ground.

CVT unit Terminal	—	Condition	Resistance (Approx.)
6	Ground	CVT fluid temperature: 20°C (68°F)	5.3 Ω
		CVT fluid temperature: 50°C (122°F)	6.0 Ω
		CVT fluid temperature: 80°C (176°F)	6.7 Ω

Is the inspection result normal?

YES >> INSPECTION END

NO >> There is a malfunction of low brake solenoid valve. Replace transaxle assembly. Refer to [TM-252](#).
["Removal and Installation"](#).

P0999 SHIFT SOLENOID F

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

P0999 SHIFT SOLENOID F

DTC Logic

INFOID:0000000009019732

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P0999	Shift solenoid F control circuit high	The TCM low brake solenoid valve current monitor reading is 200 mA or less continuously for 200 msec or more under the following diagnosis conditions: • Diagnosis conditions - Solenoid valve output current: 750 mA or more - GND short diagnosis of the solenoid valve circuit is not satisfied. - TCM power supply voltage: More than 11 V	• Harness or connector (Low brake solenoid valve circuit is open or shorted to power supply) • Low brake solenoid valve

DTC CONFIRMATION PROCEDURE

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

1. Start the engine.
2. Shift the selector lever to "D" position and wait for 5 seconds or more.
3. Check the first trip DTC.

Is "P0999" detected?

YES >> Go to [TM-193, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000009019733

1. CHECK CIRCUIT BETWEEN TCM AND CVT UNIT

1. Turn ignition switch OFF.
2. Disconnect TCM connector and CVT unit connector.
3. Check continuity between TCM harness connector terminal and CVT unit harness connector terminal.

TCM		CVT unit		Continuity
Connector	Terminal	Connector	Terminal	
F44	39	F46	6	Existed

Is the inspection result normal?

YES >> GO TO 2.
NO >> Repair or replace malfunctioning parts.

2. CHECK LOW BRAKE SOLENOID VALVE

Check low brake solenoid valve. Refer to [TM-193, "Component Inspection \(Low Brake Solenoid Valve\)"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).
NO >> Repair or replace malfunctioning parts.

Component Inspection (Low Brake Solenoid Valve)

INFOID:0000000009019734

1. CHECK LOW BRAKE SOLENOID VALVE

P0999 SHIFT SOLENOID F

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

Check resistance between CVT unit connector terminal and ground.

CVT unit Terminal	—	Condition	Resistance (Approx.)
6	Ground	CVT fluid temperature: 20°C (68°F)	5.3 Ω
		CVT fluid temperature: 50°C (122°F)	6.0 Ω
		CVT fluid temperature: 80°C (176°F)	6.7 Ω

Is the inspection result normal?

YES >> INSPECTION END

NO >> There is a malfunction of low brake solenoid valve. Replace transaxle assembly. Refer to [TM-252](#).
["Removal and Installation"](#).

P099B SHIFT SOLENOID G

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

P099B SHIFT SOLENOID G

DTC Logic

INFOID:0000000009019735

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P099B	Shift solenoid G control circuit low	The TCM high clutch & reverse brake solenoid valve current monitor reading is 200 mA or less continuously for 200 msec or more under the following diagnosis conditions: • Diagnosis conditions - Solenoid valve output current: 750 mA or more - GND short circuit diagnosis occurs in the solenoid valve drive circuit. - TCM power supply voltage: More than 11 V	• Harness or connector (High& clutch reverse brake solenoid valve circuit shorted to ground) • High clutch & reverse brake solenoid valve

DTC CONFIRMATION PROCEDURE

1.PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2.CHECK DTC DETECTION

1. Start the engine and wait for 5 seconds or more.
2. Check the first trip DTC.

Is "P099B" detected?

YES >> Go to [TM-195, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000009019736

1.CHECK CIRCUIT BETWEEN TCM AND CVT UNIT

1. Turn ignition switch OFF.
2. Disconnect TCM connector and CVT unit connector.
3. Check continuity between TCM harness connector terminal and ground.

TCM		—	Continuity
Connector	Terminal		
F44	37	Ground	Not existed

Is the inspection result normal?

YES >> GO TO 2.
NO >> Repair or replace malfunctioning parts.

2.CHECK HIGH CLUTCH & REVERSE BRAKE SOLENOID VALVE

Check high clutch & reverse brake solenoid valve. Refer to [TM-195, "Component Inspection \(High Clutch & Reverse Brake Solenoid Valve\)"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).
NO >> Repair or replace malfunctioning parts.

Component Inspection (High Clutch & Reverse Brake Solenoid Valve)

INFOID:0000000009019737

1.CHECK HIGH CLUTCH & REVERSE BRAKE SOLENOID VALVE

P099B SHIFT SOLENOID G

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

Check resistance between CVT unit connector terminal and ground.

CVT unit Terminal	—	Condition	Resistance (Approx.)
7	Ground	CVT fluid temperature: 20°C (68°F)	5.3 Ω
		CVT fluid temperature: 50°C (122°F)	6.0 Ω
		CVT fluid temperature: 80°C (176°F)	6.7 Ω

Is the inspection result normal?

YES >> INSPECTION END

NO >> There is a malfunction of high & reverse brake solenoid valve. Replace transaxle assembly. Refer to [TM-252, "Removal and Installation"](#).

P099C SHIFT SOLENOID G

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

P099C SHIFT SOLENOID G

DTC Logic

INFOID:0000000009019738

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P099C	Shift solenoid G control circuit high	The TCM high clutch & reverse brake solenoid valve current monitor reading is 200 mA or less continuously for 200 msec or more under the following diagnosis conditions: • Diagnosis conditions - Solenoid valve output current: 750 mA or more - GND short diagnosis of the solenoid valve circuit is not satisfied. - TCM power supply voltage: More than 11 V	• Harness or connector (High clutch & reverse brake solenoid valve circuit is open or shorted to power supply) • High clutch & reverse brake solenoid valve

DTC CONFIRMATION PROCEDURE

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

1. Start the engine and wait for 5 seconds or more
2. Check the first trip DTC.

Is "P099C" detected?

YES >> Go to [TM-197, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000009019739

1. CHECK CIRCUIT BETWEEN TCM AND CVT UNIT

1. Turn ignition switch OFF.
2. Disconnect TCM connector and CVT unit connector.
3. Check continuity between TCM harness connector terminal and CVT unit harness connector terminal.

TCM		CVT unit		Continuity
Connector	Terminal	Connector	Terminal	
F44	37	F46	7	Existed

Is the inspection result normal?

YES >> GO TO 2.
NO >> Repair or replace malfunctioning parts.

2. CHECK HIGH CLUTCH & REVERSE BRAKE SOLENOID VALVE

Check high clutch & reverse brake solenoid valve. Refer to [TM-197, "Component Inspection \(High Clutch & Reverse Brake Solenoid Valve\)"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).
NO >> Repair or replace malfunctioning parts.

Component Inspection (High Clutch & Reverse Brake Solenoid Valve)

INFOID:0000000009019740

1. CHECK HIGH CLUTCH & REVERSE BRAKE SOLENOID VALVE

P099C SHIFT SOLENOID G

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

Check resistance between CVT unit connector terminal and ground.

CVT unit Terminal	—	Condition	Resistance (Approx.)
7	Ground	CVT fluid temperature: 20°C (68°F)	5.3 Ω
		CVT fluid temperature: 50°C (122°F)	6.0 Ω
		CVT fluid temperature: 80°C (176°F)	6.7 Ω

Is the inspection result normal?

YES >> INSPECTION END

NO >> There is a malfunction of high & reverse brake solenoid valve. Replace transaxle assembly. Refer to [TM-252, "Removal and Installation"](#).

P1586 G SENSOR

DTC Logic

INFOID:000000009019741

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P1586	G Sensor Circuit Electrical	When the following diagnosis conditions are satisfied and the detection conditions are satisfied twice in the same DC: • Diagnosis conditions - While driving - TCM power supply voltage: More than 11 V • Detection condition - The G sensor detection voltage is 0.7 V or less continuously for 5 seconds or more.	• Harness or connector (G sensor circuit) • G sensor
		When the following diagnosis conditions are satisfied and the detection conditions are satisfied twice in the same DC: • Diagnosis conditions - While driving - TCM power supply voltage: More than 11 V • Detection condition - The G sensor detection voltage is 3.2 V or more continuously for 5 seconds or more.	

NOTE:

DC stands for "DRIVING CYCLE" and indicates a series of driving cycle of "Ignition switch OFF → ON → driving → OFF".

DTC CONFIRMATION PROCEDURE

CAUTION:

Be careful of the driving speed.

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION **With CONSULT**

1. Start the engine.
2. Drive the vehicle for 10 seconds or more.
3. Stop the vehicle.

CAUTION:

Never stop the engine.

4. Repeat step 2 through 3.
5. Check the DTC.

Is "P1586" detected?

YES >> Go to [TM-199, "Diagnosis Procedure"](#).

NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009019742

1. CHECK G SENSOR SIGNAL **With CONSULT**

1. Park the vehicle on a level surface.
2. Turn ignition switch ON.
3. Select "Data Monitor" in "TRANSMISSION".

P1586 G SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

4. Select "G SEN SLOPE".
5. Swing the vehicle and check if value varies between -40.45% and 40.45%.

Monitor item	Condition	Standard
G SEN SLOPE	Flat road	0%
	Uphill	Positive value (Maximum 40.45%)
	Downhill	Negative value (Minimum -40.45%)

Is the inspection result normal?

- YES >> GO TO 2.
NO >> GO TO 3.

2. G SENSOR CALIBRATION (PART 1)

With CONSULT

1. Select "Self Diagnostic Results" in "TRANSMISSION".
2. Touch "Erase".

>> Perform "G SENSOR CALIBRATION". Refer to [TM-130, "Procedure"](#).

3. CHECK SENSOR POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect G sensor connector.
3. Turn ignition switch ON.
4. Check voltage between G sensor harness connector terminal and ground.

+		-	Voltage (Approx.)
G sensor			
Connector	Terminal		
M83	3	Ground	5.0 V

Is the inspection result normal?

- YES >> GO TO 4.
NO >> GO TO 8.

4. CHECK CIRCUIT BETWEEN TCM AND G SENSOR (PART 1)

1. Turn ignition switch OFF.
2. Disconnect TCM connector.
3. Check continuity between TCM harness connector terminals and G sensor harness connector terminals.

TCM		G sensor		Continuity
Connector	Terminal	Connector	Terminal	
F44	11	M83	2	Existed
	14		1	

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Repair or replace malfunctioning parts.

5. CHECK CIRCUIT BETWEEN TCM AND G SENSOR (PART 2)

Check continuity between TCM harness connector terminals and ground.

TCM		—	Continuity
Connector	Terminal		
F44	14	Ground	Not existed

Is the inspection result normal?

P1586 G SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]


- YES >> GO TO 6.
NO >> Repair or replace malfunctioning parts.

6.CHECK G SENSOR

1. Remove G sensor. [TM-239, "Removal and Installation"](#).
2. Connect the all connectors.
3. Turn ignition switch ON.
4. Check voltage between TCM harness connector terminal and ground.

← : Direction of gravitational force

+		−	Condition	Voltage (Approx.)
TCM				
Connector	Terminal			
F44	14	Ground	Vertical (−1G) (A)	1.17 V
			Horizontal (B)	2.5 V
			Vertical (1G) (C)	3.83 V



Is the inspection result normal?

- YES >> GO TO 7.
NO >> Replace G sensor. [TM-239, "Removal and Installation"](#).

7.G SENSOR CALIBRATION (PART 2)

With CONSULT

1. Install G sensor. [TM-239, "Removal and Installation"](#).
2. Select "Self Diagnostic Results" in "TRANSMISSION".
3. Touch "Erase".

>> Perform "G SENSOR CALIBRATION". Refer to [TM-130, "Procedure"](#).

8.CHECK SENSOR POWER SUPPLY CIRCUIT (PART 1)

1. Turn ignition switch OFF.
2. Disconnect TCM connector.
3. Check continuity between TCM harness connector terminal and G sensor harness connector terminal.

TCM		G sensor		Continuity
Connector	Terminal	Connector	Terminal	
F44	26	M83	3	Existed

Is the inspection result normal?

- YES >> GO TO 9.
NO >> Repair or replace malfunctioning parts.

9.CHECK SENSOR POWER SUPPLY CIRCUIT (PART 2)

Check continuity between TCM harness connector terminal and ground.

TCM		—	Continuity
Connector	Terminal		
F44	26	Ground	Not existed

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).
NO >> Repair or replace malfunctioning parts.

P1588 G SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

P1588 G SENSOR

DTC Logic

INFOID:000000009019743

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P1588	G Sensor Circuit Range/Performance	When the following diagnosis conditions are satisfied and the detection conditions are satisfied twice in the same DC: • Diagnosis condition (1 second or more) - The rate of change in G sensor detection value (mV): Between -15 and +15 inclusive • Detection condition - The rate of change in acceleration/deceleration stays +0.0273 G or more/-0.0273 or less at least for 5 seconds or more.	G sensor

NOTE:

DC stands for "DRIVING CYCLE" and indicates a series of driving cycle of "Ignition switch OFF → ON → driving → OFF".

DTC CONFIRMATION PROCEDURE

CAUTION:

Be careful of the driving speed.

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

With CONSULT

1. Start the engine.
2. Select "Data Monitor" in "TRANSMISSION".
3. Select "G SPEED".
4. Drive the vehicle.
5. Maintain the following conditions for 10 seconds or more.

Selector lever : "D" position

G SPEED : 0.05 G or more

6. Stop the vehicle.

CAUTION:

Never stop the engine.

7. Repeat steps 4 through 6.
8. Check the DTC.

Is "P1588" detected?

YES >> Go to [TM-202, "Diagnosis Procedure"](#).

NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009019744

1. CHECK G SENSOR SIGNAL

With CONSULT

1. Park the vehicle on a level surface.
2. Turn ignition switch ON.
3. Select "Data Monitor" in "TRANSMISSION".
4. Select "G SEN SLOPE".

P1588 G SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

5. Swing the vehicle and check if value varies between -40.45% and 40.45%.

Monitor item	Condition	Standard
G SEN SLOPE	Flat road	0%
	Uphill	Positive value (Maximum 40.45%)
	Downhill	Negative value (Minimum -40.45%)

Is the inspection result normal?

YES >> GO TO 2.

NO >> GO TO 3.

2.G SENSOR CALIBRATION (PART 1)

With CONSULT

1. Select "Self Diagnostic Results" in "TRANSMISSION".
2. Touch "Erase".


>> Perform "G SENSOR CALIBRATION". Refer to [TM-130, "Procedure"](#).

3.CHECK G SENSOR

1. Remove G sensor. [TM-239, "Removal and Installation"](#).
2. Connect the all connectors.
3. Turn ignition switch ON.
4. Check voltage between TCM harness connector terminal and ground.

 : Direction of gravitational force

+		−	Condition	Voltage (Approx.)
TCM				
Connector	Terminal			
F44	14	Ground	Vertical (−1G) (A)	1.17 V
			Horizontal (B)	2.5 V
			Vertical (1G) (C)	3.83 V



Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace G sensor. [TM-239, "Removal and Installation"](#).

4.G SENSOR CALIBRATION (PART 2)

With CONSULT

1. Install G sensor. [TM-239, "Removal and Installation"](#).
2. Select "Self Diagnostic Results" in "TRANSMISSION".
3. Touch "Erase".

>> Perform "G SENSOR CALIBRATION". Refer to [TM-130, "Procedure"](#).

P2765 CLUTCH B SPEED SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

P2765 CLUTCH B SPEED SENSOR

DTC Logic

INFOID:000000009019745

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P2765	Input/Turbine Speed Sensor B Circuit	The secondary speed sensor value is less than 150 rpm continuously for 5 seconds or more under the following diagnosis conditions: • Diagnosis conditions - Primary pulley speed: 1,000 rpm or more - TCM power supply voltage: More than 11 V The secondary pulley speed sensor value is 240 rpm or less continuously for 500 msec or more under the following diagnosis conditions: • Diagnosis condition - 10-msec-ago secondary pulley speed: 1,000 rpm or more - TCM power supply voltage: More than 11 V	• Harness or connector (Secondary speed sensor circuit is open or shorted) • Secondary speed sensor

DTC CONFIRMATION PROCEDURE

CAUTION:

Be careful of the driving speed.

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

1. Start the engine.
2. Drive the vehicle.
3. Maintain the following conditions for 10 seconds or more.

Selector lever : "D" position

Vehicle speed : 55 km/h (34 MPH) or more

4. Stop the vehicle.
5. Check the first trip DTC.

Is "P2765" detected?

YES >> Go to [TM-204, "Diagnosis Procedure"](#).

NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009019746

1. CHECK SECONDARY SPEED SENSOR POWER CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect secondary speed sensor connector.
3. Turn ignition switch ON.
4. Check voltage between secondary speed sensor harness connector terminal and ground.

+		–	Voltage
Secondary speed sensor			
Connector	Terminal		
F48	3	Ground	10 – 16 V

Is the inspection result normal?

P2765 CLUTCH B SPEED SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

YES >> GO TO 2.
NO >> GO TO 6.

2.CHECK SECONDARY SPEED SENSOR GROUND CIRCUIT

Check continuity between of primary speed sensor harness connector terminal and ground.

Secondary speed sensor		—	Continuity
Connector	Terminal		
F48	1	Ground	Existed

Is the inspection result normal?

YES >> GO TO 3.
NO >> Repair or replace malfunctioning parts.

3.CHECK CIRCUIT BETWEEN SECONDARY SPEED SENSOR AND TCM (PART 1)

1. Turn ignition switch OFF.
2. Disconnect TCM connector.
3. Check continuity between secondary speed sensor harness connector terminal and TCM harness connector terminal.

Secondary speed sensor		TCM		Continuity
Connector	Terminal	Connector	Terminal	
F48	2	F44	34	Existed

Is the inspection result normal?

YES >> GO TO 4.
NO >> Repair or replace malfunctioning parts.

4.CHECK CIRCUIT BETWEEN SECONDARY SPEED SENSOR AND TCM (PART 2)

Check continuity between secondary speed sensor harness connector terminal and ground.


Secondary speed sensor		—	Continuity
Connector	Terminal		
F48	2	Ground	Not existed

Is the inspection result normal?

YES >> GO TO 5.
NO >> Repair or replace malfunctioning parts.

5.CHECK TCM INPUT SIGNALS

1. Connect all of disconnected connectors.
2. Lift the vehicle.
3. Start the engine.
4. Check frequency of secondary speed sensor.

+		-	Condition	Frequency (Approx.)
TCM				
Connector	Terminal			
F44	34	Ground	• Selector lever: "L" position • Vehicle speed: 20 km/h (12 MPH)	700 Hz 1mSec/div  5V/div JSDIA1905GB

Is the inspection result normal?

P2765 CLUTCH B SPEED SENSOR

[CVT: RE0F11A]

< DTC/CIRCUIT DIAGNOSIS >

- YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).
NO >> Replace secondary speed sensor. [TM-243, "Removal and Installation"](#).

6. CHECK CIRCUIT BETWEEN IPDM E/R AND SECONDARY SPEED SENSOR

1. Disconnect IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector terminal and secondary speed sensor harness connector terminal.

IPDM E/R		Secondary speed sensor		Continuity
Connector	Terminal	Connector	Terminal	
E45	21	F48	3	Existed

Is the check result normal?

- YES >> GO TO 7.
NO >> Repair or replace malfunctioning parts.

7. DETECT MALFUNCTIONING ITEMS

Check the following items:

- Open circuit or short circuit in harness between ignition switch and IPDM E/R. Refer to [PG-17, "Wiring Diagram — Ignition Power Supply —"](#).
- Short circuit in harness between IPDM E/R harness connector terminal 21 and secondary speed sensor harness connector terminal 3.
- 10A fuse (No.49, IPDM E/R). Refer to [PG-60, "IPDM E/R Terminal Arrangement"](#).
- IPDM E/R

Is the check result normal?

- YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).
NO >> Repair or replace malfunctioning parts.

P2857 CLUTCH A PRESSURE

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

P2857 CLUTCH A PRESSURE

DTC Logic

INFOID:000000009019747

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P2857	Clutch A pressure engagement performance	The auxiliary gearbox gear ratio is 2.232 or more for the auxiliary gearbox 1GR ratio continuously for 5 seconds or more under the following diagnosis conditions: • Diagnosis conditions - Selector lever: Other than "P", "R" and "N" positions - Accelerator pedal position: 0.7/8 or more - Engine speed: More than 550 rpm - Output speed: More than 300 rpm - Secondary pulley speed: More than 300 rpm - Command for the 1GR of auxiliary gearbox is in progress. - Auxiliary gearbox shifting is not in progress. - TCM power supply voltage: More than 11 V	• Low brake solenoid valve • Control valve assembly

DTC CONFIRMATION PROCEDURE

CAUTION:

- Be sure to perform "[TM-207, "Diagnosis Procedure"](#)" and then perform "DTC CONFIRMATION PROCEDURE".
- Never perform "DTC CONFIRMATION PROCEDURE" before the repairs. Doing so may result in a secondary malfunction.
- Be careful of the driving speed.

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

1. Start the engine.
2. Drive the vehicle.
3. Maintain the following conditions for 10 seconds or more.

Selector lever	: "L" POSITION
Accelerator pedal position	: 0.7/8 or more
Vehicle speed	: 10 km/h (6 MPH) or more

4. Stop the vehicle.
5. Check the first trip DTC.

Is "P2857" detected?

YES >> Go to [TM-207, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009019748

1. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

Is the inspection result normal?

YES >> Replace transaxle assembly. Refer to [TM-252, "Removal and Installation"](#).
NO >> Repair or replace malfunctioning parts.

P2858 CLUTCH B PRESSURE

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

P2858 CLUTCH B PRESSURE

DTC Logic

INFOID:000000009019749

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P2858	Clutch B pressure engagement performance	The auxiliary gearbox gear ratio is 2.232 or more for the auxiliary gearbox 2GR ratio continuously for 5 seconds or more under the following diagnosis conditions: • Diagnosis conditions - Selector lever: Other than "P", "R" and "N" positions - Accelerator pedal position: 0.7/8 or more - Engine speed: More than 550 rpm - Output speed: More than 300 rpm - Secondary pulley speed: More than 300 rpm - Command for the 2GR of auxiliary gearbox is in progress. - Auxiliary gearbox shifting is not in progress. - TCM power supply voltage: More than 11 V	• High clutch & reverse brake solenoid valve • Control valve assembly

DTC CONFIRMATION PROCEDURE

CAUTION:

- Be sure to perform "[TM-208, "Diagnosis Procedure"](#)" and then perform "DTC CONFIRMATION PROCEDURE".
- Never perform "DTC CONFIRMATION PROCEDURE" before the repairs. Doing so may result in a secondary malfunction.
- Be careful of the driving speed.

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

1. Start the engine.
2. Drive the vehicle.
3. Maintain the following conditions for 10 seconds or more.

Selector lever	: "D" POSITION
Accelerator pedal position	: 0.7/8 or more
Vehicle speed	: 45 km/h (28 MPH) or more

4. Stop the vehicle.
5. Check the first trip DTC.

Is "P2858" detected?

YES >> Go to [TM-208, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009019750

1. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

Is the inspection result normal?

YES >> Replace transaxle assembly. Refer to [TM-252, "Removal and Installation"](#).
NO >> Repair or replace malfunctioning parts.

P2859 CLUTCH A PRESSURE

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

P2859 CLUTCH A PRESSURE

DTC Logic

INFOID:000000009019751

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P2859	Clutch A pressure disengagement performance	The detection conditions continuously for 200 msec or more under the following diagnosis conditions: • Diagnosis conditions - Selector lever: Other than "P", "R" and "N" positions - Vehicle speed: 10 km/h (6 MPH) or more - Engine speed: More than 550 rpm - Output speed: More than 300 rpm - Secondary pulley speed: More than 300 rpm - A lapse of 500 msec or more after the stop lamp switch is turned from ON to OFF. - Command for the 2GR of auxiliary gearbox is in progress. - Auxiliary gearbox shifting is not in progress. - TCM power supply voltage: More than 11 V • Detection conditions - Acceleration/deceleration: Less than -0.05 G - Actual auxiliary gearbox gear ratio – Auxiliary gearbox 2GR ratio $\geq 50\%$ The auxiliary gearbox gear ratio is $\pm 10\%$ or less for the auxiliary gearbox 1GR ratio continuously for 500 msec or more under the following diagnosis conditions: • Diagnosis conditions - Selector lever: Other than "P", "R" and "N" positions - Accelerator pedal position: 0.7/8 or more - Engine speed: More than 550 rpm - Secondary pulley speed: More than 300 rpm - Output speed: More than 300 rpm - Command for the 2GR of auxiliary gearbox is in progress. - Auxiliary gearbox shifting is not in progress. - TCM power supply voltage: More than 11 V	• Low brake solenoid valve • Control valve assembly

DTC COFIRMATION PROCEDURE

CAUTION:

- Be sure to perform "[TM-210, "Diagnosis Procedure"](#)" and then perform "DTC CONFIRMATION PROCEDURE".
- Never perform "TC CONFIRMATION PROCEDURE" before the repairs. Doing so may result in a secondary malfunction.
- Be careful of the driving speed.

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

1. Start the engine.

P2859 CLUTCH A PRESSURE

[CVT: RE0F11A]

< DTC/CIRCUIT DIAGNOSIS >

2. Drive the vehicle.
3. Maintain the following conditions for 10 seconds or more.

Selector lever	: "D" position
Accelerator pedal position	: 0.7/8 or more
Vehicle speed	: 45 km/h (28 MPH) or more

4. Stop the vehicle
5. Check the first trip DTC.

Is "P2859" detected?

YES >> Go to [TM-210, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009019752

1.CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

Is the inspection result normal?

YES >> Replace transaxle assembly. Refer to [TM-252, "Removal and Installation"](#).
NO >> Repair or replace malfunctioning parts.

P285A CLUTCH B PRESSURE

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

P285A CLUTCH B PRESSURE

DTC Logic

INFOID:000000009019753

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P285A	Clutch B pressure disengagement performance	The detection conditions continuously for 200 msec or more under the following diagnosis conditions: • Diagnosis conditions - Selector lever: Other than "P", "R" and "N" positions - Vehicle speed: 10 km/h (6 MPH) or more - Engine speed: More than 550 rpm - Output speed: More than 300 rpm - Secondary pulley speed: More than 300 rpm - Command for the 1GR of auxiliary gearbox is in progress. - Auxiliary gearbox shifting is not in progress. - TCM power supply voltage: More than 11 V • Detection conditions - Acceleration/deceleration: Less than -0.05 G - Actual auxiliary gearbox gear ratio – Auxiliary gearbox 1GR ratio $\geq 50\%$ The auxiliary gearbox gear ratio is $\pm 10\%$ or less for the auxiliary gearbox 2GR ratio continuously for 500 msec or more under the following diagnosis conditions: • Diagnosis conditions - Selector lever: Other than "P", "R" and "N" positions - Accelerator pedal position: 0.7/8 or more - Engine speed: More than 550 rpm - Secondary pulley speed: More than 300 rpm - Output speed: More than 300 rpm - Command for the 1GR of auxiliary gearbox is in progress. - Auxiliary gearbox shifting is not in progress. - TCM power supply voltage: More than 11 V	• High clutch & reverse brake solenoid valve • Control valve assembly

DTC CONFIRMATION PROCEDURE

CAUTION:

- Be sure to perform "**TM-212, "Diagnosis Procedure"**" and then perform "DTC CONFIRMATION PROCEDURE".
- Never perform "DTC CONFIRMATION PROCEDURE" before the repairs. Doing so may result in a secondary malfunction.
- Be careful of the driving speed.

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

1. Start the engine.
2. Drive the vehicle.
3. Maintain the following conditions for 10 seconds or more.

P285A CLUTCH B PRESSURE

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

Selector lever	: "L" POSITION
Accelerator pedal position	: 0.7/8 or more
Vehicle speed	: 10 km/h (6 MPH) or more

4. Stop the vehicle.
5. Check the first trip DTC.

Is "P285A" detected?

YES >> Go to [TM-212, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000009019754

1. CHECK INTERMITTENT INCIDENT

Refer to [GI-41, "Intermittent Incident"](#).

Is the inspection result normal?

YES >> Replace transaxle assembly. Refer to [TM-252, "Removal and Installation"](#).
NO >> Repair or replace malfunctioning parts.

MAIN POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

MAIN POWER SUPPLY AND GROUND CIRCUIT

Diagnosis Procedure

INFOID:000000009019755

1.CHECK TCM POWER CIRCUIT (PART 1)

1. Turn ignition switch OFF.
2. Disconnect TCM connector.
3. Check voltage between TCM harness connector terminals and ground.

+		–	Voltage
TCM			
Connector	Terminal		
F44	45	Ground	10 – 16 V
	46		

Is the inspection result normal?

- YES >> GO TO 2.
NO >> GO TO 4.

2.CHECK TCM POWER CIRCUIT (PART 2)

Check voltage between TCM harness connector terminals and ground.

+		–	Condition	Voltage
TCM				
Connector	Terminal			
F44	47	Ground	Ignition switch ON	10 – 16 V
			Ignition switch OFF	Approx. 0 V
	48		Ignition switch ON	10 – 16 V
			Ignition switch OFF	Approx. 0 V

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 5.

3.CHECK TCM GROUND CIRCUIT

Check continuity between TCM harness connector terminals and ground.

TCM		—	Continuity
Connector	Terminal		
F44	41	Ground	Existed
	42		

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).
NO >> Repair or replace malfunctioning parts.

4.DETECT MALFUNCTION ITEMS (PART 1)

Check the following items:

- Open circuit or short circuit in harness between battery positive terminal and TCM connectors terminals 45, and 46.
- 10A fuse (No.33, fuse and fusible link block). Refer to [PG-59, "Terminal Arrangement"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).
NO >> Repair or replace malfunctioning parts.

MAIN POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

5. CHECK CIRCUIT BETWEEN IPDM E/R AND TCM

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector terminal and TCM harness connector terminals.

IPDM E/R		TCM		Continuity
Connector	Terminal	Connector	Terminal	
E45	21	F44	47	Existed
			48	

Is the check result normal?

- YES >> GO TO 6.
NO >> Repair or replace malfunctioning parts.

6. DETECT MALFUNCTIONING ITEMS (PART 2)

Check the following items:

- Open circuit or short circuit in harness between ignition switch and IPDM E/R. Refer to [PG-17, "Wiring Diagram — Ignition Power Supply —"](#).
- Short circuit in harness between IPDM E/R harness connector terminal 21 and TCM harness connector terminal 47, and 48.
- 10A fuse (No.49, IPDM E/R). Refer to [PG-60, "IPDM E/R Terminal Arrangement"](#).
- IPDM E/R

Is the check result normal?

- YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).
NO >> Repair or replace malfunctioning parts.

OVERDRIVE CONTROL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

OVERDRIVE CONTROL SWITCH

Component Function Check

INFOID:000000009019756

1.CHECK OD OFF INDICATOR LAMP FUNCTION

Check OD OFF indicator lamp turns ON for approx. 2 seconds when ignition switch turns ON.

Is the inspection results normal?

YES >> GO TO 2.

NO >> Go to [TM-217, "Diagnosis Procedure"](#).

2.CHECK OVERDRIVE CONTROL SWITCH FUNCTION

1. Shift the selector lever to "D" position.
2. Check that OD OFF indicator lamp turns ON/OFF when overdrive control switch is operated.

Is the inspection results normal?

YES >> INSPECTION END

NO >> Go to [TM-215, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009019757

1.CHECK OVERDRIVE CONTROL SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect CVT shift selector connector.
3. Turn ignition switch ON.
4. Check voltage between CVT shift selector harness connector terminals.

CVT shift selector			Voltage (Approx.)
Connector	+	−	
	Terminal		
M38	1	2	5 V

Is the inspection result normal?

YES >> GO TO 2.

NO >> GO TO 4.

2.CHECK OVERDRIVE CONTROL SWITCH

Check overdrive control switch. Refer to [TM-216, "Component Inspection \(Overdrive Control Switch\)"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace malfunctioning parts.

3.CHECK GROUND CIRCUIT

Check continuity between CVT shift selector harness connector terminal and ground.

CVT shift selector		—	Continuity
Connector	Terminal		
M38	2	Ground	Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace malfunctioning parts.

4.CHECK CIRCUIT BETWEEN COMBINATION METER AND CVT SHIFT SELECTOR (PART 1)

1. Turn ignition switch OFF.
2. Disconnect combination meter connector.
3. Check continuity between combination meter harness connector terminal and CVT shift selector harness connector terminal.

OVERDRIVE CONTROL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

Combination meter		CVT shift selector		Continuity
Connector	Terminal	Connector	Terminal	
M24	8	M38	1	Existed

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace malfunctioning parts.

5.CHECK CIRCUIT BETWEEN COMBINATION METER AND CVT SHIFT SELECTOR (PART 2)

Check continuity between combination meter harness connector terminal and ground.

Combination meter		—	Continuity
Connector	Terminal		
M24	8	Ground	Not existed

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace malfunctioning parts.

6.CHECK COMBINATION METER INPUT SIGNAL

1. Connect all of disconnected connectors.
2. Turn ignition switch ON.
3. Select "Data Monitor" in "METER/M&A".
4. Select "O/D OFF SW".
5. Check that "O/D OFF SW" turns ON/OFF when overdrive control switch is operated. Refer to [MWI-18, "Reference Value"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

NO >> Replace combination meter. Refer to [MWI-54, "Removal and Installation"](#).

Component Inspection (Overdrive Control Switch)

INFOID:000000009019758

1.CHECK OVERDRIVE CONTROL SWITCH


Check continuity between wires of selector lever knob (1)

Condition	Continuity
Overdrive control switch is depressed	Existed
Overdrive control switch is depressed	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace selector lever knob. Refer to [TM-229, "Removal and Installation"](#).



JSDIA1969ZZ

OD OFF INDICATOR LAMP

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

OD OFF INDICATOR LAMP

Component Function Check

INFOID:0000000009019759

1.CHECK OD OFF INDICATOR LAMP FUNCTION

Check OD OFF indicator lamp turns ON for approx. 2 seconds when ignition switch turns ON.

Is the inspection results normal?

- YES >> INSPECTION END
- NO >> Go to [TM-217, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000009019760

1.CHECK DTC (TCM)

④With CONSULT

1. Turn ignition switch ON.
2. Check "Self Diagnostic Results" in "TRANSMISSION".

Is any DTC detected?

- YES >> Check DTC detected item. Refer to [TM-112, "DTC Index"](#).
- NO >> GO TO 2.

2.CHECK DTC (COMBINATION METER)

④With CONSULT

Check "Self Diagnostic Results" in "METER/M&A".

Is any DTC detected?

- YES >> Check DTC detected item. Refer to [MWI-21, "DTC Index"](#).
- NO >> GO TO 3.

3.CHECK COMBINATION METER INPUT SIGNAL

④With CONSULT

1. Shift the selector lever to "D" position.
2. Select "Data Monitor" in "METER/M&A".
3. Select "O/D OFF IND".
4. Check that "O/D OFF IND" turns ON/OFF when overdrive control switch is operated. Refer to [MWI-18, "Reference Value"](#).

Is the inspection result normal?

- YES >> Replace combination meter. Refer to [MWI-54, "Removal and Installation"](#).
- NO >> GO TO 4.

4.CHECK TCM INPUT/OUTPUT SIGNAL

④With CONSULT

1. Select "Data Monitor" in "TRANSMISSION".
2. Select "SPORT MODE SW".
3. Check that "SPORT MODE SW" turns ON/OFF when overdrive control switch is operated. Refer to [TM-100, "Reference Value"](#).

Is the inspection result normal?

- YES >> Replace combination meter. Refer to [MWI-54, "Removal and Installation"](#).
- NO >> Check overdrive control switch. Refer to [TM-215, "Diagnosis Procedure"](#).

SHIFT POSITION INDICATOR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

SHIFT POSITION INDICATOR CIRCUIT

Component Parts Function Inspection

INFOID:000000009019761

1.CHECK SHIFT POSITION INDICATOR

1. Start the engine.
2. Shift selector lever.
3. Check that the selector lever position and the shift position indicator on the combination meter are identical.

Is the inspection result normal?

YES >> INSPECTION END
NO >> Go to [TM-218, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009019762

1.CHECK TCM INPUT/OUTPUT SIGNAL

Ⓔ With CONSULT

1. Start the engine.
2. Select "Data Monitor" in "TRANSMISSION".
3. Select "RANGE".
4. Shift selector lever.
5. Check that selector lever position, "RANGE" on CONSULT screen, and shift position indicator display on combination meter are identical.

Is the check result normal?

YES >> INSPECTION END
NO-1 ("RANGE" is changed but is not displayed on shift position indicator.)>>Check "Self Diagnostic Result" in "TRANSMISSION".
NO-2 ("RANGE" and shift position indicator are different.)>>Check "Self Diagnostic Result" in "TRANSMISSION".
NO-3 (Specific "RANGE" is not displayed on shift position indicator.)>>Check "Self Diagnostic Result" in "METER/M&A".

SHIFT LOCK SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

SHIFT LOCK SYSTEM

Component Function Check

INFOID:000000009019763

1.CHECK SHIFT LOCK OPERATION (BRAKE PEDAL RELEASED)

1. Ignition switch ON.
2. Attempt to shift selector lever to any position other than "P" position with brake pedal released.

Can the selector lever be shifted?

- YES >> Go to [TM-219, "Diagnosis Procedure"](#).
NO >> GO TO 2.

2.CHECK SHIFT LOCK OPERATION (BRAKE PEDAL APPLIED)

Attempt to shift the selector lever to any position other than "P" position with brake pedal applied.

Can the selector lever be shifted?

- YES >> Inspection End.
NO >> Go to [TM-219, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009019764

1.CHECK STOP LAMP SWITCH

1. Ignition switch ON.
2. Check voltage between stop lamp switch connector E13 terminal 4 and ground.

Stop lamp switch		Ground	Brake pedal	Voltage
Connector	Terminal			
E13	4	Ground	Applied	Battery voltage
			Released	0V

Is the inspection result normal?

- YES >> GO TO 2.
NO >> GO TO 4.

2.CHECK CVT SHIFT SELECTOR

Check voltage between CVT shift selector connector M38 terminal 6 and ground.

CVT shift selector		Ground	Brake pedal	Shift selector	Voltage
Connector	Terminal				
M38	6	Ground	Applied	Park	Battery voltage
				Others	0V

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 5.

3.CHECK GROUND CIRCUIT

1. Ignition switch OFF.
2. Disconnect CVT shift selector connector.
3. Check continuity between CVT shift selector connector M38 terminal 6 and ground.

CVT shift selector		Ground	Continuity
Connector	Terminal		
M38	6	Ground	Yes

Is the inspection result normal?

- YES >> Replace CVT shift selector. Refer to [TM-229, "Removal and Installation"](#).
NO >> Repair or replace ground circuit.

SHIFT LOCK SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F11A]

4. CHECK STOP LAMP SWITCH POWER CIRCUIT

Check voltage between stop lamp switch connector E13 terminal 3 and ground.

Stop lamp switch		Ground	Voltage
Connector	Terminal		
E13	3	Ground	Battery voltage

Is the inspection result normal?

YES >> Replace stop lamp switch.

NO >> Repair or replace power circuit.

5. CHECK CVT SHIFT SELECTOR POWER CIRCUIT

Check voltage between CVT shift selector connector M38 terminal 5 and ground.

CVT shift selector		Ground	Brake pedal	Voltage
Connector	Terminal			
M38	5	Ground	Applied	Battery voltage

Is the inspection result normal?

YES >> Replace CVT shift selector. Refer to [TM-229, "Removal and Installation"](#).

NO >> Repair or replace power circuit.

CVT CONTROL SYSTEM

< SYMPTOM DIAGNOSIS >

[CVT: RE0F11A]

SYMPTOM DIAGNOSIS

CVT CONTROL SYSTEM

Symptom Table

INFOID:0000000009019765

The diagnosis item number indicates the order of check. Start checking in the order from 1.

Symptom diagnosis chart 1-1

Symptom		Check under on board condition (repair and part replacement)						Replace the transaxle assembly.											
		Engine system	Incorrect adjustment of CVT fluid level	Line pressure is out of the standard value.	Control cable	Electric system													
						TCM	Overdrive control switch	Primary speed sensor (P0715)	Secondary speed sensor (P2765)	Output speed sensor (P0720)	Transmission position switch (P0705, P0706)	Secondary pressure sensor (P0846, P0847, P0848)	Primary pressure solenoid valve (P17BA, P17BB)	Line pressure solenoid valve (P0746, P0962, P0963)	Lock-up solenoid valve (P0740, P0743, P0744)	High clutch &reverse brake solenoid valve (P1739, P173C, P17B7, P17B8)	Low brake solenoid valve (P173A, P173B, P17B4, P17B5)	CVT fluid temperature sensor (P0711, P0712, P0713)	
		<u>EC-118</u>	<u>TM-227</u>	<u>TM-131</u>	<u>TM-230</u>	<u>TM-100</u>	<u>TM-215</u>	<u>TM-112</u>											
Driving is not possible.	The engine speed increases in “D”, “L”, or “R” position, but the vehicle cannot start.	1	1	1	1	1		1	1		1	2		1		1	1	2	
	Engine stall occurs in “D”, “L”, or “R” position and the vehicle does not start.				1	1		1	1		1	1	1	1		1	1	2	
	Acceleration at start is not sufficient in “D”, “L”, or “R” position.	1		2		1		1	1	1	2	2	1	1	2	1	1	1	
	The engine speed increases suddenly in “D”, “L”, or “R” position during driving.		1	1									2	1	1		1		
	Engine brake is suddenly applied in “D” or “R” position during driving.	1		1										1	1		1		

CVT CONTROL SYSTEM

< SYMPTOM DIAGNOSIS >

[CVT: RE0F11A]

Symptom		Check under on board condition (repair and part replacement)						Replace the transaxle assembly.											
		Engine system	Incorrect adjustment of CVT fluid level	Line pressure is out of the standard value.	Control cable	Electric system													
						TCM	Overdrive control switch	Primary speed sensor (P0715)	Secondary speed sensor (P2765)	Output speed sensor (P0720)	Transmission position switch (P0705, P0706)	Secondary pressure sensor (P0846, P0847, P0848)	Primary pressure solenoid valve (P17BA, P17BB)	Line pressure solenoid valve (P0746, P0962, P0963)	Lock-up solenoid valve (P0740, P0743, P0744)	High clutch &reverse brake solenoid valve (P1739, P173C, P17B7, P17B8)	Low brake solenoid valve (P173A, P173B, P17B4, P17B5)	CVT fluid temperature sensor (P0711, P0712, P0713)	
		EC-118	TM-227	TM-131	TM-230	TM-100	TM-215	TM-112											
Shifting is not possible.	The engine races when the auxiliary gearbox is shifted from 1GR ⇔ 2GR.	2		1										1		1			
	Engine braking is not effective in “L” position.			1	1	1		1	1		1		2	1	1		1		
	Shifting does not occur with OD OFF.					1	1	1	1	1	1		1	1					
	Engine stall occurs immediately before stop at deceleration in “D” or “L” position.									1				1					
	During driving in “D” position, slippage occurs in lockup or lockup is not possible.					1		1	1	1	1	2	1	1	1		1		

CVT CONTROL SYSTEM

< SYMPTOM DIAGNOSIS >

[CVT: RE0F11A]

Symptom diagnosis chart 1-2

Symptom		Replace the transaxle assembly.												
		Oil pressure control		Power transmission										
		Valve body, control valve	Oil pump	Torque converter	Pulley, steel belt	Low brake	High clutch	Reverse brake	Bearings	Counter gear	Planetary gear	Reduction gear	Final gear, differential gear	Parking mechanism
		TM-252												
Driving is not possible.	The engine speed increases in "D", "L", or "R" position, but the vehicle cannot start.	1	1		1	1 (In "D" or "L")		1 (In "R")		1	1	1	1	
	Engine stall occurs in "D", "L", or "R" position and the vehicle does not start.	1							1	1	1	1	1	1
	Acceleration at start is not sufficient in "D", "L", or "R" position.	1		1		1 (In "D" or "L")		1 (In "R")						
	The engine speed increases suddenly in "D", "L", or "R" position during driving.	1	1		1	1 (In "D" or "L")	1 (In "D" or "L")	1 (In "R")						
	Engine brake is suddenly applied in "D" or "R" position during driving.	1				1 (In "D" or "L")	1 (In "D" or "L")	1 (In "R")						
Shifting is not possible.	The engine races when the auxiliary gearbox is shifted from 1GR ⇔ 2GR.	1	1		2	1	1							
	Engine braking is not effective in "L" position.	1	2	1	2	1	1							
	Shifting does not occur with OD OFF.													
	Engine stall occurs immediately before stop at deceleration in "D" or "L" position.	1		1										
	During driving in "D" position, slippage occurs in lockup or lockup is not possible.	1		1										

CVT CONTROL SYSTEM

[CVT: RE0F11A]

< SYMPTOM DIAGNOSIS >

Symptom diagnosis chart 2-1

Symptom		Check under on board condition (repair and part replacement)										Replace the transaxle assembly.									
		Engine system	Incorrect adjustment of CVT fluid level	Line pressure is out of the standard value.	Control cable	Electric system															
						TCM	Overdrive control switch	Primary speed sensor (P0715)	Secondary speed sensor (P2765)	Output speed sensor (P0720)	Transmission position switch (P0705, P0706)	Secondary pressure sensor (P0846, P0847, P0848)	Primary pressure solenoid valve (P17BA, P17BB)	Line pressure solenoid valve (P0746, P0962, P0963)	Lock-up solenoid valve (P0740, P0743, P0744)	High clutch &reverse brake solenoid valve (P1739, P173C, P17B7, P17B8)	Low brake solenoid valve (P173A, P173B, P17B4, P17B5)	CVT fluid temperature sensor (P0711, P0712, P0713)			
		EC-118	TM-227	TM-131	TM-230	TM-100	TM-215	TM-112													
Shock vibration Noise	Shock at start is large in “D”, “L”, or “R” position.			1								2		1	1						
	Shock is large when the auxiliary gearbox is shifted from 1GR → 2GR.	2		1		2							2	2		1	1				
	Shock in lockup is large during driving in “D” or “L” position.					1									1						
	Shock is large when the lever is shifted from “N” → “D” and “N” → “R” positions.	1		1		2		1	1		1			1	1	1	1	1			
	Shock is large when the lever is shifted from “D” → “L” position.																				
	Vibration occurs in “D”, “L”, or “R” position during driving.	1	1	1		1				1		2			1	1	1				
	Noise occurs during driving.		1																		
	Noise occurs in idling.	1	1																		
Other	Starter operates in “D”, “L”, or “R” position.				1	1					1										
	Starter does not operate in “P” or “N” position.				1	1					1										
	Engine stall occurs in “D”, “L”, or “R” position during stop.	1				1				1					1						
	Engine stall occurs in “P” or “N” position during stop.	1				1				1					1						
	Parking lock does not operate in “P” position.				1						1										
	Parking lock cannot be cancelled when the selector lever is shifted from “P” position to other position.				1						1										

CVT CONTROL SYSTEM

< SYMPTOM DIAGNOSIS >

[CVT: RE0F11A]

Symptom diagnosis chart 2-2

Symptom		Replace the transaxle assembly.												
		Oil pressure control		Power transmission										
		Valve body, control valve	Oil pump	Torque converter	Pulley, steel belt	Low brake	High clutch	Reverse brake	Bearings	Counter gear	Planetary gear	Reduction gear	Final gear, differential gear	Parking mechanism
		TM-252												
Shock vibration Noise	Shock at start is large in "D", "L", or "R" position.	1			1	1 (In "D" or "L")		1 (In "R")		2	2	2	2	
	Shock is large when the auxiliary gearbox is shifted from 1GR → 2GR.	1				1	1							
	Shock in lockup is large during driving in "D" or "L" position.	1		1										
	Shock is large when the lever is shifted from "N" → "D" and "N" → "R" positions.	1				1 (("N" → "D"))		1 (("N" → "D"))						
	Shock is large when the lever is shifted from "D" → "L" position.	1				1	1							
	Vibration occurs in "D", "L", or "R" position during driving.	1	1	1	1	1 (In "D" or "L")	1 (In "D" or "L")	1 (In "R")	1	1	1	1	1	
	Noise occurs during driving.	1	1		1				1	1	1	1	1	
	Noise occurs in idling.	1	1		1				1	1	1			
Other	Starter operates in "D", "L", or "R" position.													
	Starter does not operate in "P" or "N" position.													
	Engine stall occurs in "D", "L", or "R" position during stop.	1		1										
	Engine stall occurs in "P" or "N" position during stop.													
	Parking lock does not operate in "P" position.													1
	Parking lock cannot be cancelled when the selector lever is shifted from "P" position to other position.													1

PERIODIC MAINTENANCE


CVT FLUID

Inspection

INFOID:000000009019766

FLUID LEAKAGE

- Check transaxle surrounding area (oil seal and plug etc.)for fluid leakage.
- If anything is found, repair or replace damaged parts and adjust CVT fluid level. Refer to [TM-227, "Adjustment"](#).



Replacement

INFOID:000000009019643

- CVT fluid** : Refer to [TM-256, "General Specification"](#).
Fluid capacity : Refer to [TM-256, "General Specification"](#).

CAUTION:

- Use only Genuine NISSAN CVT Fluid NS-3. Using transmission fluid other than Genuine NISSAN CVT Fluid NS-3 will damage the CVT, which is not covered by the (NISSAN new vehicle limited) warranty.
- Always use shop paper. Never use shop cloth.
- Replace a drain plug gasket with new ones at the final stage of the operation when installing.
- Use caution when looking into the drain hole as there is a risk of dripping fluid entering the eye.
- After replacement, always perform CVT fluid leakage check.

1. Select "Data Monitor" in "TRANSMISSION" using CONSULT.
2. Select "FLUID TEMP" and confirm that the CVT fluid temperature is 40°C (104°F) or less.
3. Check that the selector lever is in the "P" position, then completely engage the parking brake.
4. Lift up the vehicle.
5. Remove the drain plug and overflow tube and drain the CVT fluid from the oil pan. [TM-240, "Removal and Installation"](#).

6. Install the charging pipe set (KV311039S0) (A) into the drain hole.

CAUTION:

Tighten the charging pipe by hand.

7. Install the ATF changer hose (B) to the charging pipe.

CAUTION:

Press the ATF changer hose all the way onto the charging pipe until it stops.


8. Fill approximately 3 liter (2-5/8 Imp qt) of the CVT fluid.
9. Remove the ATF changer hose and charging pipe, then install the drain plug.

NOTE:

Perform this work quickly because CVT fluid leaks.

10. Lift down the vehicle.
11. Start the engine.
12. While depressing the brake pedal, shift the selector lever to the entire position from "P" to "L", and shift it to the "P" position.

NOTE:



CVT FLUID

< PERIODIC MAINTENANCE >

[CVT: RE0F11A]

Hold the lever at each position for 5 seconds.

13. Check that the CONSULT "Data monitor" in "FLUID TEMP" is 35°C (95°F) to 45°C (113°F).

14. Stop the engine.

15. Lift up the vehicle.

16. Remove the drain plug, and then drain CVT fluid from oil pan.

17. Repeat steps 6 to 16 (one time).

18. Install the overflow tube. Refer to [TM-240, "Removal and Installation"](#).

CAUTION:

Be sure to tighten to the specified torque. If it is not tightened to the specified torque, the tube may be damaged.

19. Install the charging pipe set (KV311039S0) (A) into the drain hole.

CAUTION:

Tighten the charging pipe by hand.

20. Install the ATF changer hose (B) to the charging pipe.

CAUTION:

Press the ATF changer hose all the way onto the charging pipe until it stops.

21. Fill approximately 3 liter (2-5/8 Imp qt) of the CVT fluid.

22. Remove the ATF changer hose and charging pipe, then install the drain plug.

NOTE:

Perform this work quickly because CVT fluid leaks.

23. Lift down the vehicle.

24. Start the engine.

25. While depressing the brake pedal, shift the selector lever to the entire position from "P" to "L", and shift it to the "P" position.

NOTE:

Hold the lever at each position for 5 seconds.

26. Check that the CONSULT "Data monitor" in "FLUID TEMP" is 35°C (95°F) to 45°C (113°F).

27. Lift up the vehicle.

28. Remove the drain plug and confirm that the CVT fluid is drained from the overflow tube.

CAUTION:

Perform this work with the vehicle idling.

NOTE:

If the CVT fluid is not drained, refer to "Adjustment" and refill with the CVT fluid.

29. When the flow of CVT fluid slows to a drip, tighten the drain plug to the specified torque. [TM-240, "Removal and Installation"](#).

CAUTION:

Never reuse drain plug gasket.

30. Lift down the vehicle.

31. Select "Work Support" in "TRANSMISSION" using CONSULT.

32. Select "CONFORM CVTF DETERIORATION".

33. Select "Erase".

34. Stop the engine.

Adjustment

CVT fluid


: Refer to [TM-256, "General Specification"](#).

Fluid capacity

: Refer to [TM-256, "General Specification"](#).

CAUTION:

- Use only Genuine NISSAN CVT Fluid NS-3. Using transmission fluid other than Genuine NISSAN CVT Fluid NS-3 will damage the CVT, which is not covered by the (NISSAN new vehicle limited) warranty.



INFOID:000000009019644

CVT FLUID

< PERIODIC MAINTENANCE >

[CVT: RE0F11A]

- During adjustment of the CVT fluid level, check CONSULT so that the oil temperature may be maintained from 35 to 45°C (95 to 113°F).
- Use caution when looking into the drain hole as there is a risk of dripping fluid entering the eye.

1. Check that the selector lever is in the "P" position, then completely engage the parking brake.
2. Start the engine.
3. Adjust the CVT fluid temperature to be approximately 40°C (104°F).

NOTE:

The CVT fluid is largely affected by temperature. Therefore be sure to use CONSULT and check the "FLUID TEMP" under "TRANSMISSION" in "Data Monitor" while adjusting.

4. While depressing the brake pedal, shift the selector lever to the entire position from "P" to "L", and shift it to the "P" position.

NOTE:

Hold the lever at each position for 5 seconds.

5. Lift up the vehicle.
6. Check that there is no CVT fluid leakage.
7. Remove the drain plug. Refer to [TM-240, "Removal and Installation"](#).

8. Install the charging pipe set (KV311039S0) (A) into the drain plug hole.

CAUTION:

Tighten the charging pipe by hand.

9. Install the ATF changer hose (B) to the charging pipe.

CAUTION:

Press the ATF changer hose all the way onto the charging pipe until it stops.

10. Fill approximately 0.5 liter (1/2 Imp qt) of the CVT fluid.
11. Remove the ATF changer hose from the charging pipe, and check that the CVT fluid drains out from the charging pipe. If it does not drain out, perform charging again.

CAUTION:


Perform this work with the vehicle idling.

12. When the flow of CVT fluid slows to a drip, remove the charging pipe from the oil pan.
13. Tighten the drain plug to the specified torque. Refer to [TM-240, "Removal and Installation"](#).

CAUTION:

Never reuse drain plug gasket.

14. Lift down the vehicle.
15. Stop the engine.



CVT SHIFT SELECTOR

< REMOVAL AND INSTALLATION >


[CVT: RE0F11A]

REMOVAL AND INSTALLATION

CVT SHIFT SELECTOR

Exploded View

INFOID:0000000009019767



- | | | |
|------------------------------|----------------------------|--------------------------------|
| 1. Shift selector handle | 2. Lock pin | 3. Shift selector handle cover |
| 4. Position indication panel | 5. Shift selector assembly | |

Removal and Installation

INFOID:0000000009019768

CAUTION:

Always apply the parking brake before performing removal and installation.

REMOVAL

1. Move the shift selector to the "N" position.
2. Remove the shift selector handle. Refer to [TM-230, "Disassembly and Assembly"](#).
3. Remove the center console. Refer to [IP-18, "Removal and Installation"](#).
4. Disconnect the harness connectors from shift selector.
5. Move the shift selector to the "P" position.
6. Remove the key interlock cable from the shift selector assembly. Refer to [TM-235, "Exploded View"](#).
7. Remove the control cable from the shift selector assembly. Refer to [TM-232, "Exploded View"](#).
8. Remove the shift selector assembly.

INSTALLATION


Installation is in the reverse order of removal.

CVT SHIFT SELECTOR

< REMOVAL AND INSTALLATION >

[CVT: RE0F11A]

- When connecting the control cable (1) to the shift selector assembly (2), face the grooved surface of the rib (A) up and insert the control cable until it stops.




Disassembly and Assembly


INFOID:000000009019769

DISASSEMBLY

- Slide the shift selector handle cover (1) down.
CAUTION:
Do not damage the shift selector handle cover.
- Pull out the lock pin (2).
- Pull the shift selector handle (3) and shift selector handle cover upward to remove.
- Remove the position lamp.




- Disengage the hooks (A) (4 locations), and lift up the position indication panel (1) to separate it from the shift selector assembly (2).
CAUTION:
Do not damage the shift selector assembly.



ASSEMBLY

Assembly is in the reverse order of disassembly.

- Follow the procedure below to install the shift selector handle.
- Install the lock pin (2) onto the shift selector handle (3).
- Install the shift selector handle cover (1) onto the shift selector handle.
- Press the shift selector handle onto the shift selector until it clicks.
CAUTION:
 - When pressing the shift selector handle onto the shift selector, do not press the shift selector handle button.
 - Do not strike the shift selector handle to install it.



Inspection

INFOID:000000009019770

INSPECTION AFTER INSTALLATION

CVT SHIFT SELECTOR

< REMOVAL AND INSTALLATION >

[CVT: RE0F11A]

Check CVT position. Refer to [TM-133. "Inspection"](#).

A

B

C

TM

E

F

G

H

I

J

K

L

M

N

O

P

CONTROL CABLE


< REMOVAL AND INSTALLATION >

[CVT: RE0F11A]

CONTROL CABLE

Exploded View

INFOID:000000009019771



- | | | |
|-----------------|------------------|--------------------------------|
| 1. Bracket B | 2. Lock plate | 3. Transaxle assembly |
| 4. Bracket A | 5. Control cable | 6. CVT shift selector assembly |
| A: Manual lever | B: Grommet | |

Removal and Installation


INFOID:000000009019772

CAUTION:

Always apply the parking brake before performing removal and installation.

REMOVAL

1. Remove the battery negative terminal. Refer to [PG-67, "Exploded View"](#).
2. Remove the TCM and bracket. Refer to [TM-237, "Removal and Installation"](#).
3. Remove the IPDM E/R. Refer to [PCS-31, "Removal and Installation"](#).
4. Remove the battery tray and bracket.
5. Remove instrument lower panel LH. Refer to [IP-24, "Removal and Installation"](#).
6. Remove the center console assembly. Refer to [IP-18, "Removal and Installation"](#).
7. Remove the control cable from the shift selector assembly.
8. Disengage the pawls (B) of the grommet (A), and pull downward to remove.
9. Remove the control cable nut from the manual lever.




CONTROL CABLE

< REMOVAL AND INSTALLATION >

[CVT: RE0F11A]


10. Remove the lock plate (1).



11. Lift up the heat plate.

12. Remove the control cable (1) from the bracket (2).

⇐ Front



13. Remove the control cable from the vehicle.

14. Remove bracket.


INSTALLATION

Installation is in the reverse order of removal.

- From below the vehicle, press the grommet (A) into place until the pawls (B) make a click sound.


CAUTION:

Check that pulling down on the grommet does not disconnect it.



- Pay attention to the following when connecting the control cable to the shift selector.

1. When connecting the control cable (1) to the shift selector assembly (2), face the grooved surface of the rib (A) up and insert the control cable until it stops.



CONTROL CABLE


< REMOVAL AND INSTALLATION >

[CVT: RE0F11A]

2. Install the socket (A) onto the shift selector assembly.

CAUTION:

- Insert the socket into the shift selector assembly, then push it firmly in place.
- Check that pulling on the socket does not disconnect it.



INFOID:000000009019773

Inspection and Adjustment

INSPECTION AFTER INSTALLATION

Check CVT position. Refer to [TM-133, "Inspection"](#).

ADJUSTMENT AFTER INSTALLATION

Adjust CVT position. Refer to [TM-133, "Adjustment"](#).

KEY INTERLOCK CABLE


< REMOVAL AND INSTALLATION >

[CVT: RE0F11A]

KEY INTERLOCK CABLE

Exploded View

INFOID:000000009019774



1. Shift selector assembly
B: Lock plate

2. Key interlock cable
C: Clip

A: Key cylinder

Removal and Installation

INFOID:000000009019775


REMOVAL

CAUTION:

Always apply the parking brake before performing removal and installation.

1. Move the shift selector to the "N" position.
2. Remove the shift selector handle. Refer to [TM-230, "Disassembly and Assembly"](#).
3. Remove the instrumental lower panel LH. Refer to [IP-24, "Removal and Installation"](#).
4. Remove steering column covers. Refer to [IP-17, "Removal and Installation"](#).
5. Remove the center console. Refer to [IP-18, "Removal and Installation"](#).
6. Move the shift selector to the "P" position.
7. Press the pawls (B) of the key interlock cable slider (A) while sliding it in the direction of the casing cap (C), and separate the adjusting holder (D) and slider.

(E) :Key interlock rod



8. Remove the key interlock cable from the shift selector assembly.

KEY INTERLOCK CABLE


< REMOVAL AND INSTALLATION >

[CVT: RE0F11A]

9. Lift lock plate (A) in the direction of the arrow (←C) and remove in the direction of the arrow (←D).

- (1) :Key interlock cable
(B) :Key cylinder

10. Remove the key interlock cable from the key cylinder.
11. Disengage the clips and remove the key interlock cable from the vehicle.




INSTALLATION

Installation is in the reverse order of removal.

- Temporarily install the adjust holder (A) to the key interlock rod (B).
- Install the casing cap (C) to the cable bracket (D) on the shift selector assembly.

CAUTION:


- Do not bend or twist key interlock cable excessively when installing.
- After installing key interlock cable to cable bracket (D) on shift selector assembly, make sure casing caps (C) is firmly secured in cable bracket (D) on shift selector assembly.
- If casing cap (C) is loose [less than 39.2 N (4.0 kg, 8.8 lb) removing force], replace key interlock cable.



- Slide the slider (A) toward the key interlock rod (D) while pressing the pull lock (B) down to securely connect the adjust holder (C) with the key interlock rod (D).

CAUTION:

- Do not press tabs when holding slider (A).
- Do not apply any side to side force to key interlock rod (D) when sliding slider (A).



Inspection

INFOID:000000009019776


INSPECTION AFTER INSTALLATION

- Check the CVT operation. If a malfunction is found, adjust the CVT position. Refer to [TM-230, "Inspection"](#).
- Make sure the key can be removed only when the shift selector is in the "P" position.
- Make sure the ignition switch will not turn to LOCK position when the shift selector is not in the "P" position.

TCM

Exploded View

INFOID:000000009019777



1. TCM
 ⇐ Front

2. Bracket

3. Clip

Removal and Installation

INFOID:000000009019778

CAUTION:

When replacing TCM, note the "CVTF DETERIORATION DATE" value displayed on CONSULT "CONFORM CVTF DETERIORATION" in MAINTENANCE BOOKLET, before starting the operation.

NOTE:

When replacing the TCM and transaxle assembly as a set, replace the transaxle assembly first and then replace the TCM. Refer to [TM-127, "Description"](#).

REMOVAL

1. Remove the battery. Refer to [PG-67, "Removal and Installation \(Battery\)"](#).
2. Disconnect the harness connector from the TCM.
3. Remove the TCM and bracket as an assembly.
4. Remove the TCM from the bracket (if necessary).

INSTALLATION

Installation is in the reverse order of removal.

Adjustment

INFOID:000000009019779

ADJUSTMENT AFTER INSTALLATION

Perform "ADDITIONAL SERVICE WHEN REPLACING TCM". Refer to [TM-127, "Description"](#).

AIR BREATHER HOSE

Removal and Installation

INFOID:000000009019780

REMOVAL


1. Remove air duct (inlet). Refer to [EM-26, "Exploded View"](#).
2. Remove air breather hose from transaxle assembly.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- Check that air breather hose is not collapsed or blocked due to folding or bending when installed.
- Be sure to insert air breather hose (1) fully until it reaches the base of the transaxle tube (A).



G SENSOR


< REMOVAL AND INSTALLATION >

[CVT: RE0F11A]

G SENSOR

Exploded View

INFOID:0000000009019781



1. G sensor

Front

Removal and Installation

INFOID:0000000009019782

CAUTION:

- Do not drop or strike G sensor, because it may be damaged by impact.
- Do not use a power tool.

REMOVAL

1. Disconnect the battery negative terminal. Refer to [PG-67, "Exploded View"](#).
2. Remove center console assembly. Refer to [IP-18, "Removal and Installation"](#).
3. Disconnect the harness connector from G sensor.
4. Remove G sensor.

INSTALLATION

Installation is in the reverse order of removal.

Adjustment

INFOID:0000000009019783

ADJUSTMENT AFTER INSTALLATION

Perform "G SENSOR CALIBRATION". Refer to [TM-130, "Description"](#).

OIL PAN


< REMOVAL AND INSTALLATION >

[CVT: RE0F11A]

OIL PAN

Exploded View

INFOID:000000009019784



- | | | |
|-----------------------|-------------------------|----------------------|
| 1. Transaxle assembly | 2. Oil pan gasket | 3. Magnet |
| 4. Oil pan | 5. Overflow tube | 6. Drain plug gasket |
| 7. Drain plug | 8. Oil pan fitting bolt | |

Removal and Installation

INFOID:000000009019785

REMOVAL

1. Remove the drain plug and overflow tube, and then drain the CVT fluid.


WARNING:

CVT fluid can splash when draining, use safety glasses to protect eyes.

2. Remove the drain plug gasket from the drain plug.
3. Remove the oil pan bolts (←), and then remove the oil pan and oil pan gasket.

← : Front

4. Remove the magnets from the oil pan.



INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- Do not reuse oil pan gasket and drain plug gasket.


OIL PAN

< REMOVAL AND INSTALLATION >

[CVT: RE0F11A]

- Do not reuse oil pan bolts.
- Completely remove all moisture, oil and old gasket, etc. from the oil pan gasket mating surface of transaxle case and oil pan.
- When installing the overflow tube, be sure to tighten to the specified torque. If it is not tightened to the specified torque, the tube may be damaged.
- When the oil pan is installed, temporarily tighten oil pan bolts, then tighten the oil pan bolts to specification in the order shown.

← : Front



Inspection and Adjustment

INFOID:000000009019786

INSPECTION AFTER REMOVAL

Check oil pan for foreign material.

- If a large amount of worn material is found, clutch plate may be worn.
 - If iron powder is found, bearings, gears, or clutch plates may be worn.
 - If aluminum powder is found, bushing may be worn, or chips or burrs of aluminum casting parts may enter.
- Check points where wear is found in all cases.

INSPECTION AFTER INSTALLATION

Check for CVT fluid leakage. Refer to [TM-226, "Inspection"](#).

ADJUSTMENT AFTER INSTALLATION

Check the CVT fluid level. Refer to [TM-227, "Adjustment"](#).

PRIMARY SPEED SENSOR


< REMOVAL AND INSTALLATION >

[CVT: RE0F11A]

PRIMARY SPEED SENSOR

Exploded View

INFOID:0000000009019787



1. Transaxle assembly

2. O-ring

3. Primary speed sensor

⇐ Front

: Genuine NISSAN CVT Fluid NS-3

Removal and Installation

INFOID:0000000009019788

REMOVAL

1. Partially remove fender protector (LH). Refer to [TM-242, "Exploded View"](#).
2. Disconnect the harness connector from primary speed sensor.
3. Remove the primary speed sensor.
4. Remove the O-ring from the primary speed sensor.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- Do not reuse O-ring.
- Apply Genuine NISSAN CVT Fluid NS-3 to the O-ring.

Inspection and Adjustment

INFOID:0000000009019789

INSPECTION AFTER INSTALLATION

Check for CVT fluid leakage. Refer to [TM-226, "Inspection"](#).

ADJUSTMENT AFTER INSTALLATION

Adjust the CVT fluid level. Refer to [TM-227, "Adjustment"](#).

SECONDARY SPEED SENSOR


< REMOVAL AND INSTALLATION >

[CVT: RE0F11A]

SECONDARY SPEED SENSOR

Exploded View

INFOID:000000009019790



1. Transaxle assembly

⇐ Front

2. O-ring

: Genuine NISSAN CVT Fluid NS-3

3. Secondary speed sensor

Removal and Installation

INFOID:000000009019791

REMOVAL

1. Remove battery tray. Refer to [PG-68, "Removal and Installation \(Battery Tray\)"](#).
2. Remove IPDM/ER. Refer to [PCS-60, "Removal and Installation"](#).
3. Disconnect the harness connector from secondary speed sensor.
4. Remove the secondary speed sensor.
5. Remove the O-ring from the secondary speed sensor.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- Do not reuse O-ring.
- Apply Genuine NISSAN CVT Fluid NS-3 to the O-ring.

Inspection and Adjustment

INFOID:000000009019792

INSPECTION AFTER INSTALLATION

Check for CVT fluid leakage. Refer to [TM-226, "Inspection"](#).

ADJUSTMENT AFTER INSTALLATION

Adjust the CVT fluid level. Refer to [TM-227, "Adjustment"](#).

OUTPUT SPEED SENSOR


< REMOVAL AND INSTALLATION >

[CVT: RE0F11A]

OUTPUT SPEED SENSOR

Exploded View

INFOID:0000000009019793



1. Transaxle assembly

⇐ Front

2. Output speed sensor

 Genuine NISSAN CVT Fluid NS-3

3. O-ring

Removal and Installation

INFOID:0000000009019794

REMOVAL

1. Disconnect the harness connector from output speed sensor.
NOTE:
Lift up the vehicle and perform the work from rear of the transaxle assembly.
2. Remove the output speed sensor.
3. Remove the O-ring from the output speed sensor.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- Do not reuse O-ring.
- Apply Genuine NISSAN CVT Fluid NS-3 to the O-ring.

Inspection and Adjustment

INFOID:0000000009019795

INSPECTION AFTER INSTALLATION

Check for CVT fluid leakage. Refer to [TM-226, "Inspection"](#).

ADJUSTMENT AFTER INSTALLATION

Check the CVT fluid level. Refer to [TM-227, "Adjustment"](#).

DIFFERENTIAL SIDE OIL SEAL


< REMOVAL AND INSTALLATION >

[CVT: RE0F11A]

DIFFERENTIAL SIDE OIL SEAL

Exploded View

INFOID:0000000009019796



1. Transaxle assembly

⇐ Front

2. Differential side oil seal (left side)



Genuine NISSAN CVT Fluid NS-3

3. Differential side oil seal (right side)

Removal and Installation

INFOID:0000000009019797

NOTE:

When removing components such as hoses, tubes/lines, etc., cap or plug openings to prevent fluid from spilling.

REMOVAL

1. Remove the front drive shaft from the transaxle assembly. Refer to [FAX-19, "Removal and Installation"](#)
2. Remove the differential side oil seal using suitable tool.

CAUTION:

When removing the differential side oil seal, be careful not to scratch the oil seal mating surfaces of the transaxle case and converter housing.

INSTALLATION


1. Drive the differential side oil seal into the transaxle case side (A) and converter housing side (B) using suitable tool to the specified dimension.

CAUTION:

- Be careful not to scratch the lip of the differential side oil seal when press-fitting it.
- Do not reuse differential side oil seal.
- Apply Genuine NISSAN CVT Fluid NS-3 to the differential side oil seal lip and around the oil seal.

Dimension (C) : $1.8 \pm 0.5 \text{ mm}$ ($0.071 \pm 0.020 \text{ in.}$).

Dimension (D) : $1.8 \pm 0.5 \text{ mm}$ ($0.071 \pm 0.020 \text{ in.}$).



2. Install the front drive shaft. Refer to [FAX-19, "Removal and Installation"](#).

Inspection and Adjustment

INFOID:0000000009019798

INSPECTION AFTER INSTALLATION

Check for CVT fluid leakage. Refer to [TM-226, "Inspection"](#).

ADJUSTMENT AFTER INSTALLATION

DIFFERENTIAL SIDE OIL SEAL

< REMOVAL AND INSTALLATION >

[CVT: RE0F11A]

Adjust the CVT fluid level. Refer to [TM-227. "Adjustment"](#).

WATER HOSE


< REMOVAL AND INSTALLATION >

[CVT: RE0F11A]

WATER HOSE

Exploded View

INFOID:000000009019799



- | | | |
|------------------|----------------------|-------------------|
| 1. Hose clamp | 2. Water hose A | 3. Clip |
| 4. Bracket A | 5. Bracket B | 6. CVT oil warmer |
| 7. Water hose B | 8. Water bypass pipe | 9. Hose clamp |
| 10. Water hose C | 11. Water outlet | |

A. To heater core

✕ : Always replace after every disassembly.

⊙ : N·m (kg-m, in-lb)

Removal and Installation

INFOID:000000009019800

REMOVAL

WARNING:

Do not remove the radiator cap when the engine is hot. Serious burns could occur from high-pressure engine coolant escaping from the radiator. Wrap a thick cloth around the cap. Slowly push down and turn it a quarter turn to allow built-up pressure to escape. Carefully remove the cap by pushing it down and turning it all the way.

CAUTION:

Perform these steps after the engine coolant temperature has cooled sufficiently.

NOTE:

When removing components such as hoses, tubes/lines, etc., cap or plug openings to prevent fluid from spilling.

1. Remove the hose clamp and pull out the water hose A.
2. Remove the hose clamp and pull out the water hose B.
3. Remove the hose clamp and pull out the water hose C.
4. Pull out the heater hose and remove the water bypass pipe.
5. Remove the heater thermostat assembly.

WATER HOSE

< REMOVAL AND INSTALLATION >

[CVT: RE0F11A]

6. Remove the bracket.

INSTALLATION


Installation is in the reverse order of removal.

CAUTION:

- Do not reuse hose clamps.
- Do not reuse clips.
- When installing bracket A to the transaxle assembly.
- Face arrow (A) of bracket A toward the front of the vehicle.

⇐ : Front


- Set baffle (B) of bracket A to rib (C) of transaxle.



- When installing the bracket B to the transaxle assembly.
- Face arrow (A) of bracket A towards the top of vehicle.


⇐ : Front

- Insert baffle (B) into the boss hole (C) of transaxle.



- Refer to the following when installing water hoses.

Water hose (1)	Installation side tube (2)	Direction of paint mark	Hose insertion depth (L)
Water hose A	Water outlet	Upward	(A): 27 mm (1.06 in) (End reaches the 2-stage bulge.)
	CVT oil warmer	Frontward	
Water hose B	CVT oil warmer	Frontward	
	Water bypass pipe	Rightward (Align with the mark of the water bypass pipe side)	
Water hose C	Water bypass pipe	—	
	Water outlet	Upward	



- Refer to the following when installing hose clamp.

CAUTION:


Hose clamp should not interfere with the bulge of fluid cooler tube.

WATER HOSE

< REMOVAL AND INSTALLATION >

[CVT: RE0F11A]

Water hose (1)	Installation side tube (2)	Hose clamp (3)	
		Dieection of tab	Clamping position
Water hose A	Water outlet	Upward	5 - 7 mm (0.20 - 0.28 in) (A) from hose end
	CVT oil warmer	Frontward	
Water hose B	CVT oil warmer	Leftward	
	Water bypass pipe	Rightward	
Water hose C	Water bypass pipe	Upward and 45° frontward	
	Water outlet	Upward and 45° frontward	



Inspection

INFOID:000000009019801

INSPECTION AFTER INSTALLATION

Start the engine and check visually that there is no leakage of engine coolant.

FLUID COOLER HOSE


< REMOVAL AND INSTALLATION >

[CVT: RE0F11A]

FLUID COOLER HOSE

Exploded View

INFOID:000000009300290



1. CVT fluid cooler

2. Hoses

Removal and Installation

INFOID:000000009300291

NOTE:

When removing components such as hoses, tubes/lines, etc., cap or plug openings to prevent fluid from spilling.

REMOVAL

1. Remove the front bumper fascia. Refer to [EXT-24, "Removal and Installation"](#).
2. Disconnect CVT fluid cooler hoses.
3. Remove CVT fluid cooler bolts.
4. Remove CVT fluid cooler.

INSTALLATION

Installation is in the reverse order of removal.

After installation be sure to check the CVT fluid and add the specified CVT fluid as necessary. Refer to [TM-226, "Inspection"](#).

CAUTION:

Do not reuse hose clamps.

Inspection and Adjustment

INFOID:000000009300292

INSPECTION AFTER INSTALLATION

Check for CVT fluid leakage. Refer to [TM-226, "Inspection"](#).

ADJUSTMENT AFTER INSTALLATION

Adjust the CVT fluid level. Refer to [TM-227, "Adjustment"](#).

PLUG

< REMOVAL AND INSTALLATION >

[CVT: RE0F11A]

PLUG


Description

INFOID:0000000009019802

Replace the O-ring if oil leakage or exudes from the plug.

Exploded View

INFOID:0000000009019803



Removal and Installation

INFOID:0000000009019804

REMOVAL

Remove the plugs and O-rings.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- Do not reuse O-rings.
- Apply Genuine NISSAN CVT Fluid NS-3 to O-rings.

Inspection and Adjustment

INFOID:0000000009019805

INSPECTION AFTER INSTALLATION

Check for CVT fluid leakage. Refer to [TM-226, "Inspection"](#).

ADJUSTMENT AFTER INSTALLATION


Adjust the CVT fluid level. Refer to [TM-227, "Adjustment"](#).

UNIT REMOVAL AND INSTALLATION

TRANSMISSION ASSEMBLY

Exploded View

INFOID:000000009019806



1. Transaxle assembly

A : For the tightening torque, refer to [TM-252. "Removal and Installation"](#).

Removal and Installation

INFOID:000000009019807

WARNING:

Do not remove the radiator cap when the engine is hot. Serious burns could occur from high-pressure engine coolant escaping from the radiator. Wrap a thick cloth around the cap. Slowly push down and turn it a quarter turn to allow built-up pressure to escape. Carefully remove the cap by pushing it down and turning it all the way.

CAUTION:

- Perform these steps after the coolant temperature has cooled sufficiently.

NOTE:

- When removing components such as hoses, tubes/line, etc., cap or plug openings to prevent fluid from spilling.
- When replacing the TCM and transaxle assembly as a set, replace the transaxle assembly first and then replace the TCM. Refer to [TM-127. "Description"](#).

REMOVAL

1. Remove the engine and transaxle assembly. Refer to [EM-86. "Removal and Installation"](#).
2. Disconnect the harness connectors and harnesses.
 - For CVT unit harness connector.
 - Transmission position switch harness connector

TRANSMISSION ASSEMBLY

< UNIT REMOVAL AND INSTALLATION >


[CVT: RE0F11A]

- Primary speed sensor harness connector
 - Secondary speed sensor harness connector
 - Output speed sensor harness connector
 - Ground
3. Rotate the crankshaft and remove the nuts that secure the drive plate to the torque converter from the stator motor mount.

CAUTION:

When turning crankshaft, turn it clockwise as viewed from the front of the engine.

4. Remove the bolts (engine to transaxle) that fasten the transaxle assembly and engine assembly.



Bolt position	A	B	C	D
Direction of insertion	Transaxle assembly ⇒ Engine assembly	Engine assembly ⇒ Transaxle assembly		
Quantity	2	2	1	3
Nominal length [mm (in)]	40 (1.57)	44 (1.73)	69 (2.72)	49 (1.93)
Tightening torque N·m (kg-m, ft-lb)	48.0 (4.9, 35)			

5. Remove transaxle assembly from vehicle.

CAUTION:


- **Secure torque converter to prevent it from dropping.**
- **Secure transaxle assembly to a suitable jack.**

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- **Do not reuse O-rings.**
- **Apply Genuine NISSAN CVT Fluid NS-3 to the O-rings.**
- When installing the transaxle assembly onto the engine assembly, check the engagement of the dowel pins (↔).




TRANSMISSION ASSEMBLY

< UNIT REMOVAL AND INSTALLATION >

[CVT: RE0F11A]


- When using suitable tool (A) for alignment, install it to the alignment stud bolt used to align the torque converter to the drive plate.



- Rotate the crankshaft so that the alignment hole (A) of drive plate aligns with the position of the torque converter alignment stud bolt.

CAUTION:

- Rotate the crankshaft clockwise (as viewed from the front of the engine).
- Be careful that torque converter stud bolts are aligned to the drive plate holes. Otherwise the stud bolts contact the drive plate.
- Insert the alignment stud bolt of torque converter into the alignment hole of the drive plate, aligning the drive plate holes with the torque converter stud bolts.



CAUTION:


Be careful not to strike the drive plate with the torque converter stud bolts.

- When installing the torque converter nuts, temporarily tighten the nuts. Then, after installing the engine and transaxle assembly bolts tighten the nuts to the specified torque.

Tightening torque : 51 N·m (5.2 kg-m, 38 ft-lb)

CAUTION:

- Rotate the crankshaft clockwise (as viewed from the front of the engine).
- Check the tightening torque for the crankshaft pulley bolts after the bolts fastening the drive plate and torque converter have been tightened and the crankshaft pulley bolts have been secured. Refer to [EM-51, "Removal and Installation"](#).
- Install the transaxle assembly and engine assembly bolts according to the following standards.



Bolt position	A	B	C	D
Direction of insertion	Transaxle assembly ⇒ Engine assembly	Engine assembly ⇒ Transaxle assembly		
Quantity	2	2	1	3
Nominal length [mm (in)]	40 (1.57)	44 (1.73)	69 (2.72)	49 (1.93)
Tightening torque N·m (kg-m, ft-lb)	48.0 (4.9, 35)			

Inspection and Adjustment

INFOID:000000009019808

INSPECTION BEFORE INSTALLATION

TRANSMISSION ASSEMBLY


< UNIT REMOVAL AND INSTALLATION >

[CVT: RE0F11A]

Check the distance (A) between the converter housing and torque converter.

- (B) : Scale
(C) : Straightedge

Dimension (A) : [TM-257, "Torque Converter"](#)



INSPECTION AFTER INSTALLATION

Check the following items:

- For CVT position, refer to [TM-230, "Inspection"](#).
- Before starting engine, check oil/fluid levels including engine coolant and engine oil. If less than required quantity, fill to the specified level. Refer to [MA-11, "Fluids and Lubricants"](#).
- Use procedure below to check for fuel leakage.
- Turn ignition switch ON (with engine stopped). With fuel pressure applied to fuel piping, check for fuel leakage at connection points.
- Start engine. With engine speed increased, check again for fuel leakage at connection points.
- Run engine to check for unusual noise and vibration.

NOTE:

If hydraulic pressure inside timing chain tensioner drops after removal and installation, slack in the guide may generate a pounding noise during and just after engine start. However, this is normal. Noise will stop after hydraulic pressure rises.

- Warm up engine thoroughly to make sure there is no leakage of fuel, exhaust gas, or any oils/fluids including engine oil and engine coolant.
- Bleed air from passages in lines and hoses, such as in cooling system.
- After cooling down engine, again check oil/fluid levels including engine oil and engine coolant. Refill to specified level, if necessary.
- Summary of the inspection items:

Item		Before starting engine	Engine running	After engine stopped
Engine coolant		Level	Leakage	Level
Engine oil		Level	Leakage	Level
Transmission/transaxle fluid	A/T and CVT Models	Leakage	Level/Leakage	Leakage
	M/T Models	Level/Leakage	Leakage	Level/Leakage
Other oils and fluids*		Level	Leakage	Level
Fuel		Leakage	Leakage	Leakage
Exhaust gas		—	Leakage	—

*Power steering fluid, brake fluid, etc.

ADJUSTMENT AFTER INSTALLATION

- Adjust the CVT fluid level. [TM-227, "Adjustment"](#).
- Perform "ADDITIONAL SERVICE WHEN REPLACING TRANSAXLE ASSEMBLY". Refer to [TM-128, "Description"](#).

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[CVT: RE0F11A]

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specification

INFOID:000000009019809

Applied model	Engine	HR16DE
	Axle	2WD
Transaxle model		RE0F11A
Stall torque ratio		1.91 : 1
Pulley ratio	Forward	2.200 – 0.550
	Reverse	2.200
Auxiliary gearbox gear ratio	1GR	1.821
	2GR	1.000
	Reverse	1.714
Counter gear		0.967
Final drive		3.882
Recommended fluid		Genuine NISSAN CVT Fluid NS-3 ^{*1}
Fluid capacity		Approx. 6.9 liter (7-1/4 US qt, 6-1/8 Imp qt) ^{*2}

CAUTION:

- Use only Genuine NISSAN CVT Fluid NS-3. Do not mix with other fluid.
- Use only Genuine NISSAN CVT Fluid NS-3. Using transmission fluid other than Genuine NISSAN CVT Fluid NS-3 will damage the CVT, which is not covered by the (NISSAN new vehicle limited) warranty.

*1: Refer to [MA-11, "Fluids and Lubricants"](#).

*2: The CVT fluid capacity is the reference value.

Shift Characteristics

INFOID:000000009019810

Unit: rpm

Throttle position	Shift pattern	Engine speed	
		At 40 km/h (25 MPH)	At 60 km/h (37 MPH)
2/8	"D" position (Overdrive control OFF)	1,300 – 3,100	1,400 – 3,400
	"D" position (Overdrive control ON)	2,200 – 3,100	2,700 – 3,500
	"L" position	3,000 – 3,800	3,500 – 4,300
8/8	"D" position (Overdrive control OFF)	3,600 – 4,400	4,300 – 5,100
	"D" position (Overdrive control ON)	3,600 – 4,400	4,300 – 5,100
	"L" position	3,600 – 4,400	4,300 – 5,100

CAUTION:

Lock-up is engaged at the vehicle speed of approximately 10 km/h (11 MPH) to 90 km/h (56 MPH).

Stall Speed

INFOID:000000009019811

Unit: rpm

Stall speed	2,420 – 2,870
-------------	---------------

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[CVT: RE0F11A]

Line Pressure

INFOID:0000000009019812

Unit: MPa (bar, kg/cm², psi)

Shift selector position	Engine speed	Line pressure
"P" and "N"	At idle	0.40 (4, 4.1, 58)
	At stall	0.40 (4, 4.1, 58) – 1.39 (13.9, 14.2, 201.6)
"R" and "D"	At idle	0.40 (4, 4.1, 58) – 1.39 (13.9, 14.2, 201.6)
	At stall	4.20 (42, 42.8, 609) – 4.70 (47, 47.9, 681.5)

Torque Converter

INFOID:0000000009019813

Distance (A) between the converter housing and torque converter	16.2 mm
---	---------

Heater Thermostat

INFOID:0000000009019814

Standard

Valve lift	More than 5.0 mm (0.197 in)
------------	-----------------------------

Reference value

Valve opening temperature	71°C (160°F)
Minimum valve lift	5.0 mm/85°C (0.197 in/203°F)