

Buick Regal 2014 – 2016 fuse box diagram

Engine Compartment Fuse Block



Buick Regal mk5 – fuse box – engine

compartment

Fuses	Usage
1	Transmission control module
2	Engine control module
3	Not Used
4	Not Used
5	Ignition/ Transmission control module/Engine control module
6	Windshield wiper
7	BPIM (eAssist only)
8	Not Used
9	Fuel injection, Ignition system
10	Engine control module
11	Oxygen sensor
12	Starter
13	Fuel system control module
14	Trunk release
15	MGU coolant pump (eAssist only)
16	Heated steering wheel
17	Not Used
18	BPIM (eAssist only)
19	Not Used
20	Not Used
21	Rear power windows
22	Antilock Brake System Valve
23	Obstacle detection
24	Front power windows
25	Power outlets
26	Antilock Brake System Pump
27	Electric parking brake
28	Rear window defogger


29	Left-Hand Seat Lumbar
30	Right-Hand Seat Lumbar
31	A/C clutch
32	Body control module 6
33	Heated front seats
34	Sunroof
35	Infotainment system
36	Adaptive cruise
37	Right high-beam headlamp
38	Left high-beam headlamp
39	All-Wheel Drive
40	Not Used
41	Vacuum pump
42	Radiator fan
43	Passive entry/ Passive start
44	Transmission auxiliary pump (eAssist only)
45	Radiator fan
46	Terminal 87/Main relay
47	Oxygen sensor
48	Fog lamps
49	Right-Hand Low Beam, High Intensity Discharge Headlamp
50	Left-Hand Low Beam, High Intensity Discharge Headlamp
51	Horn
52	Motor Indicator Lamp
53	Inside Rearview Mirror
54	Rear camera
55	Power windows/ Mirrors
56	Windshield washer
57	Not Used
58	Not Used
59	Secondary air induction (eAssist only)
60	Heated mirrors
61	Not Used
62	Canister vent solenoid
63	Not Used
64	Heater, Ventilation, and Air Conditioning Pump (eAssist Only)
65	Not Used
66	SAI check valve (eAssist only)
67	Fuel system control module

68	Not Used
69	Battery sensor
70	Right low-beam headlamp/DRL
71	Not Used

Relays	Usage
1	Air Conditioning Control
2	Starter
3	Not Used
4	Front wiper (step 2)
5	Front Wiper (Step 1, Interval)
6	Right low-beam headlamp/DRL
7	Main relay
8	Auxiliary heater pump (eAssist only)
9	Cooling fan
10	Cooling fan
11	Transmission auxiliary pump (eAssist only)
12	Not Used
13	Cooling fan
14	HID headlamps/Left low-beam headlamp/DRL
15	Ignition
16	Secondary AIR pump (eAssist only)
17	Window/Mirror defogger

Instrument Panel Fuse Block

The instrument panel fuse block is located in the instrument panel, on the driver side of the vehicle.



Buick Regal mk5 – fuse box – instrument panel

Item	Usage
------	-------

1	Suspension control module/Universal garage door opener/ESC
2	Body control module 1
3	Body control module 5
4	Radio
5	Radio displays/ Parking assist/ Infotainment/Module tunnel control
6	Instrument panel power outlet
7	Console power outlet
8	Body control module 3
9	Body control module 4
10	Body control module 8
11	Front Heater Ventilation Air Conditioning/Blower
12	Right-Hand Power Front Seat
13	Left-Hand Power Front Seat
14	Diagnostic Link Connector
15	Airbag
16	Steering wheel controls
17	Heating Ventilation Air Conditioning Controller
18	Service fuse/ Logistics relay
19	Memory seats
20	Automatic occupant sensing
21	Instrument cluster
22	Discrete Logic Ignition Switch/PEPS
23	Body control module 6
24	Body control module 2
25	OnStar
26	Spare