

IGNITION

IG(DOHC TURBO)

	Page
1. General Description.....	2
2. Spark Plug.....	4
3. Ignition Coil and Ignitor Assembly.....	8



GENERAL DESCRIPTION

Ignition

1. General Description S181001

A: SPECIFICATIONS S181001E49

Item		Designation
Ignition coil and ignitor assembly	Model	FK0140
	Manufacturer	DIAMOND
Spark plug	Type and manufacturer	PFR6G NGK
	Thread size mm	14, P = 1.25
	Spark gap mm (in)	0.7 — 0.8 (0.028 — 0.031)

B: COMPONENT S181001A05
en0853



EN0853

- (1) Spark plug
- (2) Ignition coil and ignitor ASSY

Tightening torque: N·m (kgf-m, ft-lb)

T1: 21 (2.1, 15)

T2: 16 (1.6, 11.7)

C: CAUTION S181001A03

- Wear working clothing, including a cap, protective goggles, and protective shoes during operation.
- Remove contamination including dirt and corrosion before removal, installation or disassembly.
- Keep the disassembled parts in order and protect them from dust or dirt.
- Before removal, installation or disassembly, be sure to clarify the failure. Avoid unnecessary

- removal, installation, disassembly, and replacement.
- Be careful not to burn your hands, because each part on the vehicle is hot after running.
 - Be sure to tighten fasteners including bolts and nuts to the specified torque.
 - Place shop jacks or safety stands at the specified points.
 - Before disconnecting electrical connectors of sensors or units, be sure to disconnect negative terminal from battery.

SPARK PLUG

2. Spark Plug

S181003

A: REMOVAL

S181003A18

CAUTION:

All spark plugs installed on an engine, must be of the same heat range.


Spark plug:

NGK: PFR6G

1. RH SIDE

S181003A1801

- 1) Disconnect battery ground cable.




- 2) Remove air cleaner lower case. <Ref. to IN(DOHC TURBO)-7, REMOVAL, Air Cleaner.>
- 3) Disconnect connector from ignition coil.

en0854




- 4) Remove ignition coil.

en0855



- 5) Remove spark plugs with the spark plug socket.


en0856




2. LH SIDE

S181003A1802

- 1) Disconnect battery cables, and then remove battery and battery carrier.



- 2) Disconnect washer motor connector (A).




- 3) Disconnect rear window glass washer hose from washer motor, then plug connection with a suitable cap.

SPARK PLUG

Ignition

- 4) Remove the two bolts which hold the washer tank, then take the tank away from the working area.



- 5) Disconnect connector from ignition coil.

en0857



- 6) Remove ignition coil.

en0858



- 7) Remove spark plug with the spark plugs socket.

en0859



B: INSTALLATION S181003A11

1. RH SIDE S181003A1101

- 1) Install in the reverse order of removal.

Tightening torque (Spark plug):
21 N·m (2.1 kgf-m, 15 ft-lb)

Tightening torque (Ignition coil):
16 N·m (1.63 kgf-m, 11.8 ft-lb)

CAUTION:

The above torque should be only applied to new spark plugs without oil on their threads. In case their threads are lubricated, the torque should be reduced by approximately 1/3 of the specified torque in order to avoid over-stressing.

2. LH SIDE S181003A1102

- 1) Install in the reverse order of removal.

Tightening torque (Spark plug):
21 N·m (2.1 kgf-m, 15 ft-lb)

Tightening torque (Ignition coil):
16 N·m (1.63 kgf-m, 11.8 ft-lb)

CAUTION:


The above torque should be only applied to new spark plugs without oil on their threads. In case their threads are lubricated, the torque should be reduced by approximately 1/3 of the specified torque in order to avoid over-stressing.

SPARK PLUG

C: INSPECTION

S181003A10

Check electrodes and inner and outer porcelain of plugs, noting the type of deposits and the degree of electrode erosion.




S6M0420A

- (A) Electrode gap
- (B) Carbon accumulation or wear
- (C) Cracks
- (D) Damage
- (E) Damaged gasket

1) Normal

Brown to grayish-tan deposits and slight electrode wear indicate correct spark plug heat range.




G6M0087

2) Carbon fouled

Dry fluffy carbon deposits on insulator and electrode are mostly caused by slow speed driving in city, weak ignition, too rich fuel mixture, dirty air cleaner, etc.


It is advisable to replace with plugs having hotter heat range.



G6M0088

3) Oil fouled


Wet black deposits show excessive oil entrance into combustion chamber through worn rings and pistons or excessive clearance between valve guides and stems. If same condition remains after repair, use a hotter plug.



G6M0089

4) Overheating

White or light gray insulator with black or gray brown spots and bluish burnt electrodes indicate engine overheating. Moreover, the appearance results from incorrect ignition timing, loose spark plugs, wrong selection of fuel, hotter range plug, etc. It is advisable to replace with plugs having colder heat range.



G6M0090

SPARK PLUG

Ignition

D: ADJUSTMENT S181003A01


Clean spark plugs in a sand blast type cleaner. Avoid excessive blasting. Clean and remove carbon or oxide deposits, but do not wear away porcelain.

If deposits are too stubborn, replace plugs.

After cleaning spark plugs, recondition firing surface of electrodes with file. Then correct the spark plug gap using a gap gauge.

Spark plug gap: L

0.7 — 0.8 mm (0.028 — 0.031 in)



NOTE:

Replace with new spark plug if this area is worn to "ball" shape.

IGNITION COIL AND IGNITOR ASSEMBLY

Ignition

3. Ignition Coil and Ignitor Assembly S181015

A: REMOVAL S181015A18

Direct ignition type has been adopted. Refer to the "Spark Plug Removal" for removal procedure. <Ref. to IG(DOHC TURBO)-4, REMOVAL, Spark Plug.>

B: INSTALLATION S181015A11

Install in the reverse order of removal.

Tightening torque:

16 N·m (1.63 kgf-m, 11.8 ft-lb)

C: INSPECTION S181015A10

Because ignition coil is a direct ignition type, the resistance cannot be measured in a single unit. For inspection procedure of ignition system, refer to the following. <Ref. to EN(DOHC TURBO)-72, IGNITION CONTROL SYSTEM, Diagnostics for Engine Starting Failure.>