



The Ultimate  
Driving Machine

# Contents

## A to Z



[CarManuals2.com](http://CarManuals2.com)

[CarManuals2.com](http://CarManuals2.com)

**X5 3.0i**  
**X5 4.4i**  
**X5 4.8is**

Congratulations, and thank you for choosing a BMW.

Thorough familiarity with your vehicle will provide you with enhanced control and security when you drive it. We therefore have this request:

Please take the time to read this Owner's Manual and familiarize yourself with the information that we have compiled for you before starting off in your new BMW. The manual contains important data and instructions intended to assist you in obtaining maximum satisfaction from your BMW's unique array of advanced technical features. It also contains information on vehicle maintenance designed to enhance operating safety while simultaneously helping you to maintain your BMW's value throughout an extended service life. For additional information refer to the supplemental manuals.

This Owner's Manual should be considered a permanent part of this vehicle. It should stay with the vehicle when sold to provide the next owner with important operating, safety and maintenance information.

We wish you an enjoyable driving experience.

BMW AG

# Contents

## Notes

|                            |    |
|----------------------------|----|
| About this Owner's Manual  | 8  |
| Symbols used               | 8  |
| Your individual vehicle    | 8  |
| Status at time of printing | 9  |
| For your own safety        | 9  |
| Symbol on vehicle parts    | 10 |
| Service and Warranty       | 10 |
| Reporting safety defects   | 11 |

## Overview

|                             |    |
|-----------------------------|----|
| Cockpit                     | 14 |
| Instrument cluster          | 15 |
| Indicator and warning lamps | 19 |
| Buttons on steering wheel   | 23 |
| Warning triangle            | 24 |
| First-aid kit               | 24 |
| Refueling                   | 24 |
| Fuel specifications         | 26 |

## Controls and features

### Locks and security systems:

|                        |    |
|------------------------|----|
| Keys                   | 30 |
| Central locking system | 30 |
| Opening and closing:   |    |
| from outside           | 31 |
| Opening and closing:   |    |
| from inside            | 34 |
| Liftgate               | 35 |
| Tailgate               | 36 |
| Alarm system           | 38 |
| Windows                | 39 |
| Panorama glass sunroof | 41 |

### Adjustments:

|                                 |    |
|---------------------------------|----|
| Sitting safely                  | 43 |
| Seats                           | 44 |
| Mechanical seat adjustment      | 45 |
| Power seat adjustment           | 46 |
| Head restraints                 | 47 |
| Power rear-seat backrest        |    |
| adjustment                      | 48 |
| Safety belts                    | 49 |
| Seat, mirror and steering wheel |    |
| memory                          | 50 |
| Heated seats                    | 52 |
| Steering wheel                  | 52 |
| Steering wheel heater           | 53 |
| Mirrors                         | 54 |

© 2004 Bayerische Motoren Werke

Aktiengesellschaft

Munich, Germany

Reprinting, including excerpts,  
only with the written consent of  
BMW AG, Munich.

Order No. 01 41 0 158 701

US English IX/04

Printed in Germany

Printed on environmentally friendly paper,  
bleached without chlorine, suitable for recycling.

CarManuals2.com

**Passenger safety systems:**

- Airbags 57
- Transporting children safely 59
- Vehicle Memory,
  - Key Memory 63

**Driving:**

- Ignition lock 64
- Starting engine 64
- Switching off engine 65
- Handbrake 66
- Manual transmission 66
- Automatic transmission with
  - Steptronic 67
- Turn signals/
  - headlamp flasher 70
- Washer/wiper system/
  - rain sensor 71
- Cruise control 74

**Everything under control:**

- Odometer, outside temperature
  - display 76
- Tachometer 77
- Energy control 77
- Engine oil thermometer 78
- Fuel gage 78
- Coolant temperature gage 79
- Service Interval Display 79
- Check Control 80
- Computer 82
- MID Multi-Information
  - Display 84

Digital clock in MID 85

Computer in MID 88

**Technology for safety and driving convenience:**

- PDC Park Distance Control 93
- Antilock Brake System 94
- DSC Dynamic Stability
  - Control 95
- xDrive 97
- HDC Hill Descent Control 97
- Self-leveling suspension 98
- 2-axle self-leveling
  - suspension 99
- Brake Force Display 101
- Flat Tire Monitor 101

**Lamps:**

- Parking lamps/low beams 103
- Adaptive Head Light 104
- High beams/roadside parking
  - lamps 104
- Front fog lamps 105
- Instrument lighting 105
- Interior lamps 105

**Controlling the climate for pleasant driving:**

- Air conditioner 107
- Automatic climate control 110
- Roller sun blinds 115
- Independent ventilation 116

**Cabin convenience:**

- Integrated universal remote
  - control 117
- Portable phone 119
- Glove compartment 120
- Storage compartments 120
- Cup holders 121
- Ashtray, front 122
- Ashtray, rear 122
- Cigarette lighter, rear 123

**Loading and transporting:**

- Ski bag 124
- Cargo area
  - Folding rear backrests
    - down 126
  - Roll-up cover 126
  - Partition net 127
  - Flaps in cargo area 128
  - Power outlets 129
  - Pull-out floor in cargo
    - area 130
- Cargo loading 131
- Roof-mounted luggage rack 133

# Contents

## Operation, maintenance

### Special operating instructions:

- Breaking-in [136](#)
- General driving notes [137](#)
- Driving your X5 [138](#)
- Safe braking [140](#)

### Wheels and tires:

- Tire inflation pressure [141](#)
- Tire identification marks [143](#)
- Wheel/tire condition [144](#)
- Replacing wheels/tires [146](#)
- Snow chains [147](#)

### Under the hood:

- Hood [148](#)
- Engine compartment  
essentials [149](#)
- Washer fluid [150](#)
- Engine oil [150](#)
- Coolant [152](#)
- Brake fluid [153](#)

### Care and maintenance:

- The BMW Maintenance  
System [154](#)
- OBD interface socket [155](#)

## Owner service procedures

### Replacement procedures:

- Onboard tool kit [158](#)
- Windshield wiper blades [158](#)
- Lamps and bulbs [159](#)
- Changing a tire [163](#)
- Vehicle battery [168](#)
- Fuses [169](#)

### Assistance, giving and receiving:

- Receiving assistance [170](#)
- Jump starting [171](#)
- Tow-starting and towing [172](#)

## Technical data

Engine specifications [178](#)  
Dimensions [179](#)  
Weights [180](#)  
Capacities [181](#)

## Index

Everything from A to Z [184](#)

[CarManuals2.com](http://CarManuals2.com)

### About this Owner's Manual

We have made every effort to ensure that you are able to find what you need in this Owner's Manual as quickly as possible. The fastest way to find certain topics is by using the detailed index at the end. If you desire an initial overview of your vehicle, this can be found in the first chapter.

Should you want to sell your BMW some day, please remember to hand over the Owner's Manual as well; it is an important component of your vehicle.

Additional sources of information:

If you have any questions, your BMW Sports Activity Vehicle center will be glad to advise you.

You can find information on BMW, e.g. technology, on the Internet at [www.bmwusa.com](http://www.bmwusa.com).

### Symbols used



Indicates precautions that must be followed precisely in order to avoid the possibility of personal injury and serious damage to the vehicle.



Indicates information that will assist you in gaining the optimum benefit from your vehicle and enable you to care more effectively for your vehicle.



Refers to measures that can be taken to help protect the environment.

◀ Marks the end of a specific item of information.

\* Indicates special equipment, country-specific equipment and optional extras, as well as equipment and functions not yet available at the time of printing.



Vehicle Memory, Key Memory, refer to page 63. Identifies functions that can be specifically adapted for a particular key or vehicle. These adjustments can be performed by your BMW Sports Activity Vehicle center.

[CarManuals2.com](http://CarManuals2.com)

### Your individual vehicle

On buying your BMW, you have decided in favor of a model with individualized equipment and features. This Owner's Manual describes all models and equipment that BMW offers within the same group.

We hope you will understand that equipment and features are included that you might not have chosen for your vehicle. Sections describing options and special equipment are marked by an asterisk \* to assist you in identifying possible differences between the descriptions in this manual and your own vehicle's equipment.

Should equipment of your BMW not be described in this Owner's Manual, please refer to the included Supplementary Owner's Manuals.

# Notes

## Status at time of printing

BMW pursues a policy of continuous, ongoing development that is conceived to ensure that our vehicles continue to embody the highest quality and safety standards combined with advanced, state-of-the-art technology. Thus in rare circumstances, the features described in this Owner's Manual may differ from those of your vehicle.

## For your own safety

Maintenance and repair:



Advanced technology, e.g. the use of modern materials and high-performance electronics, requires specially adapted maintenance and repair methods. Therefore, only have corresponding work on your BMW carried out by a BMW Sports Activity Vehicle center or a workshop that works according to BMW repair procedures with correspondingly trained personnel. If work is carried out improperly there is a danger of consequential damage and the related safety risks. ◀

California Proposition 65 Warning:

California laws require us to state the following warning:



Engine exhaust and a wide variety of automobile components and parts, including components found in the interior furnishings in a vehicle, contain or emit chemicals known to the State of California to cause cancer and birth defects and reproductive harm. In addition, certain fluids contained in vehicles and certain products of component wear contain or emit chemicals known to the State of California to

cause cancer and birth defects or other reproductive harm.

Battery posts, terminals and related accessories contain lead and lead compounds. Batteries also contain other chemicals known to the State of California to cause cancer. Wash your hands after handling.

Used engine oil contains chemicals that have caused cancer in laboratory animals. Always protect your skin by washing thoroughly with soap and water. ◀

Parts and accessories:



For your own safety, use genuine parts and accessories approved by BMW.

When you purchase accessories tested and approved by BMW and Genuine BMW Parts, you simultaneously acquire the assurance that they have been thoroughly tested by BMW to ensure optimum performance when installed on your vehicle.

BMW warrants these parts to be free from defects in material and workmanship.

BMW will not accept any liability for damages resulting from installation of parts and accessories not approved by BMW.

BMW cannot test every product on the market to determine whether it can be used on a BMW safely and without risk to either the vehicle, its operation, or its occupants.

Genuine BMW Parts, BMW Accessories and other products approved by BMW, together with professional advice on using these items, are available from all BMW Sports Activity Vehicle centers. Installation and operation of non-BMW approved accessories such as alarms, radios, amplifiers, radar detectors, wheels, suspension components, brake dust shields, telephones – including operation of any portable phone from within the vehicle without using an externally mounted antenna – or transceiver equipment such as CB, walkie-talkie, ham radio or similar accessories, may cause extensive damage to the vehicle, compromise its safety, interfere with the vehicle's electrical system or affect the validity of the BMW Limited Warranty. Refer to your BMW Sports Activity Vehicle center for additional information. ◀



Maintenance, replacement, or repair of the emission control devices and systems may be performed by any automotive repair establishment or individual using any certified automotive part. ◀

### Symbol on vehicle parts



Indicates that you should consult the relevant section of this Owner's Manual for information on a particular part or assembly.

[CarManuals2.com](http://CarManuals2.com)

### Service and Warranty

This manual is supplemented by a Service and Warranty Information Booklet for US models or a Warranty and Service Guide Booklet for Canadian models.

We recommend that you read this publication thoroughly.

Your BMW is covered by the following warranties:

- ▷ New Vehicle Limited Warranty
- ▷ Rust Perforation Limited Warranty
- ▷ Federal Emissions System Defect Warranty
- ▷ Federal Emissions Performance Warranty
- ▷ California Emissions Control System Limited Warranty

Detailed information about these warranties is listed in the Service and Warranty Information Booklet for US models or in the Warranty and Service Guide Booklet for Canadian models.

# Notes

## Reporting safety defects

The following only applies to vehicles owned and operated in the US.

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration NHTSA in addition to notifying BMW of North America, LLC, P.O. Box 1227, Westwood, New Jersey 07675-1227, Telephone 800-831-1117.

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or BMW of North America, LLC.

To contact NHTSA, you may either call the Auto Safety Hotline toll-free at 1-800-424-9393 or 366-0123 in Washington, D.C. area or write to: NHTSA, U.S. Department of Transportation, Washington, D.C. 20590. You can also obtain other information about motor vehicle safety from the Hotline.

CarManuals2.com



## Overview

Controls and features

Operation, maintenance


Owner service procedures

Technical data

Index



CarManuals2.com



- 1 Parking lamps/low beams 103
- 2 Fog lamps 105
- 3 ▷ Turn signals 70
  - ▷ Roadside parking lamps 104
  - ▷ High beams 104
  - ▷ Headlamp flasher 70
  - ▷ Computer 82

- 4 Washer/wiper system/rain sensor 71
- 5 Rear window defroster 108, 113
- 6 Central locking system 30
- 7 Hazard warning flashers
- 8 Horn: the entire surface
- 9 Adjusting steering wheel 52




- |                                                      |                                                                        |                                               |
|------------------------------------------------------|------------------------------------------------------------------------|-----------------------------------------------|
| 1 Fuel gage <a href="#">78</a>                       | 3 Speedometer                                                          | 5 Tachometer <a href="#">77</a>               |
| 2 Indicator lamp for turn signals <a href="#">22</a> | 4 Indicator and warning lamps <a href="#">19</a> to <a href="#">22</a> | Energy control <a href="#">77</a>             |
|                                                      |                                                                        | 6 Coolant temperature gage <a href="#">79</a> |

## 16 Instrument cluster X5 3.0i, 4.4i




- |                                                                        |                                                                                                                                                                                            |                                                                                      |
|------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------|
| 7 Indicator and warning lamps <a href="#">19</a> to <a href="#">22</a> | 11 Display for computer; operation via turn signal lever, refer to page <a href="#">82</a> :<br>▷ Outside temperature<br>▷ Average fuel consumption<br>▷ Cruising range<br>▷ Average speed | 12 Service Interval Display <a href="#">79</a>                                       |
| 8 Reset button for trip odometer <a href="#">76</a>                    |                                                                                                                                                                                            | 13 Selector lever and program display for automatic transmission* <a href="#">67</a> |
| 9 Indicator for Check Control <a href="#">80</a>                       |                                                                                                                                                                                            | 14 Indicator and warning lamps <a href="#">19</a> to <a href="#">22</a>              |
| 10 Odometer and trip odometer <a href="#">76</a>                       |                                                                                                                                                                                            |                                                                                      |



- |                                                                        |                                                                                                             |                                                                                      |
|------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------|
| 1 Fuel gage <a href="#">78</a>                                         | 7 Indicator and warning lamps <a href="#">19</a> to <a href="#">22</a>                                      | 12 Selector lever and program display for automatic transmission* <a href="#">67</a> |
| 2 Indicator lamp for turn signals <a href="#">22</a>                   | 8 Reset button for trip odometer <a href="#">76</a>                                                         | 13 CHECK button <a href="#">80</a>                                                   |
| 3 Speedometer                                                          | 9 Service Interval Display <a href="#">79</a>                                                               | 14 Indicator and warning lamps <a href="#">19</a> to <a href="#">22</a>              |
| 4 Indicator and warning lamps <a href="#">19</a> to <a href="#">22</a> | 10 Indicator for<br>▷ Trip odometer/odometer <a href="#">76</a><br>▷ Outside temperature <a href="#">76</a> |                                                                                      |
| 5 Tachometer <a href="#">77</a><br>Energy control <a href="#">77</a>   | 11 Indicator for Check Control <a href="#">80</a>                                                           |                                                                                      |
| 6 Coolant temperature gage <a href="#">79</a>                          |                                                                                                             |                                                                                      |

## 18 Instrument cluster X5 4.8is



- |                                           |                                                                             |                                                                     |
|-------------------------------------------|-----------------------------------------------------------------------------|---------------------------------------------------------------------|
| 1 Fuel gage 78                            | 7 Indicator and warning lamps 19 to 22                                      | 12 Selector lever and program display for automatic transmission 67 |
| 2 Indicator lamp for turn signals 22      | 8 Reset button for trip odometer 76                                         | 13 CHECK button 80                                                  |
| 3 Speedometer                             | 9 Service Interval Display 79                                               | 14 Indicator and warning lamps 19 to 22                             |
| 4 Indicator and warning lamps 19 to 22    | 10 Indicator for<br>▷ Trip odometer/odometer 76<br>▷ Outside temperature 76 |                                                                     |
| 5 Tachometer 77<br>Engine oil thermometer | 11 Indicator for Check Control 80                                           |                                                                     |
| 6 Coolant temperature gage 79             |                                                                             |                                                                     |

# Indicator and warning lamps

## Technology that monitors itself

Indicator and warning lamps that are identified by ● are tested for proper functioning whenever the ignition key is turned. They each light up once for different periods of time.

If a fault should occur in one of the monitored systems, the corresponding lamp does not go out after the engine is started or it lights up while the vehicle is moving. You will see how to react to this in the following section.

## Red: stop immediately



**Battery charge current ●**  
The battery is not being charged. There is a malfunction of the alternator drive belt or in the charging circuit of the alternator. Have the system checked immediately.



**▲** If the drive belt is defective, do not continue driving. The engine could be damaged due to overheating. If the drive belt is defective, increased steering effort is also required. ◀



**Engine oil pressure ●**  
Stop immediately and switch off the engine. Check the engine oil level; top up as required. If the oil level is correct: have the system checked immediately.



**▲** Do not continue driving. The engine could be damaged because of inadequate lubrication. ◀



**Handbrake\* /  
brake hydraulic system ●**  
Lights up with handbrake engaged.

For additional information, refer to page 66

Comes on although the handbrake is released: stop immediately. The brake fluid in the reservoir has fallen to below the minimum level. At the same time, a considerably longer brake pedal travel may be noticeable. Have the system checked immediately.



**▲** During continued driving increased brake pedal pressure may be necessary, and considerably longer braking distances may result. Please remember to adapt your driving style accordingly. ◀

Before continuing your journey, be sure to read the notes on pages 140 and 153.

Also comes on in the Check Control with the message CHECK BRAKE LININGS.



**Indication of the malfunction in Canadian models described above.**



**Transmission temperature\*** ●  
The transmission is overheated. Reduce speed immediately and stop at a suitable location so that the system can cool down again. Have the system checked immediately.

### Yellow: stop immediately



**Flat Tire Monitor** ●  
An acoustic signal also sounds: there is a flat tire or extensive inflation pressure loss. Reduce speed immediately for stopping while avoiding extreme braking and steering maneuvers.

For additional information, refer to page [102](#)

### Red or yellow: continue to drive cautiously



The red brake warning lamp lights up together with the warning lamps for ABS and DSC/xDrive. In addition, a warning signal sounds:



ABS, DSC, HDC and xDrive have failed. Drive may then only be carried out via the rear axle.



Have the system checked as soon as possible.

For additional information, refer to pages [94](#), [95](#)



Proceed cautiously and defensively. When driving on poor roads, avoid using full throttle or pressing the accelerator beyond the kick-down point and also avoid forceful braking or full braking. Otherwise the drive train may be damaged or accidents can occur. ◀

If the brake warning lamp lights up yellow in the described combination, the EBV Electronic brake-force distribution is still available.



Indication of the above-described malfunction in Canadian models.



# Indicator and warning lamps

## Red: an important reminder



**Handbrake\***  
Lights up with handbrake engaged.

For additional information, refer to page [66](#)



**Handbrake warning lamp\*** for Canadian models



**Please fasten safety belts ●**  
Indicator lamp flashes or lights up. In addition, a signal sounds and, depending on the equipment, a message\* appears in the Check Control. Please check safety belts for correct placement.

The belt memory is activated when the safety belt on the driver's side has not yet been fastened.

The belt memory is also active from a speed of approx. 5 mph/8 km/h when the passenger belt has not yet been fastened, heavy objects are placed on the front passenger seat or passengers sitting in the front remove their safety belts.

For additional information on safety belts, refer to page [49](#)



**Airbags ●**  
Malfunction in airbag system. Have the system checked as soon as possible.

For additional information, refer to page [57](#)

## Yellow: check as soon as possible



**DBC Dynamic Brake Control ●**  
Malfunction in the DBC system. Please have the system checked as soon as possible.

For details on DBC, refer to page [94](#)



Indication of the above-described malfunction in Canadian models.



**Engine oil level ●**  
Comes on while driving: the oil level is at the absolute minimum; refill as soon as possible. Do not drive more than approx. 30 miles/50 km until you do.

For additional information, refer to page [150](#)



**Engine oil level ●**  
Comes on after the engine has been switched off: add engine oil at your earliest opportunity, e.g. when you stop to refuel.

For additional information, refer to page [150](#)



**Automatic transmission\***  
The automatic transmission switches into the emergency program due to a fault. Have the system checked as soon as possible.

For additional information, refer to page [69](#)



**Brake pads\* ●**  
Have the condition of the brake pads checked.

For additional information, refer to page [140](#)



**Self-leveling suspension\* ●**  
The self-leveling suspension is inactive. Have the system checked as soon as possible.

For additional information, refer to page [98](#)

## 22 Indicator and warning lamps



DSC Dynamic Stability Control/xDrive ●

The warning lamp lights up continuously and a warning signal sounds: DSC and HDC or the xDrive 4-wheel drive system have failed.

The stabilizing interventions of DSC or the xDrive 4-wheel drive system are no longer available. Drive may then only be carried out via the rear axle.

Have the system checked as soon as possible.

For additional information, refer to page [95](#)



Proceed cautiously and defensively. When driving on poor roads, avoid using full throttle or pressing the accelerator beyond the kick-down point and also avoid forceful braking or full braking. Otherwise the drive train may be damaged or accidents can occur.◀



Engine electronics\*

Malfunction in the engine electronics. You can continue to drive with reduced engine output or engine speed. Have the system checked as soon as possible.



Service Engine Soon ●

If the indicator lamp lights up continuously or intermittently, there is a fault in the exhaust-relevant electronic systems. Although the vehicle remains operable, the system must be checked as soon as possible.

For additional information, refer to page [155](#)



Indication of the above-described malfunction in Canadian models.



Check Gas Cap\* ●

Warning lamp lights up. Fuel filler cap is not properly closed or is missing. Check whether the fuel filler cap is properly closed.

For additional information, refer to page [25](#)

### Green: for your information



Turn signals

Flashes when the turn signals are operated. Rapid flashing indicates a system malfunction.

For additional information, refer to page [70](#)



Cruise control\*

Lights up when system is switched on: ready for operation using the buttons on the steering wheel.

For additional information, refer to page [74](#)



Fog lamps

Lights up when fog lamps are switched on.

For additional information, refer to page [105](#)

### Blue: for your information



High beams

Lights up when the high beams are on or the headlamp flasher is actuated.

For additional information, refer to pages [70](#), [104](#)

## Buttons on steering wheel\*

The buttons integrated in the steering wheel are provided so that you can operate a number of accessories quickly and without being distracted from traffic conditions. You may operate:

- ▷ selected functions of the audio sources\*
- ▷ the recirculated-air mode of the air conditioner\* or the steering-wheel heater\*
- ▷ the cruise control
- ▷ selected phone functions\* and
- ▷ the voice command system\*.



In order to operate a system, the corresponding system must be switched on. ◀



Press briefly:  
Accept incoming call, start dialing, terminate call.  
Extended pressure:  
Switch voice command system on and off



Display/hide phonebook. Display the entries consecutively with the buttons for forward/back



Forward:

- ▷ Radio  
Press briefly: next stored station  
Extended pressure: station search function
- ▷ CD  
Press briefly: track search  
Extended pressure: fast forward in track
- ▷ Cassette  
Press briefly: stop track search or fast forward  
Extended pressure: fast forward
- ▷ Portable phone  
Scroll through list of names



Reverse: functions as for fast forward



Volume

On the sports steering wheel\*, there are +/- buttons for volume on the left side of the steering wheel.



Cruise control: call up



Cruise control: store and accelerate + as well as decelerate and store -

On the sports steering wheel\*, there are +/- buttons on the right side of the steering wheel for the cruise control.



Cruise control: activate/interrupt/deactivate



Recirculated-air mode\* and AUC automatic recirculated-air control or steering wheel heater\*: switch on/off



1. Open the cover on the left in the cargo area: lift the handle on the cover
2. Pull the tab of the retaining strap, refer to arrow, and remove the hazard warning triangle from the support bracket
3. To install: slide the hazard warning triangle into the support bracket and press on the retaining strap.



Comply with legal requirements requiring you to carry a hazard warning triangle in the vehicle. ◀

## First-aid kit\*



The first-aid kit is located under the front passenger's seat.


To open: pull the handle and fold the cover down.

To close: fold the cover up.



Some of the articles in the first-aid kit may be used within a limited time only. Therefore, check the expiration dates of the contents regularly and replace the contents concerned in good time if necessary. You can find replacements in any pharmacy. Always observe all legal regulations requiring a first-aid kit to be carried in the vehicle. ◀

## Refueling



### Fuel filler door



Before filling the tank, switch off the engine. If you do not, fuel cannot be filled into the tank and the Service Engine Soon lamp may come on. ◀

To open the fuel filler door, press on the front edge.

In the event of an electrical malfunction, you can also open the fuel filler door manually:

1. Open the cover on the right in the cargo area: lift the handle on the cover
2. Pull the knob with the fuel pump symbol.

 When handling fuels always observe any safety guidelines posted at the service station. Never carry spare fuel containers in your vehicle. Whether empty or full, these containers can leak, cause an explosion, or lead to fire in the event of a collision. ◀



## Observe the following when refueling

 Open the filler cap carefully to prevent fuel from spraying out. Fuel spray may cause injury. Do not top off. Topping off may cause fuel spillage. ◀

Keep the filler cap in the bracket attached to the fuel filler door.

When refueling, insert the filler nozzle completely into the filler pipe. Pulling the nozzle out of the pipe during refueling

- ▷ results in premature pump shutoff
- ▷ and will reduce the effect of the vapor recovery system on the pump.

The fuel tank is full when the filler nozzle clicks off the first time.

To close the fuel filler cap:  
Fit the cap and turn it clockwise until you clearly hear a click.

 Close the filler cap carefully after refueling until a click is heard. While closing, be sure not to squeeze the strap which is fastened to the cap. A loose or missing cap will activate the message CHECK GAS CAP in the Check Control\* or the Check Gas Cap lamp\*. ◀

Tank capacity:  
approx. 24.6 gal./approx. 93 liters, including reserve  
6-cylinder engine: approx. 2.0 gal./approx. 8 liters  
8-cylinder engine: approx. 2.5 gal./approx. 10 liters.

 Never attempt to continue driving until the tank is completely empty, as engine functions could be affected, and the vehicle could sustain damage as a result. ◀

The engine uses lead-free gasoline only.

### Required fuel

Premium Unleaded Gasoline,  
Minimum Octane Rating: 91.

Minimum Octane Rating corresponds to the Anti Knock Index AKI and is determined according to the so-called (R+M)/2 method.



Do not use leaded gasoline, as otherwise the lambda probe and catalytic converter will be permanently damaged. ◀

### Use high-quality brands

Field experience has indicated significant differences in fuel quality: volatility, composition, additives, etc., among gasolines offered for sale in the United States and Canada. Fuels containing up to and including 10% ethanol or other oxygenates with up to 2.8% oxygen by weight, that is, 15% MTBE or 3% methanol plus an equivalent amount of co-solvent, will not void the applicable warranties with respect to defects in materials or workmanship.



The use of poor-quality fuels may result in drivability, starting and stalling problems especially under certain environmental conditions such as high ambient temperature and high altitude.

Should you encounter drivability problems which you suspect could be related to the fuel you are using, we recommend that you respond by switching to a recognized high-quality brand.

Failure to comply with these recommendations may also result in unscheduled maintenance. ◀

CarManuals2.com

Index

Data

Repairs

Maintenance

Controls

Overview



Overview

Controls and features


Operation, maintenance

Owner service procedures

Technical data

Index

CarManuals2.com



### The key set

- 1 Each master key with remote control contains a long-life battery as power supply, which is automatically recharged in the ignition lock while driving. It is therefore necessary to use each master key at least twice per year in order to maintain the charge. Depending on which master key the vehicle detects during unlocking, different settings will be requested and executed in the vehicle, refer to Vehicle and Key memory on page [63](#).

- 2 Spare key for storage in a safe place, such as in your wallet.

This key does not fit in the lock of the glove compartment. This is an advantage in a hotel, for example. The key is not intended for continuous use.

### Replacement keys

Additional or replacement keys are available at your BMW Sports Activity Vehicle center.

## Central locking system

### The concept

The central locking system is ready for operation as soon as you close the front doors. The system engages or releases the locks on the

- ▷ doors
- ▷ liftgate/tailgate
- ▷ fuel filler door.

The central locking system can be operated

- ▷ from outside via the remote control as well as via the driver's door lock
- ▷ from inside via the button for the central locking system.

If the system is locked from inside, the fuel filler door remains unlocked, refer to page [34](#).

When the system is actuated from outside of the vehicle, the anti-theft system is actuated simultaneously. This prevents the doors from being unlocked via lock buttons or door handles. The alarm system is also armed or disarmed.

In an accident of sufficient severity the central locking system automatically unlocks, but only doors which have not been locked separately with the lock buttons, refer to page [34](#). In addition, the hazard warning flashers and the interior lamps are switched on.

# Opening and closing: from outside

## Using remote control

When you engage/release the vehicle locks, you also activate/deactivate the anti-theft system, arm/disarm the alarm system, and switch the interior lamps on/off.



Protect the remote control against unauthorized use by handing over only the spare key, for example when using hotel valet parking. ◀

You can find more detailed information on the alarm system on page 38.



Since passengers or animals remaining in the vehicle might be able to lock the doors from the inside, take the vehicle's keys with you so that the vehicle can be opened again from the outside at any time. ◀

## Unlocking vehicle



Press button.

Press the button once to unlock the driver's door and the fuel filler door only; press a second time to unlock all remaining doors as well as the tailgate/liftgate.

## Convenience opening mode



Press the button briefly and then hold down.

The windows and the panorama glass sunroof open.

## Locking and securing



Press button.

As a confirmation that the vehicle is correctly locked, the hazard warning flashers light up.



If you so desire, you can have this function deactivated if your vehicle is not equipped with an alarm system. ◀ [CarManuals2.com](http://CarManuals2.com)

## Switching on interior lamps



If the vehicle is locked, press button. With this function, you can also search for your vehicle, e.g. when parked in an underground garage.

## Switching off tilt alarm sensor and interior motion sensor



Press button once again directly after locking.

For more detailed information, refer to page 39.

## Opening liftgate



Briefly press the button.

The liftgate will open slightly, regardless of whether it was previously locked or unlocked.

## 32 Opening and closing: from outside



If the vehicle is locked, the tailgate/liftgate is also locked again when closed.

Before and after a trip, be sure that the tailgate/liftgate was not opened unintentionally. ◀

### Panic mode



By pressing and holding the button for more than two seconds, you can start the alarm system if there is an impending danger if it is armed.

To switch off the alarm



Press button.

### Malfunction

The remote control can be subjected to malfunctions by local radio waves. Should the remote control fail to operate owing to interference of this kind, unlock and lock the vehicle via the door lock using the master key.

If it is no longer possible to lock the vehicle via the remote control, the battery is discharged. Use this remote control during an extended drive; this will recharge the battery, refer to page 30.

### For US owners only

The transmitter and receiver units comply with part 15 of the FCC/Federal Communication Commission regulations. Operation is governed by the following:

FCC ID: LX8EWS  
LX8FZVS  
LX8FZVE

Compliance statement:


This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- ▷ This device may not cause harmful interference, and
- ▷ this device must accept any interference received, including interference that may cause undesired operation.



Any unauthorized modifications to these devices could void the user's authority to operate this equipment. ◀

## Opening and closing: from outside



### Using door lock

One turn of the key in the driver's door lock unlocks the driver's door only.

Turning the key a second time unlocks all of the remaining doors, the liftgate/tailgate and the fuel filler door.

As a confirmation that the vehicle is correctly locked, the hazard warning flashers light up.



If you so desire, you can deactivate this function if your vehicle is not equipped with an alarm system. ◀

### Convenience operation

You also have the option of operating the windows and the panorama glass sunroof from the door lock.

- ▷ To open: with the door closed, turn the key to the Unlock position and hold it.
- ▷ To close: with the door closed, turn the key to the Lock position and hold it.



Watch during the closing process to be sure that no one is injured. Releasing the key stops the operation. ◀

### Manual operation

In the event of an electrical malfunction, turn the key to the extreme left or right to unlock/lock the door.

## 34 Opening and closing: from inside



When the front doors are closed, this button unlocks or locks the doors and liftgate, but does not engage the anti-theft system. The fuel filler door remains unlocked.



You have the option of setting the central locking system to lock automatically as soon as you move off. This can be adjusted to be key-specific. ◀



If only the driver's door was unlocked from the outside and you press the button

- ▷ all other doors, the tailgate/liftgate and the fuel filler door will be unlocked when the driver's door is opened
- ▷ the driver's door will be locked again when it is closed. ◀

### Unlocking and opening doors

- ▷ Either unlock the doors together with the button for the central locking system and then pull the door handle above the armrest or
- ▷ pull the release handle for each door twice: the first pull unlocks the door, and the second one opens it.


### Locking

- ▷ Use the central locking button to lock all of the doors simultaneously, or
- ▷ press down the individual lock buttons. As an added design feature to prevent the driver from being inadvertently locked out of the vehicle, the driver's lock button will not engage as long as the door is open.



When the vehicle is moving, do not lock the doors with the lock buttons. Doors locked in this manner would not unlock automatically in the event of an accident.

Since passengers or animals remaining in the vehicle might be able to lock the doors from the inside, take the vehicle's keys with you so that the vehicle can be opened again from the outside at any time. ◀



## Opening from outside

Press the button, refer to arrow:  
The liftgate opens slightly.

The cargo area is illuminated whenever the liftgate is opened, refer also to page [105](#).

 With the liftgate open, the distance from the ground to the upper edge is more than 6.6 ft/2 m. Please consider this, e.g. when opening the liftgate in a garage. ◀



## Opening from inside

Press this button to open the liftgate when the vehicle is stationary.

 If pointed or sharp-edged objects could strike the rear window while driving, be sure to provide protection around all edges. If you do not do this, the heating conductors of the rear window could be damaged. ◀


For information on the cargo area cover and on other details in the cargo area, refer to Cargo area, beginning on page [126](#).



## Manual release

In the event of an electrical malfunction, you can release the liftgate manually:

1. Remove the plastic plug from inside the cargo area and pull toward the interior, refer to arrow. The liftgate will be released
2. Reinstall the plug.



### Closing

You can pull the liftgate down by placing both hands in the handle recesses, refer to arrows.


### Automatic Soft Close function

To close the liftgate, merely press it down gently. The closing process will then be carried out automatically.



To avoid injuries, be sure that the travel path of the liftgate is clear when it is closed, as with all closing procedures. ◀

## Tailgate




### Opening

Press button:

You can fold the tailgate down.




When opened, the tailgate can accept loads of up to 440 lbs./ 200 kg. When the vehicle is stationary you may, for example, utilize the tailgate as a seat or as a loading platform for luggage or recreation gear. ◀




### Manual release

In the event of an electrical malfunction, you can release the tailgate manually:

1. Unfasten the trim panel clip with the vehicle key or with a screwdriver, refer to arrow 1, and remove it toward the top, refer to arrow 2



2. Using the same tool, press the latch in the direction of the arrow; the tailgate is released
3. Reinstall the trim panel.



## Luggage straps

Use the retaining straps on the cargo floor cover to secure smaller items of luggage.

Movement is reduced when objects are placed on the straps.

The lashing eyes located at the corners of the cargo area provide you with a convenient means of attaching luggage nets\* or flexible straps for securing luggage.

Refer also to Cargo loading on page [131](#).

### The concept

The vehicle alarm system responds:

- ▷ When a door, the hood, or the liftgate is opened
- ▷ To movement in the vehicle interior: interior protection, refer to Tilt alarm sensor and interior motion sensor
- ▷ To variations in the vehicle tilt angle such as occur during attempts to steal the wheels or tow the vehicle
- ▷ To interruption of battery voltage.

The system responds to unauthorized vehicle entry and attempted theft by simultaneously activating the following:

- ▷ Sounding an acoustical alarm for 30 seconds
- ▷ The hazard warning flashers are activated for approx. five minutes
- ▷ The high beams flash on and off in the same rhythm.

### Arming and disarming alarm system


When you lock or unlock the vehicle, either with the remote control or at the door lock, the alarm system is armed or disarmed at the same time.



You can have different acknowledgment signals set to confirm arming and disarming. ◀



The liftgate can also be opened with the system armed using the button on the remote control, refer to page 31. The liftgate is locked again when closed. Pressing the button longer triggers the alarm: panic mode, refer to page 32.



### Indicator lamp displays

- ▷ The indicator lamp below the interior rearview mirror flashes continuously: the system is armed
- ▷ The indicator lamp flashes when the vehicle is locked: door(s) or liftgate are not completely closed. Even if you do not close the alerted area, the system begins to monitor the remaining areas, and the indicator lamp flashes continuously after 10 seconds. However, the interior motion sensor is not activated
- ▷ The indicator lamp goes out when the vehicle is unlocked: no manipulation or attempted intrusions have been detected in the period since the system was armed

## Alarm system

- ▷ The indicator lamp flashes for 10 seconds after the vehicle is unlocked: an attempted entry has been detected in the period since the system was armed.

Following triggering of an alarm, the indicator lamp will flash continuously.

### Tilt alarm sensor and interior motion sensor

**Tilt alarm sensor:**

The tilt of the vehicle is monitored. The alarm system reacts, for example, if someone attempts to steal the wheels or tow the vehicle.

**Interior motion sensor:**

In order for the interior motion sensor to function properly, the windows and panorama glass sunroof must be completely closed.

### Avoiding unintentional alarms

The tilt alarm sensor and interior motion sensor may be switched off at the same time. This prevents unintentional alarms, e.g. in the following situations:

- ▷ In stacking garages
- ▷ When transporting on car-carrying trains
- ▷ If animals are to remain in the vehicle.

Switching off the tilt alarm sensor and interior motion sensor:



Press the button on the remote control twice consecutively.

The indicator lamp lights up briefly and then flashes continuously. The tilt alarm sensor and the interior motion sensor are switched off up to the next unlock- and locking actions.

## Windows



### Opening and closing windows

As of ignition key position 1:

- ▷ Press the switch up to the resistance point:  
The window continues to move as long as you continue to hold the switch
  - ▷ Briefly press the switch beyond the resistance point:  
The window moves downward automatically. Briefly press the switch again to stop the opening movement.
- You can close the windows in the same manner by pulling the switch.

After the ignition has been switched off:

- ▷ You can still operate the windows as long as neither of the front doors has been opened. To open the windows, press the switch beyond the resistance point.

 When leaving the vehicle, always remove the remote control and close the doors, as otherwise children could operate the windows and injure themselves etc. ◀

For the convenience mode via the remote control or the door lock, refer to pages [31](#), [33](#).

### Anti-trapping mechanism

A contact strip is integrated into the inner side of each of the upper window frame sections. If pressure is exerted against this contact strip while a window is being raised, the system will respond by stopping the window and then retracting it a small distance.

 Despite the anti-trapping mechanism, be extremely careful that the closing path of the window is not obstructed whenever it is closed. Otherwise, an object might not touch the contact strip in some situations, with very thin objects, for instance. You can disable the anti-trapping mechanism by pulling the switch beyond the resistance point and holding it.

Because the power windows are sealed at high pressure to prevent wind noise when closed, a powerful motor is required for efficient closing. When closing the windows, always ensure that they are not obstructed in any way. Unsupervised use of these systems can result in serious personal injury. Remove the ignition key to deactivate the power windows whenever you leave the vehicle. Never leave the keys in the vehicle with unsupervised children. Never place anything that could obstruct the driver's vision on or next to the windows. ◀



### Safety switch

With the safety switch, you can prevent the rear windows from being opened or closed via the switches in the rear passenger area, by children, for example. You can also prevent adjustments of the power rear-seat backrests from the rear passenger area, refer to page [48](#).

 Always press the safety switch when children ride in the rear, as otherwise unchecked closing of the windows could lead to injuries. ◀


## Panorama glass sunroof\*



When leaving the vehicle, always remove the remote control and close the doors, as otherwise children could operate the roof and injure themselves etc. ◀

The panorama glass sunroof is operational from ignition key position 1.

After the ignition has been switched off: You can operate the panorama glass sunroof for up to 1 minute as long as neither of the doors has been opened.



### Raising, opening, closing

Press the switch or slide it in the desired direction up to the resistance point. Release the switch to stop the motion.

The sliding visor is opened slightly when the panorama glass sunroof is raised.

The panorama glass sunroof can be opened or closed independently with the sliding visor open.

### Ventilation setting:

The panorama glass sunroof is raised and the sliding visor is opened slightly: Briefly press the switch twice consecutively.

### Automatic opening and closing

Briefly press the switch beyond the resistance point and then release it. Briefly pressing the switch again stops the motion.

Opening and closing panorama glass sunroof and sliding visor together: Briefly press the switch beyond the resistance point twice consecutively. Briefly pressing the switch again stops the motion.

### Comfort position

Each time the panorama glass sunroof is completely opened or closed, it stops in the comfort position. If desired, continue the motion following this with the switch.

In the comfort position the wind noises in the interior are reduced.

### Anti-trapping mechanism


If the panorama glass sunroof or sliding visor encounter resistance when closing from roughly one third of the roof opening or when closing from the raised position, the closing action is interrupted and the panorama glass sunroof and sliding visor reopen a little.



Despite the anti-trapping mechanism inspect the roof's travel path prior to closing it, as the safety system might fail to detect certain kinds of obstructions, such as very thin objects, and the roof would continue closing. The anti-trapping mechanism for closing the panorama glass sunroof is deactivated if the switch is pressed beyond the resistance point and held there. The closing action is interrupted when you release the switch. ◀

### Following a power failure

Following interruptions in electrical power, for instance, when the battery is disconnected, it is possible that the panorama glass sunroof will extend to its tilt-up position, but fail to respond to other commands. The system must be initialized. BMW recommends having this work carried out by your BMW Sports Activity Vehicle center.



### Manual operation

In the event of an electrical malfunction, you can operate the panorama glass sunroof manually.

1. Take Allen wrench and screwdriver from onboard tool kit, refer to page 158
2. Remove cover panel on headliner. To do so, insert the screwdriver from behind slightly off-center and carefully pry the cover out
3. Insert the Allen wrench into the opening provided and turn the panorama glass sunroof in the desired direction.

## Sitting safely

The ideal sitting position can make a vital contribution to relaxed driving that is as fatigue-free as possible. In conjunction with the safety belts, the head restraints and the airbags, the seat position also plays an important role for the passive safety of the occupants in an accident. To ensure that the safety systems operate with optimized efficiency, we strongly urge you to observe the instructions contained in the following section.

For additional information on transporting children safely, refer to page 59.

### Airbags



Always maintain an adequate distance between yourself and the airbags. Always hold the steering wheel by its rim with hands at the 9 o'clock and 3 o'clock positions to minimize the risk of injuries to your hands and arms in the event of airbag deployment. No one and nothing is to come between the airbags and the seat occupant. Do not use the cover of the front airbag on the front passenger side as a storage area. Make sure that the front passenger is correctly seated and does not rest feet or legs on the instrument panel, otherwise leg injuries can occur if the front airbag is triggered. Never let

an occupant's head rest near or on a side airbag because the inflating airbag could cause a serious injury. ◀

Even if you adhere to all the instructions injuries resulting from contact with airbags cannot be fully excluded, depending on the circumstances. The ignition and inflation noise may provoke a mild – usually temporary – hearing loss in extremely sensitive individuals.

For airbag locations and additional information on airbags, refer to page 57.

### Safety belt

For every trip, use the safety belt on all occupied seats. Airbags complement the safety belt as an additional safety device, but they do not represent a substitute.

Your vehicle has five seats that are all equipped with a safety belt.



At all times, occupants should sit upright and be properly restrained – infants and small children in appropriate child-restraint systems; larger children and adults using the safety belts. Each safety belt should always be used by only one person, babies and children may not ride on the lap of another passenger.

Pregnant women should also always wear a safety belt and take make especially sure that the belt rests low on the hips in the lap area, and does not press against the abdomen.

Do not route the belt across your neck, or run it across sharp edges. Be sure that the belt does not become caught or jammed. Wear the safety belt without twisting and tautly across the lap and shoulders as close to the body as possible. Be sure not to route it over solid or breakable objects, as otherwise the belt can slip over the hips in the lap area in a frontal impact and injure the abdomen. Avoid wearing clothing that prevents the belt from fitting properly and pull the belt in the upper body area periodically to readjust the tension, in order to avoid a reduction in the restraint of the safety belt. ◀

## 44 Sitting safely

If the middle safety belt in the rear is used, the wider seatback must be locked, refer to page 126, as otherwise the safety belt has no restraining action. Fasten safety belt, refer to page 49.

## Seats

### Note before adjusting





Never try to adjust your seat while operating the vehicle. The seat could respond with unexpected movement, and the ensuing loss of vehicle control could lead to an accident. On the front passenger side as well, do not tilt the backrest too far toward the rear while driving. Failure to observe this precaution can prevent the belt from providing effective protection against injury, as the passenger could slide under the belt in an accident. ◀

Also observe the information on the safety belts on page 49 and on the head restraints on page 47.

### Seat adjustment

- ▷ Mechanical seat adjustment, refer to following columns
- ▷ Power seat adjustment, refer to page 46
- ▷ Head restraints, refer to page 47
- ▷ Power rear-seat backrest adjustment, refer to page 48



## Seat adjustment

- 1 Backward/forward direction  
Pull the lever and slide the seat to the desired position.  
After you release the lever, move the seat forward or backward slightly so that it engages fully
- 2 Height  
Pull the lever and apply weight to or remove weight from the seat as required

- 3 Backrest  
Pull the lever and apply weight to or remove weight from the backrest as needed



Comply with the adjustment instructions on page 43. Failure to do so could result in diminished personal safety. ◀

## Sports seat\* adjustment

You can adjust the thigh support additionally:

Pull the lever and adjust the position of the thigh support for your personal comfort.

## 46 Power seat adjustment\*



### Seat adjustment

- 1 Angle
- 2 Backward/forward adjustment
- 3 Cushion height
- 4 Backrest angle

Adjust the head restraint manually, refer to page 47.



Comply with the adjustment instructions on page 43. Failure to do so could result in diminished personal safety. ◀



### Comfort seat\* adjustment

This seat allows you to make additional adjustments for

- 1 Lumbar support
- 2 Shoulder support
- 3 Head restraint height

Lumbar support:

You can also adjust the contours of the backrest to obtain additional support in the lumbar region.

The upper hips and spinal column receive supplementary support to help you maintain a relaxed, upright sitting position.

- ▷ Increase or decrease curvature: push switch forward or backward.
- ▷ Shift curvature up or down: push switch up or down.



### Shoulder support:

Move the switch in the direction of the arrow to adjust the tilt angle of the shoulder support.

You can use the adjustable upper backrest for supplementary support in the shoulder region. This provides a relaxed sitting position and helps relieve stress on the shoulder muscles.

For optimum adjustment the following is recommended:

### Driver and front passenger:

1. Adjust the upper backrest section to its extreme rear position
2. Adjust for the optimal sitting position as described on page [43](#)
3. Bring the upper backrest section further forward until your shoulders are well supported.

Front passenger's seat adjusted for relaxed traveling:


1. Adjust the upper backrest section to its extreme rear position
2. Tilt the backrest down to a slightly more horizontal angle
3. Bring the upper backrest section forward until your shoulders are well supported.



Make corrections in the forward/backward adjustment of the seat to ensure that the safety belt still fits firmly against your body. If you do not do this, the protection provided by the safety belt may be reduced. ◀

### Head restraint height:

Move the switch in the desired direction.



### Adjustments


To adjust the angle of the front head restraints, tilt the head restraint to the desired angle.

To adjust the height of the front or rear head restraints, pull the head restraint up or push it down.

Power height adjustment, refer to page [46](#).



Head restraints reduce the risk of spinal injury in the event of an accident. Adjust the head restraints so that their center is approx. at ear level. ◀

**Removal – front**

1. Pull the head restraint upward to the stop
2. Press the button, refer to arrow, and remove the head restraint.

**Installation – front**

1. Press the button, refer to arrow, and insert the head restraint into the guides
2. Adjust the head restraint for your personal comfort.

**Removal and installation – rear**

To remove the head restraint, pull it outward with a firm movement.

To install it, press it down firmly.

**Power rear-seat backrest adjustment\***

You can make separate adjustments of the backrest tilt angle on the right and left sides.

You can select a comfortable sitting position and also increase the capacity of the cargo area by moving the backrests into their most upright position.

From the rear seats: press the corresponding switch.



You can prevent adjustments of the power rear-seat backrest from the rear passenger area with the safety switch for the power windows, refer to page 40. ◀



From the cargo area: the switches are located on both sides of the cargo area.

# Safety belts



 Comply with the instructions on page 43. Failure to do so could result in diminished personal safety. ◀

For every trip, use the safety belts on all occupied seats. Airbags complement the safety belt as an additional safety device, but they do not represent a substitute.

## Closing

Make sure you hear the latch plate engage in the belt buckle.

## Unlocking

1. Press the red button in the belt buckle
2. Hold the belt firmly
3. Guide the belt back into its reel.

 In the back, the middle safety belt buckle is provided for use exclusively by the middle passenger. If it is not possible to extract the center belt, this indicates that the larger backrest is not securely locked, refer to page 126. ◀

## Safety belt memory for front seat

 Indicator lamp flashes or lights up. In addition, a signal sounds and, depending on the equipment, a message\* appears in the Check Control. Please check safety belts for correct placement.

The belt memory is activated when the safety belt on the driver's side has not yet been fastened.

The belt memory is also active from a speed of approx. 5 mph/8 km/h when the passenger belt has not yet been fastened, heavy objects are placed on the front passenger seat or passengers sitting in the front remove their safety belts.



## Safety belt height adjustment

You can adjust the safety belts to fit your own physical dimensions by using the safety belt height adjustment:

Slide the button up or down as required.

Also observe the instructions on adjusting the seats on page 43.

**Damage to safety belts**

If the safety belts are damaged or stretched in an accident: have the entire belt system, including the tensioning mechanisms, replaced at your BMW Sports Activity Vehicle center or at a workshop that works according to BMW repair procedures with corresponding trained personnel. Have the belt anchorage points inspected for damage at the same time. Failure to observe this precaution may prevent the safety belts from effectively providing optimal protection when needed. If a child-restraint system was in the vehicle during an accident, consult the manufacturer's instructions regarding replacement. ◀

**Seat, mirror and steering wheel memory\***

You can store and call up three different seat, exterior mirror and steering wheel positions. The illustration shows the buttons on the seat for making these position adjustments.



The adjustment of the lumbar support is not stored in the memory. ◀

**Storing**

1. Turn the ignition key to position 1 or 2
2. Adjust the desired positions for the seat, exterior mirror and steering wheel
3. Press the **MEMORY** button: the indicator lamp in the button comes on
4. Press memory button 1, 2 or 3, as desired: the indicator lamp goes out.

## Calling up a stored setting

 Do not call up a position from the memory while the vehicle is moving. There is a risk of accident from unexpected movement of the seat or steering wheel. ◀

Convenience function:

1. Open the driver's door after unlocking the vehicle or place the ignition key in position 1
2. Briefly press memory button 1, 2 or 3, as desired.

Movement stops immediately when one of the seat-adjustment or memory buttons is activated during the adjustment process.

Security function:

1. With the driver's door closed and the ignition key either removed or in position 0 or 2
2. Maintain pressure on the desired memory button 1, 2 or 3 until the adjustment process is completed.

 If you press the **MEMORY** button accidentally: press the button a second time – the indicator lamp goes out. ◀



You can have your vehicle programmed to automatically dial in your own individual adjustment settings for the seat, mirrors and steering wheel whenever you use your personal remote control to unlock the vehicle. ◀



If you make use of this adjustment, be sure that the footwell behind the driver's seat is unobstructed before unlocking the vehicle. If you fail to do so, any persons or objects behind the seat could be injured or damaged by a rearward movement of the seat. ◀

CarManuals2.com



## Passenger-side exterior mirror tilt function


Automatic curb monitor

Activating:

1. Select the driver's mirror with the mirror selection switch
2. When you engage reverse gear or selector-lever position R, the exterior mirror glass on the front passenger side tilts downward slightly. This allows the driver to see the area immediately adjacent to the vehicle – such as a curb – when parking, etc.

Deactivating:

Slide the mirror selection switch to the passenger's side position.

**Front**

The seat cushion and backrest can be heated when the ignition key is in position 2.

You can call up different heating modes by repeatedly pressing the button.

You can also switch the higher heating modes off directly:

Press the button and hold it slightly longer.

**Rear**

The operating concept is the same as for the front heated seats. You can select between two heating modes.

[CarManuals2.com](http://CarManuals2.com)

**Steering wheel****Adjustments**

The steering wheel can be moved in any of four directions. Adjust the steering wheel by moving the control lever in the desired direction.



Do not adjust the steering wheel while the vehicle is moving. There is a risk of accident from unexpected movement. ◀

To store the steering wheel setting, refer to Seat, mirror and steering wheel memory on page 50.

## Steering wheel

### Automatic steering wheel adjustment

only in conjunction with seat, mirror and steering wheel memory

In order to make it easier to get into and out of the vehicle, the steering wheel automatically moves into the top position and returns to the driving or memory position.

This automatic feature is controlled by the position of the ignition key and by the driver's door.

## Steering wheel heater\*



Steering wheel heater functions in ignition key position 2.


Press the button to activate or deactivate this system.

The indicator lamp within the button lights up when the steering wheel heater is in operation.

If your vehicle is not equipped with steering wheel heater, the button for the recirculated-air mode is located here, refer to page [23](#).

**Exterior mirrors**

 The mirror on the passenger's side is more curved than the driver's mirror. Objects reflected in the mirror are closer than they appear. This means that estimations of the distance to following traffic should not be regarded as precise. The same is true for the outer part of both mirrors. ◀



- 1 Adjustments
- 2 Switching to the other mirror or to the automatic parking function\*
- 3 Folding mirrors in and out\*

To store the mirror settings, refer to Seat, mirror and steering wheel memory on page 50.

**Adjusting manually**

The mirrors can also be adjusted manually if need be: press at the outer edges of the mirror glass.

**Folding mirrors in and out**

Pressing button 3 allows you to fold mirrors in and out up to a speed of 6 mph/10 km/h. This is advantageous, for example, in narrow streets or for bringing mirrors that have been manually folded-in back into the correct position.

 Before going through a car wash, manually, or with button 3 fold the exterior mirrors inward, otherwise they could be damaged, depending on the width of the car wash system. ◀

**Automatic heating**

Below a certain outdoor temperature, both exterior mirrors are automatically heated when the motor is running or the ignition is switched on.



## Interior rearview mirror

To reduce glare from vehicles behind you when you are driving at night, tilt the mirror by turning the button.



## Compass interior rearview mirror\* with automatic dimming action

- 1 Adjustment button
- 2 Display


The display shows you the direction you are currently driving.


The compass zone must be set according to where you and your vehicle are located. To do so, press the adjustment button on the bottom edge of the interior rearview mirror for approximately 3 – 4 seconds. The display indicates the number of the current compass zone.

In order to change the zone setting, keep pressing the adjustment button until the display indicates the number of the compass zone that corresponds to your location, refer to the world map below, with compass zones.

The compass will be operational again after approximately 10 seconds.

For automatic dimming action, refer to Interior and exterior mirrors, automatic dimming.





- 1 Front airbags for driver and front passenger
- 2 Side Impact Head Protection System for front and rear
- 3 Side airbags for front and rear\*

## Protective action

 Comply with the instructions on page 43. Failure to do so could result in diminished personal safety.◀

The front airbags supplement the safety belts by helping to provide additional protection for the front-seat occupants in the event of a severe frontal impact in which the protection afforded by the safety belts alone may no longer be sufficient. The head airbag and side airbag help provide protection in the event of

a side impact. The side airbag is designed to help support the body at the side of the chest region. The Side Impact Head Protection System protects the head.

The airbags are intentionally not triggered in every impact situation, e.g. in minor accidents, certain rollover situations or rear-end collisions.

For information on the correct sitting position, refer to page 43.

 Do not apply adhesive materials to the cover panels of the airbags, cover them or modify them in any other way.

Do not attempt to remove the airbag restraint system from the vehicle. Do not modify or tamper with either the wiring or the individual components in the airbag system. These include the padded steering wheel hub, the instrument panel, the side trim panels, the doors and the roof pillars or the sides of the headliner. Do not remove or dismantle the steering wheel yourself. Do not touch the individual components directly after the system has been triggered, as otherwise there is a danger of burns. In case of faults, decommissioning or after triggering of the airbag restraint system, only commission a

BMW Sports Activity Vehicle center or a workshop that works according to BMW repair procedures with correspondingly trained personnel and is equipped with the required explosives permits for testing, repair, dismantling or scrapping of the airbag generators. Unprofessional attempts to service the system could lead to failure in an emergency or undesired airbag activation, either of which could result in personal injury.◀

 At all times, occupants should sit upright and be properly restrained – infants and small children in appropriate child-restraint systems; larger children and adults using the safety belts. Never let an occupant's head rest near or on a side airbag because the inflating airbag could cause a serious injury. Please note that the word Airbag imprinted on the door trim panel indicates the airbag's location. Accident research shows that the safest place for children in an automobile is in the rear seat.

If your vehicle is equipped with rear side airbags, do not allow children to lean towards the door trim, as serious injuries could occur if the side airbags were deployed and children are too close to the airbags.

## 58 Airbags

Labels in the rear door opening should indicate the status of your rear seat side airbags. If you are uncertain of their status, or wish to have the airbags activated or deactivated, please contact your BMW Sports Activity Vehicle center. ◀

Airbag warning information is also provided on both sun visors.



This is the right way a child should sit in a child-restraint device when rear side airbags, refer to arrow, are provided.

[CarManuals2.com](http://CarManuals2.com)



This is the right way a larger child should sit wearing the safety belt when rear side airbags, refer to arrow, are provided.

## Airbags

### Operational readiness of airbag system



As of ignition key position 1, the warning lamp in the instrument cluster lights up for a short time, thus indicating the operational readiness of the entire airbag system and the safety belt tensioners.

### Airbag system malfunction



A fault has occurred in the airbag system:

- ▷ Warning lamp does not light up as of ignition key position 1
- ▷ Warning lamp lights up permanently.



Have the airbag system checked immediately if a malfunction occurs, as otherwise there is a danger of the system failing to respond in the expected manner to an impact occurring within its normal response range. ◀

## Transporting children safely

### The right place for children

Children always in the rear:

Accident research shows that the safest place for children in a vehicle is in the rear seat.

Older children should be tightly secured with a safety belt, after they have outgrown a booster seat that is appropriate for their age, height and weight.



If your vehicle is equipped with rear side airbags, do not allow children to lean towards the door trim, as serious injuries could occur if the side airbags were deployed and children are too close to the airbags. ◀

Deactivate rear side airbags:

Labels in the rear door opening should indicate the status of your rear seat side airbags. If you are uncertain of their status, or wish to have the airbags activated or deactivated, please contact your BMW Sports Activity Vehicle center.

### Child-restraint systems in the rear



Children under 13 years of age and children less than 5 ft/150 cm tall should always ride in the rear and the restraint systems should be properly restraint. ◀

Younger children should be secured in an appropriate child-restraint system that has been first properly secured to the vehicle.

All rear sitting positions in your vehicle meet the recommendations of SAE J1819, an industry-recommended practice for securing child-restraint systems in motor vehicles.

### Exception for front passenger seat



Should it become necessary to use a child-restraint system on the front passenger seat, the front passenger airbags must be deactivated. Your BMW Sports Activity Vehicle center will be happy to advise you on this subject. ◀

 Never install a rearward-facing child-restraint system in the front passenger seat of this vehicle if the passenger airbag is not deactivated. If you do so, the child could be severely injured or killed when the airbag is triggered. Your vehicle is equipped with an airbag supplemental restraint system for the front passenger. Because the backrest on any rearward-facing child-restraint system – of the kind designed for infants under 1 year and 20 lbs./9 kg – would be within the airbag's deployment range, you should never mount such a system in the front passenger seat, since the impact of the airbag against the child restraint's backrest could lead to serious injuries. ◀

### **Installing child-restraint systems**

Before installing any child-restraint system or child seat, read the following:

 Observe the child-restraint system manufacturer's instructions when selecting, installing and using the child-restraint systems. Otherwise the degree of protection can be reduced. After an accident, have all parts of the child-restraint system and of the relevant vehicle safety belt system checked by a BMW Sports Activity Vehicle center and replaced if necessary. ◀

Commercially-available child-restraint systems are designed to be secured with a lap belt or with the lap belt portion of a combination lap/shoulder belt. Improperly or inadequately installed restraint systems can increase the risk of injury to children. Always read and follow the instructions that come with the system.



### **Child-restraint system security**

All of the rear belt retractors and the front passenger's safety belt can be locked for mounting and securing child-restraint systems.


Information regarding this is located near the buckle latch of each safety belt.

### **Locking safety belt**

Pull the entire length of the belt from the belt retractor. Allow the reel to retract the belt somewhat and engage the buckle, then tighten the belt against the child-restraint system. The retraction mechanism is now locked.


## Unlocking safety belt

Unlock the safety belt, remove the child-restraint device and allow the belt retractor to reel the belt completely in.




## Child-restraint system with tether strap

If you use a child-restraint system with a tether strap, three additional tether anchorage points have been provided, refer to the arrows in the illustration. Depending on the location selected for seating in the rear passenger area, attach the tether strap to the corresponding anchorage point to secure the child-restraint system, as shown in the illustration below.



Each sitting position is fitted with a head restraint.

The figure shows the fastening of the tether strap in the outer seating positions.



The figure shows the fastening of the tether strap in the center seating position.


**Routing of the tether strap:**

Route the tether strap through the center between the head restraint and the rear backrest.

When using the cargo area roll-up cover, also route the tether strap between the rear backrest and the casing of the roll-up cover.



Adjust the tether strap according to the child-restraint manufacturer's instructions. ◀



### LATCH child-restraint fixing system

LATCH: Lower Anchor and Tethers for Children.


The rear outer seating positions are provided with anchors for a LATCH child-restraint fixing system.

The figure shows the left rear seat as an example. The mounts for attachment of the LATCH child-restraint fixing system are located behind the cover panels: Remove cover panels by pulling them toward the front.

To remount, simply slide into place.



Follow the manufacturer's operating and safety instructions for attachment of the LATCH child-restraint fixing system. ◀



### Child-safety locks of rear doors

Slide the safety lever on the rear doors downward:

The door can now be opened from the outside only.

### Safety switch for power windows

Press the safety switch for the power windows, refer to page 40, when children ride on the back seat

# Vehicle Memory, Key Memory

## How the system functions

You have probably frequently wished that you could configure individual functions of your vehicle to reflect your own personal requirements. In engineering your vehicle, BMW has included several user-defined functions in the vehicle's design. Your BMW Sports Activity Vehicle center can make these settings for you.

There are vehicle and person-related adjustments: Vehicle Memory and Key Memory. You can have up to four different basic positions configured for four different persons. The only requirement is that each person uses his or her own remote control key.

When your vehicle is unlocked with the remote control, the vehicle recognizes the individual user by means of a data exchange with the key, and makes adjustments accordingly.

In order for you to distinguish between the master keys with remote control, color-coded decals are supplied together with the keys.

## What the system can do

Your BMW Sports Activity Vehicle center can provide you with details on the capabilities of the Vehicle Memory and Key Memory systems.



You will see this symbol throughout the Owner's Manual. It is to remind you at appropriate places of the settings that are available to you. ◀




Following configuration of the memory functions, vehicle operation may differ from the description in the Owner's Manual. Should you want to sell your BMW some day, please remember to have the memory functions reset to the default state. ◀

### Examples for Vehicle Memory:

- ▷ Various signals that can serve as acknowledgment for locking and unlocking the vehicle, refer to pages [31](#), [33](#)
- ▷ Deactivating/activating the Pathway lighting function, refer to page [103](#).

### Examples for Key Memory:

- ▷ Automatic adjustment of the driver's seat, exterior mirror and steering wheel with settings stored in the memory for the individual driver when the vehicle is unlocked, refer to page [51](#)
- ▷ Calling up customized settings for the automatic climate control when unlocking the vehicle, refer to page [112](#).



### Ignition key positions

- 0 Steering lock engaged
- 1 Steering lock disengaged
- 2 Ignition on
- 3 Starting engine

### Steering lock engaged

The key can only be inserted or removed in this position.

After removing the key, turn the steering wheel slightly to the left or right until you hear the lock engage.

If the key is not removed, an acoustic signal sounds after the driver's door is opened.



Vehicles with automatic transmission:

Only move the selector lever from position P with the engine running. To turn the key back to position 0 or to remove it, first place the selector lever in position P: interlock. ◀

### Steering lock disengaged

Slightly moving the steering often makes it easier to turn the key from 0 to 1.

Individual current consumers are ready for operation.

### Starting engine



Vehicles with manual transmission:

Depress the clutch pedal when starting the engine. If you do not, a lock prevents the engine from starting. ◀

## Starting engine

### Before starting

- ▷ Engage the handbrake
- ▷ Be sure that the gearshift lever is in Neutral or the selector lever in Park if the vehicle is equipped with an automatic transmission
- ▷ Press the clutch pedal.  
If the clutch pedal is not depressed, the engine cannot be started
- ▷ In vehicles with automatic transmissions, depress the footbrake.



Do not run the engine in closed rooms, as otherwise the inhaling of toxic exhaust gases can cause unconsciousness and death. The exhaust gases contain carbon monoxide, an odorless and colorless, but highly toxic gas.

Never leave an unattended vehicle with the engine running, as such a vehicle represents a potential safety hazard. To prevent the vehicle from rolling, always select neutral or the position P and engage the handbrake before leaving the vehicle with the engine running. ◀

When starting the engine, do not press the accelerator pedal.

## Starting engine

Do not allow the engine to warm up by leaving it running while the vehicle remains stationary. Instead, begin to drive immediately at a moderate engine speed.

X5 3.0i:

Do not end the starting procedure too soon, however at the latest after approx. 20 seconds. Release the ignition key immediately as soon as the engine starts.

X5 4.4i, 4.8is:

Your BMW is equipped with the convenience starting feature. Here, it is sufficient to turn the ignition key only briefly to position 3 'Start engine' and to let go of it right away. The starter actuation continues to operate automatically for a certain period of time and is stopped automatically as soon as the engine has started.

The automatic starting mode will not operate or will be canceled if the battery voltage is insufficient. The engine can be jump started, refer to page 171.

Should the engine fail to start on the first attempt, if it is very hot or cold, for instance:

- ▷ Press the accelerator pedal halfway down while engaging the starter.

Cold starts at altitudes above 3,300 ft/ 1,000 meters and at very low temperatures, from approx. +5 °F / -15 °C:

- ▷ For the initial starting attempt, allow the starter to remain engaged somewhat longer, approx. 10 seconds.

Engine idle speed is controlled by the engine computer system. Increased speeds at startup are normal and should decrease as the engine warms up. If engine speed does not decrease, service is required.

To prevent the battery from discharging, always switch off electrical devices that are not in use. Switch the ignition off when the vehicle is not being driven.



Extended starting attempts, characterized by excessively frequent or long periods with the starter engaged, can lead to damage of the catalytic converter. ◀

## Switching off engine

Manual transmission:

1. Turn the ignition key to position 1 or 0.
2. Shift into first gear or reverse.

Automatic transmission:

1. Shift into selector lever position P.
2. Turn the ignition key to position 1 or 0.



Do not remove the ignition key when the vehicle is moving, as otherwise the steering could lock. When leaving the vehicle, always remove the ignition key and lock the steering.


Vehicles with manual transmission:

Always engage the handbrake when parking on slopes and inclined surfaces. Even placing the gearshift lever in 1st gear or reverse may not provide adequate resistance to rolling.

Vehicles with automatic transmission: Place the selector lever in Park. ◀

Vehicles with automatic transmission:

The vehicle must be stationary and the selector lever in Park before you can remove the ignition key.



The handbrake is primarily intended to prevent the vehicle from rolling while parked; it brakes the rear wheels.

### Engaging

The lever engages automatically when you pull it up and the indicator lamp comes on in the instrument cluster in ignition key position 2, refer to pages 19, 21.

### Releasing

Pull up slightly on the lever, press the button and lower the lever.

**!** If exceptional circumstances should make it necessary to engage the handbrake while the vehicle is in motion, do not pull it too strongly. In doing so, continuously press the button of the handbrake lever. Excessive pressure can lead to over-braking and loss of traction – fishtailing – at the rear axle.

The brake lamps do not light up when the handbrake is applied.

Vehicles with manual transmission:

Always engage the handbrake when parking on slopes and inclined surfaces. Even placing the gearshift lever in 1st gear or reverse may not provide adequate resistance to rolling.

Vehicles with automatic transmission: Place the selector lever in Park. ◀

To avoid corrosion, apply the handbrake lightly from time to time when coasting to a standstill at a traffic signal, for instance, provided that it is safe to do so.

## Manual transmission



Press the clutch pedal all the way down each time you shift, pressing the gearshift lever into its proper end position.

Depress the clutch when starting the vehicle, too, otherwise, the interlock will prevent the engine from starting if the clutch is not depressed.

**!** While shifting in the 5th/6th gear lane, press the selector lever toward the right, as otherwise accidental shifting into the 3rd or 4th gear could result in engine damage. ◀

### Reverse

Select only when the vehicle is stationary. Press the gearshift lever to the left to overcome the resistance.

As you do this, the backup lamps will turn on automatically when the ignition key is in position 2.



In addition to fully automatic operation, you can also manually shift with the Steptronic, refer to page 69.

Under normal operating conditions, fuel consumption is lowest when driving in position D.



### Selector lever positions

P R N D M/S

The transmission range display varies according to the equipment of your vehicle.

### Starting engine

The engine can only be started in the selector lever position Park or Neutral.

### **Range selection**

- ▷ The selector lever can be removed from the P position with the ignition switched on or the engine running: interlock
- ▷ With the vehicle stationary, press the footbrake before shifting out of P or N, as otherwise the selector lever is blocked: shiftlock. Hold the footbrake down until starting off. The vehicle will otherwise creep when a drive position is engaged.



An interlock prevents inadvertent gear-shifts into selector-lever positions R and P. To cancel the interlock, press the button on the front of the selector lever knob, refer to arrow.

### **P Park**

Select only when the vehicle is stationary. The transmission locks to prevent the rear wheels from turning.

### **R Reverse**

Select only when the vehicle is stationary.

### **N Neutral, idle**

For example, engage in automatic car washes. The vehicle can roll.

### **D Drive, automatic driving position**

This position is designed for driving under all normal operating conditions. All forward gears are available.

### **Kick-down**

The kick-down mode provides maximum acceleration.

Depress the accelerator pedal past the increased resistance point at the full-throttle position.



## M/S manual operation and Sport Program

Shift selector lever from position D toward the left into the shifting slot M/S: the Sport Program is activated and DS appears in the instrument cluster. This position is recommended for a performance-oriented driving style.

When you briefly press the selector lever in the + or – direction, manual operation is activated and Steptronic changes the gear. The following appears in the instrument cluster depending on the model

- ▷ 1 to 5 or 1 to 6
- ▷ M1 to M5 or M1 to M6.

Upshifts and downshifts are executed only when they will result in a plausible combination of engine and vehicle speed; thus, for example, a downshift that would cause the engine to overrev will not be executed by the system. The gear selected will appear briefly in the instrument cluster followed by the current gear.

In order to go back to using automatic, move the selector lever toward the right into position D.

## Malfunction



The warning lamp lights up or the message TRANS.FAILSAFE PROG appears in the Check

Control. A malfunction has occurred in the transmission system. Avoid heavy loads.


Bring the vehicle to a stop. Move the transmission selector lever to P. Set the handbrake and switch the engine off, ignition key to position 0.

Wait a few seconds, then start the engine.

If the indicator lamp goes out after a few seconds, normal transmission performance has been restored. You may continue to drive as usual. If the indicator lamp does not go out, you can place the selector lever in all positions. However, the vehicle will now only drive forward with limited gear selection. Have the system checked as soon as possible.

Information on jump starting, tow-starting and towing begins on page 171.

## 70 Turn signals/headlamp flasher



- 1 High beams
- 2 Headlamp flasher
- 3 Turn signals

[CarManuals2.com](http://CarManuals2.com)

### Signaling briefly

Press lever to resistance point and hold for as long as you wish to signal.



Atypically rapid flashing of the turn signal indicator light indicates the failure of a turn signal lamp and when towing a trailer, indicates the failure of one of the trailer's turn signal lamps. After switching off the ignition, make sure the roadside parking lamps have not been left on. ◀



- 0 Wipers retracted
- 1 Intermittent mode or rain sensor
- 2 Normal wipe
- 3 Fast wipe
- 4 Brief wipe
- 5 Windshield washing
- 6 Special wash program\*
- 7 Serrated dial for control of the wipe interval or the sensitivity of the rain sensor

## Fold-out position

The left wiper is partially concealed by the hood. In order to bring the wipers to roughly a vertical position, this is important for changing the wiper blades or to fold the wipers out during frosty weather, for example:

- ▷ With the lever in position 1, switch off the ignition as soon as the wipers come to a stop.

If equipped with a rain sensor:

1. Switch on the wipers with the lever in position 1, 2 or 4
2. When the wipers are approx. vertical, switch the ignition off.

For changing the wiper blades, refer to page 158.



Fold the wipers back down onto the windshield before you turn the ignition key to position 1 or 2 again. If you do not, they could be damaged. ◀

## Intermittent mode

Not on vehicles with rain sensor.

You can set the wipe interval to four stages with serrated dial 7. In addition, the wipe interval is varied automatically depending on road speed.

## Rain sensor

The rain sensor automatically controls the wiper operation as a function of the rain intensity. It is positioned on the windshield, directly in front of the interior rearview mirror.

To activate the rain sensor:

Move the lever to position 1 as of ignition key position 1. The wipers travel once across the windshield, regardless of the weather conditions.

You can leave the lever permanently in position 1. It is then only necessary to activate the rain sensor as of ignition key position 1.

To do this, turn serrated dial 7 briefly.

To adjust the sensitivity of the rain sensor:

Turn serrated dial 7.

Deactivating the rain sensor:

Move lever to position 0.



Deactivate the rain sensor when passing through an automatic car wash. Failure to do so could result in damage caused by undesired wiper activation. ◀

### **Normal wipe**

The system switches automatically to intermittent mode when the vehicle is stationary, not on vehicles with rain sensor.

### **Fast wipe**

The wipers operate at normal speed when the vehicle is not moving, not on vehicles with rain sensor.

### **Windshield washing**

The system sprays washer fluid against the windshield and activates the wipers for a brief period.

### **Special wash program\***

As with 5; several additional wash cycles are carried out and the headlamps are cleaned\*.

This program is recommended after you have driven on extremely dirty roads.

### **Headlamp washing\***

- ▷ With the special wash program 6
- ▷ With every actuation of clean the windshield 5 when the vehicle's lighting is switched on, the headlamps will be cleaned at appropriate intervals.



Do not use the washers if there is any danger that the fluid will freeze on the windshield. If you do so, your vision could be obscured. Therefore use antifreeze, refer to page 150. Do not actuate washer systems when the fluid reservoir is empty, as otherwise the washer pump will be damaged. ◀

### **Windshield washer nozzles**

The windshield washer jets are warmed automatically when the ignition key is in position 2.

## Washer/wiper system/rain sensor\*



Programming is deleted:

- ▷ approximately 10 seconds after the lever is placed in position 0 or
- ▷ after the engine is switched off.

For changing the wiper blade, refer to page [158](#).

### Rear window wiper

- 0 Retracted position of the rear window wiper
- 1 Rear window wiper in intermittent mode. When reverse gear is engaged, continuous operation is switched on automatically
- 2 Cleaning rear window

You can also program the interval:

- ▷ Switch briefly from position 0 to position 1
- ▷ The time until reactivation, from position 0 to 1, is the programmed interval; max. 30 seconds.

You can automatically maintain and store any desired vehicle speed above approx. 20 mph/30 km/h.

You can use cruise control whenever the system is active while the engine is running.

On the sports steering wheel\*, there are +/- buttons on the right side of the steering wheel for the cruise control.



Do not use the cruise control when unfavorable conditions do not permit driving at constant speed. Otherwise you could lose control of the vehicle and cause an accident. These unfavorable conditions include winding roads, heavy traffic or poor road conditions, e.g. snow, rain, ice or a loose road surface. ◀

### Activating system

I/O

As of ignition key position 2: Press button; the indicator lamp in the instrument cluster comes on, refer to page 22. You are able to use the cruise control.

### Deactivating system

I/O

Press the button repeatedly until the indicator lamp in the instrument cluster goes out.

The cruise control is also deactivated when the ignition key is turned into position 0.

The speed stored in the memory is deleted.

### Maintaining and storing speed or accelerating



Briefly press button +:

The system maintains and stores the current vehicle speed. Every time you briefly press the button, the speed increases by approx. 0.6 mph/1 km/h.

Press and hold button +:

The vehicle accelerates without pressure on the accelerator pedal. When you release the button, the system maintains and stores the current speed.

If, on a downhill grade, the engine's braking effect is not sufficient, the controlled speed can be exceeded. Speed can drop on uphill grades if the engine output is insufficient.

# Cruise control\*

## Deceleration



Briefly press button **-**:

When cruise control is active, every brief touch of the button reduces the speed by approx. 0.6 mph/1 km/h.

Press and hold button **-**:

With the cruise control active, the system automatically reduces the throttle opening to slow the vehicle. When you release the button, the system maintains and stores the current speed.

## Interrupting cruise control



When the system is activated, press button 1. The indicator lamp stays on. You can use the cruise control again whenever required by calling up the speed that was stored last.

In addition, cruise control is interrupted automatically:


- ▷ When you apply pressure to the brake pedal
- ▷ When you apply pressure to the clutch pedal or when you move the automatic transmission selector lever from Drive to Neutral
- ▷ If you exceed or fall below the controlled speed for an extended period, by depressing the accelerator, for example
- ▷ When DSC Dynamic Stability Control is set.

## Recalling stored setting



Press button:

The vehicle accelerates to and maintains the last speed stored.



- 1 Odometer
- 2 Trip odometer
- 3 Outside temperature display

### Odometer

You can activate the displays shown in the illustration with the ignition key in position 0 by pressing the button in the instrument cluster, refer to arrow.

The range of available displays varies according to your individual vehicle's equipment.

### Trip odometer

To reset the trip odometer to zero, press the button, refer to arrow, with the ignition key in position 1 or 2.

### Outside temperature display

The outside temperature appears in the display as of ignition key position 1.

You can change the units of measurement °F/°C by

1. pressing and holding down the button, refer to arrow, with the ignition key in position 1 and
2. then turning the ignition key to 0.

At the same time the units of measurement in the temperature display of the automatic climate control will be changed, refer to page [110](#).

Refer also to page [83](#).

### Ice warning

If the outside temperature drops to approx. +37.5 °F/+3 °C, a signal sounds as a warning and the display flashes for a brief period.

 The ice warning does not alter the fact that surface ice can form at temperatures above +37.5 °F/+3 °C, on bridges or shaded road surfaces, for instance. ◀



## X5 3.0i, 4.4i

Do not operate the engine with the needle in the red overspeed zone of the gage, refer to arrow.

In this range, the fuel supply is interrupted to protect the engine.



## X5 4.8is

The orange warning sector gradually moves upward as the engine warms to its normal operating temperature. As the engine temperature increases, an increasing number of sectors in this warning panel go out.

Avoid allowing the engine speed to rise as far as the orange warning sector whenever possible.

Do not operate the engine with the needle in the red overspeed zone of the gage, refer to arrow.

In this range, the fuel supply is interrupted to protect the engine.



## X5 3.0i, 4.4i

Shows the current fuel consumption. This allows you to see whether your current driving style is conducive to fuel economy with minimum exhaust emissions.

**X5 4.8is**

The general operating temperature lies between 176 °F/80 °C and 248 °F/120 °C. Do not exceed the maximum value of 302 °F/150 °C.



Refuel well before the tank is empty, as otherwise engine functions will not be ensured and damage can occur if you drive down to the last drop. ◀

When you switch on the ignition, the indicator lamp comes on briefly to confirm that the system is operational.

If the indicator lamp comes on and stays on, there are approx.

- ▷ 2.0 gal./8 liters, 6-cylinder engine
  - ▷ 2.5 gal./10 liters, 8-cylinder engine
- of fuel still in the tank.

Tank capacity: approx. 24.6 gal./  
approx. 93 liters.

If the tilt of the vehicle varies, when you are driving in mountainous areas, for example, the indicator may fluctuate slightly.

## Coolant temperature gage



### Between blue and red zones

Normal operating range. The dial may wander up to the red field.

### Blue

The engine is still cold. Drive at moderate engine and vehicle speeds.

### Red

When you switch on the ignition, the warning lamp\* comes on briefly to confirm that the system is operational.

If the warning lamp lights up during driving or the message COOLANT TEMPERATURE appears in the Check Control: the engine is overheated. Switch off the engine immediately and allow it to cool down.

Checking coolant level, refer to page 152.

## Service Interval Display 79



The range of available displays varies according to your individual vehicle's equipment.

### Green lamps

The number of illuminated lamps decreases as the time for your next maintenance visit approaches.

### Yellow lamp


This field appears together with OILSERVICE or INSPECTION.

Maintenance is due. Please contact your BMW Sports Activity Vehicle center for an appointment.

### Red lamp

The maintenance deadline has been passed.

## Check Control



### Graphic display\*

The following alerts or status messages are displayed with icons as of ignition key position 2 until the defects are corrected:

- 1 Check low beams
- 2 Add washer fluid, goes out after approx. 1 minute
- 3 Door open
- 4 Tailgate open
- 5 Check brake and tail lamps. A defective center brake lamp is indicated by the upper symbol.

When you open the door after stopping, a warning signal sounds without a visual indicator for:

- ▷ LIGHTS ON
- ▷ KEY IN IGNITION LOCK.



### Alphanumeric display\*

Text messages are used to alert the driver to system malfunctions as of ignition key position 2. The alert is accompanied by an acoustic signal.

- 1 Status messages symbol
- 2 Display
- 3 CHECK button

Messages concerning system faults are differentiated based on two priorities:

#### Priority 1

These defects are immediately indicated by an acoustic signal and a flashing warning symbol 1. Simultaneous defects will be displayed consecutively. These status messages remain in the display until the defects are corrected. They cannot be deleted by pressing the CHECK button 3:

- ▷ RELEASE PARKINGBRAKE
- ▷ COOLANT TEMPERATURE  
Temperature too high. Stop the vehicle immediately and switch off the engine, refer to pages [79](#) and [152](#)
- ▷ STOP! ENGINE OILPRESS  
Oil pressure too low. Stop the vehicle immediately and switch off the engine, refer to pages [19](#), [150](#)

# Check Control

## ▷ CHECK BRAKE FLUID

Level has dropped approx. to minimum. Have the brake fluid topped up as soon as possible, refer to page 153. Have the reason for the brake fluid loss eliminated by your BMW Sports Activity Vehicle center

## ▷ DSC/4x4 INACTIVE

DSC and/or four-wheel drive system xDrive has failed.

The stabilizing interventions of DSC and/or the four-wheel drive system xDrive are no longer available. Drive may then only be carried out via the rear axle.

Have the system checked at the nearest BMW Sports Activity Vehicle center.

For additional information, refer to page 97

## ▷ SELFLEVEL SUSP.INACT\*

Please consult the nearest BMW Sports Activity Vehicle center

## ▷ SELFLEVEL SUSP.INACT\*

MAX. 35 MPH/MAX. 60 KM/H\*

These messages are displayed consecutively.

Do not exceed a maximum speed of 35 mph/60 km/h.

Please consult the nearest BMW Sports Activity Vehicle center

## ▷ TRANSMISS'N OVERHEAT\*

Reduce speed immediately and stop at a suitable location so that the system can cool down again. Please contact the nearest BMW Sports Activity Vehicle center.

## ▷ LIMIT\*

Display when the programmed road-speed limit is exceeded, refer to page 88.

## Priority 2

These displays appear for 20 seconds as of ignition key position 2. The warning symbols remain after the message disappears. You can open the messages again for display by pressing the CHECK button.

## ▷ TRUNKLID OPEN

This message only appears when starting off

## ▷ DOOR OPEN

This message appears after a minimal defined road speed has been exceeded

## ▷ FASTEN SEAT BELTS\*

In addition, the indicator lamp with the belt symbol lights up and an acoustic signal sounds

## ▷ WASHER FLUID LOW

Too low, top up at the next opportunity, refer to page 150

## ▷ CHECK ENGINE OIL LEV

The oil level is at the absolute minimum point. Therefore, have the engine oil topped up as soon as possible, refer to page 150. Until then, do not drive more than approx. 30 miles/50 km.

## ▷ CHECK GAS CAP

Check to see whether the fuel filler cap has been closed properly, refer to page 25

## ▷ OUTSIDE TEMP. +23 °F /-5 °C

This display is only an example. The current temperature is displayed at outside temperatures of +37.5 °F / +3 °C and below, refer also to page 76

## ▷ CHECK BRAKE LIGHTS

A lamp has failed or the electrical circuit has a fault, refer to page 161 or consult a BMW Sports Activity Vehicle center

## ▷ CHECK LOWBEAM LIGHTS

CHECK SIDE LIGHTS

CHECK REAR LIGHTS

CHECK FRONT FOGLAMPS

CHECK LICPLATE LIGHT

CHECK HIGHBEAM LIGHT

CHECK BACK UP LIGHTS

The respective lamp may have failed or the electrical circuit may be defective, refer to page 159 or consult a BMW Sports Activity Vehicle center

- ▷ **TRANS. FAILSAFE PROG\***  
Please consult the nearest BMW Sports Activity Vehicle center, refer to page 69
- ▷ **CHECK BRAKE LININGS**  
Have the brake pads inspected by your BMW Sports Activity Vehicle center, refer to page 140
- ▷ **CHECK COOLANT LEVEL**  
Coolant too low, top off at the next opportunity, refer to page 152
- ▷ **ENGINE FAILSAFE PROG**  
Fault in the engine electronics.  
You can continue to drive with reduced engine output or engine speed.  
Please have the system inspected by your BMW Sports Activity Vehicle center.

### Displays after completion of trip

All of the malfunctions registered during the trip appear consecutively when the ignition key is turned to position 0.

The following displays will appear when appropriate:

- ▷ **LIGHTS ON**
- ▷ **KEY IN IGNITION LOCK**
- ▷ **CHECK ENGINE OIL LEV**  
Top up engine oil at the next opportunity, e.g. while refueling, refer to page 150.

This display appears when you open the driver's door after parking the vehicle. A supplementary acoustic signal is also heard.

Status messages remain available with the CHECK button 3 for a period of approx. three minutes after the display goes out and the key is removed from the ignition lock. If there were multiple messages, press the CHECK button repeatedly to view them all in sequence.

### Checking Check Control

Press the CHECK button 3 with the ignition key in position 2:  
CHECK CONTROL OK appears in the display.

No malfunctions are present in the monitored systems.


### Computer

You can find a description of the computer on pages 82 and 88 as well as in the Owner's Manual for Onboard Computer.



You can have the Check Control and computer messages displayed in a different language. ◀

## Computer



### Mode selection

As of ignition key position 1, you can call up information from the computer using the computer button in the turn signal lever.

A new function appears each time you briefly press the computer button.

The display sequence:

- ▷ Outside temperature
- ▷ Average fuel consumption
- ▷ Cruising range
- ▷ Average speed.

As of ignition key position 1, the last active setting is displayed.

The range of available displays varies according to your individual vehicle's equipment.



### Outside temperature and average fuel consumption

You can change the units of measurement °F/°C for the outside temperature display by

1. pressing and holding the trip odometer reset button with the ignition key in position 1 and
2. then turning the ignition key to 0.  
At the same time the units of measurement in the temperature display of the automatic climate control will be changed, refer to page 110.

Refer also to page 76.

The average fuel consumption is calculated for the time during which the engine is running.

### Cruising range and average speed

Displays the estimated cruising range available with the remaining fuel. The fuel level is measured and the range is calculated taking the driving style over the last 20 miles/30 km into account.

Periods with the vehicle parked and the engine off are not included in the calculations of average speed.

### Canceling display

If the button in the turn signal lever is pressed briefly while the average speed is displayed, the computer display can be masked out.

### Restarting calculations

If you continue to press the computer button in the turn signal lever, the average values which were just displayed for fuel consumption and speed will be recalculated from that point. The engine must be running for this calculation.

### Computer with alphanumeric display\*

If your vehicle has Check Control with alphanumeric display, the system's computer is described beginning on page 88 and in the Owner's Manual for Onboard Computer.

**Central display**

The MID serves as the central display and operation for the following onboard systems:

- ▷ Digital clock, e.g. time display, date
- ▷ Audio systems: radio, cassette, CD
- ▷ Computer, e.g. fuel consumption, cruising range
- ▷ Telephone, e.g. dialing.

You will find explanations and notes for operating the digital clock and the computer on the following pages. Please refer to the separate Owner's Manuals for operating the audio systems, the telephone and the onboard computer.

 Any unrealistic numerical entries will not be accepted.

All stored data will be lost if the power supply is interrupted. Time display, switch-on times for independent ventilation, distance and cruise control speed limit may have to be reset once the power supply has been reestablished. ◀



- 1 Function button for audio systems
- 2 Function button for the telephone
- 3 Indicator lamp for independent ventilation
  - ▷ remains on if switch-on time is active
  - ▷ flashes while operating
- 4 Function button for the digital clock and computer
- 5 Indicator display for the various onboard systems
- 6 Display for the entry and call-up buttons. Depending on the operating mode, the functions and alternatives that can be selected at the buttons are displayed here
- 7 Entry and call-up buttons for operating the various onboard systems

# Digital clock in MID



To avoid endangering yourself or other road users, only make entries when the vehicle is stationary.

## Calling up time or date



Press the left side of the button.

Display shows:



You can have the time displayed in 12 or 24 hours.

To change the display:



Press the left side of the button.

If the 12-hour time display is in use, AM or PM appears after the time.

## Changing time



Press the left side of the button.



Press the right side of the button:  
The dots flash in the display.

To change the setting:



Press on the left/right, or hold the button down.

To store the entry:



Press the right side of the button.

## Changing date



Press the left side of the button.



Press.



Press the right side of the button:  
The dots and the DATE display flash.

To change the setting:



Press on the left/right, or hold the button down.

To store the entry:



Press the right side of the button.

The clock takes leap years into account and therefore does not have to be reset manually.

**Reminder signal**

You can program a reminder signal – memo – to be heard every hour, so that you are sure not to miss a news broadcast.



Press the left side of the button.



Press:

MEMO OFF appears in the display for entry and call-up buttons, and the tone symbol will appear in the upper right of the display.

A signal is then heard 15 seconds before each hour.

**Stopwatch**

Press the left side of the button.



Press.

Display shows:



To start the stopwatch function:



Press the right side of the button.

To take an intermediate time reading:



Press.



Press:

The stopwatch display can be seen counting up; the stopwatch continues to run.

To halt the stopwatch:



Press the right side of the button.



The stopwatch is halted when the ignition key is turned back to 0, but starts to run again when the ignition key is turned to 1. ◀

## Digital clock in MID

### Entering switch-on times for independent ventilation

You can enter two different switch-on times.

The ventilation will switch off automatically after 30 minutes.

 Please follow the instructions for operating the independent ventilation that start on page 116. ◀



Press the left side of the button.



Press on the left/right.

Display shows:



Press the right side of the button:  
Display flashes, e.g. TIMER 1.

To enter the time:



Press on the left/right, or hold the button down.

To confirm the entry:



Press the right side of the button.

The activated time is marked with an asterisk.



The switch-on times remain stored until new entries are made.

You can change switch-on times that have already been stored by making a new time entry as described above.

When the switch-on time is active, the LED comes on in the MID. During actual operation of the ventilation, the LED flashes. The LED goes out when the system is switched off.

To activate/deactivate the time:



Press twice.

### Directly switching independent ventilation on and off

 The independent ventilation function can only be called up in ignition key position 1. ◀



Press the left side of the button.



Press.



To avoid endangering yourself or other road users, only make entries when the vehicle is stationary. ◀

Computer calculations begin at the start of the journey.

Information can also be called up in the display by the remote control, refer to page 92.

## Speed limit

Speed limit entry:

You can enter the road speed here at which you wish to hear and see a reminder signal: a signal will sound, the word LIMIT will flash, and with the Check Control with alphanumeric display\*, the speed limit warning stored in the memory will appear on the instrument cluster briefly.

The speed limit reminder is only repeated if road speed has fallen at least 3 mph/5 km/h below the preset speed limit.



Press the right side of the button.



Press.



Press the right side of the button.

Display shows:



Enter the limit by pressing the function buttons.

To correct an entry:



Press the left side of the button and repeat the entry.

To store the entry:



Press the right side of the button.

## Computer\* in MID

Adopting the current speed as the speed limit:



Press the right side of the button.



Press.



Press twice at right.

Deactivating the speed limit:



Press the right side of the button.



Press.

The LIMIT display goes out, but the stored value is not lost and can be reactivated by pressing the LIMIT button.

### Distance to destination

The remaining distance to the destination will be displayed on the screen. Enter the entire distance before starting the journey.

To enter:



Press the right side of the button.



Press the left side of the button.



Press the right side of the button.

Display shows:



You can enter the distance by pressing the function buttons.

To correct an entry:



Press the left side of the button and repeat the entry.

To store the entry:



Press the right side of the button.

Checking stored value:



Press the right side of the button.



Press the left side of the button.

**Estimated time of arrival**

When you have entered the distance to your destination, you can obtain an estimated time of arrival display which is continuously updated by the computer as your average driving period varies.



Press the right side of the button.



Press the right side of the button:  
The estimated time of arrival is displayed.

**Cruising range**

The distance which the vehicle should cover on the remaining fuel in the tank is displayed.



Press the right side of the button.



Press:  
The display shows the probable range.



Always refuel as soon as possible once your cruising range falls to below 30 miles/50 kilometers. Otherwise engine functions are not ensured and damage can occur. ◀

The computer will only register fuel amounts over 1.8 gal/6 liters.

**Fuel consumption**

You can have the average fuel consumption displayed for two different distances, for example a complete journey and part of the journey.

To start the calculation, select the function with the engine running:



Press the right side of the button.



Press the left or right side of the button:  
The display will show the average fuel consumption.

To restart the fuel consumption calculation:



Press the left or right side of the button.



Press the right side of the button.

## Speed

You can open a display of the vehicle's average speed.

To start the calculation, select the function with the engine running:



Press the right side of the button.



Press:

The display shows the average speed.

To recalculate the speed:



Press the right side of the button.

## Extended immobilizer function

You can establish a code that will prevent the engine from being started unless the code is entered.

If you do not have access to the code, the emergency deactivation procedure will have to be carried out, refer to next page.

To establish and activate the code:



Press the right side of the button.



Press the left side of the button.

Display shows:



Enter the code with the function buttons.

To correct an entry:



Press the left side of the button and repeat the entry.

To store the entry:



Press the right side of the button.

Turn the ignition key to position 0.

Deactivating the code:

When you are asked to enter the code with the ignition key in position 1 or 2:

▷ Enter the code at the function buttons.



Press the right side of the button.

After the code has been entered correctly and confirmed with the SET button, the time display appears.


After three incorrect code entries, or three attempts to start the engine without a code entry, the alarm will sound for 30 seconds on vehicles fitted with an alarm system.

Deactivating the alarm in an emergency:

If you have forgotten the code, proceed as follows:

1. Disconnect the battery, wait approx. 2 minutes, then reconnect it. Note that on vehicles with an alarm system, the alarm will sound
2. Set the ignition key to position 1: the time display will count down for the next ten minutes
3. After ten minutes, start the engine.

 If the code becomes available again in the meantime, it can be entered during the waiting period after pressing the CODE button. ◀



### Remote control

The computer button on the turn signal lever can be used to select the items of computer information which are to be displayed.

To do this, press:

- ▷ the button on the lever until PROG shows on the display
- ▷ the MID buttons in the order in which you wish the information to be displayed.

Each time an entry is stored, the program number appears on the display.

To terminate the selection procedure:



Press the right side of the button.

To have all the available information displayed, press

- ▷ the button on the lever until PROG shows on the display
- ▷ the SET button.

To obtain individual items of information, briefly press the button as often as necessary.

## The concept

PDC provides extra safety and convenience during parking maneuvers. Signal tones indicate the current distance to an object behind or in front of your vehicle. To do this, four ultrasonic sensors in the front and rear bumpers each measure the distance to the nearest object. The detection range of the front sensors and the two sensors located at the ends of the rear bumper is approx. 2 ft/60 cm, while the rear center sensors can detect objects to a distance of approx. 5 ft/1.50 m.



PDC is a parking aid that can indicate objects when they are approached slowly, as is usually the case when parking. Avoid approaching objects too fast, otherwise the system may give warning of physical obstacles too late. ◀

## Automatic operation

The system starts to operate automatically approx. one second after you select reverse or move the selector lever into the R position with the ignition key in position 2. Wait this short period before backing up. The system switches off when you shift back out of reverse.



## Manual activation

Press the button, the indicator lamp lights up.

## Manual deactivation

Press the button again; the indicator lamp goes out.

## Automatic deactivation

After driving a distance of more than approx. 160 ft/50 m or exceeding a speed of approx. 20 mph/30 km/h, the system switches off and the indicator lamp goes out. You may switch the system on again manually as needed.

**Signal tones**

The distance from an object is indicated in front with a higher intermittent tone, and at the rear with a lower intermittent tone. As the distance between vehicle and object decreases, the intervals between the tones become shorter. The signal tone becomes continuous once the distance to the nearest object falls to below roughly 1 ft/30 cm.

The warning signal is canceled after approx. 3 seconds if you are moving parallel to a wall.

**Malfunction**

The indicator lamp flashes and a short steady signal tone is sounded

- ▷ if you activate PDC with the button
- ▷ when you select reverse for the first time after switching on the ignition
- ▷ if a malfunction occurs while the PDC system is active.

Switch the system off and have the cause of the malfunction corrected by your BMW Sports Activity Vehicle center.

**System limits**

Even with PDC, final responsibility for estimating the distance between the vehicle and any obstructions always remains with the driver. Even when sensors are involved, there is a blind spot in which objects cannot be detected. This applies especially in those cases where the system approaches the physical constraints of ultrasonic measurement, as occurs with tow bars and trailer couplings, and in the vicinity of thin or wedge-shaped objects. Low objects already displayed, e.g. a curb, can also disappear from the detection area of the sensors again before a continuous tone sounds. Loud sources of sound, inside and outside the vehicle, could drown out the PDC signal tone. ◀

Keep the sensors clean and free of ice or snow in order to ensure that they will continue to operate effectively. Do not apply high pressure spray to the sensors for a prolonged period of time. Keep the spray at least 4 in/10 cm away from the sensors.

**Antilock Brake System****The concept**

The ABS Antilock Brake System prevents the wheel brakes from locking during braking. Safe steering response is maintained even during full braking. This increases active safety.

The ABS is operational every time you start the engine. Safe braking, refer to page 140.

**EBV Electronic brake-force distribution**

EBV controls the brake system's application pressure at the rear wheels to ensure stable deceleration.

**DBC Dynamic Brake Control**

When the brake pedal is depressed rapidly, this system automatically generates a maximal boost of braking force and thus aids in keeping braking distances as short as possible during full braking. This system exploits all of the benefits provided by ABS.

Do not reduce the pressure on the brake pedal for the duration of the brake application. DBC is deactivated when you release the brake pedal.

## Malfunction

Please be absolutely sure to follow instructions regarding possible combinations of indicator lights on page 20.

## The concept

DSC prevents the drive wheels from slipping when starting off and accelerating. DSC also identifies unstable driving conditions, such as a loss of traction at the rear of the vehicle or sliding of the vehicle in its front wheels. Under these circumstances, DSC helps the vehicle maintain a safe course within the physical limits by reducing the engine output and by applying the brakes in the individual wheels.

The DSC is operational every time you start the engine.



The laws of physics cannot be repealed, even with DSC.

An appropriate driving style always remains the responsibility of the driver. So please do not further limit the additional safety margin by risky driving. ◀

## Indicator lamp



The indicator lamp in the instrument cluster goes out after the engine is started.

The indicator lamp flashes: DSC is active and governs drive and braking force.

The indicator lamp stays lit: DSC has been switched off using the button and the stabilizing interventions are no longer available.

CarManuals2.com



### Switching DSC off

Press the button; the indicator lamp comes on and stays on.

Stabilizing interventions of the chassis control system DSC are no longer available. However, the braking interventions that simulate the function of the differential lock continue to be active.

In the following exceptional circumstances, it may be effective to switch off the DSC for a short period:

- ▷ When rocking the vehicle and starting off in deep snow or on loose road surfaces
- ▷ On sandy road surfaces
- ▷ On poor surfaces with deep ruts

- ▷ If the wheels churn on muddy surfaces
- ▷ When driving with snow chains.

▶ As a result of the braking interventions, the brakes may be subjected to additional loads when the system is switched off. In order to limit the brake temperature, brief automatic masking of the brake activation is possible.

To maintain vehicle stability, always drive with the system switched on when possible. ◀



### Switching DSC on

Press the button a second time – the indicator lamp goes out. DSC is now activated.

### Malfunction

Please be sure to observe the information on the DSC Dynamic Stability Control/xDrive warning lamp on page 22 and on the possible lamp combinations that can light up on page 20.

## xDrive

xDrive is the 4-wheel drive system of your X5. The combined effects of xDrive and DSC further optimize the traction and dynamic driving characteristics. The 4-wheel drive system xDrive variably distributes the drive torque to the front and rear axle depending on the driving situation and prevailing road conditions.

### Malfunction

Please be sure to observe the information on the DSC Dynamic Stability Control/xDrive warning lamp on page 22 and on the possible lamp combinations that can light up on page 20.

## HDC Hill Descent Control

### The concept

HDC is a system for driving downhill in steep terrain. This system reduces vehicle speed on steep downhill gradients, thus allowing you to maintain even better control of your BMW under these conditions.

The vehicle moves at slightly more than walking speed without active intervention from the driver.

HDC is available for activation at vehicle speeds below approx. 20 mph/ 35 km/h. When driving down steep hills with a speed below approx. 20 mph/ 35 km/h, the vehicle reduces speed automatically down to slightly more than walking speed, approx. 3 mph/ 8 km/h, and then maintains this speed at a constant.

You can use the accelerator or brakes to vary this automatically controlled speed within a range extending from approx. 3 mph/5 km/h to 15 mph/ 25 km/h.

You can specify a target speed within the same range by using the +/- buttons of the cruise control.

HDC is automatically deactivated once vehicle speed again exceeds approx. 35 mph/60 km/h.



### Activating system

Press the button, the indicator lamp lights up.

The indicator lamp flashes when the brakes are applied automatically.

### Deactivating system

Press the button again; the indicator lamp goes out.

HDC is deactivated automatically above a road speed of approx. 35 mph/ 60 km/h and when the ignition is switched off.

**Using HDC**

With manual transmission:

Use HDC in first gear and in Reverse since the engine's braking effect is diminished in the higher gears.

With automatic transmission:

You can use HDC in every drive position.

**In case of a malfunction**

If the warning lamp in the button goes out during HDC operation or does not light up when the HDC is activated: HDC is temporarily not available as brake temperature is too high.



The warning lamp for the self-leveling suspension comes on, or the message SELFLEVEL

SUSP.INACT appears in the Check Control: there is a malfunction in the self-leveling suspension.

Stop and inspect the vehicle. If the rear of the vehicle is visibly lower than the front, possibly accompanied by a tilt noticeable when you compare the left rear with the right rear, please respond by immediately proceeding to the nearest BMW Sports Activity Vehicle center. Drive with appropriate caution in the meantime. The vehicle has reduced ground clearance and driving comfort may be noticeably reduced.

Even when the position of the vehicle is normal, have the system checked as soon as possible when a malfunction is indicated.

## 2-axle self-leveling suspension\*

### The concept

Your vehicle is equipped with 2-axle self-leveling suspension acting on both the front and rear suspension. This system combines automatic self-leveling, which compensates for variations in front-to-rear load-distribution patterns, with a selection feature allowing drivers to choose from among several ride-height options.

You may choose from among the following ride heights:

- ▷ Normal  
The standard setting is intended for most operating conditions, including trailer towing
- ▷ Off-Road  
Increased level for more ground clearance
- ▷ Access  
Lowers vehicle for more convenient cargo handling or easier passenger entries and exits.

Changes in ride height are initiated either manually, using the control button, refer to page 100, or automatically in response to specific speeds. When the ride height is selected manually, the driver has the additional option of revising the ride-height selection by entering


a new command during the adjustment process.

When the vehicle is stationary, the system executes ride-height changes in both directions – up and down – whenever the doors are closed. The tailgate/liftgate may be open. The system raises the vehicle only when the engine is running.

The system's automatic self-leveling feature automatically compensates for variations in the vehicle's load.

 Frequent changes in ride height initiated at short intervals can overheat the compressor, causing the system to briefly suspend active operation. ◀

[CarManuals2.com](http://CarManuals2.com)



### Self-leveling suspension display

- 1 Off-Road
- 2 Standard
- 3 Access

The LEDs not only show the current ride height, but also indicate changes:

- ▷ LED on: indicates the vehicle's current ride height
- ▷ Ride-height LED flashes while the LED for the earlier level remains on: the ride height is being adjusted to a new level, either automatically or in response to driver input at the button.

When the suspension reaches the new ride height the flashing LED reverts to continuous operation, and the LED for the earlier level goes out

## 100 2-axle self-leveling suspension\*

- ▷ LED for current ride height flashes for roughly 3 seconds when you press the button: change in ride height is not possible.



### Raising

Available only when the engine is running.

From Standard to Off-Road:

Press button 1 while traveling at a speed of less than approx. 30 mph/50 km/h.

From Access to Standard:

- ▷ Press button 1 or
- ▷ the setting automatically reverts to the standard setting once the vehicle exceeds a speed of approx. 20 mph/35 km/h.

### Lowering

Available with ignition key in position 2.

From Standard to Access:


1. Press button 2 while traveling at less than approx. 50 mph/80 km/h. The system enters its preselection mode. The preselection mode is canceled
  - ▷ by pressing button 1
  - ▷ automatically once the vehicle exceeds a speed of approx. 50 mph/80 km/h or approx. 60 seconds after button 2 is pressed
2. Reduce speed to below approx. 15 mph/25 km/h within approx. 60 seconds after pressing button 2.

▷ When you press button 2 at speeds below approx. 15 mph/25 km/h the system automatically lowers the vehicle to the Access level. ◀

From Off-Road to Standard:

- ▷ Press button 2 or
- ▷ automatically once you exceed a speed of approx. 30 mph/50 km/h.

## Brake Force Display



The Brake Force Display lights up in two stages, depending on how forcefully you apply the brakes.

The display has two levels:

- ▷ Normal braking:  
The brake lamp 1 and the center brake lamp light up
- ▷ Heavy braking and braking with ABS:  
The brake lamps 1 and 2 light up together with the center brake lamp.

## Flat Tire Monitor

### The concept

The Flat Tire Monitor keeps track of the inflation pressures in the four fitted tires as you drive. The system provides an alert whenever the inflation pressure drops significantly in relation to the pressure another tire.

The check of the tire inflation pressure is based on monitoring the relative speeds of the wheels. A flat is detected and reported on the basis of a deviation in certain speed ratios.

### Functional requirement

To ensure reliable operation, the system should have been initialized with the correct tire inflation pressure.

### System limits

 The Flat Tire Monitor cannot indicate sudden severe tire damage caused by outside factors and does not detect a natural, even pressure drop in all four tires. ◀

In the following situations, the system could be delayed or malfunction:

- ▷ When driving on snow-covered or slippery road surfaces
- ▷ In the case of performance-oriented driving: slip on the drive wheels, high lateral acceleration
- ▷ False alarms and undetected loss of pressure may occur when you are driving with snow chains fitted.



### Initializing system

 Perform the initialization immediately every time you correct the inflation pressure, change a tire or change a wheel or all wheels. A drive is required for this purpose. ◀

1. Before the start of driving, start the engine, but do not drive off
2. Press the button until the yellow indicator lamp in the instrument cluster lights up for a few seconds
3. Drive off.

It takes a few minutes of driving before the Flat Tire Monitor can detect and report a flat tire.

 When driving with snow chains, do not initialize the system. ◀

### Indication of a flat tire



The warning lamp lights up yellow. There is a flat tire or extensive inflation pressure loss.

1. Reduce speed and stop the vehicle carefully. Avoid sudden braking and steering maneuvers
2. Identify damaged tire
 

 If identification is not possible, contact your BMW Sports Activity Vehicle center. ◀
3. Replace the damaged wheel, refer to Wheel changes on page 163.

[CarManuals2.com](http://CarManuals2.com)

## Parking lamps/low beams



### Parking lamps/side marker lamps



The front, rear and side vehicle lighting is switched on. You can use the parking lamps for parking. For lighting on one side for parking as an additional feature, refer to page 104.

### Low beams



When the ignition is switched off and the low beams are on, only the parking lamps/side marker lamps remain on.



**Pathway lighting:**  
When you activate the headlamp flasher after parking the vehicle and switching off the lamps, the low beams will come on for a brief period. You may also have this function deactivated if you wish. ◀

### Lights on warning

Whenever you open the driver's door, after having turned the ignition key to position 0, you will hear an acoustic signal for a few seconds to remind you that the lamps have not been switched off.

On vehicles with alphanumeric Check Control\*:

The reminder is given through the Check Control.

### Daytime driving lamps\*

The headlamps are automatically switched on for daytime driving at ignition key position 2.

### Automatic headlamp control\*



When you set the switch to this position, the system activates and switches on and off the low beams in response to changes in ambient light conditions, for instance, in tunnels, at dawn and dusk, and in rain and snow.



The low beams remain switched on regardless of the ambient light when you switch on the front fog lamps. ◀



Automatic headlamp control cannot serve as a substitute for the driver's judgment in determining when the vehicle lamps should be switched on. For example, the system cannot detect fog. To avoid safety risks, you should always switch on the lamps manually under these conditions. ◀



You can have the sensitivity of the headlamp control system adjusted on your vehicle. ◀

**The concept**

Adaptive Head Light is a variable headlamp control system that enables better illumination of the road surface.

Depending on the steering angle and other assumptions, the light from the headlamp follows the course of the road.

**Activating Adaptive Head Light**

In ignition key position 2, turn the light switch to the position 'Automatic headlamp control',


refer to page 103.

To avoid blinding oncoming traffic, the Adaptive Head Light

- ▷ is not active when driving in reverse
- ▷ is active only when pointing toward the passenger side.

**Malfunction**

The LED next to the symbol for automatic headlamp control flashes. Adaptive Head Light is faulty or has failed. Have the system checked as soon as possible.

**High beams/roadside parking lamps**

- 1 High beams
- 2 Headlamp flasher
- 3 Roadside parking lamps

**Roadside parking lamps, left or right\***

As an additional feature, you can illuminate your vehicle on either side for parking, if you wish to do so:

With the ignition key in position 0, engage the lever in the appropriate turn signal position.



The roadside parking lamps drain the battery. Avoid use for extended periods of time, otherwise, it will no longer be possible to start the engine. ◀

## Front fog lamps



Briefly press the button to switch on/off.



The parking lamps or low beams must be switched on for the fog lamps to operate. A green indicator lamp appears in the instrument cluster to indicate that the front fog lamps are on.

If the high beams are switched on, the front fog lamps go out.




If the automatic headlamp control is activated, the low beams will automatically be switched on when the front fog lamps are switched on. ◀

## Instrument lighting



Turn the serrated dial to adjust the illumination intensity.

## Interior lamps



The interior lamps operate automatically.

### Switching interior lamps on and off manually

Briefly press button 1.

If you want the interior lamps to remain off all the time, press and hold the button for approx. 3 seconds.

Briefly press the button to revert to normal operation.

The button for the interior lamps in the rear passenger area only switches these lamps on and off.

### **Reading lamps\***

Reading lamps are located at the front and in the rear next to the dome light. They can be switched on and off with the respective buttons 2 located next to them.

### **Footwell and cargo area lamps**


The lamps are controlled in the same manner as the front interior lamps.

### **Front area lighting\***

This lighting system in the two exterior mirrors illuminates the ground in the area near the two front doors. It is also controlled in the same manner as the front interior lamps, but it does not function while the vehicle is moving.



In order to prevent battery discharge, all of the lamps in the vehicle are switched off automatically approx. 15 minutes after the ignition key is turned to position 0. ◀



- 1 Airflow directed toward the windshield and side windows
- 2 Airflow for the upper body [109](#)
- 3 Front footwell ventilation

- 4 Rear footwell ventilation
- 5 Airflow for the upper body in the rear seat [109](#)
- 6 Temperature [108](#)
- 7 Air distribution [108](#)

- 8 Air supply [108](#)
- 9 Rear window defroster [108](#)
- 10 Air conditioning [108](#)
- 11 Recirculated-air mode [108](#)

**Temperature**

The graduations on the dial provide general reference values for the interior temperature. 70 °F/22 °C is recommended as a comfortable setting. After the start of driving the selected temperature is reached as quickly as possible and held constant by the control system.

**Air distribution**

You can direct air to flow onto the windows , toward the upper body , and into the footwell . All intermediate settings are possible. In the  setting, there is a low flow of air onto the windows to keep them free of condensation.

**Air supply**

You can adjust the air supply through an infinitely-variable range. The heating and ventilation become more and more effective as the air supply settings are increased. In the 0 setting, the blower and climate control are switched off and the outside air supply is blocked.

**Rear window defroster**

When the rear window defroster is activated, the indicator lamp comes on. The rear window defroster switches off automatically.

**Air conditioning**

The air is cooled and dehumidified and – depending on the temperature setting – warmed again. Depending on the weather, the windshield may fog over briefly when the engine is started. You can reduce condensation forming on the windows by switching on the air conditioning.



During air conditioning condensation forms, which then exits under the vehicle. Traces of water on the ground are therefore normal. ◀


**Recirculated-air mode**

You can respond to unpleasant odors outside the vehicle by temporarily switching off the outside air supply. The system then recirculates the air currently within the vehicle.

With the button on the steering wheel you can also switch over to the recirculated-air mode, refer to page 23.



If the windows fog over in the recirculated-air mode, switch the recirculated-air mode off and increase the air supply as required. ◀



## Ventilation

The air vents for the upper body region are adjustable:

- 1 Serrated dials for opening and closing the vent outlets through an infinitely-variable range
- 2 Levers for adjusting airflow direction
- 3 With the serrated dial you can adjust the temperature of the incoming air:
  - ▷ Turn toward blue: colder
  - ▷ Turn toward red: warmer.



## Rear ventilation\*

- 1 Serrated dial for opening and closing the vent outlets through an infinitely-variable range
- 2 Levers for adjusting airflow direction

The air that flows out here is somewhat cooler than the air delivered to the footwell.

## Microfilter


The microfilter removes dust and pollen from the incoming air and in the recirculated-air mode. It is replaced by your BMW Sports Activity Vehicle center during regular maintenance. A substantial reduction in air supply indicates that the filter must be replaced before normal maintenance.



## Defrosting windows and removing condensation

1. You can specify an interior temperature that is comfortable for you with the rotary temperature dial. A good starting point is 70 °F/22 °C
2. Set the air distribution rotary dial to
3. Set the blower/air supply rotary dial completely to the right
4. Close the vent outlets in the rear seating area
5. Switch on the rear window defroster to defrost the rear window.

## 110 Automatic climate control\*



1 Airflow directed toward the windshield and side windows

2 Airflow for the upper body [114](#)

3 Airflow for the footwell

4 Rear footwell ventilation


5 Airflow for the upper body in the rear seat [114](#)

6 Automatic air distribution and supply [112](#)

7 Individual air distribution [112](#)

8 Temperature, left side of passenger compartment [112](#)

9 Display for temperature and air supply [112](#)



- 10 Temperature, right side of passenger compartment [112](#)
- 11 Defrosting windows and removing condensation [112](#)
- 12 Air conditioning [113](#)

- 13 AUC Automatic recirculated-air control [113](#)
- 14 Rear window defroster [113](#)
- 15 Air supply [112](#)

- 16 Maximum cooling [113](#) or residual heat utilization [113](#)
- 17 Air grill for interior temperature sensor – please keep clear and unobstructed

**Tips for pleasant driving**

For nearly all conditions, AUTO program 6 offers the optimal air distribution and airflow volume. Select the interior temperature that is comfortable for you.

Detailed setting options are described for you in the following section.




Your BMW Sports Activity Vehicle center can program the settings of your vehicle in such a manner that, when you unlock the vehicle with your individualized key, your own personalized setting for the automatic climate control is initiated. ◀

**Automatic air distribution**

The AUTO program adjusts the airflow and distribution patterns for you while also using your preselected temperature setting as the basis for adjusting the interior climate to adapt to external influences: summer, winter.

**Individual air distribution**

You can cancel the AUTO program by selecting specific air distribution patterns for your personal comfort, the automatic air supply remains in operation. You can direct air to flow onto the windows , toward the upper body , and into the footwell . You can reactivate the automatic air distribution mode by selecting the AUTO button.

**Temperature**

You can make individual temperature settings on the driver's side or the front passenger side. Your specifications appear in the display 9. The displayed temperature values are reference values for the interior temperature. We recommend 72 °F / 22 °C as a comfortable setting, whether the air conditioner is operating or not. When you start the vehicle, the AUTO program ensures that the selected temperature is achieved as quickly as possible. It then maintains this temperature, regardless of the season.

To change the units of measurement of the display °F/°C, refer to page [76](#) or [83](#).

**Air supply**

In the AUTO program the air supply is automatically controlled, and AUTO appears in the display 9, refer to overview on page [110](#). You can vary the air supply by pressing the left or right half of the button. When your setting is displayed by bars, the automatic air supply is switched off. Automatic air distribution maintains its setting. You can reactivate the automatic air supply by pressing the AUTO button.

When you press the left side of the button during operation at minimum blower speed all displays are canceled: the blower, heating and air conditioner are switched off. The outside air supply is closed. You can switch the system back on by pressing any button of the automatic climate control, except the MAX button 16.

**Defrosting windows and removing condensation**

This program quickly removes ice and condensation from the windshield and the side windows.

## Air conditioning



The air is cooled and dehumidified and – depending on the temperature setting – warmed again. Depending on the weather, the windshield may fog over briefly when the engine is started. You can reduce condensation forming on the windows by switching on the air conditioning.



During air conditioning condensation forms, which then exits under the vehicle. That traces of water on the ground are therefore normal. ◀

## Maximum cooling



You will get maximum cooling capacity using this program if the engine is running and the outside temperature is above approx. 41 °F/5 °C.

The temperature display 9 jumps to 60 °F/16 °C, the system switches over to the recirculated-air mode, and the maximum air supply flows from the ventilation grills only. That is why you need to keep these open if you select this program.

## AUC Automatic recirculated-air control



You can respond to unpleasant odors or pollutants in the immediate environment by shutting off the supply of outside air. The system then recirculates the air currently within the vehicle. In AUC operating mode, a sensor detects pollutants in the external air and controls the shut-off automatically.

Press the button repeatedly to run through the following control sequence

- ▷ Indicator lamps off: outside air supply operational
- ▷ Left indicator lamp on, AUC mode: the system recognizes pollutants in the outside air and blocks the flow of air when necessary. The system then recirculates the air currently within the vehicle. Depending on the air quality, the automatic system then switches back and forth between outside air supply and recirculation of the air within the vehicle
- ▷ Right-hand indicator lamp on: the outside air supply into the vehicle is completely blocked. The system then recirculates the air currently within the vehicle.

With the button on the steering wheel you can also switch between Off and recirculated-air mode or AUC and recirculated-air mode, refer to page 23.



If the windows fog over in the recirculated-air mode, switch the recirculated-air mode off and increase the air supply as required. ◀

## Rear window defroster



When the rear window defroster is activated, the indicator lamp comes on. The rear window defroster switches off automatically.


## Residual heat



Press button when the motor is switched off, but warm.

The heat which is stored in the engine is utilized for heating the interior when the engine has been switched off – while waiting at a railroad crossing, for instance.

This function may be activated when the outside temperature is below approx. 59 °F/15 °C, the engine is at operating temperature, and the battery is adequately charged. The LED on the button will light up when all conditions have been met.



### Ventilation


The air vents for the upper body region are adjustable:

- 1 Serrated dials for opening and closing the vent outlets through an infinitely-variable range
- 2 Selector levers for airflow direction
- 3 Use the serrated dial to control the temperature of the airflow:
  - ▷ Turn toward blue: colder
  - ▷ Turn toward red: warmer.



### Rear climate control\*

- 1 Air supply
- 2 Temperature
- 3 Adjusting the direction of the airflow



### Air supply

0 Blower off

I Maximum blower speed

You can adjust the air supply for the vent outlets through an infinitely-variable range between the 0 and I settings.

In the 0 setting, the blower is switched off and the supply of air through the vent outlets is blocked.

Individual adjustments on the front-seat control elements influence the air supply for rear passenger area climate control.



### Temperature

Passengers in the rear seating area can adjust their own temperature for the vent outlets:

- ▷ Turn toward blue: colder
- ▷ Turn toward red: warmer.

When you start the vehicle, this system ensures that the selected temperature is achieved as quickly as possible. It then maintains this temperature, regardless of the season.

 A temperature setting is only possible when the blower is switched on, not in the 0 setting.◀

### Microfilter/activated-charcoal filter

[CarManuals2.com](http://CarManuals2.com)

The microfilter removes dust and pollen from the incoming air. The activated-charcoal filter provides additional protection by filtering gaseous pollutants from the outside air. Your BMW Sports Activity Vehicle center replaces this combined filter as a standard part of your scheduled maintenance. A substantial reduction in air supply indicates that the filter must be replaced before normal maintenance.

### Roller sun blinds for rear side windows\*

Use the strap to pull out the blinds, then hook them in the provided attachment.



With roller sun blinds attached, do not open the windows during travel. The blinds may otherwise be damaged by the wind.◀

You can use this system to ventilate the interior and lower its temperature, using the blower of the independent ventilation or of the automatic climate control.

The independent ventilation is operated via the MID Multi-Information Display, refer to page 87, or via the onboard computer, refer to the separate Owner's Manual.

You can set two different times for the system to start; it will remain active for 30 minutes. You can also switch it on and off directly. Since the system uses a substantial amount of electrical current, you should refrain from switching it on twice in succession without allowing the battery to be recharged in normal operation between use.

When a preselected activation time is set, the independent ventilation is operational at outside temperatures above approx. 60 °F / 16 °C, or by direct switch activation.

The air enters the passenger compartment through the vent outlets in the instrument cluster, which can be adjusted for both direction and airflow. Therefore, the vent outlets must be open for the system to operate.

CarManuals2.com

## The concept

The integrated universal remote control can replace as many as three hand-held transmitters for various remote-controlled accessories, such as door openers and house alarm systems. The integrated universal remote control recognizes and learns the transmitted signal of each of the original hand-held transmitters.

The signal of an original hand-held transmitter can be programmed on one of the three memory buttons 1. Following that, each of the devices can be actuated with the appropriately-programmed memory button 1. The indicator lamp 2 flashes to confirm transmission of the signal.

Should you sell your vehicle one day, be sure to delete the stored programs beforehand for your safety, refer to page 119.



To prevent possible damage or injury, before programming or using the integrated universal remote control, always inspect the immediate area to make certain that no people, animals or objects are within the travel range of the device. Also, comply with the safety precautions of the original hand-held transmitter. ◀



To Canadian residents:  
During programming, your hand-held transmitter may automatically stop transmitting after two seconds, which may not be long enough to program the integrated universal remote control. If you are programming from one of these hand-held transmitters, the integrated universal remote control's light may begin to flash in a series of double-blinks. If this occurs, continue to hold the button of the integrated universal remote control while you reactivate your hand-held transmitter. You may have to repeat this function several times while programming. ◀

## Checking compatibility



If you see this symbol on the packaging or in the manual supplied with the original hand-held transmitter, it is safe to assume that it is compatible with the integrated universal remote control.

A list of compatible hand transmitters is available via fax polling by calling +49 (0)6838 907283 3333. For details, please call the toll-free HomeLink Hotline at +49 (0)6838 907 277 or 0800 0466 35465 in Germany.

HomeLink is a registered trademark of Johnson Controls.



## Programming

- 1 Memory buttons
- 2 Indicator lamp

## Fixed-code hand-held transmitter

1. Switch on the ignition
2. For initial use: press both outer buttons 1 for approx. 20 seconds, maintaining pressure until the indicator lamp 2 starts to flash. The three memory buttons 1 are cleared
3. Hold the original hand-held transmitter at a distance of approx. 2 to 8 in/ 5 to 20 cm from the memory buttons 1

 The required distance between the hand-held transmitter and memory buttons 1 depends on the

relevant system of the original hand-held transmitter used. ◀

4. Simultaneously press the transmit button on the original hand-held transmitter and the desired memory button 1 of the integrated universal remote control. Initially, the indicator lamp 2 flashes slowly. Release both buttons as soon as the indicator lamp 2 flashes rapidly. If the indicator lamp 2 does not flash rapidly after approx. 15 seconds, change the distance
5. To program other original hand-held transmitters, repeat steps 3 and 4.

The corresponding memory button 1 is now programmed with the signal of the original hand-held transmitter.

You can operate the system when the engine is running or when the ignition is switched on.

 If the system cannot be operated after repeated programming, check whether the original hand-held transmitter uses an alternating-code system. To do so, either read the instructions of the original hand-held transmitter or press and hold down the programmed memory button 1 of the integrated universal remote control.

If the indicator lamp 2 on the integrated universal remote control flashes quickly for a brief period and then remains lit up for approx. two seconds, this indicates that the original hand-held transmitter is equipped with an alternating code. In the case of an alternating-code system, program the memory buttons 1 as described at the section on alternating-code hand-held transmitters.

If you have additional questions, please consult your BMW Sports Activity Vehicle center or call 1-800-355-3515.

You can also visit this website [www.bmwusa.com](http://www.bmwusa.com) ◀

## Alternating-code hand-held transmitter

To program the integrated universal remote control, consult the Owner's Manuals for the equipment to be set. You will find information there on the possibilities for synchronization. When programming alternating-code hand-held transmitters, please observe the following supplementary instructions:

 Programming will be easier with the aid of a second person. ◀


1. Park your vehicle within the range of the remote-controlled device
2. Program the integrated universal remote control as described at the section on fixed-code hand-held transmitters
3. Localize the button on the receiver of the device you want to set up, e.g. on the upper section of the motor
4. Press the button on the receiver of the device you want to set up. After step 4, you have approx. 30 seconds for step 5
5. Press the programmed memory button 1 on the integrated universal remote control three times.

The corresponding memory button 1 is now programmed with the signal of the original hand-held transmitter.

 If you have any additional questions, please contact your BMW Sports Activity Vehicle center. ◀

## Clearing memory buttons


Individual memory buttons 1 cannot be cleared. However, you clear all three memory buttons 1 together as follows: Press both outer buttons 1 of the integrated universal remote control for approx. 20 seconds, maintaining pressure until the indicator lamp 2 starts to flash.



## Hands-free system

On vehicles with telephone preparation\*, the hands-free microphone is located in the headliner.

For further information on the telephone, refer to the Telephone Owner's Manual.

**Opening**

Pull the handle. The lamp inside the glove compartment comes on.

**Closing**

Fold the cover up.

 To prevent injury in the event of an accident, close the glove compartment immediately after use. ◀

**Locking**

Use one of the master keys. A master key is also required for unlocking.


 If you turn over only your spare key for valet parking, for example, refer to page 30, access to the glove compartment is not possible. ◀

**Rechargeable flashlight**

Located on the left-hand side of the glove compartment.

Features integral overload-protection, so it can be left in its holder continuously.

 To avoid completely discharging and possibly damaging the lamp, always ensure that it is switched off before inserting it in the socket. ◀

**Storage compartments**

You will find two storage compartments in the armrest between the front seats.

To open the top compartment: Press the button, refer to arrow 1. A built-in phone\* is located in this compartment.

To move the armrest or open the lower compartment:

Pull the handle, refer to arrow 2.

This compartment contains a coin tray and a storage compartment\* for cassettes or CDs.

You will find additional storage compartments in all of the doors as well as on the backrests of the front seats.


## Clothes hooks

 When suspending clothing from the hooks ensure that it will not obstruct the driver's vision. Do not hang heavy objects on the hooks. If you do so, they could cause endanger passengers during braking or evasive maneuvers. ◀



## Front

Below the sliding cover, refer to illustration.



## Rear

At the end of the center console under the lighter.

Briefly press to open; push back inward to close.

 Do not place glass containers in the cup holders, as otherwise there is a danger of injury in an accident. ◀

**Emptying**

Press the edge of the lid, refer to arrow: the ashtray moves up and can be removed.

**Cigarette lighter, front**

Press the lighter 1 in.

The lighter can be removed as soon as it retracts.



Hold or briefly press the hot cigarette lighter by the knob only.

Holding or touching it in other areas could result in burns.

The cigarette lighter remains operational when the ignition key has been removed. For this reason, do not leave unsupervised children in the vehicle. ◀

**Power socket**

The cigarette lighter socket can be used to plug in hand flashlights, car vacuum cleaners etc., with power ratings of up to approx. 200 W at 12 V. Be careful not to damage the socket with unsuitable plugs.

You will find additional power outlets in the cargo area, refer to page 129.

**Emptying**

Remove the insert tray.



Press the lighter in.

The lighter can be removed as soon as it retracts.



Hold or briefly press the hot cigarette lighter by the knob only.

Holding or touching it in other areas could result in burns.

The cigarette lighter remains operational when the ignition key has been removed. For this reason, do not leave unsupervised children in the vehicle. ◀

CarManuals2.com

## 124 Ski bag\*


The ski bag allows the safe and clean transport of up to 4 pairs of standard skis or up to two snowboards.

With the length of the ski bag and the additional space in the cargo area, you can store skis with a length of up to 6.9 ft/2.1 m. Because of the tapered shape of the bag, the ski bag can only accommodate two pairs of skis with a length of 6.9 ft/2.1 m.



### Loading


1. Fold the center armrest outward.  
Loosen the trim from the upper Velcro® fastener and place it on the armrest



2. Press button 1 downward and swing the cover forward
3. Press button 2: the cover in the cargo area is unlocked.  
In conjunction with pull-out cargo floor, refer to page 130: pull out floor, release cover and push back floor again; the floor then conceals the cover
4. Place ski bag between the front seats and load. The zip fastener facilitates access to the stowed items.

Make sure that only clean skis are loaded into the ski bag. Wrap sharp edges so that no damage occurs.

## Ski bag\*



If the cover in the cargo area is concealed by the pull-out cargo floor, do not fold the larger rear backrest down. If you do so, it will damage the cover. ◀


### Securing load

After loading, secure the ski bag and its contents. To do so, tighten the retaining belt at the buckle.



Secure the ski bag in this way. If you fail to do so, it could endanger occupants during braking or evasive maneuvers. ◀

When stowing the ski bag, proceed in the reverse order from loading.




### Folding rear backrests down

Reach into the recess and pull forward, refer to arrow.



When you fold back the backrest, be sure that the catch engages securely. The red warning indicator disappears in the recess when the catch is engaged.

The center safety belt can be retracted only when the larger backrest is engaged. ◀



### Roll-up cover


Pull out the roll-up cover and hook it into the brackets at the rear.

You can carry light objects such as items of clothing on the roll-up cover.



Do not place heavy or hard objects on the roll-up cover. If you do so, they could already pose a danger to vehicle occupants during braking or evasive maneuvers.

Do not allow the roll-up cover to snap back, as otherwise it could be damaged. ◀





### Removing roll-up cover

1. Unlock the case with the button, refer to arrow 1, lift it out of the bracket on the side and hold it in place on the opposite side with the other hand
2. Then push the case toward the side window, refer to arrow 2. This pulls it out of the second bracket and it can be removed.

### Installation

Lay the case in the two side brackets and then press down until it engages.



## Partition net\*

1. Remove the bag with the partition net from the retainer by releasing the hooks from the lashing eyes on both sides


2. Remove the partition net from the bag, unroll it half way and hook it into the retaining strap on both sides, refer to arrow



Note how the partition net is stored in the bag and secured in the vehicle so that you can return everything to its proper place again after use.

If your vehicle has a pull-out cargo floor, observe the note on page [130](#).◀


3. Slide back the covers on the retainers for the partition net on both sides of the roof, refer to arrow
4. Insert the curved ends of the partition net rod in the retainers on both sides
5. Now you can slide the covers toward the front again, refer to arrow



6. Pull down the partition net downward on both sides by the loop, refer to arrow, and hook the hook into the eye on the backrest



The case with the roll-up cover is not shown in the illustration. With the case removed it is easier to hook the hooks of the partition net onto the backrest. ◀




7. When the rear backrests are folded down, you can unhook the partition net from the retaining straps, completely unroll it, insert it in the front retainers on the roof and attach the three hooks into the eyes on the backrests.

The illustration shows securing at the bottom right as an example.



### Side covers

Pull the handle to open the side covers.



## Floor cover

To access the spare wheel.

To open: press the recess in the handle, refer to arrow, and raise the cover with the handle.



## Folding floor cover up

Disengage the loop end on the lower side of the floor cover and hook it in with the catch on the upper frame of the luggage cutout.

Before swinging down the floor cover, reengage the loop end in the retainer on the underside of the floor cover.




## Power outlets

When you fold the cover caps up, you have access to additional power outlets.

You can use the power outlets for flashlights, car vacuum cleaners or other automotive appliances with up to approx. 200 watts at 12 volts. Be careful not to damage the socket with unsuitable plugs.

Also refer to page [122](#).



### **Pull-out cargo floor\***

To release, pull the handle recess upward. Then pull the floor out.



Do not drive when the cargo floor is pulled out.

Do not release the cargo floor on steep grades. If you do, it could extend automatically and cause personal injuries. A load which is not properly secured could begin to slide if the floor extends automatically and then drop to the ground as a result of the rapid braking of the cargo floor at the limit stop. ◀

When it is extended, you can load the cargo floor:

- ▷ With up to 990 lbs./450 kg, distributed evenly across the entire surface
- ▷ With up to 330 lbs./150 kg on the rear edge.



Do not overload the cargo floor when it is extended. If you do so, it could cause damage.

When you slide the cargo floor back in, do not grasp it on the bottom. If you do so, there is a risk of personal injury. ◀



### **Raising cargo floor**

For access to the spare wheel or other stored items:

Swing the cargo floor up and secure it with the rod, refer to illustration.



If your vehicle has a partition net: Take the bag with the partition net out of the retainer, refer to page 127, before you raise the cargo floor. Otherwise, the bag could slide downward. ◀

 Avoid overloading the vehicle so that the permissible loading capacity of the tires is not exceeded. Overloading can lead to overheating and increases the rate at which damage develops inside the tires. The ultimate result can assume the form of a sudden air loss. ◀




## Determining loading limit

1. Locate the following statement on your vehicle's placard\*:


 The combined weight of occupants and cargo should never exceed XXX lbs. or YYY kg, as otherwise the vehicle may be damaged and unstable driving conditions may result. ◀

2. Determine the combined weight of the driver and passengers that will be riding in your vehicle
3. Subtract the combined weight of the driver and passengers from XXX lbs. or YYY kg

4. The resulting figure equals the available amount of cargo and luggage load capacity.  
For example, if the XXX amount equals 1350 lbs. and there will be five 150 lbs. passengers in your vehicle, the amount of available cargo and luggage load capacity is 600 lbs.:  
 $1350 \text{ lbs.} - 750 \text{ lbs.} = 600 \text{ lbs.}$
5. Determine the combined weight of luggage and cargo being loaded on the vehicle. That weight may not safely exceed the available cargo and luggage load capacity calculated in step 4
6. If your vehicle will be towing a trailer, load from your trailer will be transferred to your vehicle. Consult the manual for transporting a trailer to determine how this may reduce the available cargo and luggage load capacity of your vehicle.

**Load:**

The permitted load is the total of the weight of occupants and cargo/luggage. The greater the weight of occupants, the less cargo/luggage can be transported.

**Stowing cargo**

- ▷ Position heavy cargo as far forward as possible directly behind the backrests and as low as possible
- ▷ Cover sharp edges and corners
- ▷ Do not pile objects higher than the top edge of the backrest
- ▷ Fasten the partition net, refer to page 127, and ensure that carried items cannot pass through the partition net
- ▷ Wrap objects which could strike the rear window while driving accordingly
- ▷ If you are transporting very heavy loads when the rear seat is not occupied, secure the outer safety belts in the opposite buckles.

[CarManuals2.com](http://CarManuals2.com)


**Securing load**

- ▷ Secure smaller, light pieces with the retaining straps or a luggage net\*, or use elastic straps, refer to page 37
- ▷ Heavy-duty cargo straps\* for securing larger and heavier objects are available at your BMW Sports Activity Vehicle center. The lashing eyes provided at the corners of the cargo area serve for mounting these heavy-duty cargo straps
- ▷ Read and comply with the information enclosed with the heavy-duty cargo straps.

 Always position and secure the load as described above. If you do not, it can even endanger the passengers during braking or evasive maneuvers.

Do not exceed the permissible gross vehicle weight and the permissible axle loads, refer to page 180. If you do, the operating safety of the vehicle is no longer ensured and you are in violation of the law.

You should never transport heavy or hard objects unsecured in the passenger compartment, as they could fly around and pose a safety hazard to the vehicle's occupants even during abrupt braking or evasive maneuvers. ◀



A special rack system is available as an option for your BMW. Please comply with the precautions included with the installation instructions.

[CarManuals2.com](http://CarManuals2.com)

### Mounting points

Access to the mounting points:  
To fold up the cover, refer to arrow, please use the tool which is provided with the rack system.

### Loading luggage rack

Roof-mounted luggage racks raise the center of gravity of the vehicle when they are loaded. For this reason, they exercise a major effect on the vehicle's handling and steering response.

You should therefore always remember not to exceed the approved roof weight, the approved gross vehicle weight or the axle loads when loading the rack.

You will find the specifications under Technical data on page 180.

Make sure that the load is distributed evenly, and that it does not extend outward to beyond the limits of the loading surface. Always load the heaviest pieces on the bottom. Be sure that adequate clearance is maintained for raising the panorama glass sunroof, and that objects do not project into the opening path of the liftgate.

 Always ensure that roof-mounted loads are tightly secured, as loose loads can shift or even fly off the roof, posing a serious hazard for following traffic. ◀

Drive smoothly. Avoid sudden acceleration and braking maneuvers. Take corners gently.



CarManuals2.com

## Overview

CarManuals2.com


## Controls and features

## Operation, maintenance

## Owner service procedures

## Technical data

## Index



Overview

Controls

Maintenance

Repairs

Data

Index

Moving parts should be allowed to break in. To ensure that your vehicle provides maximum economy throughout a long service life, we request that you observe the following instructions:

### **Engine and differential**

Up to 1,200 miles/2,000 km:

Drive at varying engine speeds and road speeds, but do not exceed 4,500 rpm and the following road speeds during this initial period:

6-cylinder engines: 100 mph/160 km/h

8-cylinder engines: 106 mph/170 km/h

Obey your local and state maximum speed limits.

Avoid full-throttle operation and use of the transmission's kick-down mode during these initial miles.

Once you have driven 1,200 miles/2,000 km, the engine and vehicle speeds can be gradually increased.

### **Tires**

Due to technical factors associated with their manufacture, tires do not achieve their full traction potential until after an initial break-in period. Therefore, drive reservedly during the first 200 miles/300 km.

Obey your local and state maximum speed limits.



When the vehicle is operated on wet or slushy roads, a wedge of water may form between the tire and the road surface. This phenomenon is referred to as hydroplaning and can lead to partial or complete loss of traction, vehicle control and braking effectiveness. Reduce your speed on wet roads. ◀

### **Brake system**

Brakes require an initial break-in period of approx. 300 miles/500 km to achieve optimal contact and wear patterns between brake pads and rotors.

To break in the separate handbrake drums, apply the handbrake lightly when coasting to a standstill at a traffic signal, for instance, provided that traffic conditions allow you to do so.

To avoid corrosion, repeat this procedure from time to time.



The brake lamps do not light up when the handbrake is applied. Vacuum for the brake system servo unit on your BMW is available only when the engine is running. When you move the vehicle with the engine switched off, when towing, for instance, substantially higher levels of pedal force will be required to brake the vehicle. ◀

### **Clutch**

The function of the clutch is only at its optimized level after a distance driven of approx. 300 miles/500 km. During this break-in period, engage the clutch gently.

### **Following component replacements**

Observe the break-in instructions again if previously addressed components must be replaced again during driving later.

## General driving notes

### Closing liftgate/tailgate

 Operate the vehicle only when the tailgate and liftgate are completely closed. Otherwise, exhaust fumes could enter into the passenger compartment. ◀

However, if special circumstances should make it absolutely necessary to operate the vehicle with the liftgate/tailgate open:

1. Close all windows and the panorama glass sunroof
2. Increase the air supply for the air conditioner or automatic climate control to a high level, refer to page 108 or 112.

### Hot exhaust system

 Extreme temperatures occur at the catalytic converter on this and every catalyst-equipped vehicle. Do not remove the heat shields installed adjacent to various sections of the exhaust system, and never apply undercoating to them. When driving, standing at idle and while parking take care to avoid possible contact between a hot exhaust system and any highly flammable materials such as hay, leaves, grass etc.

Otherwise there is a danger of ignition and of a fire with the risk of serious injuries and damage. ◀

### Portable phone in vehicle

 BMW advises against using mobile radio devices such as portable phones inside the vehicle unless they are directly connected to the external antenna. Otherwise, it is impossible to prevent a mutual interference of the vehicle electronics with the portable phone device. Also, there is no guarantee that the radiation generated by the transmission will be conveyed out from the interior of the vehicle. ◀

### When vehicle is parked

Condensation forms in the air conditioner system during operation, and then exits under the vehicle. Traces of water on the ground are therefore normal.

### Brakes

 Do not drive with your foot resting on the brake pedal. Even light but consistent pedal pressure can lead to excessively high temperatures, brake wear and possibly even brake failure. ◀

### Road hazards

 If road hazards, obstacles or curbs are unavoidable, only drive over them very slowly and carefully, as otherwise the wheels and suspension parts, especially on vehicles fitted with low profile tires, can be damaged. ◀

For more information on wheels and tires, refer to page 144.

### Before driving into a car wash

Fold in the exterior mirrors, refer to page 54, as otherwise they could be damaged due to the width of the vehicle.

### Hydroplaning


 When driving on wet or slushy roads, reduce road speed. If you do not, a wedge of water can form between tires and road surface. This state can cause a partial or total loss of contact with the road surface, of braking control and of control over the vehicle. ◀

**Driving through water**

 Do not drive through water on the road if it is deeper than 20 in/ 50 cm, and then only at walking speed at the most. Otherwise, the vehicle's engine, the electrical systems and the transmission may be damaged. When equipped with 2-axle self leveling suspension\*, switch the vehicle into the Off-Road setting before driving through, refer to page 100. ◀

**Using handbrake on slopes**

 Do not hold the vehicle in place on slopes by slipping or riding the clutch; use the handbrake instead. Otherwise, severe clutch wear will result. ◀

**Interior and exterior mirrors, automatic dimming feature\***

Two photocells serve to control the automatic dimming of the interior and exterior rearview mirrors. One photocell is in the mirror glass, refer to arrow, while the other is offset somewhat on the back of the mirror.

For trouble-free operation, keep the photocells clean and do not cover the area between the interior rearview mirror and the windshield. Do not attach any kind of stickers on the windshield in front of the mirror, either.

CarManuals2.com

**Driving your X5****On poor roads**

When you are driving on poor roads, there are a few points which you should strictly observe – for your own safety, for that of your passengers, and for the safety of the vehicle:

 Driving on unpaved terrain can cause damage to the vehicle. ◀

- ▷ Always adapt the driving speed to the road conditions. The rougher or steeper the road surface is, the lower the speed should be
- ▷ You can operate your vehicle on uphill and downhill gradients with a maximum slope of 50%. If you want to drive on uphill or downhill gradients of this kind, make sure beforehand that the engine oil and coolant levels are near the max mark, refer to pages 150 and 152. Use the HDC Hill Descent Control when driving down steep grades, refer to page 97. Starting off is possible on grades of up to 33%. The permissible body roll is also 50%
- ▷ While driving, watch carefully for obstacles such as rocks or holes. Try to avoid these obstacles whenever possible

## Driving your X5

- ▷ Please note that, for example on crests and bumpy roads, the body can make ground contact.  
The ground clearance of the vehicle is:
  - 8 in/20 cm with up to four persons
  - 7 in/18 cm fully loaded, without level control
- ▷ Only drive through water up to a maximum depth of 20 in/50 cm and only at walking speed, making sure not to stop in the process. When equipped with 2-axle self leveling suspension\*, switch the vehicle to the Off-Road setting before driving through, refer to page 100.  
After leaving the water, apply the footbrake lightly several times while driving at low speeds so as to dry the brakes by braking and to prevent decreased braking action due to wetness.

### Back onto paved road

In recommending that you observe the following points after driving on adverse road surfaces, it is not as a beauty treatment for your BMW. Instead, it is intended for the maintenance of driving safety:

- ▷ Clean the worst of the dirt from the body and inspect the undercarriage for damage
- ▷ Clean mud, snow, ice etc. from the wheels and tires and check the wheels for damage
- ▷ Check to determine whether rocks, gravel or accumulations of dirt on the brake rotors and calipers could influence braking performance. Remove all such foreign objects
- ▷ In order to clean the brake rotors, apply the footbrake gently several times while driving at a low speed. Be sure that following traffic is not endangered by this
- ▷ For cleaning the handbrake, apply the lever slightly at approx. 25 mph/ 40 km/h and continue to drive for approx. 200 yards/200 meters, provided that traffic conditions allow you to do so.

CarManuals2.com

**Emergency stops**

You brake most effectively when you apply maximum pedal pressure in situations requiring it: emergency stops.

Since the vehicle maintains steering responsiveness, you can nevertheless avoid possible obstacles with a minimum of steering effort.

Pulsation at the brake pedal combined with sounds from the hydraulic circuits indicates to the driver that ABS is in its active mode.

**Brake fluid level**

If the brake fluid level is too low and brake pedal travel has become longer, there may be a defect in one of the two brake system's hydraulic circuits.



Proceed to the nearest BMW Sports Activity Vehicle center. Here increased pressure on the brake pedal may be required, and slight pulling to the side and longer braking distances may result. Please remember to adapt your driving style accordingly. ◀

**Disc brakes**

When the vehicle is driven only occasionally, during extended periods when the vehicle is not used at all, and in operating conditions where brake applications are less frequent, there is an increased tendency for corrosion to form on rotors, while contaminants accumulate on the brake pads. This occurs because the minimal pressure which must be exerted by the pads during brake applications to clean the rotors is not reached.

If the brake rotors are corroded, they will tend to respond to braking with a pulsating effect which even extended application will fail to cure.

When driving in wet conditions and in heavy rain, it is advisable to apply light pressure to the brake pedal from time to time. Monitor traffic conditions to ensure that this maneuver does not endanger other road users. The heat generated in this process helps dry the pads and rotors to ensure that the braking force is then immediately available when required.

Extended or steep mountain descents should be driven in the gear in which only minimal periodic brake application is required. This avoids excessive strain

on the brakes and possible impairment of the braking effect.



Do not coast with the clutch depressed or with the transmission or selector lever in neutral. Do not drive with the engine switched off. The engine provides no braking effect when the clutch is depressed or the transmission is in neutral, and there is no power-assist for braking or steering when the engine is not running.

BMW recommends having brake inspections performed at a BMW Sports Activity Vehicle center only. If you do not, parts of the 4-wheel drive system could be damaged. Never allow floor mats, carpets or any other objects to protrude into the area around the accelerator, clutch and brake pedals and obstruct their movement. ◀

**Brake pads**

For your own safety: use only brake pads that BMW has released for your particular vehicle model. BMW cannot evaluate non-approved brake pads to determine if they are suited for use, and therefore cannot ensure the operating safety of the vehicle if they are installed. ◀

# Tire inflation pressure

## Information for your safety

It is not merely the tire's service life, but also driving comfort and – to a great extent – driving safety that depend on the condition of the tires and the maintenance of the specified tire pressure.

## Checking inflation pressure

Only check tire inflation pressure when the tires are cold. i.e. after driving a maximum of 1.25 miles/2 km or when the vehicle has been parked for at least 2 hours. When tires are warm, the tire inflation pressure increases.



Regularly check the tire inflation pressure and correct as needed, including the spare tire: at least every two weeks and before beginning a longer trip. If this is not done, incorrect tire pressures can cause driving instability and tire damage, ultimately resulting in an accident. Do not drive with a depressurized, i.e. flat, tire. A flat tire greatly impairs steering and braking response, and can lead to complete loss of control over the vehicle. ◀



After correcting the inflation pressure(s), always reinitialize the Flat Tire Monitor, refer to page 102. ◀



## Inflation pressure for original equipment tires

You will find tire inflation pressures on the inside door pillar.

## Inflation pressure for other tire sizes

The tire pressure table below gives all of the tire pressure specifications for the tire sizes indicated, with the ambient temperature.



In order to clearly identify the correct tire inflation pressure for your tires, be sure to note the specifications for the appropriate tire sizes. ◀

## 142 Tire inflation pressure

| BMW Tires                                                                                                             |                          |  |        |  |        |
|-----------------------------------------------------------------------------------------------------------------------|--------------------------|-----------------------------------------------------------------------------------|--------|-------------------------------------------------------------------------------------|--------|
| All pressure specifications in the table are indicated in psi/ kilopascal with cold tires, cold = ambient temperature |                          |                                                                                   |        |                                                                                     |        |
| X5 3.0i                                                                                                               | 235/65 R 17 104 H M+S    | 32/220                                                                            | 32/220 | 32/220                                                                              | 39/270 |
|                                                                                                                       | 255/55 R 18 105 H M+S    |                                                                                   |        |                                                                                     |        |
|                                                                                                                       | 255/55 R 18 105 V        |                                                                                   |        |                                                                                     |        |
|                                                                                                                       | 235/65 R 17 104 H M+S    |                                                                                   |        |                                                                                     |        |
|                                                                                                                       | 255/55 R 18 105 H M+S    |                                                                                   |        |                                                                                     |        |
|                                                                                                                       | Front: 255/50 R 19 103 V | 32/220                                                                            | –      | 32/220                                                                              | –      |
|                                                                                                                       | Rear: 285/45 R 19 107 V  | –                                                                                 | 32/220 | –                                                                                   | 39/270 |
| X5 4.4i                                                                                                               | Front: 275/40 R 20 102 W | 32/220                                                                            | –      | 32/220                                                                              | –      |
|                                                                                                                       | Rear: 315/35 R 20 106 W  | –                                                                                 | 32/220 | –                                                                                   | 39/270 |
|                                                                                                                       | 235/65 R 17 104 H M+S    | 32/220                                                                            | 33/230 | 32/220                                                                              | 39/270 |
|                                                                                                                       | 255/55 R 18 105 H M+S    |                                                                                   |        |                                                                                     |        |
|                                                                                                                       | 255/55 R 18 105 V        |                                                                                   |        |                                                                                     |        |
|                                                                                                                       | 235/65 R 17 104 H M+S    |                                                                                   |        |                                                                                     |        |
|                                                                                                                       | 255/55 R 18 105 H M+S    |                                                                                   |        |                                                                                     |        |
| X5 4.8is                                                                                                              | Front: 255/50 R 19 103 V | 32/220                                                                            | –      | 32/220                                                                              | –      |
|                                                                                                                       | Rear: 285/45 R 19 107 V  | –                                                                                 | 32/220 | –                                                                                   | 39/270 |
|                                                                                                                       | Front: 275/40 R 20 102 W | 32/220                                                                            | –      | 32/220                                                                              | –      |
|                                                                                                                       | Rear: 315/35 R 20 106 W  | –                                                                                 | 32/220 | –                                                                                   | 39/270 |
|                                                                                                                       | Front: 275/40 R 20 102 W | 32/220                                                                            | –      | 33/230                                                                              | –      |
|                                                                                                                       | Rear: 315/35 R 20 106 W  | –                                                                                 | 35/240 | –                                                                                   | 39/270 |
|                                                                                                                       | 255/55 R 18 105 H M+S    | 32/220                                                                            | 35/240 | 33/230                                                                              | 39/270 |

You will find more information about permissible loads and weights on page [180](#).

CarManuals2.com

## Tire identification marks

Knowledge of the labeling on the side of the tire makes it easier to identify and choose the right tires.

### Tire size

e.g. 235/65 R 17 104 H

Nominal width in mm — 235

Cross-sectional ratio in % — 65

Belted construction radial — R

Rim diameter in inches — 17

Load index, not with ZR tires — 104

Speed code letter, with ZR tires before the R — H

Speed code letter:

Q = up to 105 mph/160 km/h  
 T = up to 118 mph/190 km/h  
 H = up to 131 mph/210 km/h  
 V = up to 150 mph/240 km/h  
 W = up to 167 mph/270 km/h

### Tire Identification Number

Tires with DOT codes meet the guidelines of the U.S. Department of Transport.

DOT code:

e.g. DOT xxxx xxx 3603

Manufacturer's code for tire brand — xxxx

Tire size and tire model — xxx

Tire age — 3603

### Tire age

The manufacturer of your BMW recommends that all tires, i.e. including the spare wheel, be replaced regardless of the actual wear after 6 years at the latest.

The tire's date of manufacture is indicated on the sidewall:  
 DOT... 3603 indicates that the tire was manufactured in week 36 of 2003.

### Uniform Tire Quality Grading

Quality grades can be found where applicable on the tire sidewall between tread shoulder and maximum section width. For example:

### DOT Quality Grades

Tread wear

Traction AA A B C

Temperature A B C



All passenger car tires must conform to Federal Safety Requirements in addition to these grades. ◀

### Tread wear

The tread wear grade is a comparative rating based on the wear rate of the tire when tested under controlled conditions on a specified government test course.

For example, a tire graded 150 would wear one and one-half, 1 ½, times as well on the government course as a tire graded 100. The relative performance of tires depends upon the actual conditions of their use, however, and may depart significantly from the norm due to variations in driving habits, service practices and differences in road characteristics and climate.

**Traction**

The traction grades, from highest to lowest, are AA, A, B, and C.

Those grades represent the tire's ability to stop on wet pavement as measured under controlled conditions on specified government test surfaces of asphalt and concrete. A tire marked C may have poor traction performance.



The traction grade assigned to this tire is based on straight-ahead braking traction tests, and does not include acceleration, cornering, hydroplaning, or peak traction characteristics. ◀

**Temperature**

The temperature grades are A, the highest, B, and C, representing the tire's resistance to the generation of heat and its ability to dissipate heat when tested under controlled conditions on a specified indoor laboratory test wheel.

Sustained high temperature can cause the material of the tire to degenerate and reduce tire life, and excessive temperature can lead to a sudden flat tire. The grade C corresponds to a level of performance which all passenger car tires must meet under the Federal Motor Vehicle Safety Standard No. 109. Grades B and A represent higher levels of performance on the laboratory test wheel than the minimum required by law.



The temperature grade for this tire is established for a tire that is properly inflated and not overloaded. Excessive speed, underinflation, or excessive loading, either separately or in combination, can cause heat buildup and possible a tire failure. ◀

**M+S**

Winter and all-season tires. These have better winter properties than summer tires.

**Wheel/tire condition****Wheel/tire damage**

Inspect your wheels and tires frequently for tread wear, signs of damage and for foreign objects lodged in the tread. Check the tread pattern depth.



Please note that low-profile tires make your wheels, tires and suspension parts more susceptible to road hazard and consequential damages. Unusual vibrations encountered during normal vehicle operation can indicate tire failure or some other vehicle defect. This can, for example, be caused by driving over curbs. This is also true for irregularities in the vehicle's handling characteristics, such as a pronounced tendency to pull to the left or right. Should this occur, respond by immediately reducing your speed. Carefully proceed – or have your vehicle towed – to the nearest BMW Sports Activity Vehicle center or tire dealer to have the wheels or tires inspected. Tire damage, extending to sudden and complete loss of pressure in extreme cases, can pose a potentially lethal safety hazard for the vehicle's occupants and other road users alike. ◀

## Wheel/tire condition

### Tire tread

The tread depth should not fall below 0.12 in/3 mm although, for example, European regulations only require a minimum tread depth of 0.063 in/ 1.6 mm.

At tread depths below 0.12 in/3 mm there is an increased risk of high-speed hydroplaning, even when only small amounts of water are present on the road surface.

As winter tires display a noticeable loss in their ability to cope with cold-weather driving conditions once the tread wears to below 0.16 in/4 mm, you should always have such tires replaced to ensure continued safety.



Wear indicators at the tread-groove base, refer to arrow, are distributed over the tire's circumference and are marked on the side of the tire with TWI – Tread Wear Indicator. These indicators signal at a tread depth of 0.063 in/ 1.6 mm that the legally permitted wear limit has been reached.



Have new wheels and tires installed only by your BMW Sports Activity Vehicle center or a tire specialist workshop that works according to BMW guidelines with appropriately trained personnel. If this work is not carried out properly, there is a danger of subsequent damage and related safety hazards. ◀

### **Retreaded tires**



BMW does not recommend the use of retread tires, as otherwise driving safety may be reduced. The reason for this is that possible variations in the design and aging – which could be substantial – of the tire casing can result in a limited service life. ◀

### **The right wheels and tires**



BMW recommends that you use only wheel and tire combinations that BMW has tested and approved for your particular vehicle. Variations in factors such as manufacturing tolerances mean that even wheels and tires with identical official size ratings could actually have different dimensions than the approved units – these differences could lead to body contact, and with it the risk of severe accidents. If non-approved wheels and tires are used,

BMW cannot evaluate their suitability, and therefore cannot be held liable for driving safety. ◀

You can ask your BMW Sports Activity Vehicle center for the correct wheel/tire combination.

The correct wheel/tire combination also affects various systems whose function would otherwise be impaired, e.g. ABS, DSC, xDrive.

To maintain good handling and vehicle response, use only tires of a single tread configuration from a single manufacturer. After a flat tire, always remember to have the original wheel and tire combination remounted on the vehicle as soon as possible.

Recommended tire sizes and makes: For each tire size, certain tire makes have been tested by BMW and classified and approved as safe. You can find out about them at a specialized store, preferably your BMW Sports Activity Vehicle center. Follow any national regulations, e.g. listed in the vehicle documents.

The factory-approved radial ply tires are matched to your vehicle and with proper use, offer both optimal driving safety and the desired driving comfort.

### **Special features of winter tires**

BMW recommends winter tires for use in cold winter driving conditions.

Although all-season M+S tires provide better winter traction than summer tires, they generally fail to provide the same levels of cold-weather performance as winter tires.

When switching to winter tires, observe the description under Tire condition, page 144, and Replacing wheels/tires.

Observing speed ratings:



Never exceed the maximum speed for which the winter tires are rated. Unprofessional attempts by laymen to service tires can lead to damage and accidents. Have this work performed by skilled professionals only. The technicians at your BMW Sports Activity Vehicle center will be glad to assist you with the required professional knowledge and specialized equipment. ◀

## Replacing wheels/tires

### Storage

Store wheels or tires in a cool, dry place, protecting them against light whenever possible. Always protect tires against all contact with oil, grease and fuels.

Do not exceed the maximum tire inflation pressure indicated on the side wall of the tire.

## Snow chains\*

Only certain snow chains have been tested by BMW and classified and approved as safe. Consult your BMW Sports Activity Vehicle center for details. BMW recommends only using these approved, narrow-link snow chains. Use is only permitted in pairs on the rear wheels with the following tire sizes:

X5 4.8is: 255/55 R 18


All other models: 235/65 R 17

Observe the manufacturer's instructions when installing snow chains.

Do not exceed a maximum speed of 30 mph/50 km/h.



After mounting snow chains, do not initialize the Flat Tire Monitor. When you are driving with snow chains, it can be beneficial to switch off DSC briefly, refer to page [96](#). ◀



### Unlocking

Pull the lever located under the left side of the instrument panel.




Never attempt to perform any service or repair operations on your vehicle without the required professional technical training. If you are not familiar with the regulations to be observed, only have work on your vehicle carried out by a BMW Sports Activity Vehicle center or a workshop that uses personnel trained in accordance with BMW requirements. If this work is not carried out properly, there is a danger of subsequent damage and related safety hazards. ◀



### Opening

Pull the release handle and open the hood.

[CarManuals2.com](http://CarManuals2.com)




### Closing

Allow the hood to fall from a height of about 12 in/30 cm so that it audibly engages.



Observe the same precautions that apply to all closing operations by ensuring that the hood's travel range is clear and unobstructed before allowing the hood to fall into position. If it is determined that the hood is not completely closed while driving, stop immediately and close it securely. ◀



1 Engine oil dipstick [150](#)

2 Brake fluid reservoir, located  
beneath the microfilter cover [153](#)

3 Auxiliary terminal for jump  
starting [171](#)

4 Coolant expansion tank [152](#)

5 Engine oil filler neck [150](#)

6 Reservoir for windshield and  
headlamp washer system [150](#)



### Windshield and headlamp washer system

Approximate capacity is 8.2 US quarts/ 7.8 liters.

Fill with water and – if required – with the addition of a washer antifreeze, according to manufacturer's recommendations.




We recommend that you mix the washer fluid before adding it to the reservoir. ◀



Antifreeze agent for the washer systems is inflammable. For this reason, keep it away from sources of flame and store it only in its original containers. Store it so that it is inaccessible to children. Comply with the instructions on the containers. ◀

## Engine oil



### Checking oil level


Oil consumption depends on driving style and operating conditions.

1. With the engine at operating temperature, i.e. after at least 6 miles/10 km of continuous driving, park the vehicle in a horizontal position
2. Switch off the engine
3. After approx. 5 minutes, pull the dipstick out and wipe it off with a clean lint-free cloth, paper towel, or similar material

4. Slide the dipstick carefully all the way into the dipstick tube and pull it out again.

The oil level should be in between the two marks on the dipstick

5. Slide the dipstick all the way into the dipstick tube again.




The oil volume between the two marks on the dipstick corresponds to approx. 1.1 US quarts/1 liter.

**⚠** Do not fill beyond the upper mark on the dipstick. Excess oil will damage the engine. ◀

X5 4.8is:

With a very sporty driving style, the engine oil level should be at the upper mark on the dipstick.



## Adding engine oil

Wait until the level has dropped to just above the lower mark on the dipstick before adding oil.

**⚠** Add oil within the next 30 miles/ 50 km, otherwise, the engine could be damaged. ◀

**⚠** Always store oils, grease and similar materials so that they are inaccessible to children. Comply with warning labels and information on containers. ◀

Oil change:

Have oil changed only by your BMW Sports Activity Vehicle center or by a repair shop that works according to

BMW guidelines with appropriately trained personnel.

## Specified engine oils

The quality of the engine oil selected has critical significance for the operation and service life of an engine. Based on extensive testing, BMW has approved only certain engine oils.

Use only approved BMW High Performance Synthetic Oil.

If you are unable to obtain BMW High Performance Synthetic Oil, you can add small amounts of synthetic oil in between oil changes. Use only oils with the API SH specification or higher.

**▶** Ask your BMW Sports Activity Vehicle center for details concerning the specific BMW High Performance Synthetic Oil or synthetic oils which have been approved. ◀

You can also call BMW of North America at 1-800-831-1117 or visit this website: [www.bmwusa.com](http://www.bmwusa.com) to obtain this information.

**⚠** BMW engines are designed to operate without additives, and their use could even lead to damage in some cases. ◀

**Viscosity ratings**

Viscosity is the oil flow rating as established in SAE classes.

The selection of the correct SAE class depends on the climatic conditions in the area where you typically drive your BMW.

 Approved oils are in SAE classes 5W-40 and 5W-30. ◀

These oils may be used for driving in all ambient temperatures.

**Coolant**

 Do not open the cooling system when the engine is hot. Escaping coolant can cause burns. ◀

Coolant is comprised of water and coolant additive. Not all commercially available additives are suitable for your BMW. Your BMW Sports Activity Vehicle center knows which additives are suitable.

 Use only suitable additives, otherwise you could damage your engine. The additives can be harmful to your health. ◀

 Always observe all applicable environmental rules and regulations when disposing of coolant additives. ◀

**Checking coolant level**

1. The engine must be at ambient temperature
2. Start by turning the cap of the expansion tank counterclockwise. Pause to allow any accumulated pressure to escape, then open
3. The coolant level is correct when the end of the red float is aligned with the upper edge of the filler opening, refer to the arrow in the illustration, or max. 0.8 in/2 cm higher, i. e. up to the mark on the float, refer also to the schematic diagram, next to the cap

4. When necessary, slowly add coolant until the correct level is reached; do not overfill
5. Close the cap and tighten snugly
6. Have the cause of the coolant loss corrected as soon as possible.

### Brake fluid level



If the warning lamp lights up or the message CHECK BRAKE FLUID appears in the Check Control: stop immediately.



The brake fluid in the reservoir has fallen to below the minimum level.

### Add brake fluid

The brake fluid reservoir is located under the microfilter housing trim panel on the driver's side of the vehicle. For adding brake fluid or for determining and correcting the cause of brake fluid loss, consult your BMW Sports Activity Vehicle center. Your BMW Sports Activity Vehicle center is familiar with the specifications for factory-approved DOT 4 brake fluids.

Brake fluid loss may result in extended brake pedal travel. For this situation, refer to the notes on page [140](#).



Brake fluid is hygroscopic, that is, it absorbs moisture from the air over time.

In order to ensure the safety and reliability of the brake system, have the brake fluid changed every two years by a BMW Sports Activity Vehicle center. Refer also to the Service and Warranty Information Booklet for US models or the Warranty and Service Guide Booklet for Canadian models.

Brake fluid is toxic and also damages vehicle paintwork. Always store these agents in tightly-closed original containers kept well away from the reach of children.

Do not spill the fluid and do not refill the brake fluid reservoir to beyond the MAX mark. The brake fluid could ignite upon contact with hot engine parts and cause serious burns. ◀



Always observe all applicable environmental rules and regulations when disposing of used brake fluid. ◀



The BMW Maintenance System helps maintain the road and driving safety of your BMW.

Please keep in mind that regular maintenance is not only necessary for the safety of your vehicle, but also plays a significant role in maintaining the resale value of the vehicle.

### Service Interval Display

Conventional systems rely solely on distance traveled to determine when service is due. The BMW Maintenance System, on the other hand, began many years ago to take the actual conditions under which the vehicle is driven into consideration. After all, different drivers can accumulate mileage in very different ways.

From the point of view of maintenance, 62,000 miles/100,000 km accumulated in short-distance urban driving are not the equivalent of the same distance covered at moderate speeds in long-distance highway travel.

The BMW Maintenance System includes the Engine Oil Service and Inspections I and II.

Determining the maintenance intervals according to the actual loads on the vehicle covers every kind of operating situation. However, even those who drive only short distances, significantly less than 6,000 miles/10,000 km annually, should have the engine oil changed at least every 2 years since oil deteriorates over time, regardless of use.

### Service and Warranty Information Booklet for US models/ Warranty and Service Guide Booklet for Canadian models

For additional information on maintenance intervals and procedures, please refer to the Service and Warranty Information Booklet for US models or the Warranty and Service Guide Booklet for Canadian models.

[CarManuals2.com](http://CarManuals2.com)

As a precaution against corrosion, it is advisable to have the body checked for damage from rocks or gravel at the same time, depending upon operating conditions.


 Have your BMW Sports Activity Vehicle center do the maintenance and repair.

Be sure that all maintenance work is confirmed in the Service and Warranty Information Booklet for US models or the Warranty and Service Guide Booklet for Canadian models.

These entries will constitute your proof that the vehicle has received regular maintenance. They are also required for warranty claims. ◀

### Car care

For all information on this subject, refer to the Caring for your vehicle brochure.



The interface socket for the Onboard Diagnostic is located on the left of the driver's side at the bottom of the instrument panel and under a cover. The cover has the letters OBD on it.

The purpose of the OBD system is to ensure proper operation of the emission control system for the vehicle's lifetime. The system monitors emission-related components and systems for deterioration and malfunction.



An illuminated indicator lamp informs you of the need for service, not of the need to stop the vehicle. However, the systems should be checked by your BMW Sports Activity Vehicle center at the earliest possible opportunity.



Indication of the above-described malfunction in Canadian models.

Under certain conditions, the indicator lamp will blink or flash. This indicates a rather severe level of engine misfire. When this occurs, you should reduce speed and consult the nearest BMW Sports Activity Vehicle center as soon as possible. Severe engine misfire over only a short period of time can seriously damage emission control components, especially the catalytic converter.



When the filler cap is not properly tightened, the OBD system can detect the vapor leak and the indicator will light up. If the filler cap is subsequently tightened, the indicator lamp should extinguish within a few days. ◀

## Event Data Recorders

Your vehicle may be equipped with one or more sensing and diagnostic modules or a recording device capable of recording or transmitting certain vehicle data or information. In addition, if you have a Subscription Service Agreement for the BMW Assist system, certain vehicle information may be transmitted or recorded in order to provide such services.



[CarManuals2.com](http://CarManuals2.com)

## Overview

## Controls and features

## Operation, maintenance

## Owner service procedures

## Technical data

## Index

Overview

Controls

Maintenance


Repairs

Data

Index



CarManuals2.com



Under the cargo floor cover in a pocket.

## Windshield wiper blades




### Front

1. Move the wiper to a fold-out position, refer to page 71
2. Lift the wiper arm and press the securing spring, refer to arrow
3. Pull the wiper blade off toward the wiper arm
4. Insert the new blade and snap it into place.



Fold the wipers back down onto the windshield before you turn the ignition key to position 1 or 2 again. If you do not, they could be damaged.◀



### Rear

1. Hold the wiper blade on the window and remove/unclip the wiper arm at the articulated joint, refer to arrow
2. Insert a new wiper blade and press it on/clip it into the wiper arm.



Use only wiper blades approved by BMW.◀


## Lamps and bulbs

The lamps and bulbs make essential contributions to the safety of your vehicle. For this reason, follow the instructions below carefully when replacing a bulb. If you are not familiar with any of the procedures, consult your BMW Sports Activity Vehicle center.

 Never touch the glass on new bulbs with your bare fingers, as even minute amounts of contamination will burn into the bulb's surface and reduce its service life. Use a clean cloth, paper napkin, or a similar material, or hold the bulb by its metallic base. ◀

A replacement bulb set is available from your BMW Sports Activity Vehicle center.

 To prevent short circuits, before working on any electrical system, equipment or accessory you should always switch it off and disconnect the cable from the battery's negative terminal before starting. To avoid possible injury or equipment damage when replacing bulbs, observe any instructions provided by the bulb manufacturer. ◀




### Releasing lamp cover

The illustration shows the right-hand side of the engine compartment.

- 1 Halogen low beams  
Turn cover cap to left, refer to arrow
- 2 High beams and parking lamps  
Press tab downward, refer to arrow

 For checking and adjusting head-lamp aim, please contact your BMW Sports Activity Vehicle center. ◀




### 1 Halogen low beams

H7 bulb, 55 watts

 The bulb is pressurized. Therefore, wear safety glasses and protective gloves. Failure to comply with this precaution could lead to injury if the bulb is accidentally damaged during replacement. ◀

1. Remove the cover
2. Turn the bulb holder to the left and remove
3. Pull bulb out of bulb holder by base and replace.



## 2 Halogen high beams

H1 bulb, 55 watts



The bulb is pressurized. Therefore, wear safety glasses and protective gloves. Failure to comply with this precaution could lead to injury if the bulb is accidentally damaged during replacement. ◀

1. Remove the cover
2. Disconnect the plug
3. Unhook wire spring
4. Remove and replace the bulb.

## 3 Parking lamps and roadside parking lamps

10 watt bulb: H 10 W

1. Remove the cover
2. Disconnect the plug
3. Turn reflector module with bulb to left and remove
4. Replace module with bulb.

## Xenon lamps\*

The operating life of these lamp units is extremely long and the likelihood of failure very low, provided that they are not switched on and off a very great number of times. If one of these bulbs should nevertheless fail, it is possible to continue driving with great caution using the fog lamps, provided traffic laws in your area do not prohibit this.




To avoid risk of potentially fatal injuries: owing to the extremely high voltages at which these units operate, service work should always be entrusted to qualified personnel. ◀

## Front turn signals/side-marker lamps

S 8 bulb

Please contact a BMW Sports Activity Vehicle center in case of a malfunction.



## Side turn signals

5 watt bulb: W 5 W or WY 5 W\*

1. Use finger pressure against the rear end of the lamp, refer to arrow, to press it forward for removal
2. Apply gentle pressure to the bulb while turning it to the left and pull it out
3. Replace the bulb.




## Front fog lamps

H11 bulb, 55 watts

**!** The bulb is pressurized. Therefore, wear safety glasses and protective gloves. Failure to comply with this precaution could lead to injury if the bulb is accidentally damaged during replacement. ◀

1. Pull the cover in front of the fog lamp forward
2. Loosen the two screws, refer to arrows, and remove the fog lamp. When pulling out, overcome initial resistance and turn the headlamp somewhat to the left
3. Pull the cable connector off the bulb
4. Turn the bulb to the left and remove


5. Insert a new bulb in the headlamp and turn it as far to the right as possible
6. Connect the plug connector to the bulb, ensuring proper engagement.



## Tail lamps


21 watt bulbs: P 21 W or PY 21 W\*, recommendation: BMW special bulbs with neutral coloration

- 1 Turn signal
- 2 Rear lamp/side marker lamp
- 3 Backup lamp
- 4 Brake lamp
- 5 Reflector



#### Lamps in the side panel:

1. Open the cover in the side panel
2. Lift the side panel if necessary
3. Apply gentle pressure to the bulb holder while turning it to the left for removal and replacement
4. Remove the bulb.




#### Lamps in the tailgate:

1. Unclip the trim panel in the tailgate with a screwdriver
2. Apply gentle pressure to the bulb holder while turning it to the left for removal and replacement
3. Remove the bulb.

#### Center brake lamp

LED strip in the rear spoiler: please contact a BMW Sports Activity Vehicle center in case of a malfunction.



#### License plate lamps

5 Watt bulb

1. Press the lamp out to the side with a screwdriver
2. Remove the lamp and replace the bulb.

## Lamps and bulbs

### LEDs light-emitting diodes

Light-emitting diodes installed behind translucent lenses serve as the light source for many of the controls and displays in your vehicle. The concept behind their operation is related to that employed for lasers.



Do not remove the covers, and never stare into the unfiltered light several hours, as irritation of the iris could result. ◀

## Changing a tire



Safety precautions to observe in the event of a flat and during all tire changes:

Park the vehicle as far as possible from passing traffic. Park on a firm, flat, surface. Switch on the hazard warning flashers.

Turn the steering wheel to the straight-ahead position, remove the key and engage the steering lock. Shift into 1st or reverse, selector lever in Park with automatic transmission, and engage the handbrake.




All passengers should be outside the vehicle and well away from your immediate working area, behind a guardrail, for instance.

If a warning triangle or portable hazard warning lamp is required, set it up on the roadside at an appropriate distance from the rear of the vehicle. Comply with all safety guidelines and regulations.

Change the wheel only on a level, firm surface which is not slippery. The vehicle or the jack could slip to the side if you attempt to raise the vehicle on a soft or slippery surface such as snow, ice, tiles, etc.

Position the jack on a firm support surface.

Do not place wooden blocks or similar objects under the jack. If this is done, the jack might not be able to reach its full support capacity because of the limited height. To avoid serious or fatal injury: never lie under the vehicle, and never start the engine while it is supported by the jack. ◀




### What you will need

In order to avoid rattling noises later, note the position of the tools when you remove them and return them to their original position when you are through using them.

- ▷ Two wedges – wheel chocks  
Open the liftgate and tailgate.  
Raise floor cover or pull-out cargo floor, refer to pages [129](#), [130](#).  
Remove the chocks, refer to arrow, next to the spare tire

- ▷ Lug wrench  
Located beside the spare wheel


- ▷ Handle for the jack  
Remove from its holder



## ▷ Jack

Remove the rubber band from the holder, refer to arrow, and take out the jack.

When you have completed work, screw the jack all the way back down, remove the handle and insert it into its holder.



## Spare wheel

1. Loosen the wing nut 1
2. Remove the plate 2 to the side
3. Unscrew the threaded rod 3 completely.



## Removal aid for spare wheel

By using this device, you do not have to lift the spare wheel out of the recess by hand.

Its task is to help you to move the wheel onto the tailgate, from where you can easily lift it off.


1. Close the tailgate again
2. Grasp the handle of the removal aid behind the spare wheel with both hands and pull upward over the tailgate, refer to arrow



3. Hook both buckles into the latch of the tailgate, refer to arrow; the tailgate is released




4. Remove the support rod from the bracket



5. Press the tailgate down and hold it there. The spare wheel is now pulled by means of the removal aid onto the tailgate



Hold the tailgate in the opened position and do not allow it to retract sharply upward. If you do so, there is a risk of personal injury and vehicle damage. ◀




6. Insert the support rod in the tailgate lock and press down until it engages, refer to arrow 1; then lock hook of rod in striker, refer to arrow 2

**⚠** Be sure that the support rod is locked firmly in place. If you fail to do so, the tailgate could move upward quickly and cause personal injury and vehicle damage.◀

7. You can now release the locked tailgate and take the spare wheel down from the tailgate. It is recommended that you leave the tailgate locked into place until you have completed the wheel change and placed the wheel with the defective tire into the removal aid.

## Procedure

1. Read carefully and comply with the safety precautions on page 163
2. Secure the vehicle to prevent it from rolling:  
Place the wedges – chocks – behind the wheels on the side opposite the side you are lifting. If the vehicle is parked on a downward slope, place the wedges securely in front of the wheels. If the wheel must be changed on a surface with a more severe slope, take additional precautions to secure the vehicle from rolling
3. Loosen the lug bolts 1/2-turn
4. Insert the jack handle into the jack, refer to the illustration in the next column



5. Position the jack at the jacking point closest to the flat tire so that the jack base is vertically below the jacking point and the entire surface of the head of the jack will move into the square recess of the jacking point, refer to the illustration detail, when the jack is cranked
6. Jack the vehicle up until the wheel you are changing is raised from the ground
7. Unscrew the lug bolts and remove the wheel
8. Remove accumulations of mud or dirt from the mounting surfaces of the wheel and hub. Clean the lug bolts
9. Position the spare wheel. Secure the wheel by turning at least two lug bolts into opposite bolt holes

10. Screw in the remaining lug bolts. Tighten all the bolts securely in a diagonal pattern
11. Lower the jack and remove it from beneath the vehicle
12. Tighten the lug bolts in a diagonal pattern
13. Check and correct the tire inflation pressure at the earliest opportunity. After mounting the spare wheel or correcting the inflation pressure, reinitialize the Flat Tire Monitor, refer to page 102.

Protect valve stems and valves from dirt using screw-on valve stem caps. Dirt in the valve stems frequently leads to slow leaks.

 The vehicle jack is designed for changing wheels only. Do not attempt to raise another vehicle model with it or to raise any load of any kind. To do so could cause accidents and personal injury. To ensure safety, always have the lug bolts checked with a calibrated torque wrench as soon as possible to ensure that they are tightened to the specified torque. The tightening torque is 101 ft-lb/140 Nm. ◀

Store the wheel and the tools in the order opposite that for removal.

 Before removing the support rod, be sure that the tailgate is held down firmly. If you fail to do so, it could retract sharply upward and cause personal injury and vehicle damage. After you remove the rod, close the tailgate carefully. Continue to hold it firmly until it is completely closed. ◀

If light-alloy wheels other than Genuine BMW light-alloy wheels have been mounted, it may be necessary to use different lug bolts for those wheels.

Replace the defective tire as soon as possible and have the new wheel/tire balanced.

### **Driving with spare wheel**

 Do not exceed a speed of 130 mph/210 km/h, otherwise tire damage could lead to accidents. ◀

 With certain wheel-and-tire combinations the size of the spare wheel differs from that of the other wheels. To restore the original state, the normal wheel should be remounted as soon as possible. ◀

## **Vehicle battery**

 Battery posts, terminals and related accessories contain lead and lead compounds. Wash hands after handling. ◀

### **Battery care**

The battery is maintenance-free, that is, the original electrolyte will normally last for the service life of the battery under moderate climatic conditions. Your BMW Sports Activity Vehicle center will be glad to advise in all matters concerning the battery.

### **Charging battery**

Only charge the battery in the vehicle via the terminals in the engine compartment with the engine off. For correct connections, refer to Jump starting on page 171.

### **Disposal**

 Following replacement, have old batteries disposed of by your BMW Sports Activity Vehicle center or hand them in to a recycling center. Maintain the battery in an upright position for transport and storage. Always restrain the battery to prevent it from tipping over during transport. ◀

## Power failure


Following a temporary power failure, e.g. in the case of a flat battery, some equipment is subject to restricted use and must be reinitialized. Individual settings are also lost and must be updated again:

- ▷ Seat, mirror and steering wheel memory  
The positions must be newly stored, refer to page 50
- ▷ Time and date  
Have to be updated, refer to page 85
- ▷ Activation time for independent ventilation  
Has to be updated again, refer to page 87.



## In glove compartment

Open the fuse cover in the glove compartment by the indentations on the right and left.



## In cargo area

Open the right cover by pulling the handle.

 Never attempt to repair a blown fuse, and do not replace a defective fuse with a substitute of another color or amperage rating, as this could lead to a circuit overload, ultimately resulting in a fire in the vehicle. ◀

The Roadside Assistance of the BMW Group offers you assistance in the event of a breakdown around the clock, also at weekends and on public holidays.

The phone numbers of the Roadside Assistance control center in your home country can be found in the BMW Dealer Directory.

In the case of vehicles with the corresponding equipment, you can use buttons in the headlining to contact Roadside Assistance or initiate an emergency call.

When the emergency call is initiated, a telephone connection with the BMW Assist response center is established.

In vehicles with activated BMW Assist, if the current position of your vehicle can be determined, it is transmitted to the BMW Assist response center.

The condition for initiating an emergency call or contacting Roadside Assistance:

- ▷ Ignition key in position 1
- ▷ The car phone is logged on to a mobile telephone network
- ▷ The emergency call system is operable.



- 1 Initiating an emergency call
- 2 Establishing contact to Roadside Assistance

### Initiating an emergency call\*

Press button 1 for at least 2 seconds. The indicator lamp in the button lights up. As soon as the telephone connection to the BMW Assist response center has been established, the indicator lamp flashes. If the indicator lamp flashes, but you are unable to hear the response center, you can still be heard by the response center.



For technical reasons, the emergency call cannot be guaranteed under the most unfavorable conditions. ◀

Under certain conditions, an emergency call is initiated automatically immediately after a severe accident. The automatic emergency call is not affected by the button being pressed.

### Roadside Assistance\*

Press button 2 for at least 2 seconds.

With the BMW Assist activated, the current location of your vehicle will be transmitted in the specific country.

# Jump starting

When your battery is discharged you can use two jumper cables to start your vehicle with power from the battery in a second vehicle. You can also use the same method to help start another vehicle. Use only jumper cables with fully-insulated clamp handles.

 To avoid the risk of potentially fatal injury, always avoid all contact with electrical components while the engine is running. Carefully observe the following instructions to avoid personal injury and/or damage to one or both vehicles. ◀

## Preparing

1. Check whether the battery of the other vehicle has a voltage of 12 Volts and approximately the same capacitance in Ah. This information can be found on the battery
2. Switch off the engine of the support vehicle
3. Switch off any electrical systems and components in both vehicles.

 Ensure that no contact exists between the bodywork on the two vehicles, otherwise there is a danger of short circuits. ◀


## Connecting jumper cables

 To avoid personal injury from sparks, always observe this sequence when connecting jumper cables. ◀



On your BMW the so-called jump-start connection point in the engine compartment acts as the battery positive terminal, also refer to the engine compartment overview on page 149. The cover cap is marked with +.

1. Fold up the cap of the BMW auxiliary terminal for jump starting, refer to arrow
2. Connect one terminal clamp of the positive/+ jumper cable to the positive terminal of the battery or an auxiliary terminal for jump starting of the vehicle providing starting assistance
3. Connect the second terminal clamp of the positive/+ jumper cable to the positive terminal of the battery or to an auxiliary terminal for jump starting of the vehicle to be started



Your BMW is equipped with a special nut on the left side panel as a body ground or negative terminal, refer to arrow in illustration.

4. Attach one end of the negative/– jumper cable to the negative terminal of the battery or to an engine or body ground of the vehicle providing assistance
5. Connect the second terminal clamp of the negative/– jumper cable to the negative terminal of the battery or to the engine or body ground of the vehicle to be started.

### Starting engine

1. Start the engine on the support vehicle and allow it to run for several minutes at a fast idle
2. Start the engine on the other vehicle in the usual way.

If the first start attempt is not successful, wait a few minutes before another attempt in order to allow the discharged battery to recharge

3. Let the engines run for a few minutes
4. Disconnect the jumper cables by reversing the connection sequence.

Depending on the cause of the fault, have the battery recharged by your BMW Sports Activity Vehicle center.



Never use spray fluids to start the engine. ◀


## Tow-starting and towing

### Using tow fitting

The screw-in tow fitting is stored beneath the cargo floor cover. Carry it with you at all times. It can be screwed in at the front or rear of the vehicle.




To prevent damage to the tow fitting and the vehicle, observe the following: only use the tow fitting that comes with the vehicle and screw it in as far as it will go. Use the tow fitting for towing only on the roadway. Avoid lateral loading of the tow fitting, e.g. do not lift the vehicle by the tow fitting. ◀



## Access to screw thread

Front:

Use a screwdriver to press the right or left cover out, refer to arrows.



Rear:

Pull the cover off.

## Being towed

 Make sure that the ignition key is in position 1, otherwise the steering lock could engage and it would not be possible to steer the vehicle. When the engine is stopped, there is no power assist. This requires increased braking and steering effort. ◀

Switch on the hazard warning flashers depending on the local regulations. If the electrical system fails, mark the vehicle to be towed, e.g. with a sign or warning triangle in the rear window.

[CarManuals2.com](http://CarManuals2.com)

 Do not exceed a towing speed of 30 mph/50 km/h and a towing distance of 95 miles/150 km, as otherwise the automatic transmission may be damaged. ◀

Vehicles with manual transmission:  
Gearshift lever in idle position

Vehicles with automatic transmission:  
Selector lever in N.

## Towing methods

In some countries, towing with a tow bar or rope on public roads is not permitted.

Familiarize yourself with all regulations on towing in the respective country.

With tow bar:

 The towing vehicle may not be lighter than the vehicle to be towed, as otherwise handling will be uncontrollable. ◀

The tow fitting of both vehicles should be on the same side. If an angled position of the bar cannot be avoided, observe the following:

## 174 Tow-starting and towing


- ▷ The freedom of movement is restricted during cornering
- ▷ The angled position of the tow bar creates lateral forces.

 Only secure the tow bar on the tow fittings. Otherwise, damage could result on other vehicle component. ◀

With tow-rope:

When starting off in the towing vehicle, make sure that the tow-rope is taut.

 Use nylon ropes or nylon straps for towing, and avoid all too sudden jerking movements. Only secure tow-ropes on the tow fitting. Otherwise, damage could result on other vehicle component. ◀



With tow truck:

 Do not tow the X5 with the front or rear axle raised individually, as otherwise the wheels may block and the transfer case may be damaged. ◀

The X5 may only be transported on a truck bed.

### Tow-starting

 Do not tow-start vehicles with an automatic transmission. For information on jump starting, refer to page 171. ◀

Only tow-start vehicles with a catalytic converter with the engine cold. It is better to jump start the engine, refer to page 171.

1. Switch on the hazard warning flashers and observe local regulations
2. Turn the ignition key to position 2
3. Engage the 3rd gear
4. Tow-start with the clutch pedal completely depressed and slowly release the clutch pedal. After the engine starts, immediately depress the clutch pedal again completely
5. Stop at a suitable location, remove the tow bar or rope and switch off the hazard warning flashers
6. Have the vehicle checked.

 Do not activate the HDC Hill Descent Control during tow-starting, refer to page 97. ◀

CarManuals2.com

Index


Data

Repairs

Maintenance


Controls

Overview



## Overview

CarManuals2.com



Controls and features

Operation, maintenance

Owner service procedures

Technical data

Index

Overview

Controls

Maintenance

Repairs


Data

Index

## 178 Engine specifications

|                                   |                       | X5 3.0i          | X5 4.4i          | X5 4.8is         |
|-----------------------------------|-----------------------|------------------|------------------|------------------|
| Displacement                      | cu in/cm <sup>3</sup> | 181.8/2,979      | 268.4/4,398      | 292.9/4,799      |
| Number of cylinders               |                       | 6                | 8                | 8                |
| Maximum output<br>at engine speed | hp<br>rpm             | 225<br>5,900     | 315<br>5,400     | 355<br>6,200     |
| Maximum torque<br>at engine speed | lb-ft/Nm<br>rpm       | 214/290<br>3,500 | 324/440<br>3,600 | 369/500<br>3,500 |

An engine performance test is authorized only on an appropriate chassis dynamometer.



All dimensions are given in inches/mm. Height: with level control system: 67.2/1,707; without level control system: 67.5/1,715. Height with roof-mounted luggage rack: with level control system: 68.5/1,740; without level control system: 68.9/1,750. Track width: X5 3.0i: 62.0/1,576; X5 4.8i: front 61.7/1,566, rear 62.8/1,596.

Min. turning circle dia.: 39.7 ft/12.1 meters.

Online Edition for Part No. 01 41 0 158 701 - © 10/04 BMW AG

|                                                                          |         | X5 3.0i                                                                    | X5 4.4i     | X5 4.8is    |
|--------------------------------------------------------------------------|---------|----------------------------------------------------------------------------|-------------|-------------|
| Curb weight                                                              |         |                                                                            |             |             |
| with manual transmission                                                 | lbs./kg | 4,652/2,110                                                                | –           | –           |
| with automatic transmission                                              | lbs./kg | 4,696/2,130                                                                | 4,927/2,235 | 5,016/2275  |
| Approved gross vehicle weight                                            |         |                                                                            |             |             |
| with manual transmission                                                 | lbs./kg | 6,008/2,725                                                                | –           | –           |
| with automatic transmission                                              | lbs./kg | 6,008/2,725                                                                | 6,008/2,725 | 6,008/2,725 |
| Load                                                                     |         |                                                                            |             |             |
| with manual transmission                                                 | lbs./kg | 1,356/615                                                                  | –           | –           |
| with automatic transmission                                              | lbs./kg | 1,312/595                                                                  | 1,080/490   | 992/450     |
| Approved front axle load                                                 | lbs./kg | 2,712/1,230                                                                | 2,789/1,265 | 2,789/1,265 |
| Approved rear axle load                                                  | lbs./kg | 3,307/1,500                                                                | 3,307/1,500 | 3,307/1,500 |
| Approved roof load capacity                                              | lbs./kg | 220/100                                                                    |             |             |
| Never exceed either the approved axle loads or the gross vehicle weight. |         |                                                                            |             |             |
| Cargo area capacity                                                      | cu ft/l | 16.4 – 54.4/465 – 1,540, according to DIN<br>69.04/1,955, according to SAE |             |             |

|                                                      |               |                         | Notes                                       |
|------------------------------------------------------|---------------|-------------------------|---------------------------------------------|
| Fuel tank of that reserve                            | gal./liters   | approx. 24.6/approx. 93 | Fuel specification: page <a href="#">26</a> |
| X5 3.0i                                              | gal./liters   | approx. 2.0/approx. 8   |                                             |
| X5 4.4i, 4.8is                                       | gal./liters   | approx. 2.5/approx. 10  |                                             |
| Windshield washer system with headlamp washer system | quarts/liters | approx. 8.2/approx. 7.8 | For details: page <a href="#">150</a>       |
| Engine with oil filter change                        |               |                         | BMW High Performance Synthetic Oil.         |
| X5 3.0i                                              | quarts/liters | 8.0/7.5                 |                                             |
| X5 4.4i, 4.8is                                       | quarts/liters | 8.5/8.0                 | For details: page <a href="#">151</a>       |



[CarManuals2.com](http://CarManuals2.com)



Overview

Controls and features

Operation, maintenance

Owner service procedures

Technical data

Index

Overview

Controls

Maintenance

Repairs

Data

Index

# Everything from A to Z

## A

- Ability to climb, refer to
  - Driving on poor roads [138](#)
- ABS Antilock Brake System [94](#)
  - warning lamp [20](#)
- Accessories, refer to For your own safety [9](#)
- Accident, refer to
  - Emergency call [170](#)
  - Roadside Assistance [170](#)
- Activated-charcoal filter [115](#)
- Adaptive Head Light [104](#)
- Adjusting cooling capacity of rear climate control [115](#)
- Adjusting seats [44](#)
  - electric [46](#)
  - electric comfort seat [46](#)
  - mechanical [45](#)
  - mechanical sports seat [45](#)
- Air circulation, refer to
  - Recirculated-air mode [108](#)
- Air conditioner [107](#)
- Air conditioning
  - air conditioner [108](#)
  - automatic climate control [113](#)
- Air distribution
  - air conditioner [108](#)
  - automatic climate control [112](#)
  - individual [112](#)
- Air outlets, refer to
  - Ventilation [109](#), [114](#)
- Air pressure, refer to Tire inflation pressure [141](#)
- Air recirculation, refer to
  - Automatic recirculated-air control AUC [113](#)
- Air supply
  - air conditioner [108](#)
  - automatic climate control [112](#)
  - rear climate control [114](#)
- Air vents, refer to
  - Ventilation [107](#), [110](#)
- Air, drying, refer to Air conditioning [108](#), [113](#)
- Airbags [57](#)
  - sitting safely [43](#)
  - warning lamp [21](#)
- Airing, refer to
  - Ventilation [109](#), [114](#)
- Alarm system [38](#)
  - avoiding unintentional alarms [39](#)
- All-season tires, refer to
  - Special features of winter tires [146](#)
- Antenna, refer to Caring for your vehicle brochure [74](#)
- Antifreeze
  - coolant [152](#)
  - washer fluid [150](#)
- Antilock Brake System ABS [94](#)
  - warning lamp [20](#)
- Anti-theft alarm system [30](#)
  - refer to Alarm system [38](#)
- Anti-trapping mechanism
  - panorama glass sunroof [42](#)
  - power windows [40](#)
- Armrest, refer to Storage compartments [120](#)
- Artificial leather, refer to Caring for your vehicle brochure
- Artificial wood trim, refer to Caring for your vehicle brochure
- Ashtray
  - front [122](#)
  - rear [122](#)
- AUC Automatic recirculated-air control [113](#)
- AUTO program, refer to
  - Automatic air distribution and air flow [112](#)
- Automatic
  - air distribution [112](#)
  - air supply [112](#)
  - cruise control [74](#)
  - headlamp control [103](#)
  - steering wheel adjustment [53](#)
- Automatic car wash, refer to Caring for your vehicle brochure
- Automatic climate control [110](#)
- Automatic cruise control [74](#)
- Automatic curb monitor [51](#)
- Automatic headlamp control [103](#)
- Automatic rear window washer [73](#)
- Automatic recirculated-air control AUC [113](#)
- Automatic Soft Close function, liftgate [36](#)
- Automatic speed reduction for descents, refer to HDC Hill Descent Control [97](#)
- Automatic transmission with Steptronic [67](#)
  - interlock [64](#)
  - selector lever interlock [68](#)
  - shiftlock [68](#)
  - towing [173](#)
  - tow-starting [173](#)
  - warning lamp [20](#), [21](#)
- Average fuel consumption [83](#), [90](#)
- Average speed [83](#), [91](#)
- Avoiding alarms [39](#)
- Axle loads, refer to Weights [180](#)

- B**
- Backrests, refer to Adjusting seats [45, 46](#)
  - Backup lamps [67](#)
    - replacing bulbs [161](#)
  - Bandages, refer to First-aid kit [24](#)
  - Bar, towing [173](#)
  - Battery [168](#)
    - disposal [168](#)
    - indicator lamp [19](#)
    - jump starting [171](#)
    - power failure [169](#)
    - remote control [30](#)
  - Belts, refer to Safety belts [49](#)
  - Beverage holder, refer to Cup holders [121](#)
  - Black ice, refer to Ice warning [76](#)
  - Blower
    - air conditioner [108](#)
    - automatic climate control [112](#)
    - refer to Air supply [108, 112](#)
  - BMW High Performance Synthetic Oil [151](#)
  - BMW Maintenance System [154](#)
  - Bottle holder, refer to Cup holders [121](#)
  - Brake fluid [153](#)
    - adding [153](#)
    - level [153](#)
    - replacing [153](#)
    - warning lamp [19](#)
  - Brake Force Display [101](#)
  - Brake hydraulic system [140](#)
    - warning lamp [19, 20](#)
  - Brake lamps, replacing bulbs [161](#)
  - Brake pads [140](#)
    - breaking-in [136](#)
    - warning lamp [19, 21](#)
  - Brake rotors
    - brake system [140](#)
    - breaking-in [136](#)
  - Brake system
    - brake fluid [153](#)
    - brake fluid level [140, 153](#)
    - brake pads [140](#)
    - breaking-in [136](#)
    - disc brakes [140](#)
    - warning lamp [19](#)
  - Brake wear warning
    - brake pads [140](#)
    - indicator lamp [19, 21](#)
  - Brakes [140](#)
    - ABS [94](#)
    - brake fluid [153](#)
    - brake pads [140](#)
    - breaking-in [136](#)
    - handbrake [66](#)
    - indicator/warning lamp [19, 20](#)
  - Breakdown assistance, refer to Roadside Assistance [170](#)
  - Breakdown, Flat Tire Monitor [101](#)
  - Breaking-in [136](#)
  - Buttons on steering wheel [23](#)
- C**
- California Proposition 65 Warning [9](#)
  - Calling, refer to telephone Owner's Manual
  - Can holders, refer to Cup holders [121](#)
  - Capacities [181](#)
    - cargo area [180](#)
  - Car care, refer to Caring for your vehicle brochure
  - Car keys, refer to Keys [30](#)
  - Car radio, refer to Owner's Manual for Radio/Onboard Computer
  - Car telephone
    - preparation [119](#)
  - Car telephone, refer to separate Owner's Manual
  - Car vacuum cleaner, connecting, refer to Power socket [122](#)
  - Car wash, refer to Caring for your vehicle brochure
  - Car-care products, refer to Caring for your vehicle brochure
  - Care of paintwork, refer to Caring for your vehicle brochure
  - Care, refer to Caring for your vehicle brochure
  - Cargo area [126](#)
    - capacity [180](#)
    - cover, refer to Roll-up cover [126](#)
    - emergency operation, refer to Unlocking manually [35, 36](#)
    - floor cover [129](#)
    - increasing capacity [126](#)
    - lamps [106](#)
    - lid, refer to Liftgate/tailgate [35, 36](#)
    - opening, remote control [31](#)
  - Cargo floor, pull-out [130](#)

# Everything from A to Z

- Cargo loading [131](#)
- Cargo-area partition net [127](#)
- Caring for leather, refer to
  - Caring for your vehicle brochure
- Caring for the carpet, refer to
  - Caring for your vehicle brochure
- Cassette operation, refer to
  - Owner's Manual for Radio/Onboard Computer
- Catalytic converter, refer to
  - Hot exhaust system [137](#)
- CD changer, refer to Owner's Manual for Radio/Onboard Computer
- CD operation, refer to
  - Owner's Manual for Radio/Onboard Computer
- Center armrest, refer to
  - Storage compartments [120](#)
- Center brake lamp, replacing bulbs [162](#)
- Central locking system [30](#)  
interior [34](#)
- Changes, technical, refer to
  - For your own safety [9](#)
- Changing a wheel [163](#)
- Changing gears with automatic transmission with Steptronic [68](#)
- Changing tires [143](#)
- Charge-current indicator lamp [19](#)
- Charging battery [168](#)
- CHECK button [80](#)
- Check Control [80](#)
- Checking oil level [150](#)
- Child's seat, refer to Child-restraint systems [59](#)
- Child-restraint fixing system LATCH [62](#)
- Child-restraint systems [59](#)
- Child-safety locks [62](#)
- Chocks [164](#)
- Chrome parts, care, refer to
  - Caring for your vehicle brochure
- Chrome parts, refer to
  - Caring for your vehicle brochure
- Cigarette lighter [122](#), [123](#)
- Cigarette lighter socket, refer to Power socket [122](#)
- Circulation of air, refer to
  - Recirculated-air mode [108](#), [113](#)
- Cleaning rear window [73](#)
- Cleaning, vehicle, refer to
  - Caring for your vehicle brochure
- Climate control in the rear passenger area [114](#)
- Clock [85](#)
  - 12 or 24-hour mode [85](#)
  - hour signal [86](#)
  - setting [85](#)
  - setting time and date [85](#)
  - setting, also refer to Owner's Manual for Radio/Onboard Computer
- Closing
  - from inside [34](#)
  - from outside [31](#)
- Clothes hooks [121](#)
- Clutch [136](#)
  - breaking-in [136](#)
- Cockpit [14](#)
- Code
  - activating [91](#)
  - deactivating [92](#)
  - establishing [91](#)
- Cold starting, refer to
  - Starting engine [65](#)
- Combination of wheels/tires [146](#)
- Comfort seat [46](#)
- Comfort starting, refer to
  - Starting engine [65](#)
- Compact Disc operation, refer to Owner's Manual for Radio/Onboard Computer
- Compartments, refer to
  - Storage compartments [120](#)
- Compass interior rearview mirror [55](#)
- Computer [82](#), [88](#)
  - also refer to Owner's Manual for Onboard Computer
- Condensation, refer to
  - Air conditioning [108](#), [113](#)
- Connecting vacuum cleaner, refer to Power sockets [129](#)
- Consumption display, refer to Energy control [77](#)
- Consumption indicator, refer to Fuel page [78](#)
- Consumption, refer to
  - Average consumption [83](#)
  - Fuel consumption [90](#)
- Contents [4](#)
- Controls, refer to Cockpit [14](#)
- Convenience opening mode
  - panorama glass sunroof [31](#)
  - windows [31](#)
- Convenience operation
  - from outside [33](#)
  - panorama glass sunroof [33](#)
  - windows [33](#)

Coolant [152](#)  
     level [152](#)  
     temperature gage [79](#)  
     warning lamp [79](#)  
 Coolant temperature  
     gage [79](#)  
 Cooling, maximum [113](#)  
 Cooling, refer to  
     Air conditioning [108](#), [113](#)  
     Temperature [108](#), [112](#)  
 Copyright [4](#)  
 Cornering light, refer to  
     Adaptive Head Light [104](#)  
 Correct tires  
     wheel/tire  
         replacement [146](#)  
         winter tires [146](#)  
 Courtesy lighting [106](#)  
 Cruise control [74](#)  
     buttons on steering  
         wheel [23](#)  
     indicator lamp [22](#)  
 Cruising range [83](#), [90](#)  
 Cup holders [121](#)  
 Curb weight, refer to  
     Weights [180](#)  
 Current consumption, refer  
     to Energy control [77](#)  
 Cylinders, refer to Engine  
     data [178](#)

**D**  
 Dashboard lighting, refer to  
     Instrument lighting [105](#)  
 Dashboard, refer to  
     Cockpit [14](#)  
 Data, technical [178](#)  
     dimensions [179](#)  
     engine [178](#)  
     filling capacities [181](#)  
     weights [180](#)  
 Date  
     also refer to Owner's  
         Manual for Onboard  
         Computer  
         calling up [85](#)  
         changing [85](#)  
 Daytime driving lamps [103](#)  
 DBC Dynamic Brake  
     Control [94](#)  
     indicator lamp [21](#)  
 Deactivating the alarm in an  
     emergency [92](#)  
 Defective lamp [159](#)  
 Defrost position, refer to  
     Defrosting  
         windows [109](#), [112](#)  
 Defrosting  
     windows [109](#), [112](#)  
     air conditioner [109](#)  
     automatic climate  
         control [112](#)

Defrosting windows and  
     removing condensation  
     air conditioner [109](#)  
     automatic climate  
         control [112](#)  
 Defrosting windshield, refer  
     to Defrosting  
         windows [109](#), [112](#)  
 Digital clock [85](#)  
     also refer to Owner's  
         Manual for Onboard  
         Computer  
 Dimensions [179](#)  
 Dipstick, engine oil [150](#)  
 Directional indicators, refer  
     to Turn signals [70](#)  
 Disc brakes [140](#)  
 Displacement, refer to  
     Engine specifications [178](#)  
 Display lighting, refer to  
     Instrument lighting [105](#)  
 Display, refer to Instrument  
     cluster [15](#), [17](#), [18](#)  
 Disposal, vehicle battery [168](#)  
 Distance to destination [89](#)  
 Distance warning, refer to  
     PDC Park Distance  
         Control [93](#)  
 Divided rear seat backrest,  
     refer to Folding rear seat  
         back [126](#)  
 Door keys [30](#)

Door lock [33](#)  
 DOT Quality Grades [143](#)  
 Draft-free  
     ventilation [109](#), [114](#)  
 Driving lamps, refer to  
     Parking lamps/low  
         beams [103](#)  
 Driving notes  
     breaking-in [136](#)  
     driving hints [137](#), [138](#)  
 Driving on poor roads [138](#)  
 Driving stability control [95](#)  
 Driving your X5 [138](#)  
 Dry air, refer to Air  
     conditioning [108](#), [113](#)  
 DSC Dynamic Stability  
     Control [95](#)  
         warning lamp [22](#)  
 DVD changer, refer to  
     Owner's Manual for Radio/  
     Onboard Computer  
 Dynamic Brake Control  
     DBC [94](#)  
         indicator lamp [21](#)  
 Dynamic Stability Control  
     DSC [95](#)  
         warning lamp [22](#)

# Everything from A to Z

## E

EBV Electronic brake-force distribution [94](#)

Electric steering wheel adjustment [52](#)

Electrical malfunction automatic transmission with Steptronic [69](#)

door lock [33](#)

driver's door [33](#)

fuel filler door [24](#)

liftgate [35](#)

panorama glass sunroof [42](#)

tailgate [36](#)

Electronic brake-force distribution EBV [94](#)

Electronic Stability Program ESP, refer to DSC Dynamic Stability Control [95](#)

Emergency call [170](#)

Emergency operation, refer to Manual operation

driver's door [33](#)

fuel filler door [24](#)

liftgate [35](#)

panorama glass sunroof [42](#)

tailgate [36](#)

Emergency Service, refer to Roadside Assistance [170](#)

Energy control [77](#)

Energy-conscious driving, refer to Energy control [77](#)

Engine

breaking-in [136](#)

data [178](#)

electronic circuitry [22](#)

speed [77](#)

switching off [65](#)

Engine compartment [149](#)

Engine coolant [152](#)

Engine oil [150](#)

additives, refer to

Specified engine oils [151](#)

filling capacity [181](#)

indicator/warning lamp [19](#)

specified engine oils [151](#)

Engine oil level [150](#)

indicator/warning lamp [21](#)

Engine oil pressure,

indicator/warning lamp [19](#)

Engine oil thermometer [78](#)

Engine output, refer to

Engine specifications [178](#)

Engine specifications [178](#)

Engine speed, refer to

Engine specifications [178](#)

Environmentally friendly

driving, refer to Energy

control [77](#)

ESP Electronic Stability Program, refer to DSC Dynamic Stability Control [95](#)

Event Data Recorders [155](#)

Exhaust system [137](#)

Extended immobilizer function [91](#)

Exterior mirrors [54](#)

automatic dimming

feature [138](#)

folding in and out [54](#)

External air, automatic

climate control [113](#)

## F

Failure messages, refer to Check Control [80](#)

Failure of a current consumer [169](#)

False alarms, refer to Avoiding unintentional alarms [39](#)

Fasten safety belts

refer to Safety belts

warning lamp [21](#), [49](#)

Fault displays, refer to Check Control [80](#)

Fill pressure, refer to Tire inflation pressure [141](#)

Filter, refer to

Microfilter [109](#)

Microfilter/activated-charcoal filter [115](#)

First aid, refer to First-aid kit [24](#)

First-aid kit [24](#)

Flashlight [120](#)

Flat tire [163](#)

Flat Tire Monitor [101](#)

refer to Tire inflation

pressure [141](#)

refer to Wheel

changes [163](#)

spare wheel [165](#)

Flat Tire Monitor [101](#)

initializing [102](#)

warning lamp [102](#)

Flooding, refer to Driving through water [138](#)

Floor mats, refer to Caring for your vehicle brochure

Fluid level, indicator lamp [21](#)

Fog lamps, indicator lamp [22](#)

Folding floor cover up [129](#)

Folding rear backrest [126](#)

Folding rear seat back [126](#)

Footbrake, refer to General driving notes [137](#)

Footwell lamps [106](#)

[CarManuals2.com](http://CarManuals2.com)

# Everything from A to Z

For information on breaking  
in the differential, refer to  
Engine and differential [136](#)

Front airbags [57](#)

Front fog lamps [105](#)  
replacing bulbs [161](#)

Fuel  
average  
consumption [83](#), [90](#)  
display [78](#)  
quality [26](#)  
volume, refer to  
Capacities [181](#)

Fuel clock, refer to Fuel  
gauge [78](#)

Fuel display, refer to Fuel  
gauge [78](#)

Fuel filler door [24](#)  
manual operation [24](#)

Fuel tank capacity, refer to  
Capacities [181](#)

Fuel-saving driving, refer to  
Energy control [77](#)

Fuses [169](#)

## G

Garage-door opener, refer to  
Integrated universal  
remote control [117](#)

Gasoline display, refer to  
Fuel gauge [78](#)

Gasoline, refer to Fuel  
quality [26](#)

Gear display [67](#)

Gearshift lever, manual  
transmission [66](#)

General driving notes [137](#)

Glove compartment [120](#)

Grills, refer to  
Ventilation [109](#), [114](#)

Gross weight, refer to  
Weights [180](#)

Ground clearance [139](#)

## H

Hand lamp, refer to  
Rechargeable  
flashlight [120](#)

Handbrake [66](#)  
indicator lamp [19](#), [21](#)

Hands-free microphone,  
refer to Portable  
phone [119](#)

Hands-free system [119](#)

Hazard warning flashers [14](#)

HDC Hill Descent Control [97](#)

Head airbags [57](#)

Head restraints [47](#)

Headlamp control,  
automatic [103](#)

Headlamp cover, care, refer  
to Caring for your vehicle  
brochure

Headlamp flasher [70](#)  
indicator lamp [22](#)

Headlamp washer  
reservoir [150](#)  
volume, refer to Filling  
capacities [181](#)

Headlamp washing system  
headlamp washing [72](#)  
washer fluid [150](#)

Headlamps  
care, refer to Caring for  
your vehicle brochure  
replacing bulbs [159](#)

Heated mirrors [54](#)

Heated rear window  
air conditioner [108](#)  
automatic climate  
control [113](#)

Heated seats [52](#)

Heated steering wheel [53](#)

Heating  
exterior mirror [54](#)  
rear window [108](#), [113](#)  
seats [52](#)

steering wheel [53](#)

Heating and  
ventilation [107](#), [110](#)

Heating while stationary [113](#)

Heavy cargo, refer to  
Loading [132](#)

Heavy-duty cargo straps,  
refer to Cargo loading [132](#)

Height adjustment  
seats [45](#), [46](#)  
steering wheel [52](#)

Height, refer to  
Dimensions [179](#)

High beams [104](#)  
headlamp flasher [70](#)  
indicator lamp [22](#)  
replacing bulbs [160](#)

High temperatures [137](#)

Hill Descent Control HDC [97](#)

Hills [138](#), [140](#)

Holder for cups [121](#)

Hood [148](#)

Horn [14](#)

Hot exhaust system [137](#)

Hotel function [30](#)

Hydraulic brake assistant,  
refer to DBC [94](#)

Hydraulic system, brakes [19](#)

Hydroplaning [137](#), [145](#)

## I

Ice warning [76](#)

Identification, tire [143](#)

Ignition [64](#)

Ignition key [30](#)

Ignition lock [64](#)

Immobilizer function [91](#)

Imprint [4](#)

# Everything from A to Z

## Independent ventilation [116](#)

activating/deactivating  
switch-on times [87](#)

also refer to Owner's  
Manual for Onboard  
Computer  
entering switch-on  
times [87](#)

switching on and off  
directly [87](#)

## Indicating

elements [15](#), [17](#), [18](#)

Indicator lighting, refer to  
Instrument lighting [105](#)

## Indicator/warning lamp

airbags [59](#)

alarm system [38](#)

automatic transmission  
with Steptronic [69](#)

brakes [153](#)

coolant temperature [79](#)

DSC [95](#)

engine temperature [79](#)

fasten safety belts [49](#)

Flat Tire Monitor [102](#)

front fog lamps [105](#)

reserve [78](#)

self-leveling

suspension [98](#)

Indicator/warning lamps,  
overview [19](#)

## Individual air distribution [112](#)

Individual settings, refer to  
Vehicle Memory, Key  
Memory [63](#)

Inflation pressure  
monitoring, refer to Flat  
Tire Monitor [101](#)

Inflation pressure, tires [141](#)

INSPECTION [79](#)

Instrument cluster [15](#), [17](#), [18](#)

Instrument lighting [105](#)

Instrument panel, refer to  
Cockpit [14](#)

Integrated universal remote  
control [117](#)

Interface socket for Onboard  
Diagnostics [155](#)

Interior lamps [105](#)  
remote control [31](#)

Interior mirror, automatic  
dimming feature [138](#)

Interior motion sensor [39](#)  
switching off [31](#), [39](#)

Interior rearview mirror [55](#)  
compass [55](#)

Interlock, refer to Locking  
steering [64](#)

Intermittent operation of  
wipers [71](#), [73](#)

## J

Jacking points [167](#)

Jump starting [171](#)

Jumpering, refer to Jump  
starting [171](#)

## K

Key Memory [63](#)

Keys [30](#)

Kick-down [68](#)

## L

Lamps and bulbs [159](#)

Lamps, refer to Parking  
lamps/low beams [103](#)

Lashing eyes, refer to  
Securing load [132](#)

LATCH child-restraint fixing  
system [62](#)

LEDs light-emitting  
diodes [163](#)

Length, refer to  
Dimensions [179](#)

License plate lamp  
replacing bulbs [162](#)

Liftgate [35](#)  
emergency operation,  
refer to Unlocking  
manually [35](#)  
opening, remote  
control [31](#)  
remote control [31](#)

## Liftgate/tailgate

emergency operation,  
refer to Unlocking  
manually [35](#), [36](#)  
opening from inside [35](#)  
opening from outside [35](#)  
unlocking manually [35](#), [36](#)

Light switch [103](#)

Light-alloy wheels, care,  
refer to Caring for your  
vehicle brochure

Light-emitting diodes  
LEDs [163](#)

Lighter [122](#), [123](#)

Lighting of instruments [105](#)

Lights on warning [103](#)

Limit [88](#)

Limit speed, refer to Speed  
limit [88](#)

Load, refer to Cargo  
loading [131](#)

Lock buttons, doors, refer to  
Locking [34](#)

## Locking

from inside [34](#)  
from outside [31](#)

Locking and unlocking doors  
from inside [34](#)  
from outside [31](#)

Locking, vehicle  
from inside [34](#)  
from outside [31](#)

Low beams [103](#)  
     automatic [103](#)  
     replacing bulbs [159](#)  
 Lower back support, refer to  
     Lumbar support [46](#)  
 Low-fuel indicator lamp,  
     refer to Fuel gage [78](#)  
 Lug bolts [167](#)  
     torque [168](#)  
 Luggage compartment  
     capacity [180](#)  
     cover, refer to Roll-up  
     cover [126](#)  
     lamps, refer to Cargo area  
     lamps [106](#)  
     opening from inside [35](#)  
     opening from outside [35](#)  
     opening, with remote  
     control [31](#)  
     opening/closing, refer to  
     Liftgate [35](#)  
     opening/closing, refer to  
     Tailgate [36](#)  
     refer to Cargo area [126](#)  
 Luggage compartment lid,  
     refer to  
     Liftgate [35](#)  
     Tailgate [36](#)  
 Luggage compartment  
     net [37](#)

Luggage rack, refer to Roof-  
 mounted luggage rack [133](#)  
 Luggage straps [37](#)  
 Lumbar support [46](#)

## M

M+S tires, refer to Winter  
 tires [146](#)  
 Maintenance system [154](#)  
 Maintenance, refer to  
     Service Interval Display [79](#)  
 Malfunction  
     automatic transmission  
     with Steptronic [69](#)  
     door lock [33](#)  
     fuel filler door [24](#)  
     liftgate [35](#)  
     panorama glass  
     sunroof [42](#)  
     tailgate [36](#)  
 Manual operation  
     door lock [33](#)  
     driver's door [33](#)  
     fuel filler door [24](#)  
     liftgate [35](#)  
     panorama glass  
     sunroof [42](#)  
     tailgate [36](#)  
 Manual transmission [66](#)  
 Master key [30](#)  
     with remote control [30](#)  
 Maximum cooling [113](#)

Maximum roof weight [180](#)  
 Maximum speed with winter  
     tires [146](#)  
 Measurements, refer to  
     Dimensions [179](#)  
 Mechanical key, refer to  
     Door and ignition key [30](#)  
 Mechanical seats [45](#)  
 Memo [86](#)  
 Memory, refer to  
     Seat, mirror and steering  
     wheel memory [50](#)  
     Vehicle Memory, Key  
     Memory [63](#)  
 Microfilter  
     air conditioner [109](#)  
     automatic climate  
     control [115](#)  
 Microphone for telephone,  
     refer to Telephone [119](#)  
 MID Multi-Information  
     Display [84](#)  
 Mirror dimming feature [138](#)  
 Mirrors [54](#)  
     automatic curb monitor [51](#)  
     mirror heating [54](#)  
     mirror memory, refer to  
     Seat, mirror and steering  
     wheel memory [50](#)  
 Mobile phone, refer to  
     separate Owner's Manual

Mobile Service, refer to  
     Roadside Assistance [170](#)  
 Multifunction steering wheel,  
     refer to Buttons on  
     steering wheel [23](#)  
 Multifunction switch  
     turn signals/headlamp  
     flasher [70](#)  
     washer/wiper system [71](#)  
 Multi-Information Display  
     MID [84](#)

## N

Navigation system, refer to  
     Owner's Manual for  
     Onboard Computer/Radio  
     and Navigation System  
 Neck support, refer to Head  
     restraints [47](#)  
 Nozzles, refer to  
     Ventilation [109](#), [114](#)  
 Nylon rope, refer to Tow-  
     starting and towing [174](#)

# Everything from A to Z

## O

OBD interface socket [155](#)  
Odometer [76](#)  
Oil  
    additives, refer to  
    Specified engine oils [151](#)  
    consumption [150](#)  
    dipstick [150](#)  
    filling capacity [181](#)  
    specified engine oil  
    grades [151](#)  
Oil change interval, refer to  
    Service and Warranty  
    Information Booklet, US  
    models or Warranty and  
    Service Guide Booklet,  
    Canadian models  
Oil consumption [150](#)  
Oil level [150](#)  
Oil pressure, indicator/  
    warning lamp [19](#)  
Oil temperature [78](#)  
OILSERVICE [79](#)  
Old batteries, refer to  
    Disposal [168](#)  
Onboard computer, refer to  
    separate Owner's Manual  
Onboard tool kit [158](#)

Opening and closing  
    from inside [34](#)  
    from outside [31](#)  
    using door lock [33](#)  
    using remote control [31](#)  
Output, refer to Engine  
    specifications [178](#)  
Outside air, automatic  
    climate control [108](#)  
Outside temperature  
    display [76](#)  
    changing unit of  
    measure [76](#), [83](#)  
    in computer [83](#)

## P

Package shelf, refer to Roll-  
    up cover [126](#)  
Panorama glass sunroof [41](#)  
    automatic opening and  
    closing [41](#)  
    closing in the event of an  
    electrical malfunction [42](#)  
    comfort operation [33](#)  
    comfort position [41](#)  
    initializing [42](#)  
    power failure [42](#)  
    remote control [31](#)  
Park Distance Control  
    PDC [93](#)

Parking aid, refer to PDC  
    Park Distance Control [93](#)  
Parking brake, refer to  
    Handbrake [66](#)  
Parking lamps [103](#)  
    replacing bulbs [160](#)  
Parking lamps/low  
    beams [103](#)  
Parking, vehicle [65](#)  
Parts and accessories, refer  
    to For your own safety [9](#)  
Passenger-side mirror tilt  
    function [51](#)  
Pathway lighting [103](#)  
PDC Park Distance  
    Control [93](#)  
Permissible axle load, refer  
    to Weights [180](#)  
Permissible gross weight,  
    refer to Weights [180](#)  
Plastic care, refer to Caring  
    for your vehicle brochure  
Plastic, refer to Caring for  
    your vehicle brochure  
Pollen, refer to  
    Microfilter [109](#)  
    Microfilter/activated-  
    charcoal filter [115](#)  
Portable phone, refer to  
    separate Owner's Manual  
Power electric seat [46](#)

Power failure [169](#)  
Power rear backrests [48](#)  
Power socket [122](#)  
Power windows [39](#)  
    safety switch [40](#)  
Pressure monitoring, tires  
    Flat Tire Monitor [101](#)  
Pressure, tires [141](#)  
Programming settings, refer  
    to Vehicle Memory, Key  
    Memory [63](#)  
Protective function,  
    panorama glass  
    sunroof [42](#)  
Pull-out cargo floor [130](#)

## R

Radio navigation, refer to  
    separate Owner's Manual  
Radio, refer to Owner's  
    Manual for Radio/Onboard  
    Computer  
Radio-control key, refer to  
    Master key with remote  
    control [30](#)  
Rain sensor [71](#)  
Reading lamps  
    front [106](#)  
    rear [106](#)  
Real wood, refer to Caring  
    for your vehicle brochure

Rear backrests, power [48](#)  
Rear climate control [114](#)  
    air supply [114](#)  
    temperature [115](#)  
Rear lamps  
    refer to Tail lamps [161](#)  
    replacing bulbs [161](#)  
Rear seat back, folding [126](#)  
Rear seat backrest,  
    electric [48](#)  
Rear seats, heating [52](#)  
Rear window blind, refer to  
    Roller sun blinds [115](#)  
Rear window defroster  
    air conditioner [108](#)  
    automatic climate  
    control [113](#)  
Rear window safety  
    switch [40](#)  
Rear window wiper [73](#)  
    replacing bulbs [158](#)  
Rear-seat backrest, folding  
    down [126](#)  
Rearview mirror [54](#)  
Recirculated-air mode  
    air conditioner [108](#)  
    automatic climate  
    control [113](#)  
Refueling [24](#)  
    fuel filler door [24](#)

Remaining distance for  
    service, refer to Service  
    Interval Display [79](#)  
Remaining distance, refer to  
    Cruising range [83](#), [90](#)  
Remote control [31](#)  
    garage door opener, refer  
    to Integrated universal  
    remote control [117](#)  
    liftgate [31](#)  
    malfunction [32](#)  
Removal aid for spare  
    wheel [165](#)  
Removing condensation,  
    windows  
    air conditioner [109](#)  
    automatic climate  
    control [112](#)  
Replacement fuses [169](#)  
Replacement keys [30](#)  
Replacement of tires, wheel  
    changes [163](#)  
Replacement tire [165](#)  
Replacing bulbs, refer to  
    Lamps and bulbs [159](#)  
Replacing tires, tire  
    replacement [143](#)  
Reporting safety defects [11](#)  
Residual heat [113](#)  
Restraint systems for  
    children [59](#)

Restraint systems, refer to  
    Safety belts [49](#)  
Reverse gear  
    automatic transmission  
    with Steptronic [68](#)  
    manual transmission [67](#)  
Roadside Assistance [170](#)  
Roadside parking lamps [104](#)  
    replacing bulbs [160](#)  
Roller sun blinds [115](#)  
Roll-up cover [126](#)  
Roof-mounted luggage  
    rack [133](#)  
Rope, refer to Tow-starting  
    and towing [174](#)  
Rotating coin holder, refer to  
    Storage  
    compartments [120](#)

## S

Safe braking [140](#)  
Safety belt height  
    adjustment [49](#)  
Safety belt tensioners, refer  
    to Safety belts [50](#)  
Safety belts [49](#)  
    adjusting belt height [49](#)  
    care, refer to Caring for  
    your vehicle brochure  
    sitting safely [43](#)  
    warning lamp [21](#), [49](#)

Safety Defects [11](#)  
Safety feature, power  
    windows [40](#)  
Safety systems, refer to  
    Airbags [57](#)  
    Antilock Brake System [94](#)  
    Brake system [140](#)  
    DSC Dynamic Stability  
    Control [95](#)  
    xDrive [97](#)  
Screwdriver, refer to  
    Onboard tool kit [158](#)  
Seat heating [52](#)  
Seat memory, refer to Seat,  
    mirror and steering wheel  
    memory [50](#)  
Seats [44](#)  
    adjusting comfort seat [46](#)  
    adjusting electrically [46](#)  
    adjusting sports seat [45](#)  
    heating [52](#)  
    memory, refer to Seat,  
    mirror and steering wheel  
    memory [50](#)  
    sitting safely [43](#)  
    storing adjustment [50](#)  
Securing cargo, refer to  
    Cargo loading [131](#)  
Securing load [132](#)  
Selector lever interlock, refer  
    to Changing selector lever  
    positions [68](#)

# Everything from A to Z

- Selector lever positions, automatic transmission with Steptronic [67](#)
- Selector lever, automatic transmission with Steptronic [68](#)
- Self-leveling suspension [98](#)
- 2-axle self-leveling suspension [99](#)
- inactive [98](#)
- Service and Warranty Information Booklet for US models [154](#)
- Service Interval Display [79](#), [154](#)
- Service, refer to Roadside Assistance [170](#)
- Setting interior temperature [108](#), [112](#)
- Setting time, refer to Preselecting switch-on times [87](#)
- Shifting
- automatic transmission with Steptronic [68](#)
  - manual transmission [66](#)
- Shiftlock [68](#)
- Shoulder support [47](#)
- Side airbags [57](#)
- Side Impact Head Protection System [57](#)
- Side tilt, permissible [138](#)
- Side turn signals, replacing bulbs [160](#)
- Side window blinds, refer to Rear window blind [115](#)
- Signaling briefly [70](#)
- Sitting safely [43](#)
- with airbags [43](#)
  - with safety belts [43](#)
- Ski bag [124](#)
- Snow chains [147](#)
- Sockets [129](#)
- Soft closure aid for liftgate, refer to Automatic Soft Close function [36](#)
- Spare fuses [169](#)
- Spare key [30](#)
- Spare wheel [165](#)
- removal aid [165](#)
- Special wash program [72](#)
- Specified engine oils [151](#)
- Speed
- with spare wheel [168](#)
  - with winter tires [146](#)
- Speed limit [88](#)
- Speedometer, refer to Instrument cluster [15](#), [17](#), [18](#)
- Sport Program, automatic transmission with Steptronic [69](#)
- Sports seat [45](#)
- Stability control, refer to DSC Dynamic Stability Control [95](#)
- xDrive [97](#)
- Starting engine [64](#)
- Starting problems
- at very low temperatures [65](#)
  - jump starting [171](#)
- Status of this Owner's Manual at time of printing [9](#)
- Steering lock [64](#)
- Steering wheel
- adjustment [52](#)
  - adjustment, automatic [53](#)
  - lock [64](#)
- Steering wheel heater [53](#)
- Steering wheel memory [50](#)
- Steering wheel with multi-function buttons [23](#)
- Steptronic, refer to Manual mode [69](#)
- Stopwatch [86](#)
- Storage compartments [120](#)
- in the cargo area [128](#)
- Storage space, refer to Cargo area [126](#)
- Storing desired speed, refer to Cruise control. [74](#)
- Storing sitting position, refer to Seat, mirror and steering wheel memory [50](#)
- Storing the seat adjustment [50](#)
- Storing tires [147](#)
- Supply reservoir
- washing systems [150](#)
- Switches, refer to Cockpit [14](#)
- Switching air conditioner mode on and off manually [108](#), [113](#)
- Switching off engine [65](#)
- Switching on hour signal [86](#)
- Switch-on times input [87](#)
- Symbols [8](#)
- Synthetic oil [151](#)
- T**
- Tachometer [77](#)
- Tail lamps, replacing bulbs [161](#)
- Tailgate [36](#)
- unlocking manually [36](#)
- Taking time, refer to Stopwatch [86](#)
- Tank capacity, refer to Fuel tank capacity [181](#)
- Technical data [178](#)
- Technical modifications [9](#)

- Telephone [119](#)
- Telephone provisions, refer to Hands-free telephone operation [119](#)
- Telephone, refer to separate Owner's Manual
- Temperature
  - air conditioner [108](#)
  - automatic climate control [112](#)
- Temperature display
  - ice warning [76](#)
  - interior temperature [112](#)
  - outside
  - temperature [76](#), [83](#)
  - setting the units [76](#), [83](#)
- Tempomat, refer to Cruise control. [74](#)
- Thigh support adjustment [45](#)
- Third brake lamp
  - refer to Center brake lamp [162](#)
  - replacing bulbs [162](#)
- Three-point seat belt, refer to Safety belts [49](#)
- Tightening torque of lug bolts [168](#)
- Tilt alarm sensor
  - remote control [31](#)
  - switching off [39](#)
- Tilt function, passenger-side mirror [51](#)
- Time of arrival [90](#)
- Timer, refer to Stopwatch [86](#)
- Tire Identification Number [143](#)
- Tire inflation pressure, producing [141](#)
- Tire pressure monitoring, refer to Flat Tire Monitor [101](#)
- Tire Quality Grading [143](#)
- Tires
  - age [143](#)
  - breaking-in [136](#)
  - changing [146](#), [163](#)
  - condition [144](#)
  - damage [144](#)
  - DOT Quality Grades [143](#)
  - flat [163](#)
  - inflation pressure [141](#)
  - size [143](#)
  - storage [147](#)
  - traction [144](#)
  - tread [145](#)
  - tread wear [143](#)
  - Uniform Tire Quality Grading [143](#)
  - wear indicators, refer to Tire tread [145](#)
  - winter tires [146](#)
- Tools, refer to Onboard tool kit [158](#)
- Torque
  - engine [178](#)
  - lug bolts [168](#)
- Tow bar [173](#)
- Tow fitting [172](#)
- Tow sockets for tow fitting [173](#)
- Towing the vehicle [172](#), [173](#)
  - with automatic transmission [173](#)
- Tow-rope [174](#)
- Tow-starting [172](#)
- Track width, refer to Dimensions [179](#)
- Traction [144](#)
- Traction aid, refer to DSC Dynamic Stability Control [95](#)
- Traction control, refer to DSC Dynamic Stability Control [95](#)
- Transmission
  - automatic transmission with Steptronic [67](#)
  - manual transmission [66](#)
- Transmission fault, refer to Malfunction [69](#)
- Transmission lockout, refer to P Park [68](#)
- Transport securing device, refer to Securing cargo [132](#)
- Transporting children safely [59](#)
- Tread depth, refer to Tire tread [145](#)
- Tread wear [143](#)
- Trip odometer [76](#)
- Trip-distance counter, refer to Trip odometer [76](#)
- Trunk
  - opening from the inside [35](#)
  - opening from the outside [35](#)
  - opening, with remote control [31](#)
- Trunk lamps, refer to Cargo area lamps [106](#)
- Trunk lid, refer to Liftgate [35](#)
- Tailgate [36](#)
- Turn signals [70](#)
  - indicator lamp [22](#)
  - replacing bulbs [160](#), [161](#)
- Turn signals, side
  - replacing bulbs [160](#)
- Turning circle, refer to Dimensions [179](#)
- TV function, refer to Owner's Manual for Onboard Computer

# Everything from A to Z

TV set, refer to Owner's

Manual for Onboard  
Computer

Two-axle self-leveling  
suspension  
display [99](#)

lowering [100](#)

raising [100](#)

## U

Underbody protection, refer  
to Caring for your vehicle  
brochure

Uniform Tire Quality  
Grading [143](#)

Units,  
temperature [76](#), [83](#), [112](#)

Universal garage door  
control, refer to Integrated  
universal remote  
control [117](#)

Universal portable phone  
preparation, refer to  
separate Owner's Manual

Universal remote control [117](#)

Unlocking  
from inside [34](#)  
from outside [31](#)  
hood [148](#)

Use antifreeze [150](#), [152](#)

## V

Vacuum cleaner,  
connecting, refer to  
Power socket [122](#)  
Power sockets [129](#)

Valve  
inserts [168](#)  
screw caps [168](#)

Vehicle  
battery [168](#)  
breaking-in [136](#)  
care, refer to Caring for  
your vehicle brochure  
cargo loading [131](#)  
measurements, refer to  
Dimensions [179](#)  
parking [65](#)  
storage, refer to Caring for  
your vehicle brochure  
washing, refer to Caring for  
your vehicle brochure  
weight [180](#)

Vehicle jack [165](#)  
jacking points [167](#)

Vehicle Memory [63](#)  
Ventilation [109](#), [114](#)

Ventilation in the rear [109](#)  
Ventilation while parked [116](#)  
Viscosity [152](#)

Voice command system [23](#)

Voice control, refer to  
separate Owner's Manual

## W

Warning and indicator  
lamps [19](#)

Warning triangle [24](#)

Warnings, refer to Check  
Control [80](#)

Warranty [10](#)  
refer also to Service and  
Warranty Information  
Booklet for US models or  
Warranty and Service  
Guide Booklet for  
Canadian models

Warranty and Service Guide  
Booklet for Canadian  
models [154](#)

Washer fluid [150](#)

Washer fluid reservoir,  
content [181](#)

Washer jets, refer to  
Windshield washer  
nozzles [72](#)

Washer reservoir, refer to  
Windshield and Headlamp  
washing system [150](#)

Waste container, refer to  
Ashtray [122](#)

Water on roads, flooding [138](#)

Wear indicators in the tires,  
refer to Tire tread [145](#)

Weights [180](#)

Wheel bolts, wrench [164](#)

Wheel/tire combinations [146](#)

Wheelbase, refer to  
Dimensions [179](#)

Width, refer to  
Dimensions [179](#)

Windows [39](#)  
convenience operation [33](#)  
safety switch [40](#)

Windshield cleaner reservoir  
volume, refer to Filling  
capacities [181](#)

Windshield washer fluid  
reservoir [150](#)

Windshield washer  
nozzles [72](#)

Windshield washer system,  
washer/wiper system [71](#)

Windshield washer, washer  
fluid [150](#)

Windshield washing [72](#)  
reservoir [150](#)

Windshield wiper blades  
care, refer to Caring for  
your vehicle brochure  
replacement [158](#)

Windshield wipers, refer to  
Wiper/washer system [71](#)

Winter tires [146](#)  
changing [146](#)  
condition [144](#)  
storage [147](#)

Wiper blade  
  replacement [158](#)  
Wiper system [71](#)  
Working in the engine  
  compartment [148](#)  
Wrenches, refer to Onboard  
  tool kit [158](#)

## X

xDrive [97](#)  
Xenon lamps  
  replacing bulbs [160](#)

# Refueling

BMW recommends 

So that you will have important specifications available when you stop to refuel, we recommend that you supplement this table with data which apply to your vehicle.  
Consult the index for individual specifications.

## Fuel

|             |  |
|-------------|--|
| Designation |  |
|-------------|--|

Please enter your preferred fuel here.

## Engine oil

|         |  |
|---------|--|
| Quality |  |
|---------|--|

The oil volume between the two marks on the oil dipstick corresponds to approx. 1.1 US quarts/1 liter.

| Tire inflation pressures    | Summer tires |      | Winter tires |      |
|-----------------------------|--------------|------|--------------|------|
|                             | Front        | Rear | Front        | Rear |
| 4 persons                   |              |      |              |      |
| 5 persons or 4 plus luggage |              |      |              |      |

CarManuals2.com

More about BMW

[bmwusa.com](http://bmwusa.com)



**The Ultimate  
Driving Machine**

[CarManuals2.com](http://CarManuals2.com)

[CarManuals2.com](http://CarManuals2.com)