


Remote Control Mirror



 : Parts Location

Code	See Page	Code	See Page	Code	See Page
J2	39	R14	41		
R7	39	R15	41		

 : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
IF	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
3A	29	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)
3C		
4B	32	Instrument Panel Wire and Center J/B (Behind the Combination Meter)

 : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IC3	44	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
IH1	45	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)

 : Ground Points

Code	See Page	Ground Points Location
IE	44	Behind Combination Meter