

SECTION

CL

CLUTCH

A
B
C
CL

CONTENTS

E

PRECAUTION	2	Inspection and Adjustment	12
PRECAUTIONS	2	CLUTCH MASTER CYLINDER	13
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	2	Exploded View	13
General Precautions	2	Removal and Installation	13
PREPARATION	3	Inspection and Adjustment	14
PREPARATION	3	CLUTCH PIPING	15
Special Service Tool	3	Exploded View	15
Commercial Service Tools	3	Hydraulic Layout	15
SYMPTOM DIAGNOSIS	4	Removal and Installation	15
NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING	4	Inspection and Adjustment	16
NVH Troubleshooting Chart	4	UNIT REMOVAL AND INSTALLATION	17
PERIODIC MAINTENANCE	5	CSC (CONCENTRIC SLAVE CYLINDER)	17
CLUTCH PEDAL	5	Exploded View	17
Inspection and Adjustment	5	Removal and Installation	17
CLUTCH FLUID	7	Inspection and Adjustment	18
Inspection	7	CLUTCH DISC AND CLUTCH COVER	19
Draining	7	Exploded View	19
Refilling	8	Removal and Installation	19
Air Bleeding	9	Inspection	20
REMOVAL AND INSTALLATION	11	SERVICE DATA AND SPECIFICATIONS (SDS)	22
CLUTCH PEDAL	11	SERVICE DATA AND SPECIFICATIONS (SDS)	22
Exploded View	11	General Specifications	22
Removal and Installation	11	Clutch Pedal	22
		Clutch Disc	22
		Clutch Cover	22

F

G

H

I

J

K

L

M

N

O

P

cardiagn.com

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000012432210

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

General Precautions

INFOID:0000000012432211

WARNING:

After cleaning clutch disc, wipe it with a dust collector. Do not use compressed air.

CAUTION:

- Always use recommended clutch fluid. Refer to [MA-11, "Fluids and Lubricants"](#).
- Do not reuse drained clutch fluid.
- Keep painted surface on the body and other parts free of clutch fluid. If fluid spills, wipe up immediately and wash the affected area with water.
- Do not use mineral oils, such as gasoline or kerosene. It will ruin the rubber parts of the hydraulic system.
- Do not reuse CSC (Concentric Slave Cylinder). CSC slides back to the original position every time when removing transaxle assembly. At this time, dust on the sliding parts may damage the seal of CSC and may cause clutch fluid leakage. Refer to [CL-17, "Removal and Installation"](#).
- Do not disassemble clutch master cylinder and CSC.

PREPARATION

< PREPARATION >

PREPARATION

PREPARATION

Special Service Tool

INFOID:0000000012432212

The actual shape of the tools may differ from those illustrated here.

Tool number (TechMate No.) Tool name	Description
ST20050240 (—) Diaphragm adjusting wrench ZZA0508D	Adjusting unevenness of diaphragm spring lever

Commercial Service Tools

INFOID:0000000012432213

Tool name	Description
Clutch aligner MCIB0404E	Installing clutch disc
Power tool PIIB1407E	Loosening nuts, screws and bolts

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

NVH Troubleshooting Chart

INFOID:000000012432214

Use the chart below to find the cause of the symptom. The numbers indicate the order of the inspection. If necessary, repair or replace these parts.

Reference page		CL-5	CL-9	EM-86	CL-18	CL-20										CL-19	
SUSPECTED PARTS (Possible cause)		CLUTCH PEDAL (Inspection and adjustment)	CLUTCH LINE (Air in line)	ENGINE MOUNTING (Loose)	CSC (Concentric Slave Cylinder) (Worn, dirty or damaged)	CLUTCH DISC (Out of true)	CLUTCH DISC (Runout is excessive)	CLUTCH DISC (Lining broken)	CLUTCH DISC (Dirty or burned)	CLUTCH DISC (Oily)	CLUTCH DISC (Worn out)	CLUTCH DISC (Hardened)	CLUTCH DISC (Lack of spline grease)	DIAPHRAGM SPRING (Damaged)	DIAPHRAGM SPRING (Out of tip alignment)	PRESSURE PLATE (Distortion)	FLYWHEEL (Distortion)
Symptom	Clutch grabs/chatters			1			2			2	2	2			2		
	Clutch pedal spongy		1		2												
	Clutch noisy				1												
	Clutch slips	1								2	2			3		4	5
	Clutch does not disengage	1	2		3	3	3	3	3	3			3	4	4	5	

CLUTCH PEDAL

< PERIODIC MAINTENANCE >

PERIODIC MAINTENANCE

CLUTCH PEDAL

Inspection and Adjustment

INFOID:0000000012432215


INSPECTION

The Height of Clutch Pedal

1. Turn the floor carpet.
2. Check that the clutch pedal height (H₁) from the dash lower panel (1) is within the reference value.

Clutch pedal height (H₁) : Refer to [CL-22, "Clutch Pedal"](#).

3. Replace clutch pedal if the height is outside the reference value.



Clutch Pedal Height When Disengaging The Clutch

1. Securely engage the parking brake.
2. Turn the floor carpet.
3. Start the engine and run at idle.
4. Fully depress clutch pedal and shift to the 1st gear.

CAUTION:

Securely depress the brake pedal with shifter lever in 1st gear.


5. Gradually release the clutch pedal and check that the clutch pedal height (H₂) from the dash lower panel (1) is within the reference value with a scale immediately before the clutch is engaged.

Clutch pedal height at clutch disengagement (H₂) : Refer to [CL-22, "Clutch Pedal"](#).

NOTE:

Although the clutch pedal height differs according to whether the clutch gets disengaged or engaged, clutch-engaged case is regarded as clutch-disengaged case for easier inspection.

6. Replace clutch pedal if the height is outside the reference value.




Clutch Pedal Play

1. Push the pedal pad by hand until a resistance can be felt and check that the play (A) on the upper surface of the pedal pad is within the reference value.

Clutch pedal play (A) : Refer to [CL-22, "Clutch Pedal"](#).

2. Replace clutch pedal if the play is outside the reference value.




Position of Clutch Interlock Switch

CLUTCH PEDAL

< PERIODIC MAINTENANCE >

Check that the clearance (C) between the thread end of clutch interlock switch (1) and stopper rubber (2) is within the specification range while clutch pedal is fully depressed.


Clearance (C) : Refer to [CL-22, "Clutch Pedal"](#).



Position of Clutch Pedal Position Switch (if equipped)

Check that the clearance (A) between the thread end of clutch pedal position switch (1) and clutch pedal (2) is within the specification range while clutch pedal is fully released.

Clearance (A) : Refer to [CL-22, "Clutch Pedal"](#).



ADJUSTMENT


Position of Clutch Interlock Switch

1. Disconnect the harness connector from the clutch interlock switch.
2. Rotate the clutch interlock switch (1) 45 degrees counterclockwise to release from bracket.
3. With the clutch pedal fully depressed, insert the clutch interlock switch (1) until it contacts the stopper rubber (2).
4. Rotate the clutch interlock switch 45 degrees clockwise to set clearance (A) between the clutch interlock switch (1) and stopper rubber (2).

CAUTION:

The clearance (C) must be within the specification range.

Clearance (C) : Refer to [CL-22, "Clutch Pedal"](#).




NOTE:

Fully depressed clutch pedal means a clutch pedal condition that the clutch pedal lever contacts the pedal stopper rubber.

Position of Clutch Pedal Position Switch (if equipped)

1. Disconnect the harness connector from the clutch pedal position switch.
2. Rotate the clutch pedal position switch 45 degrees counterclockwise to release from bracket.
3. Insert the clutch pedal position switch (1) until it contacts the clutch pedal (2).
4. Rotate the clutch pedal position switch 45 degrees clockwise to set clearance (A) between the clutch pedal position switch (1) and clutch pedal (2).

Clearance (A) : Refer to [CL-22, "Clutch Pedal"](#).



CLUTCH FLUID

< PERIODIC MAINTENANCE >

CLUTCH FLUID

Inspection

INFOID:0000000012432216

CLUTCH FLUID LEAKS


- Check clutch line for cracks, deterioration or other damage. Replace any damaged parts.
- Check for clutch fluid leaks by fully depressing clutch pedal while engine is running.

CAUTION:

If leaks occur around connections, reinstall the lines or replace damaged parts, if necessary.

CLUTCH FLUID LEVEL

- Check that the clutch fluid level in the reservoir tank is within the specified range, between the MAX and MIN lines as shown.
- Visually check for any clutch fluid leaks around the reservoir tank.
- Check the clutch system for any leaks if the clutch fluid level is extremely low (lower than MIN).




Draining

INFOID:0000000012432217


CAUTION:

Do not spill clutch fluid onto painted surfaces. If clutch fluid spills, wipe up immediately and wash the affected area with water.

1. Connect a transparent vinyl hose to air bleeder of bleeding connector (1).



2. Press the lock pin (1) into the bleeding connector (2), and maintain the position.



CLUTCH FLUID

< PERIODIC MAINTENANCE >


- Slide clutch tube (1) for the specified distance (A) in the direction of the arrow (←) as shown.

(2) : Bleeding connector

Dimension (A) : 5 mm (0.20 in)

CAUTION:

Do not allow the clutch tube to disconnect from the bleeding connector.



- Depress clutch pedal to gradually discharge clutch fluid.

CAUTION:

Clutch tube is under hydraulic pressure; do not allow the clutch tube to disconnect from the bleeding connector.

Refilling

INFOID:0000000012432218

CAUTION:


Do not spill clutch fluid onto painted surfaces. If clutch fluid spills, wipe up immediately and wash the affected area with water.

- Check that there is no foreign material in reservoir tank and then fill with new clutch fluid.


CAUTION:

Do not reuse drained clutch fluid.

- Connect a transparent vinyl hose to air bleeder of bleeding connector (1).



- Press the lock pin (1) into the bleeding connector (2), and maintain the position.




CLUTCH FLUID

< PERIODIC MAINTENANCE >

- Slide clutch tube (1) for the specified distance (A) in the direction of the arrow (←) as shown.

(2) : Bleeding connector

Dimension (A) : 5 mm (0.20 in)



- Slowly depress clutch pedal to the full stroke position and then release the pedal.

CAUTION:

Clutch tube is under hydraulic pressure; do not allow the clutch tube to disconnect from the bleeding connector.

- Repeat step 5 at intervals of 2 or 3 seconds until new clutch fluid is discharged.

CAUTION:

Monitor clutch fluid level in reservoir tank so as not to empty the tank.

- Return clutch tube and lock pin in their original positions while clutch pedal is depressed.
- Perform the air bleeding. Refer to [CL-9, "Air Bleeding"](#).

Air Bleeding

INFOID:000000012432219

CAUTION:


- Monitor clutch fluid level in reservoir tank so as not to empty the tank.
- Do not spill clutch fluid onto painted surfaces. If clutch fluid spills, wipe up immediately and wash the affected area with water.

- Fill reservoir tank with new clutch fluid.

CAUTION:

Do not reuse drained clutch fluid.


- Connect a transparent vinyl hose to air bleeder of bleeding connector (1).
- Depress and release the clutch pedal slowly and fully 15 times at an interval of 2 to 3 seconds and release the clutch pedal.



- Press the lock pin (1) into the bleeding connector (2), and maintain the position.

CAUTION:

Clutch tube is under hydraulic pressure; do not allow the clutch tube to disconnect from the bleeding connector.



CLUTCH FLUID

< PERIODIC MAINTENANCE >


- Slide clutch tube (1) for the specified distance (A) in the direction of the arrow (←) as shown and immediately depress the clutch pedal and hold it, to bleed the air from the system.

(2) : Bleeding connector

Dimension (A) : 5 mm (0.20 in)

CAUTION:

Clutch tube is under hydraulic pressure; do not allow the clutch tube to disconnect from the bleeding connector.



- Return clutch tube and lock pin in their original positions.
- Release clutch pedal and wait for 5 seconds.
- Repeat steps 3 to 7 until no bubbles are observed in the clutch fluid.
- Check that the clutch fluid level in the reservoir tank is within the specified range after air bleeding. Refer to [CL-7, "Inspection"](#).

CLUTCH PEDAL


< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION

CLUTCH PEDAL

Exploded View

INFOID:0000000012432220




- | | | |
|----------------------------|-------------------------|---|
| 1. Clutch pedal | 2. Pedal stopper rubber | 3. Pedal pad |
| 4. Clutch interlock switch | 5. Clip | 6. Clutch pedal position switch (if equipped) |
| 7. Clip | ↙ Front | |

Removal and Installation

INFOID:0000000012432221

REMOVAL

1. Remove the instrument lower panel LH. Refer to [IP-24, "Removal and Installation"](#).
2. Disconnect master cylinder rod end (↙) from clutch pedal.



3. Disconnect the harness connector from the clutch interlock switch.
4. Disconnect the harness connector from the clutch pedal position switch (if equipped).
5. Remove harness clips from clutch pedal.
6. Remove clutch pedal nuts and remove clutch pedal.
7. Remove pedal pad from clutch pedal.
8. Rotate the clutch interlock switch 45 degrees counterclockwise to release from bracket.
9. Rotate the clutch pedal position switch 45 degrees counterclockwise to release from bracket (if equipped).
10. Remove pedal stopper rubber from clutch pedal using a suitable tool.

CLUTCH PEDAL

< REMOVAL AND INSTALLATION >

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

Press master cylinder rod end into clutch pedal until it stops.

Inspection and Adjustment

INFOID:0000000012432222

INSPECTION AFTER REMOVAL

- Check clutch pedal for bend, damage, or a cracked weld. If bend, damage, or a cracked weld is found, replace clutch pedal.
- Check pedal stopper rubber. If damage or deformation is found, replace pedal stopper rubber.
- Check pedal pad. If wear or damage is found, replace pedal pad.

INSPECTION AND ADJUSTMENT AFTER INSTALLATION

- Inspect the clutch interlock switch position and adjust as necessary. Refer to [CL-5, "Inspection and Adjustment"](#).
- Inspect the clutch pedal position switch position and adjust as necessary (if equipped). Refer to [CL-5, "Inspection and Adjustment"](#).


CLUTCH MASTER CYLINDER

< REMOVAL AND INSTALLATION >

CLUTCH MASTER CYLINDER

Exploded View

INFOID:000000012432223



1. Reservoir hose
2. Master cylinder

Removal and Installation

INFOID:000000012432224

CAUTION:

- Do not spill clutch fluid onto painted surfaces. If clutch fluid spills, wipe up immediately and wash the affected area with water.
- Do not disassemble clutch master cylinder.


NOTE:

When removing components such as hoses, tubes/lines, etc., cap or plug openings to prevent fluid from spilling.

REMOVAL

1. Remove battery. Refer to [PG-70, "Removal and Installation \(Battery\)"](#).
2. Remove air cleaner and air duct. Refer to [EM-26, "Removal and Installation"](#).
3. Remove IPDM E/R. Refer to [PCS-30, "Removal and Installation"](#).
4. Remove ECM bracket nuts (A).


⇐: Front




CLUTCH MASTER CYLINDER

< REMOVAL AND INSTALLATION >

5. Remove master cylinder rod end (←) from clutch pedal.
6. Use one of the following methods to remove reservoir hose from master cylinder.
 - Drain clutch fluid from reservoir tank and remove reservoir hose. Refer to [CL-7. "Draining"](#).
 - Remove hose from master cylinder.



7. Pull up the lock pin (1) from connector of master cylinder (2) and separate clutch tube (3).
8. Rotate master cylinder clockwise by 45 degrees and then remove master cylinder from the vehicle.



INSTALLATION

CAUTION:

Do not spill clutch fluid onto painted surfaces. If fluid spills, wipe up immediately and wash the affected area with water.


1. With the nipple (1) rotated clockwise by 45 degrees, insert clutch master cylinder into the mounting hole. Rotate the clutch master cylinder counterclockwise by 45 degrees (A) as shown to secure it. At this time, nipple is in the upward (B).

2. Install master cylinder rod end to clutch pedal.

CAUTION:

Press master cylinder rod end into clutch pedal until it stops.

3. Install reservoir hose to master cylinder.
4. Press down the lock pin into connector of master cylinder until it stops.
5. Install clutch tube into connector of master cylinder until it stops.
6. Fill with clutch fluid and bleed clutch hydraulic system. Refer to [CL-8. "Refilling"](#).
7. Installation of the remaining components is in the reverse order of removal.



Inspection and Adjustment

INFOID:000000012432225

INSPECTION AFTER INSTALLATION

Check for clutch fluid leaks and check the fluid level. Refer to [CL-7. "Inspection"](#).


CLUTCH PIPING

< REMOVAL AND INSTALLATION >

CLUTCH PIPING

Exploded View


INFOID:0000000012432226



- | | | |
|------------------------------------|------------|--------------------|
| 1. CSC (Concentric Slave Cylinder) | 2. Clip | 3. Clutch tube |
| 4. Clutch damper | 5. Bracket | 6. Master cylinder |

Hydraulic Layout

INFOID:0000000012432227



- | | | |
|------------------|--------------------|------------------------------------|
| 1. Clutch tube | 2. Lock pin | 3. CSC (concentric slave cylinder) |
| 4. Clutch damper | 5. Master cylinder | 6. Clutch pedal |

Removal and Installation

INFOID:0000000012432228

CAUTION:

Do not spill clutch fluid onto painted surfaces. If clutch fluid spills, wipe up immediately and wash the affected area with water.

NOTE:


When removing components such as hoses, tubes/lines, etc., cap or plug openings to prevent fluid from spilling.

CLUTCH PIPING

< REMOVAL AND INSTALLATION >

REMOVAL

1. Remove the battery. Refer to [PG-70, "Removal and Installation \(Battery\)"](#).
2. Use one of the following methods to remove hose from clutch master cylinder.
 - Drain clutch fluid from reservoir tank and remove hose. Refer to [CL-7, "Draining"](#).
 - Remove hose from clutch master cylinder.
3. Remove clutch tube lock pin from clutch master cylinder.
4. Remove clutch tube lock pin at clutch housing.
5. Remove clutch tube lock pins (2) from clutch damper (3).
6. Remove clutch tube (1) from clutch damper (3).
7. Remove clutch damper (3) from bracket (4).



INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

Do not damage clutch tube.

- Insert each clutch tube into the CSC bleeding connector, the clutch damper connector, and the clutch master cylinder connector until it contacts the end of each connector.
- Install each lock pin into the clutch damper connector and the clutch master cylinder connector until it contacts the end of each connector.
- After installation, bleed the air from the clutch hydraulic system. Refer to [CL-9, "Air Bleeding"](#).

Inspection and Adjustment

INFOID:0000000012432229

INSPECTION AFTER REMOVAL

- Check the clutch tube for cracks and damage. If the clutch tube has cracks or damage, replace it with a new one.
- Check the O-ring of the clutch tube for cracks and damage. If the O-ring of the clutch tube has cracks or damage, replace clutch tube with a new one.
- Check the clutch damper for cracks and damage. If the clutch damper has cracks or damage, replace it with a new one.

INSPECTION AFTER INSTALLATION

Check for clutch fluid leaks and check the clutch fluid level. Refer to [CL-7, "Inspection"](#).

CSC (CONCENTRIC SLAVE CYLINDER)


< UNIT REMOVAL AND INSTALLATION >

UNIT REMOVAL AND INSTALLATION

CSC (CONCENTRIC SLAVE CYLINDER)

Exploded View

INFOID:0000000012432230



1. Transaxle assembly

2. CSC (concentric slave cylinder)

Removal and Installation

INFOID:0000000012432231

CAUTION:


- Do not reuse CSC (concentric slave cylinder). CSC slides back to the original position every time when removing transaxle assembly. At this time, dust on the sliding parts may damage the seal of CSC and may cause clutch fluid leaks.
- Do not disassemble CSC.
- Do not spill clutch fluid onto painted surfaces. If clutch fluid spills, wipe up immediately and wash the affected area with water.

NOTE:

When removing components such as hoses, tubes/lines, etc., cap or plug openings to prevent fluid from spilling.

REMOVAL

1. Remove engine transaxle assembly. Refer to [EM-87, "Removal and Installation"](#).
2. Remove CSC bolts (←) and the CSC from clutch housing.



INSTALLATION

1. Install CSC to clutch housing and then tighten CSC bolts to the specified torque.

CAUTION:

- Do not reuse CSC.

CSC (CONCENTRIC SLAVE CYLINDER)

< UNIT REMOVAL AND INSTALLATION >

- **Do not insert and operate CSC when transaxle is removed. Piston and stopper of CSC components may fall off.**

2. Install engine and transaxle assembly. Refer to [EM-87, "Removal and Installation"](#).

Inspection and Adjustment

INFOID:0000000012432232

INSPECTION AFTER INSTALLATION

Check for clutch fluid leaks and clutch fluid level. Refer to [CL-7, "Inspection"](#).

ADJUSTMENT AFTER INSTALLATION

Perform the air bleeding. Refer to [CL-9, "Air Bleeding"](#).


CLUTCH DISC AND CLUTCH COVER

< UNIT REMOVAL AND INSTALLATION >

CLUTCH DISC AND CLUTCH COVER

Exploded View

INFOID:0000000012432233



1. Flywheel
2. Clutch disc
3. Clutch cover
4. Input shaft
- A. First step
- B. Final step

 : Apply lithium-based grease including molybdenum disulphide.

Removal and Installation

INFOID:0000000012432234

CAUTION:

- Do not reuse CSC (concentric slave cylinder). CSC slides back to the original position every time when removing transaxle assembly. At this time, dust on the sliding parts may damage the seal of CSC and may cause clutch fluid leaks.
- Do not allow any grease to contact the clutch disc facing, pressure plate surface and flywheel surface.
- Do not clean clutch disc using solvent.

REMOVAL

1. Remove engine and transaxle assembly. Refer to [TM-24, "Removal and Installation"](#).
2. Loosen clutch cover bolts evenly. Then remove clutch cover and clutch disc.

INSTALLATION

1. Clean clutch disc and input shaft splines to remove grease and dust caused by abrasion.
2. Apply recommended grease to clutch disc and input shaft splines.


CAUTION:

Be sure to apply grease to the points specified. Otherwise, noise, poor disengagement, or damage to the clutch may result. Excessive grease may cause slip or shudder. If grease adheres to seal of CSC, it may cause clutch fluid leaks. Wipe off excess grease. Wipe off any grease oozing from the parts.

CLUTCH DISC AND CLUTCH COVER

< UNIT REMOVAL AND INSTALLATION >

3. Install clutch disc, using suitable tool (A).
4. Install clutch cover and then temporarily tighten clutch cover bolts.
5. Tighten clutch cover bolts to the specified torque evenly into two steps in the numerical order as shown.
6. Install engine and transaxle assembly. Refer to [TM-24, "Removal and Installation"](#).



INFOID:0000000012432235

Inspection

INSPECTION AFTER REMOVAL

Clutch Disc

- Measure clutch facing runout. If it is outside the specification, replace clutch disc.



Runout limit/diameter of the area to be measured : Refer to [CL-22, "Clutch Disc"](#).

- Measure spline backlash at outer edge of clutch disc. If it is outside the specification, replace clutch disc.

Maximum allowable spline backlash (at outer edge of disc) : Refer to [CL-22, "Clutch Disc"](#).

- Measure the depth (A) to clutch disc facing rivet heads, using suitable tool. If it exceeds the allowable wear limit, replace clutch disc.

Facing wear limit (depth to the rivet head) (A) : Refer to [CL-22, "Clutch Disc"](#).



Clutch Cover

- Check clutch cover thrust ring for wear or damage. If wear or damage is found, replace clutch cover.

NOTE:

- Worn thrust ring will generate a beating noise when tapped at the rivet using suitable tool.
- Broken thrust ring will make a clinking sound when cover is shaken up and down.
- If a trace of burn or discoloration is found on the clutch cover pressure plate to clutch disc contact surface, repair the surface with sandpaper. If surface is damaged or distorted, replace clutch cover.

INSPECTION AFTER INSTALLATION

Clutch Cover


CLUTCH DISC AND CLUTCH COVER

< UNIT REMOVAL AND INSTALLATION >

Check diaphragm spring levers for unevenness with the clutch cover installed on the engine. If they exceed the tolerance, adjust diaphragm spring lever height, using Tool (A).

Tool number (A) : ST20050240 (—)

Tolerance for diaphragm spring lever unevenness : Refer to [CL-22, "Clutch Cover"](#).



A

B

C

CL

E

F

G

H

I

J

K

L

M

N

O

P

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specifications

INFOID:0000000012432236

Unit: mm (in)

Type of clutch control	Hydraulic
Clutch disc Facing size (Outer dia. × Inner dia. × Thickness)	200 × 140 × 3.1 (7.87 × 5.51 × 0.122)
Recommended clutch fluid	Refer to MA-11, "Fluids and Lubricants" .

Clutch Pedal

INFOID:0000000012432237

Unit: mm (in)

Clutch pedal height	158.8 – 168.8 (6.25 – 6.65)
Clutch pedal height at clutch disengagement	73 (2.87) or more
Clutch pedal play [Looseness at clutch pedal pin]	2 – 8 (0.08 – 0.31) [0 – 1.3 (0 – 0.051)]
Clearance between clutch pedal and clutch interlock switch threaded end while clutch pedal is fully depressed	0.2 – 1.96 (0.0079 – 0.0772)
Clearance between clutch pedal and clutch pedal position switch threaded end while clutch pedal is fully released (if equipped)	0.2 – 1.96 (0.0079 – 0.0772)

Clutch Disc

INFOID:0000000012432238

Unit: mm (in)

Clutch facing runout limit / diameter of the area to be measured	1.0 (0.039) / 190 (7.48) dia.
Maximum allowable spline backlash (at outer edge of disc)	0.8 (0.031)
Clutch facing wear limit (depth to the rivet head)	0.3 (0.012)

Clutch Cover

INFOID:0000000012432239

Unit: mm (in)

Tolerance for diaphragm spring lever unevenness	0.7 (0.028) or less
---	---------------------