
(IG)
10A
GAUGE
4
1A
B–Y
7
I27
Inner Mirror
6
W–B
2
1A
8
1J
W–B
A
J 3
Junction
Connector
IF

○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
I27	64 (*3)	I27	65 (*4)	J3	62

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	26 (*1)	Roof Wire and Driver Side J/B (Lower Finish Panel)
	30 (*2)	
1J	26 (*1)	Cowl Wire and Driver Side J/B (Lower Finish Panel)
	30 (*2)	

▽ : Ground Points

Code	See Page	Ground Points Location
IF	82	Left Kick Panel

* 1 : w/o Daytime Running Light * 2 : w/ Daytime Running Light * 3 : Access Cab * 4 : Standard Cab * 5 : Access Cab Captain Seat
* 6 : Access Cab Separate Seat * 7 : Standard Cab Bench Seat