
(IG)
10A
ECU–IG
1
1M
B–R
7
I27
Inner
Mirror
6
W–B
7
1M
1
1G
W–B
IN

○ : **Parts Location**

Code	See Page	Code	See Page	Code	See Page
I27	76				

: **Junction Block and Wire Harness Connector**

Code	See Page	Junction Block and Wire Harness (Connector Location)
1G	49	Cowl Wire and Driver Side J/B (Lower Finish Panel)
1M	49	Roof Wire and Driver Side J/B (Lower Finish Panel)

▽ : **Ground Points**

Code	See Page	Ground Points Location
IN	92	Right Kick Panel