


1989
BMW 525i/535i (E34)
Electrical
Troubleshooting
Manual
Production 2/89 and Later (All vehicles equipped with KL61 Relay - see page 0670.0-00).

CONTENTS

Index	0100.0-00
Introduction	0110.0-00
Systematic Troubleshooting	0130.0-00
Symbols	0140.0-00
Power Distribution Chart	0670.0-00
Fuse Chart	0670.1-00
Power Distribution	0670.2-00
Ground Distribution	0670.4-00
Component Location Chart	7000.0-00
Component Location Views	7100.0-00
Splice Location Views	8000.0-00
Connector Views Chart	8400.0-00
Connector Views	8500.0-00

Back to Start Page

cardiagn.com

P/N 89 89 1 000 291

Antilock Brake System 3450.0-00
Auxiliary Fan 6454.0-00
Brake Lining Warning 6200.0-01
CD Changer 6510.0-05
Cellular Telephone (Provisions) 6561.0-00
Central Body Electronics 6100.0-00
ZKE Central Locking (ZV) 5126.0-00
Charging Plug 6332.0-00
Charging System 1230.0-00
Check Control 6200.0-00
Cigar Lighter 6332.0-01
Component Location Chart 7000.0-00
Component Location Views 7100.0-00
Connector Views 8500.0-00
Connector Views Chart 8400.0-00
Cruise Control (TEMPOMAT) 6571.0-00
Diagnostic Link 0670.5-00
ZKE Door Lock Heating (TSH) 5120.0-00
E-Box Fan 1290.0-00
Electronic Transmission Control (AEGS) 2460.0-00
Fuse Details
— Fuse 1 . . . . . 0670.3-00
— Fuse 2 . . . . . 0670.3-00
— Fuse 3 . . . . . 0670.3-01
— Fuse 4 . . . . . 0670.3-01
— Fuse 5 . . . . . 0670.3-01
— Fuse 6 . . . . . 0670.3-01
— Fuse 7 . . . . . 0670.3-02
— Fuse 9 . . . . . 0670.3-02
— Fuse 10 . . . . . 0670.3-02
— Fuse 11 . . . . . 0670.3-02
— Fuse 12 . . . . . 0670.3-03
— Fuse 13 . . . . . 0670.3-05
— Fuse 14 . . . . . 0670.3-05
— Fuse 15 . . . . . 0670.3-05
— Fuse 16 . . . . . 0670.3-06
— Fuse 17 . . . . . 0670.3-07
— Fuse 18 . . . . . 0670.3-08
— Fuse 19 . . . . . 0670.3-09
— Fuse 20 . . . . . 0670.3-09
— Fuse 21 . . . . . 0670.3-10
— Fuse 22 . . . . . 0670.3-11
— Fuse 23 . . . . . 0670.3-11
— Fuse 24 . . . . . 0670.3-12
— Fuse 25 . . . . . 0670.3-13
— Fuse 26 . . . . . 0670.3-13
— Fuse 28 . . . . . 0670.3-13
— Fuse 29 . . . . . 0670.3-14
— Fuse 30 . . . . . 0670.3-15
— Fuse 31 . . . . . 0670.3-15
— Fuse 32 . . . . . 0670.3-16
— Fuse 40 . . . . . 0670.3-16
— Fuse 41 . . . . . 0670.3-16
— Fuse 42 . . . . . 0670.3-16
— Fuse 43 . . . . . 0670.3-17
— Fuse 44 . . . . . 0670.3-17
— Fuse 46 . . . . . 0670.3-17
— Fuse 47 . . . . . 0670.3-18
— Fuse 48 . . . . . 0670.3-18
— Fuse 49 . . . . . 0670.3-18
Fuel Pump Gauges
— Fuel 6200.0-07
— Fuel Economy 6200.0-06
— Speedometer 6200.0-06
— Tachometer 6200.0-04
— Temperature 6200.0-04
Ground Distribution
— X165 . . . . . 0670.4-00
— X166 . . . . . 0670.4-01
— X167 . . . . . 0670.4-02
— X173 . . . . . 0670.4-02
— X175 . . . . . 0670.4-03

cardiagn.com

— X179 ..... 0670.4-02
— X490 ..... 0670.4-04
— X491 ..... 0670.4-05
— X492 ..... 0670.4-06
— X493 ..... 0670.4-09
— X495 ..... 0670.4-10
— X496 ..... 0670.4-12
— X497 ..... 0670.4-14
— X818 ..... 0670.4-17
— X955 ..... 0670.4-17
— X1541 (525i) 0670.4-18
— X1541 (535i) 0670.4-20
— X1542 (525i) 0670.4-23
— X1542 (535i) 0670.4-22
— X2008 ..... 0670.4-22
— X8072 ..... 0670.4-17
Heated Seats 5203.0-00
Horn 6133.0-00
IHKR Air Delivery 6450.1-06
IHKR Auxiliary Water Pump 6450.1-09
IHKR Blower Controls 6450.1-01
IHKR Compressor Controls 6450.1-08
IHKR Temperature Controls 6450.1-03
IHKR Water Valves 6450.1-02
Indicators
— "ABS" 3450.0-02
— "Air Bag" 3234.0-00
— Brake Lining Wear 6200.0-01
— "Check Engine" 6200.0-00
— Charge 6200.0-00
— Fog Lights 6312.0-01
— High Beam 6312.0-00
— Left Turn 6313.0-02
— Low Fuel Warning 6200.0-07
— Oil Pressure Warning 6200.0-00
— Park Brake 6200.0-02
— Right Turn 6313.0-02
Injection Electronics (DME 1.3) 1210.2-00
Instrument Cluster 6200.0-00
Lamp Monitor (LKM) 6301.0-00
Lights
— Back Up 6322.0-00
— Brake 6325.0-00
— Front Fog 6312.0-01
— Glove Box 6332.0-00
— Hazard 6313.0-01
— Headlights/Fog Lights 6312.0-00
— Interior Lights (IB) (ZKE) 6330.0-00
— License 6320.0-00
— Makeup Mirror 6300.0-01
— Park/Tail 6314.0-00
— Turn/Hazard 6313.0-00
— Trunk 6320.0-01
— Underhood 6314.0-00
Light Switch Details 6300.0-00
On-Board Computer (BCIV) 6581.0-00
Power Assist Steering 3240.0-00
Power Distribution 0670.2-00
Power Mirrors 5116.0-00
Power Seats 5200.0-00
Power Windows (FH) (ZKE) 5133.0-00
Radio/C.D. Player (Provisions) 6510.0-00
Rear Defogger (IHKR) 6450.1-10
Splice Location Views 8000.0-00
Start
— Automatic Transmission 1240.0-00
— Manual Transmission 1240.0-00
Sunroof (SHD) (ZKE) 5410.0-00
Supplemental Restraint System (Air Bag) 3234.0-00
Windshield Wiper Control (SWS) (ZKE) 6160.0-00
Windshield Washer Jet Heaters 6169.0-00
Windshield Wiper Pressure
Control (ADV) (ZKE) 6164.0-00

cardiagn.com

Schematics

The schematics divide the entire vehicle electrical system into individual circuits. Interacting electrical components are shown on one common schematic.

Switches and other components are represented in such a way that their general layout and function are self-explicit. They are arranged on the sheet such that the current path can be followed from positive (top) to negative (bottom).

Important: The components and wires are not drawn to scale. For instance, a lead with a length of over 1m can be shown as a lead which is only a few cm long. To ensure clear arrangement, all connectors, line branches and connected components from the fuses to the component and from the component to ground connection are not shown within the individual cells. If required, reference can be made to the cells 0670.3 Fuse Details and 0670.4 Ground Distribution where all lines are illustrated with all plug connections, line branches and connected components.


All circuit symbols used are listed and explained in the **0140.0 Symbols**.

In cell **7000.0 Component Location Chart** all important connectors, ground points and components are listed in tabular form. It provides a precise description of the component locations in the vehicle.

In cell **7100.0 Component location views** the locations of the connectors and components which are difficult to locate are shown in photographs.– **This cell is not included in the first issue and will be supplied as a supplement.** – In cell **8400.0 Connector Views Chart**, all connectors with more than 2 pins are listed in tabular form. This chart references the page and figure in cell 8500.0 where a view of the connector can be found. In cell **8500.0 Connector Views** diagrams of all connectors with more than 2 pins are illustrated.

Example

General conventions can be explained based on the following schematic example.



carDiagn.com

General Conventions

1. Switches and relays are always shown in rest position (e.g. K11).

2. A component shown in a dashed frame signifies that the component is illustrated only in part (e.g. P90 and P91).

3. A component shown in a completely drawn frame signifies that the component is illustrated in full (e.g. K11).

4. The dashed line between pin 8 and pin 6 of connector X293 indicates that both pins belong connector X293.

5. The dashed line from fuse 1 to pin 8 of the connector X293 shows the positive supply of the relay K11. If required, refer to cell 0670.3 Fuse details at fuse F1 for the complete line progression with all plug connections, line branches, wire colors and cross sections.

6. The dashed line with arrow at connector X452 indicates that several wires lead to connector X452. All lines leading to the connection are illustrated in cell 6100.0 Central Body Electronics (ZKE). An uninterrupted line with arrow indicates that only this one wire leads to another circuit.

7. The dashed line from pin 4 of connector X293 to ground X493 shows the ground supply for relay K11. If required, refer to cell 0670.4 Ground Distribution at ground X493 for the complete line progression with all plug connections, line branches, wire colors and cross sections.

8. The uninterrupted line from connector X452 with an *A* in the open arrow is continued on Page 6160.0-02. Termination of the wire 4 VI/SW from connector X452 with a wavy line indicates that the wire is continued on the opposite page.

carmanuals.com

TROUBLESHOOTING PROCEDURES

Diagnostic procedures for many of the circuits in this manual are included with the schematics. These procedures are based on a logical problem-solving method. The steps listed below are provided for those circuits that do not include diagnostic procedures. Following these steps will enable you to make a quick diagnosis of the problem.

1. **Verify the Problem**

   Operate the problem circuit to check the accuracy of the complaint. Note the symptoms of the inoperative circuit.

2. **Analyze the Problem**

   Refer to the schematic of the problem circuit in the ETM. Determine how the circuit is supposed to work by tracing the current path(s) from the power feed through the circuit components to ground. Then, based on the symptoms you noted in step 1 and your understanding of circuit operation, identify one or more causes of the problem.

3. **Isolate the Problem**

   Make circuit tests to prove or disprove the preliminary diagnosis made in step 2. Keep in mind that a logical, simple procedure is the key to efficient troubleshooting. Test for the most likely cause of failure first. Try to make tests at points which are easily accessible.

4. **Repair the Problem**

   Once the specific problem is identified, make the repair using the proper tools and safe procedures.

5. **Check the Problem**


   Operate the circuit to check for satisfactory circuit operation. Good repair practice calls for rechecking all circuits you have worked on.

TROUBLESHOOTING TOOLS

Isolating the problem (Step 3 of TROUBLESHOOTING PROCEDURES) requires the use of a voltmeter and/or ohmmeter. A voltmeter measures voltage at selected points in a circuit. An ohmmeter measures a circuit's resistance to current flow. It has an internal battery that provides current to the circuit under test. Disconnect the car battery when using an ohmmeter because the battery voltage will cause the ohmmeter to give false readings. Also, do not use an ohmmeter on solid-state components. The voltage that the ohmmeter applies to the circuit could damage these components.

Fused Jumper Wire

A jumper wire is made up of an in-line fuse holder connected to a set of test leads. It should have a five ampere fuse. Use it for bypassing open circuits. Never use a jumper wire across any load (motors, etc.). This direct battery short will blow the fuse.



Fused Jumper Wire


cardiagn.com

TROUBLESHOOTING TESTS

Voltage Test

This test measures voltage in a circuit. By taking measurements at several points (terminals or connectors) along the circuit, you can isolate the problem.

To take a voltage measurement, connect the negative lead of the voltmeter to the battery's negative terminal or other known good ground. Then connect the positive lead of the voltmeter to the point you want to test. The voltmeter will measure the voltage present at that point in the circuit.




Voltage Test

Voltage Drop Test

Wires, connectors and switches are designed to conduct current with a minimum loss of voltage. A voltage drop of more than one volt indicates a problem.

To test for voltage drop, connect the voltmeter leads to connectors at either end of the circuit's suspected problem area. The positive lead should be connected to the connector closest to the power source. The voltmeter will show the voltage drop between these two points. Any switches in the circuit should be on during this test.




Voltage Drop Test

cardiagn.com

Continuity Test

To perform a continuity test, first disconnect the car battery. Then, while holding the leads together, adjust the ohmmeter to read zero. Connect the ohmmeter leads to connector or terminals at either end of the circuit's suspected problem area. The ohmmeter will show the resistance across that part of the circuit.




Continuity Test

Short Test Using Voltmeter

To locate a wiring short to ground, remove the blown fuse and disconnect the load. Connect the voltmeter leads to the fuse terminals. The positive lead should be connected to the terminal closest to the power source.

Starting near the FRONT POWER DISTRIBUTION BOX, move the wire harness back and forth and watch the voltmeter reading. If the voltmeter registers a reading, there is a short to ground in the wiring. Somewhere in the area of the harness being moved, the wire insulation is worn away and the circuit is grounding.



Short Test Using Voltmeter

cardiagn.com

SYMBOLS



BATTERY



FUSE



CIRCUIT BREAKER



VARIABLE RESISTANCE SENSOR
VARIABLE CONTACT IS MOVED BY AN EXTERNAL FORCE



VARIABLE RESISTOR
RESISTANCE IS CHANGED BY TEMPERATURE OR PRESSURE



DIODE
CURRENT CAN FLOW ONLY IN DIRECTION OF ARROW



ZENER DIODE
TO REGULATE VOLTAGE



LIGHT EMITTING DIODE



LIGHT




BIFILAMENT LIGHT




PERMANENT MAGNET MOTOR
ONE SPEED



PERMANENT MAGNET MOTOR
TWO SPEED




HEATING ELEMENT




LOUDSPEAKER OR HORN

COIL OR SOLENOID




SOLENOID CONTROLLER VALVE OR CLUTCH SOLENOID




TRANSISTORIZED SWITCH

cardiagn.com


SYMBOLS




ENTIRE COMPONENT SHOWN




PART OF A COMPONENT SHOWN



COMPONENT WITH SCREW TERMINALS




CONNECTOR ATTACHED TO COMPONENT



CONNECTOR ATTACHED TO COMPONENT LEAD (PIGTAIL)





COMPONENT CASE DIRECTLY ATTACHED TO METAL PART OF CAR (GROUNDED)





INDICATES THAT FUSE 9 IS SUPPLIED WITH POWER AT ALL TIMES

TERMINAL NUMBER	DESCRIPTION
50	VOLTAGE: IGNITION SWITCH IN START
30	VOLTAGE: SUPPLIED AT ALL TIMES
15	VOLTAGE: IGNITION SWITCH IN RUN OR START
15E	VOLTAGE: IGNITION SWITCH IN RUN
R	VOLTAGE: IGNITION SWITCH IN ACCESSORY, RUN OR START











cardiagn.com




ONE POLE,
TWO POSITION
SWITCH




SWITCHES THAT MOVE
TOGETHER

DASHED LINE SHOWS
A MECHANICAL
CONNECTION BETWEEN
SWITCHES




RELAY WITH NO
CURRENT FLOWING
THROUGH COIL

WHEN COIL IS
ENERGIZED, SWITCH
IS PULLED CLOSED




RELAY WITH
RESISTOR ACROSS
COIL



TERMINAL NUMBER	DESCRIPTION
50	VOLTAGE: IGNITION SWITCH IN START
30	VOLTAGE: SUPPLIED AT ALL TIMES
15	VOLTAGE: IGNITION SWITCH IN RUN OR START
15I	VOLTAGE: IGNITION SWITCH IN RUN
R	VOLTAGE: IGNITION SWITCH IN ACCESSORY, RUN, OR START

cardiagn.com




cardiagn.com


POWER DISTRIBUTION CHARTS

FRONT POWER DISTRIBUTION BOX, AUXILIARY RELAY BOX

P90 FRONT POWER DISTRIBUTION BOX



P92 AUXILARY RELAY BOX



cardiagn.com

POWER DISTRIBUTION CHARTS


FRONT POWER DISTRIBUTION BOX, AUXILIARY RELAY BOX

COMPONENTS IN FRONT POWER DISTRIBUTION BOX		
NUMBER	CONNECTOR	DESCRIPTION
A3	X12	LAMP CONTROL MODULE
A4	X18, X19	CHECK CONTROL MODULE
K1	X55	STARTER RELAY
B900	X55	JUMPER PLUG (MANUAL)
K2	X56	HORN RELAY
K3	X57	UNLOADER RELAY, KLR
K4	X58	BLOWER RELAY
	X62	NOT IN U.S.
K9	X63	UNLOADER RELAY, KL 15
K16	X64	HAZARD FLASHER RELAY
K31		PRESENTLY NOT AVAILABLE
K50	X47	WATER PUMP RELAY
K61	X1021	UNLOADER RELAY KL61
N17	X65	CRASH CONTROL UNIT

COMPONENTS IN AUXILIARY RELAY BOX		
NUMBER	CONNECTOR	DESCRIPTION
K21	X52	NORMAL SPEED RELAY
K22	X53	HIGH SPEED RELAY
K33	X50	AIR CONDITIONING RELAY
K9000	X8063	PHONE HORN ALERT RELAY (WITH CELLULAR TELEPHONE PROVISIONS)
	X61	NOT IN U.S.

cardiagn.com

P91 REAR POWER DISTRIBUTION BOX



cardiagn.com

POWER DISTRIBUTION CHARTS

REAR POWER DISTRIBUTION BOX

COMPONENTS IN REAR POWER DISTRIBUTION BOX		
NUMBER	**CONNECTOR**	**DESCRIPTION**
A1	X253, X254 X255, X332	GENERAL MODULE
A5	X258, X259	RELAY MODULE
K11	X293	WIPER RELAY
K12	X291	WIPER PRESSURE CONTROL RELAY (ADV)
K13	X292	REAR DEFOGGER RELAY
K15	X294	ELECTRIC POWER PROTECTION RELAY
	X297	NOT IN U.S.

cardiagn.com

FUSE	CIRCUIT PROTECTED	
F1 15A	1230.0	Charging System (Also Fuse 28)
	3450.0	ABS Antilock Brake System (Also Fuse 17)
	6200.0	Instrument Cluster Check Control (K/CC) (Also Fuses 15,17, 20)
	6301.0	Lamp Monitor (LKM) (Also Fuses 2, 3, 4, 5, 7, 10, 11, 13, 14, 15)
	6325.0	Brake Lights (Also Fuse 15)
	6571.0	Cruise Control (Tempomat) (Also Fuse 17)
F2 7.5A	6300.0	Light Switch Details (Also Fuses 3, 4, 5, 24)
	6301.0	Lamp Monitor (LKM) (Also Fuses 1, 3, 4, 5, 7, 10, 11, 13, 14, 15)
	6312.0	Headlights/Fog Lights (Also Fuses 3, 5, 7, 10, 11, 13, 14)
	6313.0	Turn/Hazard Lights (Also Fuses 3, 6, 13, 14)
F3 7.5A	6100.0	Central Body Electronics (ZKE) (Also Fuses 5, 15, 17, 30, 44, 47)
	6300.0	Light Switch Details (Also Fuses 2, 4, 5, 24)
	6301.0	Lamp Monitor (LKM) (Also Fuses 1, 2, 4, 5, 7, 10, 11, 13, 14, 15)
	6312.0	Headlights/Fog Lights (Also Fuses 2, 5, 7, 10, 11, 13, 14)
	6313.0	Turn/Hazard Lights (Also Fuses 2, 6, 13, 14)
F4 7.5A	6300.0	Light Switch Details (Also Fuses 2, 3, 5, 24)
	6301.0	Lamp Monitor (LKM) (Also Fuses 1, 2, 3, 5, 7, 10, 11, 13, 14, 15)
	6314.0	Park/Tail/Underhood Lights (Also Fuses 5, 15, 20)
F5 10A	6100.0	Central Body Electronics (ZKE) (Also Fuses 3, 15, 17, 30, 44, 47)
	6300.0	Light Switch Details (Also Fuses 2, 3, 4, 24)
	6301.0	Lamp Monitor (LKM) (Also Fuses 1, 2, 3, 4, 7, 10, 11, 13, 14, 15)
	6312.0	Headlights/Fog Lights (Also Fuses 2, 3, 7, 10, 11, 13, 14)
	6314.0	Park/Tail/Underhood Lights (Also Fuses 4, 15, 20)
	6320.0	License/Trunk Lights (Also Fuses 15, 21)
	6330.0	ZKE Interior Lights (Also Fuses 15, 17, 21, 30, 44)
	6332.0	Glove Box Light/Cigar Lighter/Charging Plug (Also Fuses 18, 21, 26)
F6 7.5A	6313.0	Turn/Hazard Lights (Also Fuses 2, 3, 13, 14)
F7 15A	6301.0	Lamp Monitor (LKM) (Also Fuses 1, 2, 3, 4, 5, 10, 11, 13, 14, 15)
	6312.0	Headlights/Fog Lights (Also Fuses 2, 3, 5, 10, 11, 13, 14)

cardiagn.com

FUSE	CIRCUIT PROTECTED	
F9 15A	6133.0	Horn
	6450.1	Integrated Climate Regulation (IHKR) (Also Fuses 19, 20, 24, 29, 46)
F10 7.5A	6301.0	Lamp Monitor (LKM) (Also Fuses 1, 2, 3, 4, 5, 7, 11, 13, 14, 15)
	6312.0	Headlights/Fog Lights (Also Fuses 2, 3, 5, 7, 11, 13, 14)
F11 7.5A	6301.0	Lamp Monitor (LKM) (Also Fuses 1, 2, 3, 4, 5, 7, 10, 13, 14, 15)
	6312.0	Headlights/Fog Lights (Also Fuses 2, 3, 5, 7, 10, 13, 14)
F12 15A	5116.0	Power Mirrors
	6169.0	Windshield Washer Jet Heaters
	6322.0	Back Up Lights
F13 7.5A	6301.0	Lamp Monitor (LKM) (Also Fuses 1, 2, 3, 4, 5, 7, 10, 11, 14, 15)
	6312.0	Headlights/Fog Lights (Also Fuses 2, 3, 5, 7, 10, 11, 14)
	6313.0	Turn/Hazard Lights (Also Fuses 2, 3, 6, 14)
F14 7.5A	6301.0	Lamp Monitor (LKM) (Also Fuses 1, 2, 3, 4, 5, 7, 10, 11, 13, 15)
	6312.0	Headlights/Fog Lights (Also Fuses 2, 3, 5, 7, 10, 11, 13)
	6313.0	Turn/Hazard Lights (Also Fuses 2, 3, 6, 13)
F15 7.5A	6100.0	Central Body Electronics (ZKE) (Also Fuses 3, 5, 17, 30, 44, 47)
	6160.0	ZKE Windshield Wiper Control (SWS) (Also Fuse 44)
	6164.0	ZKE Windshield Wiper Pressure Control (ADV) (Also Fuses 22, 44)
	6200.0	Instrument Cluster/Check Control (K/CC) (Also Fuses 1, 17, 20)
	6301.0	Lamp Monitor (LKM) (Also Fuses 1, 2, 3, 4, 5, 7, 10, 11, 13, 14)
	6314.0	Park/Tail/Underhood Lights (Also Fuses 4, 5, 20)
	6320.0	License/Trunk Lights (Also Fuses 5, 21)
	6325.0	Brake Lights (Also Fuse 1)
	6330.0	ZKE Interior Lights (Also Fuses 5, 17, 21, 30, 44)
	6581.0	On Board Computer (BCIV) (Also Fuses 17, 20)
F16 30A	5203.0	Heated Seats

cardiagn.com

FUSE	CIRCUIT PROTECTED	
F17 7.5A	1210.2	Injection Electronics (DME 1.3) (Also Fuse 23)
	1240.0	Start
	1290.0	E-Box Fan (Also Fuse 28)
	2460.0	Electronic Transmission Control (AEGS)
	3450.0	Antilock Brake System (ABS) (Also Fuse 1)
	5120.0	ZKE Door Lock Heating (TSH) (Also Fuse 30)
	5133.0	ZKE Power Windows (FH) (Also Fuses 30, 31, 47)
	5410.0	ZKE Sunroof (SHD) (Also Fuses 30, 31, 47)
	6100.0	Central Body Electronics (ZKE) (Also Fuses 3, 5, 15, 30, 44, 47)
	6200.0	Instrument Cluster/Check Control (K/CC) (Also Fuses 1, 15, 20)
	6330.0	ZKE Interior Lights (IB) (Also Fuses 5, 15, 21, 30, 44)
	6571.0	Cruise Control (Tempomat) (Also Fuse 1)
	6581.0	On Board Computer (BCIV) (Also Fuses 15, 20)
F18 15A	6332.0	Glove Box Light/Cigar Lighter/Charging Plug (Also Fuses 5, 21, 26)
	6510.0	Radio/CD Player (Provisions) (Also Fuse 41)
	6561.0	Cellular Telephone (Provisions) (Also Fuses 31, 48)
F19 30A	6450.1	Integrated Climate Regulation (IHKR) (Also Fuses 9, 20, 24, 29, 46)
F20 7.5A	6200.0	Instrument Cluster/Check Control (K/CC) (Also Fuses 1, 15, 17)
	6314.0	Park/Tail/Underhood Lights (Also Fuses 4, 5, 15)
	6450.1	Integrated Climate Regulation (IHKR) (Also Fuses 9, 19, 24, 29, 46)
	6581.0	On Board Computer (BCIV) (Also Fuses 15, 17)
F21 10A	6320.0	License/Trunk Lights (Also Fuses 5, 15)
	6332.0	Glove Box Light/Cigar Lighter/Charging Plug (Also Fuses 5, 18, 26)
	6330.0	ZKE Interior Lights (IB) (Also Fuses 5, 15, 17, 30, 44)
F22 30A	6164.0	ZKE Windshield Wiper Pressure Control (ADV) (Also Fuses 15, 44)

cardiagn.com

FUSE CHARTS

FUSE	CIRCUIT PROTECTED	
F23 7.5A	1210.2	Injection Electronics (DME 1.3) (Also Fuse 17)
F24 7.5A	6300.0 6450.1	Light Switch Details (Also Fuses 2, 3, 4, 5) Integrated Climate Regulation (IHKR) (Also Fuses 9, 19, 20, 29, 46)
F25 30A	6454.0	Auxiliary Fan (Also Fuse 29)
F26 30A	6332.0	Glove Box Light/Cigar Lighter/Charging Plug (Also Fuses 5, 18, 21)
F28 15A	1230.0 1290.0 3240.0	Charging System (Also Fuse 1) E-Box Fan (Also Fuse 17) Power Assist Steering (Servotronic)
F29 7.5A	6450.1 6454.0	Integrated Climate Regulation (IHKR) (Also Fuses 9, 19, 20, 24, 46) Auxiliary Fan (Also Fuse 25)
F30 7.5A	5120.0 5126.0 5133.0 5410.0 6100.0 6330.0	ZKE Door Lock Heating (TSH) (Also Fuse 17) ZKE Central Locking (ZV) (Also Fuses 31, 47) ZKE Power Windows (FH) (Also Fuses 17, 31, 47) ZKE Sunroof (SHD) (Also Fuses 17, 31, 47) Central Body Electronics (ZKE) (Also Fuses 3, 5, 15, 17, 44, 47) ZKE Interior Lights (Also Fuses 5, 15, 17, 21, 44)
F31 7.5A	5126.0 5133.0 5410.0 6561.0	ZKE Central Locking (ZV) (Also Fuses 30, 47) ZKE Power Windows (FH) (Also Fuses 17, 30, 47) ZKE Sunroof (SHD) (Also Fuses 17, 30, 47) Cellular Telephone (Provisions) (Also Fuses 18, 48)
F32 7.5A	NOT USED	
F40 15A	NOT USED	
F41 30A	6510.0	Radio/CD Player (Provisions) (Also Fuse 18)
F42 30A	5200.0	Power Seats (Also Fuse 43)
F43 30A	5200.0	Power Seats (Also Fuse 42)


cardiagn.com

FUSE	CIRCUIT PROTECTED
F44 30A	6100.0 Central Body Electronics (ZKE) (Also Fuses 3, 5, 15, 17, 30, 47) 6160.0 ZKE Windshield Wiper Control (SWS) (Also Fuse 15) 6164.0 ZKE Windshield Wiper Pressure Control (ADV) (Also Fuses 15, 22) 6330.0 ZKE Interior Lights (IB) (Also Fuses 5, 15, 17, 21, 30)
F46 30A	6450.1 Integrated Climate Regulation (IHKR) (Also Fuses 9, 19, 20, 24, 29)
F47 30A	5126.0 ZKE Central Locking (ZV) (Also Fuses 30, 31) 5133.0 ZKE Power Windows (FH) (Also Fuses 17, 30, 31) 5410.0 ZKE Sunroof (SHD) (Also Fuses 17, 30, 31) 6100.0 Central Body Electronics (ZKE) (Also Fuses 3, 5, 15, 17, 30, 44)
F48 15A	6561.0 Cellular Telephone (Provisions) (Also Fuses 18, 31)
F49	NOT USED

cardiagn.com

POWER DISTRIBUTION


FRONT POWER DISTRIBUTION BOX



cardiagn.com

POWER DISTRIBUTION


FRONT POWER DISTRIBUTION BOX




cardiagn.com

POWER DISTRIBUTION

FRONT POWER DISTRIBUTION BOX




cardiagn.com



cardiagn.com

POWER DISTRIBUTION


FRONT POWER DISTRIBUTION BOX



cardiagn.com

POWER DISTRIBUTION


FRONT POWER DISTRIBUTION BOX



cardiagn.com

POWER DISTRIBUTION


REAR POWER DISTRIBUTION BOX



cardiagn.com

POWER DISTRIBUTION


AUXILIARY RELAY BOX



cardiagn.com

FUSE DETAILS


FUSES 1 AND 2



cardiagn.com

FUSE DETAILS


FUSES 3,4,5 AND 6



cardiagn.com

FUSE DETAILS


FUSES 7, 9, 10 AND 11



cardiagn.com

FUSE DETAILS


FUSE 12



cardiagn.com

FUSE DETAILS


FUSE 12



cardiagn.com

FUSE DETAILS


FUSES 13,14 AND 15



cardiagn.com

FUSE DETAILS


FUSE 16



cardiagn.com

FUSE DETAILS


FUSE 17



cardiagn.com

FUSE DETAILS


FUSE 18



cardiagn.com

FUSE DETAILS


FUSES 19 AND 20



cardiagn.com

FUSE DETAILS


FUSE 21



cardiagn.com

FUSE DETAILS


FUSES 22 AND 23



cardiagn.com

FUSE DETAILS


FUSE 24



cardiagn.com

FUSE DETAILS


FUSES 25,26 AND 28



cardiagn.com

FUSE DETAILS


FUSE 29



cardiagn.com

FUSE DETAILS


FUSES 30 AND 31



cardiagn.com

FUSE DETAILS


FUSES 32, 40, 41 AND 42



cardiagn.com

FUSE DETAILS


FUSES 43,44 AND 46



cardiagn.com

FUSE DETAILS


FUSES 47, 48 AND 49



cardiagn.com

GROUND DISTRIBUTION


GROUND X165



cardiagn.com

GROUND DISTRIBUTION


GROUND X166



cardiagn.com

GROUND DISTRIBUTION


GROUNDS X167, X173 AND X179



cardiagn.com

GROUND DISTRIBUTION


GROUND X175



cardiagn.com

GROUND DISTRIBUTION


GROUND X490



cardiagn.com

GROUND DISTRIBUTION


GROUND X491



cardiagn.com

GROUND DISTRIBUTION


GROUND X492



cardiagn.com

GROUND DISTRIBUTION


GROUND X492



carplan.com

GROUND DISTRIBUTION


GROUND X492



cardiagn.com

GROUND DISTRIBUTION


GROUND X493




cardiagn.com

GROUND DISTRIBUTION

GROUND X495




cardiagn.com




cardiagn.com

GROUND DISTRIBUTION

GROUND X496




cardiagn.com



carmanuals.com

GROUND DISTRIBUTION


GROUND X497



cardiagn.com

GROUND DISTRIBUTION


GROUND X497



carplan.com

GROUND DISTRIBUTION


GROUND X497



carDiagn.com

GROUND DISTRIBUTION


GROUNDS X818, X955 AND X8072



cardiagn.com

GROUND DISTRIBUTION

GROUND X1541




cardiagn.com

GROUND DISTRIBUTION

GROUND X1541

525i




cardiagn.com

GROUND DISTRIBUTION

GROUND X1541


535i



cardiagn.com

GROUND DISTRIBUTION


GROUND X1541



cardiagn.com

GROUND DISTRIBUTION

GROUNDS X1542 AND X2008




cardiagn.com

GROUND DISTRIBUTION

GROUND X1542


525i



cardiagn.com

DIAGNOSTIC LINK


BLOCK DIAGRAM



cardiagn.com

DIAGNOSTIC LINK


TXD



cardiagn.com

DIAGNOSTIC LINK


TXD



cardiagn.com

DIAGNOSTIC LINK


RXD



cardiagn.com


DIAGNOSTIC LINK

RXD




cardiagn.com

DIAGNOSTIC LINK




cardiagn.com

DIAGNOSTIC LINK



cardiagn.com


DIAGNOSTIC LINK



cardiagn.com

DIAGNOSTIC LINK


TXD (.5 WS/VI)	20
GROUND X1542 (0670.4) (1.5 BR)	19
A200 MOTRONIC CONTROL UNIT (1210.2) (1.5 GN/BL)	18
NOT USED	17
M201 E-BOX FAN (1290.0) A17 SERVOTRONIC CONTROL UNIT (3240.0) FUSE 28 (0670.3) (1.5 GN/WS)	16
RXD (.5 WS/GE)	15
X1540 B+ JUNCTION POST (1210.2) FOR E-BOX (2.5 RT)	14
NOT USED	13
G2 ALTERNATOR (1230.0) A2 INSTRUMENT CLUSTER (6200.0) A7 ABS CONTROL UNIT (3450.0) (.75 BL)	12
B900 JUMPER PLUG (1240.0) K1 STARTER RELAY (1240.0) M1 STARTER (1240.0) (2.5 SW/GE)	11



NOT USED	10
NOT USED	9
NOT USED	8
A2 INSTRUMENT CLUSTER (6200.0) 7 (.5 WS/GN)	
NOT USED	6
NOT USED	5
NOT USED	4
NOT USED	3
NOT USED	2
T200 IGNITION COIL (1210.2) A200 MOTRONIC CONTROL UNIT (1210.2) 1 (1 SW)	


cardiagn.com

INJECTION ELECTRONICS (DME 1.3)




carlagn.com

INJECTION ELECTRONICS (DME 1.3)




cardiagn.com


INJECTION ELECTRONICS (DME 1.3)




cardiagn.com




cardiagn.com


1210.2-02
L
6 RT/WS
1210.2-08
B
.5 RT/WS
1 RT
ANTILOCK BRAKE SYSTEM 3450.0
X1914
4 RT/WS
2.5 RT/WS
5
2.5 RT/WS
X1912
X1563
X1955
1 RT/WS
.5 RT/WS
.5 RT/WS
.5 RT/WS
.5 RT/WS
.5 RT/WS
.5 RT/WS
.5 RT/WS
1 X1513
Y213
EVAPORATIVE PURGE VALVE
2 X1513
1 X1501
Y201
1
2 X1501
1 X1503
Y203
3
2 X1503
1 X1505
Y205
5
2 X1505
1 X1502
Y202
2
2 X1502
1 X1504
Y204
4
2 X1504
1 X1506
Y206
6
2 X1506
.5 BR/WS
.5 BR/WS
.5 BR/WS
.5 BR/GE
.5 BR/GE
.5 BR/GE
X1954
X1951
.5 BR
1.5 BR/WS
1.5 BR/GE
6
7
X1563
1.5 BR/WS
1.5 BR/GE
E
K
R
S
1210.2-06

carplan.com



POWER DISTRIBUTION 0670.2
X1540
30
.5 RT
6
8
X1516
WITH AEGS
86
30
K202 MAIN RELAY
34
X2000
A300 ELECTRONIC TRANSMISSION CONTROL UNIT (AEGS)
85
87 a
87
31
4
5
2
X1516
6 RT/WS
X1914
1.5 RT/BL
2
X1537
1 RT
.5 RT/WS
4 RT/WS
1 RT/BL
2
X2001
ANTILOCK BRAKE SYSTEM (ABS) 3450.0
B
L
.5 BR
1.5 RT/BL
1.5 RT/BL
35
X2000
1210.2-08
1210.2-05
A300 ELECTRONIC TRANSMISSION CONTROL UNIT (AEGS)
WITH AEGS
31
36
37
18
X1500
A200 MOTRONIC CONTROL UNIT (DME)
31
31
31

carplan.com




cardiagn.com

INJECTION ELECTRONICS (DME 1.3)




cardiagn.com




cardiagn.com

INJECTION ELECTRONICS (DME 1.3)




cardiagn.com

INJECTION ELECTRONICS (DME 1.3)




cardiagn.com

INJECTION ELECTRONICS (DME 1.3)




cardiagn.com

INJECTION ELECTRONICS (DME 1.3)




cardiagn.com


CHARGING SYSTEM



cardiagn.com




cardiagn.com




1240.0-01 535i
1240.0-02 525i

cardiagn.com




cardiagn.com




cardiagn.com

E - BOX FAN




cardiagn.com

ELECTRONIC TRANSMISSION CONTROL (AEGS)




cardiagn.com

ELECTRONIC TRANSMISSION CONTROL (AEGS)




cardiagn.com

ELECTRONIC TRANSMISSION CONTROL (AEGS)




cardiagn.com

ELECTRONIC TRANSMISSION CONTROL (AEGS)



cardiagn.com


ELECTRONIC TRANSMISSION CONTROL (AEGS)



	3	4	5	6
P	1	1	0	0
R	1	0	0	1
N	0	1	1	0
D	0	0	0	1
3	0	0	1	0
2	1	0	0	0
1	1	0	1	0


cardiagn.com

ELECTRONIC TRANSMISSION CONTROL (AEGS)




cardiagn.com

ELECTRONIC TRANSMISSION CONTROL (AEGS)




cardiagn.com

SUPPLEMENTAL RESTRAINT SYSTEM (AIR BAG)




cardiagn.com

SUPPLEMENTAL RESTRAINT SYSTEM (AIR BAG)




cardiagn.com

POWER ASSIST STEERING (SERVOTRONIC)




carplan.com


ANTILOCK BRAKE SYSTEM (ABS)



cardiagn.com



X1540
30
POWER
DISTRIBUTION
0670.2
.5 RT
8
6
X1516
K202
MAIN
RELAY
30
86
87
87a
85
2
5
4
X1516
.5 BR
6 RT/WS
INJECTION
ELECTRONICS
(DME 1.3)
1210.2
X1914
1 RT
4
X79
1 RT
X1202
KL61
CHARGING SYSTEM
1230.0
.5 BL/WS
1 RT
.75 RT
15
1
X11
A7
ABS
ELECTRONIC
CONTROL UNIT
31
31
A7
ABS
ELECTRONIC
CONTROL UNIT
31
31
31
10
34
20
X11
GROUND
DISTRIBUTION
0670.4
GROUND
DISTRIBUTION
0670.4
X497
X166

carplan.com




cardiagn.com

ANTILOCK BRAKE SYSTEM (ABS)




cardiagn.com


ANTILOCK BRAKE SYSTEM (ABS)



cardiagn.com




cardiagn.com



cardiagn.com

ZKE DOOR LOCK HEATING (TSH)


INPUT DETAILS



cardiagn.com

ZKE DOOR LOCK HEATING (TSH)


OUTPUT DETAILS




cardiagn.com

ZKE CENTRAL LOCKING (ZV)

INPUT DETAILS




cardiagn.com



cardiagn.com

ZKE CENTRAL LOCKING (ZV)


OUTPUT DETAILS



cardiagn.com

ZKE CENTRAL LOCKING (ZV)


OUTPUT DETAILS



cardiagn.com

ZKE CENTRAL LOCKING (ZV)


OUTPUT DETAILS



cardiagn.com

ZKE CENTRAL LOCKING (ZV)


OUTPUT DETAILS



cardiagn.com

ZKE POWER WINDOWS (FH)


INPUT DETAILS



cardiagn.com

ZKE POWER WINDOWS (FH)


INPUT DETAILS




cardiagn.com

ZKE POWER WINDOWS (FH)

INPUT DETAILS




cardiagn.com



cardiagn.com

ZKE POWER WINDOWS (FH)


LEFT SIDE OUTPUT DETAILS



cardiagn.com

ZKE POWER WINDOWS (FH)


RIGHT SIDE OUTPUT DETAILS




cardiagn.com

POWER SEATS


DRIVER'S SEAT




cardiagn.com



cardiagn.com




cardiagn.com





cardiagn.com

HEATED SEATS



cardiagn.com







cardiagn.com

ZKE SUNROOF (SHD)

INPUT DETAILS




cardiagn.com



cardiagn.com

ZKE SUNROOF (SHD)


INPUT DETAILS



cardiagn.com

ZKE SUNROOF (SHD)


OUTPUT DETAILS



cardiagn.com

CENTRAL BODY ELECTRONICS (ZKE)


GENERAL MODULE



cardiagn.com

CENTRAL BODY ELECTRONICS (ZKE)


GENERAL MODULE



carDiagn.com

CENTRAL BODY ELECTRONICS (ZKE)


RELAY MODULE



cardiagn.com

CENTRAL BODY ELECTRONICS (ZKE)


RELAY MODULE



cardiagn.com

CENTRAL BODY ELECTRONICS (ZKE)


RELAY MODULE



cardiagn.com


CENTRAL BODY ELECTRONICS (ZKE)

RELAY MODULE



carplan.com


HORN




cardiagn.com

ZKE WINDSHIELD WIPER CONTROL (SWS)

INPUT DETAILS




cardiagn.com



cardiagn.com

ZKE WINDSHIELD WIPER CONTROL (SWS)


OUTPUT DETAILS



cardiagn.com

ZKE WINDSHIELD WIPER PRESSURE CONTROL (ADV) 535i


INPUT DETAILS



cardiagn.com


ZKE WINDSHIELD WIPER PRESSURE CONTROL (ADV) 535i

OUTPUT DETAILS




cardiagn.com

WINDSHIELD WASHER JET HEATERS



cardiagn.com


INSTRUMENT CLUSTER/ CHECK CONTROL (K/CC)



cardiagn.com

INSTRUMENT CLUSTER/ CHECK CONTROL (K/CC)


INPUT DETAILS



cardiagn.com

INSTRUMENT CLUSTER/ CHECK CONTROL (K/CC)


OUTPUT DETAILS



cardiagn.com

INSTRUMENT CLUSTER/ CHECK CONTROL (K/CC)


INDICATORS



cardiagn.com

INSTRUMENT CLUSTER/ CHECK CONTROL (K/CC)


INDICATORS



carlagn.com

INSTRUMENT CLUSTER/ CHECK CONTROL (K/CC)


INDICATORS



cardiagn.com

INSTRUMENT CLUSTER/ CHECK CONTROL (K/CC)


INDICATORS



cardiagn.com


INSTRUMENT CLUSTER/ CHECK CONTROL (K/CC)

GAUGES



cardiagn.com


INSTRUMENT CLUSTER/ CHECK CONTROL (K/CC)



cardiagn.com

INSTRUMENT CLUSTER/ CHECK CONTROL (K/CC)


GAUGES



cardiagn.com

INSTRUMENT CLUSTER/ CHECK CONTROL (K/CC)


GAUGES



carplan.com

INSTRUMENT CLUSTER/ CHECK CONTROL (K/CC)


GAUGES



cardiagn.com

INSTRUMENT CLUSTER/ CHECK CONTROL (K/CC)


GEAR SELECTOR



	3	4	5	6
P	1	1	0	0
R	1	0	0	1
N	0	1	1	0
D	0	0	0	1
3	0	0	1	0
2	1	0	0	0
1	1	0	1	0

cardiagn.com


INSTRUMENT CLUSTER/ CHECK CONTROL (K/CC)



carDiagn.com

INSTRUMENT CLUSTER/ CHECK CONTROL (K/CC)


CHECK CONTROL



cardiagn.com

INSTRUMENT CLUSTER/ CHECK CONTROL (K/CC)


CHECK CONTROL



carlabgr.com

INSTRUMENT CLUSTER/ CHECK CONTROL (K/CC)


DATA LINK



cardiagn.com

INSTRUMENT CLUSTER/ CHECK CONTROL (K/CC)


DATA LINK



cardiagn.com


INSTRUMENT CLUSTER/ CHECK CONTROL (K/CC)

CHECK CONTROL




cardiagn.com

LIGHT SWITCH DETAILS




cardiagn.com

LIGHT SWITCH DETAILS




cardiagn.com

LIGHT SWITCH DETAILS




cardiagn.com

LIGHT SWITCH DETAILS




cardiagn.com

LIGHT SWITCH DETAILS




LIGHT SWITCH DETAILS

IHKR




cardiagn.com

LAMP MONITOR (LKM)




carDiagn.com

LAMP MONITOR (LKM)




cardiagn.com

LAMP MONITOR (LKM)




cardiagn.com

LAMP MONITOR (LKM)




cardiagn.com

LAMP MONITOR (LKM)




carplan.com

LAMP MONITOR (LKM)




cardiagn.com

LAMP MONITOR (LKM)



cardiagn.com


LAMP MONITOR (LKM)



cardiagn.com


LAMP MONITOR (LKM)

DATA LINK




cardiagn.com

LAMP MONITOR (LKM)




carplan.com

HEADLIGHTS/ FOG LIGHTS




carplan.com

HEADLIGHTS/ FOG LIGHTS




cardiagn.com

HEADLIGHTS/ FOG LIGHTS




carplan.com

TURN/ HAZARD LIGHTS




cardiagn.com




cardiagn.com

TURN/ HAZARD LIGHTS




carDiagn.com

TURN/ HAZARD LIGHTS



carDiagn.com


PARK/ TAIL/ UNDERHOOD LIGHTS



carplan.com

PARK/ TAIL/ UNDERHOOD LIGHTS


FRONT AND REAR PARK LIGHTS



carDiagn.com

LICENSE/ TRUNK LIGHTS


LICENSE LIGHTS



cardiagn.com


LICENSE/ TRUNK LIGHTS

TRUNK LIGHTS




cardiagn.com

BACK UP LIGHTS




carldata.com



cardiagn.com


BRAKE LIGHTS



cardiagn.com

ZKE INTERIOR LIGHTS (IB)


INPUT DETAILS



carDiagn.com

ZKE INTERIOR LIGHTS (IB)


INPUT DETAILS



cardiagn.com


ZKE INTERIOR LIGHTS (IB)

OUTPUT DETAILS




cardiagn.com

GLOVE BOX LIGHT/ CIGAR LIGHTER/ CHARGING PLUG




cardiagn.com

GLOVE BOX LIGHT/ CIGAR LIGHTER/ CHARGING PLUG



cardiagn.com


INTEGRATED CLIMATE REGULATION (IHKR)



cardiagn.com

INTEGRATED CLIMATE REGULATION (IHKR)


POWER



cardiagn.com

INTEGRATED CLIMATE REGULATION (IHKR)


BLOWER CONTROLS




cardiagn.com

INTEGRATED CLIMATE REGULATION (IHKR)

BLOWER CONTROLS




WATER VALVES



cardiagn.com

INTEGRATED CLIMATE REGULATION (IHKR)


TEMPERATURE CONTROLS



cardiagn.com

INTEGRATED CLIMATE REGULATION (IHKR)


TEMPERATURE CONTROLS



cardiagn.com

INTEGRATED CLIMATE REGULATION (IHKR)


AIR DELIVERY



cardiagn.com

INTEGRATED CLIMATE REGULATION (IHKR)


AIR DELIVERY



cardiagn.com

INTEGRATED CLIMATE REGULATION (IHKR)


AIR DELIVERY



carplan.com

INTEGRATED CLIMATE REGULATION (IHKR)


COMPRESSOR CONTROLS



cardiagn.com

INTEGRATED CLIMATE REGULATION (IHKR)


AUXILIARY WATER PUMP



cardiagn.com

INTEGRATED CLIMATE REGULATION (IHKR)


REAR WINDOW DEFOGGER



carlagn.com


INTEGRATED CLIMATE REGULATION (IHKR)

DIAGNOSTIC LINK AND STARTER INPUT




cardiagn.com

AUXILIARY FAN



cardiagn.com


AUXILIARY FAN



cardiagn.com

RADIO/ CD PLAYER (PROVISIONS)


HIFI, TEN SPEAKER SYSTEM



cardiagn.com

RADIO/ CD PLAYER (PROVISIONS)


HIFI, TEN SPEAKER SYSTEM



cardiagn.com

RADIO/ CD PLAYER (PROVISIONS)


HIFI, TEN SPEAKER SYSTEM



cardiagn.com

RADIO/ CD PLAYER (PROVISIONS)


HIFI, TEN SPEAKER SYSTEM



cardiagn.com

RADIO/ CD PLAYER (PROVISIONS)


HIFI, TEN SPEAKER SYSTEM



cardiagn.com


RADIO/ CD PLAYER (PROVISIONS)

CD CHANGER (IF EQUIPPED)




cardiagn.com

CELLULAR TELEPHONE (PROVISIONS)




carplan.com




cardiagn.com

CRUISE CONTROL (TEMPOMAT)




cardiagn.com

CRUISE CONTROL (TEMPOMAT)




cardiagn.com

CRUISE CONTROL (TEMPOMAT)




cardiagn.com

CRUISE CONTROL (TEMPOMAT)




carplan.com

ON-BOARD COMPUTER (BCIV)




cardiagn.com

ON-BOARD COMPUTER (BCIV)



carDiagn.com


ON-BOARD COMPUTER (BCIV)



cardiagn.com

ON-BOARD COMPUTER (BCIV)


ANTITHEFT HORN



carplan.com

ON-BOARD COMPUTER (BCIV)


FUEL GAUGE



cardiagn.com

ON-BOARD COMPUTER (BCIV)


CHIME MODULE



carDiagn.com

ON-BOARD COMPUTER (BCIV)

DATA LINK



cardiagn.com

COMPONENT LOCATION CHART

COMPONENTS

			Page-Figure
A1	General Module	Below LH side of rear seat, in P91 Rear Power Distribution Box	7100.0-34-2
A3	Lamp Control Module	LH rear of engine compartment, in P90 Front Power Distribution Box	7100.0-01-1
A4	Check Control Module	LH rear of engine compartment, in P90 Front Power Distribution Box	7100.0-01-1
A5	Relay Module	Below LH side of rear seat, in P91 Rear Power Distribution Box	7100.0-34-2
A7	ABS Electronic Control Unit	In P93 E-Box, behind RH front shock tower	7100.0-13-2
A8	Cruise Control Module (Tempomat)	In P93 E-Box, behind RH front shock tower	7100.0-13-2
A12	Diagnostic Module (SRS)	Behind LH side of dash, on LH side of steering column	7100.0-22-1
A16	Compressor Control Unit	Inside LH kick panel	7100.0-20-3
A17	Servotronic Control Unit	Inside LH kick panel	Not in US
A18	HIFI Amplifier	LH side of luggage compartment, on brace	7100.0-39-1
A31	Defogger Control Unit	Behind center of dash, RH side of IHKR plenum	Not in US
A200	Motronic Control Unit (DME)	In P93 E-Box, behind RH front shock tower	7100.0-13-2
A300	Electronic Transmission Control Unit (AEGS)	Inside RH kick panel	7100.0-29-3
A9000	Integrated Climate Regulation Control Unit (IHKR)	Behind center of dash, ahead of IHKR plenum	7100.0-29-2
B1	Right Front Speed Sensor	Behind RH front wheel	7100.0-17-1
B2	Left Front Speed Sensor	Behind LH front wheel	7100.0-16-3
B3	Right Rear Speed Sensor	Behind RH rear wheel, on axle	7100.0-17-3
B4	Left Rear Speed Sensor	Behind LH rear wheel, on axle	7100.0-17-2
B6	Fuel Tank Sensor	Below luggage compartment, through RH access panel, RH side of spare tire	7100.0-38-3
B7	Low Pressure Switch	RH front of engine compartment, below washer reservoir	7100.0-09-2
B8	High Pressure Switch	RH front of engine compartment below washer reservoir	7100.0-09-2
B9	Intermediate Pressure Switch	RH front of engine compartment, below washer reservoir	7100.0-09-2
B10	Vehicle Speed Sensor	Rear of car, on differential	7100.0-20-2
B11	Left Heat Exchanger Temperature Sensor	Behind LH side of dash, in LH side of IHKR plenum	7100.0-25-1
B12	Right Heat Exchanger Temperature Sensor	Behind RH side of dash, in RH side of IHKR plenum	7100.0-29-1

carcdan.com

COMPONENT LOCATION CHART

COMPONENTS

			Page-Figure
B13	Outside Temperature Sensor	Behind center of cowl, on RH side of M30 Blower Motor	7100.0-15-3
B14	Evaporator Temperature Sensor	Behind LH side of dash, on lower LH side of IHKR plenum	7100.0-25-2
B15	Electro-Hydraulic Converter (Servotronic)	Lower LH front of engine compartment, behind LH front wheel	Not in US
B16	Left Front Brake Pad Sensor	Behind LH front wheel, on caliper	7100.0-16-3
B17	Right Rear Brake Pad Sensor	Behind RH rear wheel, on caliper	7100.0-17-3
B18	Brake Fluid Level Switch (M20 Engine)	LH rear of engine compartment, top of brake fluid reservoir	7100.0-02-2
B18	Brake Fluid Level Switch (M30 Engine)	LH rear of engine compartment, top of brake fluid reservoir	7100.0-02-3
B21	On-Board Computer Temperature Sensor	Under LH side of front bumper	7100.0-16-2
B201	Cylinder Identification Sensor	RH front of engine, near distributor	7100.0-10-3
B202	Engine Speed/Reference Point Sensor	Front of engine, below distributor	7100.0-10-3
B203	Oxygen Sensor (M30 Engine)	In top of catalyst, near rear of transmission	7100.-19-3
B203	Oxygen Sensor (M20 Engine)	Lower RH side of engine compartment	7100.0-12-3
B204	Coolant Temperature Sensor (M30 Engine)	On coolant inlet, near valve cover	7100.0-10-2
B204	Coolant Temperature Sensor (M20 Engine)	On coolant inlet, near valve cover	7100.0-10-1
B205	Oil Level Sensor (M20 Engine)	On bottom of oil pan	7100.0-18-1
B205	Oil Level Sensor (M30 Engine)	On bottom of oil pan	7100.0-18-2
B206	Oil Pressure Switch (M30 Engine)	Top rear of engine, rear of cylinder head	7100.0-15-2
B206	Oil Pressure Switch (M20 Engine)	Lower LH front of engine	7100.0-19-1
B207	Coolant Temperature Sender (M30 Engine)	On coolant inlet, near valve cover	7100.0-10-2
B207	Coolant Temperature Sender (M20 Engine)	On coolant inlet, near valve cover	7100.0-10-1
B208	Air Flow Meter (M20 Engine)	LH side of engine	7100.0-05-3
B208	Air Flow Meter (M30 Engine)	Top center of engine, ahead of oil fill cap	7100.0-12-2
B210	Temperature Switch	In P93 E-Box, behind RH front shock tower	7100.0-14-1
B900	Jumper Plug	LH rear of engine compartment, in P90 Front Power Distribution Box	7100.0-00-3
C100	Contact Ring	Inside steering wheel	7100.0-23-2

carpages.com

COMPONENT LOCATION CHART

COMPONENTS

			Page-Figure
C900	Defogger Coupler	In RH "C" Pillar	7100.0-38-2
D100	Diagnostic Connector	LH rear of engine compartment, RH side of shock tower	7100.0-01-3
E48	Door Lock Heater	In door, at key lock assembly	
E51	Left Washer Jet Heater	Under cover, on engine hood	7100.0-07-3
E52	Right Washer Jet Heater	Under cover, on engine hood	7100.0-08-1
E56	Driver's Seatback Heater	In back of driver's seat	
E57	Driver's Seat Heater	In driver's seat	
E58	Passenger's Seat Heater	In passenger's seat	
E59	Passenger's Seatback Heater	In back of passenger's seat	
F0	Fusible Link 80A	RH side of engine compartment	7100.0-09-3
F99	Fusible Link 50A (535i)	Below RH side of rear seat	7100.0-36-3
F99	Fusible Link 50A (525i)	Below RH side of rear seat	7100.0-36-1
G1	Battery (M30 Engine)	Below RH side of rear seat	7100.0-36-3
G1	Battery (M20 Engine)	RH front of engine compartment	7100.0-09-3
G2	Alternator	Lower LH front of engine	7100.0-06-3
G5	Driver's Air Bag Generator	Inside center of steering wheel	7100.0-23-2
H2	Left Horn	Front of car, behind grille	7100.0-08-2
H3	Right Horn	Front of car, behind grille	7100.0-08-2
H10	Chime Module	Behind LH side of dash, mounted in hush panel	7100.0-21-3
H60	Audible Turn-Signal Relay	Below steering column	7100.0-24-1
H9002	On Board Computer Antitheft Horn	Behind center of cowl	7100.0-15-3
K1	Starter Relay	LH rear of engine compartment, in P90 Front Power Distribution Box	7100.0-00-3
K2	Horn Relay	LH rear of engine compartment, in P90 Front Power Distribution Box	7100.0-00-3
K3	Unloader Relay, KLR	LH rear of engine compartment, in P90 Front Power Distribution Box	7100.0-00-3
K4	Blower Relay	LH rear of engine compartment, in P90 Front Power Distribution Box	7100.0-00-3

cardiagn.com

COMPONENT LOCATION CHART

COMPONENTS

			Page-Figure
K5	Washer Pump Relay	LH rear of engine compartment, in P90 Front Power Distribution Box	Not in US
K9	Unloader Relay, KL15	LH rear of engine compartment, in P90 Front Power Distribution Box	7100.0-01-1
K11	Wiper Relay	Below LH side of rear seat, on P91 Rear Power Distribution Box	7100.0-34-3
K12	Wiper Pressure Control (ADV) Relay	Below LH side of rear seat, on P91 Rear Power Distribution Box	7100.0-34-2
K13	Rear Defogger Relay	Below LH side of rear seat, on P91 Rear Power Distribution Box	7100.0-34-3
K15	Electric Power Protection Relay	Below LH side of rear seat, on P91 Rear Power Distribution Box	7100.0-34-3
K16	Hazard Flasher Relay	LH rear of engine compartment, in P90 Front Power Distribution Box	7100.0-00-3
K21	Normal Speed Relay	LH side of engine compartment, in P92 Auxiliary Relay Box	7100.0-04-1
K22	High Speed Relay	LH side of engine compartment, in P92 Auxiliary Relay Box	7100.0-04-1
K33	Air Conditioning Relay	LH side of engine compartment, in P92 Auxiliary Relay Box	7100.0-04-1
K50	Water Pump Relay	LH rear of engine compartment, in P90 Front Power Distribution Box	7100.0-01-1
K91	On-Board Computer Horn Relay	Below LH side of rear seat, ahead of P91 Rear Power Distribution Box	7100.0-35-1
K201	Fuel Pump Relay (M20 Engine)	In P93 E-Box, behind RH front shock tower	7100.0-14-1
K201	Fuel Pump Relay (M30 Engine)	In P93 E-Box, behind RH front shock tower	7100.0-13-3
K202	Main Relay (M20 Engine)	In P93 E-Box, behind RH front shock tower	7100.0-14-1
K202	Main Relay (M30 Engine)	In P93 E-Box, behind RH front shock tower	7100.0-13-3
K203	Oxygen Sensor Relay	In P93 E-Box, behind RH shock tower	7100.0-13-3
M1	Starter (M20 Engine)	LH side of engine, below intake manifold	7100.0-03-1

carmanuals.com

COMPONENT LOCATION CHART

COMPONENTS

			Page-Figure
M1	Starter (M30 Engine)	LH side of engine, below intake manifold	7100.0-03-2
M2	Fuel Pump	Below luggage compartment, RH side of spare tire	7100.0-38-3
M3	Wiper Motor	Behind LH side of fresh air cowl	7100.0-00-1
M4	Washer Pump	RH front of engine compartment, on washer fluid reservoir	7100.0-09-1
M5	Intensive Wash Pump	RH front of engine compartment, on washer fluid reservoir	Not in US
M6	Wiper Pressure Control Motor (ADV)	Behind LH side of fresh air cowl	7100.0-00-2
M9	Auxiliary Fan Motor	Center front of engine compartment, behind bumper	7100.0-08-2
M12	Driver's Door Lock Motor	Top rear of driver's door	7100.0-30-3
M13	Passenger's Door Lock Motor	Top rear of passenger's door	7100.0-30-3
M14	Right Rear Door Lock Motor	Top rear of RH rear door	7100.0-31-2
M15	Left Rear Door Lock Motor	Top rear of LH rear door	7100.0-31-2
M16	Gas Filler Lock Motor	In luggage compartment, behind RH wheel well	7100.0-39-2
M17	Trunk Lock Motor	In trunk lid, RH side of lid lock assembly	7100.0-40-2
M20	Left Rear Window Motor	Lower front of LH rear door	7100.0-31-2
M21	Driver's Window Motor	Lower front of driver's door	7100.0-30-3
M22	Right Rear Window Motor	Lower front of RH rear door	7100.0-31-2
M23	Passenger's Window Motor	Lower front of passenger's door	7100.0-30-3
M24	Sunroof Motor	In center of windshield header, near rear view mirror	7100.0-25-3
M25	Cruise Control Actuator (Tempomat)	Left center of engine compartment, ahead of shock tower	7100.0-05-2
M30	Blower Motor	Behind center of cowl	7100.0-15-3
M31	Left Footwell Flap Motor	Behind LH side of dash, on LH side of IHKR plenum	7100.0-25-1
M32	Right Footwell Flap Motor	Behind RH side of dash, on RH side of IHKR plenum	7100.0-29-1
M34	Right Mixing Flap Motor	Behind center of dash, RH side of N9 Radio	7100.0-29-1
M35	Defroster Flap Motor	Behind LH side of dash, on lower LH side of IHKR plenum	7100.0-25-1
M36	Fresh Air Flap Motor	Behind LH side of dash, on LH side of IHKR plenum	7100.0-25-1
M37	Water Pump	LH rear of engine compartment, on engine bulkhead	7100.0-02-1
M40	Air Circulation Flap Motor	Behind LH side of dash, on LH side of IHKR plenum	7100.0-25-1

carDiagn.com

COMPONENT LOCATION CHART

COMPONENTS

			Page-Figure
M50	Driver's Seat Cushion Tilt Motor	Under LH side of driver's seat	7100.0-31-3
M51	Driver's Seat Movement Motor	Under RH side of driver's seat	7100.0-32-1
M52	Driver's Seat Height Motor	Under front of driver's seat	7100.0-31-3
M53	Driver's Seatback Recliner Motor	Under front of driver's seat	7100.0-31-3
M54	Driver's Headrest Motor	In top RH corner of driver's seatback	7100.0-34-1
M57	Passenger's Seat Headrest Motor	In top RH corner of passenger's seatback	7100.0-34-1
M58	Passenger's Seatback Recliner Motor	Under front of passenger's seat	7100.0-32-3
M59	Passenger's Seat Height Motor	Under front of passenger's seat	7100.0-32-3
M60	Passenger's Seat Movement Motor	Under RH side of passenger's seat	7100.0-32-3
M61	Passenger's Seat Cushion Tilt Motor	Under LH side of passenger's seat	7100.0-32-3
M201	E-Box Fan	In P93 E-Box, below modules	7100.0-14-2
N2	Final Stage Unit	In LH side of RH footwell, ahead of IHKR plenum	7100.0-29-2
N4	On-Board Computer	Center of dash, RH side of N9 Radio	7100.0-26-2
N8	Antenna Amplifier	In LH "C" pillar	7100.0-38-1
N17	Crash Control Unit	LH rear of engine compartment, in P90 Front Power Distribution Box	7100.0-01-1
P90	Front Power Distribution Box	LH rear of engine compartment	7100.0-02-1
P91	Rear Power Distribution Box	Below LH side of rear seat	7100.0-34-2
P92	Auxiliary Relay Box	LH side of engine compartment, ahead of shock tower	7100.0-05-2
P93	E-Box	RH side of engine, behind RH front shock tower	7100.0-13-1
R1	Temperature Distribution Potentiometer	Behind center of dash, above N9 Radio	7100.0-26-2
S10000	Rear Vent Flap Switch	In rear of console, on rear vent flap	
S2	Ignition Switch	Top RH side of steering column	7100.0-24-1
S3	Automatic Transmission Range Switch	Under console, at base of gear shifter	7100.0-28-1
S4	Horn Switch	Top of steering column, in steering wheel	
S7	Combination Switch	Inside top of steering column	7100.0-23-3
S13	Passenger's Door Jamb Switch	In center rear of passenger's door jamb, in latch assembly	
S14	Driver's Door Jamb Switch	In center rear of driver's door jamb, in latch assembly	
S15	Right Rear Door Jamb Switch	In top of RH rear door jamb, in latch assembly	
S16	Left Rear Door Jamb Switch	In top rear of LH rear door jamb, in latch assembly	

cardiag.com

COMPONENT LOCATION CHART

COMPONENTS

			Page-Figure
S19	Underhood Light Switch	LH front of hood	7100.0-07-2
S21	Engine Hood Switch	LH rear of engine compartment, rear of shock tower	7100.0-01-1
S22	Battery Switch	Under RH side of rear seat, near battery	Not in US
S24	Rear Seat Switch	Under RH side of rear seat, right of battery	Not in US
S27	Inertia Switch	Below center of rear seat, RH side of P91 Rear Power Distribution Box	7100.0-35-3
S29	Brake Light Switch	Behind LH side of dash, on brake pedal support bracket	7100.0-22-1
S31	Park Brake Switch	Below console, on rear of park brake lever	7100.0-28-2
S32	Clutch Switch	Behind LH side of dash, on clutch pedal support bracket	
S36	Temperature Switch	RH top of radiator	7100.0-08-3
S37	Glove Box Light Switch	In LH side of glove box	7100.0-28-3
S39	Sunroof Position Switch	In center of windshield header, near rear view mirror	7100.0-25-3
S43	Driver's Window Limit Switch	Center front of driver's door	7100.0-30-3
S44	Passenger's Window Limit Switch	Center front of passenger's door	7100.0-30-3
S45	Left Rear Window Limit Switch	Center front of LH rear door	7100.0-31-2
S46	Right Rear Window Limit Switch	Center front of RH rear door	7100.0-31-2
S47	Driver's Door Lock Switch	Behind driver's door lock assembly	
S48	Driver's Door Handle Switch	In top rear of driver's door, near door handle cable	
S49	Passenger's Door Lock Switch	Behind passenger's door lock assembly	
S58	Driver's Seat Belt Switch	In driver's seat belt buckle	
S61	Trunk Lid Switch	In center of trunk lid, in trunk latch assembly	7100.0-40-1
S63	Coolant Level Switch	Top of coolant reservoir	7100.0-12-2
S64	Washer Fluid Level Switch	RH side of washer fluid reservoir	7100.0-09-1
S70	Safety Switch	LH side of engine compartment, near S71 Left Front Crash Sensor	
S71	Left Front Crash Sensor	Ahead of LH shock tower	7100.0-04-1
S72	Right Front Crash Sensor	Ahead of RH shock tower	7100.0-11-3
S77	Driver's Makeup Mirror Switch	In driver's visor	
S78	Passenger's Makeup Mirror Switch	In passenger's visor	
S200	Throttle Switch (M20 Engine)	LH rear of engine	7100.0-03-3

carDiagn.com

COMPONENT LOCATION CHART

COMPONENTS

			Page-Figure
S200	Throttle Switch (M30 Engine)	Top of engine, on throttle body	7100.0-12-2
S301	Transmission Kickdown Switch	Behind LH side of dash, underneath accelerator pedal	7100.0-24-3
S302	Back-Up Switch	Top RH side of transmission	
S901	Passenger's Visor Switch	LH hinge of passenger's visor	7100.0-26-1
S902	Driver's Visor Switch	RH hinge of driver's visor	7100.0-26-1
T200	Ignition Coil	RH side of engine compartment, at strut tower	7100.0-14-3
V6	Diode	Behind center of dash	
X779	Charging Plug	In LH side of glove box	7100.0-28-3
Y1	ABS Hydraulic Unit (M30 Engine)	LH center of engine compartment, near shock tower	7100.0-02-3
Y1	ABS Hydraulic Unit (M20 Engine)	LH center of engine compartment, near shock tower	7100.0-02-2
Y2	Compressor Clutch	Lower RH front of engine	7100.0-18-3
Y4	Water Valve Assembly	LH rear of engine compartment, on engine bulkhead	7100.0-02-1
Y201	Fuel Injector 1	Top of engine, near B207 Coolant Temperature Sender	7100.0-12-1
Y202	Fuel Injector 2	Top of engine, on intake manifold	7100.0-12-1
Y203	Fuel Injector 3	Top of engine, on intake manifold	7100.0-12-1
Y204	Fuel Injector 4	Top of engine, on intake manifold	7100.0-12-1
Y205	Fuel Injector 5	Top of engine, on intake manifold	7100.0-12-1
Y206	Fuel Injector 6	Top of engine, on intake manifold	7100.0-12-1
Y213	Fuel Air Valve (M20 Engine)	LH rear of engine	7100.0-03-3
Y213	Fuel Air Valve (M30 Engine)	LH side of engine, RH side of oil filter	7100.0-04-3
Y214	Idle Speed Actuator (M20 Engine)	On center rear of throttle body	7100.0-05-3
Y214	Idle Speed Actuator (M30 Engine)	On center rear of throttle body	7100.0-12-2
Y300	Transmission	LH rear side of transmission	7100.0-19-2
X1.0	Junction Post for Front Power Distribution Box	Behind LH side of dash, under carpet	7100.0-21-2
X1.1	Junction Post for Front Power Distribution Box	LH rear of engine compartment, in P90 Front Power Distribuiton Box	7100.0-01-2
X1.2	Junction Post for Front Power Distribution Box	LH rear corner of engine compartment, in P90 Front Power Distribution Box	7100.0-01-2
X13	Connector (21 pins)	Below LH side of dash, below driver's footrest (White)	7100.0-21-1
X14	Connector (30 pins)	Below LH side of dash, below driver's footrest (Yellow)	7100.0-21-1

carmanuals.com

COMPONENT LOCATION CHART

COMPONENTS

			Page-Figure
X15	Connector (30 pins)	Below LH side of dash, near kick panel	7100.0-22-2
X16	Connector (26 pins)	Behind LH side of dash, on rear of A2 Instrument Cluster (Yellow)	7100.0-24-2
X17	Connector (24 pins)	Behind LH side of dash, on rear of A2 Instrument Cluster (Brown)	7100.0-24-2
X18	Connector (26 pins)	LH rear of engine compartment, on A4 Check Control Module (Blue)	
X19	Connector (26 pins)	LH rear of engine compartment, on A4 Check Control Module (Green)	
X20	Connector (20 pins)	LH rear of engine compartment, near shock tower	7100.0-01-3
X22	Connector (26 pins)	RH rear of engine compartment, on A8 Cruise Control Module (Tempomat)(Blue)	7100.0-13-3
X31	Connector (12 pins)	LH center of engine compartment, on Y1 ABS Hydraulic Unit, under plastic cover	
X32	Connector (12 pins)	Behind LH side of dash, LH side of steering column	7100.0-22-2
X33	Connector (12 pins)	Behind LH side of dash, near kick panel	7100.0-22-2
X34	Connector (21 pins)	Behind LH side of dash, near kick panel	7100.0-22-2
X35	Connector (21 pins)	Behind LH side of dash, near kick panel	7100.0-22-3
X61	Connector (9 pins)	LH rear of engine compartment, inside P92 Auxiliary Relay Box	7100.0-04-1
X62	Connector (9 pins)	LH rear of engine compartment, in P90 Front Power Distribution Box	7100.0-00-3
X71	Connector (8 pins)	Above E26 Left Fog Light	7100.0-16-1
X72	Connector (8 pins)	Behind LH side of dash, LH side of steering column	7100.0-22-2
X74	Connector (8 pins)	Behind LH side of dash, above footrest	7100.0-23-1
X75	Connector (6 pins)	Behind LH side of dash, above footrest	7100.0-23-1
X79	Connector (4 pins)	In P93 E-Box, behind RH front shock tower	7100.0-14-1
X81	Connector (3 pins)	Ahead of LH shock tower	7100.0-04-1
X83	Connector (3 pins)	Inside LH kick panel (Yellow)	7100.0-20-3
X84	Connector (3 pins)	Inside LH kick panel (Yellow)	7100.0-20-3

cardiagn.com

COMPONENT LOCATION CHART

COMPONENTS

		Page-Figure
X85	Connector (3 pins) — LH rear of engine compartment	7100.0-01-3
X86	Connector (3 pins) — Ahead of RH shock tower	7100.0-11-3
X88	Connector (3 pins) — Behind LH side of dash, on LH side of steering column	7100.0-22-3
X105	Connector (2 pins) — On engine hood, under cover	7100.0-07-3
X106	Connector (2 pins) — On engine hood, under cover	7100.0-08-1
X110	Connector (2 pins) — RH front corner of engine compartment	7100.0-09-1
X113	Connector (2 pins) — RH rear of engine compartment, near base of shock tower	7100.0-11-2
X114	Connector (2 pins) — LH rear of engine compartment, bottom of shock tower	7100.0-04-2
X118	Connector (2 pins) — On LH front wheel, above brake caliper	7100.0-16-3
X120	Connector (2 pins) — LH side of engine compartment	7100.0-04-2
X121	Connector (2 pins) — Behind LH side of dash, near clutch switch	7100.0-22-3
X122	Connector (2 pins) — LH rear of engine compartment, on engine bulkhead	7100.0-01-3
X126	Connector (2 pins) — RH front corner of engine compartment	7100.0-09-2
X127	Connector (2 pins) — RH front corner of engine compartment	7100.0-09-2
X146	Connector (1 pin) — LH rear of engine compartment, in P90 Front Power Distribution Box	
X163	Connector (3 pins) — RH front of engine compartment, near Y2 Compressor Clutch	7100.0-11-1
X165	Ground (Dash) — Behind LH side of dash, LH side of steering column	7100.0-22-1
X166	Ground — RH front of engine compartment, ahead of wheel well	7100.0-09-2
X167	Ground — LH front of engine compartment, ahead of wheel well	7100.0-06-2
X170	Terminal Post — LH side of engine compartment, on Y1 ABS Hydraulic Unit	7100.0-04-2
X175	Ground — LH front of engine compartment, ahead of wheel well	7100.0-06-2
X179	Ground — RH front of engine compartment, ahead of wheel well	7100.0-09-2
X251	Connector (30 pins) — Behind LH side of dash, LH side of steering column	7100.0-22-1
X252	Connector (26 pins) — Below LH side of rear seat	7100.0-35-1
X253	Connector (26 pins) — Below LH side of rear seat, on A1 General Module (Green)	

cardiagn.com

COMPONENT LOCATION CHART

COMPONENTS

			Page-Figure
X254	Connector (26 pins)	Below LH side of rear seat, on A1 General Module (White)	
X255	Connector (26 pins)	Below LH side of rear seat, on A1 General Module (Yellow)	
X256	Connector (26 pins)	Inside front of RH front door jamb, in wire grommet housing	7100.0-30-1
X257	Connector (26 pins)	Inside front of LH front door jamb, in wire grommet housing	7100.0-30-1
X258	Connector (20 pins)	Below LH side of rear seat, on A5 Relay Module (White)	
X259	Connector (20 pins)	Below LH side of rear seat, on A5 Relay Module (Black)	
X260	Connector (21 pins)	Below RH side of rear seat, near battery (Black)	7100.0-37-3
X262	Connector (26 pins)	Below LH side of rear seat	7100.0-34-2
X269	Connector (6 pins)	Below LH side of rear seat	7100.0-34-3
X271	Connector (12 pins)	Behind LH side of dash, on rear of A2 Instrument Cluster (Gray)	7100.0-24-2
X272	Connector (12 pins)	Below LH side of rear seat, near P91 Rear Power Distribution Box	7100.0-34-2
X273	Connector (12 pins)	Inside front of LH rear door jamb, in wire grommet housing	7100.0-30-2
X274	Connector (12 pins)	Inside front of RH rear door jamb, in wire grommet housing	7100.0-30-2
X275	Connector (12 pins)	Under driver's seat	7100.0-32-1
X277	Connector (10 pins)	Inside front of LH rear door jamb, in wire grommet housing	7100.0-30-2
X278	Connector (10 pins)	Inside front of RH rear door jamb, in wire grommet housing	7100.0-30-2
X279	Connector (12 pins)	Under passenger's seat	7100.0-33-2
X295	Connector (8 pins)	Behind LH side of dash, LH side of steering column	7100.0-22-2
X297	Connector (9 pins)	Below LH side of rear seat	
X316	Connector (6 pins)	On S40 Front Console Window Switch Assembly (White)	7100.0-28-2
X317	Connector (6 pins)	On S40 Front Console Window Switch Assembly (Black)	7100.0-28-2

cardiagn.com

COMPONENT LOCATION CHART

COMPONENTS

			Page-Figure
X318	Connector (4 pins)	In trunk, behind E17 Right Rear Light Assembly	7100.0-39-2
X319	Connector (4 pins)	In trunk, behind E16 Left Rear Light Assembly	7100.0-39-1
X322	Connector (6 pins)	Below LH side of rear seat, near P91 Rear Power Distribution Box	7100.0-34-2
X328	Connector (4 pins)	RH side of trunk lid, on E47 Right Trunk Light Assembly	7100.0-40-2
X329	Connector (4 pins)	LH side of trunk lid, on E46 Left Trunk Light Assembly	7100.0-39-3
X331	Connector (5 pins)	Below LH side of rear seat, on K91 On-Board Computer Horn Relay (Green)	
X332	Connector (5 pins)	Below LH side of rear seat, on A1 General Module (White)	
X333	Connector (4 pins)	Behind LH fresh air cowl	7100.0-00-1
X334	Connector (4 pins)	Behind LH fresh air cowl	7100.0-00-1
X335	Connector (4 pins)	Below LH side of rear seat, on K91 On-Board Computer Horn Relay (Green)	
X336	Connector (4 pins)	In center of windshield header	7100.0-25-3
X337	Connector (4 pins)	Below LH side of rear seat	7100.0-34-3
X342	Connector (4 pins)	Behind RH side of dash, above RH kick panel	7100.0-29-3
X355	Connector (3 pins)	In RH "C" pillar	7100.0-38-2
X356	Connector (3 pins)	In LH "C" pillar	7100.0-38-1
X358	Connector (3 pins)	In RH rear of trunk lid	7100.0-40-2
X360	Connector (2 pins)	In LH side of windshield header, above LH visor	
X371	Connector (2 pins)	Behind LH fresh air cowl	7100.0-00-1
X374	Connector (2 pins)	Below RH side of rear seat	7100.0-37-2
X375	Connector (2 pins)	Below RH side of rear seat	7100.0-37-1
X376	Connector (2 pins)	Below LH side of rear seat, behind P91 Rear Power Distribution Box	7100.0-34-2
X377	Connector (2 pins)	Below RH side of rear seat, behind battery	7100.0-37-1
X393	Connector (6 pins)	In LH rear corner of trunk	7100.0-39-1
X400	Connector (3 pins)	LH rear corner of trunk	7100.0-39-1
X416	Connector (2 pins)	LH side of windshield header, near LH visor	
X417	Connector (2 pins)	RH side of windshield header, near RH visor	

cardiagn.com

COMPONENT LOCATION CHART

COMPONENTS

			Page-Figure
X418	Connector (1 pin)	Below LH side of rear seat	7100.0-35-1
X490	Ground	Behind LH side of dash, LH side of steering column	7100.0-22-1
X491	Ground	Behind LH side of dash, LH side of steering column	7100.0-22-1
X492	Ground	Below LH side of rear seat, near P91 Rear Power Distribution Box	7100.0-35-2
X493	Ground	Below LH side of rear seat, near P91 Rear Power Distribution Box	7100.0-35-2
X495	Ground	Below RH side of rear seat, RH side of battery	7100.0-36-3
X496	Ground	Below RH side of rear seat, RH side of battery	7100.0-36-3
X497	Ground (Battery)	Ahead of RH side of rear seat, under carpet	7100.0-36-2
X501	Connector (26 pins)	Behind center of dash, on N4 On-Board Computer	
X502	Connector (26 pins)	Behind LH side of dash, on rear of A2 Instrument Cluster (White)	7100.0-24-2
X506	Connector (12 pins)	Below center console, front of gear shifter	7100.0-28-1
X511	Connector (8 pins)	Below center console	7100.0-28-1
X512	Connector (8 pins)	Behind RH side of dash, taped to harness	
X514	Connector (6 pins)	Behind center of dash, in harness	
X518	Connector (4 pins)	Behind LH side of dash, on H10 Chime Module (Black)	7100.0-21-3
X522	Connector (3 pins)	Behind LH side of dash, on H10 Chime Module (White)	7100.0-21-3
X526	Connector (8 pins)	Below LH side of dash, at kick panel	7100.0-22-2
X539	Connector (2 pins)	Behind center of dash, LH side of N9 Radio	
X546	Connector (2 pins)	Below center console, LH side of manual gear selector	7100.0-27-3
X605	Connector (12 pins)	LH side of trunk, on A18 HIFI Amplifier (Black)	
X606	Connector (12 pins)	LH side of trunk, on A18 HIFI Amplifier (White)	
X610	Connector (26 pins)	Behind center of dash, on A9000 Integrated Climate Regulation Control Unit (IHKR) (White)	7100.0-25-2
X611	Connector (26 pins)	Behind center of dash, on A9000 Integrated Climate Regulation Control Unit (IHKR) (Green)	7100.0-25-2
X612	Connector (26 pins)	Behind center of dash, on S9000 Integrated Climate Regulation Switch (IHKR) (Blue)	7100.0-27-2

cardiagn.com

COMPONENT LOCATION CHART

COMPONENTS

			Page-Figure
X613	Connector (26 pins)	Behind center of dash, on A9000 Integrated Climate Regulation Control Unit (IHKR) (Blue)	7100.0-29-2
X614	Connector (26 pins)	Behind center of dash, on A9000 Integrated Climate Regulation Control Unit (IHKR) (Yellow)	7100.0-29-2
X623	Connector (4 pins)	In top front of driver's door	
X624	Connector (4 pins)	In top front of passenger's door	
X627	Connector (8 pins)	In center of windshield header	7100.0-25-3
X633	Connector (8 pins)	Behind center of dash, near N9 Radio	7100.0-26-3
X638	Connector (8 pins)	Below trunk, RH side of spare tire	7100.0-38-3
X652	Connector (6 pins)	Under driver's seat	7100.0-32-1
X659	Connector (6 pins)	Under passenger's seat	7100.0-33-3
X684	Connector (3 pins)	In passenger's door, near door handle	7100.0-31-1
X685	Connector (3 pins)	In driver's door, near door handle	7100.0-31-1
X692	Connector (3 pins)	Behind center of dash, behind LH side of N9 Radio	7100.0-27-1
X693	Connector (3 pins)	Behind center of dash, on S9000 Integrated Climate Regulation Switch (IHKR) (Black)	7100.0-27-2
X702	Connector (2 pins)	Behind center of dash, on N9 Radio (White)	7100.0-26-3
X703	Connector (2 pins)	Behind center of dash, on N9 Radio (Black)	7100.0-26-3
X705	Connector (2 pins)	Below car, near RH rear suspension frame attachment point	7100.0-20-1
X713	Connector (2 pins)	At RH rear wheel, above brake caliper	7100.0-17-3
X714	Connector (2 pins)	In lower rear of LH rear door	7100.0-31-2
X715	Connector (2 pins)	In center rear of LH rear door	7100.0-31-2
X720	Connector (2 pins)	In lower rear of RH rear door	7100.0-31-2
X721	Connector (2 pins)	In center rear of RH rear door	7100.0-31-2
X726	Connector (2 pins)	Under RH side of driver's seat	7100.0-32-1
X727	Connector (2 pins)	Under LH side of driver's seat	7100.0-32-2
X728	Connector (2 pins)	Under front of driver's seat	7100.0-31-3
X729	Connector (2 pins)	Under front of driver's seat	7100.0-31-3
X731	Connector (2 pins)	Inside RH side of driver's seatback	7100.0-34-1

cardiagn.com

COMPONENTS

			Page-Figure
X732	Connector (2 pins)	In driver's seatback, near driver's seatback heater	7100.0-34-1
X733	Connector (2 pins)	Under RH side of driver's seat	7100.0-32-1
X734	Connector (2 pins)	Under RH side of passenger's seat	7100.0-33-2
X735	Connector (2 pins)	Under LH side of passenger's seat	7100.0-33-3
X736	Connector (2 pins)	Under front of passenger's seat	7100.0-33-1
X737	Connector (2 pins)	Under front of passenger's seat	7100.0-33-1
X738	Connector (2 pins)	Inside RH side of passenger's seatback	7100.0-34-1
X740	Connector (2 pins)	Under RH side of passenger's seat	7100.0-33-1
X741	Connector (2 pins)	In passenger's seatback, near passenger's seatback heater	7100.0-34-1
X742	Connector (2 pins)	In passenger's door, near door handle	7100.0-31-1
X743	Connector (2 pins)	In center front of passenger's door	7100.0-30-3
X744	Connector (2 pins)	In lower front of pasenger's door	7100.0-30-3
X747	Connector (2 pins)	In driver's door, near door handle	7100.0-31-1
X749	Connector (2 pins)	In lower front of driver's door	7100.0-30-3
X750	Connector (2 pins)	In center front of passenger's door	7100.0-30-3
X751	Connector (2 pins)	In driver's door, near door handle	7100.0-31-1
X752	Connector (2 pins)	In driver's door, near door handle	7100.0-31-1
X770	Connector (2 pins)	Under LH side of front bumper	7100.0-16-2
X771	Connector (2 pins)	Behind LH side of dash, on lower LH side of IHKR plenum	7100.0-25-2
X778	Connector (2 pins)	Under driver's seat, near base of driver's seat belt buckle	7100.0-32-2
X783	Connector (2 pins)	Below steering column	7100.0-24-1
X784	Connector (2 pins)	Behind LH side of dash, at kick panel	7100.0-22-1
X789	Connector (2 pins)	Rear of car, near differential	7100.0-20-2
X800	Connector (2 pins)	Inside LH kick panel	7100.0-20-3
X803	Connector (2 pins)	Behind center of dash, on N9 Radio (Black)	7100.0-27-1
X804	Connector (2 pins)	Behind center of dash, on N9 Radio (White)	7100.0-27-1
X813	Connector (1 pin)	Behind center of dash, on N9 Radio (Black)	7100.0-27-1
X815	Connector (1 pin)	Behind center of dash, near N9 Radio	7100.0-27-1

carDiagn.com

COMPONENT LOCATION CHART

COMPONENTS

			Page-Figure
X818	Ground	Below LH side of dash, LH side of steering column	7100.0-22-1
X910	B+ Junction Post	LH rear of engine compartment	7100.0-01-3
X948	Connector (1 pin)	In LH "C" pillar	7100.0-38-1
X949	Connector (1 pin)	In LH "C" pillar	7100.0-38-1
X951	Connector (1 pin)	In RH "C" pillar	7100.0-38-2
X952	Connector (1 pin)	In RH "C" pillar	7100.0-38-2
X953	Connector (1 pin)	In LH "C" pillar	7100.0-38-1
X955	Ground (Battery)	Lower RH front of engine compartment	7100.0-18-3
X960	B+ Junction Post	Behind LH side of dash, near accelerator pedal	7100.0-25-1
X962	B+ Junction Post	RH side of engine compartment, inside cover	7100.0-09-3
X963	B+ Junction Post	Below RH side of rear seat, inside cover	7100.0-36-1
X964	B+ Junction Post	Lower LH rear of engine compartment, on M1 Starter	7100.0-03-1
X1521	Conector (3 pins) (M20 Engine)	LH side of engine	7100.0-06-1
X1521	Connector (3 pins) (M30 Engine)	Top front of engine	7100.0-10-2
X1522	Connector (3 pins) (M20 Engine)	LH front of engine	7100.0-06-1
X1522	Connector (3 pins) (M30 Engine)	Top front of engine	7100.0-10-2
X1523	Connector (4 pins) (M20 Engine)	RH rear of engine, LH side of P93 E-Box	7100.0-15-1
X1523	Connector (4 pins) (M30 Engine)	Lower LH rear side of engine	7100.0-04-3
X1525	Connector (3 pins) (M20 Engine)	LH front of engine	7100.0-07-1
X1525	Connector (3 pins) (M30 Engine)	Lower LH front of engine	7100.0-05-1
X1532	Diagnostic Connector D100 (20 pins)	LH rear of engine compartment, RH side of shock tower	7100.0-01-3
X1533	Connector (3 pins)	Lower LH rear side of engine	7100.0-04-3
X1537	Connector (8 pins)	In P93 E-Box, behind RH front shock tower	7100.0-14-1
X1540	B+ Junction Post for E-Box	In P93 E-Box, behind RH front shock tower	7100.0-13-2
X1541	Ground	RH rear of engine compartment, near shock tower	7100.0-14-3
X1542	Ground	RH rear of engine compartment, near shock tower	7100.0-14-3
X1563	Connector (7 pins)	LH side of engine, in front of M1 Starter	7100.0-03-1
X2001	Connector (12 pins)	Behind glove box, in RH corner	7100.0-29-3
X2005	Connector (8 pins)	On LH side of transmission	7100.0-19-2
X2008	Ground	Below RH side of rear seat, RH side of battery	7100.0-37-2

cardiagn.com

COMPONENT LOCATION CHART

COMPONENTS

		Page-Figure
X9000 . . . Connector (2 pins)	Behind center of dash, on N9 Radio (Black)	7100.0-26-3
X9997 . . . Connector (2 pins)	Inside steering wheel, on G5 Driver's Air Bag Generator	7100.0-23-2

cardiagn.com




Figure 1- Behind LH Fresh Air Cowl

M3 Wiper Motor
X333 Connector (4 pins) SW
X334 Connector (4 pins) WS
X371 Connector (2 pins) SW




Figure 2- Behind LH Fresh Air Cowl

M6 Wiper Pressure Control Motor (ADV)




Figure 3- LH Rear Corner Of Engine Compartment

B900 Jumper Plug
K1 Starter Relay
K2 Horn Relay
K3 Unloader Relay, KLR
K4 Blower Relay
K16 Hazard Flasher Relay
X62 Connector (9 pins) WS

carmanuals.com

COMPONENT LOCATION VIEWS




Figure 1- LH Rear Corner Of Engine Compartment

A3 Lamp Control Module
A4 Check Control Module
K9 Unloader Relay, KL15
K50 Water Pump Relay
N17 Crash Control Unit
S21 Engine Hood Switch




Figure 2- LH Rear Corner Of Engine Compartment

X1.1 Junction Post For Front Power Distribution Box
X1.2 Junction Post For Front Power Distribution Box




Figure 3- LH Rear Of Engine Compartment (M30 Engine Shown; M20 Engine Similar)

D100 Diagnostic Connector
X20 Connector (20 pins) SW
X85 Conenctor (3 pins) SW
X122 Connector (2 pins) SW
X1532 Diagnostic Connector (20 pins) SW
X910 B+ Junction Post

cardiagn.com




Figure 1- LH Rear Of Engine Compartment (M30 Engine Shown; M20 Engine Similar)

M37 Water Pump
P90 Front Power Distribution Box
Y4 Water Valve Assembly




Figure 2- LH Side Of Engine Compartment (M20 Engine)

M18 Brake Fluid Level Switch
Y1 ABS Hydraulic Unit




Figure 3- LH Side Of Engine Compartment (M30 Engine)

B18 Brake Fluid Level Switch
Y1 ABS Hydraulic Unit

carDiagn.com




Figure 1- LH Side Of Engine Compartment (M20 Engine)

M1 Starter
X964 B+ Junction Post
X1563 Connector (7 pins) SW




Figure 2- LH Rear Of Engine (M30 Engine)

M1 Starter




Figure 3- LH Rear Of Engine (M20 Engine)

S200 Throttle Switch
Y213 Fuel Air Valve

carmanuals.com




Figure 1- Top LH Side Of Engine Compartment (M30 Engine Shown; M20 Engine Similar)

K21 Normal Speed Relay
K22 High Speed Relay
K33 Air Conditioning Relay
S71 Left Front Crash Sensor
X61 Connector (9 pins) SW
X81 Connector (3 pins) OR




Figure 2- Lower LH Side Of Engine Compartment (M30 Engine Shown; M20 Engine Similar)

X114 Connector (2 pins) WS
X120 Connector (2 pins) SW
X170 Terminal Post




Figure 3- Lower LH Side of Engine (M30 Engine)

Y213 Fuel Air Valve
X1523 Connector (4 pins) SW
X1533 Connector (3 pins) SW

carcdagh.com




Figure 1- Lower LH Side Of Engine (M30 Engine)

X1525 Connector (3 pins) SW




Figure 2- LH Side Of Engine Compartment (M20 Engine shown; M30 Engine Similar)

M25 Cruise Control Actuator (Tempomat)
P92 Auxiliary Relay Box




Figure 3- Top LH Side Of Engine Compartment (M20 Engine)

B208 Air Flow Meter
Y214 Idle Speed Actuator

cardiagn.com




Figure 1- Lower LH Side Of Engine (M20 Engine) (Air Cleaner Assembly Removed)

X1521 Connector (3 pins) SW
X1522 Connector (3 pins) SW




Figure 2- LH Front Of Engine Compartment (M30 Engine Shown; M20 Engine Similar)

X167 Ground
X175 Ground



Figure 3- Lower LH Front Of Engine Compartment (M30 Engine Shown; M20 Engine Similar)

G2 Alternator

carlabgh.com




Figure 1- Lower LH Front Of Engine (M20 Engine) (Air Flow Assembly Removed)

X1525 Connector (3 pins) SW



Figure 2- LH Front Of Engine Hood

S19 Underhood Light Switch




Figure 3- Rear Of Engine Compartment Hood

E51 Left Washer Jet Heater
X105 Connector (2 pins) SW

cardiagn.com




Figure 1- Rear Of Engine Compartment Hood

E52 Right Washer Jet Heater
X106 Connector (2 pins) SW




Figure 2- Front Of Car (Grille Removed)

H2 Left Horn
H3 Right Horn
M9 Auxiliary Fan Motor




Figure 3- RH Front Of Engine Compartment (M30 Engine Shown; M20 Engine Similar)

S36 Temperature Switch

carlagn.com




Figure 1- RH Front Of Engine Compartment (M30 Engine Shown; M20 Engine Similar)

M4 Washer Pump
S64 Washer Fluid Level Switch
X110 Connector (2 pins) BL




Figure 2- RH Front Of Engine Compartment (Washer Fluid Reservoir Removed)

B7 Low Pressure Switch
B8 High Pressure Switch
B9 Intermediate Pressure Switch
X126 Connector (2 pins) WS
X127 Conector (2 pins) SW
X166 Ground
X179 Ground




Figure 3- RH Front Of Engine Compartment (M20 Engine)

F0 Fusible Link 80A
G1 Battery
X962 B+ Junction Post

carDiagn.com




Figure 1- Top Front Of Engine (M20 Engine)

B204 Coolant Temperature Sensor
B207 Coolant Temperature Sender




Figure 2- Top Front Of Engine (M30 Engine)

B204 Coolant Temperature Sensor
B207 Coolant Temperature Sender
X1521 Connector (3 pins) SW
X1522 Connector (3 pins) SW



Figure 3- RH Front Of Engine (M20 Engine Shown; M30 Engine Similar)

B201 Cylinder Identification Sensor
B202 Engine Speed/Reference Point Sensor

cardiagn.com



Figure 1- RH Front Of Engine (M20 Engine Shown; M30 Engine Similar)

X163 Connector (3 pins) SW




Figure 2- Lower RH Side Of Engine Compartment (M20 Engine Shown, M30 Engine Similar)

X113 Connector (2 pins) WS




Figure 3- RH Side Of Engine Compartment (M30 Engine Shown, M20 Engine Similar)

S72 Right Front Crash Sensor
X86 Connector (3 pins) OR

cardiagn.com




Figure 1- Top Of Engine (M20 Engine Shown; M30 Engine Similar)

Y201 Fuel Injector 1
Y202 Fuel Injector 2
Y203 Fuel Injector 3
Y204 Fuel Injector 4
Y205 Fuel Injector 5
Y206 Fuel Injector 6




Figure 2- Top Rear Of Engine (M30 Engine)

B208 Air Flow Meter
S63 Coolant Level Switch
S200 Throttle Switch
Y214 Idle Speed Actuator



Figure 3- Lower RH Rear Of Engine (M20 Engine Shown; M30 Engine Similar)

B203 Oxygen Sensor

cardiagn.com




Figure 1- RH Rear Of Engine Compartment

P93 E-Box




Figure 2- RH Rear Of Engine Compartment

A7 ABS Electronic Control Unit
A8 Cruise Control Module (Tempomat)
A200 Motronic Control Unit (DME)
X1540 B+ Junction Post for E-Box




Figure 3- RH Rear Of Engine Compartment (M30 Engine)

K201 Fuel Pump Relay
K202 Main Relay
K203 Oxygen Sensor Relay
X22 Connector (26 pins) BL

carbagh.com




Figure 1- RH Rear Of Engine Compartment (M20 Engine)

B210 Temperature Switch
K201 Fuel Pump Relay
K202 Main Relay
X79 Connector (4 pins) WS
X1537 Connector (8 pins) SW




Figure 2- RH Rear Of Engine Compartment (M30 Engine Shown; M20 Engine Similar) Modules Removed

M201 E-Box Fan




Figure 3- RH Rear Of Engine Compartment (M30 Engine Shown; M20 Engine Similar)

T200 Ignition Coil
X1541 Ground
X1542 Ground

cardiagn.com




Figure 1- RH Rear Of Engine Compartment (M20 Engine)

X1523 Connector (4 pins) SW




Figure 2- Rear Of Engine (M30 Engine)

B206 Oil Pressure Switch




Figure 3- Behind Center Of Cowl Panel

B13 Outside Temperature Sensor
H9002 On Board Computer Antitheft Horn
M30 Blower Motor

cardiagn.com

COMPONENT LOCATION VIEWS




Figure 1- Under LH Side Of Front Bumper

X71 Connector (8 pins) SW




Figure 2- Under LH Side Of Front Bumper

B21 On-Board Computer Temperature Sensor
X770 Connector (2 pins) WS




Figure 3- Behind LH Front Wheel

B2 Left Front Speed Sensor
B16 Left Front Brake Pad Sensor
X118 Connector (2 pins) SW

carbagn.com




Figure 1- Behind RH Front Wheel

B1 Right Front Speed Sensor




Figure 2- Behind LH Rear Wheel

B4 Left Rear Speed Sensor




Figure 3- Behind RH Rear Wheel

B3 Right Rear Speed Sensor
B17 Right Rear Brake Pad Sensor
X713 Connector (2 pins) SW

cardiagn.com




Figure 1- Lower LH Front Of Engine (M20 Engine)

B205 Oil Level Sensor




Figure 2- Lower Front Of Engine (M30 Engine)

B205 Oil Level Sensor




Figure 3- Lower RH Front Of Engine (M20 Engine Shown; M30 Engine Similar)

Y2 Compressor Clutch
X955 Ground

carbagn.com




Figure 1- Lower RH Side Of Engine (M20 Engine)

B206 Oil Pressure Switch




Figure 2- LH Side Of Transmission

Y300 Transmission
X2005 Connector (8 pins) SW




Figure 3- LH Side Of Transmission (M30 Engine)

B203 Oxygen Sensor

carmanuals.com




Figure 1- Front Of RH Wheel Well

X705 Connector (2 pins) SW




Figure 2- Rear Of Car, On Differential

B10 Vehicle Speed Sensor
X789 Connector (2 pins) GE




Figure 3- Inside LH Kick Panel

A16 Compressor Control Unit
X83 Connector (3 pins) GE
X84 Connector (3 pins) GE
X800 Connector (2 pins) WS

cardiagn.com




Figure 1- Below LH Side Of Dash, Below Driver's Footrest

X13 Connector (21 pins) WS
X14 Connector (30 pins) GE




Figure 2- Behind LH Side Of Dash

X1.0 Junction Post For Front Power Distribution Box




Figure 3- Behind LH Side Of Dash

H10 Chime Module
X518 Connector (4 pins) SW
X522 Connector (3 pins) WS

cardiagn.com




Figure 1- Behind LH Side Of Dash, LH Side Of Steering Column

A12 Diagnostic Module (SRS)
S29 Brake Light Switch
X251 Connector (30 pins) SW
X784 Connector (2 pins) OR
X165 Ground
X490 Ground
X491 Ground
X818 Ground




Figure 2- Behind LH Side Of Dash, LH Side Of Steering Column

X15 Connector (30 pins) WS
X32 Connector (12 pins) WS
X33 Connector (12 pins) SW
X34 Connector (21 pins) WS
X72 Connector (8 pins) WS
X295 Connector (8 pins) SW
X526 Connector (8 pins) SW




Figure 3- Behind LH Side Of Dash, LH Side Of Steering Column

X35 Connector (21 pins) SW
X88 Connector (3 pins) SW
X121 Connector (2 pins) WS

carlagh.com




Figure 1- Behind LH Side Of Dash, LH Side Of Steering Column

X74 Connector (8 pins) OR
X75 Connector (6 pins) OR




Figure 2- Inside Steering Wheel

C100 Contact Ring
G5 Driver's Air Bag Generator
X9997 Connector (2 pins) OR




Figure 3- Top Of Steering Column (Steering Wheel Removed)

S7 Combination Switch

cardiagn.com




Figure 1- Underside Of Steering Column

H60 Audible Turn-Signal Relay
S2 Ignition Switch
X783 Connector (2 pins) OR




Figure 2- Rear Of Instrument Cluster

X16 Connector (26 pins) GE
X17 Connector (24 pins) BR
X271 Conenctor (12 pins) GR
X502 Connector (26 pins) WS




Figure 3- Below LH Side Of Dash

S301 Transmission Kickdown Switch

carlabh.com




Figure 1- Behind Center Of Dash, LH Side Of IHKR Plenum

B11 Left Heat Exchanger Temperature Sensor
M31 Left Footwell Flap Motor
M35 Defroster Flap Motor
M36 Fresh Air Flap Motor
M40 Air Circulation Flap Motor
X960 B+ Junction Post




Figure 2- Behind Center Of Dash, LH Side Of IHKA Plenum

B14 Evaporator Temperature Sensor
X610 Connector (26 pins) WS
X611 Connector (26 pins) GN
X771 Connector (2 pins) SW




Figure 3- Center Of Windshield Header

M24 Sunroof Motor
S39 Sunroof Position Switch
X336 Connector (4 pins) WS
X627 Connector (8 pins) SW

cardiagn.com




Figure 1- Center Of Winshield Header

S901 Passenger's Visor Switch
S902 Driver's Visor Switch




Figure 2- Center Of Dash

N4 On-Board Computer Module
R1 Temperature Distribution Potentiometer




Figure 3- Behind Center Of Dash

X633 Connector (8 pins) SW
X702 Connector (2 pins) WS
X703 Connector (2 pins) SW
X9000 Connector (2 pins) SW

cardiagn.com

COMPONENT LOCATION VIEWS




Figure 1- Behind Center Of Dash

X692 Connector (3 pins) SW
X803 Connector (2 pins) SW
X804 Connector (2 pins) WS
X813 Connector (1 pin) SW
X815 Connector (1 pin) WS




Figure 2- Behind Center Of Dash

X612 Connector (26 pins) BL
X693 Connector (3 pins) SW



Figure 3- Below Center Console

X546 Connector (2 pins) WS

carpagr.com




Figure 1- Below Center Console (Console Removed)

S3 Automatic Transmission Range Switch
X506 Connector (12 pins) SW
X511 Connector (8 pins) SW




Figure 2- Below Center Console (Console Removed)

S31 Park Brake Switch
X316 Connector (6 pins) WS
X317 Connector (6 pins) SW




Figure 3- In LH Side Of Glove Box

S37 Glove Box Light Switch
X779 Charging Plug

carDiagn.com




Figure 1- Behind Center Of Dash, RH Side of IHKR Plenum

B12 Right Heat Exchanger Temperature Sensor
M32 Right Footwell Flap Motor
M34 Right Mixing Flap Motor




Figure 2- Behind Center Of Dash LH Side Of IHKA Plenum

A9000 Integrated Climate Regulation Control Unit (IHKR)
N2 Final Stage Unit
X613 Connector (26 pins) BL
X614 Connector (26 pins) GE




Figure 3- Behind RH Side Of Dash, at Kick Panel

A300 Electronic Transmission Control Unit (AEGS)
X342 Connector (4 pins) WS
X2001 Connector (12 pins) SW

cardiagn.com




Figure 1- RH Front Dor Jamb (LH Similar)

X256 Connector (RH) (26 pins) GR
X257 Connector (LH) (26 pins) GR




Figure 2- LH Rear Door Jamb (RH Similar)

X273 Connector (LH) (12 pins) GR
X274 Connector (RH) (12 pins) GR
X277 Connector (LH) (10 pins) BL
X278 Connector (RH) (10 pins) BL




Figure 3- Behind Door Panel (Driver's Shown; Passenger's Similar)

M12 Driver's Door Lock Motor
M13 Passenger's Door Lock Motor
M21 Driver's Window Motor
M23 Passenger's Window Motor
S43 Driver's Window Limit Switch
S44 Passenger's Window Limit Switch
X743 Connector (2 pins) (RH) SW
X744 Connector (2 pins) (RH) BL
X749 Connector (2 pins) (LH) BL
X750 Connector (2 pins) (LH) SW

carmanualsonline.info




Figure 1- Driver's Door (Passenger's Similar)

X684 Connector (3 pins) (RH) SW
X685 Connector (3 pins) (LH) SW
X742 Connector (2 pins) (RH) GE
X747 Connector (2 pins) (LH) GE
X751 Connector (2 pins) BL
X752 Connector (2 pins) WS




Figure 2- Behind LH Rear Door Panel (RH Rear Similar)

M14 Right Rear Door Lock Motor
M15 Left Rear Door Lock Motor
M20 Left Rear Window Motor
M22 Right Rear Window Motor
S45 Left Rear Window Limit Switch
S46 Right Rear Window Limit Switch
X714 Connector (2 pins) (LH) BL
X715 Connector (2 pins) (LH) SW
X720 Connector (2 pins) (RH) BL
X721 Connector (2 pins) (RH) SW




Figure 3- Under Driver's Seat

M50 Driver's Seat Cushion Tilt Motor
M52 Driver's Seat Height Motor
M53 Driver's Seatback Recliner Motor
X728 Connector (2 pins) SW
X729 Connector (2 pins) WS

carmanualsonline.com




Figure 1- Under Driver's Seat

M51 Driver's Seat Movement Motor
X275 Connector (12 pins) WS
X652 Connector (6 pins) BL
X726 Connector (2 pins) WS
X733 Connector (2 pins) WS




Figure 2- Under Driver's Seat

X727 Connector (2 pins) SW
X778 Connector (2 pins) SW




Figure 3- Under Passenger's Seat

M58 Passenger's Seatback Recliner Motor
M59 Passenger's Seat Height Motor
M60 Passenger's Seat Movement Motor
M61 Passenger's Seat Cushion Tilt Motor

cardiagn.com




Figure 1- Under Passenger's Seat

X736 Connector (2 pins) WS
X737 Connector (2 pins) SW
X740 Connector (2 pins) WS




Figure 2- Under Passenger's Seat

X279 Connector (12 pins) WS
X734 Connector (2 pins) WS




Figure 3- Under Passenger's Seat

X659 Connector (6 pins) BL
X735 Connector (2 pins) SW

cardiagn.com




Figure 1- Inside Back Of LH Front Seat (RH Similar)

M54 Driver's Headrest Motor
M57 Passenger's Headrest Motor
X731 Connector (2 pins) (LH) WS
X732 Connector (2 pins) (LH) WS
X738 Connector (2 pins) (RH) WS
X741 Connector (2 pins) (RH) WS




Figure 2- Below LH Side Of Rear Seat

A1 General Module
A5 Relay Module
K12 Wiper Pressure Control (ADV) Relay
P91 Rear Power Distribution Box
X262 Connector (26 pins) BL
X272 Connector (12 pins) SW
X322 Connector (6 pins) SW
X376 Connector (2 pins) WS




Figure 3- Below LH Side Of Rear Seat

K11 Wiper Relay
K13 Rear Defogger Relay
K15 Electric Power Protection Relay
X269 Connector (6 pins) SW
X337 Connector (4 pins) WS

cardiagn.com




Figure 1- Below LH Side Of Rear Seat (Rear Power Distribution Box Removed)

K91 On-Board Computer Horn Relay
X252 Connector (26 pins) GN
X418 Connector (1 pin) GE




Figure 2- Below LH Side Of Rear Seat

X492 Ground
X493 Ground




Figure 3- Below LH Side Of Rear Seat

S27 Inertia Switch

carmanuals.com




Figure 1- Below RH Side Of Rear Seat (525i)

F99 Fusible Link 50A
X963 B+ Junction Post




Figure 2- Ahead Of RH Side Of Rear Seat

X497 Ground (Battery)




Figure 3- Below RH Side Of Rear Seat (535i Shown; 525i Similar)

F99 Fusible Link
G1 Battery
X495 Ground
X496 Ground

cardiagn.com

COMPONENT LOCATION VIEWS




Figure 1- Below RH Side Of Rear Seat (535i Shown; 525i Similar)

X375 Connector (3 pins) SW
X377 Connector (2 pins) WS




Figure 2- Below RH Side Of Rear Seat (535i Shown; 525i Similar)

X374 Connector (3 pins) SW
X2008 Ground




Figure 3- Below RH Side Of Rear Seat (535i Shown; 525i Similar)

X260 Connector (21 pins) SW

carmanuals.com




Figure 1- LH "C" Pillar

N8 Antenna Amplifier
X356 Connector (3 pins) WS
X948 Connector (1 pin) SW
X949 Connector (1 pin) SW
X953 Connector (1 pin) SW




Figure 2- RH "C" Pillar

C900 Defogger Coupler
X355 Connector (3 pins) WS
X951 Connector (1 pin) SW
X952 Connector (1 pin) SW




Figure 3- RH Side Of Luggage Compartment, Below Maintenance Cover

B6 Fuel Tank Sensor
M2 Fuel Pump
X638 Connector (8 pins) SW

carlabg.com




Figure 1- LH Side Of Luggage Compartment

A18 HIFI Amplifier
X319 Connector (4 pins) SW
X393 Conenctor (6 pins) SW
X400 Conector (3 pins) SW




Figure 2- RH Side Of Luggage Compartment

M16 Gas Filler Lock Motor
X318 Connector (4 pins) SW




Figure 3- LH Rear Of Trunk Lid

X329 Connector (4 pins) SW

cardiagn.com




Figure 1- Center Rear Of Trunk Lid

S61 Trunk Lid Switch




Figure 2- RH Rear Of Trunk Lid

M17 Trunk Lock Motor
X328 Connector (4 pins) SW
X358 Connector (3 pins) SW

carlabgr.com

SPLICE LOCATION VIEWS

INDEX


This index contains all the splices in the car, what harness each one is in, and the page that the splices appear on. The drawings after the index show how the harness is routed through the car and where the splices are located on the harness.

Splice	Harness	Page
X181-X246	Front	8000.0-01
X433-X479	Rear	8000.0-05
X557-X584	Instrument	8000.0-04
X831	Sunroof	Not shown
X833	Rear	8000.0-05
X834	LH Rear Door	Not shown
X835	RH Rear Door	Not shown
X836	Driver's Seat	Not shown
X839-X843	Driver's Seat	Not shown
X844-X847	Passenger's Seat	Not shown
X848-X851	Driver's Door	Not shown
X852-X860	IHKR	Not shown
X863	Passenger's Door	Not shown
X864-X865	Park Ventilation	Not shown
X1022	Front	8000.0-01
X1023	Front	8000.0-01
X1029	Front	8000.0-01
X1043	Front	8000.0-01
X1047	Front	8000.0-01
X1159	Front	8000.0-01
X1202	Front	8000.0-01
X1359	Rear	8000.0-05
X1360	Rear	8000.0-05
X2010	AEGS	Not shown

cardiagn.com

SPLICE LOCATION VIEWS

FRONT HARNESS




X189 ●
X202 ●

X181 ●	X195 ●	X206 ●	X223 ●	X1022 ●
X182 ●	X196 ●	X207 ●	X225 ●	X1023 ●
X183 ●	X197 ●	X208 ●	X226 ●	X1029 ●
X184 ●	X198 ●	X209 ●	X227 ●	X1043 ●
X185 ●	X199 ●	X212 ●	X228 ●	X1047 ●
X188 ●	X200 ●	X213 ●	X241 ●	X1159 ●
X190 ●	X201 ●	X214 ●	X245 ●	X1202 ●
X191 ●	X203 ●	X215 ●	X246 ●	
X192 ●	X204 ●	X217 ●		
X193 ●	X205 ●	X222 ●		

cardiagn.com

SPLICE LOCATION VIEWS


M30 ENGINE HARNESS (535i)



cardiagn.com

SPLICE LOCATION VIEWS


M20 ENGINE HARNESS (525i)



cardiagn.com

SPLICE LOCATION VIEWS


INSTRUMENT HARNESS



cardiagn.com

SPLICE LOCATION VIEWS

REAR HARNESS



cardiagn.com

Connector Views Chart

Connector		Page - Fig.
X11	Connector (35-Pins, Natural)	8500.0-00-3
X12	Connector (35-Pins, Black)	8500.0-00-2
X13	Connector (21-Pins, White)	8500.0-01-3
X14	Connector (30-Pins, Yellow)	8500.0-00-4
X15	Connector (30-Pins, White)	8500.0-00-4
X16	Connector (26-Pins, Beige)	8500.0-01-1
X17	Connector (24-Pins, Brown)	8500.0-01-4
X18	Connector (26-Pins, Blue)	8500.0-01-1
X19	Connector (26-Pins, Green)	8500.0-01-1
X20	Connector (20-Pins, Black)	8500.0-01-2
X21	Connector (20-Pins, Black)	8500.0-01-5
X22	Connector (26-Pins, Blue)	8500.0-01-1
X31	Connector (12-Pins, Black)	8500.0-01-6
X32	Connector (12-Pins, White)	8500.0-02-1
X33	Connector (12-Pins, Black)	8500.0-02-1
X34	Connector (21-Pins, White)	8500.0-01-3
X35	Connector (21-Pins, Black)	8500.0-01-3
X48	Connector (9-Pins, White)	8500.0-02-3
X49	Connector (9-Pins, White)	8500.0-02-3
X50	Connector (9-Pins, White)	8500.0-02-3
X51	Connector (9-Pins, Black)	8500.0-02-3
X52	Connector (9-Pins, White)	8500.0-02-3
X53	Connector (9-Pins, White)	8500.0-02-3
X54	Connector (9-Pins, Black)	8500.0-02-3
X55	Connector (9-Pins, White)	8500.0-02-3
X56	Connector (9-Pins, White)	8500.0-02-3
X57	Connector (9-Pins, White)	8500.0-02-3
X58	Connector (9-Pins, White)	8500.0-02-3
X59	Connector (9-Pins, White)	8500.0-02-3

Connector		Page - Fig.
X61	Connector (9-Pins, Black)	8500.0-02-3
X62	Connector (9-Pins, White)	8500.0-02-3
X63	Connector (9-Pins, White)	8500.0-02-3
X64	Connector (9-Pins, Black)	8500.0-02-3
X69	Connector (8-Pins, White)	8500.0-03-1
X70	Connector (8-Pins, Black)	8500.0-03-2
X71	Connector (8-Pins, Black)	8500.0-03-2
X72	Connector (8-Pins, White)	8500.0-03-1
X73	Connector (8-Pins, Black)	8500.0-03-1
X74	Connector (8-Pins, Orange)	8500.0-03-1
X75	Connector (6-Pins, Orange)	8500.0-04-1
X76	Connector (6-Pins, Black)	8500.0-04-1
X79	Connector (4-Pins, White)	8500.0-06-5
X81	Connector (3-Pins, Orange)	8500.0-04-4
X82	Connector (3-Pins, Black)	8500.0-04-2
X83	Connector (3-Pins, Yellow)	8500.0-04-5
X84	Connector (3-Pins, Yellow)	8500.0-04-3
X85	Connector (3-Pins, Black)	8500.0-04-2
X86	Connector (3-Pins, Orange)	8500.0-04-4
X87	Connector (3-Pins, Black)	8500.0-04-4
X88	Connector (3-Pins, Black)	8500.0-03-3
X89	Connector (3-Pins, Black)	8500.0-03-6
X90	Connector (3-Pins, Black)	8500.0-03-6
X93	Connector (3-Pins, Black)	8500.0-03-6
X94	Connector (3-Pins, Black)	8500.0-03-6
X116	Connector (4-Pins, Black)	8500.0-06-5
X163	Connector (3-Pins, Black)	8500.0-04-2
X251	Connector (30-Pins, Black)	8500.0-00-4
X252	Connector (26-Pins, Green)	8500.0-01-1

cardiagn.com

Connector Views Chart

Connector		Page - Fig.
X253	Connector (26-Pins, Green)	8500.0-01-1
X254	Connector (26-Pins, White)	8500.0-01-1
X255	Connector (26-Pins, Yellow)	8500.0-01-1
X256	Connector (26-Pins, Black)	8500.0-13-1
X257	Connector (26-Pins, Black)	8500.0-13-1
X258	Connector (20-Pins, White)	8500.0-08-4
X259	Connector (20-Pins, Black)	8500.0-08-4
X260	Connector (21-Pins, Black)	8500.0-01-3
X262	Connector (26-Pins, Blue)	8500.0-01-1
X263	Connector (26-Pins, Green)	8500.0-01-1
X269	Connector (6-Pins, Black)	8500.0-04-1
X270	Connector (12-Pins, Black)	8500.0-08-5
X271	Connector (12-Pins, Grey)	8500.0-08-2
X272	Connector (12-Pins, Black)	8500.0-02-1
X273	Connector (12-Pins, Gray)	8500.0-02-2
X274	Connector (12-Pins, Gray)	8500.0-02-2
X275	Connector (12-Pins, White)	8500.0-02-1
X277	Connector (10-Pins, Blue)	8500.0-02-2
X278	Connector (10-Pins, Blue)	8500.0-02-2
X279	Connector (12-Pins, White)	8500.0-02-1
X290	Connector (9-Pins, Black)	8500.0-02-3
X291	Connector (9-Pins, Black)	8500.0-02-3
X292	Connector (9-Pins, White)	8500.0-02-3
X293	Connector (9-Pins, White)	8500.0-02-3
X294	Connector (9-Pins, White)	8500.0-02-3
X295	Connector (8-Pins, Black)	8500.0-03-1

Connector		Page - Fig.
X296	Connector (6-Pins, White)	8500.0-04-1
X297	Connector (9-Pins, White)	8500.0-02-3
X311	Connector (6-Pins, Black)	8500.0-08-3
X299	Connector (6-Pins, White)	8500.0-04-1
X301	Connector (26-Pins, Green)	8500.0-01-1
X312	Connector (6-Pins, Black)	8500.0-08-3
X316	Connector (6-Pins, White)	8500.0-05-4
X317	Connector (6-Pins, Black)	8500.0-05-4
X318	Connector (4-Pins, Black)	8500.0-06-5
X319	Connector (4-Pins, Black)	8500.0-06-5
X322	Connector (6-Pins, Black)	8500.0-04-1
X323	Connector (6-Pins, Black)	8500.0-06-1
X328	Connector (4-Pins, Black)	8500.0-06-5
X329	Connector (4-Pins, Black)	8500.0-06-5
X331	Connector (5-Pins, Green)	8500.0-02-4
X332	Connector (5-Pins, White)	8500.0-05-2
X333	Connector (4-Pins, Black)	8500.0-08-6
X334	Connector (4-Pins, White)	8500.0-08-6
X335	Connector (4-Pins, Green)	8500.0-02-6
X336	Connector (4-Pins, White)	8500.0-06-5
X337	Connector (4-Pins, White)	8500.0-06-5
X338	Connector (4-Pins, Black)	8500.0-06-3
X339	Connector (4-Pins, Black)	8500.0-06-3
X342	Connector (4-Pins, White)	8500.0-06-5
X355	Connector (3-Pins, White)	8500.0-05-5
X356	Connector (3-Pins, White)	8500.0-05-5

cardiagn.com

Connector Views Chart

Connector		Page - Fig.
X358	Connector (3-Pins, Black)	8500.0-03-3
X360	Connector (3-Pins, Natural)	8500.0-05-3
X393	Connector (6-Pins, Black)	8500.0-04-1
X400	Connector (3-Pins, Black)	8500.0-03-3
X501	Connector (26-Pins, Green)	8500.0-01-1
X502	Connector (26-Pins, White)	8500.0-01-1
X503	Connector (12-Pins, Black)	8500.0-05-6
X504	Connector (12-Pins, Black)	8500.0-05-6
X506	Connector (12-Pins, Black)	8500.0-02-1
X509	Connector (9-Pins, Black)	8500.0-02-3
X510	Connector (9-Pins, Black)	8500.0-02-3
X511	Connector (8-Pins, Black)	8500.0-03-1
X512	Connector (8-Pins, Black)	8500.0-03-1
X514	Connector (6-Pins, Black)	8500.0-06-1
X516	Connector (5-Pins, Black)	8500.0-06-2
X517	Connector (4-Pins, Black)	8500.0-06-5
X518	Connector (4-Pins, Black)	8500.0-06-5
X519	Connector (4-Pins, White)	8500.0-06-5
X520	Connector (3-Pins, White)	8500.0-03-3
X521	Connector (6-Pins, Black)	8500.0-06-4
X522	Connector (3-Pins, White)	8500.0-05-5
X523	Connector (6-Pins, Black)	8500.0-09-2
X524	Connector (4-Pins, Black)	8500.0-06-5
X526	Connector (8-Pins, Black)	8500.0-03-1
X529	Connector (6-Pins, Black)	8500.0-06-1
X601	Connector (26-Pins, White)	8500.0-01-1
X602	Connector (26-Pins, Yellow)	8500.0-01-1
X603	Connector (12-Pins, Black)	8500.0-06-6

Connector		Page - Fig.
X604	Connector (12-Pins, Black)	8500.0-06-6
X605	Connector (12-Pins, Black)	8500.0-02-1
X606	Connector (12-Pins, White)	8500.0-02-1
X607	Connector (12-Pins, Black)	8500.0-08-5
X608	Connector (12-Pins, Black)	8500.0-07-2
X609	Connector (15-Pins, Black)	8500.0-12-2
X610	Connector (26-Pins, White)	8500.0-01-1
X611	Connector (26-Pins, Green)	8500.0-01-1
X612	Connector (26-Pins, Blue)	8500.0-01-1
X613	Connector (26-Pins, Blue)	8500.0-01-1
X614	Connector (26-Pins, Yellow)	8500.0-01-1
X620	Connector (9-Pins, White)	8500.0-02-3
X621	Connector (10-Pins, Black)	8500.0-07-1
X622	Connector (10-Pins, Black)	8500.0-07-1
X623	Connector (4-Pins, Black)	8500.0-06-3
X624	Connector (4-Pins, Black)	8500.0-06-3
X625	Connector (6-Pins, Black)	8500.0-07-4
X626	Connector (8-Pins, Black)	8500.0-03-1
X627	Connector (8-Pins, Black)	8500.0-03-1
X628	Connector (3-Pins, Black)	8500.0-07-5
X629	Connector (8-Pins, Natural)	8500.0-07-3
X630	Connector (13-Pins, Black)	8500.0-07-6
X631	Connector (9-Pins, White)	8500.0-02-3
X632	Connector (9-Pins, White)	8500.0-02-3
X633	Connector (8-Pins, Black)	8500.0-09-5
X634	Connector (6-Pins, White)	8500.0-04-1

cardiagn.com

Connector Views Chart

carmanuals.com

Connector		Page - Fig.
X635	Connector (6-Pins, Black)	8500.0-04-1
X636	Connector (6-Pins, Black)	8500.0-08-3
X637	Connector (6-Pins, Black)	8500.0-08-3
X638	Connector (6-Pins, Black)	8500.0-09-4
X641	Connector (6-Pins, Black)	8500.0-09-4
X642	Connector (6-Pins, Black)	8500.0-09-3
X643	Connector (6-Pins, Blue)	8500.0-10-2
X644	Connector (6-Pins, Black)	8500.0-09-4
X645	Connector (6-Pins, Black)	8500.0-08-3
X646	Connector (6-Pins, Black)	8500.0-09-4
X647	Connector (6-Pins, Black)	8500.0-08-3
X648	Connector (6-Pins, Black)	8500.0-08-3
X649	Connector (6-Pins, White)	8500.0-08-3
X650	Connector (6-Pins, Black)	8500.0-08-3
X651	Connector (6-Pins, Black)	8500.0-08-3
X652	Connector (6-Pins, Blue)	8500.0-08-3
X653	Connector (6-Pins, Black)	8500.0-08-3
X654	Connector (6-Pins, White)	8500.0-08-3
X655	Connector (6-Pins, Blue)	8500.0-08-3
X656	Connector (6-Pins, Green)	8500.0-08-3
X657	Connector (6-Pins, Brown)	8500.0-08-3
X658	Connector (6-Pins, Black)	8500.0-08-3
X659	Connector (6-Pins, Blue)	8500.0-08-3
X661	Connector (6-Pins, Black)	8500.0-10-4
X662	Connector (6-Pins, Black)	8500.0-10-4
X663	Connector (6-Pins, Black)	8500.0-10-4
X664	Connector (6-Pins, Black)	8500.0-10-4

Connector		Page - Fig.
X665	Connector (6-Pins, Black)	8500.0-10-4
X666	Connector (6-Pins, Black)	8500.0-10-4
X667	Connector (6-Pins, Black)	8500.0-10-4
X668	Connector (6-Pins, Black)	8500.0-10-4
X669	Connector (6-Pins, Black)	8500.0-10-4
X670	Connector (6-Pins, Black)	8500.0-10-4
X671	Connector (5-Pins, Green)	8500.0-02-4
X672	Connector (4-Pins, Black)	8500.0-10-5
X673	Connector (4-Pins, Black)	8500.0-06-5
X674	Connector (4-Pins, Black)	8500.0-06-5
X677	Connector (9-Pins, Black)	8500.0-10-6
X681	Connector (3-Pins, White)	8500.0-03-3
X682	Connector (3-Pins, Natural)	8500.0-10-3
X684	Connector (3-Pins, Black)	8500.0-04-2
X685	Connector (3-Pins, Black)	8500.0-04-2
X686	Connector (3-Pins, Blue)	8500.0-10-3
X687	Connector (3-Pins, Blue)	8500.0-10-3
X688	Connector (3-Pins, Blue)	8500.0-10-3
X689	Connector (3-Pins, Blue)	8500.0-10-3
X690	Connector (3-Pins, Blue)	8500.0-10-3
X692	Connector (3-Pins, Black)	8500.0-03-3
X693	Connector (3-Pins, Black)	8500.0-05-5
X694	Connector (3-Pins, Natural)	8500.0-10-3
X695	Connector (3-Pins, Black)	8500.0-03-3
X696	Connector (3-Pins, Black)	8500.0-07-5
X902	Connector (9-Pins, Black)	8500.0-10-6

Connector Views Chart

Connector		Page - Fig.
X903	Connector (3-Pins, Natural)	8500.0-08-3
X918	Connector (6-Pins, Black)	8500.0-08-3
X919	Connector (6-Pins, Black)	8500.0-08-3
X926	Connector (3-Pins, Natural)	8500.0-10-3
X928	Connector (3-Pins, Black)	8500.0-04-2
X929	Connector (3-Pins, Black)	8500.0-04-2
X1021	Connector (9-Pins, White)	8500.0-02-3
X1500	Connector (55-Pins, Natural)	8500.0-00-1
X1514	Connector (3-Pins, Black)	8500.0-03-5
X1515	Connector (9-Pins, White)	8500.0-02-3
X1516	Connector (9-Pins, White)	8500.0-02-3
X1517	Connector (9-Pins, White)	8500.0-02-3
X1521	Connector (3-Pins, Black)	8500.0-03-5
X1522	Connector (3-Pins, Black)	8500.0-03-5
X1523	Connector (4-Pins, Black)	8500.0-11-4
X1525	Connector (3-Pins, Black)	8500.0-03-5
X1528	Connector (5-Pins, Black)	8500.0-11-2
X1532	Connector (20-Pins, Black)	8500.0-11-5
X1533	Connector (3-Pins, Black)	8500.0-03-5
X1536	Connector (6-Pins, Black)	8500.0-11-3
X1537	Connector (8-Pins, Black)	8500.0-03-1
X1550	Connector (35-Pins, Black)	8500.0-00-3
X1552	Connector (4-Pins, Black)	8500.0-06-3
X1554	Connector (8-Pins, Black)	8500.0-10-1
X1563	Connector (7-Pins, Black)	8500.0-12-4
X2000	Connector (35-Pins, Natural)	8500.0-00-3
X2001	Connector (12-Pins, Black)	8500.0-02-1
X2003	Connector (6-Pins, Blue)	8500.0-08-3

Connector		Page - Fig.
X2004	Connector (12-Pins, Black)	8500.0-07-2
X2005	Connector (8-Pins, Black)	8500.0-11-1
X3500	Connector (3-Pins, White)	8500.0-03-3
X3502	Connector (3-Pins, White)	8500.0-03-3
X3505	Connector (4-Pins, Black)	8500.0-06-5
X3506	Connector (21-Pins, White)	8500.0-01-3
X3510	Connector (3-Pins, Black)	8500.0-13-2
X3511	Connector (3-Pins, Black)	8500.0-13-2
X3524	Connector (3-Pins, White)	8500.0-03-3
X8062	Connector (9-Pins, Gray)	8500.0-13-3
X8063	Connector (9-Pins, Black)	8500.0-02-3
X8074	Connector (13-Pins)	Not shown
X8075	Connector (13-Pins)	Not shown
X9269	Connector (26-Pins, White)	8500.0-01-1
X9557	Connector (5-Pins, Black)	8500.0-02-4
X9569	Connector (9-Pins, White)	8500.0-02-3
X9607	Connector (20-Pins, Black)	8500.0-08-4
X18059	Connector (9-Pins, Black)	8500.0-02-3
X18060	Connector (9-Pins, Black)	8500.0-02-3
X18064	Connector (6-Pins, White)	8500.0-08-3
X18065	Connector (6-Pins, White)	8500.0-08-3
X18069	Connector (6-Pins, Orange)	8500.0-04-1
X18130	Connector (4-Pins, Black)	8500.0-06-5

carlabgi.com

FIGURE 1

B550001.00




FIGURE 2

B350001.00




FIGURE 3

B350002.00





FIGURE 4

B300001.00



cardiagn.com

CONNECTOR VIEWS

cardiagn.com

FIGURE 1

B260002.00




FIGURE 2

B200002.00




FIGURE 3

B210001.00




FIGURE 4

B240001.00




FIGURE 5

B200004.00





FIGURE 6

B120013.00



CONNECTOR VIEWS

FIGURE 1

B120002.01





FIGURE 2

B120003.00



B100001.00




FIGURE 3

B090001.00




FIGURE 4

B050005.00





FIGURE 5

B120007.00



B100003.00





FIGURE 6

B040003.00



carmanuals.com

CONNECTOR VIEWS

FIGURE 1

B080002.00




FIGURE 2

B080004.00




FIGURE 3

B030001.00




FIGURE 4

B080003.00




FIGURE 5

B030015.00





FIGURE 6

B030014.00



carlabr.com

CONNECTOR VIEWS

carlagh.com

FIGURE 1

B060017.00




FIGURE 2

B030004.00



FIGURE 3

B030013.00



FIGURE 4

B030005.00





FIGURE 5

B030012.00



FIGURE 6

B030006.00



CONNECTOR VIEWS

FIGURE 1

B060004.00



FIGURE 2

B050005.00




FIGURE 3

B0300010.00




FIGURE 4

B060002.00




FIGURE 5

B030003.04





FIGURE 6

B120006.00



cardiagn.com

FIGURE 1

B060006.00




FIGURE 2

B050003.00




FIGURE 3

B040004.00




FIGURE 4

B060020.00




FIGURE 5

B040002.00





FIGURE 6

B120008.00



cardiagn.com

carplan.com

FIGURE 1

B100002.00




FIGURE 2

B120009.00




FIGURE 3

B080006.00




FIGURE 4

B060013.00




FIGURE 5

B030009.00




FIGURE 6

B130002.00




FIGURE 1

B260001.00




FIGURE 2

B120011.00




FIGURE 3

B120011.00




FIGURE 4

B200001.00




FIGURE 5

B120005.00





FIGURE 6

B040010.00



carlagh.com

CONNECTOR VIEWS

carplan.com

FIGURE 1

B060007.00




FIGURE 2

B060023.00




FIGURE 3

B060016.00




FIGURE 4

B060009.00




FIGURE 5

B080010.00





FIGURE 6

B0400011.00



CONNECTOR VIEWS

FIGURE 1

B080009.00




FIGURE 2

B060011.00




FIGURE 3

B030016.00




FIGURE 4

B060010.01




FIGURE 5

B040013





FIGURE 6

B090002.00



carlagu.com

CONNECTOR VIEWS

carplan.com

FIGURE 1

B080005.00




FIGURE 2

B050006.00




FIGURE 3

B060014.00




FIGURE 4

B040006.00




FIGURE 5

B200003.00




FIGURE 6

B07000.00




FIGURE 1

B170000.00





FIGURE 2



B150003.00

cardiagn.com

FIGURE 1

B260003.00




FIGURE 2

B070001.00





FIGURE 3

B100006.00



carbagn.com