DTC	62-43	CD-ROM Abnormal

DTC	63-43	CD-ROM Abnormal

DESCRIPTION

DTC No.	DTC Detecting Condition	Trouble Area
62-43	CD-ROM operation is abnormal	• CD • Radio receiver
63-43	CD-ROM operation is abnormal	

INSPECTION PROCEDURE

HINT:
After the inspection is completed, clear the DTCs.

1 CHECK IF A PROPER CD IS INSERTED

(a) Make sure that the CD is an audio CD and that it is not deformed, flawed, stained, burred, or otherwise defective.
OK:
Normal CD
HINT:
- Translucent or uniquely-shaped CDs cannot be played.
- CDs with adhesive paper labels should not be played.
- Commercial audio CDs can be played.
- For details on playable CDs, refer to the Owner's Manual.

NG → **CHANGE DISC**

OK ↓

2 REPLACE CD

(a) Replace the CD with another and recheck.
(1) Replace the CD with another normal one.
(2) Clear the DTCs (See page AV-14).
(3) Recheck for DTCs and check if the same trouble occurs again.
OK:
Malfunction disappears.

NG → **REPLACE RADIO RECEIVER**

OK ↓

END

cardiagn.com

DTC	62-44	CD Abnormal

DTC	62-48	Excess Current

DTC	62-50	Tray Insertion / Ejection Error

DTC	63-44	CD Abnormal

DTC	63-48	Excess Current

DTC	63-50	Tray Insertion / Ejection Error

DESCRIPTION

DTC No.	DTC Detecting Condition	Trouble Area
62-44	Operation error in the CD mechanism	Radio receiver
62-48	Excess current is present in the CD player	
62-50	Malfunction in insertion/ejection system	
63-44	Operation error in the CD mechanism	
63-48	Excess current is present in the CD changer	
63-50	Malfunction in insertion/ejection system	

INSPECTION PROCEDURE

HINT:
After the inspection is completed, clear the DTCs.

1 CLEAR DTC

(a) Clear the DTCs (See page AV-14).

NEXT

2 RECHECK DTC

(a) Recheck for DTCs and check if the same trouble occurs again.
HINT:
If DTCs are detected frequently, replace the radio receiver.
OK:
Malfunction disappears.

NG → **REPLACE RADIO RECEIVER**

OK

END

cardiagn.com