J POWER SOURCE (Current Flow Chart)

The chart below shows the route by which current flows from the battery to each electrical source (Fusible Link, Circuit Breaker, Fuse, etc.) and other parts.



[LOCATION] ① : Engine Room J/B (See page 78) ② : Instrument Panel J/B (See page 80)



③ : Engine Room R/B No.1 (See page 82)

④ : Engine Room R/B No.2 (See page 83)