tC

2009

SCHEDULED MAINTENANCE GUIDE

KEEP MOVING.
EXPLORE.

what moves you

KEEP YOUR RIDE RUNNING

Now that you've got your Scion on the road, you want to make sure it keeps going. That's where scheduled maintenance comes in. Taking your car in for regular service will help your ride run better and last longer. It will keep your repair bills down too.

This booklet makes it easy to keep your Scion running smoothly. It lists all the factory-recommended services and tells you when your vehicle needs them. Be sure to look this booklet over carefully and keep it in your glove box. Do what it says and your Scion should be happy for many miles to come.

Complimentary 5,000 Mile & 10,000 Mile Factory-Recommended Maintenance Services

To help you get started with regular maintenance, Scion provides your vehicle's 5,000 mile and 10,000 mile factory-recommended maintenance services on a complimentary basis. To find out how to obtain your complimentary maintenance services, see the section titled "Complimentary Maintenance Services."

Please make sure that all the other services recommended in this booklet are performed on your car as well.

Put it In Writing

To help you keep track of your Scion's service history, each maintenance chart in this booklet includes:

- Boxes to check for each service item performed
- Space for the maintenance provider to include a service verification stamp
- Space to write the date and mileage that service is performed

Documenting your service history may make your car worth more when you're ready to sell. There's a reason smart people write things down.

In addition to scheduled maintenance, your vehicle requires general maintenance such as fluid checks and visual inspections. These procedures are explained in the "Vehicle Maintenance and Care" section of the *Owner's Manual*. To help keep your Scion out of trouble, be sure to perform these procedures regularly.

Scion is a marque of Toyota Motor Sales, U.S.A., Inc.

MAINTENANCE & SCION WARRANTY COVERAGE

Maintenance Records

To make sure your warranty coverage stays intact, you need to maintain your Scion according to the recommendations in this booklet. You should keep records of vehicle maintenance, including date and mileage at time of service and a description of service items performed and parts installed. The scheduled maintenance log can help you keep track of this information. If you sell your car, be sure to give your maintenance records to the new owner.

Scion will not deny a warranty claim solely because you don't have records to show that you maintained your vehicle. However, damage or failures caused by lack of proper maintenance are not covered under warranty.

Maintenance Providers

You can have maintenance and repair services done by any automotive service provider you choose, or you can do them yourself. Scion won't deny a warranty claim solely because you used a service provider other than a Scion dealership for maintenance and repairs. However, damage or failures caused by improper maintenance or repairs are not covered under warranty.

Note: Only Scion dealerships and Toyota dealerships are authorized to provide warranty service/repairs for your Scion.

Dealer-Recommended Maintenance

Your dealer may recommend more frequent maintenance intervals or more maintenance services than those listed in the scheduled maintenance log. You don't need to have these additional services performed to maintain your warranty coverage. Ask your dealer to explain any recommended maintenance that is not included in the scheduled maintenance log.

For a complete description of Scion warranty coverages, check out the booklet called *2009 Owner's Warranty Information*. You'll find it in your glove box.

TABLE OF CONTENTS

USING THE MAINTENANCE LOG CHARTS 2

COMPLIMENTARY MAINTENANCE SERVICES 3

MAINTENANCE LOG 4

EXPLANATION OF MAINTENANCE ITEMS 20

VEHICLE IDENTIFICATION

Model _____

In-service date _____

Selling dealership _____

Key number _____

Body style _____

Mileage at delivery _____

Selling dealership phone number _____

Vehicle Identification Number _____

USING THE MAINTENANCE LOG CHARTS

Miles or Months?

Scion recommends obtaining scheduled maintenance for your vehicle every 5,000 miles or six months, whichever comes first.

For example:

- If you drive 5,000 miles in less than six months, you should obtain maintenance at **5,000 miles - don't wait until six months.**
- If at six months you have driven less than 5,000 miles, you should obtain maintenance at **six months - don't wait until 5,000 miles.**

Be sure to keep an eye on your mileage so that you obtain maintenance when recommended. If you are a low-mileage driver, mark your calendar to remind yourself to obtain maintenance every six months.

Special Operating Conditions

In addition to standard maintenance items, the maintenance log indicates services that should be performed on vehicles that are driven under especially demanding conditions. These "special operating conditions" and their required maintenance items are clearly indicated in each chart.

Note: You should perform these additional maintenance services if you drive *primarily* under any of the special operating conditions indicated. If you drive only occasionally under these conditions, it is not necessary to perform the additional services.

COMPLIMENTARY MAINTENANCE SERVICES

To help you get started with regular maintenance, Scion provides your vehicle's 5,000 mile and 10,000 mile factory-recommended maintenance services on a complimentary basis. While these complimentary factory-recommended maintenance services do not have to be performed at exactly 5,000 miles and 10,000 miles, the complimentary services must be performed within 18 months or 12,000 miles (whichever occurs first) of your vehicle's original in-service date. It is important to note that these services are not meant to be used for maintenance service on or after 15,000 miles. If you bought your Scion used and the previous owner did not use both of the complimentary maintenance services, you are entitled to the remaining complimentary maintenance service or services if your car is still within 18 months or 12,000 miles of its original in-service date.

To obtain a complimentary maintenance service, call a Scion dealership or participating Toyota dealership to make an appointment. The dealership will verify that the service was performed by completing the "Dealer Service Verification" portion of the Maintenance Log.

Complimentary maintenance services include change of engine oil, oil filter and drain plug gasket, rotating tires and visually inspecting brake linings/drums and brake pads/discs only. You are responsible for the cost of any other services performed at the time of your complimentary maintenance services.

MAINTENANCE LOG

Complimentary Maintenance Services

5,000 Miles or 6 months

Dealer Service Verification:

___ Replace engine oil and oil filter [1]
___ Rotate tires
___ Visually inspect brake linings/drums and brake pads/discs

Additional Maintenance Items for Special Operating Conditions [2]

Driving on dirt roads or dusty roads:
___ Inspect ball joints and dust covers
___ Inspect drive shaft boots
___ Inspect engine air filter
___ Inspect steering linkage and boots
___ Tighten nuts and bolts on chassis and body

Date: Mileage:

10,000 Miles or 12 months

Dealer Service Verification:

___ Replace engine oil and oil filter [1]
___ Rotate tires
___ Visually inspect brake linings/drums and brake pads/discs

Additional Maintenance Items for Special Operating Conditions [2]

Driving on dirt roads or dusty roads:
___ Inspect ball joints and dust covers
___ Inspect drive shaft boots
___ Inspect engine air filter
___ Inspect steering linkage and boots
___ Tighten nuts and bolts on chassis and body

Date: Mileage:

MAINTENANCE LOG

15,000 Miles or 18 months

___ Replace engine oil and oil filter [1]
___ Rotate tires
___ Visually inspect brake linings/drums and brake pads/discs
___ Inspect the following:
- _ Ball joints and dust covers
- _ Brake lines and hoses
- _ Drive shaft boots
- _ Engine coolant [3]
- _ Exhaust pipes and mountings
- _ Radiator and condenser
- _ Steering gear box
- _ Steering linkage and boots

Note: Driving in heavy traffic, on dirt roads or in urban, dusty or desert areas may shorten the life of the cabin air filter. Replacement may be needed if you notice reduced air flow from the air conditioner and heater or if the windows fog easily when you use the "Fresh" mode. Consult your dealer if any of these conditions occur.

Additional Maintenance Items for Special Operating Conditions [2]

Driving on dirt roads or dusty roads:

___ Inspect engine air filter
___ Tighten nuts and bolts on chassis and body

Dealer Service Verification: **Date:** **Mileage:**

1 Reset the oil replacement reminder light ("MAINT REQD") or the message "OIL MAINTENANCE REQUIRED" on the multi-information display after engine oil replacement.
2 Perform these service items only if you drive primarily under the conditions indicated.
3 Refer to "Engine Coolant" in the "Explanation of Maintenance Items" section in the back of this guide for more information.

MAINTENANCE LOG

20,000 Miles or 24 months

___ Replace engine oil and oil filter [1]
___ Rotate tires
___ Visually inspect brake linings/drums and brake pads/discs

Dealer Service Verification:

Additional Maintenance Items for Special Operating Conditions [2]

Driving on dirt roads or dusty roads:
___ Inspect ball joints and dust covers
___ Inspect drive shaft boots
___ Inspect engine air filter
___ Inspect steering linkage and boots
___ Tighten nuts and bolts on chassis and body

Date: Mileage:

25,000 Miles or 30 months

___ Replace engine oil and oil filter [1]
___ Rotate tires
___ Visually inspect brake linings/drums and brake pads/discs

Dealer Service Verification:

Additional Maintenance Items for Special Operating Conditions [2]

Driving on dirt roads or dusty roads:
___ Inspect ball joints and dust covers
___ Inspect drive shaft boots
___ Inspect engine air filter
___ Inspect steering linkage and boots
___ Tighten nuts and bolts on chassis and body

Date: Mileage:

MAINTENANCE LOG

30,000 Miles or 36 months

___ Replace cabin air filter
___ Replace engine air filter
___ Replace engine oil and oil filter [1]
___ Rotate tires
___ Inspect the following:
- _ Ball joints and dust covers
- _ Brake lines and hoses
- _ Brake linings/drums and brake pads/discs [4]
- _ Drive shaft boots
- _ Engine coolant [3]
- _ Exhaust pipes and mountings
- _ Front differential oil
- _ Fuel lines and connections, fuel tank band and fuel tank vapor vent system hoses
- _ Fuel tank cap gasket
- _ Radiator and condenser
- _ Steering gear box
- _ Steering linkage and boots
- _ Transmission fluid or oil

Additional Maintenance Items for Special Operating Conditions [2]

Driving on dirt roads or dusty roads:

___ Tighten nuts and bolts on chassis and body

Dealer Service Verification: **Date:** **Mileage:**

1 Reset the oil replacement reminder light ("MAINT REQD") or the message "OIL MAINTENANCE REQUIRED" on the multi-information display after engine oil replacement.
2 Perform these service items only if you drive primarily under the conditions indicated.
3 Refer to "Engine Coolant" in the "Explanation of Maintenance Items" section in the back of this guide for more information.
4 Inspect thickness measurement and disc runout.

MAINTENANCE LOG

35,000 Miles or 42 months

___ Replace engine oil and oil filter [1]
___ Rotate tires
___ Visually inspect brake linings/drums and brake pads/discs

Dealer Service Verification:

Additional Maintenance Items for Special Operating Conditions [2]

Driving on dirt roads or dusty roads:
___ Inspect ball joints and dust covers
___ Inspect drive shaft boots
___ Inspect engine air filter
___ Inspect steering linkage and boots
___ Tighten nuts and bolts on chassis and body

Date: Mileage:

40,000 Miles or 48 months

___ Replace engine oil and oil filter [1]
___ Rotate tires
___ Visually inspect brake linings/drums and brake pads/discs

Dealer Service Verification:

Additional Maintenance Items for Special Operating Conditions [2]

Driving on dirt roads or dusty roads:
___ Inspect ball joints and dust covers
___ Inspect drive shaft boots
___ Inspect engine air filter
___ Inspect steering linkage and boots
___ Tighten nuts and bolts on chassis and body

Date: Mileage:

MAINTENANCE LOG

45,000 Miles or 54 months

___ Replace engine oil and oil filter [1]
___ Rotate tires
___ Visually inspect brake linings/drums and brake pads/discs
___ Inspect the following:
- _ Ball joints and dust covers
- _ Brake lines and hoses
- _ Drive shaft boots
- _ Engine coolant [3]
- _ Exhaust pipes and mountings
- _ Radiator and condenser
- _ Steering gear box
- _ Steering linkage and boots

Note: Driving in heavy traffic, on dirt roads or in urban, dusty or desert areas may shorten the life of the cabin air filter. Replacement may be needed if you notice reduced air flow from the air conditioner and heater or if the windows fog easily when you use the "Fresh" mode. Consult your dealer if any of these conditions occur.

Additional Maintenance Items for Special Operating Conditions [2]

Driving on dirt roads or dusty roads:

___ Inspect engine air filter
___ Tighten nuts and bolts on chassis and body

Dealer Service Verification: **Date:** **Mileage:**

1 Reset the oil replacement reminder light ("MAINT REQD") or the message "OIL MAINTENANCE REQUIRED" on the multi-information display after engine oil replacement.
2 Perform these service items only if you drive primarily under the conditions indicated.
3 Refer to "Engine Coolant" in the "Explanation of Maintenance Items" section in the back of this guide for more information.

MAINTENANCE LOG

50,000 Miles or 60 months

___ Replace engine oil and oil filter [1]
___ Rotate tires
___ Visually inspect brake linings/drums and brake pads/discs

Dealer Service Verification:

Additional Maintenance Items for Special Operating Conditions [2]

Driving on dirt roads or dusty roads:
___ Inspect ball joints and dust covers
___ Inspect drive shaft boots
___ Inspect engine air filter
___ Inspect steering linkage and boots
___ Tighten nuts and bolts on chassis and body

Date: Mileage:

55,000 Miles or 66 months

___ Replace engine oil and oil filter [1]
___ Rotate tires
___ Visually inspect brake linings/drums and brake pads/discs

Dealer Service Verification:

Additional Maintenance Items for Special Operating Conditions [2]

Driving on dirt roads or dusty roads:
___ Inspect ball joints and dust covers
___ Inspect drive shaft boots
___ Inspect engine air filter
___ Inspect steering linkage and boots
___ Tighten nuts and bolts on chassis and body

Date: Mileage:

MAINTENANCE LOG

60,000 Miles or 72 months

___ Replace cabin air filter
___ Replace engine air filter
___ Replace engine oil and oil filter [1]
___ Rotate tires
___ Inspect the following:
- _ Ball joints and dust covers
- _ Brake lines and hoses
- _ Brake linings/drums and brake pads/discs [4]
- _ Drive belts [5]
- _ Drive shaft boots
- _ Engine coolant [3]
- _ Engine valve clearance [6]
- _ Exhaust pipes and mountings
- _ Front differential oil
- _ Fuel lines and connections, fuel tank band and fuel tank vapor vent system hoses
- _ Fuel tank cap gasket
- _ Radiator and condenser
- _ Steering gear box
- _ Steering linkage and boots
- _ Transmission fluid or oil

Additional Maintenance Items for Special Operating Conditions [2]

Driving on dirt roads or dusty roads:

___ Tighten nuts and bolts on chassis and body

Dealer Service Verification: **Date:** **Mileage:**

1 Reset the oil replacement reminder light ("MAINT REQD") or the message "OIL MAINTENANCE REQUIRED" on the multi-information display after engine oil replacement.
2 Perform these service items only if you drive primarily under the conditions indicated.
3 Refer to "Engine Coolant" in the "Explanation of Maintenance Items" section in the back of this guide for more information.
4 Inspect thickness measurement and disc runout.
5 Initial inspection at 60,000 miles/72 months. Inspect every 15,000 miles/18 months thereafter.
6 Check for tappet noise and engine vibration and adjust if necessary.

MAINTENANCE LOG

65,000 Miles or 78 months

Dealer Service Verification:

___ Replace engine oil and oil filter [1]
___ Rotate tires
___ Visually inspect brake linings/drums and brake pads/discs

Additional Maintenance Items for Special Operating Conditions [2]

Driving on dirt roads or dusty roads:
___ Inspect ball joints and dust covers
___ Inspect drive shaft boots
___ Inspect engine air filter
___ Inspect steering linkage and boots
___ Tighten nuts and bolts on chassis and body

Date: Mileage:

70,000 Miles or 84 months

Dealer Service Verification:

___ Replace engine oil and oil filter [1]
___ Rotate tires
___ Visually inspect brake linings/drums and brake pads/discs

Additional Maintenance Items for Special Operating Conditions [2]

Driving on dirt roads or dusty roads:
___ Inspect ball joints and dust covers
___ Inspect drive shaft boots
___ Inspect engine air filter
___ Inspect steering linkage and boots
___ Tighten nuts and bolts on chassis and body

Date: Mileage:

MAINTENANCE LOG

75,000 Miles or 90 Months

___ Replace engine oil and oil filter [1]
___ Rotate tires
___ Visually inspect brake linings/drums and brake pads/discs
___ Inspect the following:
- _ Ball joints and dust covers
- _ Brake lines and hoses
- _ Drive belts
- _ Drive shaft boots
- _ Engine coolant [3]
- _ Exhaust pipes and mountings
- _ Radiator and condenser
- _ Steering gear box
- _ Steering linkage and boots

Note: Driving in heavy traffic, on dirt roads or in urban, dusty or desert areas may shorten the life of the cabin air filter. Replacement may be needed if you notice reduced air flow from the air conditioner and heater or if the windows fog easily when you use the "Fresh" mode. Consult your dealer if any of these conditions occur.

Additional Maintenance Items for Special Operating Conditions [2]

Driving on dirt roads or dusty roads:

___ Inspect engine air filter
___ Tighten nuts and bolts on chassis and body

Dealer Service Verification: **Date:** **Mileage:**

1 Reset the oil replacement reminder light ("MAINT REQD") or the message "OIL MAINTENANCE REQUIRED" on the multi-information display after engine oil replacement.
2 Perform these service items only if you drive primarily under the conditions indicated.
3 Refer to "Engine Coolant" in the "Explanation of Maintenance Items" section in the back of this guide for more information.

MAINTENANCE LOG

80,000 Miles or 96 Months

___ Replace engine oil and oil filter [1]
___ Rotate tires
___ Visually inspect brake linings/drums and brake pads/discs

Dealer Service Verification:

Additional Maintenance Items for Special Operating Conditions [2]

Driving on dirt roads or dusty roads:
___ Inspect ball joints and dust covers
___ Inspect drive shaft boots
___ Inspect engine air filter
___ Inspect steering linkage and boots
___ Tighten nuts and bolts on chassis and body

Date: Mileage:

85,000 Miles or 102 Months

___ Replace engine oil and oil filter [1]
___ Rotate tires
___ Visually inspect brake linings/drums and brake pads/discs

Dealer Service Verification:

Additional Maintenance Items for Special Operating Conditions [2]

Driving on dirt roads or dusty roads:
___ Inspect ball joints and dust covers
___ Inspect drive shaft boots
___ Inspect engine air filter
___ Inspect steering linkage and boots
___ Tighten nuts and bolts on chassis and body

Date: Mileage:

MAINTENANCE LOG

90,000 Miles or 108 Months

___ Replace cabin air filter
___ Replace engine air filter
___ Replace engine oil and oil filter [1]
___ Rotate tires
___ Inspect the following:
- _ Ball joints and dust covers
- _ Brake lines and hoses
- _ Brake linings/drums and brake pads/discs [4]
- _ Drive belts
- _ Drive shaft boots
- _ Engine coolant [3]
- _ Exhaust pipes and mountings
- _ Front differential oil
- _ Fuel lines and connections, fuel tank band and fuel tank vapor vent system hoses
- _ Fuel tank cap gasket
- _ Radiator and condenser
- _ Steering gear box
- _ Steering linkage and boots
- _ Transmission fluid or oil

Additional Maintenance Items for Special Operating Conditions [2]

Driving on dirt roads or dusty roads:

___ Tighten nuts and bolts on chassis and body

Dealer Service Verification: **Date:** **Mileage:**

1 Reset the oil replacement reminder light ("MAINT REQD") or the message "OIL MAINTENANCE REQUIRED" on the multi-information display after engine oil replacement.
2 Perform these service items only if you drive primarily under the conditions indicated.
3 Refer to "Engine Coolant" in the "Explanation of Maintenance Items" section in the back of this guide for more information.
4 Inspect thickness measurement and disc runout.

MAINTENANCE LOG

95,000 Miles or 114 Months

___ Replace engine oil and oil filter [1]
___ Rotate tires
___ Visually inspect brake linings/drums and brake pads/discs

Dealer Service Verification:

Additional Maintenance Items for Special Operating Conditions [2]

Driving on dirt roads or dusty roads:
___ Inspect ball joints and dust covers
___ Inspect drive shaft boots
___ Inspect engine air filter
___ Inspect steering linkage and boots
___ Tighten nuts and bolts on chassis and body

Date: Mileage:

100,000 Miles or 120 Months

___ Replace engine coolant [4]
___ Replace engine oil and oil filter [1]
___ Rotate tires
___ Visually inspect brake linings/drums and brake pads/discs

Dealer Service Verification:

Additional Maintenance Items for Special Operating Conditions [2]

Driving on dirt roads or dusty roads:
___ Inspect ball joints and dust covers
___ Inspect drive shaft boots
___ Inspect engine air filter
___ Inspect steering linkage and boots
___ Tighten nuts and bolts on chassis and body

Date: Mileage:

MAINTENANCE LOG

105,000 Miles or 126 Months

___ Replace engine oil and oil filter [1]
___ Rotate tires
___ Visually inspect brake linings/drums and brake pads/discs
___ Inspect the following:
- _ Ball joints and dust covers
- _ Brake lines and hoses
- _ Drive belts
- _ Drive shaft boots
- _ Engine coolant [3]
- _ Exhaust pipes and mountings
- _ Radiator and condenser
- _ Steering gear box
- _ Steering linkage and boots

Note: Driving in heavy traffic, on dirt roads or in urban, dusty or desert areas may shorten the life of the cabin air filter. Replacement may be needed if you notice reduced air flow from the air conditioner and heater or if the windows fog easily when you use the "Fresh" mode. Consult your dealer if any of these conditions occur.

Additional Maintenance Items for Special Operating Conditions [2]

Driving on dirt roads or dusty roads:

___ Inspect engine air filter
___ Tighten nuts and bolts on chassis and body

Dealer Service Verification: **Date:** **Mileage:**

1 Reset the oil replacement reminder light ("MAINT REQD") or the message "OIL MAINTENANCE REQUIRED" on the multi-information display after engine oil replacement.
2 Perform these service items only if you drive primarily under the conditions indicated.
3 Refer to "Engine Coolant" in the "Explanation of Maintenance Items" section in the back of this guide for more information.
4 Initial replacement at 100,000 miles/120 months. Replace every 50,000 miles/60 months thereafter. Refer to "Engine Coolant" in the "Explanation of Maintenance Items" section in the back of this guide for more information.

MAINTENANCE LOG

110,000 Miles or 132 Months

___ Replace engine oil and oil filter [1]
___ Rotate tires
___ Visually inspect brake linings/drums and brake pads/discs

Dealer Service Verification:

Additional Maintenance Items for Special Operating Conditions [2]

Driving on dirt roads or dusty roads:
___ Inspect ball joints and dust covers
___ Inspect drive shaft boots
___ Inspect engine air filter
___ Inspect steering linkage and boots
___ Tighten nuts and bolts on chassis and body

Date: Mileage:

115,000 Miles or 138 Months

___ Replace engine oil and oil filter [1]
___ Rotate tires
___ Visually inspect brake linings/drums and brake pads/discs

Dealer Service Verification:

Additional Maintenance Items for Special Operating Conditions [2]

Driving on dirt roads or dusty roads:
___ Inspect ball joints and dust covers
___ Inspect drive shaft boots
___ Inspect engine air filter
___ Inspect steering linkage and boots
___ Tighten nuts and bolts on chassis and body

Date: Mileage:

MAINTENANCE LOG

120,000 Miles or 144 Months

___ Replace cabin air filter
___ Replace engine air filter
___ Replace engine oil and oil filter [1]
___ Replace spark plugs [4]
___ Rotate tires
___ Inspect the following:
- _ Ball joints and dust covers
- _ Brake lines and hoses
- _ Brake linings/drums and brake pads/discs [5]
- _ Drive belts
- _ Drive shaft boots
- _ Engine coolant [3]
- _ Engine valve clearance [6]
- _ Exhaust pipes and mountings
- _ Front differential oil
- _ Fuel lines and connections, fuel tank band and fuel tank vapor vent system hoses
- _ Fuel tank cap gasket
- _ Radiator and condenser
- _ Steering gear box
- _ Steering linkage and boots
- _ Transmission fluid or oil

Additional Maintenance Items for Special Operating Conditions [2]

Driving on dirt roads or dusty roads:

___ Tighten nuts and bolts on chassis and body

Dealer Service Verification: **Date:** **Mileage:**

1 Reset the oil replacement reminder light ("MAINT REQD") or the message "OIL MAINTENANCE REQUIRED" on the multi-information display after engine oil replacement.
2 Perform these service items only if you drive primarily under the conditions indicated.
3 Refer to "Engine Coolant" in the "Explanation of Maintenance Items" section in the back of this guide for more information.
4 Maintenance services of spark plugs are required under the terms of the Emissions Control Warranty.
5 Inspect thickness measurement and disc runout.
6 Check for tappet noise and engine vibration and adjust if necessary.

EXPLANATION OF MAINTENANCE ITEMS

The following descriptions are provided to give you a better understanding of the maintenance items that should be performed on your vehicle. The scheduled maintenance log indicates at which mileage/ time intervals each item should be performed. Please note that many maintenance items should be performed only by a qualified technician.

For further information on maintenance items you can perform yourself, see the "Vehicle Maintenance and Care" and "Do-It-Yourself Maintenance" sections of the *Owner's Manual*.

Ball Joints and Dust Covers

Check the suspension and steering linkage ball joints for looseness and damage. Check all dust covers for deterioration and damage. Replace any deteriorated or damaged parts. A qualified technician should perform these operations.

Brake Lines and Hoses

Visually inspect for proper installation. Check for chafing, cracks, deterioration and signs of leakage. Replace any deteriorated or damaged parts. A qualified technician should perform these operations.

Brake Linings/Drums and Brake Pads/Discs

Check the brake linings (shoes) and drums for scoring, burning, fluid leakage, broken parts and excessive wear. Check the pads for excessive wear and the discs for runout, excessive wear and fluid leakage. Replace any deteriorated or damaged parts. A qualified technician should perform these operations.

Cabin air filter

Replace at specified intervals. Driving in heavy traffic, on dirt roads or in urban, desert or dusty areas may shorten filter's life. More frequent replacement may be necessary.

Differential Oil

When performing inspections, check each component for signs of leakage. If you discover any leakage, have it repaired by a qualified technician immediately.

Drive Belts

Inspect for cracks, excessive wear and oiliness. Check the belt tension and adjust if necessary. Replace the belts if they are damaged.

EXPLANATION OF MAINTENANCE ITEMS

Drive Shaft Boots

Check the drive shaft boots and clamps for cracks, deterioration and damage. Replace any deteriorated or damaged parts and, if necessary, repack the grease. A qualified technician should perform these operations.

Engine Air Filter

Replace at specified intervals. When performing inspections, check for damage, excessive wear and oiliness, and replace if necessary.

Engine Coolant

Drain the cooling system and refill with an ethylene-glycol type coolant. Inspect the radiator, condenser and/or intercooler for leaves, dirt and insects, and clean if necessary. Inspect hoses and connections for corrosion and leaks. Tighten connections and replace parts as necessary. A qualified technician should perform these operations. (For further details, refer to "Radiator, Condenser and Hoses" in the "Vehicle Maintenance and Care" section of the *Owner's Manual*.)

Note: Your Scion is equipped with Genuine Toyota Super Long-Life Coolant. The replacement intervals for engine coolant recommended in this booklet are based on replacement with Genuine Toyota Super Long-Life Coolant or similar high-quality non-silicate, non-amine, non-borate ethylene-glycol coolant with long-life hybrid organic acid technology (i.e., a combination of low phosphates and organic acids). If another type of ethylene-glycol coolant is used, replacement intervals may be different.

Engine Oil and Oil Filter

Replace the oil filter and drain and refill the engine oil at specified intervals. For recommended oil grade and viscosity, refer to the *Owner's Manual*.

Engine Valve Clearance

Check for tappet noise and engine vibration and adjust if necessary. A qualified technician should perform this operation.

Exhaust Pipes and Mountings

Visually inspect the exhaust pipes, muffler and hangers for cracks, deterioration and damage. Start the engine and listen carefully for any exhaust gas leakage. Tighten connections or replace parts as necessary.

EXPLANATION OF MAINTENANCE ITEMS

Fuel Lines and Connections, Fuel Tank Band and Fuel Tank Vapor Vent System Hoses

Visually inspect for corrosion, damage, cracks and loose or leaking connections. Tighten connections or replace parts as necessary.

Fuel Tank Cap Gasket

Visually inspect for cracks, deterioration and damage and replace if necessary.

Nuts and Bolts on Chassis and Body

Re-tighten the seat-mounting bolts and front/rear suspension member retaining bolts to specified torque.

Radiator and Condenser

Inspect for damage, debris, dirt, insects and signs of leakage. Have any problem repaired by a qualified technician.

Spark Plugs

Replace at specified intervals. Install new plugs of the same type as originally equipped. A qualified technician should perform this operation.

Steering Gear Box

Inspect for signs of leakage. If you discover any leakage, have it repaired immediately by a qualified technician.

Steering Linkage and Boots

With the vehicle stopped, check for excessive freeplay in the steering wheel. Inspect the linkage for bending and damage and the dust boots for deterioration, cracks and damage. Replace any damaged parts. A qualified technician should perform these operations.

Tire Rotation

Tires should be rotated according to the instructions in the *Owner's Manual*. When rotating tires, check for damage and uneven wear. Replace if necessary.

Transmission Fluid or Oil

When performing inspections, check each component for signs of leakage. If you discover any leakage, have it repaired by a qualified technician immediately.

WWW.SCION.COM

00505-SMG09-TC
Printed in U.S.A. 08/08
Second Printing

FSC
Mixed Sources
Product group from well-managed forests, controlled sources and recycled wood or fibre
Cert no. SGS-COC-004569
www.fsc.org
© 1996 Forest Stewardship Council