

INSTALLATION

1. **INSTALL FRONT LICENCE PLATE MOUNTING BRACKET**
 - (a) Install the bracket with the 2 screws.
2. **INSTALL FRONT BUMPER SIDE SUPPORT LH**
 - (a) Install the side support with a screw.
3. **INSTALL FRONT BUMPER SIDE SUPPORT RH**
 - (a) Install the side support with a screw.
4. **INSTALL FOG LIGHT ASSEMBLY LH (w/ Fog Light)**
5. **INSTALL FOG LIGHT ASSEMBLY RH (w/ Fog Light)**
6. **INSTALL FRONT BUMPER HOLE COVER LH (w/o Fog Light)**
7. **INSTALL FRONT BUMPER HOLE COVER RH (w/o Fog Light)**
8. **INSTALL FRONT BUMPER SIDE MOUNTING BRACKET LH**
9. **INSTALL FRONT BUMPER SIDE MOUNTING BRACKET RH**
10. **INSTALL FRONT BUMPER REINFORCEMENT**
 - (a) Install the reinforcement with the 4 nuts.
Torque: 36 N*m (367 kgf*cm, 27 ft.*lbf)
 - (b) Install the 2 connector clamps.
11. **INSTALL FRONT BUMPER ENERGY ABSORBER**
12. **INSTALL FRONT BUMPER EXTENTION MOUNTING BRACKET**
13. **INSTALL FRONT BUMPER COVER LOWER**
 - (a) Install the cover lower with the 8 claws and 2 bolts.
14. **INSTALL FRONT BUMPER COVER**
 - (a) Install the bumper cover with the 4 screws, 3 clips and 2 bolts.
 - (b) Aero type:
Install the bumper with the 6 screws, 3 clips and 2 bolts.
Torque: 5.0 N*m (51 kgf*cm, 44 in.*lbf)
15. **INSTALL FRONT BUMPER EXTENSION LH**
16. **INSTALL FRONT BUMPER EXTENSION RH**
17. **INSTALL FRONT FENDER LINER LH**
 - (a) Install the fender liner with the 2 clips.
 - (b) Aero type:
Install the fender liner with the 4 clips.
18. **INSTALL FRONT FENDER LINER RH**
 - (a) Use the same procedures described for the LH side.