


PC-6

PAINT • COATING

BODY PANEL UNDERCOATING AREAS**HINT:**

- 1) First wipe off any dirt, grease or oil with a rag soaked in a grease, wax and silicone remover.
- 2) Cover the surrounding areas with masking paper to avoid coating unnecessary areas. If other areas are accidentally coated, wipe off the coating immediately.
- 3) Apply the first coating of undercoat to all welded areas and panel joints, then apply a second coat over the entire area.
- 4) Do not coat parts which become hot, such as the tailpipe, or moving parts, such as the propeller shaft.
- 5) Besides the locations described below, apply undercoating to all weld points under the body to insure corrosion prevention.
- 6) Be sure to seal the edge of the flange of the member and bracket with undercoating.
- 7) If undercoat is damaged by peeling, cracks, etc., be sure to repair as necessary.
- 8) Before the undercoat apply sealer allowing rust prevention to be attained.



F15672

REFERENCE

Referring to the notes above, undercoating should be applied according to the specifications for your country.


PC-8

PAINT • COATING

BODY PANEL ANTI-RUST AGENT (WAX) APPLICATION AREAS

HINT:


- 1) Whenever adjusting the doors and hoods, apply anti-rust agent (wax) around the hinges.
- 2) Even if partially repairing a part, apply anti-rust agent (wax) over the entire application area of the part.
- 3) Wipe off the anti-rust agent immediately with a rag soaked in a grease, wax and silicone remover, if accidentally applied to other areas.



F15673

BODY PANEL ANTI-CHIPPING PAINT APPLICATION AREAS

- HINT:**
- 1) Anti-chipping paint should be applied to some areas before the second coat and to others after the top coat.
 - 2) If other areas are accidentally coated, wipe off the paint immediately with a rag soaked in grease, wax and silicone remover.



F15676



PVC




Urethan

BODY PANEL SEALING AREAS

- HINT:**
- 1) Prior to applying body sealer, clean the area with a rag soaked in grease, wax and silicone remover.
 - 2) If weld-through primer was used, first wipe off any excess and coat with anti-corrosion primer before applying body sealer.
 - 3) Wipe off excess body sealer with a rag soaked in a grease, wax and silicone remover.
 - 4) If body sealer is damaged by peeling, cracks, etc., be sure to repair as necessary.


+++++	Flat Finishing	—	No Flat Finishing
-------	----------------	---	-------------------

1. ENGINE COMPARTMENT




cardiagn.com

2. INSIDE




F15668

3. DEAR LUGGAGE COMPARTMENT




cardiagn.com

4. DOOR PARTS



cardiagn.com




cardiagn.com

FOAMED MATERIAL APPLICATION AREAS


The sections shown in the figure below are filled with foamed material to provide noise insulation. After repairing these sections or their peripheries, refill with foamed materials

HINT:

- 1) Use the service holes located on the reverse side of the body panel to refill with foamed materials.
- 2) When handling foamed material, follow the directions of the material's manufacturer.



SILENCER SHEET INSTALLATION AREAS



cardiagn.com

	non-adhesive sheet				
---	--------------------	--	--	--	--

F15675