

WIRING DIAGRAMS

Fig. 7: Comb Sw, Light Sw, Defog Sw, Pwr Antenna (Grid 24-27)
1991 BMW 318 Series

