

Citroën E-Méhari (2017 – 2018) – fuse box diagram

Year of production: 2017, 2018

Passenger compartment



Citroen E-Mehari – fuse box diagram – passenger compartment

Description	Fuse rating	Protected component
F3	7.5A	Rear foglamp
F4	10A	+12V switched, brake + third brake lamps
F5	20A	+12V switched, radio – navigation screen – aerial
F6	7.5A	Left-hand brake lamp (GEN1 only)
F7	7.5A	Right-hand brake lamp (GEN1 only)
F14	5A	+12V switched, front/rear defrosting-cabin fan relay
F15	15A	12V accessory socket
F16	25A	Front wiper and screenwash (GEN1 only)
F19	7.5A	+12V BAT starting key – dashboard
F20	20A	+12V BAT radio – navigation screen – aerial
F35	7.5A	+12V switched, switch illumination – diagnostic socket

F36	5A	+12V switched, IER telemetry box
F37	5A	+12V switched, navigation screen – radio
F38	5A	+12V BAT cabin UCE (BCM) – drive selector
FA	10A	Spare fuse
FB	15A	Spare fuse
FC	20A	Spare fuse
FD	20A	Spare fuse
FE	25A	Spare fuse
FF	7.5A	Spare fuse

WARNING: Terminal and harness assignments for individual connectors will vary depending on vehicle equipment level, model, and market.