


2009 Honda Civic LX


2009 SYSTEM WIRING DIAGRAMS Honda - Civic



[Fig. 146: Remote Starting Circuit, Canada \(1 of 3\)](#)

2009 Honda Civic LX


2009 SYSTEM WIRING DIAGRAMS Honda - Civic



[Fig. 147: Remote Starting Circuit, Canada \(2 of 3\)](#)

2009 Honda Civic LX


2009 SYSTEM WIRING DIAGRAMS Honda - Civic



[Fig. 148: Remote Starting Circuit, Canada \(3 of 3\)](#)

2009 Honda Civic LX


2009 SYSTEM WIRING DIAGRAMS Honda - Civic



[Fig. 149: Starting Circuit, A/T Except Hybrid](#)

2009 Honda Civic LX


2009 SYSTEM WIRING DIAGRAMS Honda - Civic



[Fig. 150: Starting Circuit, A/T Hybrid](#)

2009 Honda Civic LX

2009 SYSTEM WIRING DIAGRAMS Honda - Civic



[Fig. 151: Starting Circuit, M/T](#)

1.8L

2009 Honda Civic LX

2009 SYSTEM WIRING DIAGRAMS Honda - Civic




Fig. 152: 1.8L, Charging Circuit

2.0L

2009 Honda Civic LX

2009 SYSTEM WIRING DIAGRAMS Honda - Civic




Fig. 153: 2.0L, Charging Circuit