

Wiring System


A: SCHEMATIC S903482A21

1. LHD SOHC MODEL S903482A2121



ENGINE ELECTRICAL SYSTEM


Wiring System



SL10-20B

ENGINE ELECTRICAL SYSTEM


Wiring System



SL10-20C


E/G(LWO)-04

E/G(LWO)-04



ENGINE ELECTRICAL SYSTEM

Wiring System




B: B135

1	2	3		4	5	6	7
8	9	10	11	12	13	14	15
16	17	18	19	20	21	22	23
24	25	26	27	28			

SL10-20E

ENGINE ELECTRICAL SYSTEM


Wiring System



SL10-20F

ENGINE ELECTRICAL SYSTEM


Wiring System



SL10-20G

ENGINE ELECTRICAL SYSTEM


Wiring System



SL10-20H

ENGINE ELECTRICAL SYSTEM

Wiring System




SL10-20I

ENGINE ELECTRICAL SYSTEM

Wiring System


2. LHD SOHC W/O OBD MODEL S903482A2120



SL10-21A

ENGINE ELECTRICAL SYSTEM

Wiring System




SL10-21B

WI-116

ENGINE ELECTRICAL SYSTEM

Wiring System




SL10-21C

ENGINE ELECTRICAL SYSTEM

Wiring System

E/G(LOO)-04

E/G(LOO)-04




Wiring System



ENGINE ELECTRICAL SYSTEM


Wiring System



SL10-21F

ENGINE ELECTRICAL SYSTEM


Wiring System



SL10-21G

ENGINE ELECTRICAL SYSTEM


Wiring System



SL10-21H

ENGINE ELECTRICAL SYSTEM

Wiring System




SL10-211

ENGINE ELECTRICAL SYSTEM

Wiring System


3. LHD DOHC TURBO MODEL S903482A2122



SL10-22A

ENGINE ELECTRICAL SYSTEM


Wiring System



SL10-22B

ENGINE ELECTRICAL SYSTEM


Wiring System



SL10-22C



E/G(LTB)-04

E/G(LTB)-04



ENGINE ELECTRICAL SYSTEM


Wiring System



SL10-22E

ENGINE ELECTRICAL SYSTEM


Wiring System



SL10-22F










ENGINE ELECTRICAL SYSTEM

Wiring System



ENGINE ELECTRICAL SYSTEM


Wiring System



SL10-22H


ENGINE ELECTRICAL SYSTEM

Wiring System




SL10-221

Wiring System



ENGINE ELECTRICAL SYSTEM


Wiring System




SL10-22K

Wiring System


E/G(RWO)-01



Wiring System



Wiring System




ENGINE ELECTRICAL SYSTEM

Wiring System

E/G(RWO)-04


E/G(RWO)-04



SR10-20D

ENGINE ELECTRICAL SYSTEM

Wiring System




B: B135

1	2	3			4	5	6	7
8	9	10	11	12	13	14	15	16
17	18	19	20	21	22	23	24	25
26	27	28						

SR10-20E

ENGINE ELECTRICAL SYSTEM


Wiring System



SR10-20F

ENGINE ELECTRICAL SYSTEM


Wiring System



SR10-20G

ENGINE ELECTRICAL SYSTEM


Wiring System



SR10-20H

ENGINE ELECTRICAL SYSTEM

Wiring System




SR10-20I

ENGINE ELECTRICAL SYSTEM

Wiring System


5. RHD SOHC W/O OBD MODEL S903482A2123



SR10-21A

ENGINE ELECTRICAL SYSTEM


Wiring System



SR10-21B

ENGINE ELECTRICAL SYSTEM


Wiring System



SR10-21C


E/G(ROO)-04

E/G(ROO)-04



ENGINE ELECTRICAL SYSTEM


Wiring System



SR10-21E

ENGINE ELECTRICAL SYSTEM


Wiring System



SR10-21F

ENGINE ELECTRICAL SYSTEM

Wiring System




SR10-21G

WI-150

ENGINE ELECTRICAL SYSTEM


Wiring System



SR10-21H

ENGINE ELECTRICAL SYSTEM

Wiring System




SR10-211

ENGINE ELECTRICAL SYSTEM

Wiring System


6. RHD DOHC TURBO MODEL S903482A2125



SR10-22A

ENGINE ELECTRICAL SYSTEM


Wiring System



SR10-22B

ENGINE ELECTRICAL SYSTEM

Wiring System




SR10-22C

ENGINE ELECTRICAL SYSTEM

Wiring System


E/G(RTB)-04

E/G(RTB)-04



ENGINE ELECTRICAL SYSTEM

Wiring System




A: (B134)

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16	17	18	19	20	21
22						

SR10-22E

ENGINE ELECTRICAL SYSTEM


Wiring System



SR10-22F


ENGINE ELECTRICAL SYSTEM

Wiring System



ENGINE ELECTRICAL SYSTEM


Wiring System



SR10-22H

ENGINE ELECTRICAL SYSTEM


Wiring System



SR10-221

ENGINE ELECTRICAL SYSTEM


Wiring System



SR10-22J

ENGINE ELECTRICAL SYSTEM

Wiring System



SR10-22K