



2012 Audi Q7

Quick Reference Guide

Vorsprung durch Technik **Audi** 

This Quick Reference Guide provides you with a brief overview of selected procedures and functions in your vehicle. It does not replace the Owner's Manual with its important explanations and warnings.

Cockpit

1 Release button for luggage compartment

2 Hood release

3 Parking brake

Engaging: Press the pedal firmly with your foot.

Releasing: Pull the handle 5.

4 Data Link Connector for On Board Diagnostics (OBD II)

5 Parking brake release handle

6 Adjusting the exterior mirrors

Adjust the knob:

-  Left exterior mirror
-  Heating the exterior mirror
-  Right exterior mirror
-  Folding the exterior mirror

The mirror glass moves in the direction that the knob is pressed.

7 Power windows

! WARNING

Be careful when closing the windows. Check to see that no one is in the way, or serious personal injury could result.





- 8** Memory seat buttons
- 9** Light control switch
- 10** Audi side assist button
- 11** Door handle and central locking switch
 - locked
 - unlocked
- 12** Audi side assist warning display
- 13** Cruise control or Adaptive cruise control
- 14** Multifunction steering wheel controls
- 15** Turn signal and high beam lever

- 16** Instruments and indicator lights
- 17** Windshield wiper controls and trip computer buttons
- 18** Steering wheel position adjuster

! WARNING

The column should only be adjusted when the vehicle is at a complete standstill.

- 19** Activating/deactivating parking system
- Resetting the trip odometer
- Check function
- Instrument illumination

- 20** MMI display
- 21** Switching the MMI display on/off
 - Valet key function
 - Opening the glove compartment
- 22** PASSENGER AIR BAG OFF indicator light
 - Emergency flashers
 - Electronic Stability Control (ESC)
- 23** Audi multimedia
- 24** Climate control
- 25** Automatic transmission selector lever
- 26** MMI control console
- 27** Starting the engine
 - Stopping the engine

Convenience key

Opening and closing the vehicle

With the convenience key, you can lock and unlock your vehicle without using the remote control key. You only need to carry the remote control key with you.

Unlocking the vehicle:


Grasp one of the door handles or the handle recess on the rear lid.

Locking the vehicle:

Place the selector lever in the P position.
Press the lock button **1** on one of the door handles.

Closing the rear lid automatically:

Press the  button in the open rear lid.



WARNING

When you leave the vehicle, always remove the ignition key and take it with you. This will prevent passengers (children, for example) from accidentally being locked in the vehicle should they accidentally press the power locking switch in the front doors.

WARNING

When you lock your vehicle from the outside, do not leave anyone - especially children - inside the vehicle. Remember, when you lock the vehicle from the outside the windows cannot be opened from the inside.

WARNING

Always ensure that no one is within range of the rear lid when it is moving, in particular close to the hinges - fingers or hands can be pinched.

Switching the ignition on/ starting the engine

On vehicles without convenience key, start the engine as usual using the key. On vehicles with convenience key, the engine can be started without having the remote control key inserted in the ignition lock.

Switching the ignition on: Press the START ENGINE button to the first level. With diesel engines, the system is preheating in this position.

Starting the engine: Press the brake, place the selector lever in the P or N position and press the START ENGINE button down to the second level.

Stopping the engine: Stop the vehicle, place the selector lever in the P or N position and press the STOP ENGINE button. If you press the STOP ENGINE button again for more than 1 second, the steering will lock.



Automatic transmission

Selector lever positions


- P** Park
- R** Reverse
- N** Neutral (Idle)
- D** Drive

S Sport

Releasing the selector lever lock and engaging a gear: Switch the ignition on, press the brake pedal and press the lock button on the selector lever.

Place the selector lever in the D or S position to drive forward.

tiptronic: To shift manually, move the selector lever to the right out of the D position. The driver information system displays the gears.



Shifting up/down:

Press the selector lever forward/back.

Adjusting the seats

1 Adjusting seat height and forward/back position:


- Front of the seat cushion up/down
- Back of the seat cushion up/down
- Seat up/down
- Seat forward/back

2 Adjusting the backrest:

- Backrest forward/back

3 Adjusting the lumbar support:

Press on the respective area of the switch.



Adjusting the headrests

Press the knob on the side

4 to slide it down.

Adjust the head restraint so the upper edge is as even as possible with the top of your head.



⚠ WARNING

Thoroughly review your Owner's Manual for warnings and other important information about proper restraint use and what you can do to reduce the risk of injury in accidents. Failure to properly use restraint systems can cause serious personal injury.

⚠ WARNING

Never install rear facing child seats or infant carriers on the passenger seat. A child will be seriously injured or killed when the passenger airbag inflates.

⚠ WARNING

Always fasten safety belts before driving off. Always make sure passengers are properly restrained. Children 12 years old and younger must ride in the rear seat and be properly restrained as indicated in the Owner's Manual. The airbag is supplemental and does not replace safety belt use.

⚠ WARNING

Front seat passengers must never ride in a moving vehicle with the seatback reclined. The risk of personal injury increases with increasing rearward angle of the seatback. Safety belts only offer protection when the seatback is upright and belts are properly positioned on the body. Adjust your seats only when the vehicle is at a complete standstill.

⚠ WARNING

The airbag system cannot protect you properly if you are seated too close to any of the airbag locations. When adjusting their seat positions, it is important that both the driver and front passenger keep their upper bodies at a minimum safe distance of 10 inches (25 cm) between the chest and the steering wheel/instrument panel.

Climate control



Left switch - driver's side

Right switch - passenger's side

Rotary switch: Temperature selection

AUTO **Automatic mode:** Set the desired temperature and press the button.

ON/OFF **Switching on/off**

AC **Switch the air conditioning system on/off**

Fan speed

Air distribution

Heated seats

Ventilated seats

Defrost

Manual recirculation

Heated rear window

Panoramic sliding sunroof

Both sections of the roof are opened/closed separately when the ignition is switched on.

Opening/closing the front section:

Comfort position: Rotate the switch **A** to **1**.

Opening: Rotate the switch in the direction **2** until the desired position is reached.

Closing: Rotate the switch to **0**.

Tilting/closing the front segment:

Briefly press/pull the switch **A** into the **0** position. Press/pull longer to adjust the tilt height individually.

Tilting/closing the rear segment:

Briefly press the corresponding symbol on the rocker switch **B** or the button in the rear of the headliner. Press the rocker switch **B** longer to adjust the tilt height individually.

Front sunshade:

Opening: Press the  symbol in the switch **C** briefly.

Closing: Press the  symbol in the switch **C** briefly.




WARNING

Be careful when closing the panoramic sliding sunroof. Check to see that no one is in the way, or serious personal injury could result.

⚠ WARNING

Improper use of the adaptive cruise control can cause collisions, other accidents and serious personal injury. Always read and heed the Warnings in the Owner's Manual.

Adaptive cruise control



The adaptive cruise control is a combined cruise control and distance regulation system.

Switching on/off: Pull/press the lever **3**.

Storing the speed: Press the button **1**.

Changing the stored speed:

Press the lever **3** up (faster) or down (slower).

Increasing/decreasing the distance:

Press the switch **2** to the right/left.

Fuel filler flaps

Opening: Press the left side of the fuel filler flap.

Closing: Press the fuel filler flap in until it latches.




Fuel filler flap
(Gasoline engine)



Fuel filler flap (Diesel engine)

Filler openings:

- A Diesel**
- B AdBlue** (see chapter "Selective catalytic reduction")



Fuel recommendation

Gasoline	Unleaded premium grade gasoline only (minimum 91 AKI, 95 RON)
Diesel	ULSD-Diesel No. 2 only

Engine oil specifications

If you must add oil, only use oil that conforms to Audi oil standards.

Gasoline engine	VW 502 00 only
Diesel engine	VW 507 00 only

Refer to the "Checking and filling" chapter for more information.



Tire pressures

The label with the correct tire pressures is located on the driver's door pillar.

Multi Media Interface

MMI components

1 Driver information system

2 Multifunction steering wheel

Roll the **left thumbwheel** to select a menu item in the driver information system. Press the thumbwheel to confirm the menu item.

Press the **MODE button** to switch between the active radio source, navigation system and telephone.

Press the **voice recognition button** briefly to activate the voice recognition system. After the <Beep>, you can say the desired commands.

To deactivate, press and hold the **voice recognition button** until you hear the message <Cancel>.

Press the **NAV button** to repeat the last navigation announcement.


Roll the **right thumbwheel** to control the volume.


3 MMI display

 **WARNING**

Distraction causes accidents:

- Never enter data while driving!
- Obey traffic laws & road signs!
- Refer to the Owner's Manual!






- 4 **MMI display on/off**
- 5 **On/Off button**
Switching on/off: Press briefly/press and hold.
Adjusting the volume: Turn.
Mute: Press briefly.
- 6 **Function buttons**
 Call up main functions such as **MEDIA**.
- 7 **Arrow buttons**
Press briefly: Previous/next radio station, select track.
Press and hold: Fast forward/rewind.
- 8 **Button **BACK****
 Cancel the selection/go back to the function above.
- 9 **Control knob**
To select a menu item: Turn the knob.
To confirm your selection: Press the knob.
- 10 **Control buttons**
 Activate the functions currently shown in the corners of the MMI display.
- 11 **Joystick**
 To move the crosshairs in a map view (navigation) or to control the DVD menu.


MMI operation

The MMI is operated the same way in all functions.



- A **Calling up menus in the display corners:** Press the appropriate button.
- B **Selecting:** Turn the knob.
- C **Confirming:** Press the knob.

Storing a radio station



1 Press the **RADIO** function button.



2 Turn the control knob and select the desired station.



3 Press the control knob to confirm.



4 Press the "Presets" control button.
5 Turn the control knob and select "Store <station name>".



6 Press the control knob. The next free memory preset is selected.



7 Turn the control knob and select the desired preset.
8 Press the control knob to confirm.



- 1 Press the **NAV** function button.
- 2 Press the “Destination” control button.



- 3 Turn/press the control knob to select/confirm the “Address” menu.



- 4 Turn/press the control knob to select/confirm the “City/ZIP code” menu item.



- 5 Turn/press the control knob to select/confirm the first letter of the destination. Enter the remaining letters of the destination using the same procedure until the desired location name is displayed.



- 6 Press/hold the control knob longer when the city appears in the list.
- 7 Turn/press to select the city and enter detailed destination information if necessary.



- 8 Select the menu item “Start route guidance”.
- 9 Press the control knob to confirm. The route is calculated.

Driver assistance systems



Use the **CAR** button to adjust or operate many driver assistance systems in your Audi. For detailed information on this, please see your vehicle Owner's Manual.

Establishing a Bluetooth™ Connection for Cell Phones and Bluetooth™ audio players

Requirements: The vehicle must be stationary. The ignition, MMI and cell phone/Bluetooth audio player must be switched on. Switch on the "Bluetooth" and "Bluetooth audio player" menus in the MMI Bluetooth settings. Activate "Bluetooth" and "Visible mode" on the cell phone/Bluetooth audio player.





Pairing a cell phone:

- Press the **TEL** function button on the MMI.
- Select the "Search for new cell phone" menu item and confirm.
- Select your Bluetooth cell phone in the display and confirm.
- Select the "Handsfree" menu item and confirm your selection.
- Confirm the PIN displayed with "Yes" and enter the PIN in your cell phone.
- Confirm the connection in your cell phone too when requested.

Pairing an Bluetooth audio player:

- Press the **MEDIA** function button on the MMI.
- Press the "Source" control button.
- Select the "Bluetooth audio player" menu item and confirm your selection. A message appears indicating that no players are paired with the MMI.
- Press the control knob to begin the search.
- Select your Bluetooth audio player in the display and confirm your selection.
- Press the control knob to confirm the Bluetooth audio player profile.
- Confirm the PIN displayed with "Yes" and enter the PIN in your Bluetooth audio player.
- Confirm the connection in your Bluetooth audio player too when requested.

For additional information on indicator lights, refer to your vehicle Owner's Manual.


 EPC	Electronic power control		Turn signals/ Emergency flasher		High beam	 PARK BRAKE	Parking brake (USA)	 BRAKE	Brake malfunction (USA)
	Glow plug system (Diesel only)		Trailer turn signal assembly		Tire pressure low (check immediately)		Parking brake (CAN)		Brake malfunction (CAN)
	Electronic Stability Control (ESC)		Malfunction Indicator Lamp	 CRUISE	Cruise control activated (USA)		Open road (adaptive cruise control)		Cooling system malfunction
	Electronic Stability Control (ESC)		Adaptive Air Suspension		Cruise control activated (CAN)		Driving in traffic (adap- tive cruise control)		Engine oil pressure too low
 AIR BAG	Safety systems (USA)		Adaptive Air Suspension	 ABS	Anti-lock brake system (USA)		Request for driver to assume control (adap- tive cruise control)	 AdBlue	Refill AdBlue (Diesel only)
	Safety systems (CAN)		Safety belt	 (ABS)	Anti-lock brake system (CAN)		Alternator malfunction	 AdBlue	AdBlue malfunction (Diesel only)
									Steering defective
									Ignition switch defective

© 2011 AUDI AG

Audi is constantly improving their products. Modifications in form, equipment, and technology are possible. No legal commitment is implied by the information, illustrations, and descriptions in this Quick Reference Guide. Reprinting, reproduction or translation, in whole or in part, is not permitted without written permission from Audi of America, Inc. Reprinting, reproduction or translation, in whole or in part, is not permitted without written permission from Audi of America, Inc. Subject to modification without notice. Concept and design: Pfriemer GmbH. Printed in Germany.

Indicator lights

Audi Q7
Kurzanleitung
Nordamerika
Englisch 11.2011
122.562.4L0.21



1225624L021

www.audi.com