




CYLINDER HEAD (for Bank 1 2WD)

COMPONENTS






N*m (kgf*cm, ft*lbf) : Specified torque



N*m (kgf*cm, ft*lbf) : Specified torque ← MP grease


Y

MANIFOLD STAY




- Non-reusable part



Y



EM




Y



N*m (kgf*cm, ft*lb) : Specified torque


Y


A113585E01





N*m (kgf*cm, ft*lbf) : Specified torque

● Non-reusable part









● Non-reusable part

N*m (kgf*cm, ft*lbf) : Specified torque