




FAN

INSPECTION

1. INSPECT FLUID COUPLING ASSEMBLY

- (a) Check the fluid coupling for damage and silicon oil leakage.
If necessary, replace the fluid coupling.